

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.



User's Manual

ID850NW Ver. 3.00, 3.10

Integrated Debugger

Operation

Target Device
V850 Series

Document No. U17369EJ1V0UM00 (1st edition)

Date Published June 2005 CP(K)

© NEC Electronics Corporation 2005

Printed in Japan

[MEMO]

Windows and Windows NT are either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

• **The information in this document is current as of June, 2005. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.**

• No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.

• NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.

• Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.

• While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.

• NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC Electronics product in your application, please contact the NEC Electronics office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

[GLOBAL SUPPORT]

<http://www.necel.com/en/support/support.html>

NEC Electronics America, Inc. (U.S.)
Santa Clara, California
Tel: 408-588-6000
800-366-9782

NEC Electronics (Europe) GmbH
Duesseldorf, Germany
Tel: 0211-65030

NEC Electronics Hong Kong Ltd.
Hong Kong
Tel: 2886-9318

- **Sucursal en España**
Madrid, Spain
Tel: 091-504 27 87

- **Succursale Française**
Vélizy-Villacoublay, France
Tel: 01-30-67 58 00

- **Filiale Italiana**
Milano, Italy
Tel: 02-66 75 41

- **Branch The Netherlands**
Eindhoven, The Netherlands
Tel: 040-265 40 10

- **Tyskland Filial**
Taeby, Sweden
Tel: 08-63 87 200

- **United Kingdom Branch**
Milton Keynes, UK
Tel: 01908-691-133

NEC Electronics Hong Kong Ltd.
Seoul Branch
Seoul, Korea
Tel: 02-558-3737

NEC Electronics Shanghai Ltd.
Shanghai, P.R. China
Tel: 021-5888-5400

NEC Electronics Taiwan Ltd.
Taipei, Taiwan
Tel: 02-2719-2377

NEC Electronics Singapore Pte. Ltd.
Novena Square, Singapore
Tel: 6253-8311

J05.6

[MEMO]

PREFACE

Target Readers	This manual is intended for user engineers who design and develop application systems of the V850 Series.																				
Purpose	This manual is intended for users to understand the functions of the ID850NW in the organization below.																				
Organization	<p>This manual consists of the following chapters:</p> <ul style="list-style-type: none">• OVERVIEW• INSTALLATION• STARTING AND TERMINATING• ASSOCIATION WITH PM+• DEBUG FUNCTIONS• WINDOW REFERENCE• COMMAND REFERENCE																				
How to Use This Manual	<p>It is assumed that the readers of this manual have general knowledge of electrical engineering, logic circuits, microcontrollers, C language, and assemblers.</p> <p>To understand the functions of the V850 Series → Refer to Hardware User's Manual for each product..</p> <p>To understand the instruction functions of the V850 Series → Refer to V850ES Architecture User's Manual (U15943E) or V850E1 Architecture User's Manual (U14559E).</p>																				
Conventions	<table><tr><td>Data significance:</td><td>Higher digits on the left and lower digits on the right</td></tr><tr><td>Note:</td><td>Footnote for item marked with Note in the text</td></tr><tr><td>Caution:</td><td>Information requiring particular attention</td></tr><tr><td>Remark:</td><td>Supplementary information</td></tr><tr><td>Numerical representation:</td><td>Binary ... XXXX or XXXXB</td></tr><tr><td></td><td>Decimal ... XXXX</td></tr><tr><td></td><td>Hexadecimal ... 0XXXXX</td></tr><tr><td>Prefix indicating the power of 2 (address space, memory capacity):</td><td></td></tr><tr><td></td><td>K (Kilo): $2^{10} = 1024$</td></tr><tr><td></td><td>M (Mega): $2^{20} = 1024^2$</td></tr></table>	Data significance:	Higher digits on the left and lower digits on the right	Note:	Footnote for item marked with Note in the text	Caution:	Information requiring particular attention	Remark:	Supplementary information	Numerical representation:	Binary ... XXXX or XXXXB		Decimal ... XXXX		Hexadecimal ... 0XXXXX	Prefix indicating the power of 2 (address space, memory capacity):			K (Kilo): $2^{10} = 1024$		M (Mega): $2^{20} = 1024^2$
Data significance:	Higher digits on the left and lower digits on the right																				
Note:	Footnote for item marked with Note in the text																				
Caution:	Information requiring particular attention																				
Remark:	Supplementary information																				
Numerical representation:	Binary ... XXXX or XXXXB																				
	Decimal ... XXXX																				
	Hexadecimal ... 0XXXXX																				
Prefix indicating the power of 2 (address space, memory capacity):																					
	K (Kilo): $2^{10} = 1024$																				
	M (Mega): $2^{20} = 1024^2$																				

Related Documents

Refer to the documents listed below when using this manual.

The related documents indicated in this publication may include preliminary versions.

However, preliminary versions are not marked as such.

Documents related to development tools (User's Manuals)

Document Name		Document No.
IE-70000-MC-NW-A In-circuit emulator		U16348E
CA850 Ver. 3.00 C Compiler Package	Operation	U17293E
	C Language	U17291E
	Assembly Language	U17292E
	Link Directives	U17294E
PM+ Ver. 6.00 Project Manager		U17178E
ID850NW Ver. 3.00, 3.10 Integrated Debugger	Operation	This manual
SM+ System Simulator	Operation	U17246E
	User Open Interface	U17247E
SM850 Ver. 2.50 System Simulator	Operation	U16218E
SM850 Ver. 2.00 or Later System Simulator	External Part User Open Interface Specifications	U14873E
RX850 Ver. 3.20 Real-Time OS	Basics	U13430E
	Installation	U17419E
	Technical	U13431E
	Task Debugger	U17420E
RX850 Pro Ver. 3.20 Real-Time OS	Basics	U13773E
	Installation	U17421E
	Technical	U13772E
	Task Debugger	U17422E
AZ850 Ver. 3.30 System Performance Analyzer		U17423E
PG-FP4 Flash Memory Programmer		U15260E
TW850 Ver. 2.00 Performance Analysis Tuning Tool		U17241E

CONTENTS

CHAPTER 1 OVERVIEW ...	16
1.1 Features ...	17
1.1.1 New functions, enhanced functions ...	17
1.1.2 Other Functions ...	18
1.2 System Configuration ...	19
1.3 Operating Environment ...	20
1.3.1 Hardware environment ...	20
1.3.2 Software environment ...	21
1.3.3 Cautions regarding connecting to Midas Lab emulators ...	22
1.4 Cautions During Debugging ...	23
1.4.1 When performing source level debugging ...	23
CHAPTER 2 INSTALLATION ...	24
2.1 Installing ...	24
2.2 Uninstalling ...	24
CHAPTER 3 STARTING AND TERMINATING ...	25
3.1 Startup Option and Argument Specification ...	25
3.1.1 Specification method ...	26
3.1.2 Specification format and options ...	27
3.2 Starting ...	28
3.3 Terminating ...	29
CHAPTER 4 ASSOCIATION WITH PM+ ...	30
4.1 Setting Build Mode ...	30
4.2 Registering Debugger to PM+ Project ...	31
4.2.1 Selecting debugger ...	31
4.2.2 Downloading multiple load module files ...	32
4.3 To Start ID850NW from PM+ ...	33
4.3.1 Restoring debugging environment ...	33
4.4 Auto Load ...	34
4.4.1 Auto load by correcting source code ...	34
4.4.2 Auto load by starting debugger ...	35
CHAPTER 5 DEBUG FUNCTIONS ...	36
5.1 Setting Debugging Environment ...	37
5.1.1 Setting operating environment ...	37
5.1.2 Setting option ...	37
5.1.3 Setting mapping ...	37
5.2 Download Function, Upload Function ...	39
5.2.1 Download ...	39
5.2.2 Upload ...	40
5.3 Source Display, Disassemble Display Function ...	41
5.3.1 Source display ...	41
5.3.2 Disassemble display ...	41
5.3.3 Mixed display mode (Source Window) ...	42
5.3.4 Convert symbol (symbol to address) ...	43
5.4 Break Function ...	44
5.4.1 Break types ...	44
5.4.2 Breakpoint setting ...	45
5.4.3 Setting breaks to variables ...	46
5.4.4 Hardware break and software break ...	47
5.5 Program Execution Function ...	48
5.6 Watch Function ...	50
5.6.1 Displaying and changing data values ...	50
5.6.2 Displaying and changing local variable values ...	51
5.6.3 Registering and deleting watch data ...	51

5.6.4	Changing watch data ...	52
5.6.5	Temporarily displaying and changing data values ...	52
5.6.6	Callout watch function ...	53
5.6.7	Stack trace display function ...	53
5.7	Memory Manipulation Function ...	54
5.7.1	Displaying and changing memory contents ...	54
5.7.2	Filling, copying, and comparing memory contents ...	54
5.7.3	Modifying memory contents (DMM function) ...	55
5.8	Register Manipulation Function ...	56
5.8.1	Displaying and changing register contents ...	56
5.8.2	Displaying and changing peripheral I/O registers contents ...	56
5.8.3	Displaying and changing I/O port contents ...	57
5.9	Trace Function ...	58
5.9.1	Trace memory ...	58
5.9.2	Setting trace data ...	59
5.9.3	Checking Trace Data ...	60
5.9.4	Mixed display mode (Trace View Window) ...	60
5.9.5	Tracer Operation ...	61
5.9.6	Setting conditional trace ...	62
5.10	Event Function ...	63
5.10.1	Using event function ...	63
5.10.2	Creating events ...	64
5.10.3	Setting event conditions ...	64
5.10.4	Number of enabled events for each event condition ...	66
5.10.5	Managing events ...	67
5.11	RRM Function ...	68
5.11.1	Real-time RAM monitor function ...	68
5.11.2	RAM monitor function ...	68
5.12	Load/Save Function ...	69
5.12.1	Debugging environment (project file) ...	69
5.12.2	Window display information (view file) ...	71
5.12.3	Window setting information (setting file) ...	72
5.13	Functions Common to Each Window ...	73
5.13.1	Active status and static status ...	73
5.13.2	Jump function ...	74
5.13.3	Trace Result with Linking Window ...	76
5.13.4	Drag & drop function ...	77
CHAPTER 6 WINDOW REFERENCE ... 80		
6.1	Window List ...	81
6.2	Explanation of Windows ...	83
	Main Window ...	84
	Configuration Dialog Box ...	95
	Extended Option Dialog Box ...	99
	Trace Option Dialog Box ...	102
	Debugger Option Dialog Box ...	105
	Project File Save Dialog Box ...	111
	Project File Load Dialog Box ...	113
	Download Dialog Box ...	115
	Upload Dialog Box ...	118
	Load Module List Dialog Box ...	120
	Source Window ...	122
	Source Search Dialog Box ...	127
	Source Text Move Dialog Box ...	129
	Assemble Window ...	131
	Assemble Search Dialog Box ...	136
	Address Move Dialog Box ...	138
	Symbol To Address Dialog Box ...	139
	Watch Window ...	141
	Quick Watch Dialog Box ...	147
	Add Watch Dialog Box ...	150
	Change Watch Dialog Box ...	153
	Local Variable Window ...	155

Stack Window ...	157
Memory Window ...	160
Memory Search Dialog Box ...	163
Memory Fill Dialog Box ...	165
Memory Copy Dialog Box ...	167
Memory Compare Dialog Box ...	169
Memory Compare Result Dialog Box ...	171
DMM Dialog Box ...	172
Register Window ...	174
Register Select Dialog Box ...	177
IOR Window ...	179
IOR Select Dialog Box ...	183
Add I/O Port Dialog Box ...	185
Trace View Window ...	187
Trace Data Select Dialog Box ...	192
Trace Move Dialog Box ...	194
Trace Dialog Box ...	196
Delay Count Dialog Box ...	198
Software Break Manager ...	199
Event Manager ...	201
Event Dialog Box ...	206
Event Link Dialog Box ...	211
Break Dialog Box ...	214
View File Save Dialog Box ...	216
View File Load Dialog Box ...	219
Environment Setting File Save Dialog Box ...	221
Environment Setting File Load Dialog Box ...	223
Reset Debugger Dialog Box ...	225
Exit Debugger Dialog Box ...	226
About Dialog Box ...	227
Console Window ...	229
Font Dialog Box ...	230
Browse Dialog Box ...	232

CHAPTER 7 COMMAND REFERENCE ... 234

7.1 Command Line Rules ...	235
7.2 Command List ...	236
7.3 List of Variables ...	237
7.4 List of Packages ...	238
7.5 Key Bind ...	238
7.6 Expansion Window ...	238
7.7 Callback Procedure ...	239
7.8 Hook Procedure ...	240
7.9 Related Files ...	241
7.10 Cautions ...	241
7.11 Command Name ...	241
address ...	242
assemble ...	243
batch ...	244
breakpoint ...	245
cache ...	247
dbgexit ...	248
download ...	249
extwin ...	250
finish ...	251
go ...	252
help ...	253
hook ...	254
ie ...	255
inspect ...	256
jump ...	257
map ...	258
mdi ...	259

memory ...	260
module ...	261
next ...	262
refresh ...	263
register ...	264
reset ...	265
run ...	266
step ...	267
stop ...	268
upload ...	269
version ...	270
watch ...	271
where ...	272
wish ...	273
xtrace ...	274
7.12 Samples (Calculator Script) ...	275
APPENDIX A EXPANSION WINDOW ...	276
A.1 Overview ...	276
A.2 Sample Window ...	276
A.3 Activation ...	276
A.4 Explanation of Each Sample Window ...	277
List window ...	277
Grep window ...	278
RRM window ...	279
Hook window ...	280
Memory Mapped I/O window ...	282
Memory Mapped I/O dialog box ...	283
Sym Inspect window ...	284
Run Break Timer window ...	285
APPENDIX B INPUT CONVENTIONS ...	286
B.1 Usable Character Set ...	286
B.2 Symbols ...	287
B.3 Numeric Values ...	288
B.4 Expressions and Operators ...	288
B.5 File Names ...	291
APPENDIX C KEY FUNCTION LIST ...	292
APPENDIX D MESSAGES ...	295
D.1 Display Format ...	295
D.2 Types of Messages ...	295
D.3 Message Lists ...	296
APPENDIX E INDEX ...	315

LIST OF FIGURES

Figure No	Title	Page
1-1	Example of System Configuration ...	19
3-1	[Debugger Settings...] Dialog Box (PM+) ...	25
3-2	Startup Option (Example) ...	26
3-3	Configuration Dialog Box ...	28
3-4	Main Window (at Startup) ...	28
3-5	Exit Debugger Dialog Box ...	29
4-1	Downloading Multiple Files ...	32
5-1	Setting Mapping ...	37
5-2	Breakpoint Setting ...	45
5-3	Setting Break to Variable ...	46
5-4	Management of Software Breaks ...	47
5-5	Execution Button ...	48
5-6	[Run] Menu ...	48
5-7	Watch Window ...	50
5-8	Specification of the Display Format (Debugger Option Dialog Box) ...	50
5-9	Local Variable Window ...	51
5-10	Change Watch Dialog Box ...	52
5-11	Quick Watch Dialog Box ...	52
5-12	Stack Window ...	53
5-13	Displaying and Changing Memory Contents ...	54
5-14	Modifying Memory Contents (DMM Dialog Box) ...	55
5-15	Absolute Name/Function Name Switching ...	56
5-16	Displaying IOR Contents ...	56
5-17	Register I/O Port ...	57
5-18	Setting Trace Data ...	59
5-19	Checking Trace Data ...	60
5-20	Setting of Various Event Conditions ...	64
5-21	Managing Events (the Event Manager) ...	67
5-22	Setting of RRM Function (Extended Option Dialog Box) ...	68
5-23	Automatic Save/Automatic Load Setting for Project File ...	69
6-1	Main Window ...	84
6-2	Toolbar (Picture Only) ...	93
6-3	Toolbar (Picture and Text) ...	93
6-4	Status Bar ...	93
6-5	Configuration Dialog Box ...	95
6-6	Extended Option Dialog Box ...	99
6-7	Trace Option Dialog Box ...	102
6-8	Debugger Option Dialog Box ...	105
6-9	Add Source Path Dialog Box ...	107
6-10	Project File Save Dialog Box ...	111
6-11	Project File Load Dialog Box ...	113
6-12	Download Dialog Box ...	115
6-13	The Progress of Download ...	115
6-14	Upload Dialog Box ...	118
6-15	Load Module List Dialog Box ...	120
6-16	Source Window ...	122
6-17	Source Search Dialog Box ...	127
6-18	Source Text Move Dialog Box ...	129
6-19	Assemble Window ...	131
6-20	Assemble Search Dialog Box ...	136
6-21	Address Move Dialog Box (Example: When Memory Window Is Open) ...	138
6-22	Symbol To Address Dialog Box ...	139
6-23	Watch Window ...	141
6-24	Quick Watch Dialog Box ...	147
6-25	Add Watch Dialog Box ...	150

6-26	Change Watch Dialog Box ...	153
6-27	Local Variable Window ...	155
6-28	Stack Window ...	157
6-29	Memory Window ...	160
6-30	Memory Search Dialog Box ...	163
6-31	Memory Fill Dialog Box ...	165
6-32	Memory Copy Dialog Box ...	167
6-33	Memory Compare Dialog Box ...	169
6-34	Memory Compare Result Dialog Box ...	171
6-35	DMM Dialog Box ...	172
6-36	Register Window ...	174
6-37	Register Select Dialog Box ...	177
6-38	IOR Window ...	179
6-39	IOR Select Dialog Box ...	183
6-40	Add I/O Port Dialog Box ...	185
6-41	Trace View Window ...	187
6-42	Trace Data Select Dialog Box ...	192
6-43	Trace Move Dialog Box ...	194
6-44	Trace Dialog Box ...	196
6-45	Delay Count Dialog Box ...	198
6-46	Software Break Manager ...	199
6-47	Event Manager (In Detailed Display Mode) ...	201
6-48	Select Display Information Dialog Box ...	205
6-49	Event Dialog Box ...	206
6-50	Event Link Dialog Box ...	211
6-51	Break Dialog Box ...	214
6-52	View File Save Dialog Box ...	216
6-53	View File Load Dialog Box ...	219
6-54	Environment Setting File Save Dialog Box ...	221
6-55	Environment Setting File Load Dialog Box ...	223
6-56	Reset Debugger Dialog Box ...	225
6-57	Exit Debugger Dialog Box ...	226
6-58	About Dialog Box ...	227
6-59	Console Window ...	229
6-60	Font Dialog Box ...	230
6-61	Browse Dialog Box ...	232
7-1	Execution Screen ...	275
A-1	List Window ...	277
A-2	Grep Window ...	278
A-3	RRM Window ...	279
A-4	Hook Window ...	280
A-5	Memory Mapped I/O Window ...	282
A-6	Memory Mapped I/O Dialog Box ...	283
A-7	Sym Inspect Window ...	284
A-8	RunBreakTimer Window ...	285
D-1	Error/Warning Messages ...	295

LIST OF TABLES

Table No	Title, Page
2-1	Install ... 24
3-1	Startup Options ... 27
5-1	Debug Function List (Flow of Debugging Operations) ... 36
5-2	Type of Mapping Attribute ... 37
5-3	Type of File That Can Be Downloaded ... 39
5-4	Type of File That Can Be Uploaded ... 40
5-5	File Type Can Be Displayed ... 41
5-6	Specifying Symbols ... 43
5-7	Break Types ... 44
5-8	The Number of Valid Software Break ... 47
5-9	Type of Execution ... 48
5-10	Trace Memory Size ... 58
5-11	Types of Trace Mode ... 61
5-12	Types of Tracer Control Mode ... 61
5-13	Types of Conditional Trace ... 62
5-14	Various Event Conditions ... 63
5-15	Number of Enabled Events for Each Event Condition ... 66
5-16	Event Icon ... 67
5-17	Contents Saved to Project File ... 70
5-18	Type of the View Files ... 71
5-19	Type of the Setting Files ... 72
5-20	Details of Jump Source Address ... 74
5-21	Details of Drag & Drop Function (Line/Address) ... 77
5-22	Details of Drag & Drop Function (Character String) ... 78
6-1	Window List ... 81
6-2	CPU status ... 94
6-3	IE status ... 94
6-4	Break Cause ... 94
6-5	Trace Memory Sizes ... 100
6-6	Event Setting Status (Event Mark) ... 123
6-7	Watch Window Display Format (Symbol) ... 142
6-8	Watch Window Display Format (Data) ... 143
6-9	Watch Window Input Format ... 151
6-10	How a Variable Is Handled When a Scope Is Specified ... 151
6-11	Frame Number Specification Format ... 195
6-12	Number of Events Settable ... 197
6-13	Separator for Displaying Event Details ... 202
6-14	Status condition ... 207
6-15	Settable Range of Address Condition (Event) ... 209
6-16	Settable Range of Data Condition ... 209
6-17	Event Conditions for Which Event Link Condition Can Be Set ... 211
6-18	The Number of Event Conditions in Event Link Dialog Box ... 213
6-19	Number of Events Settable in Break Condition Setting Area ... 215
7-1	List of Debugger Control Commands ... 236
7-2	List of Console/Tcl Commands ... 237
7-3	Message ID ... 239
A-1	List of Expansion Window (Sample) ... 276
B-1	List of Character Set ... 286
B-2	List of Special Characters ... 286
B-3	Input Format of Numeric Values ... 288
B-4	List of Operators ... 289
B-5	Operator Priority ... 290
B-6	Range of Radixes ... 290
C-1	Key Function List ... 292
D-1	Types of Messages ... 295

CHAPTER 1 OVERVIEW

The Integrated Debugger ID850NW for the V850 Series (hereafter referred to as the ID850NW) is a software tool developed for NEC Electronics V850 Series of microcontrollers for embedded control. This software tool is intended to enable efficient debugging of user programs.

This chapter explains the following items regarding the ID850NW.

- [Features](#)
- [System Configuration](#)
- [Operating Environment](#)
- [Cautions During Debugging](#)

1.1 Features

The ID850NW has the following features:

- [New functions, enhanced functions](#)
- [Other Functions](#)

1.1.1 New functions, enhanced functions

(1) Enhanced command function

Script file specification is possible at ID startup (refer to "[3.1 Startup Option and Argument Specification](#)").

Testing can be done with 1 click by specifying a project file at the same time as the script file.

The Tcl/Tk core was updated to the latest version 8.4.

(2) Supports extension linear addresses

In Intel-HEX-format load-module files, 1 MB or more of addresses (extension linear addresses) can be downloaded. (Refer to "[5.2 Download Function, Upload Function](#)".)

(3) Supports multiple versions

Multiple versions of products can be installed in the same machine.

(4) Supports one-byte spaces

One-byte spaces can be used in folder names.

1.1.2 Other Functions

(1) Using function of in-circuit emulator

By using the event setting function of an in-circuit emulator, break events can be set (refer to "[5.10 Event Function](#)").

(2) Source debugging

A C source program and source program in assembly language can be debugged.

(3) Automatic display updating function when execution is stopped

If execution of the user program is stopped, the values of the window displayed on the screen are automatically updated.

(4) Saving/restoring debugging environment

The debugging environment including information on setting of breakpoints and events, downloading files, and display status and position of windows can be saved to a file (project file).

By loading this project file, the debugging environment can be restored (refer to "[5.12 Load/Save Function](#)").

(5) Function expansion through Tcl

The batch processing and hook processing, and the creation of original user custom windows are possible using the command line with Tcl/Tk (Tool Command Language) (refer to "[CHAPTER 7 COMMAND REFERENCE](#)", "[APPENDIX A EXPANSION WINDOW](#)").


(6) Function expansion through TIP or ToolLink

By associating with a task debugger (RD) and system performance analyzer (AZ) supporting TIP (Tool Interface Protocol) or ToolLink, the debugging efficiency of the user program using a real-time OS (RX) can be dramatically improved.

1.2 System Configuration

The ID850NW provides a comfortable debugging environment for the user program and target system developed for the V850 Series, by connecting the host machine and an in-circuit emulator with an interface card.

Figure 1-1 Example of System Configuration



IE-70000-MC-NW-A used for the ID850NW is an in-circuit emulator that provides debugging functions by connecting to a target board on which a V850 Series microcomputer and Nx85E core provided with a DCU (Debug Control Unit) is mounted.

1.3 Operating Environment

This section explains the following items regarding the operating environment.

- [Hardware environment](#)
- [Software environment](#)
- [Cautions regarding connecting to Midas Lab emulators](#)

1.3.1 Hardware environment

(1) Host machine

- The machine by which the target OS operates

(2) In-circuit emulator

(a) For emulators manufactured by NEC Electronics

- IE-70000-MC-NW-A

(b) For emulators manufactured by Midas Lab Inc. **[Note]**

- RTE-2000-TP
- RTE-1000-TP

[Note] The Target Devices are V850E/MA3, V850E/ME2, the NB85ET core and the NU85ET core.
(Target Kit: KIT-NB85E-TP, KIT-V850E/ME2-TP, KIT-V850E/MA3-TP, KIT-V850E/MA3-IE)
<http://www.midas.co.jp/download/english/manual.htm>

Caution When an emulator manufactured by Midas Lab Inc. is connected to the ID850NW, a DLL (Dynamic Link Library) for connection (N-EXEC for RTE) is required.
Access the URL below to download N-EXEC for RTE.
<http://www.midas.co.jp/download/english/program.htm#N-EXEC>

(3) Supported interface cards

(a) For emulators manufactured by NEC Electronics

- IE-70000-PCI-IF, IE-70000-PCI-IF-A (for PCI bus)
- IE-70000-CD-IF-A (for PCMCIA card slot)
- IE-70000-PC-IF-B,C (for ISA bus)

(b) For emulators manufactured by Midas Lab Inc.

Please inquire of the Midas Lab emulator handling shop.

(4) Supported ROM probe (option)

- EP-16000C
- EP-16384C

1.3.2 Software environment

(1) OS (any of the following)

- Windows98
- Windows2000
- Windows NT4.0
- WindowsMe
- WindowsXP

Caution Regardless of which of the OS above is used, we recommend that the latest Service Pack is installed.

(2) Device driver (Individual acquisition)

(a) For interface cards manufactured by NEC Electronics

- IE-PC Driver V4.00 or later

(b) For emulators manufactured by Midas Lab Inc.

Please inquire of the Midas Lab emulator handling shop.

(3) Device file (Individual acquisition)

- The device file of the target device to be used.

Remark This file is available from the following Web site of NEC Electronics.

http://www.necel.com/micro/index_e.html

(4) Supported tools (manufactured by NEC Electronics)

- C compiler package CA850 (Version 3.00 or later)
- Project manager PM+ (Version 6.00 or later)
- System performance analyzer AZ850 (Version 3.30 or later)
- Performance analysis tuning tool TW850 (Version 2.00 or later)

1.3.3 Cautions regarding connecting to Midas Lab emulators

When connecting an emulator manufactured by Midas Lab Inc. to the ID850NW, specify one of the startup options for the ID850NW given below.

For details on the startup options, refer to "[3.1 Startup Option and Argument Specification](#)".

Emulator that does not support the /NBT option[Note]

```
id850n32.exe /MON /EXEC:ex850rte
```

Emulator that supports the /NBT option[Note]

```
id850n32.exe /MON /EXEC:ex850rte /NBT
```

[Note] The /NBT option is an option applicable to the ID850NW whose version is 3.10 or later.

To know whether the /NBT option is supported or not, refer to the users' manuals for the emulator manufactured by Midas Lab Inc.

To know whether the /NBT option is supported or not, refer to the users' manuals for the emulator manufactured by Midas Lab Inc. For details on Midas Lab emulators, please inquire of the Midas Lab emulator handling shop.

1.4 Cautions During Debugging

The cautions to be observed during debugging are described below.

- [When performing source level debugging](#)

1.4.1 When performing source level debugging

The object file for which source level debugging is performed must include symbol information or other information for debugging (debugging information).

Therefore, perform the following processing during source file compiling.

(1) When using PM+

Specify [Debug Build] when the Build mode is selected.

(2) When using on standalone basis

Add the -g option.

CHAPTER 2 INSTALLATION

This chapter explains the following items about installation of ID850NW:

- [Installing](#)
- [Uninstalling](#)

2.1 Installing

The following items must be installed, when the ID850NW is used.

Table 2-1 Install

Item	Procedure
ID850NW system disk	Install the contents of this disk according to the automatically executed installer.
Used device file	Install this file according to the DFINST.exe dedicated startup installer by selecting [Start] menu -> [Program] -> [NEC Electronics Tools] -> [Device File Installer].
The device driver for interface board	In accordance with instruction of the "Readme-e.txt" in the "IE-PC Driver Installation Disk"

2.2 Uninstalling

Perform uninstallation using [Add/Remove Programs] on the Control Panel.

CHAPTER 3 STARTING AND TERMINATING

This chapter explains the following items related to the starting and terminating the ID850NW:

- [Startup Option and Argument Specification](#)
- [Starting](#)
- [Terminating](#)

3.1 Startup Option and Argument Specification


The procedure for specifying the startup options and arguments for the ID850NW is described below.

By specifying the startup options and arguments, it is possible to specify the script file at startup and the project file.

Remark For startup options used when Midas Lab emulators are connected to the ID850NW, refer to "[1.3.3 Cautions regarding connecting to Midas Lab emulators](#)".

Remark When starting up the ID850NW from PM+, the startup option and argument settings are performed in [Debugger Settings...] in the [Tool] menu of PM+ (refer to "[CHAPTER 4 ASSOCIATION WITH PM+](#)"). The debugger startup option can be set to the option column.

Figure 3-1 [Debugger Settings...] Dialog Box (PM+)




3.1.1 Specification method

- 1) Create an ID850NW shortcut on the desktop.

The ID850NW execution file (id850n32.exe) is located in the bin folder in the folder to which the installation was performed.

- 2) Open the properties of the created shortcut and after the execution file name displayed in [Target:], specify the option and argument (refer to "3.1.2 Specification format and options").

Figure 3-2 Startup Option (Example)



3.1.2 Specification format and options

(1) Specification format

```
id850n32.exe ?options?
id850n32.exe ?options? project
```

Each option and argument is separated by a space. No distinction is made between uppercase and lowercase in the character string.

Arguments enclosed between '?' can be omitted.

When a project file is specified, that project file is read at startup.

However, during PM+ startup, the project file specification is ignored.

When there are spaces in the file names and paths, specify the project file names and script file names enclosed in double quotation marks (" "). (Refer to " [Example 3\) Specification when there are spaces in the path](#)".)

(2) Specification options

The following options can be specified.

Table 3-1 Startup Options

Options	Meaning
/SC	Change background color of window to system color.
/SCRIPT: <i>script file name</i>	Specify the script file to be executed at startup.

(3) Specification example

Example 1) Specification of script file only

```
id850n32.exe /script:c:\work\script.tcl
```

Example 2) Specification of script file and project file

```
id850n32.exe /script:c:\work\script.tcl c:\work\project.prj
```

Example 3) Specification when there are spaces in the path

```
id850n32.exe /script:"c:\work folder\script.tcl" "c:\work folder\project.prj"
```

Caution Make the script file (*.tcl file) name excluding the extension different from the load module file name and project file name.

In the case of this example, do not place a file named project.tcl in c:\work (or c:\work folder).

3.2 Starting


- 1) Start ID850NW from the [Start] menu of PM+ or by clicking the shortcut created on the desktop.
Refer to "4.3 To Start ID850NW from PM+" when starting from PM+.
Start the ID850NW, the [Configuration Dialog Box](#) will be opened.

Figure 3-3 Configuration Dialog Box



- 2) Set the items related to the operating environment of the ID850NW in the [Configuration Dialog Box](#). After setting each item, click the <OK> button in the dialog box.
- 3) The [Main Window](#) will be opened and the ID850NW can be operated. Mainly use this window for debugging.


Figure 3-4 Main Window (at Startup)



3.3 Terminating

- 1) Select [File] menu -> [Exit] on the [Main Window](#). The following the [Exit Debugger Dialog Box](#) will be opened:
(An execution stop confirmation message is displayed when stop operation is performed during program execution.)

Figure 3-5 Exit Debugger Dialog Box



- 2) To save the current debugging environment to a project file, click the <Yes> button. If the <No> button is clicked, all the windows are closed the ID850NW terminated.

CHAPTER 4 ASSOCIATION WITH PM+

The ID850NW can automatically perform a series of operations in development processes, such as creating source files -> compiling -> debugging -> correcting source files, in association with the PM+.

This chapter explains the following items related to association with the PM+.

For details of the PM+ functions, refer to the PM+ User's Manual.

- [Setting Build Mode](#)
- [Registering Debugger to PM+ Project](#)
- [To Start ID850NW from PM+](#)
- [Auto Load](#)

Caution If a load module file is created by using the Windows command prompt, the function to associate the ID850NW with the PM+ cannot be used.

4.1 Setting Build Mode

To debug the load module file created by the PM+ on the ID850NW at the source level, build to output symbol information for debugging must be performed to create a load module file. This setting can be performed by selecting [Debug Build] on the PM+.

4.2 Registering Debugger to PM+ Project

The debugger to be used or the load module files to be downloaded can be specified for each project in the PM+.

4.2.1 Selecting debugger

The procedure for selecting the debugger is as follows:

The ID850NW is registered as the debugger of the active project. The ID850NW icon is displayed on the tool bar of the PM+.

(1) Creating a new workspace

- 1) Select [File] menu -> [New Workspace...] on the PM+.
-> This opens the dialog box to create a new workspace using the wizard format.
- 2) Creating the necessary settings for the workspace with the wizard, the [Select Debugger] dialog box will be opened. Specify ID850NW in this dialog box.
For details of the setting, refer to the User's manual.

(2) Using an existing workspace


- 1) Select [Tool] menu -> [Debugger Settings...] on the PM+.
-> The [Debugger Settings] dialog box will be opened.
- 2) Specify ID850NW and click the <OK> button in this dialog box. For details of the setting, refer to the User's manual.

4.2.2 Downloading multiple load module files

Load module files in the same project group can be downloaded when using ID850NW.

Download multiple load module files by specifying items in the [Debugger Settings] dialog box of PM+.

Figure 4-1 Downloading Multiple Files



For details of the project group, refer to the "User's manual".

Remark Multiple load module files that are being downloaded can be checked in the [Load Module List Dialog Box](#) of the ID850NW.

4.3 To Start ID850NW from PM+

The ID850NW can be started from the PM+ as follows:

- Click the ID850NW starting button on the tool bar of the PM+.
- Select the [Build] menu -> [Debug] on the PM+.
- Select the [Build] menu -> [Build and Debug] on the PM+.
- Select the [Build] menu -> [Rebuild and Debug] on the PM+.

If the debugging environment of the ID850NW is saved to a project file currently being used by the PM+, it will be started in the debugging environment saved in the project file.

If the debugging environment of the ID850NW is not saved to a project file being used by the PM+, the [Configuration Dialog Box](#) is opened. At this time, the device type (chip name) cannot be changed.

4.3.1 Restoring debugging environment

The previous debugging environment can be restored by the following procedure when the ID850NW is started from the PM+:

- 1) Create a new workspace (project file: e.g., sample.prj) on the PM+ **[Note]**.
- 2) Start the ID850NW from the PM+. Because a new project file is created, set items other than the device type (chip name) in the [Configuration Dialog Box](#) in the same manner as when only the ID850NW is started.
- 3) Download the load module file to be debugged with the [Download Dialog Box](#) of the ID850NW.
- 4) Debug the load module file on the ID850NW.
- 5) Click the <Yes> button on the [Exit Debugger Dialog Box](#) when the ID850NW is terminated.
 - > The debugging environment will be saved to the project file (sample.prj) for the PM plus when the ID850NW is terminated (the debug environment can also be saved to the sample.prj file by overwriting the project file at times other than the completion of ID850NW debugging).
- 6) When the ID850NW is next started up after the sample.prj file is read by PM+, the debug environment at the point when the project file was saved is automatically restored.

[Note] In the ID850NW and PM+, the environment information is saved to a project file and referenced. The extension of the project file that can be used by the ID850NW and PM+ is ".prj". For the information that is saved or restored by the project file, refer to the "User's manual" of each product.

4.4 Auto Load

If a bug is found while the load module file is being debugged by the ID850NW, correct the source file using the following procedure. Compiling and re-downloading the file can be automatically executed. (Refer to "[4.4.1 Auto load by correcting source code](#)".)

The load module is downloaded again to the ID850NW by compiling and linking the file on the PM+ with the activated ID850NW. (Refer to "[4.4.2 Auto load by starting debugger](#)".)

Caution This processing cannot be performed if it is selected that the standard editor (idea-L) is used with the PM+.

4.4.1 Auto load by correcting source code

Correct the source file for auto load as follows:

- 1) Open the source file to be corrected in the [Source Window](#). Select [File] menu -> [Open] and specify the file to be corrected on the ID850NW (if the file is already open in the Source Window, that window is displayed in the forefront).
-> The specified file will be opened in the Source Window.
- 2) Select [Edit] menu -> [Edit Source] on the ID850NW.
-> An editor will be opened and the specified source file will be read.
- 3) Correct the source file on the editor.
- 4) Terminate the editor.

Caution The CPU reset is not performed when the load module file is automatically downloaded. The debug window that was opened when the editor was called, and each event setting will be restored. If the previously used line or symbol has been deleted as a result of correcting the source file, the following happens:

- A variable that was displayed is dimmed.
- The event mark of an event condition is displayed in [yellow](#).
- A software break point may be deleted.

- 5) Select [Build] menu -> [Build and Debug], or [Build] menu -> [Rebuild and Debug] on the PM+.

4.4.2 Auto load by starting debugger

If the following operation is performed on the PM+ with the ID850NW started, the load module will be automatically downloaded to the ID850NW.

- Selecting the [Build] menu -> [Build and Debug] on the PM+.
- Selecting the [Build] menu -> [Rebuild and Debug] on the PM+.

Remark Specify whether to use a CPU reset after downloading from [Debugger Settings...] on the [Tool] menu of PM+ (a CPU reset is performed by default).

CHAPTER 5 DEBUG FUNCTIONS

This chapter explains about debug function of ID850NW.

Table 5-1 Debug Function List (Flow of Debugging Operations)

Item	Refer To
To set the debugging environment	5.1 Setting Debugging Environment
To download the load module	5.2 Download Function, Upload Function
To display the source file and the disassemble result	5.3 Source Display, Disassemble Display Function
To set a break point	5.4 Break Function
To execute the user program	5.5 Program Execution Function
To check the variable value	5.6 Watch Function
To check and edit the memory contents	5.7 Memory Manipulation Function
To check and change the register variable	5.8 Register Manipulation Function
To check the trace data	5.9 Trace Function
To manage the events	5.10 Event Function
RRM function	5.11 RRM Function
To save the debug environment and window status	5.12 Load/Save Function
Jump function, linking window function	5.13 Functions Common to Each Window

5.1 Setting Debugging Environment

This section explains the following items related to the setting debugging environment:

- [Setting operating environment](#)
- [Setting option](#)
- [Setting mapping](#)

5.1.1 Setting operating environment

The in-circuit emulator operating environment settings are performed in the [Configuration Dialog Box](#) that is automatically displayed when ID850NW starts up.

If a project file already exists, the debugging environment can be restored by clicking the <Project...> button. (Refer to "[5.12.1 Debugging environment \(project file\)](#)".)

5.1.2 Setting option

The extended options and debug options are set in the [Extended Option Dialog Box](#), the [Debugger Option Dialog Box](#).

5.1.3 Setting mapping

The mapping settings are performed in the [Configuration Dialog Box](#).

The following types of mapping attributes are available:

Figure 5-1 Setting Mapping




Table 5-2 Type of Mapping Attribute

Attribute	Meaning
Target	User area mapping The memory area specified for user area mapping becomes the area to accesses the memory in the target system or memory incorporated in the CPU.

Attribute	Meaning
Internal ROM	<p>A memory area specified as the internal ROM is equivalent to the internal ROM of the target device(core). The size of this area cannot be changed. The actual memory configuration depends on the target system. If the target device attempts writing to this memory area, a write protect break occurs.</p>
Internal RAM	<p>A memory area specified as the internal RAM is equivalent to the internal RAM of the target device(core). The size of this area cannot be changed. The actual memory configuration depends on the target system.</p>
ROM Emulation RAM	<p>The memory area specified as the ROM emulation RAM is a ROM emulation area in which a ROM probe is used. The target device accesses the memory in the in-circuit emulator. In this area, high-speed downloading and setting pseudo software breaks for the ROM area are possible.</p>
I/O Protect	<p>An I/O Protect area can be set in the area specified for the "Target". The I/O protect area is displayed in the same manner as an area that is not mapped (display symbol: ??), on the Memory Window. By mapping an area with this attribute, data cannot be read or written from/to this area by the Memory Window, on the area can therefore be protected from an illegal access. To read or write the value of the area mapped with this attribute, register the value in the IOR Window or Watch Window.</p>

5.2 Download Function, Upload Function

ID850NW allows downloading and uploading of object files in the formats listed in the following table: [Table 5-3](#), [Table 5-4](#).

This section explains the following items:

- [Download](#)
- [Upload](#)

5.2.1 Download

Object files are downloaded in the [Download Dialog Box](#).

The corresponding source text file ([Source Window](#)) is displayed by downloading load module files with debug information.

Remark Multiple load module files can be downloaded. Loaded files can be checked in the [Load Module List Dialog Box](#) that is opened by selecting [File] menu -> [Load Module].

Table 5-3 Type of File That Can Be Downloaded

Format	Extension
Load module [Note1]	Load Module (*.out)
Intel Hex format [Note2]	Hex Format (*.hex) [Note4]
Motorola Hex format S type [Note3]	
Extended Tektronix Hex format	
Binary data	Binary Data (*.bin)

[Note1] ELF(.OUT) format

[Note2] Standard, extension , and extension linear
Addresses of 1 MB or more can be downloaded.

[Note3] S0, S3, S7

[Note4] Automatic format detection

5.2.2 Upload

Uploading of memory contents, etc., is performed in the [Upload Dialog Box](#). The saving range can be set.

Table 5-4 Type of File That Can Be Uploaded

Format	Extension
Intel Hex format [Note1]	Hex Format (*.hex) [Note3]
Motorola Hex format S type [Note2]	
Extended Tektronix Hex format	
Binary data	Binary Data (*.bin)

[Note1] Standard (16-bit addresses), extension (20-bit addresses), and extension linear (32-bit addresses)
Addresses of 1 MB or more can be uploaded.

[Note2] S0, S3, S7 - 32 bit-address

[Note3] Specify saving format

5.3 Source Display, Disassemble Display Function

Source file display is performed in the [Source Window](#). Disassemble display and online assembly are performed in the [Assemble Window](#).

This section explains the following items:

- [Source display](#)
- [Disassemble display](#)
- [Mixed display mode \(Source Window\)](#)
- [Convert symbol \(symbol to address\)](#)

5.3.1 Source display

The corresponding text file is displayed in the [Source Window](#) by downloading a load module file having debug information.

The display start position can be changed in the [Source Text Move Dialog Box](#) displayed by selecting [View] menu -> [Move...].

Specifications related to the tab size, display font, etc., and specification of the source path are made in the [Debugger Option Dialog Box](#). Specify a searching method in the [Source Search Dialog Box](#) opened by clicking the <Search...> button. The search result is highlighted in the [Source Window](#).

Table 5-5 File Type Can Be Displayed

File Type (Extension)	Meaning
Source (*.c, *.s)	Source file (The extension can be changed in the Debugger Option Dialog Box .)
Text (*.txt)	Text file
All (*.*)	All files

5.3.2 Disassemble display

Disassemble display is performed in the [Assemble Window](#).

The display start position can be changed in the [Address Move Dialog Box](#) opened by selecting [View] menu -> [Move...].

Offset display and register name display are specified in the [Debugger Option Dialog Box](#).

Specify a searching method in the [Assemble Search Dialog Box](#) opened by clicking the <Search...> button. The search result is highlighted in the [Assemble Window](#).

5.3.3 Mixed display mode (Source Window)

Programs can be disassembled and displayed combined with the source file by selecting [View] menu -> [Mix] in the [Source Window](#). The contents displayed in the mixed display mode can be saved as a view file.

Normal display mode

```

58      /* Timer Set */
59      TUM1 = 0x200;
60      CE1 = 1;
61      time_over = 0;

```

In the normal display mode, general text files can be displayed as well as source files.

Mixed display mode

```

58      /* Timer Set */
59      TUM1 = 0x200;
00000394 20660002      movea 0x200, r0, r12
00000398 606740f2      st.h r12, TUM1
60      CE1 = 1;
0000039c c03f42f2      setl 0x7, TMC1
61      time_over = 0;
000003a0 440e0000      movhi 0x0, ep, r1
000003a4 61071184      st.w r0, -0x7bf0[r1]

```

If a program code corresponds to the line of the displayed source file, the disassembly line is displayed next to the source line. The label of the address, code data, and disassembled mnemonic are displayed (the display start position of the mnemonic is adjusted by the set value of the tab size).

Caution The mixed display mode is valid only when the load module is downloaded and the symbol information is read, and the corresponding source file is displayed.

5.3.4 Convert symbol (symbol to address)

In the [Symbol To Address Dialog Box](#), can be displayed the address of the specified variable or function, or the value of the specified symbol.

Convert symbol is performed by selecting the character string to be converted in the [Source Window](#) or [Assemble Window](#), and then selecting context menu -> [Symbol...].

The Specification symbols is indicated below.

Table 5-6 Specifying Symbols

Conversion Target	Specification Method
Variable	var file#var(to specify a static variable with file name) func#var(to specify a static variable with function name) file#func#var(to specify a static variable with file name and function name)
Function	func file#func (to specify a static function with file name)
Label	label file#label(to specify a local label with file name)
Line number of source file	file#no prog\$file#no
I/O port name	portname
I/O register name	I/O regname
Register name	regname
PSW flag name	pswname

Remark 1 Separator "#"

"#" is used as a separator for file names, variables, function names, and line numbers. If a specified symbol is not found in the scope, all symbols (static variables, static functions, local labels) are searched.

Remark 2 Separator "\$"

To specify a load module name when two or more load modules are read, use "\$" as a separator to delimit the load module name from a file name, variable, function name, or symbol name.

In the default status, a symbol name takes precedence. To temporarily change the priority, prefixing "\$" to a symbol gives the priority to a register name.

5.4 Break Function

The break function is used to stop execution of the user program by the CPU and operation of the tracer.

This section explains the following items:

- [Break types](#)
- [Breakpoint setting](#)
- [Setting breaks to variables](#)
- [Hardware break and software break](#)

5.4.1 Break types

The ID850NW has the following break functions.

Table 5-7 Break Types

Item	Contents
Hardware break [Note1] (Event detection break)	Function to stop user program execution upon detection of the set break event condition. -> Refer to " 5.4.2 Breakpoint setting ".
Software break [Note1]	Function to replace the instruction at the specified address software break instruction and stop the user program executed (refer to " 5.4.4 Hardware break and software break "). -> Refer to " 5.4.2 Breakpoint setting ".
[Come Here] break [Note2] (Simple break)	Function to stop user program execution selected by selecting [Run] menu -> [Come Here] upon detection of address specified in the Source Window or Assemble Window .
Break on satisfaction of condition of step execution	Function to stop execution upon satisfaction of the stop condition of each command ([Step In], [Next Over], [Return Out], [Slow motion]).
Forced break	Function to forcibly stop execution by selecting [Run] menu -> [Stop], or selecting the STOP button. It is valid for all the execution commands.

[Note1] This break is valid for [Go], [Go & GO], [Come Here] and [Restart].

[Note2] After user program execution has been stopped, the breakpoint by this function is eliminated.
During execution of a user program by this function, break events set before the cursor position does not occur.

5.4.2 Breakpoint setting

Breakpoints can simply be set to the desired location by clicking in the [Source Window](#) or [Assemble Window](#).

Since breakpoints are set as break event conditions and managed using the [Event Function](#), restrictions apply to the number of breakpoints that can be set. (Refer to "[5.10.4 Number of enabled events for each event condition](#)".)

(1) Breakpoint setting method


Breakpoints are executed by clicking lines in which " * " is displayed (lines where program code exists).

In the default setting, software breakpoint (B) is set, but if [Breakpoint] is selected in the context menu, hardware breakpoint (B, or B) is set. If a breakpoint is set on a line on which an event breakpoint has already been set, "A" indicating that multiple events have been set is marked (refer to "[Table 6-6 Event Setting Status \(Event Mark\)](#)").

Caution A software breakpoint cannot be set in an externally mapped ROM area.

Remark Breaks set by default can also be changed in the [Extended Option Dialog Box](#).

Figure 5-2 Breakpoint Setting



(2) Deleting a breakpoint method


Click the position at which the breakpoint to be deleted is set.

At the same time as setting is performed, in the default setting, software breakpoint (B) is deleted, but if [Breakpoint] is selected in the context menu, hardware breakpoint (B, or B) is deleted. As a result of deletion, if another event remains, however, the mark of that event is displayed.

5.4.3 Setting breaks to variables

Access breaks can easily be set to variables from the context menu in the [Source Window](#) or [Watch Window](#).

Figure 5-3 Setting Break to Variable



5.4.4 Hardware break and software break

(1) Hardware break

Hardware breaks are breaks that are set using one hardware resource per event condition.

Therefore, in the ID850NW, they are managed using "5.10 Event Function" as break event conditions.

The number of valid break points varies depending on the device (refer to "5.10.4 Number of enabled events for each event condition").

(2) Software break


Software breaks are breaks that are set by rewriting instructions of specified addresses to software break instructions. Therefore, the number of software breaks that can be set is not limited, but settings to external ROM, stopping at variable access timing, etc., cannot be specified.

Table 5-8 The Number of Valid Software Break

Product Name	Valid Number
ID850NW	100

Software break is managed by the [Software Break Manager](#).

Figure 5-4 Management of Software Breaks



5.5 Program Execution Function

The program execution function is used to start/stop execution of the user program by the CPU and operation of the tracer.

Through user program execution, the program counter (PC) advances until the set breakpoint or forced break. (Refer to "5.4 Break Function".)

Remark While the user program is being executed, trace event condition can be set. (Refer to " Trace Dialog Box".)

The following types of ID850NW execution functions are provided. They are operated using the execution buttons on the tool bar , or from the [Run] menu.

Figure 5-5 Execution Button



Figure 5-6 [Run] Menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
				Restart				F4	
				Stop				F2	
				Go				F5	
				Ignore break points and Go				Ctrl+F5	
				Return Out				F7	
				Step In				F8	
				Next Over				F10	
				Start From Here				Shift+F6	
				Come Here				F6	
				Go & Go					
				Slowmotion					

Table 5-9 Type of Execution

Items	Contents
[Restart]	The CPU is reset and the user program is executed starting from address 0. This is the same operation as "resetting the CPU before execution of the user program and executing [Go]".
[Stop]	Forcibly stops program execution.
[Go]	The user program is executed starting from the address indicated by the current PC register and is stopped if a set break event condition is satisfied.
[Ignore break points and Go]	The user program is executed starting from the address indicated by the current PC register Execution of the user program continues, ignoring set breakpoints.
[Return Out]	The user program is executed until execution returns to the calling function described in C language.

Items	Contents
[Step In]	<p>In the Source Window, step execution of one line of the source text is performed starting from the current PC register value and the contents of each window are updated.</p> <p>In the Assemble Window, one instruction is executed from the current PC register value and the contents of each window are updated.</p>
[Next Over]	<p>jarl instruction Next step execution is performed, assuming the function or subroutine called by the jarl instruction as one step (step execution continues until the nesting level becomes the same as when the jarl instruction was executed).</p> <p>Instruction other than jarl The same processing as [Step In] is performed.</p>
[Start From Here]	<p>This command executes the user program starting from the specified address. Execution of the user program is stopped when a set break event condition is satisfied.</p>
[Come Here]	<p>The user program is executed from the address indicated by the current PC register to the address selected in the line/address display area of the Source Window or Assemble Window, and then a break occurs. While the user program is being executed, the break event currently set does not occur.</p>
[Go & Go]	<p>The user program is executed starting from the address indicated by the current PC register and stopped if a set break event condition is satisfied. The contents of each window are updated, and execution of the user program is resumed from the address at which the program was stopped. This operation is repeated until the user executes [Stop].</p>
[Slowmotion]	<p>Step execution of one line is performed from the address indicated by the current PC register value in the source mode. In the instruction mode, step execution of one instruction is performed. The contents of each window are updated each time step execution is performed. This operation is repeated until the user executes [Stop].</p>

5.6 Watch Function

This section explains the following items related to the watch function:

- [Displaying and changing data values](#)
- [Displaying and changing local variable values](#)
- [Registering and deleting watch data](#)
- [Changing watch data](#)
- [Temporarily displaying and changing data values](#)
- [Callout watch function](#)
- [Stack trace display function](#)

5.6.1 Displaying and changing data values

Data values are displayed and changed in the [Watch Window](#). Shifts in data values can be checked by registering watch data.

The display format is specified in the [Debugger Option Dialog Box](#).

Figure 5-7 Watch Window





Figure 5-8 Specification of the Display Format (Debugger Option Dialog Box)




5.6.2 Displaying and changing local variable values

Local variables are displayed and changed in the [Local Variable Window](#).

Local variables within the current function are automatically displayed in this window. (Variable addition/deletion is not possible.)

Figure 5-9 Local Variable Window



5.6.3 Registering and deleting watch data

Data can be registered to the [Watch Window](#) from the [Source Window](#) or [Assemble Window](#). This is simply done by selecting the variable or symbol name in the respective window, and then clicking the <Watch> button. Registration is also possible with the following method.

- Drag and drop the selected variable or symbol name directly on the Watch Window. (Refer to "5.13.4 Drag & drop function".)
- Click the <Add> button in the [Quick Watch Dialog Box](#) or [Add Watch Dialog Box](#).


To delete watch data, click the variable name or symbol name (multiple selections can also be made using the Shift key or Ctrl key), and then click the <Delete> button. However, lines with an expanded hierarchy, such as elements of an array, and members of structures and unions, cannot be deleted.

5.6.4 Changing watch data

Watch data is changed in the [Change Watch Dialog Box](#).

Note that the symbol name can be changed even if it results in duplication of a name already in use with existing data.

Figure 5-10 Change Watch Dialog Box




5.6.5 Temporarily displaying and changing data values

Data values are temporarily displayed and changed in the [Quick Watch Dialog Box](#).

Select the desired variable or symbol name in the [Source Window](#) or [Assemble Window](#) and click the <Quick...> button to perform watch data registration.

The display radix, display size, and display number can be changed in this window.

Figure 5-11 Quick Watch Dialog Box




5.6.6 Callout watch function

The corresponding variable value pops up when the mouse cursor is placed over a selected variable in the [Source Window](#) or [Assemble Window](#).

5.6.7 Stack trace display function

This function displays the stack contents of the current user program in the [Stack Window](#).

Figure 5-12 Stack Window



5.7 Memory Manipulation Function

This section explains the following items related to the memory manipulation:

Verify check, etc., is specified in the [Extended Option Dialog Box](#).

- [Displaying and changing memory contents](#)
- [Filling, copying, and comparing memory contents](#)
- [Modifying memory contents \(DMM function\)](#)


5.7.1 Displaying and changing memory contents

In the [Memory Window](#), the memory contents can be displayed or changed by using mnemonic codes, hexadecimal codes, and ASCII codes. Searching is done in the [Memory Search Dialog Box](#) displayed by clicking the <Search...> button. The results of search is highlighted in the [Memory Window](#).

The display start position can be changed in the [Address Move Dialog Box](#) displayed by selecting [View] menu -> [Move...].

The variables and data allocated to the sampling range can be displayed in real time even during program execution. (Refer to "5.11 RRM Function".)

Figure 5-13 Displaying and Changing Memory Contents



5.7.2 Filling, copying, and comparing memory contents

Memory contents are Filled, copied, and compared in the [Memory Fill Dialog Box](#), the [Memory Copy Dialog Box](#), and the [Memory Compare Dialog Box](#) displayed by selecting [Edit] menu -> [Memory] -> [Fill.../Copy.../Compare...].

The comparison results are displayed in the [Memory Compare Result Dialog Box](#).


5.7.3 Modifying memory contents (DMM function)

Memory contents can be modified during user program execution in the [DMM Dialog Box](#) displayed by clicking the <Modify...> button in the [Memory Window](#).

The following points must be noted when using the DMM function.

- This function is implemented by software emulation, however, the user program under execution is temporarily stopped and then executed again.
- If the program is stopped immediately before rewriting the memory because a break event is generated, the generated break event is invalid because program execution is resumed, regardless of the break event.
- If data is written to an address for which a software break is set, the program may not run correctly.
- It is impossible to write data to the area mapped to the ROM emulation RAM or the internal ROM area.

Figure 5-14 Modifying Memory Contents (DMM Dialog Box)



5.8 Register Manipulation Function

This section explains the following items related to the register manipulation function.

- [Displaying and changing register contents](#)
- [Displaying and changing peripheral I/O registers contents](#)
- [Displaying and changing I/O port contents](#)

5.8.1 Displaying and changing register contents

Register contents can be displayed and changed in the [Register Window](#).

Register name display switching (absolute name/function name) can be done in the [Debugger Option Dialog Box](#).

Remark The display register is selected in the [Register Select Dialog Box](#).

Figure 5-15 Absolute Name/Function Name Switching



5.8.2 Displaying and changing peripheral I/O registers contents

The peripheral I/O registers contents can be displayed and changed in the [IOR Window](#).

The display start position can be changed in the [Address Move Dialog Box](#) displayed by selecting [View] menu - > [Move...].

The display register is selected in the [IOR Select Dialog Box](#).

Figure 5-16 Displaying IOR Contents

Name	Attribute	Value
CSC0	R/W 16	03FFF060 FFF1
CSC1	R/W 16	03FFF062 0000
BPC	R/W 16	03FFF064 0000
BSC	R/W 16	03FFF066 AA92
BEC	R/W 16	03FFF068 0000
BHC	R/W 16	03FFF06A 0000
VSWC	R/W 1,8	03FFF06E 77
VSWL0	R/W 1	03FFF06E.0 1
VSWL1	R/W 1	03FFF06E.1 1
VSWL2	R/W 1	03FFF06E.2 1
SUWL0	R/W 1	03FFF06E.4 1
SUWL1	R/W 1	03FFF06E.5 1
SUWL2	R/W 1	03FFF06E.6 1
DSA0L	R/W 16	03FFF080 FBBF
DSA0H	R/W 16	03FFF082 0E4E
DDA0L	R/W 16	03FFF084 BDFD

5.8.3 Displaying and changing I/O port contents

User-defined I/O ports can be displayed and changed in the [IOR Window](#) once they have been registered in the [Add I/O Port Dialog Box](#).

In the case of products that support programmable I/O registers, programmable I/O register contents can be displayed and changed by setting programmable I/O area use in the [Configuration Dialog Box](#).

Figure 5-17 Register I/O Port

The screenshot shows a dialog box titled "Add I/O Port". On the left side, there is a section labeled "I/O Port List:" which contains an empty rectangular area. To the right of this area are several input fields and controls: a "Name:" text box, an "Address:" text box, and a group box labeled "Access" containing three radio buttons: "Byte" (which is selected), "Half Word", and "Word". Below the "Access" group is another group box labeled "Read / Write" containing three checkboxes: "Read Only", "Write Only", and "Read Protect". On the right side of the dialog, there is a vertical column of seven buttons: "OK", "Cancel", "Restore", "Help", "Add", "Change", and "Delete".

5.9 Trace Function

The trace function of the ID850NW traces the branch instructions of the user program and saves the execution flow to the trace memory. The Trace function is enabled by selecting [Option] menu -> [Tracer ON].

This section explains the following items:

- [Trace memory](#)
- [Setting trace data](#)
- [Checking Trace Data](#)
- [Mixed display mode \(Trace View Window\)](#)
- [Tracer Operation](#)
- [Setting conditional trace](#)

Caution Trace function is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

5.9.1 Trace memory

ID850NW has trace memory with a ring structure. Size specification is done in the [Extended Option Dialog Box](#).

The maximum trace memory capacity is as follows.

Table 5-10 Trace Memory Size

Connected IE	Maximum Value
IE-70000-MC-NW-A	128 KB


5.9.2 Setting trace data

The detailed settings for the collected traced data are done in the [Trace Option Dialog Box](#).

Select either of the following modes: The Speed Priority mode that places emphasis on CPU operation in real time and the Trace Priority mode that places emphasis on the reliable collection of trace data.

The selection of the [Option] menu -> [Supplement Data] enables the complement display of the orders that cannot be traced by hardware and that exist between branch instructions.

Figure 5-18 Setting Trace Data



5.9.3 Checking Trace Data


The trace data saved to the trace memory can be checked in the [Trace View Window](#).

The display start position can be changed in the [Trace Move Dialog Box](#) displayed by selecting [View] -> [Move...].

The display items in the [Trace View Window](#) can be selected in the [Trace Data Select Dialog Box](#).

Setting a time tag counter, count rate, and total time tag are performed in the [Extended Option Dialog Box](#).

Figure 5-19 Checking Trace Data



5.9.4 Mixed display mode (Trace View Window)

Source file display combined with trace results can be done by selecting [View] -> [Mix] in the [Trace View Window](#) (mixed display mode).

If a program code corresponds to the program fetch address to be displayed, a source file line is displayed before the line indicating the result of tracing that program fetch address.

Frame	Time	Address	Data	Status	Address	Data	Status	ExtProbe	DisAsm
32757	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32758	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32759	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32760	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						

The source file line is displayed, emphasized in green.

Caution The mixed display mode is valid only when the load module has been downloaded and symbol information is read, and when a fetch address, fetch data, fetch status, or result of disassembly is displayed.

5.9.5 Tracer Operation

The trace operation differs as follows according to the user program execution format and the tracer control mode.

Tracer manipulations during program execution are performed by selecting [Run] -> [Tracer Start/Tracer Stop].

(1) Operation during execution

The tracer operation differs as follows according to [Run] -> [Cond. Trace ON/Cond. Trace ON] selection.

Table 5-11 Types of Trace Mode

Item	Contents
Unconditional trace	Trace is started when execution of user program, and ends when a break occurs. At this time, the set trace event conditions are ignored.
Conditional trace	Trace is started or stopped by the condition set in the Trace Dialog Box (refer to "5.9.6 Setting conditional trace"). If a break occurs while a trace is being executed, however, trace is stopped immediately.

(2) Operation during Step In execution

The tracer operates every step execution, and trace data of one step is successively added to the trace memory.

(3) Operation during Next Over execution

The operation of the tracer differs depending on the instruction to which Next Over is to be executed.

(a) jarl disp22, [lp] instruction

The jarl instruction and the subroutine that was called are traced.

(b) Other instructions

The same operation as that during Step In execution is performed.

(4) Tracer control mode

There are the following types of trace control mode. These trace mode settings are performed from the [Run] menu.

Table 5-12 Types of Tracer Control Mode

Mode	Contents
Non Stop	Goes around the trace memory and overwrites data from the oldest frame (default).
Full Stop	Goes around the trace memory and then stops the tracer.
Delay Trigger Stop	Traces data by the number of delay count frames and stops the tracer when a delay trigger event has occurred.

5.9.6 Setting conditional trace

A trace event condition triggers starting/stopping trace execution when a conditional trace is set.

By setting a trace event condition in the [Trace Dialog Box](#), the conditional trace can be set (refer to "[5.10 Event Function](#)").

There are the following types of conditional trace.

Table 5-13 Types of Conditional Trace

Item	Contents, Setting method
Section trace	Executes a trace between two specified conditions (in a specific zone). A section trace can be executed by setting a trace start event and trace end event in the Trace Dialog Box and selecting [Run] -> [Cond. Trace ON].
Delay trigger trace	Executes a trace by the number of delay counts after a condition has been satisfied. A delay trigger trace can be executed by setting a delay trigger event in the Trace Dialog Box , setting a delay count in the Delay Count Dialog Box and selecting [Run] -> [Cond. Trace ON]. In this case, select [Delay Trigger Stop].

5.10 Event Function

Events specify specific states of the target system during debugging ,such as "fetched address 0x1000" or "Wrote data to address 0x2000".

In ID850NW, such events are used as action triggers for each debugging function, such as break and trace.

This section explains the following items:

- [Using event function](#)
- [Creating events](#)
- [Setting event conditions](#)
- [Number of enabled events for each event condition](#)
- [Managing events](#)

5.10.1 Using event function

Events (event conditions and event rink conditions) consist of the event conditions listed in the following table, by assigning various debugging functions. As a result, event conditions can be utilized according to the debugging purpose.

Table 5-14 Various Event Conditions

Event Condition	Mark	Contents ->Setting Dialog Box
Break event	B	Condition in which the execution of the user program or operation of a tracer is stopped. (refer to " 5.4 Break Function "). -> Break Dialog Box
Trace event [Note]	T	Condition in which the process of user program execution is saved to the trace memory (refer to " 5.9 Trace Function "). -> Trace Dialog Box

[Note] Trace function is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

The shape of the mouse cursor changes to "OK" when it is dragged over a settable condition area.

Regarding the created event conditions, the event icon mark becomes red and the setting is enabled by clicking the <Set> button or the <OK> button in the Setting dialog box. After the event has been set, a debugging action occurs as various event conditions.

(2) Settings using selection mode (settings after checking contents)

The [Event Dialog Box](#) and [Event Link Dialog Box](#) are open in the selection mode by placing the focus on the condition area to be set and then clicking the <Add Event...> button or <Add Link...> button. Because when a condition set in the dialog box is selected, the corresponding detailed condition is displayed, conditions can be set after checking the contents.

(3) Copying and moving event icons

In the event condition setting area, event conditions can be copied and moved through drag & drop operation using the following methods.

- If event condition was dropped using only the mouse, move event condition.
- If the event condition was dropped while pressing the Ctrl key, copy the event condition.

(4) Manipulation in event manager area

Event conditions can be set by clicking the <Add> button after placing the focus on the condition area to be set and selecting an event icon.

Event setting content display

Select an event and click the <Open> button or double-click the event. The setting dialog box corresponding to the selected event will be opened and the set contents of the event will be displayed.

Deletion

An event can be deleted by selecting the event and then clicking the <Remove / Delete> button or pressing the Delete key.

Changing display mode and sorting

The display mode of and sorting in the event manager area can be selected by clicking the <Info...> button.

Area non-display

An area can be hidden by clicking the <Shrink<<< > button.

5.10.4 Number of enabled events for each event condition

Up to 256 conditions can be registered as event conditions or various event conditions.

One event condition or link event condition can be set for multiple types of events such as break and trace.

However, the number of event conditions that can be simultaneously set (enabled) is limited as follows.

Therefore, if the valid number is exceeded or if the used event conditions or event link conditions exceed the maximum number that can be used simultaneously, it is necessary to disable the set various event conditions once and then register them again. (Refer to "5.10.5 Managing events".)

Table 5-15 Number of Enabled Events for Each Event Condition

Connected IE		Event		Event Link	Break	Trace
		Execution	Access			
IE-70000-MC-NW-A	Nx85ET	6 ^a	2 ^b	1	8	1
	Nx85E901	2 ^c		1 ^d	2 ^c	-

- a. Two events before execution (address range cannot be specified) and four events after execution (address range can be specified)
- b. Address range can be specified
- c. Address range cannot be specified
- d. Can be set only in Phase 1 and Phase 2 (must always be set in two stages), without pass count and Disable condition specification.


Caution In Nx85E901, event set/change/delete cannot be performed during user program execution. Neither can event set/change/delete prior to user program execution be performed even if in Nx85ET. However, regarding event set/change following execution, the tracer can be stopped.

5.10.5 Managing events

Managing events is done with the [Event Manager](#).

The Event Manager allows display, enabling/disabling, and deletion of the [Various Event Conditions](#).

Figure 5-21 Managing Events (the Event Manager)



(1) Event icon

Event icons consist of a mark and an event name indicating the type of event. The color of each event icon indicates the setting status of that event.

Enable/disable is switched by clicking the mark part.

Table 5-16 Event Icon

Character Color	Mark	Meaning
Red	E.L.	Indicates that the event condition or event link condition which is used for various event conditions is valid.
	B.T.	Indicates that the Various Event Conditions is valid. The various events occur when its condition is satisfied.
Black	E.L.	Indicates that the event condition or event link condition which is used for various event conditions is invalid.
	B.T.	Indicates that the Various Event Conditions is invalid. The various events do not occur even when its condition is satisfied.
Yellow	E.L.	Indicates that the symbol specified for an event is held pending because it cannot be recognized by the program currently loaded.
	B.T.	Indicates that the Various Event Conditions is held pending. The various events do not occur even when its condition is satisfied.

5.11 RRM Function

RRM function displays in real time the variables allocated to the sampling range, data, etc., in [Watch Window](#) or [Memory Window](#).

The function is classified into two types. They are selectable in the [Extended Option Dialog Box](#).

- [Real-time RAM monitor function](#)
- [RAM monitor function](#)

Figure 5-22 Setting of RRM Function (Extended Option Dialog Box)

RAM Monitor	
Function:	<input type="radio"/> On <input checked="" type="radio"/> Off
Area:	<input type="radio"/> Whole <input checked="" type="radio"/> IRAM + IOR
Redraw Interval:	<input type="text" value="500"/> msec

The selection of Off in Function: enables the former function; the selection of On enables the latter.

5.11.1 Real-time RAM monitor function

When this function is selected, real-time display of the variables and data allocated to the sampling range is enabled.

All of the range is sampled.

Enter the sampling time in the Redraw Interval: area of the [Extended Option Dialog Box](#).

5.11.2 RAM monitor function

The RAM monitor function realizes the RRM function through software emulation.

This function temporarily stops the operation of user programs during sampling; therefore the variables and data allocated to the sampling area are displayed in almost real time.

To determine the sampling area, check the corresponding box in "Area:" of the [Extended Option Dialog Box](#).

5.12 Load/Save Function

ID850NW allows saving and loading the following types of information as files. As a result, recovery of these various types of information is possible.

This section explains the following items:

- [Debugging environment \(project file\)](#)
- [Window display information \(view file\)](#)
- [Window setting information \(setting file\)](#)

Remark The simple window status can be maintained by selecting [Window] menu -> [Static]. (Refer to ["5.13.1 Active status and static status"](#).)

5.12.1 Debugging environment (project file)

A project file (*.prj) is a file that records the debugging environment.


A project file is created when the debugging environment at a particular point in time is saved, and that debugging environment can be restored by loading this file at a subsequent time.

Project files are loaded and saved in the [Project File Save Dialog Box](#) and [Project File Load Dialog Box](#), respectively. To load a project file at startup, press the <Project...> button in the [Configuration Dialog Box](#).

(1) Automatic save/automatic load of project file

The project file to be loaded/saved when starting up and exiting in the [Debugger Option Dialog Box](#) can also be set in advance.

Figure 5-23 Automatic Save/Automatic Load Setting for Project File



(2) Contents saved to project File

The following contents are saved to the project file:

Table 5-17 Contents Saved to Project File

Window Name	Saved Contents
Configuration Dialog Box	All items (target device, clock setting, pin mask setting, mapping information)
Main Window	Display position, tool bar/status bar/button display information, execution mode information, trace on/off information
Download Dialog Box	File information to be downloaded
Extended Option Dialog Box Debugger Option Dialog Box Trace Option Dialog Box	Set information
Source Window	Display information of window
Assemble Window Memory Window	Display information of window, display start address
Stack Window IOR Window Local Variable Window Trace View Window Event Manager Console Window Expansion Window	Display information of window
Event Dialog Box	Display information of window, event information
Event Link Dialog Box	Display information of window, link event information
Break Dialog Box	Display information of window, break event information
Trace Dialog Box	Display information of window, trace event information
Register Window	Display information of window
Watch Window	Display information of window, watch registration information
Add I/O Port Dialog Box	Added I/O port information
DMM Dialog Box	DMM information
Delay Count Dialog Box	Delay count value
Software Break Manager	Display information of window, software break information

5.12.2 Window display information (view file)

A view file is a file that records window display information.

View files can be loaded and saved for each window.

When a view file is loaded, a reference window ([Source Window](#) in the static status) is displayed and the display information at the time of saving is displayed.

View files are loaded and saved in the [View File Load Dialog Box](#) and [View File Save Dialog Box](#), respectively.

Table 5-18 Type of the View Files

File Type	Target Window File Name
Source Text (*.sw)	Source Window View file of the Source window
Assemble (*.dis)	Assemble Window View file of the Disassemble window
Memory (*.mem)	Memory Window View file of the Memory window
Watch (*.wch)	Watch Window View file of the Watch window
Register (*.rgw)	Register Window View file of the Register window
I/O Register (*.ior)	IOR Window View file of the IOR window
Local Variable (*.loc)	Local Variable Window View file of the Local Variable window
Stack Trace (*.stk)	Stack Window View file of the Stack Trace window
Trace (*.tw)*	Trace View Window View file of the Trace View Window
Console (*.log)	Console Window View file of the Console window
All (*.*)	All files
Source (*.c, *.s) (During downloading)	Source file [Note]
Text (*.txt)	Text file

[Note] The extension of the source file can be changed in the [Extended Option Dialog Box](#).

5.12.3 Window setting information (setting file)

A setting file is a file that records the window setting information (watch data settings, peripheral I/O registers settings, and event settings).

Setting files can be loaded and saved for each window.

When a setting file is loaded, the target window is displayed and the setting information that was saved is restored.

Setting files are loaded and saved in the [Environment Setting File Load Dialog Box](#) and the [Environment Setting File Save Dialog Box](#), respectively.

Table 5-19 Type of the Setting Files

File Type	Target Window File Name
Watch (*.wch) [Note]	Watch Window Setting file of the Watch Window
I/O Register (*.ior) [Note]	IOR Window Setting file of the IOR Window
Event (*.evn)	Event Manager Setting file of event

[Note] A variable value can not be loaded.

5.13 Functions Common to Each Window

The windows have the following common functions.

- [Active status and static status](#)
- [Jump function](#)
- [Trace Result with Linking Window](#)
- [Drag & drop function](#)

5.13.1 Active status and static status

Each of the Windows below has two statuses: The [Active status](#) and the [Static status](#).

- [Source Window](#) (displaying the source file to which symbol information is read)
- [Assemble Window](#)
- [Memory Window](#)

Only one window can be opened in the active status. However, because two or more windows in the static status can be opened, the current status of the windows can be temporarily held.

Select this status by the [Window] menu.

(1) Active status

The display position and contents of the window in the active status are automatically updated in association with the current PC value.

This window is also the jump destination of the [Jump function](#). If this window is linked with the [Trace View Window](#), the contents displayed in the active window are updated in association with the [Trace View Window](#).

Only one window can be opened in the active status.

(2) Static status

The display position of the window in the static status does not move in association with the current PC value, but the displayed contents are updated.

The static window is not used as the jump destination of the [Jump function](#). In addition, it is not linked with the [Trace View Window](#).

If an active window is already open, the next window is opened in the static status.

Two or more static windows can be opened at the same time.

5.13.2 Jump function

This is a function that jumps to any of the Windows below from a line or address (a jump pointer) on which the cursor is put. The Window to which the jump is made is displayed on the jump pointer.

- [Source Window](#)
- [Assemble Window](#)
- [Memory Window](#)

You can jump among the above windows, or from [Trace View Window](#), [Stack Window](#), [Event Manager](#) and [Register Window](#) to the above windows.

(1) Jump method

The jump method is as follows:

- 1) Move the cursor to the line or address that is to be used as the jump pointer, on the window from which jumping is possible (select an event icon on the Event Manager).
- 2) Select the following menu item to which execution is to jump from the [Jump] menu.

Caution If a program code does not exist on the line at the cursor position, the first address of the line with a program code above or below that line is used as the jump pointer.

(2) Details of jump source address

The details of jump source address is as follows:

Table 5-20 Details of Jump Source Address

Target Window	Details of Jump Pointer	
From the Register Window	Registers selected	
From the Memory Window	Address at the cursor position	
From the Event Manager	If the selected event icon is that of an event condition, an address condition is used as the jump pointer.	
	If the address condition is set in point	Jump to specified address
	If the address condition is set in range	Jump to lower address (point address before the mask if a mask is specified)
	If the address condition is set in bit	Jump to address at the bit position

Target Window	Details of Jump Pointer	
From the Stack Window	A function at the cursor position that stack frame number indicates is used as the jump pointer.	
	With current function	
	If the jump destination is the Source Window	Jumps to the current PC line
	Other than above	Jumps to the current PC address
	With function other than current function	
	If the jump destination is the Source Window	Jump to the line that calls a nested function.
	Other than above	Jump to the address next to the instruction that calls a nested function.
From the Trace View Window	Jump to the Memory Window	
	If the cursor position is at an access address, access data, or access status	Access address
	Other than above	Fetch address
Jump to the Source Window or Assemble Window	Fetch address	

5.13.3 Trace Result with Linking Window

By linking [Trace View Window](#) with each window ([Source Window](#), [Assemble Window](#) or [Memory Window](#)), the corresponding part can be displayed on the linked window, by using the address at the cursor position on the [Trace View Window](#) as a pointer.

If the cursor is moved on the [Trace View Window](#), the corresponding part on the linked window is highlighted or indicated by the cursor position.

Caution This function is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

(1) Linking method

- 1) Set the [Trace View Window](#) as the current window.
- 2) Select [View] menu -> [Window Synchronize] to select a window to be linked.
- 3) Move the cursor to the line to be linked in the trace result display area of the [Trace View Window](#).
- 4) Using the address of the line selected in 3 as a pointer, the corresponding part is highlighted (or indicated by the cursor position) in the display area of the window selected in 2.

Caution The linking source address differs as follows depending on the cursor position in the trace result display area if the [Memory Window](#) is linked.

Access address, access data, access status -> Access address

Others -> Fetch address

When the [Source Window](#) or [Assemble Window](#) is linked, the fetch address is always used as the pointer.

5.13.4 Drag & drop function

Selected and highlighted line numbers, addresses, and text can be dragged and dropped in another window using the following method.

- 1) Drag the selected line number, address, or text.
 - > The shape of the mouse cursor changes from an arrow to "-".
- 2) Drop the selection in a window or area where it can be dropped.
 - > The shape of the cursor changes from "-" to "OK" when the cursor is placed over a window or area where the selection can be dropped.

In the window in which the line number of the address has been dropped, an operation is performed on the dropped address or the address that is obtained from the dropped line number. For example, a variable can be simply registered by dragging and dropping in the [Watch Window](#) such a variable located in the [Source Window](#).

(1) Drag & drop details

The operation to be performed after dropping the line number or address differs, depending on the window or area in which the line number or address has been dropped.

Table 5-21 Details of Drag & Drop Function (Line/Address)

Window/Area to Drop to	Operation After Drop
The Event Manager or the event manager area in each various event setting dialog box	Automatically creates an execution event condition by using the dropped line number or address as an address condition. Event condition names are automatically created as Evt00001, Evt00002, and so on. A path count are not specified. The address condition is set for the closest symbol in the format of symbol name + offset value.
Condition setting area in each various event setting dialog box (other than address and data setting areas)	Automatically creates an execution event condition by using the dropped line number or address as an address condition. The automatically created event condition is set in each condition setting area in which the line number or address has been dropped. Event condition names are automatically created as Evt00001, Evt00002, and so on. A path count are not specified. The address condition is set for the closest symbol in the format of symbol name + offset value.
Condition setting area in each various event setting dialog box (address and data setting areas)	The text of the dropped line number or address is set in the area in which the line number or address has been dropped. The address condition is set for the closest symbol in the format of symbol name + offset value.

Table 5-22 Details of Drag & Drop Function (Character String)

Window/Area to Drop to	Operation After Drop												
<p>The Event Manager or the event manager area in each various event setting dialog box</p>	<p>If the dropped text can be converted as a symbol into an address value, an event condition in the Access status (all access statuses) or Execute status is automatically created, using the converted address value as an address condition. Event condition names are automatically created as Evt00001, Evt00002, and so on. A data condition and path count are not specified. The address condition is set by the dropped text. The relationship between the event condition to be created and the symbol is as follows:</p> <table border="1" data-bbox="497 568 1394 869"> <thead> <tr> <th data-bbox="497 568 948 622">Symbols</th> <th data-bbox="954 568 1394 622">Status</th> </tr> </thead> <tbody> <tr> <td data-bbox="497 622 948 676">Variable</td> <td data-bbox="954 622 1394 676">Access (R/W)</td> </tr> <tr> <td data-bbox="497 676 948 730">Function</td> <td data-bbox="954 676 1394 730">Execute</td> </tr> <tr> <td data-bbox="497 730 948 784">Symbol in data section</td> <td data-bbox="954 730 1394 784">Access (R/W)</td> </tr> <tr> <td data-bbox="497 784 948 837">Symbol in code section</td> <td data-bbox="954 784 1394 837">Execute</td> </tr> <tr> <td data-bbox="497 837 948 869">Others</td> <td data-bbox="954 837 1394 869">Access (R/W)</td> </tr> </tbody> </table>	Symbols	Status	Variable	Access (R/W)	Function	Execute	Symbol in data section	Access (R/W)	Symbol in code section	Execute	Others	Access (R/W)
Symbols	Status												
Variable	Access (R/W)												
Function	Execute												
Symbol in data section	Access (R/W)												
Symbol in code section	Execute												
Others	Access (R/W)												
<p>Condition setting area in each various event setting dialog box (other than address and data setting areas)</p>	<p>If the dropped text can be converted as a symbol into an address value, an event condition in the Access status (all access statuses) or Execute status is automatically created, using the converted address value as an address condition. The automatically created event condition is set in each condition setting area in which the line number or address has been dropped. Event condition names are automatically created as Evt00001, Evt00002, and so on. A data condition and path count are not specified. The address condition is set by the dropped text. The relationship between the event condition to be created and the symbol is as follows:</p> <table border="1" data-bbox="497 1187 1394 1482"> <thead> <tr> <th data-bbox="497 1187 948 1240">Symbols</th> <th data-bbox="954 1187 1394 1240">Status</th> </tr> </thead> <tbody> <tr> <td data-bbox="497 1240 948 1294">Variable</td> <td data-bbox="954 1240 1394 1294">Access (R/W)</td> </tr> <tr> <td data-bbox="497 1294 948 1348">Function</td> <td data-bbox="954 1294 1394 1348">Execute</td> </tr> <tr> <td data-bbox="497 1348 948 1402">Symbol in data section</td> <td data-bbox="954 1348 1394 1402">Access (R/W)</td> </tr> <tr> <td data-bbox="497 1402 948 1456">Symbol in code section</td> <td data-bbox="954 1402 1394 1456">Execute</td> </tr> <tr> <td data-bbox="497 1456 948 1482">Others</td> <td data-bbox="954 1456 1394 1482">Access (R/W)</td> </tr> </tbody> </table>	Symbols	Status	Variable	Access (R/W)	Function	Execute	Symbol in data section	Access (R/W)	Symbol in code section	Execute	Others	Access (R/W)
Symbols	Status												
Variable	Access (R/W)												
Function	Execute												
Symbol in data section	Access (R/W)												
Symbol in code section	Execute												
Others	Access (R/W)												
<p>Condition setting area in each various event setting dialog box (address and data setting areas)</p>	<p>The dropped text is set in the area.</p>												
<p>Watch Window</p>	<p>If the dropped text is recognizable as a symbol, the contents of the symbol are displayed.</p>												

Remark Each various event setting dialog box are as follows.

- [Event Dialog Box](#)
- [Event Link Dialog Box](#)
- [Break Dialog Box](#)
- [Trace Dialog Box](#)

CHAPTER 6 WINDOW REFERENCE

This chapter explains in detail the functions of the windows and dialog boxes of ID850NW.

- [Window List](#)
- [Explanation of Windows](#)

6.1 Window List

The list is the windows of the ID850NW.

Table 6-1 Window List

Window Name	Contents
Main Window	This window is displayed first, when the ID850NW is started. It controls execution of the user program. Various windows are opened from this window.
Configuration Dialog Box	Displays and sets the ID850NW operation environment.
Extended Option Dialog Box	Displays and sets the extended options of the ID850NW.
Trace Option Dialog Box	Sets details regarding fetching of trace data.
Debugger Option Dialog Box	Displays and sets other options.
Project File Save Dialog Box	Saves the current debug environment to project file.
Project File Load Dialog Box	Loads the debug environment.
Download Dialog Box	Loads an object file and binary file.
Upload Dialog Box	Saves the memory contents to a file.
Load Module List Dialog Box	Lists the names of the downloaded load module files.
Source Window	Displays a source file and text file.
Source Search Dialog Box	Searches in the Source Window .
Source Text Move Dialog Box	Specifies a file to be displayed in the Source Window and the position from which displaying the file is to be started.
Assemble Window	Disassembles the program and executes online assembly.
Assemble Search Dialog Box	Searches in the Assemble Window .
Address Move Dialog Box	Specifies the start address to display the contents of the Memory Window or Assemble Window .
Symbol To Address Dialog Box	Displays the address of the specified variable or function, or the value of the specified symbol.
Watch Window	Displays and changes specified watch data.
Quick Watch Dialog Box	Displays temporarily specified watch data.
Add Watch Dialog Box	Registers watch data to display in the Watch Window .
Change Watch Dialog Box	Changes watch data to display in the Watch Window .
Local Variable Window	Displays and changes the local variable in the current function.
Stack Window	Displays the current stack contents.
Memory Window	Displays the contents of memory.
Memory Search Dialog Box	Searches in the Memory Window .
Memory Fill Dialog Box	Fills the memory contents with specified data.

Window Name	Contents
Memory Copy Dialog Box	Copies the memory.
Memory Compare Dialog Box	Compares the memory.
Memory Compare Result Dialog Box	Displays the results of comparing the memory.
DMM Dialog Box	Sets addresses and data subject to DMM.
Register Window	Displays the contents of registers.
Register Select Dialog Box	Selects registers to be displayed in the Register Window .
IOR Window	Displays the contents of peripheral I/O registers.
IOR Select Dialog Box	Selects peripheral I/O registers and I/O ports to be displayed in the IOR Window .
Add I/O Port Dialog Box	Registers an I/O port to be displayed in the IOR Window .
Trace View Window [Note]	Displays trace results.
Trace Data Select Dialog Box [Note]	Selects items to be displayed in the Trace View Window .
Trace Move Dialog Box [Note]	Specifies the start address to display the contents of the Trace View Window .
Trace Dialog Box [Note]	Registers and sets trace event conditions.
Delay Count Dialog Box [Note]	Sets the delay count of a delay trigger trace event.
Event Manager	Displays, enables/disables, and deletes each event condition.
Software Break Manager	Displays, enable or disable, and delete software breaks.
Event Dialog Box	Registers event conditions.
Event Link Dialog Box	Registers event link conditions.
Break Dialog Box	Registers and sets break event conditions.
View File Save Dialog Box	Saves the display information of the current window to a view file.
View File Load Dialog Box	Loads the view file of each window.
Environment Setting File Save Dialog Box	Saves the setting information of the current window to a setting file.
Environment Setting File Load Dialog Box	Loads the setting file of each window.
Reset Debugger Dialog Box	Initializes the ID850NW,CPU, and symbol information.
Exit Debugger Dialog Box	Terminate the ID850NW.
About Dialog Box	Displays the version of the ID850NW.
Console Window	Inputs commands.
Font Dialog Box	Displays the types of fonts displayed.
Browse Dialog Box	Selects the file to be set.

[Note] This dialog box or window is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

6.2 Explanation of Windows

This section explains each window or dialog box as follows:

Window Name / Dialog box Name

Briefly explains the function of the window or dialog box and points to be noted.

In addition, the display image of the window or dialog box is also illustrated.

Items of related operation are also explained.

Opening

Explains how to open the window or dialog box.

Explanation of each area

Explains items to be set to or displayed in each area of the window or dialog box.

Context menu

Explains the context menu that is displayed in the window when the right mouse button is clicked. From the context menu, convenient functions often used in this window can be selected with a single action (window only).

Function buttons

Explains the operation of each button in the window or dialog box.

Related operations

Explains the operation of a window or dialog box related to this window or dialog box.

Main Window

This window is automatically opened when the ID850NW is started up and initialized.


In ID850NW, other windows are manipulated from this window (refer to "Table 6-1 Window List").

Execution of the user program is controlled in this window.

Execution of the user program is controlled in the following three modes:

- Source mode (Debugs the user program at the source level.)
- Instruction mode (Debugs the user program at the instruction level.)
- Auto mode (Automatically selects the source mode or instruction mode.) (default)

Figure 6-1 Main Window



- Menu bar
- Toolbar
- Window display area
- Status bar

Menu bar

- (1) [File] menu
- (2) [Edit] menu
- (3) [View] menu
- (4) [Option] menu
- (5) [Run] menu
- (6) [Event] menu
- (7) [Browse] menu
- (8) [Jump] menu
- (9) [Window] menu

(10) [Help] menu

(1) [File] menu

Open...	Loads a view file, source file, or text file. Opens the View File Load Dialog Box . The operation differs depending on the extension of the file selected in the dialog box.
Save As...	Saves the contents displayed on the current window to the file whose name is specified. Opens the View File Save Dialog Box .
Close	Closes the current window.
Download...	Downloads a file. Opens the Download Dialog Box .
Load Module...	Lists the names of the files that have been downloaded. Opens the Load Module List Dialog Box .
Upload...	Uploads a program. Opens the Upload Dialog Box .
Project	Manipulates a project file.
Open...	Opens a project file. Opens the Project File Load Dialog Box .
Save	Overwrites the current status to the project file currently being read to the ID850NW.
Save As...	Saves the current status to a specified project file. Opens the Project File Save Dialog Box .
Environment	Manipulates a setting file.
Open...	Opens a setting file. Opens the Environment Setting File Load Dialog Box .
Save As...	Saves the setting in the current window to the setting file. Opens the Environment Setting File Save Dialog Box .
Debugger Reset...	Initializes the CPU, symbols, and ID850NW. Opens the Reset Debugger Dialog Box .
Exit	Terminate the ID850NW. Opens the Exit Debugger Dialog Box .
(Open file)	Lists the names of the files opened.

(2) [Edit] menu

Cut	Cuts a selected character string and saves it to the clipboard buffer.
Copy	Copies a selected character string and saves it to the clipboard buffer.
Paste	Pastes the contents of the clipboard buffer to the text cursor position.
Write in	Writes the modified contents to the target.
Restore	Cancel the modification.
Memory	Manipulates the memory contents.
Fill...	Fills the memory contents with specified codes. Opens the Memory Fill Dialog Box .
Copy...	Copies the memory. Opens the Memory Copy Dialog Box .
Compare...	Compares the memory. Opens the Memory Compare Dialog Box .
Modify...	Rewrites the memory contents during user program execution. Opens the DMM Dialog Box .
Edit Source	Opens the source file displayed in the active Source Window with the editor specified by the PM+ when the PM+ runs.

(3) [View] menu

The [View] menu contains common parts as well as dedicated parts added according to the active window. For details about the dedicated parts, refer to the description of each window.

(a) Common items

Search...	Performs a search. Opens the search dialog box corresponding to the current window. Same operation as the <Search> button.
Move...	Moves the display position. Opens the specification dialog box corresponding to the current window.
Quick Watch...	Temporarily displays the contents of the specified data. Opens the Quick Watch Dialog Box .
Add Watch...	Registers the specified data to the Watch window. Opens the Add Watch Dialog Box .
View Watch	Adds the selected data to the Watch window. If the data is a symbol, it is added in accordance with the setting of Debugger Option Dialog Box .
Change Watch...	Changes the data on the line selected by the Watch window. Opens the Change Watch Dialog Box . This menu is valid only when a variable is selected in Watch Window .
Delete Watch	Deletes the selected watch point from the Watch Window . This menu is valid only when a variable is selected in Watch Window .
Symbol...	Displays the address of the specified variable or function, or the value of the specified symbol. Opens the Symbol To Address Dialog Box .

(4) [Option] menu

Tool Bar	Selects whether the tool bar is displayed (default) or not.
Status Bar	Selects whether the tool bar is displayed (default) or not.
Button	Selects whether the buttons on each window are displayed (default) or not.
Source Mode	Executes step execution at the source level (in line units).
Instruction Mode	Executes step execution at the instruction level (in instruction units).
Auto Mode	Automatically selects step execution at the source level or step execution at the instruction level (default). Step execution is performed at the source level (in a mode other than mixed display mode) if Source Window is active. It is performed at the instruction level if Assemble Window is active. If neither window is active, step execution is performed at the source level.
Configuration...	Sets the environment. Opens the Configuration Dialog Box .
Extended Option...	Sets extended options. Opens the Extended Option Dialog Box .
Debugger Option...	Sets ID850NW options. Opens the Debugger Option Dialog Box .
Add I/O Port...	Adds user-defined I/O ports. Opens the Add I/O Port Dialog Box .
Trace	Settings related to tracer.
Trace Option...	This dialog box makes various settings related to trace such as the trace data selection. Opens the Trace Option Dialog Box .
Clear	Clears the trace data.
Supplement Data	Selects whether to perform trace complementation. Function to fill intervals between branch frames with pseudo trace data.
Tracer ON	Turns ON/OFF trace (default: OFF). This item cannot be selected during user program execution.

(5) [Run]menu

Restart	Resets the CPU and executes the program.  Same operation as this button.
Stop	Forcibly stops program execution.  Same operation as this button.
Go	Executes the program from the current PC.  Same operation as this button.
Ignore break points and Go	Ignores break points being set, and executes the program.  Same operation as this button.

Return Out	<p>The user program is executed until execution returns.</p>  Same operation as this button. Note: This command is used for a function described in C language.
Step In	<p>Executes the instructions in the program one by one (step execution). If a function or subroutine is called, its instructions are executed one by one.</p>  Same operation as this button.
Next Over	<p>Executes the instructions in the program one by one (Next step execution). If a function or subroutine is called, its instructions are not executed on a step-by-step basis.</p>  Same operation as this button.
Start From Here	<p>Executes the program from the cursor position on Source Window or Assemble Window.</p>
Come Here	<p>Executes the program from the current PC to the cursor position in the Source Window or Assemble Window.</p>
Go & Go	<p>Continues executing the program. If a break occurs because a break condition is satisfied, the window is updated and the program is executed again.</p>  Same operation as clicking this button each time a break has occurred.
Slowmotion	<p>Continues step execution. Each time step execution has been performed, the window is updated and then step execution is performed again.</p>  Same operation as clicking this button each time a break has occurred.
CPU Reset	<p>Resets the CPU.</p>  Same operation as this button.
Change PC	<p>Sets the address at the cursor position in the Source Window or Assemble Window to the PC.</p>
Break Point	<p>Sets or deletes a breakpoint at the cursor position in the Source Window or Assemble Window.</p>
Software Break Point	<p>Sets or deletes a software breakpoint at the cursor position in the Source Window or Assemble Window.</p>
Delete All Breakpoints	<p>Deletes all the set software break events.</p>
Uncond. Trace ON	<p>Validates unconditional trace so that trace can always be executed during program execution (default). At this time, the set trace event conditions are ignored. The trace mode cannot be changed while the tracer is activated.</p>
Cond. Trace ON	<p>Validates conditional trace and traces in accordance with the trace event condition during program execution. The trace mode cannot be changed while the tracer is activated.</p>
Tracer control mode	<p>To set trace control mode. Caution Delay trigger event condition is enabled only when [Delay Trigger Stop] is selected. In this case, cannot be selected other mode.</p>

Non Stop	Goes around the trace memory and overwrites data from the oldest frame (default).
Full Stop	Goes around the trace memory and then stops the tracer.
Delay Trigger Stop	Traces data by the number of delay count frames and stops the tracer when a delay trigger event has occurred.
Tracer Start/Tracer Stop	Starts the tracer when it is stopped, or stops it when it is in progress. This item is invalid if the program is not being executed. Immediately after program execution has been started, the tracer is executed.

(6) [Event] menu

Event Manager	Manages various event conditions. Opens the Event Manager .  Same operation as this button.
Software Break Manager	Manages software break event conditions. Opens the Software Break Manager .
Event...	Registers an event condition. Opens the Event Dialog Box .  Same operation as this button.
Event Link...	Registers an event link condition. Opens the Event Link Dialog Box .
Break...	Registers and sets a break event condition. Opens the Break Dialog Box .  Same operation as this button.
Trace...	Registers and sets a trace event condition. Opens the Trace Dialog Box .  Same operation as this button.
Delay Count...	Sets the delay count. Opens the Delay Count Dialog Box .

(7) [Browse] menu

Source Text	Displays a source text. Opens the Source Window . If there is this window already open in the active status, it is opened in the static status.  Same operation as this button.
Assemble	Displays the disassemble results. Opens the Assemble Window . If there is this window already open in the active status, it is opened in the static status.  Same operation as this button.

Memory	<p>Displays the contents of the memory. Opens the Memory Window. If there is this window already open in the active status, it is opened in the static status.</p>  Same operation as this button.
Watch	<p>Displays the watch contents. Opens the Watch Window.</p>  Same operation as this button.
Register	<p>Displays the register contents. Opens the Register Window.</p>  Same operation as this button.
I/O Register	<p>Displays the contents of the Peripheral I/O registers. Opens the IOR Window.</p>  Same operation as this button.
Local Variable	<p>Displays the local variable. Opens the Local Variable Window.</p>  Same operation as this button.
Stack Trace	<p>Displays the stack trace results. Opens the Stack Window.</p>  Same operation as this button.
Trace	<p>This area displays the trace results. Opens the Trace View Window.</p>  Same operation as this button.
Console	<p>Opens the Console Window.</p>
Others	<p>Displays other windows. (Refer to "A.2 Sample Window") Displays a user-defined window list.</p>

(8) [Jump] menu

Source Text	<p>Displays the corresponding source text and source line, using the data value selected in the current window as the jump destination address. If no line information exists at the jump destination address, however, you cannot jump. Opens the Source Window. If an active Source Window is open, that window is displayed in the forefront (so that it can be manipulated).</p>
Assemble	<p>Disassembles and displays the results from the jump destination address specified by the data value selected in the current window. Opens the Assemble Window. If an active Assemble Window is open, that window is displayed in the forefront (so that it can be manipulated).</p>
Memory	<p>Displays the memory contents from the jump destination address specified by the data value selected in the current window. Opens the Memory Window. If an active Memory Window is open, that window is displayed in the forefront (so that it can be manipulated).</p>

(9) [Window] menu

New Window	Opens a new window displaying the same contents as those of the current window. This menu is valid only when the current window is Source Window , Assemble Window , Memory Window .
Cascade	Cascade display of the windows in the Main window.
Tile	Tile display of the windows in the Main window.
Arrange Icons	Rearranges the icons in the Main window.
Close All	Closes all windows, except the Main window.
Refresh	Updates the contents of the window with the latest data.
Active	Sets the window in the active status.
Static	Sets the window in the static status.
(Open Window)	Lists the windows that are open. The window with the check mark shown on the side of the figure is the current window. By selecting a window name, the selected window is used as the current window.

(10) [Help] menu

ID850NW Help	Displays the help.
Command Reference	Opens the Help window of COMMAND REFERENCE .
Main Window Help	Displays the help of the Main window.
Current Window Help	Displays the help of the current window.
About...	Displays the version of the ID850NW. Opens the About Dialog Box .

Toolbar(1) [Meaning of each button](#)(2) [Operation of Toolbar](#)**(1) Meaning of each button**

The meaning of each button on the toolbar is as follows. When the mouse cursor is placed on a button of the toolbar, a tool hint pops up several seconds later.

 Stop	Stops execution of the user program. Same function as [Run] menu -> [Stop].
 ReGo	Resets the CPU and executes the user program. Same function as [Run] menu -> [Restart].
 Go	Executes the user program from the current PC without resetting the CPU. Same function as [Run] menu -> [Go].

 Go	Ignores break points being set, and executes the user program. Same function as [Run] menu -> [Ignore break points and Go].
 Ret	The user program is executed until execution returns Same function as [Run] menu -> [Return Out]. Note: This command is used for a function described in C language.
 Step	Step execution (executes instructions in the program one by one.) If a function or subroutine is called, its instructions are executed one by one. Same function as [Run] menu -> [Step In].
 Over	Next step execution (executes the program, assuming a function/call statement as one step.) If a function or subroutine is called, its instructions are not executed on a step-by-step basis. Same function as [Run] menu -> [Next Over].
 Res	Resets the CPU. Same function as [Run] menu -> [CPU Reset].
 Open	Opens the View File Load Dialog Box . Same function as [File] menu -> [Open...].
 Load	Opens the Download Dialog Box . Same function as [File] menu -> [Download...].
 Proj	Opens the Project File Load Dialog Box . Same function as [File] menu -> [Project] -> [Open...].
 Src	Displays the source text. Opens the Source Window . Same function as [Browse] menu -> [Source Text].
 Asm	Displays the disassemble results. Opens the Assemble Window . Same function as [Browse] menu -> [Assemble].
 Mem	Displays the contents of the memory. Opens the Memory Window . Same function as [Browse] menu -> [Memory].
 Wch	Displays the watch contents. Opens the Watch Window . Same function as [Browse] menu -> [Watch].
 Reg	Displays the register contents. Opens the Register Window . Same function as [Browse] menu -> [Register].
 IOR	Displays the contents of the Peripheral I/O registers. Opens the IOR Window . Same function as [Browse] menu -> [I/O Register].
 Loc	Displays the local variable contents. Opens the Local Variable Window . Same function as [Browse] menu -> [Local Variable].
 Stk	Displays the stack trace results. Opens the Stack Window . Same function as [Browse] menu -> [Stack Trace].
 TrW	This area displays the trace results. Opens the Trace View Window . Same function as [Browse] menu -> [Trace].
 Mgr	Opens the Event Manager . Same function as [Event] menu -> [Event Manager...].

 Evnt	Registers and sets events. Opens the Event Dialog Box . Same function as [Event] menu -> [Event...].
 Brk	Registers and sets break events. Opens the Break Dialog Box . Same function as [Event] menu -> [Break...].
 Trc	Registers and sets trace events. Opens the Trace Dialog Box . Same function as [Event] menu -> [Trace...].

(2) Operation of Toolbar

Whether the toolbar is displayed or not can be specified by selecting [Option] -> [Tool Bar] from the menu bar.

This toolbar can be displayed in the following two modes. The modes are selected in the [Debugger Option Dialog Box](#).

Figure 6-2 Toolbar (Picture Only)



Figure 6-3 Toolbar (Picture and Text)



Window display area

This area displays various debug windows.

The displayed window can be changed in size or an icon can be created in this area.

Status bar

The status bar displays the status of the ID850NW and in-circuit emulator.

While the user program is being executed, the status bar is displayed in **red**.

Whether the status bar is displayed or not can be specified by selecting [Option] -> [Status Bar] from the menu bar.

Figure 6-4 Status Bar



(1) Program name	Displays the program file name indicated by the PC value. Source name: Displays the source file name indicated by the PC value. Line number: Displays the line number indicated by the PC value.
(2) Function name	Displays the function name indicated by the PC value.
(3) PC value	Displays the current PC value.

(4) CPU status	Refer to "Table 6-2 CPU status".
(5) IE status	Refer to "Table 6-3 IE status". (If there are two or more the statuses, they delimited with ' ' and displayed.)
(6) Break Cause	Refer to "Table 6-4 Break Cause".
(7) STEP mode	Displays the step execution mode. Displays that the following modes are selected from the [Option] menu: SRC..... Source mode INST Instruction mode AUTO Automatic mode
(8) Key input mode	Displays the key input mode. INS Insertion mode OVR..... Overwrite mode The Memory Window is fixed to OVR mode.

Table 6-2 CPU status

Display	Meaning
HOLD/STOP/IDLE	Hold, software stop mode, hardware stop mode, Idle mode
RESET	Reset mode
POW OFF	Power is not supplied to the target.

Table 6-3 IE status

Display	Meaning
RUN	User program execution in progress (the color of the status bar changes).
STEP	Step execution in progress.
TRC	Tracer operating.
BREAK	Break occurring.

Table 6-4 Break Cause

Display	Meaning
Manual Break	Forced break
Temporary Break	Temporary break
Event Break	Break by event
Software Break	Software break
Trace Full Break	Break due to trace full


Configuration Dialog Box

This dialog box is used to display and set the ID850NW operation environment. (Refer to "5.1 Setting Debugging Environment".)

This dialog box is automatically displayed after the ID850NW is started up.

However, no setting is required to read a project as the results of reading the project file are reflected in this dialog box. (Refer to "5.12.1 Debugging environment (project file)".)

Figure 6-5 Configuration Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

(Automatically when the ID850NW is started up)

Select [Option] -> [Configuration...] from the menu bar.

Explanation of each area

- (1) Chip
- (2) Internal ROM/RAM
- (3) Clock
- (4) Programmable I/O Area
- (5) Emulation Bus Size
- (6) Mask
- (7) Memory Mapping

(1) Chip

This area is used to select the chip name.

A chip name is selected from the drop-down list.

On the drop-down list, only the chip names registered to the registry from the device file installer are displayed.

This area can be specified only when the debugger is started up.

Remark By default, the type selected at the previous startup is displayed, but if that type is not registered, the first type registered is displayed.

(2) Internal ROM/RAM

This area is used to set the size of the internal RAM and internal ROM of the CPU. (Refer to "[Table 5-2 Type of Mapping Attribute](#)".)

For the ID850NW, the sizes of the ROM and RAM in the device file are fixed.

(3) Clock

In this area, specify the frequency (in MHz) of the CPU system clock. (unit:MHz).

To specify the CPU-system-clock frequency, use the keyboard, or select the frequency from the drop-down list.

(4) Programmable I/O Area

This area is used to specify use of the programmable I/O area and the start address.

The start address of the programmable I/O area can be specified, only if the device selected by (1) Chip supports the programmable I/O area. The start address of the programmable I/O area can be input by checking the check box when the programmable I/O area is used. The address is aligned to 16 KB.

Caution To use a programmable I/O area or extended I/O area, mapping that area as a target is required.

Remark In the case of a device with an extended I/O area with fixed addresses, the device selected by (1) Chip, Setting of this area is performed automatically.

(5) Emulation Bus Size

This area sets the bus size of the area mapped in the ROM emulation RAM.

Although it is possible to perform the setting again after starting up ID850NW, specify in accordance with the memory configuration on the target board.

Half Word	Accesses the area mapped by the ROM emulation RAM in half words (16 bits). Select when configuring a 16-bit bus using the ROM1 probe of the IE-70000-MC-NW-A.
Word	Accesses the area mapped by the ROM emulation RAM in words (32 bits). Select when configuring a 32-bit bus using both the ROM1 and ROM2 probes of the IE-70000-MC-NW-A.

(6) Mask

This area is used to mask the signal sent from the target.

The signal of a masked pin is not input to the in-circuit emulator.

Mask a pin only when the operation of the target system is not stable at the debugging stage.

(7) Memory Mapping

This area is used to set mapping by specifying the access size, memory attribute, and address.

(a) Access Size

Selects memory access size.

However, they cannot be selected when ROM Emulation RAM is selected for mapping attribute specification in

(b) Memory Attribute.

This setting is used to specify the access size on the ID850NW software; the operation of the external bus hardware is set in accordance with the settings of the MODE pin and I/O register.

8Bit	Accesses memory with ld.b instruction/st.b instruction.
16Bit	Accesses memory with ld.h instruction/st.h instruction.
32Bit	Accesses memory with ld.w instruction/st.w instruction.

(b) Memory Attribute

The following mapping attributes can be selected. Select a mapping attribute according to the usage. (Refer to "Table 5-2 Type of Mapping Attribute".)

Target	Selects the target memory.
I/O Protect [Note]	Selects the I/O protect area. (This area can be set only in the area set as Target.) The mapping unit is 1 byte.
ROM Emulation RAM	Selects a ROM emulation area using a ROM probe.

[Note] The area set as I/O Protect is not read unless it is registered to the [IOR Window](#) or [Watch Window](#) as an I/O port. To read this area, forcibly read it on these windows.

Caution The Target area and the ROM Emulation RAM area can be mapped in 1 MB units. As the latter area, only one successive area of up to 4 MB (in 1 MB units) can be set.

(c) Mapping Address

Specify the address to be mapped.

Input the higher and lower addresses from the keyboard.

(d) <Add> button, <Delete> button

These buttons are used to set and delete mapping.

When the <Add> button is clicked, the mapping specified with (b) [Memory Attribute](#) and (c) [Mapping Address](#) is set and displayed.

Remark Moreover, mapping unit adjustment is performed except I/O Protect, and if the mapping units is not matched, the minimum settable range including the specified address becomes the mapping target.


Function buttons

OK	Validates the current environment. Sets the environment and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Project...	Opens the Project File Load Dialog Box . If an error occurs while a project file is being opened or read, the ID850NW can no longer continue and is terminated.
Help	Displays the help window of this window.

Extended Option Dialog Box

This dialog box is used to display and set the extended options of the ID850NW. (Refer to "5.1 Setting Debugging Environment".)

Figure 6-6 Extended Option Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [Option] -> [Extended Option ...] from the menu bar.

Explanation of each area

- (1) Trace Memory Size
- (2) RAM Monitor
- (3) On Mouse Click:
- (4) Break Sound
- (5) Verify Check

(1) Trace Memory Size

This area is used to set the trace memory size in which execution of the user program is to be traced.

This dialog box can be set only for CPU cores with the TRCU (TRace Control Unit) incorporated.

The specifiable size is selected from five stages from Min (level 1) to Max (level 5).

The trace memory size in each level is as follows. (Note that these figures are for reference and differ from the actual number of trace frames.)

Table 6-5 Trace Memory Sizes

Level	Frames
1(Min)	4K
2	32K (Default)
3	64K
4	90K
5(Max)	128K

Caution As the memory size gets larger, the number of trace frames to be registered increases, but the response when reading out the trace data becomes worse.

(2) RAM Monitor

(a) Function:

Validates/invalidates the [RAM monitor function](#).

Since this function is realized by software emulation, the user program execution is temporarily stopped.

On	Enables this function. All the break events already set become invalid.
Off	Disables this function. (Default)

(b) Area:

Specify a sampling range for when the [RAM monitor function](#) is selected..

Whole	RAM sampling is to be performed, the entire memory space is the target. Caution The user program execution is stopped for a long time when a large number of windows are opened because the range from which memory is read out is wid. During program execution but when the tracer is stopped, it can be displayed mnemonic in the Trace View Window
IRAM+IOR	RAM sampling is to be performed, only the internal RAM area and the peripheral I/O register area are the target. (Default)

(c) Redraw Interval:

Specify a sampling time for when the [Real-time RAM monitor function](#) is selected (units: ms).

The RAM area can be sampled during emulation.

The sampling time can be specified in 100-ms units from 0 to 65500.

If 0 is specified, or if this area is blank, the data is not displayed in real time.

(3) On Mouse Click:

This area is used to select whether a software breakpoint or hardware breakpoint is set as the default breakpoint if a breakpoint is set in the point mark area by clicking the mouse button in the [Source Window](#) or [Assemble Window](#) (refer to "[5.4.2 Breakpoint setting](#)").

Soft break	Sets a software breakpoint. (Default) The mark of breakpoint is displayed in blue .
Hard break	Sets a hardware breakpoint. The mark of breakpoint is displayed in red or green .

(4) Break Sound

If the check box is checked, a beep sound is issued when a break occurs.

(5) Verify Check

This area is used to specify whether a verify check is performed when data has been written to memory.

A verify check is performed when download, memory fill, or memory copy is executed. A verify check is also performed when a variable or data is changed in the [Watch Window](#) or [Memory Window](#) is written to memory.

Function buttons


OK	Validates the settings and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Help	Displays the help window of this window.

Trace Option Dialog Box

This dialog box makes various settings related to trace such as the trace data selection.

Caution This dialog box is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-7 Trace Option Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Option] menu -> [Trace] -> [Trace Option...].

Explanation of each area

- (1) Trace Mode
- (2) Trace Data
- (3) Data Trace Address
- (4) Execution Trace

(1) Trace Mode

This area selects the mode in which the trace data is fetched.

Speed Priority	Traces the CPU execution in real time. Note, however, that not all the trace data may be fetched, depending on the program or trace trigger.
Trace Priority	If some trace data is likely to be lost, the CPU execution is temporarily stopped internally, and all the trace data is properly fetched.

(2) Trace Data

This area specifies the trace data to be fetched.

Execution Data	Traces the result of the fetching of the program execution. This makes it possible to ascertain the program execution flow. In (4) Execution Trace, set the branch factor to be traced.
Access Data	Traces the data access to the specified address. The data access cycle issued by DMA is not traced. In (3) Data Trace Address, set a specific address.

(3) Data Trace Address

This area specifies the addresses where the access data trace is performed.

Inputting to this area is possible only when "Access Data" is selected in (2) Trace Data.

The following values can be selected for the size (unit byte) **[Note]**. 4, 8, 16, 32, 64, 128, 256, 512, 1024

Addresses and sizes can be set for up to two locations.

Note, however, that the "Address2" setting is ignored when section trace conditions are enabled (section trace conditions are set and [Run] ->[Cond. Trace ON] is selected).

[Note] When the entered size is not one of the listed sizes, or when it is not a size whose boundary is not 1 KB, the size is automatically adjusted. (The lower address is aligned with 000, 400, 800, or C00.)

(4) Execution Trace

This area selects the trigger to start an execution trace from amongst the program execution branch triggers. Inputting to this area is possible only when "Execution Data" is selected in (2) [Trace Data](#).

The trace triggers that can be selected are divided into the following two types.

Before Branch	If the checked trigger in this area is an instruction of the branch origin, this instruction is fetched as trace data.
After Branch	The instruction of the branch destination of the selected trigger is fetched as trace data.

The selectable trace factors are listed below.

CALLT	Branch by CALLT instruction
CTRET	Branch by CTRET instruction
SWITCH	Branch by SWITCH instruction
JARL	Branch by JARL instruction
JR	Branch by JR instruction
JMP	Branch by JMP instruction
DISPOSE	Branch by DISPOSE instruction
RETI	Branch by RETI instruction
Bcond (taken)	Branch by conditional branch instruction (when condition is satisfied)
Bcond (not taken)	Branch by conditional branch instruction (when condition is not satisfied)
Interrupt	An interrupt (NMI/INT) is generated
Exception	An exception occurs

Caution The trace data fetched by the ID850NW consists only of the branch triggers selected in this area. If the number of trace triggers to be fetched is small, trace data supplementation (function to fill intervals between branch frames with pseudo trace data) may not be performed correctly. To add more trace data items to the list, select the [Option] menu -> [Supplement Data].


Function buttons

OK	Validates the settings and closes this dialog box.
Cancel	Cancels the changings and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Help	Displays this dialog box online help files.

Debugger Option Dialog Box

This dialog box is used to display and set the various options of the ID850NW.

Figure 6-8 Debugger Option Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [Option] menu -> [Debugger Option...].

Explanation of each area

- (1) Source Path
- (2) Default Extension
- (3) Open File History
- (4) Font
- (5) Project File
- (6) Tool Bar Pictures
- (7) Kanji
- (8) Tab Size
- (9) Startup Routine
- (10) DisAssemble
- (11) Watch Default

(1) Source Path

This area is used to specify the directory in which a source file or text file is searched.

(a) Base:

The directory is the basis of a relative path is displayed. The base directory is determined in the following sequence:

- (i) Directory to which the project file has been loaded
- (ii) Directory to which a load module or hex file has been loaded last
- (iii) Current directory of Windows

(b) Text box

This area is used to specify the directory searched.


To specify a directory, either directly input one to the text box, or click the <Browse...> button. A relative path can also be specified.

Opens the [Add Source Path Dialog Box](#) by clicking the <Browse...> button. To delimit paths, use ";" (semicolon) or "," (comma).

Remark1 Directories that contain ";" and/or "," in the source path can be specified.
Non-existent directories cannot be specified.

Remark2 Immediately after this dialog box has been opened, the base directory is selected and opened. If the selected directory has already been set for the source path, a source path is not added.

Figure 6-9 Add Source Path Dialog Box



(2) Default Extension

This area is used to specify the default extension.

Delimit extensions with " " (blank), ";" (semicolon) or "," (comma).

Source File:	Set the extension of a source file that is displayed when the Browse Dialog Box is opened by selecting [File] menu -> [Open...]. The default extension is " *.c, *.s ".
Load Module:	Set the extension of a load module that is displayed when the Download Dialog Box is opened. The default extension is " *.out ".

(3) Open File History

This area is used to set the number of histories of the open file displayed in the bottom field of the [File] menu. The default value is 4. If 0 is set, no history is displayed on the menu.

(4) Font

This area is used to specify the font displayed on the [Source Window](#), [Watch Window](#), [Quick Watch Dialog Box](#), [Local Variable Window](#), and [Stack Window](#). Clicking the <Font...> button opens the [Font Dialog Box](#) in which the font to be displayed and its size can be set.

(5) Project File

This area is used to set automatic saving and loading of the project file. (Refer to "[5.12.1 Debugging environment \(project file\)](#)".)

(a) Auto Save:

Sets whether the project file is automatically saved at the ID850NW termination.

On	Automatically saves the project file at the ID850NW termination.
Off	Does not automatically save the project file at the ID850NW termination.
Query	Displays the Exit Debugger Dialog Box at the ID850NW termination (Default).

(b) Auto Load:

Sets whether the project file is automatically loaded at the ID850NW start up.

On	Automatically loads the project file at the ID850NW start up. Specify the project file to be loaded in (c) Load Project File: .
Off	Does not automatically loads the project file at the ID850QB start up. (Default)

(c) Load Project File:

Specify the project file to be loaded automatically.

Set a project file name by inputting from the keyboard or clicking the <Browse...> button.

Clicking the <Browse...> button displays the [Browse Dialog Box](#).

(6) Tool Bar Pictures

This area sets the buttons to be displayed on the tool bar. (Refer to "[Toolbar](#)".)

Pictures and Text	Displays a button on which a graphic and character are displayed.
Pictures only	Displays a button with only graphic (Default).

(7) Kanji

Cannot be selected in this area.

(8) Tab Size

This area is used to set the tab size for each extension when files are displayed.

(a) Extension:

Set an extension. Input an extension from the keyboard, or select one from the drop-down list.

(b) Tab Size:

Select the tab size. Select how many spaces are displayed as a tab code (2, 4, or 8).

(c) Tab List:

Displays the tab size set for each extension.

(d) <Add> button

To change the tab size setting, select [\(a\) Extension:](#) and [\(b\) Tab Size:](#) and click the <Add> button.

(e) <Delete> button

To delete the tab size setting, select the setting to be deleted from Tab List and click <Delete> button.

(9) Startup Routine

This area is used to specify the first address , end address, and display start symbol of the text area (code area) of the start-up routine by symbols.

The source file can be opened if an object file in the load module format is downloaded in the [Download Dialog Box](#).

Begin label:	Specifies the symbol of the first address (Default: <code>_start</code>)
End label:	Specifies the symbol of the end address (Default: <code>_startend</code>)
main() label:	Specifies the display start symbol (Default <code>_main</code>)

Caution1 If the specified symbol is not correct, the source file cannot be opened until the PC reaches the address range of the corresponding source file. In addition, the start-up routine cannot be skipped by step execution.

Caution2 Be sure to specify this area. If this area is blank, the dialog box cannot be closed.

(10) DisAssemble

This area is used to set for disassemble display.

(a) Show Offset:

Specifies whether an offset (symbol + offset) is displayed during disassemble display.

When the offset is not displayed, only a symbol that matches a numeric value is displayed, if any. If no matching symbol is found, the numeric value is displayed as a hexadecimal number unchanged.

Label	Specifies whether the offset is displayed in the Label field. In the default condition, the offset is not displayed.
Mnemonic	Specifies whether the offset is displayed in the Mnemonic field. In the default condition, the offset is displayed.

(b) Register Name:

This area is used to select the method of displaying register names in mnemonics during disassemble display.

Function Name	Displays register names as function names or nicknames (Default).
Absolute Name	Displays register names as absolute names.

(11) Watch Default

This area is used to specify a symbol to be watched in the [Watch Window](#) etc. .

(a) Size:

Sets the default display size of data if [Adaptive] is specified.

Byte	8-bit display(Default)
Half Word	16-bit display
Word	32-bit display

(b) Radix:

Sets the default radix in which data is to be displayed if [Proper] is specified.

Hex	Displays data in hexadecimal numbers (Default).
Dec	Displays data in decimal numbers.
Oct	Displays data in octal numbers.
Bin	Displays data in binary numbers.
String	Displays data in character strings.

(c) Show Variable Type:

Select the display/non-display of variable type is specified.

On	Displays the type of a variable.
Off	Does not display the type of a variable (Default).

(d) Language:

Select the display/non-display of type of variable is specified.

C	Displays a C-like base number (Default).
ASM	Cannot be selected.

Function buttons


OK	Validates the settings and closes this dialog box.
Cancel	Cancels the changings and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Help	Displays this dialog box online help files.

Project File Save Dialog Box

This dialog box is used to save the current debugging environment to a project file. (Refer to "5.12.1 Debugging environment (project file)".)

Project files can be newly saved or saved under an existing file name in this dialog box.

Figure 6-10 Project File Save Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [File] menu -> [Project] -> [Save As...].

(To save a file of same name as a project file previously loaded or saved, select [File] menu -> [Project] -> [Save].)

Explanation of each area

- (1) Save in:, File name:
- (2) Save as type:

(1) Save in:, File name:

This area is used to specify a file name. A file name can be directly input, or selected from the list at the upper part of this area.

Up to 257 characters string with a extension can be specified.

(2) Save as type:

This area is used to specify the extension (*.prj) of the project file to be saved.

If the extension is omitted, ".prj" is appended as the default extension.

Function buttons

Save	Saves the debugging environment to the selected file. After saving, the dialog box is closed.
Cancel	Closes this dialog box without saving the file.
Help	Displays this dialog box online help files.


Project File Load Dialog Box

This dialog box is used to restore the debugging environment to the debugging environment saved to the project file. (Refer to "5.12.1 Debugging environment (project file)".)

If there is an active [Source Window](#) after a project file has been loaded, it is displayed at the top.

Caution Following ID850NW startup, if a project file with settings that differ from those of the target device at startup has been loaded, the target device specified at startup is used.

Figure 6-11 Project File Load Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

 Click the **Proj** button, or select [File] menu -> [Project] -> [Open...].

Explanation of each area

- (1) Look in:, File name:
- (2) Files of type:

(1) Look in:, File name:

This area is used to specify the file name to be loaded. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 characters string with a extension can be specified.

(2) Files of type:

This area is used to specify the extension (*.prj) of the file to be loaded.

Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.


Download Dialog Box

This dialog box is used to select the name and format of a file to be downloaded, and downloads memory contents to the in-circuit emulator and the target system. (Refer to "5.2 Download Function, Upload Function".)

If a load module file has been downloaded, the corresponding source file is searched, and the [Source Window](#) is automatically opened.

Caution If a file other than a load module file is loaded, source debugging cannot be executed.

Figure 6-12 Download Dialog Box



Remark The following dialog box appears while downloading and the downloading can be cancelled at any time. This dialog box is closed automatically after completing downloading.

Figure 6-13 The Progress of Download



- Opening
- Explanation of each area
- Function buttons

Opening



Click the **Load** button, or select [File] menu -> [Download...].

Explanation of each area

(1) Look in:, File name:

(2) Files of type:

(3) Load

(4) Reset

(5) Offset Address:

(1) Look in:, File name:

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 257 characters string with a extension can be specified.

Remark Two or more files can be specified in this dialog box. To specify two or more files, delimit each file name with " " (double quotation mark). Files can also be specified by clicking the mouse button while holding down the Shift or Ctrl key.

Up to 20 load module files can be downloaded.

(2) Files of type:

This area is used to specify the type (extension) of the file to be downloaded. (Refer to "[Table 5-3 Type of File That Can Be Downloaded](#)".)

Remark These are default extensions; other extensions can also be used.

The default extension of the displayed load module can also be specified in the [Debugger Option Dialog Box](#).

(3) Load

This area is used to set a load condition. This setting is valid only if a file in the load module format is specified.

This setting is valid only if a file in the load module format is specified.

Symbol	Specifies whether symbol information is read or not.
Object	Specifies whether object information is read (when checked, default) or not. (The object information is read even if this button is not checked when a HEX file is loaded.)
Erase	Cannot be selected.

Remark Specifies whether symbol information is read (when checked, default) or not. The memory capacity can be saved by not reading symbol information when a program consisting of two or more load module files is to be debugged and if the symbol information of some modules does not have to be read.

(4) Reset

This area is used to set a reset condition.

This setting is valid only if a file in the load module format is specified.

Symbol	Specifies whether symbol information is reset (when checked, default) or not. [Note]
CPU	Specifies whether the CPU is reset or not. (Not checked, default.)

[Note] When debugging a program consisting of two or more load module files, load each one of the load module files without resetting the symbol information. When downloading two or more load module files, take care that location addresses do not overlap.

(5) Offset Address:

This area is used to specify the offset address that is used when a file is loaded (for binary data, specify the start address). An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".) The default radix for inputting a numeric value is hexadecimal.


Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without loading the file.
Help	Displays this dialog box online help files.
Restore	Restores the input data to the original status.

Upload Dialog Box

This dialog box is used to set the name and format of the file to be saved, and save the set memory contents, etc., to that file. (Refer to "5.2 Download Function, Upload Function".)

Figure 6-14 Upload Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [File] menu -> [Upload...].

Explanation of each area

- (1) Save in:, File name:
- (2) Save as type:
- (3) Save Address:

(1) Save in:, File name:

This area is used to specify the file name to be saved. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Save as type:

This area is used to specify the type (extension) of the file to be saved.

The format of the data to be saved is determined by the extension. (Refer to ["Table 5-4 Type of File That Can Be Uploaded"](#))

However, if "All (*.*)" is selected, the data is saved in the default Intel extended Hex format.

Remark Extensions other than those listed can also be used.

(3) Save Address:

This area is used to specify the range of address to be saved.

An address can be also specified by a symbol or expression. (Refer to ["Table 5-6 Specifying Symbols"](#).)

The default radix for inputting a numeric value is hexadecimal.

Function buttons


Save	Saves the file according to the setting.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.
Restore	Restores the status before this dialog box was opened.

Load Module List Dialog Box

This dialog box can be used to check the file name and file path name of a load module that has already been downloaded. (Refer to "5.2 Download Function, Upload Function".)

By using the <Download...> button, The [Download Dialog Box](#) can be opened and a load module can be downloaded.

Figure 6-15 Load Module List Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [File] menu -> [Load Module...].

Explanation of each area

- (1) [Module list](#)
- (2) [Add Path](#)

(1) Module list

This area displays the names of the load module files that have already been downloaded.

(a) No.

The numbers displayed indicate the sequence in which the load module file names were read.

(b) File name

The file names are displayed with the full path if [\(2\) Add Path](#) is checked; otherwise, only the file names will be displayed.

Caution If symbol information has been reset in the [Reset Debugger Dialog Box](#), or if symbol information has been reset in the [Download Dialog Box](#), the load module file names downloaded before that are cleared.

(2) Add Path

This should be checked to specify load module file names are displayed with the path in [\(1\) Module list](#).

Function buttons

Close	Closes this dialog box.
Help	Displays this dialog box online help files.
Download...	Opens the Download Dialog Box . A new load module can be downloaded. The file name of the newly downloaded module will be added to the file name display area when the Download dialog box is closed.

Source Window

This window is used to displays source files or text files. (Refer to "5.3 Source Display, Disassemble Display Function".) In addition to [Breakpoint setting](#) and [Mixed display mode \(Source Window\)](#), a number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window. Moreover, there are two statuses, [Active status](#) and [static status](#), for this window. When the window is in the active status, it has the [Trace Result with Linking Window](#). Moreover, the items selected in the window with [Drag & drop function](#) can be used in another window. (Refer to "5.13 Functions Common to Each Window".)

Caution If program codes is described in an include file and these codes are included in multiple files, the line numbers and addresses do not correspond on a one-to-one bases. In such an include file, function that indicates the correspondence relationship between line numbers and addresses dose not correctly operate.

Figure 6-16 Source Window

```

Source (main.c)
Search... << >> Watch Quick... Refresh Close
49 main()
50 {
51     int    i, j, result;
52     long   moto_time;
53     long   moto_over;
54     TIME_T tim;
55
56
57     MM = 0xB3;
58
59     TUM1 = 0x200;
60     CE1 = 1;
61     time over = 0;
62
63     OVIC1 = 0x02;
64     EI();
65     for(i=0; i<3; i++)
66     {
67         switch(i)
68         {
69             case 0:
70                 moto_time = TM1;
71                 moto_over = time_over;
72                 for(j=0; j<50; j++){
73                     memory_copy((char *)aaa, after_aaa,

```

- [Opening](#)
- [Explanation of each area](#)
- [\[View\] menu \(Source Window-dedicated items\)](#)
- [Context menu](#)
- [Function buttons](#)

Opening

 Click the **Src** button, or select [Browse] menu -> [Source Text].

(This window is automatically opened if the corresponding source file exists after the download module file has been downloaded.)

Explanation of each area

- (1) Point mark area
- (2) Current PC mark area
- (3) Line number/address display area
- (4) Source text display area

(1) Point mark area

This area is used for the [Event Setting Status \(Event Mark\)](#) and program codes (*) display, as well as [Breakpoint setting](#).

Remark The program code is displayed only when the symbol information downloaded by the load module is read. Breakpoints can be set or deleted by clicking with the mouse on this program code. (if "*" is not displayed for the line, the breakpoint is set on the line above or below the line, which ever has "*" displayed.)

If an event has been set for the corresponding line, one of the marks listed in the following table is displayed. The color of the "B" mark differs according to the breakpoint type and status. (When a breakpoint is set in this area, it is enabled at the same time that it is set.)

Table 6-6 Event Setting Status (Event Mark)

Mark	Meaning
B (blue)	Software breakpoint is set.
B (red)	Valid hardware breakpoint (after execution) is set.
B (green)	Valid hardware breakpoint (before execution) is set. Note: Breaks before execution are set with priority(Nx85ET).
B (black)	Invalid hardware breakpoint is set. This hardware breakpoint can be validated on the Event Manager or Break Dialog Box .
E	Event condition is set.
L	Event link condition is set.
T	Trace event is set.
A	Multiple events are set.

Remark If an address range is specified as the address condition of the event, the lower addresses of the range are displayed. The mask specification of the address condition is not reflected.

(2) Current PC mark area

The mark ">", which indicates the current PC value (PC register value), is displayed in this area. Clicking this mark with the mouse displays a pop-up window that shows the PC register value. By double-clicking the current PC mark area, the program can be executed up to a specified line.

(3) Line number/address display area

This area displays the line numbers of a source file or text file.

Red indicates line numbers for which corresponding program code exists, and black indicates line numbers for which corresponding program code does not exist. In the [Mixed display mode \(Source Window\)](#), disassemble display addresses are displayed in gray.

(4) Source text display area

This area displays source files and text files.

Yellow indicates the current PC line, and **red** indicates lines where a valid breakpoint is set. In the [Mixed display mode \(Source Window\)](#), source lines are displayed in the regular color.

Moreover, this area also provides the following functions for lines (start address of program code) and addresses where the cursor has been placed.

- [Come Here], [Start From Here] (Refer to "[Table 5-9 Type of Execution](#)")
- [Drag & drop function](#)
- [Context menu](#)

Caution If a Program code does not exist on the source line, the top address of the line above or below the line on which a program code exists is manipulated by these functions.

These functions cannot be performed in the following cases. The corresponding menu will be dimmed and cannot be selected.

- If a file other than a source file is displayed
- While the user program is being executed

[View] menu (Source Window-dedicated items)

The following items are added in the [\[View\] menu](#), when the Source Window is active.

Create Break Event	Sets a break event that occurs if the selected variable is accessed.
Break when Access to this Variable	Sets a break event that occurs if the selected variable is accessed for read/write.
Break when Write to this Variable	Sets a break event that occurs if the selected variable is accessed for write.
Break when Read from this Variable	Sets a break event that occurs if the selected variable is accessed for read.
Clear	Deletes a break event corresponding to the selected variable.
Event?	Displays the event information of a line at the cursor position or a selected variable name. If an event is set, the Event Dialog Box is opened.
Mix	Turns on/off Mixed display mode (Source Window) .

Context menu

Move...	Moves the display position. Opens the Source Text Move Dialog Box .
Mix	Turns on/off Mixed display mode (Source Window) .
Add Watch...	Adds the specified data to the Watch Window . Opens the Add Watch Dialog Box .
Symbol...	Displays the address of the specified variable or function, or the value of the specified symbol. Opens the Symbol To Address Dialog Box .
Break when Access to this Variable	Sets a break event that occurs if the selected variable is accessed for read/write.
Break when Write to this Variable	Sets a break event that occurs if the selected variable is accessed for write.
Break when Read from this Variable	Sets a break event that occurs if the selected variable is accessed for read.
Clear	Deletes a break event corresponding to the selected variable.
Event?	Displays the event information of a line at the cursor position or a selected variable name. If an event is set, the Event Dialog Box is opened.
Come Here	Executes the program from the current PC to the cursor position. (Refer to " Table 5-7 Break Types ".)
Change PC	Sets the address at the cursor position to the PC.
Break Point	Sets or deletes a hardware breakpoint at the cursor position. Note: Breaks before execution (B) are set with priority.
Software Break Point	Sets or deletes a software breakpoint at the cursor position.
Assemble	Disassembles and displays starting from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) Opens the Assemble Window . If an active Assemble Window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) Opens the Memory Window . If an active Memory Window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

Search...	<p>Opens the Source Search Dialog Box and searches a character string of the source text. If a character string is selected in the source text display area, the Source Search Dialog Box is opened to search the character string.</p> <p>If no character string is selected, the Source Search Dialog Box is opened with nothing specified to be searched.</p> <p>Specify a search method in the Source Search Dialog Box.</p> <p>The results of search is highlighted in the Source window.</p> <p>This is the same operation as selecting [View] menu -> [Search...].</p>
<<	<p>Searches forward (upward on screen) for the text that satisfies the search condition set in the Source Search Dialog Box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p>
>>	<p>Searches backward (downward on screen) for the text that satisfies the search condition set in the Source Search Dialog Box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p>
Stop(during a search)	Stops searching.
Watch	<p>Adds the variables selected in the source text display area to the Watch Window.</p> <p>If the Watch Window is not opened, it is opened.</p> <p>If no text is selected in the source text display area, the Watch Window is only opened.</p> <p>This is the same operation as selecting [View] menu -> [View Watch].</p>
Quick...	<p>Temporarily displays the contents, such as a variable, selected in the source text display area in the Quick Watch Dialog Box. If no text is selected in the source text display area, the Quick Watch Dialog Box is only opened.</p> <p>This is the same operation as selecting [View] menu -> [Quick Watch...].</p>
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Source Search Dialog Box

This dialog box is used to search the contents of a file in the [Source Window](#). (Refer to "5.3.1 Source display".)

By setting each item and then clicking the <Find Next> button, searching can be started. By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Source Window can be used for the search.

Figure 6-17 Source Search Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

When the [Source Window](#) is the current window, select [View] menu -> [Search...], or click the <Search...> button in the same window.

Explanation of each area

- (1) [Find What:](#)
- (2) [Match Case](#)
- (3) [Direction](#)

(1) Find What:

This area is used to specify the data to be searched. (Up to 256 character.)

In the default condition, the string selected in the window that called this dialog box is displayed. As necessary, the character string displayed can be changed.

Up to 16 input histories can be recorded.

(2) Match Case

This should be checked to distinguish between uppercase and lowercase.

(3) Direction

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search. Searches data backward (downward on screen) from the current position of the cursor (default).


Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (during searching)	Stops searching.
Cancel	Closes this dialog box. (During searching, this button is replaced by the <Stop> button.)
Help	Displays this dialog box online help files.

Source Text Move Dialog Box

This dialog box is used to specify a file to be displayed in the [Source Window](#) and the position from which displaying the file is to be started. (Refer to "[5.3.1 Source display](#)".)

Figure 6-18 Source Text Move Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [Source Window](#) is the current window, select [View] menu -> [Move...].

Explanation of each area

- (1) Option
- (2) To:

(1) Option

This area is used to select the input mode when the display start position is specified.

(a) Address/Symbol

This should be selected to specify by an address (or symbol).

(b) Line/File

This should be selected to specify by a line number (or file name). To search the file name, use the <Browse...> button.

(2) To:

This area is used to specify the file name or address to be displayed.

Up to 16 input histories can be recorded.

- When the **(a) Address/Symbol** is selected

Specifies the address from which display is to be started.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or a expression. (Refer to "[Table 5-6 Specifying Symbols](#)".)

Clicking the <OK> button displays the source text so that the source line corresponding to the specified address value can be viewed.

- When the **(b) Line/File** is selected

Specifies the line number (or a file name) from which display is to be started.

The line number is specified by **[[path name] file name]# line number**.

The default radix for inputting a numeric value is decimal.

The file name can be specified just by the file name, or using the absolute path and relative path.

If just the file name or the relative path was specified, the file in the source path specified in the [Debugger Option Dialog Box](#) is searched.

The file whose specified line number was specified as the first line is displayed by clicking the <OK> button.

When the file name is omitted, the currently displayed file is displayed from the specified line. If the line number is omitted, the file is displayed from the first line.

Function buttons


OK	Starts displaying the source text from the specified position.
Cancel	Closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Assemble Window

This window is used to disassemble and display programs. It is also used to execute [Online assembly](#). (Refer to "5.3 Source Display, Disassemble Display Function".) The results of online assembly are also reflected in the [Memory Window](#).

In addition to [Breakpoint setting](#), a number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window. Moreover, there are two statuses, [Active status](#) and [static status](#), for this window. When the window is in the active status, it has the [Trace Result with Linking Window](#). Moreover, the items selected in the window with the [Drag & drop function](#) can be used in another window. (Refer to "5.13 Functions Common to Each Window".)

Figure 6-19 Assemble Window



- Opening
- Explanation of each area
- [View] menu (Assemble Window-dedicated items)
- Context menu
- Function buttons
- Related operations

Opening



Click the **Asm** button, or select [Browse] menu -> [Assemble].

Explanation of each area

- (1) Point mark area
- (2) Current PC mark area
- (3) Address specification area
- (4) Disassemble display area

(1) Point mark area

This area is used for [Event Setting Status \(Event Mark\)](#) and [Breakpoint setting](#).

(2) Current PC mark area

The mark ">", which indicates the current PC value (PC register value), is displayed in this area.

By double-clicking the current PC mark area, the program can be executed up to a specified line.

(3) Address specification area

This area displays the disassembly start address.

(4) Disassemble display area

This area displays the labels and code data of addresses, and disassembled mnemonics.

This area displays source files and text files. Yellow indicates the current PC line, and red indicates lines where a valid breakpoint is set.

It can be [Online assembly](#) in the mnemonic field.

This area also provides the following functions:

- [Come Here], [Start From Here] (Refer to "[Table 5-9 Type of Execution](#)")
- [Drag & drop function](#)
- [Context menu](#)

[View] menu (Assemble Window-dedicated items)

The following items are added in the [\[View\] menu](#), when the Assemble Window is active.

Event?	Displays the event information of the address at the cursor position. If an event is set, the Event Dialog Box is opened.
--------	--

Context menu

The menu items are effective for the selected line or item, not the position where the mouse pointer was clicked (same operation as when selecting the main menu with the same name).

Move...	Moves the display position. Opens the Address Move Dialog Box .
Add Watch...	Adds the specified data to the Watch Window . Opens the Add Watch Dialog Box .
Symbol...	Displays the address of the specified variable or function, or the value of the specified symbol. Opens the Symbol To Address Dialog Box .
Come Here	Executes the program from the current PC to the cursor position. (Refer to " Table 5-7 Break Types ".)
Change PC	Sets the address at the cursor position to the PC.
Break Point	Sets or deletes a hardware breakpoint at the cursor position. Remark : Breaks before execution (B) are set with priority(Nx85ET).
Software Break Point	Sets or deletes a software breakpoint at the cursor position.
Source Text	Displays the corresponding source text and source line, using the data value at the cursor position as the jump destination address. (Refer to " 5.13.2 Jump function ".) If no line information exists at the jump destination address, however, you cannot jump. Opens the Source Window . If an active Source Window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) Opens the Memory Window . If an active Memory Window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

Search...	Opens the Assemble Search Dialog Box and searches for a character string of mnemonics. Specify a search method in the Assemble Search Dialog Box . The results of search is highlighted in the Assemble Window. This is the same operation as selecting [View] menu -> [Search...].
<<	Searches forward (upward on screen) for the contents that satisfy the search condition set in the Assemble Search Dialog Box , starting from the address at the cursor position. This button is displayed as the <Stop> button during a search.
>>	Searches backward (downward on screen) for the contents that satisfy the search condition set in the Assemble Search Dialog Box , starting from the address at the cursor position. This button is displayed as the <Stop> button during a search.
Stop(during a search)	Stops searching.
Watch	Adds the symbols selected in (4) Disassemble display area to the Watch Window . If the Watch Window is not opened, it is opened. If no text is selected in (4) Disassemble display area , the Watch Window is only opened. This is the same operation as selecting [View] menu -> [View Watch].
Quick...	Temporarily displays the contents, such as symbols, selected in (4) Disassemble display area on the Quick Watch Dialog Box . Opens the Quick Watch Dialog Box. If no text is selected in the disassemble display area, the Quick Watch Dialog Box is only opened. This is the same operation as selecting [View] menu -> [Quick Watch...].
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

(1) Online assembly

To change the disassembled contents, move the cursor to the mnemonic field (the overwrite and insertion modes are alternately selected by pressing the Insert key).

If an attempt is made to move the cursor to another line after the disassembled contents have been changed in the mnemonic field, the new contents are checked. If the new contents are illegal, the code data on the line where the contents have been changed is indicated as "***".

The contents changed in the mnemonic field are written into the memory by pressing the Enter key. By pressing the Enter key, the new contents are checked. If even one line is illegal, the new contents are not written into the memory. To discard the contents, press the ESC key.

If the contents are correct and if the Enter key is pressed, the contents are written to the memory, and then the cursor moves to the next line in the mnemonic field, so that the data on the next line can be changed.

Caution If the number of new instruction bytes is less than the number of previous instruction bytes as a result of changing, as many 'nop' instructions as necessary are inserted. If the number of new instruction bytes is more than the number of previous instruction bytes, the next instruction is overwritten. In this case also, as many 'nop' instructions as necessary are inserted. The same applies to instructions that straddle over source lines.

Assemble Search Dialog Box

This dialog box is used to search the contents in the [Assemble Window](#). (Refer to "5.3.2 Disassemble display".)

Successive character strings included in an input character string and disassembler character string are compared as one blank character.

By setting each item and then clicking the <Find Next> button, searching can be started. By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Assemble Window can be used for the search.

Figure 6-20 Assemble Search Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

When the [Assemble Window](#) is the current window, select [View] menu -> [Search...], or click the <Search...> button in the same window.

Explanation of each area

- (1) [Find What:](#)
- (2) [Match Case](#)
- (3) [Scan Whole Region](#)
- (4) [Direction](#)
- (5) [Address:](#)

(1) Find What:

This area is used to specify the data to be searched. (Up to 256 character.)

In the default condition, the string selected in the window that called this dialog box is displayed. As necessary, the character string displayed can be changed. Up to 16 input histories can be recorded.

(2) Match Case

This should be checked to distinguish between uppercase and lowercase.

(3) Scan Whole Region

This should be checked to search the entire specified range.

(4) Direction

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search. Searches data backward (downward on screen) from the current position of the cursor (Default).

(5) Address:

This area is used to specify the address to be searched.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".)

Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (searching)	Stops searching.
Cancel	Closes this dialog box. (During searching, this button is replaced by the <Stop> button.)
Help	Displays this dialog box online help files.

Address Move Dialog Box

This dialog box is used to specify the start address from which displaying, as follows.

- [Memory Window](#)
- [Assemble Window](#)
- [IOR Window](#)

Figure 6-21 Address Move Dialog Box (Example: When Memory Window Is Open)



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

When the target window is the current window, select [View] menu -> [Move...].

Explanation of each area

(1) To:

This area is used to specify an address.

In the default condition, the string selected in the window that called this dialog box, or the current PC value etc. is displayed. As necessary, the character string displayed can be changed.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".) Up to 16 input histories can be recorded.

Function buttons

OK	The corresponding window is displayed from the address.
Cancel	Closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Symbol To Address Dialog Box

This dialog box is used to display the address of the specified variable or function, or the value of the specified symbol. (Refer to "5.3.4 Convert symbol (symbol to address)".)

Figure 6-22 Symbol To Address Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [View] menu -> [Symbol...].

Explanation of each area

- (1) Symbol:
- (2) Conversion result display area
- (3) Radix:

(1) Symbol:

This area is used to specify the variable, function name, symbol name, or line number to be converted. (Refer to "Table 5-6 Specifying Symbols".)

The default radix for inputting a numeric value is decimal. Up to 16 input histories can be recorded.

To change the contents of this area, click the <OK> button. The conversion result will be displayed in (2) Conversion result display area.

(2) Conversion result display area

If bit symbol have been specified, they are converted to the Address.bit format. Also, equations that include bit symbols cannot be specified.

The variable, address of the function, value of the symbol, address of the line number, or value of the expression specified in (1) Symbol: is displayed. The address value of an I/O port name or peripheral I/O registers name, the register contents of a register name, or flag value of a PSW flag name is displayed.

(3) Radix:

This area is used to select the radix of the data to be displayed in (2) Conversion result display area.

Hex	Hexadecimal number (Default)
Dec	Decimal number
Oct	Octal number
Bin	Binary number

Function buttons

OK	If the contents of (1) Symbol: have been changed, converts the symbol. After conversion, closes the dialog box if the contents of (1) Symbol: have not been changed.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status. If the <OK> button has already been clicked, the data is restored to the status immediately after the <OK> button was clicked.
Help	Displays this dialog box online help files.

Watch Window

This window is used to display and change specified watch data. (Refer to "5.6 Watch Function".)

This window can also display wide-ranging watch data (such as global variables and public symbols) in real time even during program execution, in the same way as the [Memory Window](#).


The results of updating and rewriting data in this window will be reflected in the [Memory Window](#).

Watch data is registered by clicking the <Watch...> button in the [Source Window](#) or [Assemble Window](#). (Refer to "5.6.3 Registering and deleting watch data".)

This window allows easy setting of breakpoints to variables via a [Context menu](#).

Remark If a local variable and a global variable exist with the same name, the local variable takes priority.

Figure 6-23 Watch Window



- Opening
- Explanation of each area
- [View] menu (Watch Window-dedicated items)
- Context menu
- Function buttons

Opening

 Click the **Wch** button, or select [Browse] menu -> [Watch].

Explanation of each area

- (1) Left field (symbol name display area)
- (2) Right field (data value display/setting area)

(1) Left field (symbol name display area)

This area is used to display variable names, symbol names and types, and tag names of structures or unions.

'+' is prefixed to the displayed arrays, pointer variables, and structures or unions. These variables are expanded and displayed as follows when they are double-clicked:

Table 6-7 Watch Window Display Format (Symbol)

First Character	Meaning	
+	Array, pointer variable, or structure/union Expanded display is performed by double-clicking "+" (first character changes from "+" to "-").	
	Array	By double-clicking the "+", all the elements of the variable are displayed in accordance with the type of the array variable.
	Pointer variable	By double-clicking the "+", the data indicated by the pointer is displayed.
	Structure/union	By double-clicking the "+", all the members of the structure/union are displayed in accordance with the type of the member variable. If a structure or union is defined in the structure or union, the structure name or union name of the internal structure or union is also displayed. The internal structure or union can be also expanded by using "+".
-	Expanded display variable Expanded display is canceled by double-clicking "-" (first character changes from "-" to "+").	

Remark If an array has too many variables and takes too long to expand, a warning message is displayed.

Registered watch data changes are performed in the [Change Watch Dialog Box](#) opened by selecting the item to be changed and then selecting [Context menu](#) -> [Change Watch...]. A line with an expanded hierarchy, such as the elements of an array, and members of structures and unions cannot be deleted.

If an access breakpoint is set for a variable or a symbol in the Watch Window, the symbol name display area is highlighted in gold.

(2) Right field (data value display/setting area)

This area is used to display and change watch data values. A value is updated when execution is stopped.

To save a value, select [File] menu -> [Save As...]. This area is blank if getting data has failed.

Values are changed through direct input. The location to be changed is displayed in **red** and the contents of the change are written into the target memory when the Enter key is pressed. The previous value can be canceled by the ESC key.

The display format is as follows:

Table 6-8 Watch Window Display Format (Data)

Display Data	Contents
Integer	Hexadecimal (0x xxxx) Decimal (xxxx) Octal (0 xxxx) Binary (0b xxxx)
Character	"Character"
Enumeration type	Member name
If scope is specified	Displayed in accordance with specified scope.
Floating-point type	Single precision/double precision supported The input/display format is as follows: [+ -] inf [+ -] nan [+ -] integer e [+ -]exponent [+ -] integer.fraction[e [+ -]exponent
"?"	Data that has been invalidated because of a change in the scope or optimized compiling

Remark The radix of a data value can be changed on the [Context menu](#) for each variable. The display format of "integer" can be changed on the [Debugger Option Dialog Box](#).

[View] menu (Watch Window-dedicated items)

When this window is the current window, The following items are added on [\[View\] menu](#).

Only the selected item is subject to this manipulation.

Create Break Event	Creates a break event by using the selected item as follows.
Beak when Access to this Variable	Creates a break event that can be accessed for read/write.
Break when Write to this Variable	Creates a break event that can be accessed for write.
Break when Read from this Variable	Creates a break event that can be accessed for read.
Clear	Deletes a break event corresponding to the selected item.
Event?	Displays the event information of the variable selected. If an event is set, the Event Dialog Box is opened.
Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers.
String	Displays character strings.
Proper	Displays the default value of each variable . Symbols are displayed in accordance with the setting of the Debugger Option Dialog Box (Default).
Byte	Displays in 8-bit units.
Half Word	Displays in 16-bit units.
Word	Displays in 32-bit units.
Adaptive	Displays the default value of each variable (Default). Only this item is valid for a symbol in C language. Symbols in assembly language are displayed in accordance with the setting of the Debugger Option Dialog Box .
Up	Moves up one line.
Down	Moves down one line.
Compulsion Read	Forcibly reads peripheral I/O registers that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in the Add I/O Port Dialog Box .

Context menu

The menu items are effective for the selected line or item, not the position where the mouse pointer was clicked (same operation as when selecting the main menu with the same name).

Break when Access to this Variable	Creates a break event that can be accessed for read/write by using the selected item.
Break when Write to this Variable	Creates a break event that can be accessed for write by using the selected item.
Break when Read from this Variable	Creates a break event that can be accessed for read by using the selected item.
Clear	Deletes a break event corresponding to the selected item.
Event?	Displays the event information of the variable selected. If an event is set, the Event Dialog Box is opened.
Change Watch...	Changes the selected watch data. Opens the Change Watch Dialog Box .
Delete Watch	Deletes the selected watch data from the window.
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable . Symbols are displayed in accordance with the setting of the Debugger Option Dialog Box (Default).
Byte	Displays the selected line in 8-bit units.
Half Word	Displays the selected line in 16-bit units.
Word	Displays the selected line in 32-bit units.
Adaptive	Displays the selected line as the default value of each variable (Default). Only this item is valid for a symbol in C language. Symbols in assembly language are displayed in accordance with the setting of the Debugger Option Dialog Box .
Up	Moves the selected line one line up.
Down	Moves the selected line one line down.


Function buttons

Add...	Opens the Add Watch Dialog Box . If watch data is specified and the <Add...> button is clicked in the Add Watch Dialog Box , the specified watch data is added to the Watch Window.
Delete	Deletes the selected watch data from the window.
Up	Moves the selected line one line up.
Down	Moves the selected line one line down.
Refresh	Updates the contents of this window with the latest watch data.
Close	Closes this window.

Quick Watch Dialog Box

This dialog box is used to temporarily display or change specified watch data. (Refer to "5.6 Watch Function".)

Figure 6-24 Quick Watch Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [Source Window](#) or [Assemble Window](#) is the current window, select [View] menu -> [Quick Watch...], or click the <Quick...> button in same window.

Explanation of each area

- (1) Name:
- (2) Symbol name display area
- (3) Data value display/setting area
- (4) Display radix selection area (upper left field)
- (5) Display size selection area (second upper left field)
- (6) Number:

(1) Name:

This area is used to specify the watch data to be displayed.

In the default condition, the string selected in the window that called this dialog box is displayed. As necessary, the character string displayed can be changed. Up to 16 input histories can be recorded.

If the contents of this area have been changed, the data specified can be displayed in the field below by clicking the <View> button.

(2) Symbol name display area

This area is used to display watch data (variable names, symbol names and types, and tag names of structures or unions). (Refer to "(1) Left field (symbol name display area)" in the [Watch Window](#).)

This area cannot be edited.

(3) Data value display/setting area

This area is used to display and change data values. (Refer to "(2) Right field (data value display/setting area)" in the [Watch Window](#).)

(4) Display radix selection area (upper left field)

This area is used to select the display radix.

Proper	Variable: Displays the default value of each variable. Symbol: Displays data with the radix set in the Debugger Option Dialog Box .
Hex	Displays in hexadecimal numbers.
Dec	Displays in decimal numbers.
Oct	Displays in octal numbers.
Bin	Displays in binary numbers.
String	Displays as a character string.

(5) Display size selection area (second upper left field)

This area is used to select the display size.

If the display size is fixed, such as when a variable in C language or register is to be displayed, it cannot be changed.

Adaptive	Variable: Displays the default value of each variable. Symbol: Displays data with the size set in the Debugger Option Dialog Box .
Byte	Displays in 8-bit units.
Half Word	Displays in 16-bit units.
Word	Displays in 32-bit units.

(6) Number:

This area is used to specify the number of data to be displayed (blank or a number of 1 to 256).

If this area is blank, data is displayed as a simple variable. If a number of 1 or more is specified, data is displayed as an array variable in the [Watch Window](#).

If an array variable is displayed, "+" is prefixed to the data. By double-clicking this "+", all the elements of the data are expanded and displayed in accordance with the type of the data ("-" is prefixed to the expanded data. If this "-" is double-clicked, the expanded display is canceled).

If the number of data to be displayed is fixed, such as when a variable in C language or register is to be displayed, the specified number of data is invalid.

Function buttons


View	Displays the data specified in (1) Name : in the field below.
Add	Adds the data specified in (1) Name : to the Watch Window .
Close	Closes this dialog box. Data that has not actually been written to the target memory will be canceled.

Add Watch Dialog Box

This dialog box is used to register watch data to be displayed in the [Watch Window](#). (Refer to "[5.6 Watch Function](#)".)

Multiple data with the same symbol name can be registered.

Figure 6-25 Add Watch Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [View] menu -> [Add Watch...], or click the <Add...> button in the [Watch Window](#).

Explanation of each area

- (1) [Name:](#)
- (2) [Radix:](#)
- (3) [Size:](#)
- (4) [Number:](#)

(1) Name:

This area is used to specify symbol to be added to the [Watch Window](#).

In the default condition, the string selected in the window that called this dialog box is displayed. As necessary, the character string displayed can be changed. This area is blank if no character string is selected. Up to 16 input histories can be recorded.

The input format is as follows:

Table 6-9 Watch Window Input Format

- Variable Name of C language	
Variable expression : Variable Name	
Variable expression [Constant value Variable Name]	Elements of array
Variable expression . Member name	Entity members of structure/union
Variable expression -> Member name	Members of structure/union indicated by pointer
*Variable expression	Value of pointer variable
&Variable expression	Address where variable is located
- Register name	
- IOR name, IOR bit name	
- Label and address of immediate value	
- Register name.bit	
- IOR name.bit	
- Label name.bit , address of immediate value.bit	
- Specification of scope	

How a variable is handled when a scope is specified is as follows:

Table 6-10 How a Variable Is Handled When a Scope Is Specified

Scope Specification	Program Name	File Name	Function Name	Variable Name
prog\$file#func#var	prog	file	func	var
prog\$file#var	prog	file	global	var
prog\$func#var	prog	global	func	var
prog\$var	prog	global	global	var
file#func#var	current	file	func	var
file#var	current	file	global	var
func#var	current	current	func	var
var	current	current	current	var

(2) Radix:

This area is used to select the display radix. (Refer to "[\(4\) Display radix selection area \(upper left field\)](#)" in the [Quick Watch Dialog Box](#).)

(3) Size:

This area is used to select the display size. (Refer to "[\(5\) Display size selection area \(second upper left field\)](#)" in the [Quick Watch Dialog Box](#).)

(4) Number:

This area is used to specify the number of data to be displayed. (Refer to "[\(6\) Number:](#)" in the [Quick Watch Dialog Box](#).)

Function buttons

Add	Adds the specified data to the Watch Window . The dialog box remains open.
OK	Adds the specified data to the Watch Window . Closes this dialog box.
Cancel	Closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Change Watch Dialog Box


This window is used to change the data on a line selected in the [Watch Window](#). (Refer to "5.6 Watch Function".)

A line with an open hierarchy, such as the elements of an array, and members of structures and unions cannot be changed.

When watch data is changed, the contents of the selected line are replaced with the new data.

The symbol name can be changed even if it results in duplication of a name already in use with existing data.

Figure 6-26 Change Watch Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

When the [Watch Window](#) is the current window, select [View] menu -> [Change Watch...].

Explanation of each area

- (1) Name:
- (2) Radix:
- (3) Size:
- (4) Number:

(1) Name:

This area is used to change a symbol name on a line selected in the [Watch Window](#). (Refer to "(1) Name:" in the [Add Watch Dialog Box](#).)

(2) Radix:

This area is used to change the display radix on a line selected in the [Watch Window](#). (Refer to "(4) Display radix selection area (upper left field)" in the [Quick Watch Dialog Box](#).)

(3) Size:

This area is used to change the display size on a line selected in the [Watch Window](#). (Refer to "(5) Display size selection area (second upper left field)" in the [Quick Watch Dialog Box](#).)

(4) Number:

This area is used to change the number of data to be displayed on a line selected in the [Watch Window](#). (Refer to "(6) Number:" in the [Quick Watch Dialog Box](#).)

Function buttons

Add	Cannot be selected.
OK	Replaces the data on a line selected in the Watch Window with the specified data, and then closes this dialog box.
Cancel	Closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.


Local Variable Window

This window is used to display the local variable in the current function and change the local variable values. (Refer to "5.6 Watch Function".)

It is linked with the [Jump function](#) of the [Stack Window](#), and displays the local variable in the function jumped when jumping to the [Source Window](#).

A number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Figure 6-27 Local Variable Window



- [Opening](#)
- [Explanation of each area](#)
- [Context menu](#)
- [Function buttons](#)

Opening



Click the **Loc** button, or select [Browse] menu -> [Local Variable].

Explanation of each area

- (1) Left field (local variable name display area)
- (2) Right field (local variable value display/setting area)

(1) Left field (local variable name display area)

This area displays local variable name. (Refer to "(1) Left field (symbol name display area)" in the [Watch Window](#).)

Auto, Internal Static, and Register variables can be displayed. This area cannot be edited.

(2) Right field (local variable value display/setting area)

This area is used to display and change local variable values. (Refer to "(2) Right field (data value display/setting area)" in the [Watch Window](#).)

[View] menu (Local Variable Window-dedicated items)

When this window is the current window, the following items are added on [\[View\] menu](#).

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers.
String	Displays character strings.
Proper	Displays the default value of each variable (Default).

Context menu

The menu items are effective for the selected line or item, not the position where the mouse pointer was clicked (same operation as when selecting the main menu with the same name).

Add Watch...	Opens the Add Watch Dialog Box .
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable . Symbols are displayed in accordance with the setting of the Debugger Option Dialog Box (Default).

Function buttons

Refresh	Updates the contents of this window with the latest watch data.
Close	Closes this window.

Stack Window

This window is used to display or change the current stack contents of the user program. (Refer to "5.6.7 Stack trace display function".)


The window corresponding to the stack contents can be jumped to using the [Jump function](#).

A number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Caution The stack trace display function may not operate correctly if there is a function that does not create a stack frame.

Remark [ERROR] may be displayed during prologue or epilogue processing of a function.

Figure 6-28 Stack Window



- Opening
- Explanation of each area
- [View] menu (Stack Window-dedicated items)
- Context menu
- Function buttons

Opening

 Click the **Stk** button, or select [Browse] menu -> [Stack Trace].

Explanation of each area

- (1) Left field (stack frame number display area)
- (2) Center field (stack frame contents display area)
- (3) Right field (stack contents display/setting area)

(1) Left field (stack frame number display area)

This area assigns numbers to and displays the stack contents.

A stack frame number is a natural number starting from 1. The shallower the nesting of the stack, the higher the number. This means that a function having stack number one higher than that of a certain function is the function that calls the certain function.

(2) Center field (stack frame contents display area)

This area displays the stack frame contents.

It displays function names or local variable names. Note, however, that this area cannot be edited.

(a) If the stack contents consist of a function

They are displayed as follows:

[program name\$file name#function name (argument list) #line number]

If this line is double-clicked, the operation will be the same as jumping to the [Source Window](#) of the [Jump function](#) (i.e., the local variable in the function to which execution has jumped will be displayed in the [Local Variable Window](#)). If the function has a local variable, the local variable will be displayed on the next and subsequent lines.

(b) If the stack contents consist of a local variable

Its type and name are displayed. (Refer to "[Table 6-7 Watch Window Display Format \(Symbol\)](#)".)

Note that the internal Static and Register variables are not displayed.

(3) Right field (stack contents display/setting area)

This area is used to display or change the stack contents.

(a) If the stack contents are a function

"--" is displayed and the function cannot be changed.

(b) If the stack contents are a local variable

The variable value is displayed. (Refer to "[Table 6-8 Watch Window Display Format \(Data\)](#)".)

[View] menu (Stack Window-dedicated items)

When this window is the current window, The following items are added on [\[View\] menu](#).

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers.
String	Displays character strings.
Proper	Displays the default value of each variable (Default).

Context menu

Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable . Symbols are displayed in accordance with the setting of the Debugger Option Dialog Box (Default).
Source Text	Displays the corresponding source text and source line from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) If no line information exists at the jump destination address, however, you cannot jump. Opens the Source Window . If an active Source Window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Disassembles and displays starting from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) Opens the Assemble Window . If an active Assemble Window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. (Refer to " 5.13.2 Jump function ".) Opens the Memory Window . If an active Memory Window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

Refresh	Updates the contents of this window with the latest watch data.
Shrink <<<	Collapses the local variable list of the selected function.
Expand >>> (when the <Shrink<<<> button is clicked)	Displays the local variable list of the selected function.
Close	Closes this window.

Memory Window

This window is used to display and change the memory contents. (Refer to "5.7 Memory Manipulation Function".) Other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Moreover, there are two statuses, [Active status and static status](#), for this window. When the window is in the active status, it has the [Trace Result with Linking Window](#), [Jump function](#). (Refer to "5.13 Functions Common to Each Window".)


Remark The display start position when the this window is opened is as follows:

First time: Display starts from the first address of the RRM function area.

Second and subsequent times: Display starts from the address at which an active status window was closed.

(if an active status window has never been closed, display starts from the first display start position).

Figure 6-29 Memory Window



- Opening
- Explanation of each area
- [View] menu (Memory Window-dedicated items)
- Context menu
- Function buttons

Opening



Click the **Mem** button, or select [Browse] menu -> [Memory].

Explanation of each area

(1) Addr

(2) +0 +1 +2....

(3) 0 1 2 3....

(1) Addr

This area displays memory addresses.

(2) +0 +1 +2....

This area is used to display and change memory contents.

Values are changed through direct input. The location to be changed is displayed in red and the contents of the contents of the change are written into the target memory when the Enter key is pressed. The previous value can be canceled by the ESC key. Up to 256 bytes can be specified at one time.

(3) 0 1 2 3....

This area is used to display and change the memory contents in ASCII characters.

This area is displayed when [View] menu -> [Ascii] is selected.

Data can be changed in this area in the same manner as in the memory display area.

The changing method is the same as in (2) +0 +1 +2....

[View] menu (Memory Window-dedicated items)

The following items are added in the [View] menu , when the Memory Window is active.

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (Default).
Nibble	Displays in 4-bit units.
Byte	Displays in 8-bit units (Default).
Half Word	Displays in 16-bit units.
Word	Displays in 32-bit units.
Ascii	Selects whether ASCII characters are displayed or not. Checked: Displayed Not checked: No display (Default)
Little Endian	Displays in little endian (Default).
Big Endian	Displays in big endian.

Context menu

The menu items are effective for the selected line or item, not the position where the mouse pointer was clicked

(same operation as when selecting the main menu with the same name).

Move...	Moves the display position. Opens the Address Move Dialog Box .
Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (Default).
Nibble	Displays in 4-bit units.
Byte	Displays in 8-bit units (Default).
Half Word	Displays in 16-bit units.
Word	Displays in 32-bit units.
Ascii	Selects whether ASCII characters are displayed or not. Checked: Displayed Not checked: No display (Default)

Function buttons

Search...	Opens the Memory Search Dialog Box and searches for character strings from the displayed memory contents, or memory contents. Selected data (a memory value) is displayed in the Memory Search dialog box as data to be searched. If the Memory Search dialog box is opened without data specified, specify data from the keyboard. The results of the search is highlighted in the Memory window.
<<	Searches the memory contents satisfying the search condition set in the Memory Search Dialog Box , forward (upward on screen) from the address at the cursor position. This button is displayed as the <Stop> button during a search.
>>	Searches the memory contents satisfying the search condition set in the Memory Search Dialog Box , backward (downward on screen) from the address at the cursor position. This button is displayed as the <Stop> button during a search.
Stop(searching)	Stops searching.
Refresh	Updates the contents of the window with the latest data.
Modify...	Opens the DMM Dialog Box .
Close	Closes this window.

Memory Search Dialog Box


This dialog box is used to search the memory contents of the part of the [Memory Window](#) at which the cursor is located. (Refer to "[5.7 Memory Manipulation Function](#)".)

If the cursor is placed in (2) +0 +1 +2.... in the Memory Window, the specified data is treated as a binary data string, and if the cursor is placed in (3) 0 1 2 3...., the specified data is treated as an ASCII character string, and the contents of these respective areas are searched.

By setting each item and then clicking the <Find Next> button, searching can be started. By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Memory Window can be used for the search.

Caution Non-mapped, peripheral I/O registers, and I/O protect areas are not searched.

Figure 6-30 Memory Search Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [Memory Window](#) is the current window, select [View] menu -> [Search...], or click the <Search...> button in the same window.

Explanation of each area

- (1) Find What:
- (2) Unit:
- (3) Scan Whole Region
- (4) Direction
- (5) Address:

(1) Find What:

This area is used to specify the data to be searched.

In the default condition, the string selected in the window that called this dialog box is displayed. As necessary, the character string displayed can be changed. Up to 16 input histories can be recorded.

(a) When searching in (2) +0 +1 +2....

Up to 16 data items can be specified. Delimit each data with a "blank character".

(b) When searching in (3) 0 1 2 3....

Up to 256 characters can be specified. A "blank character" in the data is treated as a blank character.

(2) Unit:

This area is used to specify the number of bits of the data to be searched in (2) +0 +1 +2.....

Byte	Searches the data as 8-bit data (Default).
Half Word	Searches the data as 16-bit data.
Word	Searches the data as 32-bit data.

(3) Scan Whole Region

This should be checked to search the entire specified range.

(4) Direction

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search. Searches data backward (downward on screen) from the current position of the cursor (Default).

(5) Address:

This area is used to specify the address to be searched.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "Table 5-6 Specifying Symbols".)


Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (searching)	Stops searching.
Cancel	Closes this dialog box.(During searching, this button is replaced by the <Stop> button.)
Help	Displays this dialog box online help files.

Memory Fill Dialog Box

This dialog box is used to fill the memory contents in the [Memory Window](#) with specified codes (fill code). (Refer to "[5.7 Memory Manipulation Function](#)".)

Figure 6-31 Memory Fill Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Edit] menu -> [Memory] -> [Fill...].

Explanation of each area

- (1) [From:](#)
- (2) [fill code =>](#)

(1) From:

This area is used to specify the memory address range whose contents are filled.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".)

(2) fill code =>

This area is used to specify the data (fill code) used when filling the range specified in (1) [From:](#). Up to 16 binary data strings (byte data strings) can be specified. Delimit each data with a "blank character".

Function buttons


OK	Fills the specified data in accordance with a given condition.
Stop (filling)	Stops filling.

Cancel	Closes this dialog box. (During filling, this button is replaced by the <Stop> button.)
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Memory Copy Dialog Box

This dialog box is used to copy the memory contents in the [Memory Window](#). (Refer to "[5.7 Memory Manipulation Function](#)".)

Figure 6-32 Memory Copy Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Edit] menu -> [Memory] -> [Copy...].

Explanation of each area

(1) Address

This area is used to specify the copy source and copy destination addresses.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".)

(a) From:

Specify the address range (start address -- end address) of the copy source.

(b) To:

Specify start address of the copy destination.


Function buttons

OK	Copies the memory contents in accordance with a given condition.
Stop (copying)	Stops copying.
Cancel	Closes this dialog box. (During copying, this button is replaced by the <Stop> button.)
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Memory Compare Dialog Box

This dialog box is used to compare the memory contents in the [Memory Window](#). (Refer to "[5.7 Memory Manipulation Function](#)".)

Figure 6-33 Memory Compare Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Edit] menu -> [Memory] -> [Compare...].

Explanation of each area

(1) Address

This area is used to specify the comparison source address and comparison destination address.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "[Table 5-6 Specifying Symbols](#)".)

(a) Mem1:

Specify the address range (start address -- end address) of the comparison source.

(b) Mem2:

Specify the start address of the comparison destination.


Function buttons

OK	Compares the memory contents in accordance with a given condition. If no difference is found as a result of comparison, " Wf200: No difference encountered. " is displayed. If a difference is found, the Memory Compare Result Dialog Box is opened.
Stop (comparison)	Stops memory comparison.
Cancel	Closes this dialog box. (During comparison, this button is replaced by the <Stop> button.)
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Memory Compare Result Dialog Box

This dialog box is displayed if any difference is found in the memory contents when the memory has been compared in the [Memory Compare Dialog Box](#). (Refer to "5.7 Memory Manipulation Function".)

Figure 6-34 Memory Compare Result Dialog Box



- [Explanation of each area](#)
- [Function buttons](#)

Explanation of each area

(1) (comparison result display area)

This area displays the results of comparing the memory. Only differences that have been found as a result of comparison are displayed.

(a) Mem1 Addr

Displays a comparison source address in which a difference has been found.

(b) Memory

Displays the data in which a difference has been found (Left: Comparison source data, Right: Comparison destination data).

(c) Mem2 Addr

Displays the comparison destination address at which a difference has been found.


Function buttons

Close	Closes this dialog box.
Help	Displays this dialog box online help files.

DMM Dialog Box

This dialog box is used to set addresses and data for DMM (Dynamic Memory Modification). (Refer to "[5.7.3 Modifying memory contents \(DMM function\)](#)".)

Figure 6-35 DMM Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Edit] menu -> [Memory] -> [Modify...], or click the <Modify...> button in the [Memory Window](#).

Explanation of each area

- (1) [Address:](#)
- (2) [Data:](#)
- (3) [Data Size:](#)

(1) Address:

This area is used to specify the address to which data is to be written.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol or expression. (Refer to "Table 5-6 Specifying Symbols".)

(2) Data:

This area is used to specify the data to be written to the memory address specified in (1) Address:.

The default radix for inputting a numeric value is hexadecimal.

One binary data string can be specified at one time. Specify the data size in (3) Data Size:.

(3) Data Size:

This area is used to specify the size of the data specified in (2) Data: to be written.

Byte	Writes the data as 8-bit data.
Half Word	Writes the data as 16-bit data.
Word	Writes the data as 32-bit data.

Function buttons

OK	Writes the data in accordance with a given condition.
Cancel	Closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.


Register Window

This window is used to display and change registers (program registers/system registers). (Refer to "5.8 Register Manipulation Function".)

Other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Each area in this window are the jump pointer of the [Jump function](#).

Figure 6-36 Register Window



Register		Refresh	Close
r0 (zero)	00000000		
r1	00108000		
r2	00000002		
r3 (sp)	001003DC		
r4 (gp)	00108000		
r5 (tp)	00000000		
r6	00100014		
r7	0000000A		
pc	000005A2		
eip	000005A2		
+eipaw	00000001		
fep	00000000		
+fepaw	000000FF		
+ecr	00000080		
+psw	00000001		

- Opening
- Explanation of each area
- [View]menu (Register Window-dedicated items)
- Context menu
- Function buttons

Opening



Click the **Reg** button, or select [Browse] menu -> [Register].

Explanation of each area

- (1) Upper field (program registers display area)
- (2) Lower field (system registers display area)

(1) Upper field (program registers display area)

This area is used to display and change the program registers.

Register values are changed through direct input. The location to be changed is displayed in **red** and the contents of the change are written into the target memory when the Enter key is pressed. The previous value can be canceled by the ESC key.

Caution When overflow of a register occurs due to an illegal value entered by the user, the register will be updated with a value of 0xFFFFFFFF.

(2) Lower field (system registers display area)

This area is used to display and change the system registers.

By double-clicking "+", flag name and flag value are displayed (first character changes from "+" to "-"). Expanded display is canceled by double-clicking "-" (first character changes from "-" to "+").

Register values are changed through direct input. The location to be changed is displayed in **red** and the contents of the change are written into the target memory when the Enter key is pressed. The previous value can be canceled by the ESC key.

Caution When overflow of a register occurs due to an illegal value entered by the user, the register will be updated with a value of 0xFFFFFFFF.

[View]menu (Register Window-dedicated items)

The following items are added in the [\[View\] menu](#) , when the Register Window is active.

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (Default).
Pick Up	Displays only the registers selected in the Register Select Dialog Box .
Select...	Opens the Register Select Dialog Box .

Context menu

Add Watch...	Registers a selected character string to the Watch window. Opens the Add Watch Dialog Box .
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in binary numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers (Default).
Pick Up	Displays only the registers selected in the Register Select Dialog Box .
Select...	Selects the register to be displayed Opens the Register Select Dialog Box .


Function buttons

Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Register Select Dialog Box

This dialog box is used to select registers that are not displayed in the [Register Window](#). (Refer to "5.8 Register Manipulation Function".)

Figure 6-37 Register Select Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [Register Window](#) is the current window, select [View] menu -> [Select...].

Explanation of each area

(1) Display:, No Display:

This area is used to select registers that are displayed in the [Register Window](#), and those that are not.

(a) Display:

Registers displayed in the [Register Window](#).

(b) No Display:

Registers not displayed in the [Register Window](#).

(c) Button

The following buttons are used to change register to be displayed in the [Register Window](#).

<< Show	Moves the register selected from the (b) No Display: list to (a) Display:.
Hide >>	Moves the register selected from the (a) Display: list to (b) No Display:.
<< Show All	Moves all registers to (a) Display:.
Hide All >>	Moves all registers to (b) No Display:.

Two or more registers can be selected by clicking any of the above buttons while holding down the Ctrl or Shift key.

Function buttons

OK	Reflects the selection in this dialog box in the Register Window and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

IOR Window

This window is used to display and change the contents of peripheral I/O registers and the I/O ports that have been registered in the [Add I/O Port Dialog Box](#). (Refer to "5.8 Register Manipulation Function".)

A number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Caution However, that the values of read-only peripheral I/O registers and I/O ports cannot be changed. In addition, the peripheral I/O registers and I/O ports that cause the device to operate when they are read are read-protected and therefore cannot be read. To read these registers, select a register, and select and execute [Compulsion Read] from the [Context menu](#).

Remark1 The display start position when the window is opened is as follows.

First time: Display from peripheral I/O registers of minimum address

Second and subsequent times: Display from first peripheral I/O registers when window was last closed

Remark2 If the device supports programmable I/O registers and a programmable I/O area has been set in the [Configuration Dialog Box](#), the programmable I/O registers and expansion peripheral I/O registers are also displayed. If the value of an I/O port address is defined, the I/O port name is displayed in light color.

Figure 6-38 IOR Window

Name	Attribute	Value
CSC0	R/W 16	03FFF060 FFF1
CSC1	R/W 16	03FFF062 0000
BPC	R/W 16	03FFF064 0000
BSC	R/W 16	03FFF066 AA92
BEC	R/W 16	03FFF068 0000
BHC	R/W 16	03FFF06A 0000
VSWC	R/W 1, 8	03FFF06E 77
VSWL0	R/W 1	03FFF06E.0 1
VSWL1	R/W 1	03FFF06E.1 1
VSWL2	R/W 1	03FFF06E.2 1
SUWL0	R/W 1	03FFF06E.4 1
SUWL1	R/W 1	03FFF06E.5 1
SUWL2	R/W 1	03FFF06E.6 1
DSA0L	R/W 16	03FFF080 FBBF
DSA0H	R/W 16	03FFF082 0E4E
DDA0L	R/W 16	03FFF084 BDFD

- Opening
- Explanation of each area
- [View] menu (IOR Window-dedicated items)
- Context menu
- Function buttons

Opening



Click the **IOR** button, or select [Browse] menu -> [IOR].

Explanation of each area

- (1) Name
- (2) Attribute
- (3) Value

(1) Name

This area displays the names of peripheral I/O registers and I/O ports.

If the value of an I/O port address is not defined, the I/O port name displayed in light color.

(2) Attribute

This area displays the attributes of peripheral I/O registers and I/O ports.

This area displays the read/write attributes, access types, and displays absolute addresses from the left side. When the bit peripheral I/O registers is displayed, bit-offset value is also displayed.

It can be specified whether this area is displayed or not, by selecting [View] menu -> [Attribute].

Read/Write Attribute	
R	Read only
W	Write only
R/W	Read/write
*	Register that is read via an emulation register to prevent the device from operating when this register is read. To read this attribute directly from a peripheral I/O registers, execute [View] menu -> [Compulsion Read]. Even a write-only peripheral I/O registers can also be read via an emulation register. However, some devices do not support this function.
Access Type	
1	Can be accessed in Bit units.
8	Can be accessed in Byte units.
16	Can be accessed in Half Word units.
32	Can be accessed in Word units.

(3) Value

This area is used to display and change the contents of a peripheral I/O registers and I/O port.

The contents are displayed differently as follows, depending on the attribute:

Black Display	Read only or read/write
--	Write only
**	Value changes if read

Values are changed through direct input. The location to be changed is displayed in **red** and the contents of the contents of the change are written into the target memory when the Enter key is pressed. The previous value can be canceled by the ESC key.

Note that the values of read-only peripheral I/O registers and I/O ports cannot be changed.

The value of read-protected peripheral I/O registers and I/O ports can be read by selecting [Context menu](#) -> [Compulsion Read].

[View] menu (IOR Window-dedicated items)

When this window is the current window, the following items are added on [\[View\] menu](#).

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers (default).
Sort By Name	Displays in alphabetical order.
Sort By Address	Displays in address order (default).
Unsort	Does not sort.
Attribute	Switches on/off display of (2) Attribute .
Pick Up	Displays only the registers selected in the IOR Select Dialog Box .
Select...	Opens the IOR Select Dialog Box .
Compulsion Read	Forcibly reads the peripheral I/O registers that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in the Add I/O Port Dialog Box .

Context menu

Move...	Opens the Address Move Dialog Box .
Add Watch...	Opens the Add Watch Dialog Box .
Add I/O Port...	Opens the Add I/O Port Dialog Box .
Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers (default).
Sort By Name	Displays in alphabetical order.
Sort By Address	Displays in address order (default).
Unsort	Does not sort.
Attribute	Switches on/off display of (2) Attribute .
Pick Up	Displays only the registers selected in the IOR Select Dialog Box .
Select...	Opens the IOR Select Dialog Box .
Compulsion Read	Forcibly reads the peripheral I/O registers that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in the Add I/O Port Dialog Box .

Function buttons


Refresh	Updates the contents of this window with the latest watch data.
Close	Closes this window.

IOR Select Dialog Box

This dialog box is used to select peripheral I/O registers (IOR) and I/O ports that are not displayed the [IOR Window](#). (Refer to "5.8 Register Manipulation Function".)

It is also used to specify the sequence in which registers and ports are displayed.

Figure 6-39 IOR Select Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [IOR Window](#) is the current window, select [View] menu -> [Select...].

Explanation of each area

- (1) Display:, Pick Up, No Display:
- (2) Arrange
- (3) Sort by

(1) Display:, Pick Up, No Display:

This area is used to select IOR or I/O ports that are displayed in the [IOR Window](#), and those that are not.

(a) Display:

The IOR or I/O ports displayed in the [IOR Window](#).

(b) No Display:

The IOR or I/O ports not displayed in the [IOR Window](#).

(c) Pick Up

The following buttons are used to change IOR or I/O ports to be displayed in the [IOR Window](#). Two or more registers can be moved by clicking any of the above buttons while holding down the Ctrl or Shift key.

<< Show	Moves IOR or I/O ports selected from (b) No Display: list to (a) Display: .
Hide >>	Moves IOR or I/O ports selected from (a) Display: list to (b) No Display: .
<< Show All	Moves all IOR or I/O ports to (a) Display: .
Hide All >>	Moves all IOR or I/O ports to (b) No Display: .

(2) Arrange

The following buttons are used to change the display sequence in **(a) Display:**.

Top	Moves the selected IOR or I/O port to the top of the list.
Up	Moves the selected IOR or I/O port one line up.
Down	Moves the selected IOR or I/O port one line down.
Bottom	Moves the selected IOR or I/O port to the bottom of the list.

(3) Sort by

The following buttons are used to change the display sequence in **(b) No Display:**.

Name	Displays in alphabetical order.
Address	Displays in address order.


Function buttons

OK	Reflects the selection in this dialog box in the IOR Window and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the status before this dialog box was opened.
Help	Displays this dialog box online help files.

Add I/O Port Dialog Box

This dialog box is used to register an I/O port to be added to the [IOR Window](#). (Refer to "[5.8 Register Manipulation Function](#)".)

Figure 6-40 Add I/O Port Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

Select [Option] menu -> [Add I/O Port...].

Explanation of each area

- (1) I/O Port List:
- (2) Name:
- (3) Address:
- (4) Access
- (5) Read / Write

(1) I/O Port List:

This area lists the I/O ports currently registered.

If a new I/O port is registered, it is added to this list. An I/O port already registered can be selected and changed or deleted by [Function buttons](#).

(2) Name:

This area is used to specify an I/O port name to be added (up to 15 characters long).

(3) Address:

This area is used to specify the address of the I/O port to be added.

The default radix for inputting a numeric value is hexadecimal. An address can be also specified by a symbol. (Refer to "[Table 5-6 Specifying Symbols](#)".)

The address that can be set in this area is either a Target area address or peripheral I/O registers area address.

(4) Access

This area is used to select the access size of the I/O port to be added.

Byte	8-bit unit (default)
Half Word	16-bit unit
Word	32-bit unit

(5) Read / Write

This area is used to specify the access attribute of the I/O port to be added.

In the default condition, all the attributes are not checked (i.e., the I/O port can be both read and written).

Function buttons

OK	Reflects the results of addition in the IOR Window and closes this dialog box.
Cancel	Cancels the changing, closes this dialog box.
Restore	Restores the original status.
Help	Displays this dialog box online help files.
Add	Adds an I/O port of the specified address.
Change	Changes the setting of the I/O port selected in (1) I/O Port List .
Delete	Deletes the I/O port selected in (1) I/O Port List .

Trace View Window

This window used to display the trace results. (Refer to "5.9 Trace Function".)

Display updates are performed during breaks or during step execution.


This window has [Mixed display mode \(Trace View Window\)](#).

Also, It has "5.13.3 Trace Result with Linking Window".

A number of other operations using [Context menu](#), [Function buttons](#), etc., can be performed in this window.

Caution This window is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-41 Trace View Window



- Opening
- Explanation of each area
- [View]menu (Trace View Window-dedicated items)
- Context menu
- Function buttons

Opening



Click the TrW button, or select [Browse] -> [Trace] on the menu.

Explanation of each area

- (1) Point mark display area
- (2) Tracer control mode display area
- (3) Trace result display area

(1) Point mark display area

This area displays the [Event Setting Status \(Event Mark\)](#).

If an execution event or access event is set at the corresponding trace address, the mark corresponding to the type of the event is displayed.

The mark displayed is not that during trace but an event mark that is set when the trace result is displayed.

(2) Tracer control mode display area

This area displays the type of tracer control mode.

A	unconditional traced or section traced frame
T	Delay trigger frame
N	Frame for which not all the trace data was fetched

(3) Trace result display area

(a)	(b)	(c)	(d)	(e)				
Frame	Time	Address	Data	Status	Address	Data	Status	DisAsm
00247	2648	0000032A	63370900	BRM1				st.w r6, 0x8[sp]
00248	2658	00000358	BFFF64FF	M1				jarl _Sub2, lp
00249	2666	000002BC	F515	BRM1				br _Sub2+0x2e
		----< Last Data >----						
00263	2804	00000402	035F0300	BRM1				ld.b 0x3[sp], r11
00252	2692	000002DA	0A58	BRM1				mov r10, r11
00253	2702	000002E6	42063F00	M1				dispose 0x4, lp, [lp]
00254	2712	0000035C	23370900	BRM1				ld.w 0x8[sp], r6
00255	2722	00000360	BFFF90FF	M1				jarl Func3, lp
00256	2732	000002F0	851D	BRM1				br Func3+0x30
000E7	0744	00000100	00070100	BRM1				-----

This area displays the trace results.

Whether each of the following sub-areas is displayed or not can be selected in the [Trace Data Select Dialog Box](#).

(a) Frame

This area displays the trace frame number.

However, complemented frames other than branch frames and access frames do not have frame numbers and this area is left blank.

(b) Time

This area displays the number of clocks required for the target chip from the execution start of the program to the execution start of an instruction of each frame or generation of memory access cause.

The display contents can be switched between clock count display and time display in the [Trace Data Select Dialog Box](#).

(c) Address Data Status (fetch access display)

This area displays the result of fetching the program.

(i) Status

The following types of statuses are available:

Program fetch display

BRM1	Fetching of first byte of first instruction after branch If the fetch address is the start of the symbol, the first line is highlighted in blue.
M1	Fetching of first byte of instruction
Blank	6th byte and 8th byte fetch of the instruction, or Invalid fetch on occurrence of interrupt

Remark When a 6-byte or 8-byte instruction code is displayed, the first 4 bytes are displayed in the first frame, and the other bytes are displayed in the second and third frames. If two instructions are executed at the same time, one frame is displayed on two lines. The instruction code at the lower address is displayed on the first line and the instruction code at the higher address is displayed on the second line.

(ii) Address Data

This area displays the address and data.

Address	Displays the fetch address
Data	Displays the fetch data

(d) Address Data Status (data access display)

This area displays the result of accessing data.

Status

R	Data read
W	Data write

(e) DisAsm (mnemonic display)

This area displays the result of disassembly (only when the (i) Status is BRM1 or M1).

Remark To display instruction codes when two instructions are simultaneously executed, one instruction is displayed on the first line, and the other instruction is displayed on the second line.

[View]menu (Trace View Window-dedicated items)

The following items are added in the [\[View\] menu](#) , when the Trace View Window is active.

Select...	Selects the contents to be displayed. Opens the Trace Data Select Dialog Box .
Mix	Specifies whether the source file are displayed in mixed display mode, or not displayed. Checked: Mixed display Not checked: No display (default)
Window Synchronize	Links the Trace View Window with the following windows: (Refer to " 5.13.3 Trace Result with Linking Window ".) A checked window is linked.
Source Text	Links the Source Window .
Assemble	Links the Assemble Window .
Memory	Links the Memory Window .

Context menu

Move...	Moves the display position. Opens the Trace Move Dialog Box .
Trace Clear	Clears the trace data.
Select...	Selects the contents to be displayed. Opens the Trace Data Select Dialog Box .
Mix	Specifies whether the source file are displayed in mixed display mode, or not displayed. Checked: Mixed display Not checked: No display (default)
Window Synchronize	Links the Trace View Window with the following windows: (Refer to " 5.13.3 Trace Result with Linking Window ".)
Source Text	Links the Source Window .
Assemble	Links the Assemble Window .
Memory	Links the Memory Window .
Source Text	Displays the corresponding source text and source line, using the data value at the cursor position as the jump destination address (refer to " 5.13.2 Jump function "). If no line information exists at the jump destination address, however, you cannot jump. Opens the Source Window . If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Disassembles and displays starting from the jump destination address specified by the data value at the cursor position (refer to " 5.13.2 Jump function "). Opens the Assemble Window . If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).

Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position (refer to " 5.13.2 Jump function "). Opens the Memory Window . If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).
--------	--

Function buttons


Search...	Cannot be selected.
<<	Cannot be selected.
>>	Cannot be selected.
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Trace Data Select Dialog Box

This dialog box is used to select items to be displayed in the [Trace View Window](#). (Refer to "[5.9 Trace Function](#)".)

Caution This dialog box is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-42 Trace Data Select Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the [Trace View Window](#) is the current window, select [View] -> [Select...] menu.

Explanation of each area

- (1) Item
- (2) Radix

(1) Item

This area is used to select items to be displayed in the [Trace View Window](#). Displaying the following items may or may not be selected. The field checked is displayed.

Frame	(a) Frame field
Timetag	(b) Time field Whether the clock or time is displayed can be selected.
Instruction Fetch Address	Address field in (c) Address Data Status (fetch access display)
Instruction Fetch Data	Data field in (c) Address Data Status (fetch access display)
Instruction Fetch Status	Status field in (c) Address Data Status (fetch access display)
Memory Access Address	Address field in (d) Address Data Status (data access display)
Memory Access Data	Data field in (d) Address Data Status (data access display)
Memory Access Status	Status field in (d) Address Data Status (data access display)
DisAssemble	(e) DisAsm (mnemonic display) field

(2) Radix

This area is used to select the radix in which data is to be displayed. Displaying the following items may or may not be selected.

Instruction Fetch Data	Data field in (c) Address Data Status (fetch access display)
Memory Access Data	Data field in (d) Address Data Status (data access display)
HEX	Displays hexadecimal numbers. (default)
DEC	Displays decimal numbers.
OCT	Displays octal numbers.
Bin	Displays binary numbers.

Function buttons


OK	Reflects the results of selection in this dialog box in the Trace View Window .
Cancel	Closes this dialog box.
Restore	Restores the original status.
Help	Displays this dialog box online help files.

Trace Move Dialog Box

This dialog box is used to specify the position from which displaying the [Trace View Window](#) is started. (Refer to "5.9 Trace Function".)

Caution This dialog box is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-43 Trace Move Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

When the [Trace View Window](#) is the current window, select [View] menu -> [Move...].

Explanation of each area

(1) Frame selection area

This area is used to specify the frame at the destination.

1st frame of last block	Moves the display start position to the first frame in the newest block frame of trace data. The display start position is moved to the first frame of the trace data when using an in-circuit emulator without a block frame.
Trigger frame of last block	Cannot be selected.
Last frame of last block	Moves the display start position to the last frame of trace data.

Frame No.	<p>Moves the display start position to the specified frame number. In the default condition, the character string selected in the window that called this dialog box or "Last" is selected. The default radix for inputting a numeric value is decimal. If 0 is specified, the display start position is moved to the first frame of trace data. In addition, frame number can also be specified in the following format. Up to 16 input histories can be recorded.</p>
-----------	--

Table 6-11 Frame Number Specification Format

Specification	Abbreviation	Contents
+numeric value	None	Moves backward (downward on screen) the display start position from the frame at the cursor by the specified number of frames (numeric value).
-numeric value	None	Moves forward (upward on screen) the display start position from the frame at the cursor by the specified number of frames (numeric value).
Top	O	Moves the display start position to the first frame
First	S	Same as "1st frame of last block"
Trigger	T	Same as "Trigger frame of last block"
Last	L	Same as "Last frame of last block"
Bottom	B	Moves the display start position to the last frame

Function buttons

OK	Starts trace display from the specified position.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Displays this dialog box online help files.

Trace Dialog Box

This dialog box is used to register, set, and display trace event conditions. (Refer to "5.10 Event Function", "5.9 Trace Function".)


The trace event conditions for when performing conditional trace are specified in this dialog box (refer to "Table 5-11 Types of Trace Mode").

Registration and setting of trace event conditions is done by setting each item (256 items max.) in this dialog box and then clicking the <OK> button. The registered trace event conditions are managed by the [Event Manager](#).

The number of trace event conditions that can be simultaneously used (validated) is limited (refer to "5.10.4 Number of enabled events for each event condition").

Caution This dialog box is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-44 Trace Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons \(Related event function\)](#)

Opening

 Click the **Trc** button, or select [Event] menu -> [Trace...].

Explanation of each area

(1) Trace Name:

(2) Delay Trigger:

(3) Section Start:, Section End:

(4) Event Manager:

(1) Trace Name:

This area is used to set a trace event name.

Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event condition, select from the drop-down list.

The mark on the left of this area indicates the utilization status of events (refer to "Table 5-16 Event Icon"). The gray mark indicates that an event condition is being edited and has not been registered yet.

By clicking the left mark, an event condition can be validated or invalidated.

(2) Delay Trigger:

This area is used to set an event condition for a delay trigger (refer to "5.9.6 Setting conditional trace").

The number of event conditions that can be set in this area is as follows:

Table 6-12 Number of Events Settable

Connected IE		Total (Execution/Access)
IE-70000-MC-NW-A	Nx85ET	6 (4 ³ /2)
	Nx85E901	--

- a. Can be used to events after execution.

Event conditions are easily set by dragging the icon of the event to be set from the event manager area and dropping it in this area. For details, refer to "5.10.3 Setting event conditions".

(3) Section Start:, Section End:

This area is used to set event conditions for starting and stopping a section trace (refer to "5.9.6 Setting conditional trace").

For the number of items that can be set to this area, refer to "Table 6-12 Number of Events Settable".

Event conditions are easily set by dragging the icon of the event to be set from the event manager area and dropping it in this area. For details, refer to "5.10.3 Setting event conditions".

(4) Event Manager:

This area is used to display the list of the events registered. (Refer to "Table 5-16 Event Icon", "(4) Manipulation in event manager area".)

Function Buttons

Refer to "Function buttons (Related event function)" in the Event Manager.

Delay Count Dialog Box

This dialog box is used to set or display delay count values. (Refer to "5.9 Trace Function".)

By setting a delay count value, a trace can be executed the number of times specified by the delay count value after the delay trigger event condition set in the [Trace Dialog Box](#) has been satisfied. (Refer to "5.9.6 Setting conditional trace".)

Caution This dialog box is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

Figure 6-45 Delay Count Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Event] menu -> [Delay Count...].

Explanation of each area

(1) Delay Count

This area is used to set or display a delay count value (unit: frames).

The settable range is 0 (default) to 32767.

Function buttons


OK	Validates the settings and closes this dialog box.
Restore	Restores the previous settings.
Cancel	Closes this dialog box.
Help	Displays this dialog box online help files.

Software Break Manager

This window is used to display, enable or disable, and delete software breaks . (Refer to "5.4.4 Hardware break and software break".)

Software breakpoints cannot be set in this window; they can be set in the [Source Window](#) or [Assemble Window](#). (Refer to "5.4.2 Breakpoint setting".)

Figure 6-46 Software Break Manager



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [Event] menu -> [Software Break Manager].

Explanation of each area

- (1) Name
- (2) Brk
- (3) File#Line / Symbol+Offset
- (4) Address

(1) Name

This area displays the names of registered events, and the check boxes that indicate whether each event is enabled or disabled.

An event name is displayed in the form of "Swb+[number]" in the default condition. It can be changed to an alphanumeric string of up to 256 characters. To change an event name, select and click a name. Then directly edit the name. To set the editing, press the Enter key.

When an event is enabled, the check box is checked. To be disable, the check box is not checked.

Furthermore, the name jumps to the [Source Window](#) by double-clicking an event name if the event name corresponds to the source line, whereas the name jumps to the [Assemble Window](#) if it does not correspond to the source line.

Remark By clicking "Name" (on the label), the character strings of the displayed items can be compared and sorted lexicographically (in alphabetical order). Whether the character strings are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

(2) Brk

The ">" mark is displayed for a software break event that is set at the current PC position (so that the software break event that caused a break can be easily identified).

(3) File#Line / Symbol+Offset

This area displays the location at which a software break event was set as follows:

- Program\$file name#line number (If the event corresponds to the source line.)
- Program\$file name#symbol+offset (If the event dose not correspond to the source line.)

Events are evaluated based on this when a symbol is re-downloaded.

Remark By clicking "File#Line/Symbol+Offset" (on the label), the character strings of the displayed items can be compared and sorted lexicographically (in alphabetical order). Whether the character strings are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

(4) Address

This area displays the address at which a software break event is set.

Remark By clicking "Address" (on the label), the numeric values of the displayed items can be compared and sorted. Whether the values are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

Function buttons

Enable	Enables the selected event.
Disable	Disables the selected event.
Delete	Deletes the selected event.
Delete ALL	Deletes all the set software break events.
Close	Closes this window.


Event Manager

This window is used to manage event conditions. This window allows display, enabling/disabling, and deletion of the [Various Event Conditions](#). (Refer to "5.10 Event Function".)

Other operations using [Context menu](#), [Function buttons \(Related event function\)](#), etc., can be performed in this window.

The event icon is the jump pointer of the [Jump function](#).

Figure 6-47 Event Manager (In Detailed Display Mode)



- [Opening](#)
- [Explanation of each area](#)
- [\[View\] menu \(Event Manager-dedicated items\)](#)
- [Context menu](#)
- [Function buttons \(Related event function\)](#)

Opening



Click the Mgr button, or select [Event] -> [Event Manager] on the menu.

Explanation of each area

(1) Event display area

This area displays the icons (event icons) of the registered [Various Event Conditions](#).

By selecting the context menu -> [Detail], the details can be displayed.

(a) [In list displayed]



Displays event icon (refer to "[Table 5-16 Event Icon](#)").

The event icon is the jump pointer (refer to "[5.13.2 Jump function](#)").

(b) In detailed display

E	Evt00011	[S]R [Z]NC [A]main.c#15(0x27e)
Ti	Tmr00004	[S]Evt00010 [E]Evt00011 [U]usec [B]ON 0h 2m 51s 798ms 691us 820ns
Ti	Tmr00005	[S]Evt00001 [E]Evt00001 [U]sec [B]OFF
B	Brk00001	[B]Evt00003
L	Lnk00001	[P1]Evt00008 [P2]Evt00001 [P3]Evt00004 [P4]Evt00005
T	Trc00001	[S]Evt00006 [E]Evt00002

Details of event contents are displayed by using the following key information as a separator.

Table 6-13 Separator for Displaying Event Details

Key Information	Contents
Event condition	
[S]	Status condition
[Z]	Access size condition
[A]	Address condition Symbol or expression: (actual address)
[D]	Data condition Symbol or expression: (actual address)
[M]	Mask condition
Event link condition	
[P1] - [P4]	Event link condition on "n"th line
[D]	Disable condition
[P]	Pass count condition
Break condition	
[B]	Break condition
Trace condition [Note]	

Key Information	Contents
[M]	Tracer control mode
[D]	Delay Count
[S]	Trace start condition
[E]	Trace end condition

[Note] It is valid only for CPU cores with the TRCU (TRace Control Unit) incorporated.

[View] menu (Event Manager-dedicated items)

The following items are added in the [\[View\] menu](#) , when the Event Manager is active.

Select All Event	Selects all the registered events.
Delete Event	Deletes a selected event.
Sort By Name	Displays icons in the order of event names.
Sort By Kind	Displays icons in the order of event types.
Unsort	Does not sort icons (default).
Detail	Detail display
Overview	List display (default)

Context menu

Sort By Name	Displays icons in the order of event names.
Sort By Kind	Displays icons in the order of event types.
Unsort	Does not sort icons (default).
Detail	Displays the details.
Overview	List display (default).
Source Text	Displays the corresponding source text and source line, using the position of the selected event as the jump destination address. (Refer to " 5.13.2 Jump function ".) If no line information exists at the jump destination address, however, you cannot jump. Opens the Source Window . If an active Source Window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Displays the Assemble window from the position of the selected event, which is used as the jump destination address. (Refer to " 5.13.2 Jump function ".) Opens the Assemble Window . If an active Assemble Window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents from the position of the selected event, which is used as the jump destination address. (Refer to " 5.13.2 Jump function ".) Opens the Memory Window . If an active Memory Window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons (Related event function)

Describes the all function buttons the related event dialogs (the Event Manager, [Event Dialog Box](#), [Event Link Dialog Box](#), [Break Dialog Box](#), [Trace Dialog Box](#).)

OK	(Event Dialog Box , Event Link Dialog Box) Automatically registers the event condition being edited, if any, and closes this dialog box. In the select mode An event condition is selected and the setting dialog box (indicated on the title bar) that called the Event Link dialog box is displayed again. If the calling dialog box has already been closed, the select mode is returned to the normal mode, and the Event dialog box is not closed. Otherwise, this dialog box will be closed.
	(Other than above dialog boxes) Automatically registers the event condition being edited, if any, and closes this dialog box. Each event condition becomes valid as soon as it has been registered.
New...	(Event Manager) Opens the dialog box to create new event condition. By clicking each button of <Event...>, <Event Link...>, <Break...>, <Trace...> the corresponding event setting dialog box can be opened with the new event name set. After the event setting dialog box has been opened, this dialog box is closed. Returns to Event Manager by clicking the <Cancel> button.
	(Other than above dialog boxes) Newly creates an event condition in this dialog box. An event condition name is automatically created and a new event condition is prepared.
Set	(Event Dialog Box , Event Link Dialog Box) Registers the various event conditions. Because the dialog box is not closed even after an event has been registered, new event conditions can be registered. In the select mode An event condition is selected. If there is an event being edited, it is automatically registered and selected.
	(Other than above dialog boxes) Registers the various event conditions. Because the dialog box is not closed even after an event has been registered, new event conditions can be registered. Each event condition becomes valid as soon as it has been registered.
Enable / Disable	Validates (enables) or invalidates (disables) the selected event condition. However, event conditions and event link conditions cannot be enabled or disabled. Same operation as the clicking the mark of event icon.
Clear	Clears the contents of the event condition.
Restore	Restores the contents of an edited event condition. If an event condition not registered is displayed, all the fields other than the event name field are blank or the default values are set.
Cancel / Close	Closes this dialog box. Even if an event condition is being edited, it is not registered and the dialog box is closed.
Help	Displays the help window of this window.
Event Link...	Opens the Event Link Dialog Box .
Break...	Opens the Break Dialog Box .
Trace...	Opens the Trace Dialog Box .

Manager	Opens the Event Manager .
Add Event...	Opens the Event Dialog Box in the select mode, and selects or newly creates an event condition to be set. The event condition will be added to the area selected when the < Add Event...> button is pressed.
Add Link...	Opens the Event Link Dialog Box in the select mode, and selects or newly creates an event link condition. The event condition will be added to the area selected when the < Add Link...> button is pressed.
Open	Opens the various event setting dialog box corresponding to the selected event condition (one). Each setting dialog box displays the contents of the selected event condition. Same operation as double-clicking the event icon or pressing the Enter key.
Remove / Delete	Deletes the selected event. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as a various event condition.
Delete All	Deletes all event conditions except software break events
Expand >>> / Shrink <<<	Turns on (Expand >>>) or off (Shrink<<<) display of the event manager area. The size of the dialog box is expanded or reduced.
Add	The event condition and event link condition selected in Event Manager area add to setting area with a focus.
Info...	<p>Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.</p> <p style="text-align: center;">Figure 6-48 Select Display Information Dialog Box</p>  <p><Sort by Name> Sorts events into name order. <Sort by Kind> Sorts events into type order. <Unsort> Displays events in the order in which they have been registered without sorting the events. <Detail> Sets the detailed display mode. <Overview> Sets the list display mode. <Cancel> Closes this dialog box (same as ESC key).</p>
Other...	<p>Opens the dialog box for selecting the event type. By clicking each button of <Event...>, <Event Link...>, <Break...>, <Trace...> the corresponding event setting dialog box can be opened with the new event name set. After the event setting dialog box has been opened, this dialog box is closed.</p> <p><Manager...> Opens the Event Manager. <Cancel> Closes the dialog box to create event condition.</p>


Event Dialog Box

This dialog box is used to register and display event conditions. (Refer to "5.10 Event Function".)

Setting of event conditions is done by setting each item in this dialog box and then pressing the <OK> button. The registered event conditions are managed by the [Event Manager](#).

One event condition can be set for multiple [Various Event Conditions](#). However, the number of event conditions that can be simultaneously used is limited (refer to "5.10.4 Number of enabled events for each event condition").

Figure 6-49 Event Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons \(Related event function\)](#)

Opening

In normal mode

If the Event Dialog Box is opened as follows, an event condition can be registered without its purpose being specified.



Click the Evt button, or select [Event] -> [Event...] on the menu.

In select mode

If the <OK> button is pressed when the Event dialog box has been opened as follows, an event condition can be registered in the setting dialog box from which this dialog box was opened (the setting dialog box from which the this box was opened is displayed on the title bar.).

In each various event setting dialog box, click the <Add Event... > button.

Explanation of each area

- (1) Event Name:
- (2) Event Status:
- (3) Access Size:
- (4) Address:
- (5) Data:, Mask:
- (6) Event Manager:

(1) Event Name:

This area is used to set an event name.

Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event condition, select from the drop-down list.

In the select mode, the selected event condition can be set in the event condition setting area of the setting dialog box that called the Event dialog box.

The mark on the left of this area indicates the utilization status of events (refer to "Table 5-16 Event Icon"). The gray E. mark indicates that the event condition is being edited and has not been registered yet.

(2) Event Status:

This area is used to select a status condition.

By specifying a status condition, the type of the execution event and an access event is determined (if an execution event is specified, nothing can be input to the (3) Access Size: and (5) Data:, Mask:).

The status conditions that can be specified are listed below.

Table 6-14 Status condition

Status	Abbreviation	Meaning
Execution event		
Execution	EX	Program execution
Before Execution	EX-B	Program execution (break before execution) [Note]
Access event		
R/W	RW	Data read/write
Read	R	Data read
Write	W	Data write

[Note] Multiple items can be specified, but only two items, including access events, can be enabled. The address range cannot be specified. Can be used only for break event conditions.

(3) Access Size:

This area is used to select an access size condition.

By selecting an access size condition from the drop-down list, the access width of a data condition to be detected by an access event is determined.

Byte	Detects data condition with 8-bit width (only during 8-bit access).
Half Word	Detects data condition with 16-bit width (only during 16-bit access).
Word	Detects data condition with 32-bit width (only during 32-bit access).
No Condition	Does not detect access size (nothing can be input to the Data area).
Bit	<p>Detects data condition with 1-bit width (only during 8-bit access). In this case, a data condition is detected with 1-bit width. Because of the operation of the in-circuit emulator, access to a bit is not directly detected; the ID850NW detects a dummy bit access by internally setting address conditions and data conditions as follows:</p> <p>Input example: Address: FE20.1 Data: 1 </p> <p>Setting of trace search: Address: FE20 Data: 00000010B Mask: 11111101B</p> <p>If another bit of the same address is accessed or if all the 8 bits of the same address are accessed, therefore, an event is detected in accordance with the specified status if the address and bit match the specified value of [address.bit]. When data is written to a bit, all the 8 bits are read/written. If read or read/write is specified as the status, an event occurs if a read operation is performed at this time if the value of the specified [Address.bit] matches.</p>

Remark If no access size condition is specified, a judgment is automatically made from the address condition and data condition, and the following is set:

- Bit if the address condition is set in bit units
- Byte if the data condition is set in 8-bit units
- Half Word if the data condition is set in 16-bit units
- Word if the address condition is set in 32-bit units
- No Condition if no data condition is specified

(4) Address:

This area is used to specify an address condition (address value, mask value).

The default radix for inputting a numeric value is hexadecimal. A data can be also specified by a symbol (refer to "Table 5-6 Specifying Symbols").

Table 6-15 Settable Range of Address Condition (Event)

Settable Range	Remark
0 =< address value =< 0xFFFFFFFF	None

(a) Address:

Set an address condition (lower address - higher address) (may be omitted).

The following can be set:

Caution Specify a 28-bit address, since physical address and image space are distinguished in setting event.

(i) Setting as a point

Set a value to only the lower address, or set the same value to the lower address and the higher address.

(ii) Setting as a range

Set a value to the lower address and the higher address.

(iii) Setting as a bit

Set a value to only the lower address, or set the same value to the lower address and the higher address.

Specify a value in the form of address.bit.

The value of bit, which indicates the bit position, must be 0 =< bit =< 7.

(5) Data:, Mask:

This area is used to set data conditions.

The default radix for inputting a numeric value is hexadecimal.

The settable range differs as follows depending on the access size condition specified in (3) Access Size:.

Table 6-16 Settable Range of Data Condition

Access Size	Settable Range
Byte	0 =< data value =< 0xFF 0 =< mask value =< 0xFF
Word	0 =< data value =< 0xFFFFFFFF 0 =< mask value =< 0xFFFFFFFF
Bit	Data value = 0 or 1 Mask value = Cannot be specified.

(a) Data:

Set a data value as data conditions. A data can be also specified by a symbol (refer to "[Table 5-6 Specifying Symbols](#)").

(b) Mask:

Set a mask value for the data value.

When a mask is set, the data value for the bit whose mask value is 1 may be 0 or 1.

Example 1:

Data	0x4000
Mask	0xFF

With this setting, addresses 0x4000 to 0x40FF satisfy the condition.

Example 2:

Data	0x4000
Mask	0x101

With this setting, addresses 0x4000, 0x4001, 0x4100, and 0x4101 satisfy the condition.

(6) Event Manager:

This area is used to display the list of the events registered. (Refer to "[Table 5-16 Event Icon](#)", "[\(4\) Manipulation in event manager area](#)".)

Function Buttons

Refer to "[Function buttons \(Related event function\)](#)" in the [Event Manager](#).

Event Link Dialog Box

This dialog box is used to register and display event link conditions. (Refer to "5.10 Event Function".)

Registration of event link conditions is done by setting each item (256 items max.) in this dialog box and then pressing the <OK> button. The registered event link conditions are managed by the [Event Manager](#).

However, the number of event link conditions that can be simultaneously used is limited ("5.10.4 Number of enabled events for each event condition").


The following various event conditions can use event link conditions:

Table 6-17 Event Conditions for Which Event Link Condition Can Be Set

Connected IE		Break	Trace
IE-70000-MC-NW-A	Nx85ET	Settable	Settable ^a
	Nx85E901	Settable	Not settable

- a. Can be set in Delay Trigger area.

Figure 6-50 Event Link Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons \(Related event function\)](#)

Opening

In normal mode

If the Event Link dialog box is opened as follows, an event link condition can be registered without its purpose being specified.

Select [Event] -> [Event Link...] from the menu bar.

In select mode

If the <OK> button is pressed when the Event Link dialog box has been opened as follows, an event link condition can be registered in the setting dialog box from which this dialog box was opened.

In each various event setting dialog box, click the <Add Link... > button.

(the setting dialog box from which the Event Link dialog box was opened is displayed on the title bar.)

Explanation of each area

(1) Link Name:

(2) Phase1:, Phase2:, Phase3:, Phase4:

(3) Disable:

(4) Pass Count:

(5) Event Manager:

(1) Link Name:

This area is used to set a event link name.

Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event link condition, select from the drop-down list.

In the select mode, the selected event condition can be set in the event link condition setting area of the setting dialog box that called the Event Link dialog box.

The mark on the left of this area indicates the utilization status of event link conditions (refer to "Table 5-16 Event Icon"). The mark "L" in gray indicates that an event link condition is being edited and has not been registered yet.

(2) Phase1:, Phase2:, Phase3:, Phase4:

This area is used to specify the sequence in which event conditions and events are detected.

Up to four sequences can be specified. If a disable condition is detected while the program is being executed, however, the event conditions that have so far been satisfied are initialized, and the event conditions are detected again starting from the first event condition. If a link condition and a disable condition are detected at the same time, the disable condition takes precedence.

Set Phase 1 -> Phase 2 -> Phase 3 -> Phase 4, in that order. Phase 4 does not have to be set. In this case, an event occurs when the event condition set for the last phase has been detected. An event condition can be set for only Phase 1 or the same event condition can be set for two or more Phases.

The number of event conditions that can be set to each phase of this area and while the dialog box, is as follows:

Table 6-18 The Number of Event Conditions in Event Link Dialog Box

Connected IE		Each Phase	Disable Area (Execution/ Access)	Total (Execution/ Access)
IE-70000-MC-NW-A	Nx85ET	6	6 (4 ^a /2)	6 (4 ^a /2)
	Nx85E901	1 ^b	--	2

- a. Can be used to events after execution
- b. Can be set only for Phase 1 and Phase 2

(3) Disable:

This area is used to set an event condition that invalidates the event conditions that have so far been satisfied (refer to "[Table 6-18 The Number of Event Conditions in Event Link Dialog Box](#)").

The number of event conditions that can be set in this area, combining execution events and access events, is 10.

Setting of event conditions is easily done by dragging the icon of the event to be set from the event manager area and dropping it in this area. For details, refer to "[5.10.3 Setting event conditions](#)".

In case of Nx85E901, this area does not have to be set.

(4) Pass Count:

This area is used to set a pass count condition (settable range: 1 to 32767).

A pass count condition specifies how many times an event condition must be satisfied during user program execution before a given condition is satisfied.

If no pass count is specified, 1 is assumed (the condition is satisfied as soon as the event condition is satisfied).

(5) Event Manager:

This area is used to display the list of the events registered. (Refer to "[Table 5-16 Event Icon](#)", "[\(4\) Manipulation in event manager area](#)".)

Function Buttons

Refer to "[Function buttons \(Related event function\)](#)" in the [Event Manager](#).


Break Dialog Box

This dialog box is used to register; set, and display break event conditions. (Refer to "5.10 Event Function", "5.4 Break Function".)

Registration and setting of break event conditions is done by setting each item (256 items max.) in this dialog box and then clicking the <OK> button. The registered break event conditions are managed by the [Event Manager](#).

There are restrictions on the number of break event conditions that can be simultaneously set (enabled). (Refer to "5.10.4 Number of enabled events for each event condition".)

Figure 6-51 Break Dialog Box



- Opening
- Explanation of each area
- Function buttons (Related event function)

Opening

 Click the **Brk** button, or select [Event] menu -> [Break...].

Explanation of each area

- (1) Break Name:
- (2) Break Event:
- (3) Event Manager:

(1) Break Name:

This area is used to set a break event name. Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event condition, select from the drop-down list.

The mark on the left of this area indicates the utilization status of events. (Refer to "[Table 5-16 Event Icon](#)"). The gray mark indicates that an event condition is being edited and has not been registered yet. By clicking the left mark, an event condition can be validated or invalidated.

(2) Break Event:

This area is used to set an event condition for break.

The number of event conditions that can be set in this area is as follows:

Table 6-19 Number of Events Settable in Break Condition Setting Area

Connected IE		Total (Before Execution / After Execution / Access)
IE-70000-MC-NW-A	Nx85ET	8 (2 / 4 / 2)
	Nx85E901	2 ^a

- a. The address range cannot be specified.

Event conditions are easily set by dragging the icon of the event to be set from the event manager area and dropping it in this area. For details, refer to "[5.10.3 Setting event conditions](#)".

(3) Event Manager:

This area is used to display the list of the events registered. (Refer to "[Table 5-16 Event Icon](#)", "[\(4\) Manipulation in event manager area](#)".)


Function Buttons

Refer to "[Function buttons \(Related event function\)](#)" in the [Event Manager](#).

View File Save Dialog Box

This dialog box is used to save the current display information of the current window to a view file. (Refer to "5.12.2 Window display information (view file)".)

Figure 6-52 View File Save Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the window to be saved is the current window, select [File] menu -> [Save As...].

Explanation of each area

- (1) Save in:, File name:
- (2) Save as type:
- (3) Save range

(1) Save in:, File name:

This area is used to specify the file name to be saved. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Save as type:

This area is used to specify the type (extension) of the file to be saved. (Refer to "[Table 5-18 Type of the View Files](#)".)

The extension of the file corresponding to the current window is displayed.

(3) Save range

Specify the range of data to be saved.

This area is displayed if the current window to be saved is the following.

- [Assemble Window](#)
- [Memory Window](#)
- [Source Window](#)
- [Trace View Window](#)

(a) All

This should be selected to save the entire range, from the first line to the last line.

(b) Screen shot

This should be selected to save the area visible on the screen, from the top line on the screen to the bottom line.

If the [Source Window](#) is in the mixed display mode, however, the window contents are saved from the source line that includes the area visible on the screen.

(c) Specify Line / Specify Address

This should be selected to specify the start line and end line of the area to be saved.

If the start line and end line are omitted, the first line and last line are assumed.

If a range of 100 lines / 100 frames / 256 bytes or more is specified, a message dialog box is displayed to indicate the progress of saving. To stop saving midway, click the <Stop> button in the message dialog box.

Display any of the following corresponding to the current window:

Specify Line	Specify the range of the line numbers to be saved. The default radix for inputting a numeric value is decimal. If the Source Window is in the mixed display mode, the mixed displayed part on the specified line is also saved.
Specify Frame	Specify the range of trace frames to be saved. (Refer to " Table 6-11 Frame Number Specification Format ".) The default radix for inputting a numeric value is decimal.

Specify Address	Specify the range of address to be saved. An address can be also specified by a symbol or expression. (Refer to " Table 5-6 Specifying Symbols ".) The default radix for inputting a numeric value is hexadecimal.
-----------------	--

Function buttons

Save	Saves the display information of the current window to the selected file. After saving, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.
Restore	Restores the status before this dialog box was opened.

View File Load Dialog Box

This dialog box is used to read the view files. (Refer to "5.12.2 Window display information (view file)".)

When a view file is loaded, the reference window ([Source Window](#) in static status) opens and the display information at saving is displayed.

The window to be opened and its status differ as follows, depending on the file to be loaded.


- Loading source file to which symbol information has been read

If there is a [Source Window](#) in the active status, it is opened in the static status; otherwise, the [Source Window](#) is opened in the active status.

- Loading source file to which symbol information has not been read, or view file

A window of text-format files is opened in the [Source Window](#) in the static status.

Figure 6-53 View File Load Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening



Click the **Open** button or select [File] menu -> [Open...].

Explanation of each area

- (1) [Look in:](#), [File name:](#)
- (2) [Files of type:](#)

(1) Look in:, File name:

This area is used to specify the file name to be loaded. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Files of type:

This area is used to specify the type (extension) of the file to be loaded. (Refer to ["Table 5-18 Type of the View Files"](#).)


Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.

Environment Setting File Save Dialog Box

This dialog box is used to save the setting contents of the current window to a setting file. (Refer to "5.12.3 Window setting information (setting file)".)

Figure 6-54 Environment Setting File Save Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

When the window to be saved is the current window, select [File] menu -> [Environment] -> [Save As...].

Explanation of each area

- (1) Save in:, File name:
- (2) Save as type:

(1) Save in:, File name:

This area is used to specify the file name to be saved. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Save as type:

This area is used to specify the type (extension) of the file to be saved. (Refer to "[Table 5-19 Type of the Setting Files](#)").

The extension of the file corresponding to the current window is displayed.

Function buttons


Save	Saves the setting information of the current window to the selected file. After saving, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.
Restore	Restores the status before this dialog box was opened.

Environment Setting File Load Dialog Box

This dialog box is used to read the setting files. (Refer to "5.12.3 Window setting information (setting file)".)

When a setting file is loaded, the target window opens and the setting information at saving is restored.

Figure 6-55 Environment Setting File Load Dialog Box



- Opening
- Explanation of each area
- Function buttons

Opening

select [File] menu -> [Environment] -> [Open...].

Explanation of each area

- (1) Look in:, File name:
- (2) Files of type:

(1) Look in:, File name:

This area is used to specify the file name to be loaded. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Files of type:

This area is used to specify the type (extension) of the file to be loaded. (Refer to "[Table 5-19 Type of the Setting Files](#)".)


Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.

Reset Debugger Dialog Box

This dialog box is used to initialize the ID850NW, CPU, and symbol information.

Figure 6-56 Reset Debugger Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Select [File] menu -> [Debugger Reset...].

Explanation of each area

(1) Reset subject selection area

This area is used to specify what is to be initialized. Initializes the checked item.

Debugger	Initializes the ID850NW (default).
Symbol	Initializes the symbol information.
Target CPU	Initializes the CPU.

Function buttons

OK	Initializes according to the setting.
Cancel	Cancels the changes and closes this dialog box.
Help	Displays this dialog box online help files.


Exit Debugger Dialog Box

This dialog box is used to select whether the current debug environment is saved to a project file or not before terminating the ID850NW. (Refer to ["5.12.1 Debugging environment \(project file\)"](#).)

It can be specified in the [Debugger Option Dialog Box](#) that the ID850NW is terminated without this confirmation dialog box being opened.

Remark If an attempt is made to terminate the ID850NW while the user program is being executed, the following message is displayed " Wfb00: User program is running. Do you want to stop user program?".

Figure 6-57 Exit Debugger Dialog Box



- [Opening](#)
- [Function buttons](#)

Opening

- Select [File] menu -> [Exit].
- If forcible termination, such as to terminate the application, has been executed on the task list that terminates Windows.

Function buttons

Yes	Saves the current debug environment to a project file, closes all the windows, and terminates the ID850NW. If a project file name is not specified, the Project File Save Dialog Box is opened. If the <Cancel> button is selected on the Project File Save Dialog Box , the environment is neither saved to a project file nor is the ID850NW terminated. (If a project file is loaded or saved during debugger operation, this button has the default focus.)
No	Closes all the windows and terminates the ID850NW. (If a project file is not loaded or saved during debugger operation, this button has the default focus.)
Cancel	Closes this dialog box without executing anything.

About Dialog Box


This dialog box displays the version information of the ID850NW (the year is displayed in 4 digits).

Remark The version information can be copied to the clipboard by selecting [Select All and Copy (&C)] from the context menu in the dialog box.

The following version information is displayed:

- Product version of ID850NW
- Version of device file
- Version of GUI
- Version of debugger DLL
- Version of assembler DLL
- Version of executor
- Version of Tcl/Tk

Figure 6-58 About Dialog Box



- Opening
- Function buttons

Opening

Select [Help] menu -> [About...].

Function buttons

OK	Closes this dialog box.
----	-------------------------

Console Window


This window is used to input commands that control the ID850NW .

Because the key bind is Emacs-like, the accelerator key is not acknowledged if the Console Window is active. However, the F1 key displays the online help files of the Console Window.

While the Console Window is open, an error message window with only an <OK> button is displayed in the Console Window.

Refer to "[CHAPTER 7 COMMAND REFERENCE](#)" for details on the command specifications.

Figure 6-59 Console Window



- Opening


Opening

Select [Browse] menu -> [Console].

Font Dialog Box

This dialog box is used to select the font and font size to be displayed in the [Source Window](#), [Watch Window](#), [Quick Watch Dialog Box](#), [Local Variable Window](#) and [Stack Window](#).

Figure 6-60 Font Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Click the button in the [Debugger Option Dialog Box](#).

Explanation of each area

- (1) [Font Face:](#)
- (2) [Size:](#)
- (3) [Sample](#)

(1) Font Face:

This area is used to select a font from the fonts currently usable.

Only fonts with equal width (fonts with a constant stroke width and a fixed pitch) are enumerated. When a font name is selected from the list, the font name is displayed in the text box, and the font size that can be used with that font is displayed under [\(2\) Size:](#).

(2) Size:

This area is used to specify the font size (unit: pt.).

On the drop-down list, the font size usable for the font specified in [\(1\) Font Face:](#) is displayed in point units. When the font size is selected from the drop-down list, the selected font size is displayed in this area. The font size can also be directly input to the text box from the keyboard.

(3) Sample

This area displays a sample character string of the specified font and size.

Function buttons


OK	Validates the settings and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.

Browse Dialog Box

This dialog box is used to select the file to be set in the [Source Text Move Dialog Box](#).

Remark If this dialog box is opened for the first time after the system has been started up, the directory first specified by the source path is displayed. When the dialog box is opened the second and subsequent times, the previously displayed directory is recorded and displayed again. If the <Cancel> button is clicked, however, the previously displayed directory is not recorded.

Figure 6-61 Browse Dialog Box



- [Opening](#)
- [Explanation of each area](#)
- [Function buttons](#)

Opening

Click the <Browse...> button in the target dialog box.

Explanation of each area

- (1) [Look in:](#), [File name:](#)
- (2) [Files of type:](#)

(1) Look in:, File name:

This area is used to specify the file name to be opened. A file name can be directly input from the keyboard, or selected from the list.

Up to 257 character string with a extension can be specified.

(2) Files of type:

This area is used to specify the type (extension) of the file to be opened (refer to ["Table 5-5 File Type Can Be Displayed"](#)).

Function buttons

Open	Sets the selected file. After setting the file, this dialog box is closed.
Cancel	Closes this dialog box without executing anything.
Help	Displays this dialog box online help files.

CHAPTER 7 COMMAND REFERENCE

This chapter explains the details of the command functions of the ID850NW.

- [Command Line Rules](#)
- [Command List](#)
- [List of Variables](#)
- [List of Packages](#)
- [Key Bind](#)
- [Expansion Window](#)
- [Callback Procedure](#)
- [Hook Procedure](#)
- [Related Files](#)
- [Cautions](#)
- [Command Name](#)
- [Samples \(Calculator Script\)](#)

7.1 Command Line Rules

The specification of command lines has the following rules:

- Command name, option, and argument are specified for command line.
- To divide words, a space (space key or tab key) is used.
- At the end of a line, a line feed character or a semicolon is used.
- When a command name and an option are entered to the point of identifiability, they are recognized.
- In script, command names have to be entered completely.

Command format

```
command -options arg1 arg2 arg3 ...
```

7.2 Command List

Table 7-1 List of Debugger Control Commands

Command Name	Function
<code>address</code>	Evaluation of address expression
<code>assemble</code>	Disassemble/line assemble
<code>batch</code>	Executing batch (with echo)
<code>breakpoint</code>	Setting/deletion of breakpoint
<code>cache</code>	Setting of cache
<code>dbgexit</code>	Terminating ID850NW
<code>download</code>	Download of files
<code>extwin</code>	Creation of expansion window
<code>finish</code>	Returning from function
<code>go</code>	Continuous execution
<code>help</code>	Display of help
<code>hook</code>	Setting of hook
<code>ie</code>	Display/setting of IE register
<code>inspect</code>	Symbol inspect
<code>jump</code>	Jump to window
<code>map</code>	Setting / deleting memory mapping
<code>mdi</code>	Setting of expansion window
<code>memory</code>	Display/setting of memory
<code>module</code>	Display of the list of files and functions
<code>next</code>	Procedure step
<code>refresh</code>	Redrawing of window
<code>register</code>	Display/setting of register value and IOR value
<code>reset</code>	Reset
<code>run</code>	Reset and execution of CPU
<code>step</code>	Step execution
<code>stop</code>	Stop execution
<code>upload</code>	Upload
<code>version</code>	Display of the version information
<code>watch</code>	Display/setting of variables
<code>where</code>	Stack trace

Command Name	Function
wish	Start of Tclet
xtrace	Operation of tracer

Table 7-2 List of Console/Tcl Commands

Command Name	Function
alias	Creation of another name
cd	Change of directory
clear	Clears the screen
echo	Echo
exit	Close/end
history	Display of history
ls	Display of files
pwd	Check of the directory
source	Execution of batch
time	Measurement of time for commands
tkcon	Console control
unalias	Deletion of another name
which	Display of the command path or another name
Other	Based on Tcl/Tk 8.4

7.3 List of Variables

- dcl(chip) - Chip name read only
- dcl(prjfile) - Project file name read only
- dcl(srcpath) - Source path read only
- dcl(ieid) - IEtype read only
- dcl(iestat) - IEstatus read only
- dcl(bkstat) - Break status read only
- env(LANG) - Language
- dcl_version - Dclversion read only

7.4 List of Packages

- tcltest - Restoration test
- cwind - Automatic window control
- BWidget - Toolkit
- tcllib - Tcl library
- mclistbox - Multi-column list box
- combobox - Combo box

7.5 Key Bind

- tcsh + Emacs like
- Complement of command name [Tab]
- Complement of file name [Tab]
- HTML help [F1]

7.6 Expansion Window

The expansion windows can be created using Tk.

In the expansion windows, Widget is allocated with '.dcl' as a root instead of '.'.

When the following script files are allocated in bin/idtcl/tools/, an expansion window is added on selecting [Browse] menu - [Others].

The mdi command, an exclusive command for expansion windows, has been added.

```
# Sample.tcl
wm protocol .dcl WM_DELETE_WINDOW { exit }
mdi geometry 100 50
button .dcl.b -text Push -command exit
pack .dcl.b
```

Caution In the expansion windows, Tk menu commands cannot be used because of the restrictions of MDI windows.

7.7 Callback Procedure

Expansion windows can hold `dcl_asyncproc` procedures called by asynchronous messages.

```
proc dcl_asyncproc {mid} {
  if {$mid == 19} {
    redraw
  }
}
```

The asynchronous message ID is passed for the argument of the `dcl_asyncproc` procedure

The message IDs are shown below:

Table 7-3 Message ID

Message ID	Meaning
9	After changing configuration
10	After registering event
11	After deleting event
12	Before executing
13	After breaking
14	After resetting CPU
15	After resetting ID850NW
17	After changing extended option
18	After changing debugger option
19	After downloading
20	After changing memory or register
36	Before starting tracer
37	After stopping tracer
42	After clearing trace
45	After resetting symbol

7.8 Hook Procedure

A hook can be set in the ID850NW using the hook procedure.

The hook procedures are shown below:

- BeforeDownload(Hook before downloading)
- AfterDownload(Hook after downloading)
- AfterCpuReset(Hook after CPU reset during break)
- BeforeCpuRun(Hook before starting execution)
- AfterCpuStop(Hook after breaking)

By using hook procedures, register values can be changed before downloading programs or after resetting the CPU.

An actual example of the procedure is shown below. A hook is valid till the ID850NW is closed.

(1) [When hook is set with ID850NW control command]

- 1) Create script file a. with an editor.
- 2) Start up the ID850NW, select [Browse] menu -> [Console], and open the [Console Window](#).
- 3) If the script file is executed in the window as below, the hook in the script file is set.

```
%hook test.tcl
```

(2) [When hook is set on downloading of project file]

- 1) Create script file a. with an editor.**[Note]**
- 2) Start up the ID850NW and read test.prj. The hook in the script file is set.

```
proc BeforeDownload {} {
    register MM 0x7
    register PMC8 0xff
    register PMC9 0xff
    register PMCX 0xe0
}

proc AfterCpuReset {} {
    register MM 0x7
    register PMC8 0xff
    register PMC9 0xff
    register PMCX 0xe0
}
```

[Note] Be sure that the script file name is the same as the project file.

Example:

The script file corresponding to test.prj is test.tcl.

Allocate test.prj, test.pri, and test.tcl in the same directory.

7.9 Related Files

- Executes when the aliases.tcl console is opened.
Sets the default alias etc.
- Executes when the project file name.tcl project is opened. The following hooks can be used.
BeforeDownload, AfterDownload, AfterCpuReset, BeforeCpuRun, AfterCpuStop
- Executes when the load module name.tcl load module is downloaded. The following hooks can be used.
BeforeDownload, AfterDownload, AfterCpuReset, BeforeCpuRun, AfterCpuStop

7.10 Cautions

- The separator for file and path is a slash (/).
- When a console is open, error messages are output to the console.
- To terminate the command forcibly, close the console.
- The execution of external commands (DOS commands) is OFF by default.

7.11 Command Name

In this section, each command is explained using the format shown below.

Command name

Describes the command name.

Input format

Describes the input format of the command.

In the following explanation, italics indicate an Argument to be supplied by the user, while the argument enclosed in "?" may be omitted.

When a command name and an option are entered to the point of identifiability, they are recognized.

Functions

Explains the functions of the command.

Usage example

Shows an example of the usage of the command.

address

address - Evaluation of address expression

Input format

address *expression*

Functions

Converts the address expression specified by *expression* into address.

Usage example

```
(IDCON) 1 % address main
0xaa
(IDCON) 2 % address main+1
0xab
```

assemble

assemble - Disassemble/line assemble

Input format

assemble *?options? address ?code?*

Functions

Assembles the character strings specified by *code* from the *address* specified by *address*.

When '.' is specified for *address*, it is understood as an *address* continuing from the immediately previous assemble.

When *code* is omitted, it is assembled from the *address* specified by *address*.

The following are *options*: They are ignored for assembly.

-code	Command code is also displayed. It is ignored for assembly.
-number <i>number</i>	<i>number</i> line is displayed. It is ignored for assembly.

Usage example

```
(IDCON) 1 % assemble -n 5 main
0x000000aa B7      PUSH HL
0x000000ab B1      PUSH AX
0x000000ac 891C    MOVW AX,SP
0x000000ae D6      MOVW HL,AX
0x000000af A100    MOV  A,#0H
(IDCON) 2 % assemble main mov a,b
(IDCON) 3 % assemble . mov a,b
```

batch

batch - Executing batch (with echo)

Input format

batch *scriptname*

Functions

Executes in batch with displaying files specified by *scriptname* on the screen.

Nesting is possible.

Usage example

```
(IDCON) 1 % clear  
(IDCON) 2 % batch bat_file.tcl  
(IDCON) 3 % tkcon save a:/log.txt
```

breakpoint

breakpoint - Setting/deletion of breakpoint

Input format

breakpoint *?options? ?address1? ?address2?*

breakpoint -delete *brkno*

breakpoint -enable *brkno*

breakpoint -disable *brkno*

breakpoint -information

Functions

Operates the breakpoint specified by *options* and *address* .

If a breakpoint can be set correctly, the breakpoint number is returned.

The following are *options*:

-software	A software break is specified.
-hardware	A hardware break is specified (default).
-execute	The <i>address</i> execution break is set (default).
-beforeexecute	The break before <i>address</i> execution is set
-read	An <i>address</i> data read break is set.
-write	An <i>address</i> data write break is set.
-access	An <i>address</i> data access break is set.
-size <i>size</i>	The access size is set (8, 16, or 32bit). (unit: bit)
-data <i>value</i>	The data condition is set.
-datamask <i>value</i>	The data mask is set.
-information	The list of breakpoints is displayed.
-delete	The breakpoint whose number is specified is deleted.
-disable	The breakpoint whose number is specified is disabled.
-enable	The breakpoint whose number is specified is enabled.

Usage example

(IDCON) 1 % breakpoint main
1

(IDCON) 2 % breakpoint -i
1 Brk00001 enable rammon.c#17

(IDCON) 3 % breakpoint -software sub
2

(IDCON) 4 % breakpoint -i
1 Brk00001 enable rammon.c#17
2 Brk00001 enable rammon.c#8

(IDCON) 5 % breakpoint -disable 2

(IDCON) 6 % breakpoint -i
1 Brk00001 enable rammon.c#17
2 Brk00001 disable rammon.c#8

(IDCON) 7 % breakpoint -delete 1

2 Brk00001 disable rammon.c#8

cache

cache - Setting of cache

Input format

cache

cache *config* *?-icache itype?* *?-dcache dtype?*

cache *clear* *?-icache bool?* *?-dcache bool?*

Functions

When *config* is specified for the subcommand, the cache type is set.

When *clear* is specified for the subcommand, whether cache clear is to be done by EXEC, or not, is set (default is clear)

When subcommand or below is omitted, the current status is displayed.

itype is selected from the following:

NB85E212	NB85E212 is used.
NB85E213	NB85E213 is used.
nouse	Not used (default).

dtype is selected from the following:

NB85E252	NB85E252 is used.
NB85E263	NB85E263 is used.
nouse	Not used (default).

bool is selected from the following:

0, false, or off	off
1, true, or on	on

Usage example

(IDCON) 1 % cache config -i NB85E212 -d NB85E252

(IDCON) 2 % cache

i-cache: NB85E212

d-cache: NB85E252

(IDCON) 3 % cache clear -i false

(IDCON) 4 % cache

i-cache: NB85E212 (persist)

d-cache: nouse

dbgexit

dbgexit - Terminating ID850NW

Input format

dbgexit *?options?*

Functions

Terminate the ID850NW.

The following are *options*:

-saveprj	Project is saved on terminating ID850NW.
-----------------	--

Usage example

(IDCON) 1 % dbgexit -saveprj

download

download - Download of files

Input format

download *?options? filename ?offset?*

Functions

Downloads files specified with *filename* according to *options*.

If *offset* is specified, the address is shifted by the *offset* (if the data is in binary format, the load start address is specified for *offset*).

-binary	Binary format data is downloaded.
-append	Additional download is executed.
-nosymbol	Download is executed. Symbol information is not read.
-symbolonly	Symbol information is read.
-reset	CPU is reset after download.
-information	Download information is displayed.

Usage example

(IDCON) 1 % download test.lmf

extwin

extwin - Creation of expansion window

Input format

`extwin scriptfile`

Functions

Creates expansion window with *scriptfile*.

Usage example

(IDCON) 1 % extwin d:/foo.tcl

finish

finish - Returning from function

Input format

finish

Functions

Executes until it returns to the program that called the current function.

Usage example

(IDCON) 1 % finish

go

go - Continuous execution

Input format

go *?options?*

Functions

Executes program continuously. If -waitbreak is specified, the command waits until the program stops.

The following are *options*:

-ignorebreak	Breakpoint is ignored.
-waitbreak	The command waits for the program to stop.

Usage example

(IDCON) 1 % go -w

help

help - Display of help

Input format

help

Functions

Displays Dcl help.

Usage example

(IDCON) 1 % help

hook

hook - Setting of hook

Input format

hook *scriptfile*

Functions

Sets the procedure for hook with *scriptfile*.

The hook setting is initialized when the project file is loaded and when the ID850NW is reset.

Usage example

```
(IDCON) 1 % hook d:/foo.tcl
```

ie

ie - Display/setting of IE register

Input format

ie reg address ?value?

ie dcu address ?value?

Functions

。 The **ie** command depends on the IE.

When "reg" is specified for the subcommand, referencing and setting of the IE register is executed.

When "dcu" is specified for the subcommand, referencing and setting of the DCU register is executed.

Caution The value of a register will be reset by 0 if a DCU register is referred to.

Usage example

(IDCON) 1 % ie reg 0x100 1

(IDCON) 2 % ie dcu 0x100 1

inspect

inspect - Symbol inspect

Input format

inspect *?options? progname pattern*

Functions

Searches and displays the load module symbol specified with *progname* using the regular expression of *pattern*.

The following regular expressions can be used.

?	Match 1 character
*	Match characters other than 0
[chars]	Match chars character. (Range specification such as [a-z/0-9] also possible.)
\x	Match character x. (? * [] \ specification also possible.)

The following are *options*:

-nocase	Does not distinguish between upper and lowercase.
-address	Displays in pair with symbol address.

Usage example

(IDCON) 1 % inspect test1.out {[a-z]*}

jump

jump - Jump to window

Input format

jump -source -line *filename* *?line?*

jump *?options?* *address*

Functions

Displays the window specified by *options*.

-source	The Source Window is displayed from the address specified by <i>address</i> .
-assemble	The Assemble Window is displayed from the address specified by <i>address</i> .
-memory	The Memory Window is displayed from the address specified by <i>address</i> .
-line	The command is moved to the line specified by <i>line</i> .
-focus	The Focus is moved to the window displayed.

Usage example

```
(IDCON) 1 % jump -s main
(IDCON) 2 % jump -s -l mainfile.c 10
(IDCON) 3 % jump -m array
```

map

map - Setting/deletion of memory mapping

Input format

map *options address1 address2 ?accsize?*

Functions

Sets, deletes, and displays memory mapping.

The access size of 8, 16, or 32 is specified by *accsize* (the default is 8).

The following are *options*:

-erom	Alternate ROM is mapped.
-eram	Alternate RAM is mapped.
-target	Target area is mapped.
-protect	I/O protect area is mapped.
-clear	All the settings for the mapping are deleted.
-information	Refer to the setting for the mapping.

Usage example

```
(IDCON) 1 % map -i
1: 0 0x7fff 8 {IROM}
2: 0x8000 0x87ff 8 {Target RRM}
3: 0x8800 0x9fff 8 {Target}
4: 0xa000 0xf7ff 8 {NonMap}
5: 0xf800 0xfaff - {NonMap}
6: 0xfb00 0xfedf 8 {Saddr}
7: 0xfef0 0xfeff 8 {Register}
8: 0xff00 0xffff 8 {SFR}
```

mdi

mdi - Setting of expansion window

Input format

mdi geometry *?x y? width height*

mdi title *string*

Functions

Sets the size and title name of the expansion window.

The command can be used only from the expansion window.

Usage example

(IDCON) 1 % mdi geometry 0 0 100 100

(IDCON) 2 % mdi title foo

memory

memory - Display/setting of memory

Input format

memory *?options?* *address* *?value?*

memory *?options?* -fill *address1* *address2* *value*

memory *?options?* -copy *address1* *address2* *address3*

Functions

Sets *value* in the memory of the *address* specified by *address* according to *options*.

If *value* is omitted, display the value of the memory of the address specified by *address*.

If -fill is specified, data from *address1* to *address2* is filled with *value*.

If -copy is specified, data from *address1* to *address2* is copied to *address3*.

The following are *options*:

-byte	Displayed/set in one-byte units (default).
-halfword	Displayed/set in halfword units.
-word	Displayed/set in word units.
-fill	The data is filled in.
-copy	The data is copied.
-noverify	Verification is not executed on writing.

If memory referencing is performed for other than the real-time RAM monitor area during user program execution, the CPU is stopped for an instant. The CPU is stopped for an instant even if the memory setting is performed.

Usage example

```
(IDCON) 1 % memory 100
0x10
(IDCON) 2 % memory 100 2
(IDCON) 3 % memory 100
0x02
(IDCON) 4 % memory -fill 0 1ff 0
```

module

module - Display of the list of files and functions

Input format

module *programe* *?filename?*

Functions

Displays the list of files and functions of the load module specified by *programe*.

If *filename* is not specified, the list of files is displayed.

If *filename* is specified, the list of functions of the specified files is displayed.

Usage example

```
(IDCON) 1 % module rammon.lmf
1: rammon.c
(IDCON) 2 % module rammon.lmf rammon.c
1: rammon.c sub1
2: rammon.c main
```

next

next - Procedure step

Input format

next *?options?*

Functions

Executes the procedure steps. If functions are called, the step stops after executing function.

The following are *options*:

-source	The command is executed in source line units (default).
-instruction	The command is executed in command units.

Usage example

(IDCON) 1 % next -i

(IDCON) 2 % next -s

refresh

refresh - Redrawing of window

Input format

refresh

Functions

Redraws the window and updates the data.

Usage example

```
(IDCON) 1 % batch foo.tcl  
(IDCON) 2 % refresh
```

register

register - Display/setting of register value and IOR value

Input format

register *?options? regname ?value?*

Functions

Sets *value* in the register specified with *regname*.

If *value* is omitted, displays the value of the register specified by *regname*.

The following are *options*:

-force	Compulsory reading or writing is executed.
---------------	--

If register reference/setting is performed during user program execution, the CPU stops for an instant.

Usage example

```
(IDCON) 1 % register pc  
0x100  
(IDCON) 2 % register pc 200  
(IDCON) 3 % register pc  
0x200
```

reset

reset - Reset

Input format

reset *?options?*

Functions

Resets the ID850NW , CPU, symbols or events.

If options are omitted, the CPU is reset.

The following are *options*:

-cpu	CPU is reset (default).
-debugger	The ID850NW is reset.
-symbol	Symbol is reset.
-event	Event is reset.

Usage example

(IDCON) 1 % reset

run

run - Reset and execution of CPU

Input format

run *?options?*

Functions

Resets the program and executes it.

If -waitbreak is not specified, the command does not wait until the program stops.

The following are *options*:

-waitbreak	The command waits for the program to stop.
-------------------	--

Usage example

(IDCON) 1 % run

(IDCON) 2 % run -w

step

step - Step execution

Input format

step *?options?*

Functions

Executes step execution.

If functions are called, the command stops at the head of the functions.

The following are *options*:

-source	The command is executed in source line units (default).
-instruction	The command is executed in instruction units.

Usage example

(IDCON) 1 % step -i

(IDCON) 2 % step -s

stop

stop - Stop executing

Input format

stop

Functions

Stops the program forcibly.

Usage example

(IDCON) 1 % run
(IDCON) 2 % stop

upload

upload - Upload

Input format

upload *?options? filename address1 address2*

Functions

Saves the memory data within the specified range in a file.

The following are *options*:

-binary	The data is saved in binary format.
-intel	The data is saved in Intel HEX format (default).
-motorola	The data is saved in Motorola HEX format.
-tektronix	The data is saved in Tektronix HEX format.
-force	The file is overwritten.

Usage example

(IDCON) 1 % upload -b foo.hex 0 0xffff

version

version - Display of the version information

Input format

version

Functions

Displays the version of the ID850NW.

Usage example

```
(IDCON) 1 % version
GUI      : V3.00 [XX XXXX 200X]
Devicefile : V850 Device File [uPD703201] V1.00
Debugger  : V850 Debugger V3.90 [XX XXXX 200X]
Executer  : V850 Executer V3.00 [XX XXXX 200X]
Monitor   : V850 Peripheral V3.00 [XX XXXX 200X]
Assembler : V850 Asm/Disasm V1.90 [XX XXXX 200X]
Tcl/Tk    : 8.4.5
```

watch

watch - Display/setting of variables

Input format

watch *?options? variable ?value?*

Functions

Displays and sets the variables.

The following are *options*:

-binary	The value is displayed in binary digits.
-octal	The value is displayed in octal digits.
-decimal	The value is displayed in decimal digits.
-hexdecimal	The value is displayed in hexadecimal digits.
-string	The value is displayed in character strings.
-sizeof	The size, instead of the value, of variables is displayed in decimal digits.
-encoding <i>name</i>	Encoding during character string display is specified. By default, system encoding is used. <i>name</i> (encoding name) is based on the Tcl specification (shiftjis, euc-jp, etc.).

Usage example

```
(IDCON) 1 % watch var
0x10
(IDCON) 2 % watch -d var
16
(IDCON) 3 % watch array[0] 0xa
```

where

where - Stack trace

Input format

where

Functions

Executes the back-trace of the stack.

Usage example

```
(IDCON) 1 % where  
1: test2.c#sub2(int i)#13  
2: test.c#num(int i)#71  
3: test.c#main()#82
```

wish

wish - Startup of Tclet

Input format

wish *scriptname*

Functions

Starts up the script using Tk (Tclet).

The expansion window can be created with Tclet.

Usage example

(IDCON) 1 % wish test.tcl

xtrace

xtrace - Operation of tracer

Input format

xtrace -dump *?-append? frameno ?filename?*

xtrace -start

xtrace -stop

xtrace -clear

xtrace -addup *?bool?*

xtrace -mode *?mode?*

Functions

Operates tracer.

The following are *options*:

-start	The tracer starts on executing the program.
-stop	The tracer stops on executing the program.
-clear	Clears the trace memory.
-dump	The trace data is dumped (default). The dump result is redirected to the console window. If the file name is specified, the dump result is written in the file.
-append	The dump result is added to a file.
-addup <i>?bool?</i>	This area is used to specify whether time tags of trace data are totaled or not.(Addition only) When <i>bool</i> is omitted, the current mode is displayed.
-mode <i>?mode?</i>	The trace control mode (any one of: all, cond, nonstop, fullstop, fullbreak, delaystop, delaybreak, machine or event) is selected.

Usage example

```
(IDCON) 1 % xtrace -start
(IDCON) 2 % xtrace -stop
(IDCON) 3 % xtrace -dump 3
_ 01685 2 000000BC M1 br _sub2+0x2
_ 01686 4 0000009A BRM1 st.w r6, 0x8[sp]
_ 01687 3 0000009E BRM1 st.w r0, 0x0[sp]
(IDCON) 4 % xtrace -clear
(IDCON) 5 % xtrace -addup true
```


7.12 Samples (Calculator Script)

The script of the expansion window in which the calculator script is described and its execution screen are shown below.

Script of expansion window

```
# Calculator.tcl
mdi geometry 100 100
set top .dcl
entry $top.e -relief sunken -textvariable v
frame $top.f -height 120 -width 120; pack $top.e -fill x; pack $top.f -fill both -expand 1set i 0; set v {}; set r
0.25
foreach n {7 8 9 / 4 5 6 * 1 2 3 - 0 = + C} {
    if {$n == "=" || $n == "C"} {
        button $top.f.b$n -text $n
    } else {
        button $top.f.b$n -text $n -command "$top.e insert end $n"
    }
    place $top.f.b$n -relx [expr ($i%4)*$r] -rely [expr ($i/4)*$r] -relw $r -relh $r    incr i
}
bind $top.f.bC <1> {$top.e delete 0 end}
bind $top.f.b= <1> {catch {expr $v} v}
```

Figure 7-1 Execution Screen



APPENDIX A EXPANSION WINDOW

- [Overview](#)
- [Sample Window](#)
- [Activation](#)
- [List window](#)

A.1 Overview

With the ID850NW, the user can create custom windows in addition to the existing windows.

The Tcl (Tool Command Language) interpreter and the commands for controlling the debugger are implemented in the ID850NW. Users can create windows using this Tcl.

The ID850NW is supplied with samples of the following expansion windows.

A.2 Sample Window

Table A-1 List of Expansion Window (Sample)

Window Name	Function
List window	Displays a list of the source files and functions.
Grep window	Searches a character string.
RRM window	This is the memory window for real-time RAM monitoring.
Hook window	Sets the hook procedure.
Memory Mapped I/O window	Writes to or reads from the specified address.
Sym Inspect window	Searches through a list of properly described symbols.
Run Break Timer window	Displays two types of time: Time at which the user program starts running (Run) and time at which the user program breaks (Break).

A.3 Activation

The expansion window can be activated by selecting List, Grep, RRM, Hook, Memory, SymInspect or RunBreak-Time in [Others] on the [Browse] menu.

Remark Each .tcl file is installed in NEC Electronics Tools\ID850NW\Vx.xx\bin\idctl\tools


A.4 Explanation of Each Sample Window

The ID850NW provides the sample window below.

List window

The lists of the source files and functions are displayed in a tree format in this window. When a function name in the list is clicked, the corresponding source is displayed.

Figure A-1 List Window




Grep window

Search for a character string is performed in the files under the source path.

When the search result is clicked, the corresponding source is displayed.

Figure A-2 Grep Window



Object	Function
Pattern	Input the character string to be searched.
<Mark> button	Marks the searched character string.
<Clear> button	Clears the marking.
<Jump> button	Put the cursor on a section in the search result and click this button to open the corresponding file.
Match Case	Select whether or not to distinguish uppercase and lowercase.
Filter	Specify the type of the file to be searched.

RRM window

This is a dedicated window for RAM monitoring.


The address area in which a value was changed in the RAM area during program execution is highlighted with a color. The display range is 1 KB. With reading RAM, execution of the user program momentarily breaks. On this window, the start address of the RAM area can be changed while the user program is being executed.

Caution All data are not read at the same time (because data of 1 KB is divided and read in word units).

Remark1 This RRM window is opened even when the RAM monitor function is set to OFF in the [Extended Option Dialog Box](#).

Remark2 The sampling interval is about 0.8 seconds (40MHz), but it depend on the frequency of the CPU operation.

Figure A-3 RRM Window



Object	Function
Address	Input the start address to be displayed (automatically aligned to 1 KB.)
<Change> button	Switch the start address display.
<Refresh> button	Reads data from the memory.
<Color> button	The color can be customized. The default color is red.
Keep Color	Specify whether or not to hold the color highlighting. Selected: Once a value is changed, the color highlighting is held until a break occurs. Unselected: The color is cleared if there is no change of values(default).
<Close> button	Closes this window.

Hook window

This window is used to set a hook to the debugger, using a hook procedure.

The hook procedure enables changing the register value before downloading a program, or after a CPU reset.


On this window, a hook can be set by using the following five tabs.

- [AfterDownload] tab: Hook after downloading
- [BeforeDownload] tab: Hook before downloading
- [AfterCpuReset] tab: Hook after CPU reset during break
- [BeforeCpuRun] tab: Hook before start of execution
- [AfterCpuStop] tab: Hook after break

Remark By setting a IOR by using the [BeforeDownload] tab before downloading the load module, for example, downloading can be executed at high speeds. Access to the external memory is also facilitated by using this tab.

If the setting is saved as "project-file-name.tcl" in the directory where the project is stored, the setting is executed when the project is next opened.

Figure A-4 Hook Window



Object	Function
[AfterDownload] tab	Hook after downloading After downloading is performed, the register values input to the tab are automatically overwritten by the specified value.
[BeforeDownload] tab	Hook before downloading Before downloading is performed, the register values input to the tab are automatically overwritten by the specified value.
[AfterCpuReset] tab	Hook after CPU reset during break after resetting CPU, the register values input to the tab are automatically overwritten by the specified value.
[BeforeCpuRun] tab	Hook before starting execution before starting execution, the register values input to the tab are automatically overwritten by the specified value.
[AfterCpuStop] tab	Hook after breaking After breaking, the register values input to the tab are automatically overwritten by the specified value.
<Test> button	All the commands described on the tabs are tested.
<Save> button	Saves all the tab contents to a file. If the ID850NW was activated from a project file, the file is saved as "project-file-name.tcl".
<Clear> button	Clears all the descriptions on the tabs.

Remark: Specify the program register and the peripheral I/O registers for the register name.

Memory Mapped I/O window


Data is explicitly read or written at a specified address in this window.

When a write is performed in the [Memory Window](#), the data is internally read and verified by the ID850NW. In addition, the memory can also be read simply by scrolling in the [Memory Window](#). On the Memory Mapped I/O window, however, the above operations are not performed.

Therefore, this window is useful for reading or writing a specific address.

While the user program is being executed, it momentarily breaks before data is written in this window.

Figure A-5 Memory Mapped I/O Window



Object	Function
Address	Input the address to display. The display target address changes by pressing the Enter key or clicking the <Jump> button. The data contents are not read at this time, so the address (numerical value) is displayed in the address display section, but "XX" is displayed in the data section.
<Jump> button	Jumps to the address input in the Address field.
<Refresh All> button	Reads all the areas currently displayed only once. "ZZ" will be displayed in the data section when an attempt is made to read an unmapped area, or when an error occurs upon a read.
<Refresh One> button	Reads data in the memory of the address at which the cursor is placed only once. The read data size depends on the display format. "ZZ" will be displayed in the data section when an attempt is made to read an unmapped area, or when an error occurs upon a read.
<Modify...> button	Opens the Memory Mapped I/O dialog box . The address at which the cursor is placed is the input address displayed in the Memory Mapped I/O dialog box. If this button is clicked after the cursor position is changed in the Memory Mapped I/O dialog box, the Address field in the Memory Mapped I/O dialog box is also changed.
<Close> button	Closes this window.
Context menu	Select the display format from Byte, HalfWord, and Word.


Memory Mapped I/O dialog box

This dialog box can be opened by clicking the <Modify... > button on the [Memory Mapped I/O window](#). It is used to write data to any address.

Caution1 When the area to which data is written is displayed in the [Memory Window](#) or [Watch Window](#), data is read in these windows after the <Write in> button is clicked.

Caution2 If Data Size is less than Access Size specified in the [Configuration Dialog Box](#), ID850NW reads data in Access Size once, changes the corresponding part of the read data, and writes the changed data in Access Size.

Figure A-6 Memory Mapped I/O Dialog Box




Object	Function
Address	Input the address to be written. The address corresponding to the data for which the cursor is placed in the Memory Mapped I/O window is displayed by default.
Value	Input the value to be written.
Data Size	Select the size of the data to be written. The size specified in the Memory Mapped I/O window is selected by default.
<Write in> button	Data is written to the specified address with the specified size.
<Close> button	Closes this dialog box.

Sym Inspect window

This window displays the list of the symbols and addresses of loaded module files, and is used for searching the list for the properly described symbol.

Figure A-7 Sym Inspect Window




Object	Function
Load Module:	Selects a load module file.
Filter:	Specifies a properly described symbol so that the symbol is retrieved.
Match Case	In Filter:, specify to differentiate or not differentiate case sensitivity. Check this box to differentiate case sensitivity.
Symbol	Displays the symbols. Clicking this icon has the symbols sorted in alphabetical order.
Address	Displays the addresses. Clicking this icon has the addresses sorted in ascending numerical order.

Context Menu	Function
Copy	Copies the selected address to the clipboard.
Jump to Source	Jumps from the address in the selected line to the identical address displayed in the Source Window .
Jump to Assemble	Jumps from the address in the selected line to the identical address displayed in the Assemble Window .
Jump to Memory	Jumps from the address in the selected line to the identical address displayed in the Memory Window .

Run Break Timer window

This window displays two types of time: Time at which the user program starts running (Run) and time at which the user program breaks (Break). The window is helpful when measuring takes a long time. The Windows timer function is utilized for this window; the time is displayed in hours, minutes, and seconds.

Figure A-8 RunBreakTimer Window



Object	Function
<Clear> button	Clears the time display

APPENDIX B INPUT CONVENTIONS

- Usable Character Set
- Symbols
- Numeric Values
- Expressions and Operators
- File Names

B.1 Usable Character Set

Table B-1 List of Character Set

Classification	Character
Alphabetic characters	Uppercase: A B C D E F G H I J K L M N O P Q R S T U V W X Y Z Lowercase: a b c d e f g h i j k l m n o p q r s t u v w x y z
Numerals	0123456789
Character equivalent to alphabetic character	@ _

Table B-2 List of Special Characters

Character	Name	Usage
(Left parenthesis	Changes operation order.
)	Right parenthesis	Changes operation order.
+	Plus	Addition operator or positive sign
-	Minus	Subtraction operator or negative sign
*	Asterisk	Multiplication operator or indirect reference operator
/	Slash	Division operator
%	Percent	Remainder operator
~	Tilde	Complement operator
	Vertical line	Bit sum operator
^	Circumflex	Bit difference operator
&	Ampersand	Bit product operator or address operator
[Left bracket	Array subscript operator or base register specification symbol
]	Right bracket	

Character	Name	Usage
.	Period	Direct member operator or bit position specifier
,	Comma	Delimiter between operands

B.2 Symbols

- (1) A symbol consists of characters A to Z, a to z, @, _ (underbar), . (period) and 0 to 9.
- (2) A symbol must start with a character other than numerals 0 to 9.
- (3) Uppercase characters (A to Z) and lowercase characters (a to z) are distinguished.
- (4) A symbol must be no more than 2048 characters long (if a symbol of more than 2048 characters is defined, only the first 2048 characters are valid).
- (5) A symbol is defined by loading a load module file.
- (6) Symbols are classified into the following types by the valid range:
 - Global symbol (assembly language,C language)
 - Static symbol (C language)
 - In-file static symbol
 - In-function static symbol
 - Local symbol (C language)
 - In-file local symbol
 - In-function local symbol
 - In-block local symbol
- (7) The following symbols are available for each language used:
 - Assembly language,
 - label name, bit symbol name
 - C language
 - Variable name (including pointer variable name, enumeration type variable name, array name, structure name, and union name)
 - Function name, label name
 - Array element, structure element, union element, bit field (if the symbol is an array, structure, or union)
- (8) A symbol can be described instead of an address or numeric value.
- (9) The valid range of a symbol is determined based on the source debug information when the source file is assembled or compiled.
- (10) Describe only the symbol name of a global symbol.
- (11) A local symbol is expressed in pairs with a file name.

B.3 Numeric Values

The following four types of numeric values can be used. The input format of each type is as shown below.

The suffix (**bold**) and the alphabetic characters of hexadecimal numbers may be uppercase or lowercase characters. If the first character is A to F, 0 must be prefixed to it.

In the input field of ID850NW, decimal numbers or hexadecimal numbers are alternately selected, depending on the default radix.

Table B-3 Input Format of Numeric Values

Numeric Value	Input Format
Binary number	n Y n...n Y (n=0,1)
Octal number	n O n...n O (n=0,1,2,3,4,5,6,7) n Q n...n Q (n=0,1,2,3,4,5,6,7)
Decimal number	n n...n n T n...n T (n=0,1,2,3,4,5,6,7,8,9)
Hexadecimal numbers	n n...n n H n...n H 0xn 0xn ...n (n=0,1,2,3,4,5,6,7,8,9,A,B,C,D,E,F)

B.4 Expressions and Operators

(1) Expressions

An expression consists of constants, register names, peripheral I/O registers name and symbols coupled by operators.

If peripheral I/O registers name, label name, function name, or variable name is described as a symbol, an address is calculated as the value of the symbol.

The elements making up an expression, except operators, are called terms (constants and labels). Terms are called the first term, the second term, and so on, starting from the left.

(2) Operators

The following operators of the C language can be used:

Table B-4 List of Operators

Symbol	Meaning	Explanation
Arithmetic operator		
+	Addition	Returns the sum of the first and second terms.
-	Subtraction	Returns the difference between the first and second terms.
*	Multiplication	Returns the product of the first and second terms.
/	Division	Divides the value of the first term by the value of the second term, and returns the integer of the results.
MOD %	Remainder	Divides the value of the first term by the value of the second term, and returns the remainder of the results.
- sign	Unary operator (negative)	Returns 2's complement of the value of the term.
+ sign	Unary operator (positive)	Returns the value of the term.
Logical operator		
NOT ~	Negation	Logically negates each bit of the term, and returns the results.
AND &	Logical product	Obtains the logical product of the values of the first and second terms on each bit, and returns the results.
OR 	Logical sum	Obtains the logical sum of the values of the first and second terms on each bit, and returns the results.
XOR ^	Exclusive logical sum	Obtains the exclusive logical sum of the values of the first and second terms on each bit, and returns the results.
Shift operator		
SHR >>	Right shift	Shifts the value of the first term by the value (number of bits) of the second term to the right, and returns the results. As many 0s as the number of shifted bits are inserted in the higher bits.
SHL <<	Left shift	Shifts the value of the first term by the value (number of bits) of the second term to the left, and returns the results. As many 0s as the number of shifted bits are inserted in the lower bits.
Byte separation operator		
HIGH	Higher byte	Of the lowest 16 bits of the term, returns the higher 8 bits.
LOW	Lower byte	Of the lowest 16 bits of the term, returns the lower 8 bits.
Word separation operator		
HIGHW	Higher word	Of the 32 bits of the term, returns the higher 16 bits.
LOWW	Lower word	Of the 32 bits of the term, returns the lower 16 bits.
Other		

Symbol	Meaning	Explanation
(Left parenthesis	Performs the operation in () before the operation outside (). '(' and ')' are always used in pairs.
)	Right parenthesis	

(3) Rules of operation

Operations are performed according to the priority of the operators.

Table B-5 Operator Priority

Priority	Operators
1 Higher	(,)
2	+ sign, - sign, NOT, ~, HIGHT, LOW, HIGHW, LOWW
3	*, /, MOD, %, SHR, >>, SHL, <<
4	+, -
5	AND, &
6 Lower	OR, , XOR, ^

- If the priorities of the operators are the same, the operation is performed from the left toward the right.
- Performs the operation in () before the operation outside ().
- Each term in an operation is treated as unsigned 32-bit data.
- All operation results are treated as unsigned 32-bit data.
- If an overflow occurs during operation, the lower 32 bits are valid, and the overflow is not detected.

(4) Terms

To describe a constant for a term, the following numeric values can be described.

Table B-6 Range of Radixes

Radix	Range
Binary number	0Y <= value <= 11111111111111111111111111111111Y (32 digits)
Octal number	0O <= value <= 37777777777O
Decimal number	-2147483648 <= value <= 4294967295 (A negative decimal number is internally converted into a 2's complement.)
Hexadecimal numbers	0H <= value <= 0FFFFFFFH

B.5 File Names

The following regulations apply to the source file names and load module file names.

(1) Source file names and load module file names

File names are composed of a to z, A to Z, 0 to 9, ., _, +, and -.

File names must start with a character other than ".".

File names cannot be prefixed or suffixed by a period (.) or space.

File names are not case-sensitive.

A file name consists of up to 259 characters including the path.

(2) Other file names

Other file names comply with Windows file name regulations.

The following characters cannot be used in file names.

`\ / : * ? " < > | ;`

File names cannot be prefixed or suffixed by a period (.) or space.

File names are not case-sensitive.

A file name consists of up to 259 characters including the path.

APPENDIX C KEY FUNCTION LIST

Table C-1 Key Function List

Key	Function
BackSpace	Deletes one character before the cursor and moves the cursor to the position of the deleted character. At this time, the character string following the cursor moves forward.
Delete	<ul style="list-style-type: none"> - Deletes one character after the cursor and move the character string following the cursor forward. - Deletes a various event condition selected in the Event Manager or each event dialog box. - Deletes the data selected in the Watch Window.
Insert	Alternately selects the insert mode and overwrite mode in the Source Window and Assemble Window. However, this key is invalid in the Memory, Register, and IOR Windows, and only the overwrite mode can be used as an input mode.
PrintScreen	Loads the entire display screen to the clipboard as a bitmap image (function of Windows).
Esc	<ul style="list-style-type: none"> - Closes the pull-down menu. - Closes the modal dialog box. - Restores the input data.
Alt	Moves the cursor to the menu bar.
End	Moves the cursor to the end of the line.
Home	Moves the cursor to the beginning of the line.
PageUp	Scrolls the screen one screen up. The cursor also moves up to the top of the screen.
PageDown	Scrolls the screen one screen down. The cursor also moves up to the top of the screen.
Space	Inserts one blank character.
Tab	Moves the cursor to the next item.
Up arrow key	Moves the cursor up. If the cursor is at the bottom of the screen, scrolls the screen up one line at a time.
Down arrow key	Moves the cursor down. If the cursor is at the top of the screen, scrolls the screen down one line at a time.
Right arrow key	Moves the cursor to the left. If the cursor is at the left most position on the screen, scrolls the screen one column to the right.
Left arrow key	Moves the cursor to the right. If the cursor is at the right most position on the screen, scrolls the screen one column to the left.
Enter	<ul style="list-style-type: none"> - Sets the input data. - Presses the default push button.
F1	Opens the Help window.

Key	Function
F2	Forcibly stops program execution. Same function as [Run] menu -> [Stop].
F3	Resets the CPU. Same function as [Run] menu -> [CPU Reset].
F4	Resets the CPU and executes the program. Same function as [Run] menu -> [Restart].
F5	Executes the program. Same function as [Run] menu -> [Go].
F6	Executes the program to the cursor position in the Source or Assemble Window. Same function as [Run] menu -> [Come Here].
F7	The user program is real-time executed until execution returns. Same function as [Run] menu -> [Return Out].
F8	Step execution. Same function as [Run] menu -> [Step In].
F9	Sets a breakpoint at cursor position in Source or Assemble Window. Same function as [Run] menu -> [Break Point].
F10	Next step execution. Same function as [Run] menu -> [Next Over].
F11	Sets or deletes a software breakpoint. Same function as [Run] menu -> [Software Break Point].
Shift+End	Expands the selection range to the end of the line.
Shift+Home	Expands the selection range to the beginning of the line.
Shift+Left arrow key	Expands the selection range one character to the left.
Shift+Right arrow key	Expands the selection range one character to the right.
Shift+F6	Executes the program from the cursor position in the Source or Assemble Window. Same function as [Run] menu -> [Start From Here].
Shift+F9	Resets the CPU. Same function as [Run] menu -> [CPU Reset].
Ctrl+End	Displays the last line. The cursor will also move to the last line.
Ctrl+Home	Displays the first line. The cursor will also move to the first line.
Ctrl+Left arrow key	Moves the cursor one word to the left. If the cursor at the left most position on the screen, scrolls the screen one column to the right.
Ctrl+Right arrow key	Moves the cursor one word to the right. If the cursor at the right most position on the screen, scrolls the screen one column to the left.
Ctrl+F5	Ignores break points being set, and executes the program. Same function as [Run] menu -> [Ignore break points and Go].
Ctrl+F9	Sets the address at the cursor position in the Source Window or Assemble Window to the PC. Same function as [Run] menu -> [Change PC].
Ctrl+A	Selects all the events registered to the Event Manager. Same function as [View] menu -> [Select All Event] in the Event Manager.
Ctrl+C	Copies a selected character string and saves it to the clipboard buffer.

Key	Function
Ctrl+D	Disassembles and displays the results from the jump destination address specified by the data value selected in the current window. Opens the Assemble Window. Same function as [Jump] menu -> [Assemble].
Ctrl+E	Opens the source file displayed in the active Source Window with the editor specified by the PM plus when the PM plus is running. Same function as [Edit] menu -> [Edit Source].
Ctrl+G	Performs a search. Opens the search dialog box corresponding to the current window. Same function as [View] menu -> [Search...].
Ctrl+J	Moves the display position. Opens the each dialog box, depending on the current window. Same function as [View] menu -> [Move...].
Ctrl+M	Displays the memory contents from the jump destination address specified by the data value selected in the current window. Opens the Memory Window. Same function as [Jump] menu -> [Memory...].
Ctrl+O	Loads a view file, source file, or text file. Opens the View File Load Dialog Box. The operation will differ depending on the extension of the file. view file: Displays the file in the corresponding window. Others: Displays the file in the Source Window. Same function as [File] menu -> [Open...].
Ctrl+S	Saves the data displayed in the current window to the view file. Same function as [View] menu -> [Save...].
Ctrl+U	Displays the corresponding source text and source line, using the data value selected in the current window as the jump destination address. Opens the Source Window. Same function as [Jump] menu -> [Source Text].
Ctrl+V	Pastes the contents of the clipboard buffer to the text cursor position.
Ctrl+W	Temporarily displays the contents of the specified data. Opens the Quick Watch Dialog Box. Same function as [View] menu -> [Quick Watch...].
Ctrl+X	Cuts a selected character string and saves it to the clipboard buffer. Same function as [Edit] menu -> [Cut].
Ctrl+Shift+Left arrow key	Expands the selection range one word to the left.
Ctrl+Shift+Right arrow key	Expands the selection range one word to the right.

APPENDIX D MESSAGES


- Display Format
- Types of Messages
- Message Lists

D.1 Display Format

Messages are output to the error/warning dialog box.

By pressing the F1 key while the error/warning dialog box is open, the related online help files are displayed.

Figure D-1 Error/Warning Messages



D.2 Types of Messages

The ID850NW outputs the following types of messages.

Table D-1 Types of Messages

Types	Meaning
Axxxx	A: Abort Error Stops processing, and terminates the debugger. If this error occurs, debugging cannot be continued.
Fxxxx	F: Fail Stops processing, and opened windows and dialog boxes are closed.
Wxxxx	W: Warning Stops processing, but opened windows and dialog boxes are not closed.

D.3 Message Lists

< X0000~ > < X1000~ > < X2000~ > < X3000~ > < X4000~ > < X5000~ > < X6000~ > < X7000~ > < X8000~ > < X9000~ > < Xa000~ > < Xb000~ > < Xc000~ > < Xd000~ > < Xe000~ > < Xf000~ >

(1) X0000~

F0002: This feature is not supported.
F0100 : Can not communicate with ICE. Please confirm the installation of the device driver for the PC interface board. 1) The driver may not be correctly installed. Reinstall the driver.
A0102: Host name not found.
F0103: Data transfer to ICE is timed out. Please confirm the power of ICE, connection of the interface cable, or I/O address of the PC interface board.
F0104: Data receive from ICE is timed out. Please confirm the power of ICE, connection of the interface cable, or I/O address of the PC interface board.
A0105: Failed in reading device file (d3xxx.800). 1) Necessary files may be damaged. Reinstall the device file.
A0106: Illegal data received. 1) Check the power of the in-circuit emulator, cable connections, and setting of the interface board and restart the debugger.
A0107: Can not communicate with ICE.
A0108: Failed in reading initialization file (expc.ini).
A0109: Can not communicate with ICE. Please terminate the debugger and check the power of ICE or the connection of cable then restart the debugger.
F010a: Can not communicate. Please confirm the availability of the communication port. 1) A01a0:Please confirm the signal of the CLOCK or RESET WAIT, HLDRQ and so on.Check the HOLD signal, WAIT signal, clock signal, etc. The IOR value (or SFR value) may not be correct.
A01a1: Failed in reading ie703000.ie.
A01a3: Emulation board is not connected.
A01a4: Board configuration of ICE is not consistent.
A01a5: POD/EM1 board is not connected.
A01a6: Executor is running.
A01ad: Please update the device driver for the PC interface board. 1) The device driver may be old. Install the latest device driver.
A01ae: Failed in reading configuration file (lv8hw.ini).
A01af: Failed in executing monitor command.
A01b0: Can not communicate with monitor program. Please check the availability of communication port, the setting of CPU board or the type of cable.

A01b1: Can not communicate with monitor program. Please terminate the debugger and check the power of CPU board or the connection of cable then restart the debugger.
F0200: Verification error occurred. Failed in writing memory. 1) External memory could not be accessed, as it is not set. Change the register values necessary for accessing the external memory using the IOR Window or Hook Procedure before download.
F02a0: Bus hold error. 1) CPU is in the bus-hold status. Reset the debugger.
F02a2: Can not compulsory break.
F02a3: Reset under continuation.
F02d2: Not enough memory for trace-buffer.
F0300: User program is running.
F0301: User program is being broken.
F0302: User program is being traced.
F0303: Not traced.
F0304: Trace memory is not set.
F0306: No trace block exists.
F0307: No event condition exists.
F0308: No timer measurement is done.
F0309: No trigger frame exists.
F030a: Tracer is being stopped.
F030b: Specified snap-event has not been registered.
F030c: Specified stub-event has not been registered.
F030d: Timer is running.
F030e: Memory copy area is overlapped.
F030f: Trace has been already set.
F0310: Event condition is not set.
F0311: Too many valid timer event conditions.
F0312: Specified timer event is not set.
F0313: Illegal map range. 1) Check the map range in the Configuration Dialog Box . When mapping to external memory has been performed, change the register values necessary for accessing the external memory using the IOR Window or Hook Procedure before download).
F0314: Only trace delay mode can set with delay trigger.
F0315: Delay trigger cannot set without trace delay mode.
F0316: Overflowed the number of mapping.

F03a0: Target is not turned on. 1) Check the target power supply. Check the cable connecting the in-circuit emulator and target board. Check that the VDD signal is input to the connector of the target board.
F03a1: Step execution is being done.
F03a2: Timer and Tracer are running.
F03a3: Event link and BRS events are mixed.
F03d0: Back-trace is being executed.
F03d1: Back-trace is being stopped.
F03d2: Back-trace execution point overrun oldest frame.
F03d3: Register status or Memory status cannot be set up other than Phase1 of event link.
F03d4: No back-trace information exists.
F03d5: Last command can not be backstepped.
F0400: Illegal condition. 1) Settings of the used in-circuit emulator and those of the Configuration Dialog Box may not match. Check the Chip selection.
F0401: Result of timer measurement overflowed.
F0402: Too many event conditions with path count.
F0403: Too many address range conditions.
F0404: Too many simultaneously-usable-event conditions.
F0405: Too many snap-events.
F0406: Too many stub-events.
F0407: Too many initialization data.
F0408: Too large search data (> 16 byte).
F0409: Too large search data (> search range).
F040a: Too many Linking-event conditions.
F04a0: Software break conditions number overflow.
F04a1: Not enough memory for emulation.
F04a2: Too many partition of bus size.
F04a3: Too many execution-event conditions.
F04a4: Too many bus-event conditions.
A0600: Not enough memory for buffer. 1) There is not enough system memory. Close the applications being executed and the open files.
A0601: Not enough resource of operating system.
F0b61: Section Trace event conditions overflow.
F0c00: Monitor file read error. 1) Necessary files may be damaged. Reinstall the debugger.

A0c01: During access of register, CPU did time out. 1) Check the clock signal, etc. The register value may not be correct.
A0c02: During access of memory, CPU did time out. 1) Check the HOLD signal, WAIT signal, clock signal, etc. The memory value may not be correct.
A0c03: During access of I/O register, CPU did time out. 1) Check the HOLD signal, WAIT signal, clock signal, etc. The I/O register value may not be correct.
F0c20: Guarded area can not be accessed.
F0c21: Memory was unready status.
F0c22: Memory unready status was canceled.
F0c23: Bus hold under continuation. 1) Check the setting of the target board, or mask the HOLD pin.
F0c24: It cannot shift to debug mode. 1) Check the clock signal. This may be caused by a stopped clock or a slow clock.
F0c25: Flash macro service ROM was accessed or stepped in. 1) Please perform [Go] execution or CPU reset.
F0c26: FLMD terminal is in a write-protected state. 1) FLMD is not in the write-enabled status. Check the status of the FLMD0 and FLMD1 pins.
F0c27: Security flag is in a write-protected state. 1) The security flag of the flash memory has disabled writing, block erasure, or chip erasure. Nothing can be written to the flash memory.
F0c28: Internal RAM is not enough, the writing to flash memory is not made. 1) The internal RAM size is less than 4 KB and flash self-programming cannot be executed.
F0c29: The blank check of flash memory failed.
F0c2a: The erasing of flash memory failed.
F0c2b: The writing of flash memory failed.
F0c2c: The internal verification of flash memory failed.
F0c2d: Failed in writing flash memory.
F0c2e: There is no response from flash macro service.
F0c2f : Response from flash macro service is not right.
F0c30: Flash I/O register operation prohibition setup needs to be canceled.
F0c31: STOP mode under continuation. Can not compulsory break. Please release STOP mode or reset the CPU.
F0c40: Status of effective event conditions cannot be changed.
F0c41: Coverage test is being executed.
F0c42: Monitor has failed in shift in the debugging mode. Please reset the CPU.

<p>F0c43: Connection of emulator cannot be performed.</p> <p>1) Check the power to the in-circuit emulator. Or, the PC-IF cable may not be correctly connected. Check the connection (when the IE-70000-MC-NW-A is connected).</p>
<p>F0c44: Coverage test is being executed.</p>
<p>F0c45: Inside of Power off reset emulation cannot carry out program execution.</p>
<p>F0c60: Event before execution cannot be set up other than break conditions.</p>
<p>F0c61: Can not register event numbers which can not be used for hardware break.</p>
<p>F0c62: Event numbers reserved for hardware breaks can not be used.</p>
<p>F0c63: Event link conditions cannot set.</p>
<p>F0c64: Too many ROM-emulation-RAM areas.</p>
<p>F0c67: Writing of flash memory during block is not made.</p>
<p>F0c70: DCU cannot be accessed.</p> <p>1) The device file selection may be incorrect. Select a device file that supports the target chip in Chip Selection in the Configuration Dialog Box. Check the power to the chip. Check the connection of the signal lines (DCK, DMS, DDI, DDO, and DRSTZ). Check the noise level by a DCK waveform test on the N-Wire Checker.</p>
<p>F0c71: Reset cannot be performed.</p> <p>1) Check the clock signal. This may be caused by a stopped clock or a slow clock.</p>
<p>F0c72: Monitor memory cannot be accessed.</p> <p>1) Check the noise level by a DCK waveform test on the N-Wire Checker. The problem may also be caused by an internal chip problem.</p>
<p>F0c73: Monitor execution cannot be performed.</p> <p>1) Check the noise level by a DCK waveform test on the N-Wire Checker. The problem may also be caused by an internal chip problem .</p>
<p>F0c74: CPU register cannot be accessed.</p> <p>1) Check the noise level by a DCK waveform test on the N-Wire Checker. The problem may also be caused by an internal chip problem .</p>
<p>F0c75 : Monitor has failed in shift in the debugging mode. Please reset the CPU.</p>
<p>F0c76 : Initial state at the time of DCU access start is unusual.</p>
<p>F0c77 : DCU access is unusuall.</p>
<p>F0c78: Failed in reading of trace data.</p>
<p>F0ca0: Can not communicate with ICE. Please confirm the power of ICE, connection of the interface cable, or I/O address of the PC interface board. Error occurred inside debugger.</p> <p>1) Can not communicate with in-circuit emulator. Check the power of the in-circuit emulator, cable connections, and setting of the interface board etc.</p>
<p>F0ca1: Monitor file not found.</p> <p>1) Necessary files may be damaged. Reinstall the debugger.</p>
<p>F0ca2: This device file does not include the on-chip debug information.</p>

F0ca3: Unsupported information is included in the on-chip debug information in the device file. 1) An unknown flag is included in the on-chip debug information of the device file. The exec module may be old. Install the latest exec module.
F0caf: Trace block can not be stepped over.

(2) X1000~

A1000: Failed in initializing ICE.
A1001: No entry exists for specified number.
A1002: Can not relocate internal RAM.
F1003: Illegal relocation address.
F1004: Illegal condition.
A1005: Invalid attribute.
F1006: Illegal address.
A1007: Not enough memory on ICE.
A1008: Not enough memory for tables. 1) There is not enough system memory. Close the applications being executed and the open files.
A1009: Already initialized.
A100a: Not initialized.
F100b: User program is running.
F100c: Different bus size has been already specified.
F100d: Too large bus size.
F100e: Too large bus partition size.
W100f: Target is not turned on.
F1010: Illegal map range.
F1011: Failed in setting internal ROM and RAM.
F1012: This feature is not supported.
F1013: No terminal name.
W1014: Data is not exist.
A1015: Programmable-IOR does not exist.
F1016: Programmable-IOR does not movable. 1) Necessary files may be damaged. Reinstall the latest device file.
F1017: I/O Protect mapping is possible a target attribute only.
F1018: Illegal Internal ROM size.
A10ff: Can not communicate with ICE.
A1dbe: Error occurred inside debugger.

(3) X2000~

F2000: Illegal IOR name.
A2001: Illegal address.
F2002: User program is running.
F2003: Illegal IOR number.
F2004: Illegal bit number.
W2005: IOR of Read Protect attribute was specified.
F2006: Hidden IOR was specified.
F2007: IOR of ban read or write was specified.
F2008: IOR not existing was specified.
A2009: Device file is damaged or error is in file.
F200a: Illegal value specified for IOR.
A200b: Can not copy.
A200c: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
W200d: No initialize data for IOR.
F200e: IOR area can not be accessed.
A20ff: Can not communicate with ICE.
A2222: Illegal condition.

(4) X3000~

F3000: No mapped address was accessed. 1) The allocation addresses of the program and the addresses of the debugger may not match. Set the mapping to the external memory in the Configuration Dialog Box according to the allocation addresses specified in the link directive file on compilation. When mapping to external memory has been executed, change the register values necessary for accessing the external memory using the IOR Window or Hook Procedure before download.
F3001: Memory has different value.
F3002: Illegal start address.
F3003: Illegal end address
F3004: Illegal start address and end address.
F3005: Illegal condition.
F3006: User program is running.
F3007: Verification error.
F3008: No condition specified.
F3009: Parameter size does not align with access size alignment.
F300a: Specified address does not align with access size alignment.

F300b: Source address does not align with access size alignment.
F300c: Destination address does not align with access size alignment.
F300d: Illegal end address.
F300e: Different access size in specified area.
F300f: Different access size both in source and destination areas.
F3010: Different access size in destination area.
F3011: Different access size, source & destination.
A3012: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
F3013: Failed in writing DMM.
F3014: Overflowed mapping area.
F3015: Processing was interrupted.
F3016: This feature is not supported.
A30ff: Can not communicate with ICE.

(5) X4000~

F4000: Can not delete specified event. 1) The specified event cannot be deleted as it is being used under another condition. Invalidate it for other usages before deleting.
F4001: Illegal table number.
F4002: Illegal start address.
F4003: Illegal end address.
F4004: Illegal status.
F4005: Illegal data.
F4006: Specified event number has been already used.
F4007: Too many same events are registered.
F4008: Specified event has not been registered.
F4009: Illegal data size.
F400a: Illegal mode.
F400b: Setting value is inaccurate.
F400c: Event link conditions cannot be used for section trace conditions.
F400d: Too many identical events are registered (>= 32767).
F400e: Specified event condition does not exist.
F400f: Illegal event link condition.
F4010: Function not found.
A4011: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.

F4012: Timer is being disabled.
W4013: Access size is different from its mapped bus size.
F4014: Can not use software break.
F4015: Can not use event condition specifying address range.
F4016: Can not change event condition.
F4017: Can not access word at odd address.
A4018: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
F4019: This feature is not supported.
F401a: No Event.
F401b: Can not use tag-event.
W401c: Software break can not be set on this area.
F401d: Start event and end event of timer are not made to the same setup.
F401e: Too many trace-events.
F401f: Path count cannot be set up.
F4020: Address range cannot be set up in event before execution.
F4021: Event conditions number overflow.
F4022: Software DMM conditions number overflow.
F4023: Real-time call conditions number overflow.
F4024: Software break call conditions number overflow.
F4025: Illegal snap condition.
F4026: Too many event conditions cannot be set as Phase1 and Phase2 of event link conditions.
F4027: Software break conditions number which can be set as internal ROM was overflow.
F4318: Illegal memory bank setting.

(6) X5000~

A5000: Illegal device file type.
A5001: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
A5002: Can not open device file.
A5003: Reading of device file went wrong.
A5004: Can not close device file.
A5005: Illegal device file format. 1) Necessary files may be damaged. Reinstall the device file.
A5006: Failed in initializing ICE.
A5007: Device file has broken or error is in a file.

F5008: Can not open device file. 1) Necessary files may be damaged. Reinstall the device file.
F5009: Can not open ie703000.ie.
F500a: Specified device file is illegal version. 1) Necessary files may be damaged. Reinstall the device file.
W500b: Specified device file does not relocate IRAM.
A500c: Failed in reading expc.ini.
A500d: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
W500e: No tag data which it was going to refer to device file.
A5300: Illegal device file type.
A5301: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
A5302: Can not open database file. 1) Necessary files may be damaged. Reinstall the debugger and device file.
A5303: Reading of database file went wrong.
A5304: Can not close database file.
A5305: Illegal database file format. 1) Necessary files may be damaged. Reinstall the debugger, and device file.
A5306: Database information has been already initialized.
A5307: Database information does not exist.
F5308: Can not open specified database file. 1) Necessary files may be damaged. Reinstall the debugger.
F5309: Specified database file is illegal version. 1) Necessary files may be damaged. Reinstall the debugger, and the device file.

(7) X6000~

F6000: Current function does not exist.
F6001: Illegal symbol name.
F6002: Illegal condition.
F6003: Illegal function name.
F6004: Overflowed output buffer size.
F6005: Illegal expression.

(8) X7000~

F7000: Illegal mode.
F7001: User program is running.

F7002: User program has been stopped.
F7003: Trace enabled.
F7004: Trace memory is not set.
F7005: Function return address does not exist, can not do step execution.
W7010: No source information exists.
W7011: Unknown result of step execution.
A7012: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
A70fe: Bus hold error. 1) CPU is in the bus-hold status. Reset the debugger.
A70ff: Can not communicate with ICE.
F7801: End waiting state of step execution was canceled.
F7802: End waiting state of step execution was canceled.
F7f00: Aborted step execution.
F7f02: Suspended step execution.
A7f03: Failed in canceling RUN/STEP.
F7f04: Can not execute non-mapped area.
F7f05: This feature is not supported.

(9) X8000~

F8000: Specified file was not found.
F8001: Illegal line number.
F8002: Current information is not set.
F8003: Illegal address.
F8004: This feature is not supported.

(10) X9000~

A9000: Specified register symbol does not exist.
A9001: Specified register symbol ID does not exist.
F9002: Illegal value.
A9003: Illegal condition.
A9004: Too large register size.
F9005: This feature is not supported.

(11) Xa000~

Fa001: Illegal expression.

Fa002: Start address is bigger than the end address.
Fa003: Illegal source path.
Fa004: Too long expression.
Aa005: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
Fa006: Illegal argument.
Fa007: Illegal program number.
Fa008: Source path is not set.
Fa009: File not found.
Fa00a: Can not open file. 1) The file is damaged or does not exist. Recreate the file.
Aa00b: Can not close file.
Aa00c: Failed in reading file. 1) The file is damaged or does not exist. Recreate the file.
Fa00d: Not source file of load module.
Fa00e: Illegal line number.
Fa00f: Variable does not exist.
Aa010: Can not communicate with ICE.
Fa011: Can not access register.
Fa012: Can not access memory.
Aa013: Reading of file went wrong.
Fa014: It was going to open the binary file.
Fa015: Can not get temporary path. 1) The disk is full. Delete or move unnecessary files and increase the available memory in the disk.
Fa016: Can not create temporary file. 1) The disk is full. Delete or move unnecessary files and increase the available memory in the disk.
Fa017: Can not remove temporary file.
Fa020: This feature is not supported.
Fa021: Symbol assigned to register cannot be specified.
Fa022: The character which cannot be used for the folder is contained or the folder does not exist.

(12) Xb000~

Fb000: Illegal command line.
Fb001: Program information does not exist in specified load module file.
Fb002: File not found.
Fb003: Function not found.

Fb004: Selected load module different from kind (Chip) was loaded.
Fb005: Symbol not found. 1) The address could not be found. Specify a location holding address information.
Fb008: Illegal expression.
Ab009: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
Fb00a: Illegal symbol in load module file.
Fb00b: Current program does not exist.
Fb00c: Current file does not exist.
Ab00d: Current function does not exist.
Ab00e: Current line does not exist.
Ab00f: Tag not found.
Ab010: Failed in loading symbol table.
Ab011: Illegal line number.
Fb012: Too large line number.
Ab015: Reading of file went wrong. 1) The file is damaged or does not exist. Recreate the file.
Ab016: Can not open file. 1) The file is damaged or does not exist. Recreate the file.
Ab017: Failed in writing file. 1) The file is damaged or does not exist. Recreate the file.
Ab019: Reading of file went wrong.
Ab01a: Can not close file.
Fb01b: Too long load module file name.
Ab01c: Too many entries of the task kind.
Fb01d: Address not found.
Wb01e: No debug information (not compiled in Debug Build mode).
Fb01f: Can not find structure member.
Fb020: Can not find value.
Fb021: No debug information exists in load module file. 1) To create a load module with appended debug information, execute build in build mode of Debug Build.
Fb022: Illegal line number.
Ab023: Current stack frame is not active.
Ab024: Different section.
Fb026: Too many array dimensions (> 4).

Fb027: Found end of file. 1) The specified file may be damaged. Recreate the file.
Fb028: This feature is not supported.
Fb029: Illegal address.
Ab02a: Can not communicate with ICE.
Fb02b: Can not stack trace with current PC value.
Fb02c: Too many blocks for one function.
Fb02d: Illegal argument.
Fb02e: The file does not exist in the SOURCE PATH. 1) On stopping the program, the source that the debugger tried to display could not be found. Check if the path connects to the source in the Debugger Option Dialog Box , or check if the source is in the same directory as the out file. Refer to the Assemble Window on which the error message is displayed, and check if the corresponding path connects.
Fb02f: Information has been deleted because of optimization.
Ab030: Monitor timed out. 1) Check the power of the in-circuit emulator, cable connections, and setting of the interface board and restart the debugger.
Ab031: Already set in memory.
Ab032: Out of scope.
Ab033: LP is not stored.
Fb034: Return execution from present PC position cannot be performed.
Fb037: Too Many Line-Numbers Information.
Fb038: Compiler version mismatch. 1) Recreate the load module with the latest compiler.
Ab039: Failed in loading debug information.
Ab03a: No more section information.
Fb040: Specified file is not load module. 1) This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker.
Ab041: Too many files in load module to download.
Wb042: Symbol module is not initialized.
Fb32e: Illegal port number.
Fb32f: Illegal port name.
Fb330: Illegal port position.
Fb331: Illegal increment number.
Fb332: Port for memory bank is not set.
Fb333: Illegal bank number.

Fb334: Area for memory bank is not set.

Wb335: Too long symbol name.

(13) Xc000~

Fc001: Can not open file.

- | |
|--|
| 1) The file is damaged or does not exist. Recreate the file. |
|--|

Ac002: Can not close file.

Ac003: Reading of file went wrong.

- | |
|--|
| 1) The file is damaged or does not exist. Recreate the file. |
|--|

Ac004: Reading of file went wrong.

Fc005: Illegal file type.

Fc006: Kind (Chip) of load module is illegal.

Fc007: Specified file is not load module.

- | |
|--|
| 1) This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker. |
|--|

Fc008: Specified load module file (ELF) is old version.

Ac009: Not enough memory.

- | |
|---|
| 1) There is not enough system memory. Close the applications being executed and the open files. |
|---|

Fc00a: No mapped address was accessed.
--

Fc00b: Load module is not loaded.

Fc00c: Illegal argument.

Fc00d: User program is running.

Fc00e: User program is being traced.

Fc00f: Interrupted.

Ac010: Can not communicate with ICE.

Fc011: Illegal load module file format.

Fc012: Check sum error.

Fc013: Too wide address range to upload (> 1M byte).
--

Fc014: Failed in writing file.

- | |
|--|
| 1) The file is damaged or does not exist. Recreate the file. |
|--|

Fc015: Illegal program number.

Fc016: Load information is full.

Wc017: Symbol information is duplicated, please reset symbols.
--

Fc018: Specified file is not load module.

- | |
|--|
| 1) This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker. |
|--|

Fc019: Failed in writing memory.

Wc01a: BSS area is assigned to non-mapped area. 1) When the program is executed, a non-map break may occur. Either allocate the BSS area to the internal RAM by using a link directive, or map the emulation memory or target memory to the BSS area using the Configuration Dialog Box of the debugger.
Fc01b: Programmable-IOR address not specified. 1) Necessary files may be damaged. Reinstall the debugger.
Wc01c: Programmable IOR address mismatch. 1) Necessary files may be damaged. Reinstall the debugger.
Wc01d: Selected load module different from kind (Chip) was loaded.
Fc01e: .Flash erase is not supported.
Fc100: This feature is not supported.

(14) Xd000~

Ad000: Error occurred inside debugger.
Ad001: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
Ad002: Failed in reading initialization file (expc.ini).
Ad003: ICE is not connected.
Fd004: Can not find Dynamic Link Library.

(15) Xe000~

Fe000: Illegal argument.
Fe001: Illegal start address.
Fe002: Illegal end address.
Fe003: Too large size.
Fe004: Can not open file. 1) The file is damaged or does not exist. Recreate the file.
Fe005: Failed in reading file. 1) The file is damaged or does not exist. Recreate the file.
Fe006: Reading of file went wrong.
Fe007: Failed in writing file. 1) The file is damaged or does not exist. Recreate the file.
Ae008: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
Fe009: Illegal file format.
Fe00a: Verification error.
Fe010: This feature is not supported.

(16) Xf000~

Af000: Not enough memory. 1) There is not enough system memory. Close the applications being executed and the open files.
Ff000: Not enough memory.
Ff001: [XXX] not found.
Wf002: Not found [XXX]. Search from the beginning?
Wf003: Already exceed search region.
Ff004: Missing parameter.
Ff005: Illegal function name.
Ff006: Illegal number.
Ff007: Start address is bigger than end address.
Ff008: Illegal symbol or expression.
Ff009: [XXX] This file is illegal type.
Ff100: Disk cannot write or full.
Ff101: File not found.
Ff102: File not Create.
Ff103: Old project file version.
Ff104: Illegal project file format.
Ff105: This file is a project file for [XXX].Please select a correct file.
Wf106: CPU in the Project File was Changed. You must exit the debugger for the new CPU. Do you exit the Debugger?
Wf107: CPU in the Project File was Changed. Do you start the Debugger with this CPU?
Wf108: Selected project file different [YYY] from chip [XXX] was opened. Does it open, although the chip cannot be changed?
Wf109: Project Manager cannot be used with the debugger of this version. Please use PMplus.
Wf200: No difference encountered.
Ff201: Memory mapping error.
Ff202: Verify error. 1) External memory could not be accessed, as it is not set. Change the register values necessary for accessing the external memory using the IOR Window or Hook Procedure before download .
Wf203: When a program is running, while rewriting a memory, program execution stops for a moment. Do you wish to rewrite a memory?
Wf300: Would you like to save the changes made in [XXX]?
Ff301: The symbol being used on the event condition can't be evaluated.
Wf302: Delete: [XXX]
Wf303: [XXX] is edited. Delete: [YYY]?
Wf304: [XXX] is edited. Save: [YYY]?

Wf305: [XXX] is already exist. Do you replace it?
Ff306: This name is too long.
Ff307: There is the same name in other kinds.
Ff308: An address can't be omitted.
Ff309: Illegal address mask.
Ff30a: Illegal data mask.
Ff30b: Illegal ext probe mask.
Ff30c: Illegal ext probe data.
Ff30d: Illegal pass count.
Ff30e: Illegal register name.
Ff310: Illegal delay count.
Wf311: Only one [XXX] can be enabled. Do you make this [YYY] to enable?
Ff312: [XXX] is already there.
Ff313: Event number already exist.
Ff314: Event name is not set.
Ff315: [XXX] is already there.
Ff316: Max number of enabled [XXX] event is over. Please disable other enabled [YYY] event.
Ff317: Max number of set event is over.
Ff31e: Illegal start address.
Ff31f: Illegal end address.
Ff350: There is a phase which event are not in the middle.
Ff351: The same event is contained in Link and Disable.
Ff352: An event isn't specified.
Ff500: Illegal symbol.
Ff501: Illegal value.
Ff502: Illegal parameter.
Ff503: Max number of symbol is over.
Ff504: This variable cannot be set as a break. 1) Break cannot be set for the following variables. - Local variables, static variables - Array variables, member variables of structures/unions - Register/peripheral I/O registers - Variable expressions
Wf600: Save project file?
Wf601: When connecting the target system, please turn on the target system. 1) When a target is not connected, simply click the <OK> button.
Wf602: Please change a MODE mask condition or connect the target system.

Wf700: Do you want to download Load Module File?
Ff802: All events are deleted. because the use of external probe was changed.
Ff803: This event address is invalid on current configuration.
Ff804: Invalid PC value.
Ff805: Cannot set temporary break on this address.
Ff806: External data is being used by Debugger.
Ff900: Illegal I/O port name.
Ff901: Memory mapping error. 1) The specification of the address is illegal. Check the addresses that can be specified in the Add I/O Port Dialog Box .
Ff902: Illegal access size.
Ff903: Illegal access type.
Ff904: There is the same name.
Wf905: [XXX] is already exist. Do you replace it?
Wf906: Would you like to register the change made in [XXX]?
Ffa00: The [XXX] function of current program on PC position not found. 1) The symbol specified in main() label: in the Debugger Option Dialog Box could be found. Set a symbol of the main routine of the program. Default is <code>_main</code> .
Ffa01: The line information on PC position not found. 1) The source file corresponding to program counter (PC) value when the program was stopped could not be found. The following reasons are possible. -The source file exists in a location that the source path does not connect to. -The program stopped where the source files, such as library or RX, do not exist. -The program looped, jumped to an address that is not used by the program, and stopped there.
Wfb00: User program is running. Do you want to stop user program? 1) <Yes> button is selected, execution of the user program is stopped and then the Exit Debugger Dialog Box is displayed. If it is specified in the Debugger Option Dialog Box that the Exit Debugger dialog box is not to be displayed, however, the ID850NW is terminated. <No> button is selected, execution of the user program is not stopped and the Exit Debugger Dialog Box is not displayed. The ID850NW is not terminated.
Wfb01: Since bit 7 of address 0x79 in the ID code are 0, The N-Wire emulator becomes prohibition of use henceforth. Do you exit the debugger as it is?
Ffc00: Online help window cannot be started. Please install HTML Help environment with reference to a users manual.
Ffd00: Failed to specify [XXX].
Ffff: Interrupted.

APPENDIX E INDEX

A

About Dialog Box ... 227
Active status and static status ... 73
Add I/O Port Dialog Box ... 185
Add Watch Dialog Box ... 150
Address Move Dialog Box ... 138
Assemble Search Dialog Box ... 136
Assemble Window ... 131

B

break
 Breakpoint setting ... 45
 setting break to variable ... 46
Break Dialog Box ... 214
break function ... 44
Browse Dialog Box ... 232

C

callback procedure ... 239
Change Watch Dialog Box ... 153
character set ... 286
Come Here ... 49
command ... 229
Command reference ... 234
Conditional trace ... 61
Configuration Dialog Box ... 95
Console Window ... 229
Contents saved to project file ... 70
Context menu ... 83

D

Debug function list ... 36
Debugger Option Dialog Box ... 105
Delay Count Dialog Box ... 198
Delay trigger ... 197
Delay trigger trace ... 62
device driver ... 21
DMM Dialog Box ... 172
DMM function ... 55
download ... 39
Download Dialog Box ... 115
Download Function / Upload Function ... 39
drag & drop function ... 77

E

Environment Setting File Load Dialog Box ... 223
Environment Setting File Save Dialog Box ... 221
Errors ... 295
Event function ... 63
Event icon ... 67
Event manages ... 67
Event Setting Status (Event Mark) ... 123
Exit Debugger Dialog Box ... 226

Expansion window ... 276
Expressions ... 288
Extended Option Dialog Box ... 99

F

Font Dialog Box ... 230

G

-g option ... 23

H

hook procedure ... 240

I

I/O protect ... 38
IE-70000-MC-NW-A ... 19, 20
In-circuit emulator ... 20
input conventions ... 286
Installing ... 24
Interface card ... 20
Internal RAM ... 38
Internal ROM ... 38
IOR Select Dialog Box ... 183
IOR Window ... 179

J

jump function ... 74

L

Load Module List Dialog Box ... 120
Load/Save Function ... 69
Local Variable Window ... 155

M

Main Window ... 84
mapping ... 97
Mapping attribute ... 37
Mask ... 97
Memory Compare Dialog Box ... 169
Memory Compare Result Dialog Box ... 171
Memory Copy Dialog Box ... 167
Memory Fill Dialog Box ... 165
Memory manipulation function ... 54
Memory Search Dialog Box ... 163
Memory Window ... 160
Messages ... 295
Midas Lab emulators ... 20, 22
Mixed display mode
 Source window ... 42
 Trace View Window ... 60

N

N-EXEC for RTE ... 20

O

Operating Environment ... 20

Operators ... 289

Others

Grep window ... 278

Hook window ... 280

Memory Mapped I/O dialog box ... 283

Memory Mapped I/O window ... 282

RRM window ... 279

Run Break Timer window ... 285

Sym Inspect window ... 284

P

PM+ ... 30

Point mark area ... 123, 132

program code ... 124

Program execution function ... 48

Programmable I/O ... 96

project file ... 69, 226

Project File Load Dialog Box ... 113

Project File Save Dialog Box ... 111

Q

Quick Watch Dialog Box ... 147

R

RAM ... 68

Range of Radixes ... 290

Register Select Dialog Box ... 177

Register Window ... 174

reset ... 225

Reset Debugger Dialog Box ... 225

right click menu ... 83

ROM Emulation RAM ... 38

ROM probe ... 20

RRM ... 68

RRM function ... 68

RTE-1000-TP ... 20

RTE-2000-TP ... 20

S

Section trace ... 62, 197

Setting debugging environment ... 37

setting file ... 72

Setting mapping ... 37

Software Break Manager ... 199

Source Search Dialog Box ... 127

Source Text Move Dialog Box ... 129

Source Window ... 122

Stack trace display function ... 53

Stack Window ... 157

Start From Here ... 49

Startup option ... 25

Startup Routine ... 109

Status Bar ... 93

Supplement Data ... 59

Symbol To Address Dialog Box ... 139

T

Target ... 37

Tcl

assemble ... 243

batch ... 244

breakpoint ... 245

cache ... 247

dbgexit ... 248

download ... 249

extwin ... 250

finish ... 251

go ... 252

help ... 253

hook ... 254

ie ... 255

inspect ... 256

jump ... 257

map ... 258

mdi ... 259

memory ... 260

module ... 261

next ... 262

refresh ... 263

register ... 264

reset ... 265

run ... 266

step ... 267

stop ... 268

upload ... 269

version ... 270

watch ... 271

where ... 272

wish ... 273

xtrace ... 274

Tcl command list ... 236

Timetag ... 188

Trace Data Select Dialog Box ... 192

Trace Dialog Box ... 196

Trace function ... 58

trace memory ... 58

Trace Move Dialog Box ... 194

Trace Option Dialog Box ... 102

Tracer control mode ... 61

Types of Messages ... 295

U

Unconditional trace ... 61

Uninstalling ... 24

Upload ... 40

Upload Dialog Box ... 118

V

view file ... 71

View File Load Dialog Box ... 219

View File Save Dialog Box ... 216

W

- Watch function ... 50
- Watch Window ... 141
- window list ... 81
- window reference ... 80