RENESAS

APPLICATION NOTE

M16C/63, 64A, 64C, 65, 65C, 6C, 5LD, 56D, 5L, 56, 5M, and 57 Groups Serial Interface: Using High Speed Communication when Performing Clock Synchronous Slave Reception with DMAC

R01AN0732EJ0100 Rev. 1.00 Nov. 30, 2011

Abstract

This document describes the method of slave reception in clock synchronous serial I/O mode using high speed communication with DMAC for the M16C Group.

When the clock synchronous serial I/O mode is in slave reception mode, and continuous reception mode is used, data may not be received correctly when the transmit/receive clock becomes high speed. When communicating in high speed, data can be received correctly using DMAC instead of continuous receive mode.

Products

MCUs: M16C/63, 64A, 64C, 65, 65C, 6C, 5LD, 56D, 5L, 56, 5M, and 57 Groups

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.



Contents

1.	Specifications
1.1	Notes on Clock Synchronous Serial I/O Mode5
2.	Operation Confirmation Conditions6
3.	Software7
3.1	Operation Overview
3.2	Required Memory Size9
3.3	Constant9
3.4	Variables9
3.5	Functions10
3.6	Function Specifications10
3.7	Flowcharts11
3.7	· · · · · · · · · · · · · · · · · · ·
3.7	.2 Peripheral Function Initialization
4.	Sample Code 14
5.	Reference Documents



1. Specifications

In this application note, the clock synchronous serial I/O mode, and two channels of DMAC are used. Data is received continually 1 byte at a time, until all 256 bytes of data are received. Continuous receive mode is not used. Write dummy data to the UiTB register, and read the received data from the UiRB register using DMAC.

If continuous receive mode is used, when the transmit/receive clock becomes high speed, the read timing for the UiRB register may not adhere to the notes in section 1.1 Notes on Clock Synchronous Serial I/O Mode, thus data may not be received correctly (refer to Figure 1.1). In using DMAC for communication, even if the transmit/receive clock operates in high speed, data can be received correctly (refer to Figure 1.2).

Table 1.1 lists the Peripheral Functions and Their Applications. Figure 1.1 shows the Timing Diagram of Continuous Receive Mode, and Figure 1.2 shows Timing Diagram of Continuous Data Reception with DMAC.

Table 1.1	Peripheral Functions and Their Applications
-----------	---

Peripheral Function	Application
Serial interface (UART0)	Receiving data
DMAC (DMA0)	Writing dummy data
DMAC (DMA1)	Reading received data





Figure 1.1 Timing Diagram of Continuous Receive Mode





Figure 1.2 Timing Diagram of Continuous Data Reception with DMAC

1.1 Notes on Clock Synchronous Serial I/O Mode

This section describes notes on clock synchronous serial I/O mode for the M16C/63, 64A, 64C, 65, 65C, 6C, 5LD, 56D, 5L, 56, 5M, and 57 Groups.

When starting transmission/reception while an external clock is selected, and the TXEPT bit in the UiC0 register is 1 (no data present in transmit register), the reception start condition must be met when the level of an external clock is the following:

- When the CKPOL bit in the UiC0 register is 0 (transmit data is output at the falling edge of transmit/receive clock and receive data is input at the rising edge), an external clock is high.
- When the CKPOL bit in the UiC0 register is 1 (transmit data is output at the rising edge of transmit/receive clock and receive data is input at the falling edge), an external clock is low.



2. Operation Confirmation Conditions

The sample code accompanying this application note has been run and confirmed under the conditions below.

Item	Contents
MCU used	M16C/65 Group
Operating frequencies	 XIN Clock: 8 MHz CPU clock: 32 MHz (PLL clock: divided by 2, multiplied by 8)
Operating voltage	5 V (available between 3.3 to 5 V)
Integrated development environment	Renesas Electronics Corporation High-performance Embedded Workshop Version 4.09
	Renesas Electronics Corporation M16C Series/R8C Family C Compiler V.5.45 Release 01
C compiler	Compile options -c -finfo -dir "\$(CONFIGDIR)" (The default setting is used in the integrated development environment.)
Operating mode	Single-chip mode
Sample code version	Version 1.00

 Table 2.1
 Operation Confirmation Conditions



3. Software

The sample code uses a combination of UART0 clock synchronous I/O mode, DMAC0, and DMAC1 to receive a total of 256 bytes of data.

Table 3.1 to Table 3.3 list the settings for UART0, DMAC0, and DMAC1.

Table 3.1UART0 Setting Conditions

Item	Setting
Operation mode	Clock synchronous serial I/O mode
Transmit/receive clock	External clock
CTS/RTS function	Disabled
CLK polarity selection	Transmit data is output at the falling edge of the transmit/receive clock and receive data is input at the rising edge.
Bit order	LSB first
Transmit interrupt source	Transmit buffer empty (TI = 1)
Continuous receive mode	Disabled

Table 3.2 DMAC0 Setting Conditions

Item	Setting
Transfer unit	8 bits
Transfer mode	Single transfer
Transfer source address (RAM address) direction	Fixed
Transfer destination address (the address of U0TB register) direction	Fixed
DMA request source	UART0 transmission
Number of transfers	255

Table 3.3DMAC1 Setting Conditions

Item	Setting
Transfer unit	8 bits
Transfer mode	Single transfer
Transfer source address (the address of the U0RB register) direction	Fixed
Transfer destination address (RAM address) direction	Forward
DMA request source	UART0 reception
Number of transfers	256



3.1 Operation Overview

(1) Setting the reception start condition

Set the RE bit in the U0C1 register to 1 (reception enabled), and the TE bit to 1 (transmission enabled). Verify the CLK0 pin is high by a program, then write dummy data to the U0TB register.(2) Starting DMA0 transfer

When the data in the U0TB register is transferred to the transmit register, the TI bit in the U0C1 register becomes 1 (no data present in U0TB register), and the TXEPT bit in the U0C0 register becomes 0 (data present in transmit register). Then the DMA0 transfer is started by a UART0 transmit interrupt request, and dummy data is transferred to the U0TB register from the RAM.

- (3) Setting the reception start condition during transmitting (when TXEPT = 0) When dummy data is written to the U0TB register by the DMA0 transfer, the TI bit becomes 0 (data present in UiTB register). (1.1 Notes on Clock Synchronous Serial I/O Mode does not apply to this case as the TXEPT bit is 0.)
- (4) Starting DMA1 transfer When the reception is completed, the RI bit in the U0C1 register becomes 1 (data present in U0RB register). Then the DMA1 transfer is started by the UART0 receive interrupt request, and the received data is transferred from the U0RB register to the RAM. Repeat steps (2) to (4) until a total of 256 bytes of data is received.
- (5) When 256-byte data reception is completed When the total of 256 bytes of data is received, the receive operation is not performed for the subsequent data.

Figure 3.1 shows the Timing Diagram.





3.2 Required Memory Size

Table 3.4 lists the Required Memory Size.

Table 3.4 Required Memory Size

Memory Used	Size	Remarks
ROM	229 bytes	In the r01an0732_src module
RAM	257 bytes	In the r01an0732_src module
Maximum user stack usage	14 bytes	
Maximum interrupt stack usage	0 bytes	

The required memory size varies depending on the C compiler version and compile options.

3.3 Constant

Table 3.5 lists the Constant Used in the Sample Code.

Table 3.5Constant Used in the Sample Code

Constant Name	Setting Value	Contents
DUMMY_DATA	FFh	Dummy data

3.4 Variables

Table 3.6 lists the Global Variables.

Table 3.6 Global Variables

Туре	Variable Name	Contents	Function Used
unsigned char	trn_data	Transmitted data	peripheral_init
unsigned char	rcv_data[256]	For received data storage	main, peripheral_init



3.5 Functions

Table 3.7 lists the Functions.

Table 3.7 Functions

Function Name	Outline
mcu_init	CPU initialization
peripheral_init	Peripheral function initialization

3.6 Function Specifications

The following tables list the sample code function specifications.

mcu_init		
Outline	CPU initialization	
Header	None	
Declaration	void mcu_init(void)	
Description	Set the PLL clock divided by 2, and multiplied by 8 as the CPU clock.	
Argument	None	
Returned value	None	
Remark		

peripheral_init	eripheral_init		
Outline	Peripheral function initialization		
Header	None		
Declaration	ation void peripheral_init(void)		
Description	Initialize UART0, DMAC0, and DMAC1.		
Argument	None		
Returned value	None		
Remark			



3.7 Flowcharts

3.7.1 Main Processing

Figure 3.2 shows the Main Processing.



Figure 3.2 Main Processing



3.7.2 Peripheral Function Initialization

Figure 3.3 and Figure 3.4 show Peripheral Function Initialization.



Figure 3.3 Peripheral Function Initialization (1/2)





Figure 3.4 Peripheral Function Initialization (2/2)

RENESAS

4. Sample Code

Sample code can be downloaded from the Renesas Electronics website.

5. Reference Documents

M16C/63 Group User's Manual: Hardware Rev. 2.00 M16C/64A Group User's Manual: Hardware Rev. 2.00 M16C/64C Group User's Manual: Hardware Rev. 1.00 M16C/65 Group User's Manual: Hardware Rev. 2.00 M16C/65C Group User's Manual: Hardware Rev. 1.00 M16C/6C Group User's Manual: Hardware Rev. 2.00 M16C/5L Group, M16C/56 Group User's Manual: Hardware Rev. 1.10 M16C/5LD Group, M16C/56D Group User's Manual: Hardware Rev. 1.10 M16C/5M Group, M16C/57 Group User's Manual: Hardware Rev. 1.10 The latest versions can be downloaded from the Renesas Electronics website.

Technical Update/Technical News The latest information can be downloaded from the Renesas Electronics website.

C Compiler Manual M16C Series/R8C Series C Compiler Package V.5.45 C Compiler User's Manual Rev. 2.00 The latest version can be downloaded from the Renesas Electronics website.

Website and Support

Renesas Electronics website http://www.renesas.com/

Inquiries http://www.renesas.com/inquiry



	M16C/63, 64A, 64C, 65, 65C, 6C, 5LD, 56D, 5L, 56, 5M, and 57 Groups
Revision History	Serial Interface: Using High Speed Communication when Performing
	Clock Synchronous Slave Reception with DMAC

Γ	Pov	Rev. Date	Description		
	IXEV.		Page	Summary	
	1.00	Nov. 30, 2011	_	First edition issued	

All trademarks and registered trademarks are the property of their respective owners.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this manual, refer to the relevant sections of the manual. If the descriptions under General Precautions in the Handling of MPU/MCU Products and in the body of the manual differ from each other, the description in the body of the manual takes precedence.

1. Handling of Unused Pins

Handle unused pins in accord with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.
- 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.
 - In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.
- 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.
- 5. Differences between Products

Before changing from one product to another, i.e. to one with a different part number, confirm that the change will not lead to problems.

— The characteristics of MPU/MCU in the same group but having different part numbers may differ because of the differences in internal memory capacity and layout pattern. When changing to products of different part numbers, implement a system-evaluation test for each of the products.

Notice

- All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or othere
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which is not intended without the prior written consent of Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended wither you may damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The recommended here use the recommended here way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - *Specific*: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by vou.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Refer to "http://www.renesas.com/" for the latest and detailed information

Renesas Electronics Corporation

http://www.renesas.com

 Renesas Electronics America Inc.

 2880 Scott Boulevard Santa Ciara, CA 95050-2554, U.S.A.

 Tel: +1-408-588-6000, Fax: +1-408-588-6130

 Renesas Electronics Canada Limited

 1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada

 Tel: +1-905-989-5441, Fax: +1-905-989-5220

 Renesas Electronics Europe Limited

 Dukes Meadow, Millozard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

 Tel: +44-1028-585-100, Fax: +44+1628-585-900

 Renesas Electronics Europe GmbH

 Arcadiastrasse 10, 40472 Disseldorf, Germany

 Tel: +49-211-65030, Fax: +44-116503-1327

 Renesas Electronics (Shanghal) Co., Ltd.

 7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China

 Tel: +86-10-8235-1155, Fax: +862-10887-7690

 Renesas Electronics (Shanghal) Co., Ltd.

 Unit 1001-1613, 16/F, Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

 Tel: +862-869-9318, Fax: +862-2085-90229044

 Renesas Electronics Singapore Pla. Ltd.

 1 harbourfront Avenue, 406-10, kappel Bay Tower, Singapore 098632

 Tel: +862-28175-9600, Fax: +868-29810

 Renesas Electronics Singapore Pla. Ltd.

 1 harbourfront Avenue, 406-10, kappel Bay Tower, Singapore 098632

 Tel: +862-28175-9600, Fax: +868 2-9175-9610

 Rene