

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

USER'S MANUAL

IE-70732-MC
IN-CIRCUIT EMULATOR

TARGET DEVICES

V805™

V810™

The IE-70732-MC conforms to the standards of VCCI, which restricts radio interference in commercial and industrial areas.

Since using the IE-70732-MC in residential districts or their neighboring districts may cause radio or TV interference, follow this manual.

V805 and V810 are trademarks of NEC Corporation.

Ethernet is a trademark of Xerox Corporation.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Green Hills Software and MULTI are trademarks of Green Hills Software, Inc.

The information in this document is subject to change without notice.

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Corporation. NEC Corporation assumes no responsibility for any errors which may appear in this document.

NEC Corporation does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from use of a device described herein or any other liability arising from use of such device. No license, either express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Corporation or of others.

Preface

Users:

This manual is aimed at those users who are responsible for the design and development of application systems based on the μ PD70731 (also referred to as the V805) and μ PD70732 (also referred to as the V810).

Purpose:

The IE-70732-MC is an in-circuit emulator consisting of an emulation module (IE-70732-MC-EM1) and communication module (IE-70000-MC-SV2). The IE-70732-MC facilitates program debugging when designing a V805 or V810 application system. The purpose of this manual is to help users become familiar with the basic specifications of the IE-70732-MC as well as how it should be used.

Organization:

This manual includes the following chapters:

- Overview
- Using the In-Circuit Emulator
- Initialization of Network Information
- Connecting the In-Circuit Emulator
- Notes on Hardware Design

Guidance:

Readers of this manual are assumed to have a general knowledge of electronics, logic circuits, and microcomputers.

To become familiar with the basic specifications and the use of the in-circuit emulator:

→ Read this manual in the order of the table of contents.

To become familiar with points to be kept in mind when designing hardware:

→ Read **Chapter 5**.

To recognize the differences from the IE-70732-BX:

→ Read **Appendix B**.

For details of how to operate the IE-70732-MC and use the command functions:

→ Refer to the manual relating to the source debugger, available separately.

Legend:

Data weight	:	High-order digits on the left side Low-order digits on the right side
Active low	:	\overline{xxx} (Pins and signal names are overscored.)
Memory map address	:	High-order address on the upper side Low-order address on the lower side
Note	:	Explanation of the indicated part of text
Caution	:	Information to which the user should afford special attention
Remarks	:	Supplementary information
Numeric value	:	Binary : xxxx or xxxxB Decimal : xxxx Hexadecimal : xxxxH

Units representing powers of 2:

K (kilo)	:	$2^{10} = 1024$
M (mega)	:	$2^{20} = 1024^2$
G (giga)	:	$2^{30} = 1024^3$

Contents

Chapter 1 Overview	1-1
1.1 Function Overview	1-1
1.2 Features	1-2
1.3 Specifications	1-3
1.3.1 Emulation Module	1-3
1.3.2 Communication Module and Power Supply Unit	1-4
1.4 Block Diagram of Emulation Module	1-5
1.5 System Configuration	1-6
1.6 Options and Related Products	1-7
1.7 Development Procedure	1-8
Chapter 2 Using the In-Circuit Emulator	2-1
2.1 Notes on Use	2-1
2.2 Using the In-Circuit Emulator	2-1
Chapter 3 Initialization of Network Information	3-1
3.1 Initialization	3-1
3.2 Modifying the Set Network Information	3-4
3.3 Initialization Menu	3-4
3.3.1 Setting Initialization Menu Items	3-5
Chapter 4 Connecting the In-Circuit Emulator	4-1
4.1 Packing	4-1
4.2 Component Names and Functions	4-2
4.3 Connecting the IE-70732-MC	4-4
4.4 Connecting to the Network	4-7

- Chapter 5 Notes on Hardware Design5-1**
 - 5.1 Restrictions5-1**
 - 5.1.1 $\overline{\text{READY}}$ Signal 5-1
 - 5.1.2 $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ Signals 5-1
 - 5.1.3 A31-A1, ST1, ST0, $\overline{\text{MRQ}}$, R/W, and $\overline{\text{BE3}}-\overline{\text{BE0}}$ Signals 5-1
 - 5.1.4 $\overline{\text{NMI}}$ Signal 5-2
 - 5.1.5 INT Signal 5-2
 - 5.1.6 $\overline{\text{RESET}}$ Signal 5-2
 - 5.2 Recommended External Circuit.....5-2**
 - 5.3 Emulation Memory Function5-3**
 - 5.4 Emulator I/O Signals5-3**
- Appendix A CPU Pin StatesA-1**
- Appendix B Differences Between IE-70732-MC
and IE-70732-BXB-1**

List of Figures

(1/1)

<i>Figure 1-1.</i>	<i>Block Diagram of Emulation Module</i>	<i>1-5</i>
<i>Figure 1-2.</i>	<i>System Configuration.....</i>	<i>1-6</i>
<i>Figure 1-3.</i>	<i>Development Procedure and Scope of Work Applicable to IE-70732-MC</i>	<i>1-8</i>
<i>Figure 2-1.</i>	<i>Using the IE-70732-MC</i>	<i>2-2</i>
<i>Figure 3-1.</i>	<i>Connecting the Communication Module to the Terminal</i>	<i>3-1</i>
<i>Figure 3-2.</i>	<i>RS-232C Cable Configuration.....</i>	<i>3-2</i>
<i>Figure 3-3.</i>	<i>Connecting the Communication Module to the Power Supply Unit</i>	<i>3-3</i>
<i>Figure 3-4.</i>	<i>Example of Connection for Network Initialization</i>	<i>3-3</i>
<i>Figure 4-1.</i>	<i>Emulation Module Components</i>	<i>4-2</i>
<i>Figure 4-2.</i>	<i>Communication Module Components.....</i>	<i>4-3</i>
<i>Figure 4-3.</i>	<i>Connecting the Emulation Module to the Communication Module</i>	<i>4-4</i>
<i>Figure 4-4.</i>	<i>Connecting the Emulation Module to the Target System</i>	<i>4-5</i>
<i>Figure 4-5.</i>	<i>Pin Allocation of 10BASE-T Connector</i>	<i>4-7</i>
<i>Figure 4-6.</i>	<i>Connecting the Communication Module to the 10BASE-T Modular Cable.....</i>	<i>4-7</i>
<i>Figure 4-7.</i>	<i>Connecting the Communication Module to the Power Supply Unit</i>	<i>4-8</i>
<i>Figure 4-8.</i>	<i>Example of Connecting IE-70732-MC to Network</i>	<i>4-8</i>
<i>Figure 5-1.</i>	<i>Recommended External Circuit for Emulation Module.....</i>	<i>5-2</i>
<i>Figure 5-2.</i>	<i>Target System Clock and Clock Delays in Emulator</i>	<i>5-3</i>
<i>Figure 5-3.</i>	<i>Delays in Output to Target System When Only Target Memory Is Used</i>	<i>5-4</i>
<i>Figure 5-4.</i>	<i>Delays in Output to Target System When Emulation Memory Is Used (in Write Cycles).....</i>	<i>5-6</i>

List of Tables

(1/1)

<i>Table 1-1.</i>	<i>Specifications of Emulation Module (IE-70732-MC-EM1)</i>	<i>1-3</i>
<i>Table 1-2.</i>	<i>Specifications of Communication Module (IE-70000-MC-SV2)</i>	<i>1-4</i>
<i>Table 1-3.</i>	<i>Specifications of Power Supply Unit (IE-70000-MC-PS)</i>	<i>1-5</i>
<i>Table 1-4.</i>	<i>Hardware Configuration</i>	<i>1-6</i>
<i>Table 1-5.</i>	<i>Conversion Adapters</i>	<i>1-7</i>
<i>Table 3-1.</i>	<i>Terminal Initialization</i>	<i>3-2</i>
<i>Table 5-1.</i>	<i>Target System Clock and Clock Delay Values in Emulator</i>	<i>5-4</i>
<i>Table 5-2.</i>	<i>Delays in Output to Target System When Only Target Memory Is Used</i>	<i>5-5</i>
<i>Table 5-3.</i>	<i>Delays in Output to Target System When Emulation Memory Is Used (in Write Cycles)</i>	<i>5-7</i>
<i>Table A-1.</i>	<i>CPU Pins for Emulation</i>	<i>A-1</i>
<i>Table A-2.</i>	<i>CPU Pins for Break</i>	<i>A-3</i>
<i>Table B-1.</i>	<i>Major Specification Differences</i>	<i>B-2</i>
<i>Table B-2.</i>	<i>Debugging Function Comparison</i>	<i>B-3</i>

Chapter 1

Overview

This chapter outlines the functions and specifications of the IE-70732-MC.

1.1 Function Overview

The IE-70732-MC is a micro in-circuit emulator that enables the efficient debugging of hardware and software in the development of systems using the V805 and V810. The IE-70732-MC is smaller and less expensive than conventional box-type in-circuit emulators.

The IE-70732-MC is an in-circuit emulator consisting of an emulation module (IE-70732-MC-EM1) and communication module (IE-70000-MC-SV2). The emulation module is provided in a package that supports the minimum functions required of a box-type in-circuit emulator (IE-70732-BX) for the V805 and V810. The communication module is responsible for communication between the IE-70732-MC and host machine(**Note 1**) via a network (10BASE-T).

For actual debugging, a source debugger(**Note 2**) is required. For details of its use, refer to the manual supplied with the source debugger being used. This user's manual describes the basic specifications of the IE-70732-MC, the connection and use of the IE-70732-MC, and notes on hardware design.

(Note 1) For information about setting up the host machine, refer to the manual for the debugger being used.

(Note 2) The following source debuggers are offered separately:

SD732 : Manufactured by NEC

MULTI™ : Manufactured by Green Hills Software™, Inc., U.S.A. (Agent in Japan: Advanced Data Controls)

1.2 Features

- With the V805, real-time emulation at up to 20 MHz is possible. With the V810, real-time emulation at up to 25 MHz is possible.
- Very small and light hardware configuration (emulation module)
 - Functions and size closely approximate to the V810 (176-pin PGA)
 - Pin allocation fully compatible with the V810 (176-pin PGA)
- 128K-byte emulation memory
- Conformity to IEEE802.3 (10BASE-T)
- TCP/IP installed as the communication protocol
- LEDs indicating CPU status display (provided on the communication module)
- Control using the source debugger
 - A program being executed can be suspended at an arbitrary address.
 - A program can be started from an arbitrary address.
 - While a program is suspended, the contents of CPU registers can be referenced and updated.
 - While a program is suspended, the contents of memory and I/O data can be referenced and updated.
 - Event break (for up to 4 events) is enabled.
 - Step-by-step execution is enabled.
- Lower-cost

1.3 Specifications

1.3.1 Emulation Module

Table 1-1 lists the specifications of the emulation module.

For details of the break function and data manipulation function, refer to the manual for the source debugger being used. Note that the IE-70732-MC does not support pin mask or trace functions.

Table 1-1. Specifications of Emulation Module (IE-70732-MC-EM1)

Item	Description
Target CPU	<ul style="list-style-type: none"> μPD70731 (V805) • 100-pin QFP(Note) <ul style="list-style-type: none"> μPD70732 (V810) • 176-pin PGA • 120-pin QFP(Note)
Operating clock (supplied by the target)	2.5-20 MHz 2.5-25 MHz
Emulation memory	64K bytes x 2 banks (1 wait, 16-bit access)
Target communication module	IE-70000-MC-SV2 (10BASE-T)
Break function	Event break Number of events : 4 maximum Event condition : Address/instruction fetch, memory read/write access, I/O read/write access Software break Forced break
Data manipulation function	Memory, I/O, and register manipulation (modification)
Operating supply voltage, current	5 V±5%, 200 mA (typical, at 25 MHz)
Operating environment	<ul style="list-style-type: none"> • Temperature : +10°C to +40°C • Humidity : 10% to 80% RH (no condensation)
Storage environment	<ul style="list-style-type: none"> • Temperature : -15°C to +45°C • Humidity : 10% to 80% RH (no condensation)
Outside dimensions (Unit: mm)	49.1 (D) x 38.5 (W) x 8.5 (H)
Weight	30 g
(Note)	The pin allocation of the emulation module is fully compatible with that of the 176-pin PGA of the V810. So, when using a CPU other than the 176-pin PGA V810, use a conversion adapter to enable connection to the target system. (See Section 1.6.)

1.3.2 Communication Module and Power Supply Unit

The communication module is provided with a dedicated power supply unit. Table 1-2 lists the specifications of the communication module. Table 1-3 lists the specifications of the power supply unit.

Table 1-2. Specifications of Communication Module (IE-70000-MC-SV2)


Item	Description
Target emulation module	General emulation modules for micro in-circuit emulators
External interface	<ul style="list-style-type: none"> • Ethernet™: Conforms to IEEE802.3 (10BASE-T). • RS-232C: 8-pin connector
Reset function	Power-on reset, reset button
Status display	Status is displayed by LEDs. <ul style="list-style-type: none"> • IF POWER : Lit while power is supplied to the communication module. • TARGET POWER: Lit while power is supplied to the target system. • RUN : Lit while a user program is being executed. • ERROR : Lit upon the occurrence of a communication error.
Software	<ul style="list-style-type: none"> • Communication protocol control software: TCP/IP (with routing and subnet capabilities) • Control software for the IE-70732-MC: Downloaded through the external interface
Operating supply voltage, current	5 V±10%, 1.5 A (typical)
Operating environment	<ul style="list-style-type: none"> • Temperature : +10°C to +40°C • Humidity : 10% to 80% RH (no condensation)
Storage environment	<ul style="list-style-type: none"> • Temperature : -15°C to +45°C • Humidity : 10% to 80% RH (no condensation)
Outside dimensions (Unit: mm)	67 (D) x 116 (W) x 27.5 (H)
Weight	150 g

Table 1-3. Specifications of Power Supply Unit (IE-70000-MC-PS)

Item	Description
Power supply	85 – 132 VAC
Supply voltage	5 VDC \pm 10%
Supply current	2 A (Max.)
Operating environment	<ul style="list-style-type: none"> • Temperature: +10°C to +40°C • Humidity: 10% to 80% RH (no condensation)
Storage environment	<ul style="list-style-type: none"> • Temperature: -15°C to +45°C • Humidity: 10% to 80% RH (no condensation)
Outside dimensions (Unit: mm)	105 (D) x 70 (W) x 20 (H)
Weight	Main unit: 190 g, Cable: 145 g

1.4 Block Diagram of Emulation Module

Figure 1-1 is a block diagram of the emulation module (IE-70732-MC-EM1).

Figure 1-1. Block Diagram of Emulation Module

(Note) Work area for the IE-70732-MC (not accessible by the user)

1.5 System Configuration

The IE-70732-MC consists of an emulation module (IE-70732-MC-EM1) and communication module (IE-70000-MC-SV2). The communication module is provided together with a dedicated power supply unit (IE-70000-MC-PS).

Figure 1-2. System Configuration




Table 1-4. Hardware Configuration

Type of equipment	Product name	Description
Emulation module	IE-70732-MC-EM1	<ul style="list-style-type: none"> The package provides functions that closely approximate to those of the V810. The pin allocation is fully compatible with that of the V810 (176-pin PGA).
Communication module	IE-70000-MC-SV2	This module is used to make a connection to the host machine via 10BASE-T.
Power supply unit	IE-70000-MC-PS	Provided with the communication module

1.6 Options and Related Products

When the V805 (100-pin QFP) or V810 (120-pin QFP) is being used as a target CPU, a conversion adapter(**Note**), indicated in Table 1-5, is required.

See **Chapter 4** for an explanation of using the conversion adapter to connect the IE-70732-MC to a target system.

(Note) Use the LVC or ADP. These products are provided with TQPACK and TQSOCKET, respectively.
 LVC: Package conversion, 3 V capability
 ADP: Package conversion only

Table 1-5. Conversion Adapters

Target CPU (package)	Product name	Accessory
V805 (100-pin QFP)	LVC-PG177-TQF100-V805	TQPACK100SD
	ADP-PG177-TQF100-V805	TQSOCKET100SDW
V810 (120-pin QFP)	LVC-PG177-QF120-V810	TQPACK120SA
	ADP-PG177-QF120-V810	TQSOCKET120SAW

Manufacturers:

- Conversion adapters (LVC, ADP)

MIDAS LAB

TEL: 03-3357-2589

FAX: 03-3357-8029

- TQPACK, TQSOCKET


Daimaru Kogyo, Limited

TEL: 03-3820-7112, 06-244-6672

1.7 Development Procedure

Figure 1-3 shows the development procedure and scope of work applicable to IE-70732-MC.

Figure 1-3. Development Procedure and Scope of Work Applicable to IE-70732-MC



Chapter 2

Using the In-Circuit Emulator

This chapter describes how to use the IE-70732-MC.

2.1 Notes on Use

- (1) When handling the emulation module, be careful not to subject it to an electrostatic discharge or mechanical shock.
- (2) The emulation module must be connected to the communication module. Turn off the power before making the connection.
- (3) Always follow the specified power-on/off procedure. Otherwise, the IE-70732-MC and/or target system are likely to be damaged.

2.2 Using the In-Circuit Emulator

Perform the following steps, (1) through (6), in the order shown.

(1) Initialization of network information

Connect the communication module to the terminal. Then, set the network information. For details, see **Chapter 3**.

(2) Connection

Turn off the power to the communication module before attempting to make a connection. For details, see **Chapter 4**.

(3) Turning on the power

Perform steps <1> through <3> in the order shown.

- <1> Turn on the power to the host machine.
- <2> Turn on the power to the communication module.
- <3> Turn on the power to the target system.

(4) Activation of the source debugger

After power-on, execute the required commands from the host machine. For details of the commands, refer to the manual provided with the source debugger.

(5) Termination of the source debugger

Terminate the source debugger by executing the termination command. For details of this command, refer to the manual provided with the source debugger.

(6) Turning off the power

Perform steps <1> through <3> in the order shown.


<1> Turn off the power to the target system.

<2> Turn off the power to the communication module.

<3> Turn off the power to the host machine.

Figure 2-1 is a flowchart illustrating the use of the IE-70732-MC.

Figure 2-1. Using the IE-70732-MC



Chapter 3

Initialization of Network Information

The IE-70732-MC communicates with the host machine via a network (10BASE-T). The user must initialize the relevant network information, such as network addresses, by using the initialization menu displayed on the terminal (personal computer) before attempting to connect the host machine to the target system.

Caution **Before connecting the IE-70732-MC to a network, always initialize the network information.**

3.1 Initialization

Initialize the network information by following the procedure detailed below.

- (1) Connect the communication module to the terminal by using the RS-232C cable provided with the module. Figure 3-2 shows the RS-232C cable. Check that the terminal is initialized as specified in Table 3-1.

Figure 3-1. Connecting the Communication Module to the Terminal




Figure 3-2. RS-232C Cable Configuration





Table 3-1. Terminal Initialization

Item	Description
Interface	RS-232C
Baud rate	9600 bps
Data length	8 bits
Parity check	None
Stop bits	2 bits
X parameter: XON/XOFF	Not applicable
Local echo	Not used
Pressing of the return key	CR code is sent.
Reception of LF code	Line feed operation is performed.


- (2) As shown in Figure 3-3, connect the communication module to the power supply unit.

Figure 3-3. Connecting the Communication Module to the Power Supply Unit



- (3) As shown in Figure 3-4, turn on the power to the terminal once the connection has been made.

Figure 3-4. Example of Connection for Network Initialization



- (4) Turn on the power to the communication module. Then, the initialization menu appears. (For details, see Section 3.3.)
- (5) Set the initialization menu items as described in Section 3.3.1.
- (6) After checking the settings, turn off the power to the communication module.

Caution Be careful to turn off the power to the communication module at this step. Further, always disconnect the RS-232C cable from the communication module.

3.2 Modifying the Set Network Information

Once network information has been set, the user can modify that information from the terminal connected to the communication module, via the RS-232C cable. (The network information cannot be modified from the source debugger.)

When the source debugger is activated, initialized network information can be modified as follows:

- (1) Reconnect the communication module to the terminal, using the RS-232C cable.
- (2) Press the reset switch on the communication module. (The initialization menu appears on the terminal.)
- (3) Set the network information in the same way as when making the initial setting.

3.3 Initialization Menu

After connecting the communication module to the terminal, turn on the power to the power supply unit and terminal. Then, the menu screen shown below appears on the terminal.

```

--- SETUP NETWORK INFORMATION ---
1. LOCAL ETHERNET ADDRESS      XXXXXXXXXXXXXXXX
2. LOCAL IP ADDRESS            XXXXXXXXX
3. LOCAL HOST NAME             XXXXXXXXXXXXXXXXX
4. LOCAL PORT NO.              XXXX
5. REMOTE ETHERNET ADDRESS     XXXXXXXXXXXXXXXX
6. REMOTE IP ADDRESS          XXXXXXXXX
7. REMOTE HOST NAME           XXXXXXXXXXXXXXXXX
8. REMOTE PORT NO.            XXXX
9. ROUTER ADDRESS              XXXXXXXXX
10. SUBNET ADDRESS MASK        XXXXXXXXX
11. HUB LINK (ON=1/OFF=0)     0
99. EXIT

-----
FUNCTION NO.>>■

```

Enter a desired item number (from 2 to 11, or 99) on the bottom line of the menu screen. Then, the screen for setting the network information for the specified item appears.

Note that the user cannot modify the setting for LOCAL ETHERNET ADDRESS. This is because this item is specific to the board, hence cannot be selected by the user.

Data set using this menu is written to the EEPROM. Therefore, the data is not lost even if the power is turned off.

3.3.1 Setting Initialization Menu Items

The procedure for setting each initialization menu item is described in (1) through (11) below.

(1) Setting LOCAL IP ADDRESS

[Function]

This item sets the IP address of the communication module. An IP address is assigned to each node. Set the IP address assigned by the network administrator.

[Input format]

Enter an 8-digit hexadecimal number.

[Example of input]

<pre> : 99. EXIT ----- FUNCTION NO. >>2 ----- LOCAL IP ADDRESS >XXXXXXXX NEW LOCAL IP ADDRESS >12345678 ----- --- SETUP NETWORK INFORMATION --- 1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXXX : 2. LOCAL IP ADDRESS 12345678 : 99. EXIT ----- FUNCTION NO. >> </pre>	<p>Enter function number 2.</p> <p>The current IP address is displayed. Enter a new IP address.</p> <p>The menu is displayed.</p> <p>The new IP address is displayed.</p>
---	---

(2) Setting of LOCAL HOST NAME

[Function]

This item sets the host name (node name) of the communication module.

[Input format]

Enter an alphanumeric character string of no more than 16 characters.

[Example of input]

```

      :
    99. EXIT
-----
FUNCTION NO. >>3
LOCAL HOST NAME >XXXXXX
NEW LOCAL HOST NAME >LOCALHOSTNAME
--- SETUP NETWORK INFORMATION ---
    1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX
      :
    3. LOCAL HOST NAME LOCALHOSTNAME
      :
    99. EXIT
-----
FUNCTION NO. >>

```

Enter function number 3.

The current host name is displayed.

Enter a new host name.

The menu is displayed.

The new host name is displayed.

(3) Setting of LOCAL PORT NO.

[Function]

This item sets the port number of the communication module.

[Input format]

Enter a 4-digit hexadecimal number other than 0000. Usually, set 0401 (or 1025 in decimal) or a greater hexadecimal number.

[Example of input]

<pre> : 99. EXIT ----- FUNCTION NO. >>4 ----- LOCAL PORT NO. >XXXX NEW LOCAL PORT NO. >0401 ----- --- SETUP NETWORK INFORMATION --- 1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX : 4. LOCAL PORT NO. 0401 : 99. EXIT ----- FUNCTION NO. >> </pre>	<p>Enter function number 4.</p> <p>The current port number is displayed. Enter a new port number.</p> <p>The menu is displayed.</p> <p>The new port number is displayed.</p>
--	--

(4) Setting of REMOTE ETHERNET ADDRESS

[Function]

This item sets the Ethernet address of the host machine used to manipulate the IE-70732-MC.

[Input format]

Enter a 12-digit hexadecimal number. When an arbitrary host machine can be used, set FFFFFFFFFFFF. Usually, enter FFFFFFFFFFFF.

[Example of input]

```
      :  
99. EXIT  
-----  
FUNCTION NO. >>5  
  
REMOTE ETHERNET ADDRESS >XXXXXXXXXXXX  
NEW REMOTE ETHERNET ADDRESS >0123456789AB  
  
--- SETUP NETWORK INFORMATION -----  
      1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX  
      :  
      5. REMOTE ETHERNET ADDRESS 0123456789AB  
      :  
99. EXIT  
-----  
FUNCTION NO. >>■
```

Enter function number 5.

The current Ethernet address is displayed.
Enter a new Ethernet address.

The menu is displayed.

The new Ethernet address is displayed.

(5) Setting of REMOTE IP ADDRESS

[Function]

This item sets the IP address of the host machine.

[Input format]

Enter an 8-digit hexadecimal number. When an arbitrary host machine can be used, set 0. Usually, enter 0.

[Example of input]

:		
99. EXIT		

FUNCTION NO. >>6		Enter function number 6.
REMOTE IP ADDRESS	>XXXXXXXX	The current IP address is displayed.
NEW REMOTE IP ADDRESS	>12345678	Enter a new IP address.

SETUP NETWORK INFORMATION		The menu is displayed.
1. LOCAL ETHERNET ADDRESS	XXXXXXXXXXXX	
:		
13. REMOTE IP ADDRESS	12345678	The new IP address is displayed.
:		
99. EXIT		

FUNCTION NO. >>		

(6) Setting of REMOTE HOST NAME

[Function]

This item sets the host name (node name) of the host machine.

[Input format]

Enter an alphanumeric character string not longer than 16 characters. When an arbitrary host machine can be used, enter only. Usually, just enter .

[Example of input]

```

:
99. EXIT
-----
FUNCTION NO. >>7

REMOTE HOST NAME           >XXXXXXX
NEW REMOTE HOST NAME       >REMOTEHOSTNAME

--- SETUP NETWORK INFORMATION ---
  1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXXX
  :
  7. REMOTE HOST NAME       REMOTEHOSTNAME
  :
  99. EXIT
-----
FUNCTION NO. >>■
```

Enter function number 7.

The current host name is displayed.

Enter a new host name.

The menu is displayed.

The new host name is displayed.

(7) Setting of REMOTE PORT NO.

[Function]

This item sets the port number of the host machine.

[Input format]

Enter a 4-digit hexadecimal number. When an arbitrary host machine can be used, set 0. Usually, enter 0.

[Example of input]

```

      :
      99. EXIT
-----
FUNCTION NO. >>8
-----
REMOTE PORT NO.          >XXXX
NEW REMOTE PORT NO.     >0123
-----
--- SETUP NETWORK INFORMATION ---
      1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXXX
      :
      8. REMOTE PORT NO.          0123
      :
      99. EXIT
-----
FUNCTION NO. >>

```

Enter function number 8.

The current port number is displayed.

Enter a new port number.

The menu is displayed.

The new port number is displayed.

(8) Setting of ROUTER ADDRESS

[Function]

This item sets the IP address of a router. This item must be set to enable connection to the host machine via a router.

[Input format]

Enter an 8-digit hexadecimal number. When routing is not required, enter 0.

[Example of input]

```

      :
99. EXIT
-----
FUNCTION NO. >>9
ROUTER ADDRESS          >XXXXXXXX
NEW ROUTER ADDRESS      >12345678
--- SETUP NETWORK INFORMATION ---
  1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX
      :
  9. ROUTER ADDRESS      12345678
      :
99. EXIT
-----
FUNCTION NO. >>

```

Enter function number 9.

The current router address is displayed.

Enter a new router address.

The menu is displayed.

The new router address is displayed.

(9) Setting of SUBNET ADDRESS MASK

[Function]

This item sets the subnet address mask field.

[Input format]

Enter an 8-digit hexadecimal number, with the bit indicating the subnet address position set to 1. When subnet address mask setting is not required, enter 0.

[Example of input]

An example of using the higher 24 bits of the IP address for subnet recognition and the lower 8 bits for host recognition is shown below.

<pre> : 99. EXIT ----- FUNCTION NO. >>10 SUBNET ADDRESS MASK >XXXXXXXX NEW SUBNET ADDRESS MASK >FFFFFF00 --- SETUP NETWORK INFORMATION --- 1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX : 10. SUBNET ADDRESS MASK FFFFFFF00 : 99. EXIT ----- FUNCTION NO. >>■</pre>	<p>Enter function number 10.</p> <p>The current subnet address mask is displayed.</p> <p>Enter a new subnet address mask.</p> <p>The menu is displayed.</p> <p>The new subnet address mask is displayed.</p>
---	--

(10) Setting of HUB LINK

[Function]

This item sets the HUB LINK flag to ON or OFF. When this item is set to ON, the test function for checking whether the hub is linked (connected actively) to the communication module is enabled. If a check reveals that the hub is not linked correctly, the ERROR LED on the communication module is lit. If a check determines that the hub is linked correctly, no indication is provided. When this item is set to OFF, the test function is disabled.

[Input format]

Enter 1 to set this item to ON. Enter 0 to set this item to OFF. When a number other than 0 is entered, 1 is assumed to have been input.

[Example of input]

```

:
99. EXIT
-----
FUNCTION NO. >>11
HUB LINK FLG (ON=1/OFF=0) >0
NEW HUB LINK FLG (ON=1/OFF=0) >1
--- SETUP NETWORK INFORMATION ---
  1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXXX
  :
 11. HUB LINK (ON=1/OFF=0) 1
  :
 99. EXIT
-----
FUNCTION NO. >>

```

Enter function number 11.
The current hub link test function status is displayed.
Enter a new hub link test function status.
The menu is displayed.
The new hub link test function status is displayed.

(11) EXIT

[Function]

This item terminates the network information setting menu, and writes the set values to the EEPROM.

[Input format]

Enter S, Q, or C.

S : Terminates the menu after writing the set network information to the EEPROM.

Q : Terminates the menu without writing the set network information to the EEPROM.

C : Returns to the menu to enable the continuation of network information setting.

[Example of input]

```

:
99. EXIT
-----
FUNCTION NO. >>99
Save & quit / Quit / Continue >S
-- Please reset --

:
99. EXIT
-----
FUNCTION NO. >>99
Save & quit / Quit / Continue >Q

:
99. EXIT
-----
FUNCTION NO. >>99
Save & quit / Quit / Continue >C
--- SETUP NETWORK INFORMATION ---
1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX
:
99. EXIT
-----
FUNCTION NO. >>

```

Enter function number 99.

The menu is terminated after writing network information to the EEPROM. Press the reset switch to restart setting.

Enter function number 99.

The menu is terminated without writing network information to the EEPROM.

Enter function number 99.

Network information setting is continued.

The menu is displayed.

Chapter 4

Connecting the In-Circuit Emulator

This chapter describes how to connect the IE-70732-MC.

Caution Turn off the power before attempting to make a connection.

4.1 Packing

The emulation module and communication module are packed as described below.

(1) Emulation module (IE-70732-MC-EM1)

IE-70732-MC-EM1: 1

(2) Communication module (IE-70000-MC-SV2)


- Main IE-70000-MC-SV2 unit: 1
- IE-70000-MC-PS (power supply unit): 1
- RS-232C cable (for network information setting): 1
- Interface cable (for emulation module connection): 1
- Instruction manual: 1
- Packing list: 1
- Warranty certificate: 1

Remark The source debugger must be purchased separately.

4.2 Component Names and Functions

Figures 4-1 and 4-2 show the components of the emulation module and communication module, respectively.

Figure 4-1. Emulation Module Components




(1) Connector for connection to the communication module

The emulation module is connected to the communication module via the interface cable provided with the communication module.

(2) Connector for connection to a target system

A conversion adapter is required when the target CPU is other than a 176-pin PGA. (See Section 1.6 for details.)

Figure 4-2. Communication Module Components



(1) Connector for connection to the emulation module

The communication module is connected to the emulation module via the interface cable provided with the communication module.

(2) RS-232C connector

By connecting a terminal via the RS-232C cable provided with the communication module, network information such as the IP address can be set.

(3) 10BASE-T connector

This connector is used to connect a 10BASE-T modular cable.

(4) Reset switch

The reset switch is used to reset the communication module. To press this switch, use a sharp-pointed instrument such as the tip of a mechanical pencil.

(5) Power supply connector

This connector is used to connect the power supply unit provided with the communication module.

(6) Status display LEDs


- IF POWER : Lit while power is supplied to the communication module.
- TARGET POWER : Lit while power is supplied to the target system.
- RUN : Lit while a user program is being executed.
- ERROR : Lit upon the occurrence of a TCP/IP communication error.

4.3 Connecting the IE-70732-MC


Make all necessary connections according to Figure 4-3 and Figure 4-4.

The method of connecting the IE-70732-MC to a target system depends on the target CPU (Figure 4-4). When the target CPU is a 100-pin QFP (V805) or 120-pin QFP (V810), use a conversion adapter. (See Section 1.6 for details.)


Figure 4-3. Connecting the Emulation Module to the Communication Module




- Caution**
1. Turn off the power before attempting to make a connection.
 2. Once the interface cable has been connected to the connector of the emulation module, leave the cable connected as far as possible. If the interface cable is frequently disconnected, there is a danger of the pins being damaged.

Figure 4-4. Connecting the Emulation Module to the Target System (1/2)

Caution Before attempting to make a connection, check that the A1 pin of the emulation module is aligned with the A1 pin mark on the conversion adapter.

Figure 4-4. Connecting the Emulation Module to the Target System (2/2)

Caution Before attempting to make a connection, check that the A1 pin of the emulation module is aligned with the A1 pin mark on the conversion adapter.



Caution Before attempting to make a connection, check that the A1 pin of the emulation module is aligned with the A1 pin mark on the conversion adapter.

4.4 Connecting to the Network

Caution Before connecting the IE-70732-MC to a network, first initialize the network information.

Connect the IE-70732-MC to a network by means of the following procedure. Before attempting to make a connection, turn off the power to the communication module.

- (1) Connect the 10BASE-T modular cable to the 10BASE-T connector on the communication module. (See **Figure 4-5** and **Figure 4-6**.)

Figure 4-5. Pin Allocation of 10BASE-T Connector






Figure 4-6. Connecting the Communication Module to the 10BASE-T Modular Cable




- (2) Connect the communication module to a hub via the 10BASE-T modular cable.
- (3) Connect the communication module to the power supply unit.

Figure 4-7. Connecting the Communication Module to the Power Supply Unit



- (4) Figure 4-8 shows an example system configuration where the IE-70732-MC is connected to a network.

Figure 4-8. Example of Connecting IE-70732-MC to Network



Chapter 5

Notes on Hardware Design

This chapter provides notes on the hardware design required for emulation using the IE-70732-MC.

5.1 Restrictions

The IE-70732-MC provides emulator functions, so that the functions of the following CPU pins are subject to some restrictions:

$\overline{\text{READY}}$, $\overline{\text{BCYST}}$, $\overline{\text{DA}}$, A31-A1, ST1, ST0, $\overline{\text{MRQ}}$, $\overline{\text{R/W}}$, $\overline{\text{BE3-BE0}}$, $\overline{\text{NMI}}$, INT, $\overline{\text{RESET}}$

Other pins function in almost the same way as the actual device.

5.1.1 $\overline{\text{READY}}$ Signal

If the not-ready state is set in the emulation state, the host can forcibly release the not-ready state. The not-ready state is that state which is established when a $\overline{\text{READY}}$ signal is not applied for 256 clock cycles.

5.1.2 $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ Signals

With the IE-70732-MC, whether access is being performed in the break state or in the emulation state is reported to the target system with the $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ signals only. Circuits such as a data bus protection circuit and circuit for masking access control signals including $\overline{\text{R/W}}$ signals are not provided.

Therefore, add $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ signal conditions to the generation of target system data bus control signals.

When the emulation memory function becomes active, the $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ signals are output one clock cycle later to determine access to the emulation memory area.

5.1.3 A31-A1, ST1, ST0, $\overline{\text{MRQ}}$, $\overline{\text{R/W}}$, and $\overline{\text{BE3-BE0}}$ Signals

These signals are set high by the internal pull-up resistors (about 5 ohms) when the IE-70732-MC receives the $\overline{\text{HLDRQ}}$ signal from the target system in the break state.

5.1.4 $\overline{\text{NMI}}$ Signal

An NMI interrupt generated when the IE-70732-MC is in the break state is held; the interrupt is accepted after the state changes to the emulation state.

If an event break or forced break occurs during NMI handling, NMI handling is stopped, and the state changes to the break state.

5.1.5 INT Signal

An INT interrupt, generated when the IE-70732-MC is in the break state, is ignored.

If an event break or forced break occurs during INT handling, INT handling is stopped, and the state changes to the break state.


5.1.6 $\overline{\text{RESET}}$ Signal

When the IE-70732-MC is in the break state, the $\overline{\text{RESET}}$ signal from the target system is not accepted. The $\overline{\text{RESET}}$ signal can be generated forcibly under the control of the host.

5.2 Recommended External Circuit

The data bus of the emulation module malfunctions when driven from the user system in the break state. Therefore, control the data bus by using a circuit such as that shown below.

Figure 5-1. Recommended External Circuit for Emulation Module



5.3 Emulation Memory Function

The emulation memory consists of 128K-bytes, and can be allocated in 64K-byte steps in a 4G-byte space. Note, however, that access to the emulation memory is a one-wait operation based on dynamic bus sizing. In this case, the $\overline{\text{BCYST}}$ and $\overline{\text{DA}}$ signals are not activated, but the other signals perform the same operations as in the case of ordinary dynamic bus sizing. (The $\overline{\text{SZRQ}}$ signal is automatically activated in the emulation module.)

The emulation memory has an access port from the CPU only, so that the emulation memory cannot be accessed from a separate bus master on the target system.

A source debugger is used for emulation memory setting.

5.4 Emulator I/O Signals

- (1) Figure 5-2 and Table 5-1 indicate the target system clock and clock delays in the emulator.

Figure 5-2. Target System Clock and Clock Delays in Emulator




Table 5-1. Target System Clock and Clock Delay Values in Emulator

($T_A = 25^\circ\text{C}$, $V_{DD} = 5\text{ V}$)

Abbreviation	Parameter	$f = 25\text{ MHz}$
		TYP. (ns)
t_{CYK}	Clock frequency	40
t_{DKH}	Rising edge delay	8
t_{DKL}	Falling edge delay	8

(2) Figure 5-3 and Table 5-2 indicate delays (in write cycles) in output to the target system when only the target memory is used.

Figure 5-3. Delays in Output to Target System When Only Target Memory Is Used




Table 5-2. Delays in Output to Target System When Only Target Memory Is Used

($T_A = 25^\circ\text{C}$, $V_{DD} = 5\text{ V}$)

Abbreviation	Parameter	$f = 25\text{ MHz}$ ($t_{\text{CYK}} = 40\text{ ns}$)	
			TYP. (ns)
t_{DKA}	Output active delay	(A1-A31)	11
t_{HKA}	Output inactive delay	(A1-A31)	11
t_{DKB}	Output active delay	($\overline{\text{BE0}}$ -BE3)	14
t_{HKB}	Output inactive delay	(BE0- $\overline{\text{BE3}}$)	13
t_{DKS}	Output active delay	(ST0, ST1)	11
t_{HKS}	Output inactive delay	(ST0, ST1)	10
t_{DKDT}	Output active delay	(D0-D31)	14
t_{HKDT}	Output inactive delay	(D0-D31)	13
t_{DKR}	Output active delay	($\overline{\text{R}}$ / $\overline{\text{W}}$)	12
t_{HKR}	Output inactive delay	($\overline{\text{R}}$ / $\overline{\text{W}}$)	10
t_{DKBC}	Output active delay	($\overline{\text{BCYST}}$)	22
t_{HKBC}	Output inactive delay	(BCYST)	17
t_{DKDA}	Output active delay	($\overline{\text{DA}}$)	17
t_{HKDA}	Output inactive delay	(DA)	17

- (3) Figure 5-4 and Table 5-3 indicate delays (in write cycles) in output to the target system when the emulation memory is used.

Figure 5-4. Delays in Output to Target System When Emulation Memory Is Used (in Write Cycles)




Table 5-3. Delays in Output to Target System When Emulation Memory Is Used (in Write Cycles)

($T_A = 25^\circ\text{C}$, $V_{DD} = 5\text{ V}$)

Abbreviation	Parameter	f = 25 MHz ($t_{CYK} = 40\text{ ns}$)	
			TYP. (ns)
t_{DKA}	Output active delay	(A1-A31)	11
t_{HKA}	Output inactive delay	(A1-A31)	11
t_{DKB}	Output active delay	($\overline{BE0}$ - $\overline{BE3}$)	14
t_{HKB}	Output inactive delay	($\overline{BE0}$ - $\overline{BE3}$)	13
t_{DKS}	Output active delay	(ST0, ST1)	11
t_{HKS}	Output inactive delay	(ST0, ST1)	10
t_{DKDT}	Output active delay	(D0-D31)	14
t_{HKDT}	Output inactive delay	(D0-D31)	13
t_{DKR}	Output active delay	($\overline{R/\overline{W}}$)	12
t_{HKR}	Output inactive delay	($\overline{R/\overline{W}}$)	10
t_{DKBC}	Output active delay	(\overline{BCYST})	22
t_{HKBC}	Output inactive delay	(\overline{BCYST})	17
t_{DKDA}	Output active delay	(\overline{DA})	17
t_{HKDA}	Output inactive delay	(\overline{DA})	17

Appendix A

CPU Pin States

Table A-1. CPU Pins for Emulation

Pin name	Operating state	Bus idle during reset (reset state)	Bus hold (including)	Hold acknowledge	Machine fault	Fetch		Memory access				I/O access	
						User memory	Emulation memory	User memory		Emulation memory		External I/O	
						R	R	R	W	R	W	R	W
A31-A2	H	Z1						O					
A1	C1	Z1						O					
D31-D0	Z	Z		O		I		O	I	O	I	O	
BE3-BE0	H	Z1						O					
ST1, ST0	H	Z1						O					
DA	H	Z			O	H		O	H			O	
MRQ	H	Z1						O					
R/W	H	Z1						O					
BCYST	H	Z			O	H		O	H			O	
READY				I			M	I	M			I	
HLDRO					I								
HLDK	H	L						O					
SZRQ					I								
SIZ16B					I								
BLOCK		L						O					
ICHEEN					I								
ADRSERR	H	C2						O					
INT			I		X			I					
INTV3-INTV0			I		X			I					
NMI			I		X			I					
CLK					I								
RESET					I								

Remarks I : Input O: Output H: High-level output
L : Low-level output Z: High impedance X: Invalid M: Mask
C1 : High level is output in 16-bit bus fixed mode. Low level is output in 32-bit bus mode.
C2 : High level is output during reset. In other cases, the state remains the same as the previous state.
Z1 : The pin becomes high-impedance, but high level is output with the internal pull-up resistor.

Table A-2. CPU Pins for Break

Operating state Pin name	Bus idle during reset	Bus hold	Hold acknowledge	Machine fault	Fetch	Memory access				I/O access	
					Monitor memory	User memory		Emulation memory		External I/O	
					R	R	W	R	W	R	W
A31-A2	—	Z1	—	—				O			
A1	—	Z1	—	—				O			
D31-D0	—	Z1	—	—	I		O	I	O	I	O
BE3-BE0	—	Z1	—	—				O			
ST1, ST0	—	Z1	—	—				O			
DA	—	Z	—	—	H		O	H		O	
MRQ	—	Z1	—	—				O			
R/W	—	Z1	—	—				O			
BCYST	—	Z	—	—	H		O	H		O	
READY	—	I	—	—	M		I	M		I	
HLDRQ	—	I	—	—				I			
HLDK	—	O	—	—				O			
SZRQ	—	I	—	—				I			
SIZ16B	—	I	—	—				I			
BLOCK	—	L	—	—				O			
ICHEEN	—	I	—	—				I			
ADRSERR	—	N	—	—				O			
INT	—	X	—	—				X			
INTV3-INTV0	—	X	—	—				X			
NMI	—	X	—	—				X			
CLK	—	I	—	—				I			
RESET											M

Remarks I : Input O: Output H: High-level output
L : Low-level output Z: High impedance X: Invalid M: Mask
Z1 : The pin becomes high-impedance, but high level is output with the internal pull-up resistor.
N : The state remains the same as the previous state.
— : State that cannot exist

Appendix B

Differences Between IE-70732-MC and IE-70732-BX

Table B-1 and Table B-2 indicate differences between the IE-70732-MC and IE-70732-BX.

Table B-1. Major Specification Differences

Item	Product name	IE-70732-MC	IE-70732-BX
Target CPU (package)(Note)		<ul style="list-style-type: none"> • V805 (100-pin QFP) • V810 (176-pin PGA, 120-pin QFP) 	
Operating clock		External: 2.5 MHz to 20 MHz (V805) 2.5 MHz to 25 MHz (V810)	External: 64 kHz to 25 MHz Internal: 25 MHz
Program execution		Execution, step-by-step execution, step-by-step function execution	
Break function		Event break: 4 events maximum	Event break: 16 events maximum
		Software break	
		Forced break	
Pin mask function		None	Set by commands. HLDRQ, RESET, NMI, INT, READY, SZRQ, SIZ16B, ICHEEN
Emulation memory		Standard: 128K bytes	Standard: 1M bytes
		Expansion: Not allowed	Expansion: Allowed up to 2M bytes
External logic probe		None	8-bit external input allowed
Supply voltage source		Power supply unit: IE-70000-MC-PS (85 VAC to 132 VAC)	Internal power supply (automatically switchable between 100 VAC and 220 VAC)
Outside dimensions: Depth x Width x Height (Unit: mm)		<ul style="list-style-type: none"> • IE-70732-MC-EM1: 49.1x38.5x8.5 • IE-70000-MC-SV2: 67x116x27.5 	327.5x122x320
Weight		EM1 + SV2 + PS (excluding cables) = 30 g + 150 g + 190 g = 370 g	Approx. 10 kg
Host interface		Communication module IE-70000-MC-SV2 (Conforming to 10BASE-T)	<ul style="list-style-type: none"> • EWS (UNIX) base Network interface board IE-70000-BX-SV1 (Supporting 10BASE-5 and 10BASE-2)
			<ul style="list-style-type: none"> • Personal computer base Personal computer interface board (to be purchased separately) IE-70000-98-IF-B or IE-70000- PC-IF-B
Power supply unit		IE-70000-MC-PS	Built into the main unit

(Note) Use a conversion unit to enable connection between a QFP and the target system.
(See Section 1.6 for details.)

Table B-2. Debugging Function Comparison

Item	Product name	IE-70732-MC	IE-70732-BX
Program execution			O
Program load/save			O
C source level debugging			O
Symbolic debugging			O
Software break			O
Hardware break			O
Emulation memory		Δ	O
Pin mask function		-	O
Operation with no target system		-	O
Complicated break condition		X	O
Real-time trace		X	O
Parallel interface		-	O
Network interface			O
Correspondence to actual chip		O	Δ

O: Superior Δ: Average X: Inferior -: Not applicable