

CubeSuite+ V1.00.01

Integrated Development Environment

User's Manual: RL78 Design

Target Device

RL78 Family

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

How to Use This Manual

This manual describes the role of the CubeSuite+ integrated development environment for developing application systems for RL78 family, and provides an outline of its features.

CubeSuite+ is an integrated development environment (IDE) for RL78 family, integrating the necessary tools for the development phase of software (e.g. design, implementation, and debugging) into a single platform.

By providing an integrated environment, it is possible to perform all development using just this product, without the need to use many different tools separately.

Readers This manual is intended for users who wish to understand the functions of the CubeSuite+ and design software and hardware application systems.

Purpose This manual is intended to give users an understanding of the functions of the CubeSuite+ to use for reference in developing the hardware or software of systems using these devices.

Organization This manual can be broadly divided into the following units.

CHAPTER 1 GENERAL

CHAPTER 2 FUNCTIONS (Code Generator)

APPENDIX A WINDOW REFERENCE

APPENDIX B OUTPUT FILES

APPENDIX C API FUNCTIONS

APPENDIX D INDEX

How to Read This Manual It is assumed that the readers of this manual have general knowledge of electricity, logic circuits, and microcontrollers.

Conventions

| | |
|----------------------------|---|
| Data significance: | Higher digits on the left and lower digits on the right |
| Active low representation: | \overline{XXX} (overscore over pin or signal name) |
| Note: | Footnote for item marked with Note in the text |
| Caution: | Information requiring particular attention |
| Remark: | Supplementary information |
| Numeric representation: | Decimal ... XXXX Hexadecimal ... 0xXXXX |

Related Documents

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

| Document Name | Document No. | |
|---|------------------------|-------------|
| CubeSuite+ Integrated Development Environment User's Manual | Start | R20UT0545E |
| | 78K0 Design | R20UT0546E |
| | 78K0R Design | R20UT0547E |
| | RL78 Design | This manual |
| | V850 Design | R20UT0549E |
| | R8C Design | R20UT0550E |
| | 78K0 Coding | R20UT0551E |
| | RL78,78K0R Coding | R20UT0552E |
| | V850 Coding | R20UT0553E |
| | Coding for CX Compiler | R20UT0554E |
| | R8C Coding | R20UT0576E |
| | 78K0 Build | R20UT0555E |
| | RL78,78K0R Build | R20UT0556E |
| | V850 Build | R20UT0557E |
| | Build for CX Compiler | R20UT0558E |
| | R8C Build | R20UT0575E |
| | 78K0 Debug | R20UT0559E |
| | 78K0R Debug | R20UT0560E |
| | RL78 Debug | R20UT0548E |
| | V850 Debug | R20UT0562E |
| R8C Debug | R20UT0574E | |
| Analysis | R20UT0563E | |
| Message | R20UT0407E | |

Caution The related documents listed above are subject to change without notice. Be sure to use the latest edition of each document when designing.

All trademarks or registered trademarks in this document are the property of their respective owners.

[MEMO]

[MEMO]

[MEMO]

TABLE OF CONTENTS

CHAPTER 1 GENERAL ... 10

- 1.1 Overview ... 10
- 1.2 Features ... 10

CHAPTER 2 FUNCTIONS (Code Generator) ... 11

- 2.1 Overview ... 11
- 2.2 Open Code Generator Panel ... 12
- 2.3 Enter Information ... 13
 - 2.3.1 Input rule ... 13
 - 2.3.2 Icon indicating incorrect entry ... 14
 - 2.3.3 Icon indicating pin conflict ... 15
- 2.4 Confirm Source Code ... 16
- 2.5 Output Source Code ... 17
 - 2.5.1 Set whether or not to generate source code ... 18
 - 2.5.2 Change file name ... 19
 - 2.5.3 Change API function name ... 20
 - 2.5.4 Change output mode ... 21
 - 2.5.5 Change output destination folder ... 22
- 2.6 Output Report Files ... 23
 - 2.6.1 Change output format ... 24
 - 2.6.2 Change output destination ... 26

APPENDIX A WINDOW REFERENCE ... 27

- A.1 Description ... 27

APPENDIX B OUTPUT FILES ... 54

- B.1 Overview ... 54
- B.2 Output File ... 54

APPENDIX C API FUNCTIONS ... 59

- C.1 Overview ... 59
- C.2 Output Function ... 59
- C.3 Function Reference ... 67
 - C.3.1 Clock Generator ... 69
 - C.3.2 Port ... 75
 - C.3.3 Interrupt ... 78
 - C.3.4 Serial ... 89

| | | |
|--------|--------------------------------|-----|
| C.3.5 | A/D Converter ... | 145 |
| C.3.6 | D/A Converter ... | 160 |
| C.3.7 | Timer ... | 167 |
| C.3.8 | Watchdog Timer ... | 203 |
| C.3.9 | Real-time Clock ... | 208 |
| C.3.10 | Interval Timer ... | 229 |
| C.3.11 | Comparator ... | 236 |
| C.3.12 | Clock Output/Buzzer Output ... | 242 |
| C.3.13 | Data Transfer Controller ... | 247 |
| C.3.14 | Event Link Controller ... | 253 |
| C.3.15 | DMA Controller ... | 257 |
| C.3.16 | Voltage Detector ... | 264 |

| | | |
|------------|-----------|-----|
| APPENDIX D | INDEX ... | 269 |
|------------|-----------|-----|

CHAPTER 1 GENERAL

CubeSuite+ is an integrated development environment used to carry out tasks such as design, coding, build and debug for developing application systems.

This chapter gives an overview of the design tool (Code Generator).

1.1 Overview

The design tool, which is one of the components provided by CubeSuite+, enables you to output the source code (device driver programs, C source files and header files) necessary to control the peripheral functions provided by the microcontroller (clock generator, port functions, etc.) by configuring various information using the GUI.

1.2 Features

The design tool (Code Generator) has the following features.

- Code generating function

The Code Generator can output not only device driver programs in accordance with the information configured using the GUI, but also a build environment such as sample programs containing main functions and link directive files.

Source code output by the Code Generator conforms to the MISRA-C (Guidelines for the Use of the C Language in Vehicle Based Software) coding convention.

- Reporting function

You can output configured information using the Code Generator as files in various formats for use as design documents.

- Renaming function

The user can change default names assigned to the files output by the Code Generator and the API functions contained in the source code.

CHAPTER 2 FUNCTIONS (Code Generator)

This chapter describes the key functions provided by the design tool (Code Generator) along with operation procedures.

2.1 Overview

The Code Generator outputs source code (device driver programs) based on information selected/entered on CubeSuite+ panels that is needed to control peripheral functions provided by the microcontroller (clock generator, port functions, etc.).

The following sections describe the operation procedures for Code Generator.

(1) Start CubeSuite+

Launch CubeSuite+ from the [Start] menu of Windows.

Remark See "CubeSuite+ Start User's Manual" for details on "Start CubeSuite+".

(2) Create/Open project

Create a new project (that defines a kind of project, microcontroller to be used, build tools to be used, etc.) or load an existing project.

Remark See "CubeSuite+ Start User's Manual" for details on "Create/Open project".

(3) Open Code Generator Panel

Open the [Code Generator panel](#) used to configure the information necessary to control the peripheral functions (clock generator, port functions, etc.).

(4) Enter Information

Configure the information necessary to control the peripheral functions in the [Code Generator panel](#).

(5) Confirm Source Code

Confirm the source code (device driver program) that reflects the information configured in the [Code Generator panel](#).

(6) Output Source Code

Output the source code (device driver program) to the specified folder.

(7) Output Report Files

Output report files (a file containing information configured using Code Generator and a file containing information regarding the source code) to the specified folder.

(8) Save project

Save a project.


Remark See "CubeSuite+ Start User's Manual" for details on "Save project".

2.2 Open Code Generator Panel

Open the [Code Generator panel](#) to configure the information necessary to control the peripheral functions (clock generator, port functions, etc.).

To open the [Code Generator panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[Clock Generator], [Port], etc." in the [Project Tree panel](#).

Figure 2-1. Open Code Generator Panel



Remark If an unsupported microcontroller is defined in the project for Code Generator, then "[Code Generator (Design Tool)] node" will hide under [*Project name* (Project)] in the [Project Tree panel](#).

2.3 Enter Information

Configure the information necessary to control the peripheral functions in the information setting area of the [Code Generator panel](#) which is opened as described in "2.2 [Open Code Generator Panel](#)".

Remark When controlling multiple peripheral functions, repeat the procedures described in "2.2 [Open Code Generator Panel](#)" through "2.3 [Enter Information](#)".

2.3.1 Input rule

Following is the rules for input to the [Code Generator panel](#).

(1) Character set

Character sets that are allowed to input are as follows.

Table 2-1. List of Character Set

| Character Set | Outline |
|---------------|--|
| ASCII | 1-byte alphabet, number, symbol |
| Shift-JIS | 2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana |
| EUC-JP | 2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana |
| UTF-8 | 2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji (include Chinese character) and 1-byte Katakana |


(2) Number

Notations allowed when entering numbers are as follows.

Table 2-2. List of Notation

| Notation | Outline |
|----------------|---|
| Decimal number | A numeric value that starts with a number between 1 and 9 and followed by numbers between 0 and 9, and the numeric value 0 |
| Hex number | A numeric value that starts with 0x and followed by a combination of numbers from 0 to 9 and characters from A to F (characters are not case sensitive) |

2.3.2 Icon indicating incorrect entry

When performing code generation, if you enter an invalid string in the [Code Generator panel](#), or a required input is missing, then a  icon displays next to the incorrect input, and the text is displayed in red to warn that there is a problem with the input.




Remark If the mouse cursor is moved over the  icon, information regarding the string that should be entered (tips for correcting the entry) pops up.

Figure 2-2. Icon Indicating Incorrect Entry



2.3.3 Icon indicating pin conflict

If a conflict occurs between the pins while setting various peripheral functions in the [Code Generator panel](#), the  icon is displayed at the location where the conflict occurs to warn the user of a conflict between the pins.



Remark If the mouse cursor is moved over the  icon, information regarding the conflict between the pins (tips for avoiding the conflict) pops up.

Figure 2-3. Icon Indicating Pin Conflict




2.4 Confirm Source Code

Confirm the source code (device driver program) that reflects the information configured as described in "2.3 Enter Information".

To confirm the source code, use the [Code Generator Preview panel](#) that opens by selecting [View] menu >> [Code Generator Preview].


Figure 2-4. Confirm Source Code




- Remarks 1. You can change the source code to be displayed by selecting the source file name or API function name in the [Code Generator Preview panel](#).
- 2. The following table displays the meaning of the color of the source code text displayed in the [Code Generator Preview panel](#).

Table 2-3. Color of Source Code

| Color | Outline |
|-------|------------------------------|
| Green | Comment |
| Blue | Reserved word for C compiler |
| Red | Numeric value |
| Black | Code section |
| Gray | File name |


- 3. You cannot edit the source code within the [Code Generator Preview panel](#).
- 4. For some of the API functions (such as API functions for serial array units), values such as the SFR register value are calculated and finalized when the source code is generated (when the  [Generate Code](#) button on the [Code Generator panel](#) is pressed). For this reason, the source code displayed in the [Code Generator Preview panel](#) may not be the same as that would actually be generated.

2.5 Output Source Code

Output the source code (device driver program) by pressing the  button on the [Code Generator panel](#).

The destination folder for the source code is specified by clicking [\[Generation\] tab](#) >> [Output folder] in the [Property panel](#).

Figure 2-5. Output Source Code





Remark In order to both output source files and add them to the project (display the corresponding source file names in the [Project Tree panel](#)) when you click the  button, you must open the [Property panel](#), and under [\[Generation\] tab](#) >> [Register files], specify "Output files to project".


Figure 2-6. Configure Whether to Register



2.5.1 Set whether or not to generate source code

You can set whether or not to generate the corresponding source code on a per-API function basis by selecting [Generate code/Not generate code] from the context menu displayed by right clicking the API function name in the [Code Generator Preview panel](#).

Figure 2-7. Setting That Determines Whether or Not to Generate Source Code



Remark You can confirm the current setting for the generation of source code by checking the type of icon in the [Code Generator Preview panel](#).


Table 2-4. Setting That Determines Whether or Not to Generate Source Code

| Type of Icon | Outline |
|--------------|---|
| | Source code for the currently selected API function is generated. If this icon is displayed next to the API function, the corresponding source code must be generated (it is impossible to change the icon to). |
| | Source code for the currently selected API function is generated. |
| | Source code for the currently selected API function is not generated. |

2.5.2 Change file name

The Code Generator is used to change the file name by selecting [Rename] from the context menu displayed by right clicking the file name in the [Code Generator Preview](#) panel.

Figure 2-8. Change File Name




Remark To restore the default file name defined by Code Generator, select [Default] from the context menu.

2.5.3 Change API function name

The Code Generator is used to change the name of the API function by selecting [Rename] from the context menu displayed by right clicking the API function name in the [Code Generator Preview panel](#).

Figure 2-9. Change API Function Name




Remark To restore the default name of the API function defined by Code Generator, select [Default] from the context menu.

2.5.4 Change output mode

The Code Generator is used to change the output mode (Overwrite file, Merge file, Do nothing if file exists) for the source code by selecting [Generation] tab >> [Generate file] in the Property panel.

Figure 2-10. Change Output Mode



Remark The output mode is selected from the following three types.

Table 2-5. Output Mode of Source Code

| Output Mode | Outline |
|--------------------------|---|
| Overwrite file | If a file with the same name exists, the existing file is overwritten by a new file. |
| Merge file | If a file with the same name exists, a new file is merged with the existing file. Only the section between <code>/* Start user code ...</code> . Do not edit comment generated here <code>*/</code> and <code>/* End user code</code> . Do not edit comment generated here <code>*/</code> will be merged. |
| Do nothin if file exists | If a file with the same name exists, a new file will not be output. |

2.5.5 Change output destination folder

The Code Generator is used to change the output destination folder for the source code by selecting [\[Generation\] tab](#) >> [\[Output folder\]](#) in the [Property panel](#).

To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [\[...\]](#) button in the [\[Output folder\]](#).

Figure 2-11. Change Output Destination Folder



2.6 Output Report Files

Output report files (a file containing information configured using Code Generator and a file containing information regarding the source code) by first activating the [Code Generator panel](#) or [Code Generator Preview panel](#), then selecting [File] menu >> [Save Code Generator Report].

The destination folder for the report file is specified by clicking [[Generation](#)] tab >> [Output folder] in the [Property panel](#).

Remarks 1. You can only use "macro" or "function" as a name of the report file.

Table 2-6. Output Report Files

| File Name | Outline |
|-----------|--|
| macro | A file that contains the information configured using Code Generator |
| function | A file that contains the information regarding the source code |

- The output mode for the report file is fixed to "Overwrite file".

Figure 2-12. Output Example of Report File "macro"




Figure 2-13. Output Example of Report File "function"


MCU name: RL78/G13(ROM:512KB)
Chip name: R5F100SL

| Module | File | Macro | Function | Default | Status |
|---------------------------------|--------------------|-------|-------------------------|--------------------|--------|
| Common | | | | | |
| | r_main.c | | | r_main.c | Used |
| | | | void main(void) | main | Used |
| | r_systeminit.c | | | r_systeminit.c | Used |
| | | | void R_Systeminit(void) | R_Systeminit | Used |
| | | | void hdwinit(void) | hdwinit | Used |
| | r_cg_macrodriver.h | | | r_cg_macrodriver.h | Used |
| | r_cg_userdefine.h | | | r_cg_userdefine.h | Used |
| | r_lk.dr | | | r_lk.dr | Used |
| Clock generation circuit | | | | | |
| | r_cgc.c | | | r_cgc.c | Used |
| | | | void R_CGC_Create(void) | R_CGC_Create | Used |

2.6.1 Change output format

The Code Generator is used to change the output format (HTML file or CSV file) of the report file by selecting [\[Generation\] tab](#) >> [\[Report type\]](#) in the [Property panel](#).

Figure 2-14. Change Output Format



Remark Output format is selected from the following two types.

Table 2-7. Output Mode of Source Code


| Report Type | Outline |
|-------------|---------------------------------------|
| HTML file | Outputs a report file in HTML format. |
| CSV file | Outputs a report file in CSV format. |

2.6.2 Change output destination

The Code Generator is used to change the output destination folder for the report file by selecting [\[Generation\] tab >>](#) [\[Output folder\]](#) in the [Property panel](#).

To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [\[...\]](#) button in the [\[Output folder\]](#).

Figure 2-15. Change Output Destination




APPENDIX A WINDOW REFERENCE

This appendix explains in detail the functions of the windows, panels and dialog boxes of the design tool.

A.1 Description

The design tool has the following windows, panels and dialog boxes.


Table A-1. Window/Panel/Dialog Box List

| Window/Panel/Dialog Box Name | Function |
|--|---|
| Main window | This is the first window to open when CubeSuite+ is launched. This window is used to operate various components (design tool, build tool, etc.) provided by CubeSuite+. |
| Project Tree panel | This panel displays the components of the project (microcontroller, design tool, build tool, etc.) in a tree structure. |
| Property panel | This panel allows you to view the information and change the setting for the node selected in the Project Tree panel , the peripheral function button pressed in the Code Generator panel or the file selected in the Code Generator Preview panel . |
| Code Generator panel | This panel allows you to configure the information necessary to control the peripheral functions provided by the microcontroller. |
| Code Generator Preview panel | This panel allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  button is pressed in the Code Generator panel . It also allows you to confirm the source code that reflects the information configured in the Code Generator panel . |
| Output panel | This panel displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite+. |
| Browse For Folder dialog box | This dialog box allows you to specify the output destination for files (source code, report file, etc.). |
| Save As dialog box | This dialog box allows you to name and save a file (such as a report file). |

Main window

This is the first window to open when CubeSuite+ is launched. This window is used to operate various components (design tool, build tool, etc.) provided by CubeSuite+.

Figure A-1. Main Window



The following items are explained here.

- [How to open]
- [Description of each area]

[How to open]

- From the [start] menu, select [All Programs] >> [Renesas Electronics CubeSuite+] >>[CubeSuite+].

[Description of each area]

(1) Menu bar

This area consists of the following menu items.

(a) [File] menu

| | |
|------------------------------------|--|
| Save Code Generator Report | <p>Code Generator panel/Code Generator Preview panel-dedicated item</p> <p>Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code).</p> <ul style="list-style-type: none"> - The output format for the report file (either HTML or CSV) is selected by clicking [Generation] tab >> [Report type] in the Property panel. - The destination folder for the report file is specified by clicking [Generation] tab >> [Output folder] in the Property panel. |
| Save Output- <i>Tab Name</i> | <p>Output panel-dedicated item</p> <p>Saves the message corresponding to the specified tab overwriting the existing file.</p> |
| Save Output- <i>Tab Name As...</i> | <p>Output panel-dedicated item</p> <p>Opens the Save As dialog box for naming and saving the message corresponding to the specified tab.</p> |

(b) [Edit] menu

| | |
|------------|--|
| Undo | <p>Property panel-dedicated item</p> <p>Cancels the effect of an edit operation to restore the previous state.</p> |
| Cut | <p>Property panel-dedicated item</p> <p>Sends the character string or lines selected with range selection to the clipboard and deletes them.</p> |
| Copy | <p>Property panel/Output panel-dedicated item</p> <p>Sends the character string or lines selected with range selection to the clipboard.</p> |
| Paste | <p>Property panel-dedicated item</p> <p>Inserts the contents of the clipboard at the caret position.</p> |
| Delete | <p>Property panel-dedicated item</p> <p>Deletes the character string or the lines selected with the range selection.</p> |
| Select All | <p>Property panel/Output panel-dedicated item</p> <p>Selects all the strings displayed in the item being edited or all the strings displayed in the Message area.</p> |
| Search... | <p>Code Generator Preview panel/Output panel-dedicated item</p> <p>Opens the Search and Replace dialog box for searching strings with the [Quick Search] tab selected.</p> |
| Replace... | <p>Output panel-dedicated item</p> <p>Opens the Search and Replace dialog box for replacing strings with the [Whole Replace] tab selected.</p> |

(c) [Help] menu

| | |
|----------------------------------|--|
| Open Help for Project Tree Panel | <p>Project Tree panel-dedicated item</p> <p>Displays the help of Project Tree panel.</p> |
| Open Help for Property Panel | <p>Property panel-dedicated item</p> <p>Displays the help of Property panel.</p> |

| | |
|--|---|
| Open Help for Code Generator Panel | Code Generator panel -dedicated item Displays the help of Code Generator panel . |
| Open Help for Code Generator Preview Panel | Code Generator Preview panel -dedicated item Displays the help of Code Generator Preview panel . |
| Open Help for Output Panel | Output panel -dedicated item Displays the help of Output panel . |

(2) Panel display area

This area consists of multiple panels, each dedicated to a different purpose.


See the following sections for details on this area.

- [Project Tree panel](#)
- [Property panel](#)
- [Code Generator panel](#)
- [Code Generator Preview panel](#)
- [Output panel](#)

Project Tree panel

This panel displays components of the project (microcontroller, design tool, build tool, etc.) in a tree structure.

Figure A-2. Project Tree Panel



The following items are explained here.

- [How to open]
- [Description of each area]
- [[Help] menu (Project Tree panel-dedicated items)]
- [Context menu]

[How to open]

- From the [View] menu, select [Project Tree].

[Description of each area]

(1) Project tree area

This area displays components of the project (microcontroller, design tool, build tool, etc.) in a tree structure.

(a) Code Generator (Design Tool)




This node consists of the following peripheral function nodes.

When there is peripheral function target microcontroller is not supporting, peripheral function button is not displayed.

| | |
|----------------------------|---|
| Clock Generator | Opens the [Clock Generator] for configuring the information necessary to control the functions of clock generator, on-chip debug function and etc. provided by the microcontroller. |
| Port | Opens the [Port] for configuring the information necessary to control the port functions provided by the microcontroller. |
| Interrupt | Opens the [Interrupt] for configuring the information necessary to control the interrupt functions and the key interrupt function provided by the microcontroller. |
| Serial | Opens the [Serial] for configuring the information necessary to control the functions of serial array unit and functions of serial interface provided by the microcontroller. |
| A/D Converter | Opens the [A/D Converter] for configuring the information necessary to control the function of A/D converter provided by the microcontroller. |
| D/A Converter | Opens the [D/A Converter] for configuring the information necessary to control the function of D/A converter provided by the microcontroller. |
| Timer | Opens the [Timer] for configuring the information necessary to control the functions of timer array unit provided by the microcontroller. |
| Watchdog Timer | Opens the [Watchdog Timer] for configuring the information necessary to control the functions of watchdog timer provided by the microcontroller. |
| Real-time Clock | Opens the [Real-time Clock] for configuring the information necessary to control the functions of real-time clock provided by the microcontroller. |
| Interval Timer | Opens the [Interval Timer] for configuring the information necessary to control the functions of interval timer provided by the microcontroller. |
| Comparator | Opens the [Comparator] for configuring the information necessary to control the functions of comparator provided by the microcontroller. |
| Clock Output/Buzzer Output | Opens the [Clock Output/Buzzer Output] for configuring the information necessary to control the functions of clock output/buzzer output controller provided by the microcontroller. |
| Data Transfer Controller | Opens the [Data Transfer Controller] for configuring the information necessary to control the function of data transfer controller provided by the microcontroller. |
| Event Link Controller | Opens the [Event Link Controller] for configuring the information necessary to control the functions of event link controller provided by the microcontroller. |
| DMA Controller | Opens the [DMA Controller] for configuring the information necessary to control the functions of DMA (Direct Memory Access) controller provided by the microcontroller. |
| Voltage Detector | Opens the [Voltage Detector] for configuring the information necessary to control the functions of voltage detector provided by the microcontroller. |

(b) Icons

The table below displays the meaning of the icon displayed to the left of the string representing the peripheral function node.

| | |
|---|--|
|  | Operation in the corresponding Code Generator panel has been carried out. |
|  | Operation in the corresponding Code Generator panel has not been carried out. |
|  | The problem occurs on the settings became the manipulation to the other peripheral function node influences. |

[[Help] menu (Project Tree panel-dedicated items)]

| | |
|----------------------------------|----------------------------------|
| Open Help for Project Tree Panel | Displays the help of this panel. |
|----------------------------------|----------------------------------|

[Context menu]


The following context menu items are displayed by right clicking the mouse.

| | |
|-----------------------|---|
| Return to Reset Value | Restores the information for the selected peripheral function node to its default state. |
| Property | Opens the Property panel containing the information for the selected node ([Code Generator (Design Tool)]). |

Property panel

This panel allows you to view the information on and change the setting for the node selected in the [Project Tree panel](#), the peripheral function button pressed in the [Code Generator panel](#) or the file selected in the [Code Generator Preview panel](#).

Figure A-3. Property Panel (Selected [Code Generator (Design Tool)])





The following items are explained here.



- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[Edit\] menu \(Property panel-dedicated items\)\]](#)
- [\[\[Help\] menu \(Property panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

[How to open]



- On the [Project Tree panel](#), select a node ([Code Generator (Design Tool)], peripheral function node "[Clock Generator], [Port], etc."), and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select a node ([Code Generator (Design Tool)], peripheral function node "[Clock Generator], [Port], etc."), and then select [Property] from the context menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the [View] menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the context menu.



- Remarks 1.** If this panel is already open, selecting a different node ([Code Generator (Design Tool)] or peripheral function node such as [Clock Generator], [Port], etc.) in the [Project Tree panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.
- 2.** If this panel is already open, pressing a different peripheral function button (such as , , etc.) in the [Code Generator panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.
- 3.** If this panel is already open, selecting a different file in the [Code Generator Preview panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.

[Description of each area]**(1) Detail information display/change area**



This area allows you to view the information on and change the setting for the node ([Code Generator (Design Tool)] or peripheral function node such as [Clock Generator], [Port], etc.) selected in the [Project Tree panel](#), the peripheral function button (such as  ,  , etc.) pressed in the [Code Generator panel](#), or the file selected in the [Code Generator Preview panel](#).

The content displayed in this area differs depending on the node selected in the [Project Tree panel](#), the peripheral function button pressed in the [Code Generator panel](#) or the file selected in the [Code Generator Preview panel](#).

The following table displays the meaning of  and  displayed to the left of each category.

| | |
|---|---|
|  | Indicates that the items within the category are displayed as a "collapsed view". |
|  | Indicates that the items within the category are displayed as an "expanded view". |

Remarks 1. See the sections "[\[Generation\] tab](#)", "[\[Macro Setting\] tab](#)" and "[\[File Setting\] tab](#)" for details on the content displayed in this area.

2. To switch between  and  , click this mark or double-click the category name.

(2) Explanation area

This area displays a "brief description" of the category or item selected in the [Detail information display/change area](#).

[[Edit] menu (Property panel-dedicated items)]

| | |
|------------|--|
| Undo | Cancels the effect of an edit operation to restore the previous state. |
| Cut | Sends the character string or lines selected with range selection to the clipboard and deletes them. |
| Copy | Sends the character string or lines selected with range selection to the clipboard. |
| Paste | Inserts the contents of the clipboard at the caret position. |
| Delete | Deletes the character string or the lines selected with the range selection. |
| Select All | Selects all strings displayed in the item being edited. |

[[Help] menu (Property panel-dedicated items)]

| | |
|------------------------------|----------------------------------|
| Open Help for Property Panel | Displays the help of this panel. |
|------------------------------|----------------------------------|

[Context menu]

The following context menu items are displayed by right clicking the mouse.

(1) While the item is being edited

| | |
|------|--|
| Undo | Cancels the effect of an edit operation to restore the previous state. |
| Cut | Sends the character string or lines selected with range selection to the clipboard and deletes them. |

| | |
|------------|---|
| Copy | Sends the character string or lines selected with range selection to the clipboard. |
| Paste | Inserts the contents of the clipboard at the caret position. |
| Delete | Deletes the character string or the lines selected with the range selection. |
| Select All | Selects all strings displayed in the item being edited. |


(2) While the item is not being edited

| | |
|-------------------------------|--|
| Property Reset to Default | Restores the selected item to its default state. |
| Property Reset All to Default | Restores all items to their default state. |

[Generation] tab

This tab allows you to view the information (Product Information, Generate File Mode) on and change the setting for the [Code Generator (Design Tool)] selected in the [Project Tree panel](#).

Figure A-4. [Generation] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

[How to open]

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)], and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)], and then select [Property] from the context menu.

Remark If this panel is already open, selecting a different [Code Generator (Design Tool)] in the [Project Tree panel](#) changes the content displayed accordingly.

[Description of each area]


(1) [Product Information] category

This area displays product information (Version and Release date) on Code Generator.

| | |
|--------------|--|
| Version | Displays the version of Code Generator. |
| Release date | Displays the release date of Code Generator. |

(2) [Generate File Mode] category

This area allows you to view and change the setting for the file generation mode (Generate file, Output folder, Report type and Register files) of Code Generator.

| | | |
|----------------|--|--|
| Generate file | Views or selects the operation mode applied when the  button is pressed. Operation mode applied when you select [File] menu >> [Save Code Generator Report] is fixed to "Overwrite file". | |
| | Overwrite file | If a file with the same name exists, the existing file is overwritten by a new file. |
| | Merge file | If a file with the same name exists, a new file is merged with the existing file. Only the section between "/* Start user code Do not edit comment generated here */" and "/* End user code. Do not edit comment generated here */" will be merged. |
| | Do nothing if file exists | If a file with the same name exists, a new file will not be output. |
| Output folder | Views or selects the destination folder for various files (source code and report files) which are output when the  button is pressed or when [File] menu >> [Save Code Generator Report] is selected. | |
| Report type | Views or selects the format of the report files (a file containing information configured using Code Generator and a file containing information regarding the source code) which are output when [File] menu >> [Save Code Generator Report] is selected. | |
| | HTML file | Outputs a report file in HTML format. |
| | CSV file | Outputs a report file in CSV format. |
| Register files | Selects whether source code generated by pressing the  button should be added to the project. | |
| | Output files to project | Adds output source code to the project. The source code will be added to the Project Tree panel , under the [File] - [Code Generator] node. |
| | Not output files to project | Does not add output source code to the project. |

Remark To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [...] button in this area.

(3) [Pin Configurator Reflect Mode] category

Not supported in this version.

This category will be grayed out.

[Macro Setting] tab




This tab allows you to view the information (Macro Information) on and change the setting for the peripheral function node "[Clock Generator], [Port], etc." selected in the [Project Tree panel](#), or the peripheral function button " ,  , etc." pressed in the [Code Generator panel](#).

Figure A-5. [Macro Setting] Tab





The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

[How to open]

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[Clock Generator], [Port], etc.", and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[Clock Generator], [Port], etc.", and then select [Property] from the context menu.

- Remarks 1.** If this panel is already open, selecting a different peripheral function node "[Clock Generator], [Port], etc." in the [Project Tree panel](#) changes the content displayed accordingly.
- 2.** If this panel is already open, pressing a different type of peripheral function button " ,  , etc." in the [Code Generator panel](#) changes the content displayed accordingly.

[Description of each area]

(1) [Macro Information] category


This area allows you to view the information (Macro name) on and change the setting for the peripheral function node "[Clock Generator], [Port], etc." selected in the [Project Tree panel](#), or the peripheral function button pressed in the [Code Generator panel](#).

| | |
|------------|--|
| Macro name | Displays the type of peripheral function node selected in the Project Tree panel or the type of peripheral function button pressed in the Code Generator panel . |
|------------|--|

[File Setting] tab

This tab allows you to view the information (File Information) on and change the setting for the file selected in the [Code Generator Preview panel](#).

Figure A-6. [File Setting] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

[How to open]

- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the [View] menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the context menu.

Remark If this panel is already open, selecting a different file in the [Code Generator Preview panel](#) changes the content displayed accordingly.

[Description of each area]

(1) [File Information] category


This area allows you to view the information (Default, File name) on and change the setting for the file selected in the [Code Generator Preview panel](#).

| | | |
|--------------|--|---|
| Default name | Views or selects the setting that determines whether the name of the file selected in the Code Generator Preview panel is a default name or not. | |
| | Yes | The file name is a default name. Changing this area from "No" to "Yes" changes the name of the file to its default name. |
| | No | The file name is not a default name. |
| File name | Displays or change the name of the file selected on the Code Generator Preview panel . | |

Code Generator panel

This panel allows you to configure the information necessary to control the peripheral functions provided by the microcontroller.

Figure A-7. Code Generator Panel: [Clock Generator]



The following items are explained here.

- [How to open]
- [Description of each area]
- [[File] menu (Code Generator panel-dedicated items)]
- [[Help] menu (Code Generator panel-dedicated items)]

[How to open]

- On the **Project Tree panel**, select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[Clock Generator], [Port], etc.".

Remark If this panel is already open, pressing a different peripheral function button " , , etc." changes the content displayed in the **Information setting area** accordingly.

[Description of each area]


(1) Toolbar

This area consists of the following "peripheral function buttons".

When there is peripheral function target microcontroller is not supporting, peripheral function button is not displayed.

| | |
|--|--|
| | Not supported in this version. This button will be grayed out (disabled). |
|--|--|

| | |
|---|--|
|  Generate Code | Outputs the source code (device driver program) to the folder specified by selecting [Generation] tab >> [Output folder] in the Property panel. |
|  | Changes the content displayed in the Information setting area to the "[Clock Generator] for configuring the information necessary to control the functions of clock generator, on-chip debug function and etc. provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Port] for configuring the information necessary to control the port functions provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Interrupt] for configuring the information necessary to control the interrupt functions and the key interrupt function provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Serial] for configuring the information necessary to control the functions of serial array unit and functions of serial interface provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[A/D Converter] for configuring the information necessary to control the function of A/D converter provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[D/A Converter] for configuring the information necessary to control the function of D/A converter provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Timer] for configuring the information necessary to control the functions of timer array unit provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Watchdog Timer] for configuring the information necessary to control the functions of watchdog timer provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Real-time Clock] for configuring the information necessary to control the functions of real-time clock provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Interval Timer] for configuring the information necessary to control the functions of interval timer provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Comparator] for configuring the information necessary to control the functions of comparator provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Clock Output/Buzzer Output] for configuring the information necessary to control the functions of clock output/buzzer output controller provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Data Transfer Controller] for configuring the information necessary to control the function of data transfer controller provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[Event Link Controller] for configuring the information necessary to control the functions of event link controller provided by the microcontroller". |
|  | Changes the content displayed in the Information setting area to the "[DMA Controller] for configuring the information necessary to control the functions of DMA (Direct Memory Access) controller provided by the microcontroller". |

| | |
|---|---|
|  | Changes the content displayed in the Information setting area to the "[Voltage Detector] for configuring the information necessary to control the functions of voltage detector provided by the microcontroller". |
|---|---|

(2) Information setting area

The content displayed in this area differs depending on the "peripheral function node" or "peripheral function button" selected or pressed when opening this panel.

See user's manual for microcontroller for details on the items to be set.

[[File] menu (Code Generator panel-dedicated items)]

| | |
|----------------------------|---|
| Save Code Generator Report | Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code). |
|----------------------------|---|

- Remarks 1.** The output format for the report file (either HTML or CSV) is selected by clicking [\[Generation\] tab](#) >> [\[Report type\]](#) in the [Property panel](#).
- 2.** The destination folder for the report file is specified by clicking [\[Generation\] tab](#) >> [\[Output folder\]](#) in the [Property panel](#).

[[Help] menu (Code Generator panel-dedicated items)]

| | |
|------------------------------------|----------------------------------|
| Open Help for Code Generator Panel | Displays the help of this panel. |
|------------------------------------|----------------------------------|

Code Generator Preview panel



This panel allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  button is pressed in the [Code Generator panel](#). It also allows you to confirm the source code that reflects the information configured in the [Code Generator panel](#).

Figure A-8. Code Generator Preview Panel



The following items are explained here.


- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[File\] menu \(Code Generator Preview panel-dedicated items\)\]](#)
- [\[\[Help\] menu \(Code Generator Preview panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

[How to open]

- From the [\[View\] menu](#), select [\[Code Generator Preview\]](#).





[Description of each area]

(1) Preview tree

This area allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  button is pressed in the [Code Generator panel](#).

- Remarks 1. You can change the source code to be displayed by selecting the source file name or API function name in this tree.
- 2. To select whether or not to generate the source code, use the context menu (Generate code/Not generate code) which is displayed by right-clicking the mouse while the mouse cursor is on the desired icon in the tree.
- 3. You can confirm the current setting that determines whether or not to generate the source code by checking the type of icon.

Table A-2. Setting That Determines Whether or Not to Generate the Source Code

| Type of Icon | Outline |
|---|---|
|  | Source code for the currently selected API function is generated. If this icon is displayed next to the API function, the corresponding source code must be generated (it is impossible to change the icon to ). |
|  | Source code for the currently selected API function is generated. |
|  | Source code for the currently selected API function is not generated. |


(2) Source code display area

This area allows you to confirm the source code (device driver program) that reflects the information configured in the [Code Generator panel](#).

The following table displays the meaning of the color of the source code text displayed in this area.

Table A-3. Color of Source Code

| Color | Outline |
|-------|------------------------------|
| Green | Comment |
| Blue | Reserved word for C compiler |
| Red | Numeric value |
| Black | Code section |
| Gray | File name |

- Remarks 1. You cannot edit the source code within this panel.
- 2. For some of the API functions (such as API functions for serial array units), values such as the SFR register value are calculated and finalized when the source code is generated (when the  button on the [Code Generator panel](#) is pressed). For this reason, the source code displayed in this panel may not be the same as that would actually be generated.
- 3. You can change the source code to be displayed by selecting the source file name or API function name in the preview tree.

[[File] menu (Code Generator Preview panel-dedicated items)]

| | |
|----------------------------|---|
| Save Code Generator Report | Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code). |
|----------------------------|---|






- Remarks 1. The output format for the report file (either HTML or CSV) is selected by clicking [\[Generation\] tab >>](#) [\[Report type\]](#) in the [Property panel](#).
- 2. The destination folder for the report file is specified by clicking [\[Generation\] tab >>](#) [\[Output folder\]](#) in the [Property panel](#).

[[Help] menu (Code Generator Preview panel-dedicated items)]

| | |
|--|----------------------------------|
| Open Help for Code Generator Preview Panel | Displays the help of this panel. |
|--|----------------------------------|

[Context menu]

The following context menu items are displayed by right clicking the mouse.

| | |
|-------------------|--|
| Generate code | Makes a setting so that the source code of the currently selected API function is generated to the folder specified by selecting [Generation] tab >> [Output folder] in the Property panel . Selecting this context menu item changes the icon of the currently selected API function from  to  . |
| Not generate code | Makes a setting so that the source code of the currently selected API function is not generated when the  button is pressed in the Code Generator panel . Selecting this context menu item changes the icon of the currently selected API function from  to  . |
| Rename | Changes the name portion of the currently selected file or API function into an edit box for editing the name. You can change the name of the file or API function by editing its name in the edit box. |
| Default | Reverts the file name or API function name to its original name before it was edited. |
| Property | Opens the Property panel that contains the information for the currently selected file. |

Output panel

This panel displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite+.

Figure A-9. Output Panel



The following items are explained here.

- [How to open]
- [Description of each area]
- [[File] menu (Output panel-dedicated items)]
- [[Edit] menu (Output panel-dedicated items)]
- [[Help] menu (Output panel-dedicated items)]
- [Context menu]

[How to open]

- From the [View] menu, select [Output].

[Description of each area]

(1) Message area

This area displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite+. The following table displays the meaning of the color of the message text displayed in this area.

Table A-4. Color of Message Text/Background

| Message Text/Background | Description |
|-------------------------|---|
| Block/White | Information message Displayed with information notices. |
| Blue/Standard color | Warning message Displayed with warnings about operations. |
| Red/LightGray | Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake. |

Remark See the sections "[All Output Messages] tab" and "[Code Generator] tab" for details on the content displayed in this area.

(2) Tab selection area

Select the source of message.

Remark When the new message is output, "*" mark is displayed to the left of the tab name.

[[File] menu (Output panel-dedicated items)]

| | |
|------------------------------------|--|
| Save Output- <i>Tab Name</i> | Saves the message corresponding to the specified tab overwriting the existing file. |
| Save Output- <i>Tab Name</i> As... | Opens the Save As dialog box for naming and saving the message corresponding to the specified tab. |

[[Edit] menu (Output panel-dedicated items)]

| | |
|------------|--|
| Copy | Sends the character string or lines selected with range selection to the clipboard. |
| Select All | Selects all the messages displayed on the Message area . |
| Search... | Opens the Search and Replace dialog box for searching strings with the [Quick Search] tab selected. |
| Replace... | Opens the Search and Replace dialog box for replacing strings with the [Whole Replace] tab selected. |

[[Help] menu (Output panel-dedicated items)]

| | |
|----------------------------|----------------------------------|
| Open Help for Output Panel | Displays the help of this panel. |
|----------------------------|----------------------------------|

[Context menu]

The following context menu items are displayed by right clicking the mouse.

| | |
|-----------------------|--|
| Copy | Sends the character string or lines selected with range selection to the clipboard. |
| Select All | Selects all the messages displayed on the Message area . |
| Clear | Deletes all the messages displayed on the Message area . |
| Stop Searching | <p>Cancels the search currently being executed.</p> <p>This is invalid when a search is not being executed.</p> |
| Open Help for Message | <p>Displays help for the message on the current caret location.</p> <p>This only applies to warning messages and error messages.</p> |

[All Output Messages] tab

This tab displays operation logs for all components (design tool, build tool, etc.) provided by CubeSuite+.

Figure A-10. [All Output Messages] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

[How to open]

- From the [View] menu, select [Output].

[Description of each area]

(1) Message area

This area displays operation logs for all components (design tool, build tool, etc.) provided by CubeSuite+. The following table displays the meaning of the color of the message text displayed in this area.

Table A-5. Color of Message Text/Background

| Message Text/Background | Description |
|-------------------------|---|
| Black/White | Information message Displayed with information notices. |
| Blue/Standard Color | Warning message Displayed with warnings about operations. |
| Red/LightGray | Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake. |

[Code Generator] tab

This tab displays only operation logs for Code Generator out of those for various components (design tool, build tool, etc.) provided by CubeSuite+.

Figure A-11. [Code Generator] Tab



The following items are explained here.

- [How to open]
- [Description of each area]

[How to open]

- From the [View] menu, select [Output].

[Description of each area]

(1) Message area

This area displays only operation logs for Code Generator out of those for various components (design tool, build tool, etc.) provided by CubeSuite+.

The following table displays the meaning of the color of the message text displayed in this area.


Table A-6. Color of Message Text/Background

| Message Text/Background | Outline |
|-------------------------|---|
| Black/White | Information message Displayed with information notices. |
| Blue/Standard Color | Warning message Displayed with warnings about operations. |
| Red/LightGray | Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake. |

Browse For Folder dialog box

This dialog box allows you to specify the output destination for files (source code, report file, etc.).

Figure A-12. Browse For Folder Dialog Box



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

[How to open]

- In the [Generation] tab of the Property panel, click the [...] button in [Output folder].

[Description of each area]

(1) Folder location

Select the folder to which the files (source code, report file, etc.) are output.


[Function buttons]

| Button | Function |
|-----------------|--|
| Make New Folder | Creates a "New Folder" below the folder selected in the Folder location. |
| OK | Specifies the folder selected in the Folder location as the destination for the files. |
| Cancel | Ignores the setting and closes this dialog box. |

Save As dialog box

This dialog box allows you to name and save a file (such as a report file).

Figure A-13. Save As Dialog Box



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

[How to open]

- From the [File] menu, select [Save <object> As...].

[Description of each area]

(1) [Save in]

Select the folder to which the files (report files, etc.) are output.

(2) List of files

This area displays a list of files matching the conditions selected in [Save in] and [Save as type].

(3) [File name]

Specify the name of the file to be output.

(4) [Save as type]

Select the type of the file to be output.

| | |
|-------------------------------------|------------------------------------|
| Microsoft Office Excel Book (*.xls) | Microsoft Office Excel Book format |
| Bitmap (*.bmp) | Bitmap format |
| PNG (*.png) | PNG format |
| JPEG (*.jpg) | JPEG format |
| EMF (*.emf) | EMF format |

[Function buttons]

| Button | Function |
|--------|--|
| Save | Outputs a file having the name specified in the [File name] and [Save as type] to the folder specified in the [Save in]. |
| Cancel | Ignores the setting and closes this dialog box. |

APPENDIX B OUTPUT FILES

This appendix describes the files output by the Code Generator.

B.1 Overview

Below is a list of files output by the Code Generator.

Table B-1. File List

| Unit of Output | File Name | Description |
|---------------------|--|--|
| Peripheral function | <i>r_PeripheralFunctionName.c</i> | Initial function, API function |
| | <i>r_PeripheralFunctionName_user.c</i> | Interrupt function, callback function |
| | <i>r_cg_PeripheralFunctionName.h</i> | Defines macros for assigning values to registers |
| Project | <i>r_main.c</i> | main function |
| | <i>r_systeminit.c</i> | Call initial function of peripheral function Call R_CGC_Get_ResetSource |
| | <i>r_cg_macrodriver.h</i> | Defines common macros used by all source files |
| | <i>r_cg_userdefine.h</i> | Empty file (for user definitions) |
| | <i>r_lk.dr</i> | Link directive |

B.2 Output File

Below are the files (peripheral function) output by the Code Generator.

Table B-2. File List (Peripheral Function)

| Peripheral Function | Source File Name | Names of API Functions Included |
|---------------------|----------------------|---|
| Clock Generator | <i>r_cgc.c</i> | R_CGC_Create R_CGC_Set_ClockMode R_CGC_Set_CRCON |
| | <i>r_cgc_user.c</i> | R_CGC_Create_UserInit R_CGC_Get_ResetSource |
| | <i>r_cg_cgc.h</i> | - |
| Port | <i>r_port.c</i> | R_PORT_Create |
| | <i>r_port_user.c</i> | R_PORT_Create_UserInit |
| | <i>r_cg_port.h</i> | - |
| Interrupt | <i>r_intc.c</i> | R_INTC_Create R_INTCn_Start R_INTCn_Stop R_KEY_Create R_KEY_Start R_KEY_Stop |
| | <i>r_intc_user.c</i> | R_INTC_Create_UserInit R_INTCn_Interrupt R_KEY_Create_UserInit R_KEY_Interrupt |

| Peripheral Function | Source File Name | Names of API Functions Included |
|---------------------|------------------|--|
| Interrupt | r_cg_intc.h | - |
| Serial | r_serial.c | R_SAUm_Create R_SAUm_Set_PowerOff R_SAU0_Set_SnoozeOn R_SAU0_Set_SnoozeOff R_UARTn_Create R_UARTn_Start R_UARTn_Stop R_UARTn_Send R_UARTn_Receive R_CSImn_Create R_CSImn_Start R_CSImn_Stop R_CSImn_Send R_CSImn_Receive R_CSImn_Send_Receive R_IICmn_Create R_IICmn_StartCondition R_IICmn_StopCondition R_IICmn_Stop R_IICmn_Master_Send R_IICmn_Master_Receive R_IICAn_Create R_IICAn_StopCondition R_IICAn_Stop R_IICAn_Set_PowerOff R_IICAn_Master_Send R_IICAn_Master_Receive R_IICAn_Slave_Send R_IICAn_Slave_Receive |
| | r_serial_user.c | R_SAUm_Create_UserInit R_UARTn_Interrupt_Send R_UARTn_Interrupt_Receive R_UARTn_Interrupt_Error R_UARTn_Callback_SendEnd R_UARTn_Callback_ReceiveEnd R_UARTn_Callback_Error R_UARTn_Callback_SoftwareOverRun R_CSImn_Interrupt R_CSImn_Callback_SendEnd R_CSImn_Callback_ReceiveEnd R_CSImn_Callback_Error R_IICmn_Interrupt R_IICmn_Callback_Master_SendEnd R_IICmn_Callback_Master_ReceiveEnd R_IICmn_Callback_Master_Error R_IICAn_Create_UserInit |

| Peripheral Function | Source File Name | Names of API Functions Included |
|---------------------|------------------|---|
| Serial | r_serial_user.c | R_IICAn_Interrupt R_IICAn_Callback_Master_SendEnd R_IICAn_Callback_Master_ReceiveEnd R_IICAn_Callback_Master_Error R_IICAn_Callback_Slave_SendEnd R_IICAn_Callback_Slave_ReceiveEnd R_IICAn_Callback_Slave_Error R_IICAn_Callback_GetStopCondition |
| | r_cg_serial.h | - |
| A/D Converter | r_adc.c | R_ADC_Create R_ADC_Set_ComparatorOn R_ADC_Set_ComparatorOff R_ADC_Start R_ADC_Stop R_ADC_Set_PowerOff R_ADC_Set_ADChannel R_ADC_Set_SnoozeOn R_ADC_Set_SnoozeOff R_ADC_Set_TestChannel R_ADC_Get_Result R_ADC_Get_Result_8bit |
| | r_adc_user.c | R_ADC_Create_UserInit R_ADC_Interrupt |
| | r_cg_adc.h | - |
| D/A Converter | r_dac.c | R_DAC_Create R_DACn_Start R_DACn_Stop R_DAC_Set_PowerOff R_DACn_Set_ConversionValue |
| | r_dac_user.c | R_DAC_Create_UserInit |
| | r_cg_dac.h | - |
| Timer | r_timer.c | R_TAUm_Create R_TAUm_Channeln_Start R_TAUm_Channeln_Higher8bits_Start R_TAUm_Channeln_Lower8bits_Start R_TAUm_Channeln_Stop R_TAUm_Channeln_Higher8bits_Stop R_TAUm_Channeln_Lower8bits_Stop R_TAUm_Set_PowerOff R_TAUm_Channeln_Get_PulseWidth R_TAUm_Channeln_SoftwareTriggerOn R_TMR_RDn_Create R_TMR_RDn_Start R_TMR_RDn_Stop R_TMR_RDn_Set_PowerOff |

| Peripheral Function | Source File Name | Names of API Functions Included |
|---------------------|------------------|--|
| Timer | r_timer.c | R_TMR_RDn_Get_PulseWidth R_TMR_RGn_Create R_TMR_RGn_Start R_TMR_RGn_Stop R_TMR_RGn_Set_PowerOff R_TMR_RGn_Get_PulseWidth R_TMR_RJ0_Create R_TMR_RJ0_Start R_TMR_RJ0_Stop R_TMR_RJ0_Set_PowerOff R_TMR_RJ0_Get_PulseWidth |
| | r_timer_user.c | R_TAUm_Create_UserInit R_TAUm_Channeln_Interrupt R_TAUm_Channeln_Higher8bits_Interrupt R_TMR_RDn_Create_UserInit R_TMR_RDn_Interrupt R_TMR_RGn_Create_UserInit R_TMR_RGn_Interrupt R_TMR_RJ0_Create_UserInit R_TMR_RJ0_Interrupt |
| | r_cg_timer.h | - |
| Watchdog Timer | r_wdt.c | R_WDT_Create R_WDT_Restart |
| | r_wdt_user.c | R_WDT_Create_UserInit R_WDT_Interrupt |
| | r_cg_wdt.h | - |
| Real-time Clock | r_rtc.c | R_RTC_Create R_RTC_Start R_RTC_Stop R_RTC_Set_PowerOff R_RTC_Set_HourSystem R_RTC_Set_CounterValue R_RTC_Get_CounterValue R_RTC_Set_ConstPeriodInterruptOn R_RTC_Set_ConstPeriodInterruptOff R_RTC_Set_AlarmOn R_RTC_Set_AlarmOff R_RTC_Set_AlarmValue R_RTC_Get_AlarmValue R_RTC_Set_RTC1HZOn R_RTC_Set_RTC1HZOff |
| | r_rtc_user.c | R_RTC_Create_UserInit R_RTC_Interrupt R_RTC_Callback_ConstPeriod R_RTC_Callback_Alarm |

| Peripheral Function | Source File Name | Names of API Functions Included |
|----------------------------|------------------|--|
| Rel-time Clock | r_cg_rtc.h | - |
| Interval Timer | r_it.c | R_IT_Create R_IT_Start R_IT_Stop R_IT_Set_PowerOff |
| | r_it_user.c | R_IT_Create_UserInit R_IT_Interrupt |
| | r_cg_it.h | - |
| Comparator | r_comp.c | R_COMP_Create R_COMPn_Start R_COMPn_Stop |
| | r_comp_user.c | R_COMP_Create_UserInit R_COMPn_Interrupt |
| | r_cg_comp.h | - |
| Clock Output/Buzzer Output | r_pclbuz.c | R_PCLBUZn_Create R_PCLBUZn_Start R_PCLBUZn_Stop |
| | r_pclbuz_user.c | R_PCLBUZn_Create_UserInit |
| | r_cg_pclbuz.h | - |
| Data Transfer Controller | r_dtc.c | R_DTC_Create R_DTCn_Start R_DTCn_Stop R_DTC_Set_PowerOff |
| | r_dtc_user.c | R_DTC_Create_UserInit |
| | r_cg_dtc.h | - |
| Event Link Controller | r_elc.c | R_ELC_Create R_ELC_Stop |
| | r_elc_user.c | R_ELC_Create_UserInit |
| | r_cg_elc.h | - |
| DMA Controller | r_dmac.c | R_DMACn_Create R_DMACn_Start R_DMACn_Stop R_DMACn_SoftwareTriggerOn |
| | r_dmac_user.c | R_DMACn_Create_UserInit R_DMACn_Interrupt |
| | r_cg_dmac.h | - |
| Voltage Detector | r_lvd.c | R_LVD_Create R_LVD_InterruptMode_Start |
| | r_lvd_user.c | R_LVD_Create_UserInit R_LVD_Interrupt |
| | r_cg_lvd.h | - |

APPENDIX C API FUNCTIONS

This appendix describes the API functions output by the Code Generator.

C.1 Overview

Below are the naming conventions for API functions output by the Code Generator.

- Macro names are in ALL CAPS.
The number in front of the macro name is a hexadecimal value; this is the same value as the macro value.
- Local variable names are in all lower case.
- Global variable names start with a "g" and use Camel Case.
- Names of pointers to local variables start with a "p" and are in all lower case.
- Names of pointers to global variables start with a "gp" and use Camel Case.
- Names of elements in enum statements are in ALL CAPS.

C.2 Output Function

Below is a list of API functions output by the Code Generator.

Table C-1. API Function List

| Peripheral Function | API Function Name | Function |
|---------------------|------------------------|---|
| Clock Generator | R_CGC_Create | Performs initialization required to control the clock generator, on-chip debug and etc.. |
| | R_CGC_Create_UserInit | Performs user-defined initialization relating to the clock generator, on-chip debug, and etc.. |
| | R_CGC_Get_ResetSource | Performs processing in response to RESET signal. |
| | R_CGC_Set_ClockMode | Changes the CPU clock/peripheral hardware clock. |
| | R_CGC_Set_CRCOn | Starts the CRC operation function. |
| Port | R_PORT_Create | Performs initialization necessary to control port functions. |
| | R_PORT_Create_UserInit | Performs user-defined initialization relating to the port. |
| Interrupt | R_INTC_Create | Performs initialization necessary to control the external maskable interrupt INTP _n functions. |
| | R_INTC_Create_UserInit | Performs user-defined initialization relating to the external maskable interrupt INTP _n functions. |
| | R_INTCn_Interrupt | Performs processing in response to the external maskable interrupt INTP _n . |
| | R_INTCn_Start | Enables the acceptance of the external maskable interrupts INTP _n . |
| | R_INTCn_Stop | Disables the acceptance of the external maskable interrupts INTP _n . |
| | R_KEY_Create | Performs initialization necessary to control the key interrupt INTKR functions. |
| | R_KEY_Create_UserInit | Performs user-defined initialization relating to the key interrupt INTKR functions. |
| | R_KEY_Interrupt | Performs processing in response to the key interrupt INTKR. |

| Peripheral Function | API Function Name | Function |
|--------------------------|---|---|
| Interrupt | R_KEY_Start | Enables the acceptance of the key interrupts INTKR. |
| | R_KEY_Stop | Disables the acceptance of the key interrupts INTKR. |
| Serial | R_SAUm_Create | Performs initialization necessary to control the serial array unit and serial interface functions. |
| | R_SAUm_Create_UserInit | Performs user-defined initialization related to the serial array unit and serial interface functions. |
| | R_SAUm_Set_PowerOff | Halts the clock supplied to the serial array unit. |
| | R_SAU0_Set_SnoozeOn | Enables the switch from STOP mode to SNOOZE mode. |
| | R_SAU0_Set_SnoozeOff | Disables the switch from STOP mode to SNOOZE mode. |
| | R_UARTn_Create | Performs initialization of the serial interface (UART) channel. |
| | R_UARTn_Interrupt_Send | Performs processing in response to the UART transmission end interrupt INTST <i>n</i> . |
| | R_UARTn_Interrupt_Receive | Performs processing in response to the UART reception end interrupt INTSR <i>n</i> . |
| | R_UARTn_Interrupt_Error | Performs processing in response to the UART reception error interrupt INTSRE <i>n</i> . |
| | R_UARTn_Start | Sets UART communication to standby mode. |
| | R_UARTn_Stop | Ends UART communication. |
| | R_UARTn_Send | Starts UART data transmission. |
| | R_UARTn_Receive | Starts UART data reception. |
| | R_UARTn_Callback_SendEnd | Performs processing in response to the UART transmission end interrupt INTST <i>n</i> . |
| | R_UARTn_Callback_ReceiveEnd | Performs processing in response to the UART reception end interrupt INTSR <i>n</i> . |
| | R_UARTn_Callback_Error | Performs processing in response to the reception error interrupt INTSRE <i>n</i> . |
| | R_UARTn_Callback_SoftwareOverRun | Performs processing in response to detection of overrun error. |
| | R_CSImn_Create | Performs initialization of the serial interface (CSI) channel. |
| | R_CSImn_Interrupt | Performs processing in response to the CSI communication end interrupt INTCSImn. |
| | R_CSImn_Start | Sets CSI communication to standby mode. |
| | R_CSImn_Stop | Ends CSI communication. |
| | R_CSImn_Send | Starts CSI data transmission. |
| | R_CSImn_Receive | Starts CSI data reception. |
| R_CSImn_Send_Receive | Starts CSI data transmission/reception. | |
| R_CSImn_Callback_SendEnd | Performs processing in response to the CSI transmission end interrupt INTCSImn. | |

| Peripheral Function | API Function Name | Function |
|---------------------|------------------------------------|---|
| Serial | R_CSImn_Callback_ReceiveEnd | Performs processing in response to the CSI reception end interrupt INTCSImn. |
| | R_CSImn_Callback_Error | Performs processing in response to the CSI reception error interrupt INTSREn. |
| | R_IICmn_Create | Performs initialization of the serial interface (simple IIC) channel. |
| | R_IICmn_Interrupt | Performs processing in response to the simple IIC communication end interrupt INTIICmn. |
| | R_IICmn_StartCondition | Generates start conditions. |
| | R_IICmn_StopCondition | Generates stop conditions. |
| | R_IICmn_Stop | Ends simple IIC communication. |
| | R_IICmn_Master_Send | Starts simple IIC master transmission. |
| | R_IICmn_Master_Receive | Starts simple IIC master reception. |
| | R_IICmn_Callback_Master_SendEnd | Performs processing in response to the simple IICmn master transmission end interrupt INTIICmn. |
| | R_IICmn_Callback_Master_ReceiveEnd | Performs processing in response to the simple IICmn master reception end interrupt INTIICmn. |
| | R_IICmn_Callback_Master_Error | Performs processing in response to detection of parity error (ACK error). |
| | R_IICAn_Create | Performs initialization of the serial interface (IICA). |
| | R_IICAn_Create_UserInit | Performs user-defined initialization of the serial interface (IICA). |
| | R_IICAn_Interrupt | Performs processing in response to the IICA communication end interrupt INTIICAn. |
| | R_IICAn_StopCondition | Generates stop conditions. |
| | R_IICAn_Stop | Ends IICA communication. |
| | R_IICAn_Set_PowerOff | Halts the clock supplied to the serial interface (IICA). |
| | R_IICAn_Master_Send | Starts IICA master transmission. |
| | R_IICAn_Master_Receive | Starts IICA master reception. |
| | R_IICAn_Callback_Master_SendEnd | Performs processing in response to the IICA master transmission end interrupt INTIICAn. |
| | R_IICAn_Callback_Master_ReceiveEnd | Performs processing in response to the IICA master reception end interrupt INTIICAn. |
| | R_IICAn_Callback_Master_Error | Performs processing in response to detection of IICA master communication error. |
| | R_IICAn_Slave_Send | Starts IICA slave transmission. |
| | R_IICAn_Slave_Receive | Starts IICA slave reception. |
| | R_IICAn_Callback_Slave_SendEnd | Performs processing in response to the IICA slave transmission end interrupt INTIICAn. |
| | R_IICAn_Callback_Slave_ReceiveEnd | Performs processing in response to the IICA slave reception end interrupt INTIICAn. |

| Peripheral Function | API Function Name | Function |
|-----------------------|---|---|
| Serial | R_IICAn_Callback_Slave_Error | Performs processing in response to detection of IICA slave communication error. |
| | R_IICAn_Callback_GetStopCondition | Performs processing in response to detection of stop condition. |
| A/D Converter | R_ADC_Create | Performs initialization necessary to control A/D converter functions. |
| | R_ADC_Create_UserInit | Performs user-defined initialization relating to the A/D converter. |
| | R_ADC_Interrupt | Performs processing in response to the A/D conversion end interrupt INTAD. |
| | R_ADC_Set_ComparatorOn | Enables operation of voltage converter. |
| | R_ADC_Set_ComparatorOff | Disables operation of voltage converter. |
| | R_ADC_Start | Starts A/D conversion. |
| | R_ADC_Stop | Ends A/D conversion. |
| | R_ADC_Set_PowerOff | Halts the clock supplied to the A/D converter. |
| | R_ADC_Set_ADChannel | Configures the analog voltage input pin for A/D conversion. |
| | R_ADC_Set_SnoozeOn | Enables the switch from STOP mode to SNOOZE mode. |
| | R_ADC_Set_SnoozeOff | Disables the switch from STOP mode to SNOOZE mode. |
| | R_ADC_Set_TestChannel | Sets the operation mode of A/D converter. |
| | R_ADC_Get_Result | Reads the results of A/D conversion (10-bit). |
| R_ADC_Get_Result_8bit | Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution). | |
| D/A Converter | R_DAC_Create | Performs initialization necessary to control the D/A converter functions. |
| | R_DAC_Create_UserInit | Performs user-defined initialization relating to the D/A converter. |
| | R_DACn_Start | Starts D/A conversion. |
| | R_DACn_Stop | Ends D/A conversion. |
| | R_DAC_Set_PowerOff | Halts the clock supplied to the D/A converter. |
| | R_DACn_Set_ConversionValue | Sets the analog voltage output to the ANOn pin. |
| Timer | R_TAUm_Create | Performs initialization necessary to control timer array unit functions. |
| | R_TAUm_Create_UserInit | Performs user-defined initialization relating to the timer array unit. |
| | R_TAUm_Channeln_Interrupt | Performs processing in response to the timer interrupt INTTmn. |
| | R_TAUm_Channeln_Higher8bits_Interrupt | Performs processing in response to the timer interrupt INTTmnH. |
| | R_TAUm_Channeln_Start | Starts the count for channel <i>n</i> . |

| Peripheral Function | API Function Name | Function |
|---------------------|-----------------------------------|---|
| Timer | R_TAUm_Channeln_Higher8bits_Start | Starts the count (higher 8-bit) for channel 1 or channel 3. |
| | R_TAUm_Channeln_Lower8bits_Start | Starts the count (lower 8-bit) for channel 1 or channel 3. |
| | R_TAUm_Channeln_Stop | Ends the count for channel <i>n</i> . |
| | R_TAUm_Channeln_Higher8bits_Stop | Ends the count (higher 8-bit) for channel 1 or channel 3. |
| | R_TAUm_Channeln_Lower8bits_Stop | Ends the count (lower 8-bit) for channel 1 or channel 3. |
| | R_TAUm_Set_PowerOff | Halts the clock supplied to the timer array unit. |
| | R_TAUm_Channeln_Get_PulseWidth | Captures the high/low-level width measured between pulses of the signal (pulses) input to the <i>Tl_mn</i> pin. |
| | R_TAUm_Channeln_SoftwareTriggerOn | Generates the trigger (software trigger) for one-shot pulse output. |
| | R_TMR_RDn_Create | Performs initialization necessary to control the timer RD <i>n</i> functions. |
| | R_TMR_RDn_Create_UserInit | Performs user-defined initialization relating to the timer RD <i>n</i> . |
| | R_TMR_RDn_Interrupt | Performs processing in response to the timer interrupt. |
| | R_TMR_RDn_Start | Starts the count for timer RD <i>n</i> . |
| | R_TMR_RDn_Stop | Ends the count for timer RD <i>n</i> . |
| | R_TMR_RDn_Set_PowerOff | Halts the clock supplied to the timer RD <i>n</i> . |
| | R_TMR_RDn_Get_PulseWidth | Reads the pulse width of the timer RD <i>n</i> . |
| | R_TMR_RGn_Create | Performs initialization necessary to control the timer RG <i>n</i> functions. |
| | R_TMR_RGn_Create_UserInit | Performs user-defined initialization relating to the timer RG <i>n</i> . |
| | R_TMR_RGn_Interrupt | Performs processing in response to the timer interrupt. |
| | R_TMR_RGn_Start | Starts the count for timer RG <i>n</i> . |
| | R_TMR_RGn_Stop | Ends the count for timer RG <i>n</i> . |
| | R_TMR_RGn_Set_PowerOff | Halts the clock supplied to the timer RG <i>n</i> . |
| | R_TMR_RGn_Get_PulseWidth | Reads the pulse width of the timer RG <i>n</i> . |
| | R_TMR_RJ0_Create | Performs initialization necessary to control the timer RJ0 functions. |
| | R_TMR_RJ0_Create_UserInit | Performs user-defined initialization relating to the timer RJ0. |
| | R_TMR_RJ0_Interrupt | Performs processing in response to the timer interrupt. |
| | R_TMR_RJ0_Start | Starts the count for timer RJ0. |
| | R_TMR_RJ0_Stop | Ends the count for timer RJ0. |
| | R_TMR_RJ0_Set_PowerOff | Halts the clock supplied to the timer RJ0. |
| | R_TMR_RJ0_Get_PulseWidth | Reads the pulse width of the timer RJ0. |
| | Watchdog Timer | R_WDT_Create |

| Peripheral Function | API Function Name | Function |
|----------------------|-----------------------------------|---|
| Watchdog Timer | R_WDT_Create_UserInit | Performs user-defined initialization relating to the watchdog timer. |
| | R_WDT_Interrupt | Performs processing in response to the interval interrupt INTWDTI of watchdog timer. |
| | R_WDT_Restart | Clears the watchdog timer counter and resumes counting. |
| Real-time Clock | R_RTC_Create | Performs initialization necessary to control real-time clock functions. |
| | R_RTC_Create_UserInit | Performs user-defined initialization relating to the real-time clock. |
| | R_RTC_Interrupt | Performs processing in response to the real-time clock interrupt INTRTC. |
| | R_RTC_Start | Starts the count of the real-time clock (year, month, weekday, day, hour, minute, second). |
| | R_RTC_Stop | Ends the count of the real-time clock (year, month, weekday, day, hour, minute, second). |
| | R_RTC_Set_PowerOff | Halts the clock supplied to the real-time clock. |
| | R_RTC_Set_HourSystem | Sets the clock type (12-hour or 24-hour clock) of the real-time clock. |
| | R_RTC_Set_CounterValue | Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock. |
| | R_RTC_Get_CounterValue | Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock. |
| | R_RTC_Set_ConstPeriodInterruptOn | Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function. |
| | R_RTC_Set_ConstPeriodInterruptOff | Ends the cyclic interrupt function. |
| | R_RTC_Callback_ConstPeriod | Performs processing in response to the cyclic interrupt INTRTC. |
| | R_RTC_Set_AlarmOn | Starts the alarm interrupt function. |
| | R_RTC_Set_AlarmOff | Ends the alarm interrupt function. |
| | R_RTC_Set_AlarmValue | Sets the alarm conditions (weekday, hour, minute). |
| | R_RTC_Get_AlarmValue | Reads the alarm conditions (weekday, hour, minute). |
| | R_RTC_Callback_Alarm | Performs processing in response to the alarm interrupt INTRTC. |
| | R_RTC_Set_RTC1HZOn | Enables output of the correction clock (1 Hz) to the RTC1HZ pin. |
| | R_RTC_Set_RTC1HZOff | Disables output of the correction clock (1 Hz) to the RTC1HZ pin. |
| | Interval Timer | R_IT_Create |
| R_IT_Create_UserInit | | Performs user-defined initialization relating to the interval timer. |
| R_IT_Interrupt | | Performs processing in response to the interval timer interrupt INTIT. |


| Peripheral Function | API Function Name | Function |
|--------------------------------|---------------------------|---|
| Interval Timer | R_IT_Start | Starts the count of the interval timer. |
| | R_IT_Stop | Ends the count of the interval timer. |
| | R_IT_Set_PowerOff | Halts the clock supplied to the interval timer. |
| Comparator | R_COMP_Create | Performs initialization necessary to control the comparator functions. |
| | R_COMP_Create_UserInit | Performs user-defined initialization relating to the comparator. |
| | R_COMPn_Interrupt | Performs processing in response to the comparator interrupt <i>INTCMPn</i> . |
| | R_COMPn_Start | Begins comparison of reference input voltage and analog input voltage. |
| | R_COMPn_Stop | Stops comparison of reference input voltage and analog input voltage. |
| Clock Output/ Buzzer Output | R_PCLBUZn_Create | Performs initialization necessary to control clock/buzzer output control circuit functions. |
| | R_PCLBUZn_Create_UserInit | Performs user-defined initialization relating to the clock/buzzer output control circuits. |
| | R_PCLBUZn_Start | Starts clock/buzzer output. |
| | R_PCLBUZn_Stop | Ends clock/buzzer output. |
| Data Transfer Controller | R_DTC_Create | Performs initialization necessary to control the data transfer controller functions. |
| | R_DTC_Create_UserInit | Performs user-defined initialization relating to the data transfer controller. |
| | R_DTCn_Start | Enables operation of the data transfer controller. |
| | R_DTCn_Stop | Disables operation of the data transfer controller. |
| | R_DTC_Set_PowerOff | Halts the clock supplied to the data transfer controller. |
| Event Link Controller | R_ELC_Create | Performs initialization necessary to control the event link controller functions. |
| | R_ELC_Create_UserInit | Performs user-defined initialization relating to the event link controller. |
| | R_ELC_Stop | Disables operation of the event link controller. |
| DMA Controller | R_DMACn_Create | Performs initialization necessary to control DMA controller functions. |
| | R_DMACn_Create_UserInit | Performs user-defined initialization relating to the DMA controller. |
| | R_DMACn_Interrupt | This API function is called as the interrupt process corresponding to the interval interrupt <i>INTWDTI</i> . |
| | R_DMACn_Start | Enables operation of channel <i>n</i> . |
| | R_DMACn_Stop | Disables operation of channel <i>n</i> . |
| | R_DMACn_SoftwareTriggerOn | Starts DMA transfer when DMA operation is enabled. |
| Voltage Detector | R_LVD_Create | Performs initialization necessary to control voltage detector functions. |

| Peripheral Function | API Function Name | Function |
|---------------------|---|--|
| Voltage Detector | R_LVD_Create_UserInit | Performs user-defined initialization relating to the voltage detector. |
| | R_LVD_Interrupt | Performs processing in response to the voltage detection interrupt INTLVI. |
| | R_LVD_InterruptMode_Start | Starts voltage detection (when in interrupt mode, and interrupt & reset mode). |

C.3 Function Reference

This section describes the API functions output by the Code Generator, using the following notation format.

Figure C-1. Notation Format of API Functions



(1) **Name**

Indicates the name of the API function.

(2) **Outline**

Outlines the functions of the API function.

(3) **[Classification]**

Indicates the name of the C source file to which the API function is output.

(4) **[Syntax]**

Indicates the format to be used when describing an API function to be called in C language.

(5) [Argument(s)]

API function arguments are explained in the following format.

| I/O | Argument | Description |
|-----|----------|-------------|
| (a) | (b) | (c) |

(a) I/O

Argument classification

I ... Input argument

O ... Output argument

(b) Argument

Argument data type

(c) Description

Description of argument

(6) [Return value]

API function return value is explained in the following format.

| Macro | Description |
|-------|-------------|
| (a) | (b) |

(a) Macro

Macro of return value

(b) Description

Description of return value

(7) [Example]

Shows an example of the API function in use.

C.3.1 Clock Generator

Below is a list of API functions output by the Code Generator for clock generator use.

Table C-2. API Functions: [Clock Generator]

| API Function Name | Function |
|---------------------------------------|--|
| R_CGC_Create | Performs initialization required to control the clock generator, on-chip debug and etc.. |
| R_CGC_Create_UserInit | Performs user-defined initialization relating to the clock generator, on-chip debug, and etc.. |
| R_CGC_Get_ResetSource | Performs processing in response to RESET signal. |
| R_CGC_Set_ClockMode | Changes the CPU clock/peripheral hardware clock. |
| R_CGC_Set_CRCOn | Starts the CRC operation function. |

R_CGC_Create

Performs initialization required to control the clock generator, on-chip debug and etc..

[Classification]

r_cgc.c

[Syntax]

```
void R_CGC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_CGC_Create_UserInit

Performs user-defined initialization relating to the clock generator, on-chip debug, and etc..

Remark This API function is called as the [R_CGC_Create](#) callback routine.

[Classification]

r_cgc_user.c

[Syntax]

```
void R_CGC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_CGC_Get_ResetSource

Performs processing in response to RESET signal.

[Classification]

r_cgc_user.c

[Syntax]

```
void R_CGC_Get_ResetSource ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_CGC_Set_ClockMode

Changes the CPU clock/peripheral hardware clock.

[Classification]

r_cgc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_cgc.h"
MD_STATUS R_CGC_Set_ClockMode ( enum ClockMode mode );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------------|---|
| I | enum ClockMode mode ; | Clock generator type HIOCLK: High-speed onchip oscillator SYSX1CLK: X1 clock SYSEXTCLK: External main system clock |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ERROR1 | Exit with error (abend) |
| MD_ERROR2 | Exit with error (abend) |
| MD_ERROR3 | Exit with error (abend) |
| MD_ERROR4 | Exit with error (abend) |
| MD_ARGERROR | Invalid argument specification |

R_CGC_Set_CRCOn

Starts the CRC operation function.

[Classification]

r_cgc.c

[Syntax]

```
void R_CGC_Set_CRCOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.2 Port

Below is a list of API functions output by the Code Generator for port use.

Table C-3. API Functions: [Port]

| API Function Name | Function |
|--|--|
| R_PORT_Create | Performs initialization necessary to control port functions. |
| R_PORT_Create_UserInit | Performs user-defined initialization relating to the port. |

R_PORT_Create

Performs initialization necessary to control port functions.

[Classification]

r_port.c

[Syntax]

```
void R_PORT_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_PORT_Create_UserInit

Performs user-defined initialization relating to the port.

Remark This API function is called as the [R_PORT_Create](#) callback routine.

[Classification]

r_port_user.c

[Syntax]

```
void R_PORT_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.3 Interrupt

Below is a list of API functions output by the Code Generator for interrupt and key interrupt use.

Table C-4. API Functions: [Interrupt]

| API Function Name | Function |
|--|--|
| R_INTC_Create | Performs initialization necessary to control the external maskable interrupt INTP n functions. |
| R_INTC_Create_UserInit | Performs user-defined initialization relating to the external maskable interrupt INTP n functions. |
| R_INTCn_Interrupt | Performs processing in response to the external maskable interrupt INTP n . |
| R_INTCn_Start | Enables the acceptance of the external maskable interrupts INTP n . |
| R_INTCn_Stop | Disables the acceptance of the external maskable interrupts INTP n . |
| R_KEY_Create | Performs initialization necessary to control the key interrupt INTKR functions. |
| R_KEY_Create_UserInit | Performs user-defined initialization relating to the key interrupt INTKR functions. |
| R_KEY_Interrupt | Performs processing in response to the key interrupt INTKR. |
| R_KEY_Start | Enables the acceptance of the key interrupts INTKR. |
| R_KEY_Stop | Disables the acceptance of the key interrupts INTKR. |

R_INTC_Create

Performs initialization necessary to control the external maskable interrupt INTP n functions.

[Classification]

r_intc.c

[Syntax]

```
void R_INTC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_INTC_Create_UserInit

Performs user-defined initialization relating to the external maskable interrupt INTP n functions.

Remark This API function is called as the [R_INTC_Create](#) callback routine.

[Classification]

r_intc_user.c

[Syntax]

```
void R_INTC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_INTC n _Interrupt

Performs processing in response to the external maskable interrupt INTP n .

Remark This API function is called as the interrupt process corresponding to the external maskable interrupt INTP n .

[Classification]

r_intc_user.c

[Syntax]

```
void R_INTC $n$ _Interrupt ( void );
```

Remark n is the interrupt factor number.

[Argument(s)]

None.

[Return value]

None.

R_INTC n _Start

Enables the acceptance of the external maskable interrupts INTP n .

[Classification]

r_intc.c

[Syntax]

```
void R_INTC $n$ _Start ( void );
```

Remark n is the interrupt factor number.

[Argument(s)]

None.

[Return value]

None.

R_INTC n _Stop

Disables the acceptance of the external maskable interrupts INTP n .

[Classification]

r_intc.c

[Syntax]

```
void R_INTC $n$ _Stop ( void );
```

Remark n is the interrupt factor number.

[Argument(s)]

None.

[Return value]

None.

R_KEY_Create

Performs initialization necessary to control the key interrupt INTKR functions.

[Classification]

r_intc.c

[Syntax]

```
void R_KEY_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_KEY_Create_UserInit

Performs user-defined initialization relating to the key interrupt INTKR functions.

Remark This API function is called as the [R_KEY_Create](#) callback routine.

[Classification]

r_intc_user.c

[Syntax]

```
void R_KEY_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_KEY_Interrupt

Performs processing in response to the key interrupt INTKR.

Remark This API function is called as the interrupt process corresponding to the key interrupt INTKR.

[Classification]

r_intc_user.c

[Syntax]

```
void R_KEY_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_KEY_Start

Enables the acceptance of the key interrupts INTKR.

[Classification]

r_intc.c

[Syntax]

```
void R_KEY_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_KEY_Stop

Disables the acceptance of the key interrupts INTKR.

[Classification]

r_intc.c

[Syntax]

```
void R_KEY_Stop ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.4 Serial

Below is a list of API functions output by the Code Generator for serial array unit and serial interface use.

Table C-5. API Functions: [Serial]

| API Function Name | Function |
|----------------------------------|---|
| R_SAUm_Create | Performs initialization necessary to control the serial array unit and serial interface functions. |
| R_SAUm_Create_UserInit | Performs user-defined initialization related to the serial array unit and serial interface functions. |
| R_SAUm_Set_PowerOff | Halts the clock supplied to the serial array unit. |
| R_SAU0_Set_SnoozeOn | Enables the switch from STOP mode to SNOOZE mode. |
| R_SAU0_Set_SnoozeOff | Disables the switch from STOP mode to SNOOZE mode. |
| R_UARTn_Create | Performs initialization of the serial interface (UART) channel. |
| R_UARTn_Interrupt_Send | Performs processing in response to the UART transmission end interrupt INTST n . |
| R_UARTn_Interrupt_Receive | Performs processing in response to the UART reception end interrupt INTSR n . |
| R_UARTn_Interrupt_Error | Performs processing in response to the reception error interrupt INTSRE n . |
| R_UARTn_Start | Sets UART communication to standby mode. |
| R_UARTn_Stop | Ends UART communication. |
| R_UARTn_Send | Starts UART data transmission. |
| R_UARTn_Receive | Starts UART data reception. |
| R_UARTn_Callback_SendEnd | Performs processing in response to the UART transmission end interrupt INTST n . |
| R_UARTn_Callback_ReceiveEnd | Performs processing in response to the UART reception end interrupt INTSR n . |
| R_UARTn_Callback_Error | Performs processing in response to the UART reception error interrupt INTSRE n . |
| R_UARTn_Callback_SoftwareOverRun | Performs processing in response to detection of overrun error. |
| R_CSImn_Create | Performs initialization of the serial interface (CSI) channel. |
| R_CSImn_Interrupt | Performs processing in response to the CSI communication end interrupt INTCSIm n . |
| R_CSImn_Start | Sets CSI communication to standby mode. |
| R_CSImn_Stop | Ends CSI communication. |
| R_CSImn_Send | Starts CSI data transmission. |
| R_CSImn_Receive | Starts CSI data reception. |
| R_CSImn_Send_Receive | Starts CSI data transmission/reception. |
| R_CSImn_Callback_SendEnd | Performs processing in response to the CSI transmission end interrupt INTCSIm n . |
| R_CSImn_Callback_ReceiveEnd | Performs processing in response to the CSI reception end interrupt INTCSIm n . |
| R_CSImn_Callback_Error | Performs processing in response to the CSI reception error interrupt INTSRE n . |
| R_IICmn_Create | Performs initialization of the serial interface (simple IIC) channel. |
| R_IICmn_Interrupt | Performs processing in response to the simple IIC communication end interrupt INTIICm n . |

| API Function Name | Function |
|------------------------------------|---|
| R_IICmn_StartCondition | Generates start conditions. |
| R_IICmn_StopCondition | Generates stop conditions. |
| R_IICmn_Stop | Ends simple IIC communication. |
| R_IICmn_Master_Send | Starts simple IIC master transmission. |
| R_IICmn_Master_Receive | Starts simple IIC master reception. |
| R_IICmn_Callback_Master_SendEnd | Performs processing in response to the simple IICmn master transmission end interrupt INTIICmn. |
| R_IICmn_Callback_Master_ReceiveEnd | Performs processing in response to the simple IICmn master reception end interrupt INTIICmn. |
| R_IICmn_Callback_Master_Error | Performs processing in response to detection of parity error (ACK error). |
| R_IICAn_Create | Performs initialization of the serial interface (IICA). |
| R_IICAn_Create_UserInit | Performs user-defined initialization of the serial interface (IICA). |
| R_IICAn_Interrupt | Performs processing in response to the IICA communication end interrupt INTIICAn. |
| R_IICAn_StopCondition | Generates stop conditions. |
| R_IICAn_Stop | Ends IICA communication. |
| R_IICAn_Set_PowerOff | Halts the clock supplied to the serial interface (IICA). |
| R_IICAn_Master_Send | Starts IICA master transmission. |
| R_IICAn_Master_Receive | Starts IICA master reception. |
| R_IICAn_Callback_Master_SendEnd | Performs processing in response to the IICA master transmission end interrupt INTIICAn. |
| R_IICAn_Callback_Master_ReceiveEnd | Performs processing in response to the IICA master reception end interrupt INTIICAn. |
| R_IICAn_Callback_Master_Error | Performs processing in response to detection of IICA master communication error. |
| R_IICAn_Slave_Send | Starts IICA slave transmission. |
| R_IICAn_Slave_Receive | Starts IICA slave reception. |
| R_IICAn_Callback_Slave_SendEnd | Performs processing in response to the IICA slave transmission end interrupt INTIICAn. |
| R_IICAn_Callback_Slave_ReceiveEnd | Performs processing in response to the IICA slave reception end interrupt INTIICAn. |
| R_IICAn_Callback_Slave_Error | Performs processing in response to detection of IICA slave communication error. |
| R_IICAn_Callback_GetStopCondition | Performs processing in response to detection of stop condition. |

R_SAUm_Create

Performs initialization necessary to control the serial array unit and serial interface functions.

[Classification]

r_serial.c

[Syntax]

```
void R_SAUm_Create ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_SAUm_Create_UserInit

Performs user-defined initialization related to the serial array unit and serial interface functions.

Remark This API function is called as the [R_SAUm_Create](#) callback routine.

[Classification]

r_serial_user.c

[Syntax]

```
void R_SAUm_Create_UserInit ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_SAUm_Set_PowerOff

Halts the clock supplied to the serial array unit.

Remark Calling this API function changes the serial array unit to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_serial.c

[Syntax]

```
void R_SAUm_Set_PowerOff ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_SAU0_Set_SnoozeOn

Enables the switch from STOP mode to SNOOZE mode.

[Classification]

r_serial.c

[Syntax]

```
void R_SAU0_Set_SnoozeOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_SAU0_Set_SnoozeOff

Disables the switch from STOP mode to SNOOZE mode.

[Classification]

r_serial.c

[Syntax]

```
void R_SAU0_Set_SnoozeOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Create

Performs initialization of the serial interface (UART) channel.

Remark This API function is used as an internal function of [R_SAUm_Create](#). For this reason, there is normally no need to call it from a user program.

[Classification]

r_serial.c

[Syntax]

```
void R_UARTn_Create ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Interrupt_Send

Performs processing in response to the UART transmission end interrupt INTST*n*.

Remark This API function is called as the interrupt process corresponding to the UART transmission end interrupt INTST*n*.

[Classification]

r_serial_user.c

[Syntax]

```
void R_UARTn_Interrupt_Send ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Interrupt_Receive

Performs processing in response to the UART reception end interrupt INTSR*n*.

Remark This API function is called as the interrupt process corresponding to the UART reception end interrupt INTSR*n*.

[Classification]

r_serial_user.c

[Syntax]

```
void R_UARTn_Interrupt_Receive ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Interrupt_Error

Performs processing in response to the UART reception error interrupt INTSRE*n*.

Remark This API function is called as the interrupt process corresponding to the UART reception error interrupt INTSRE*n*.

[Classification]

r_serial_user.c

[Syntax]

```
void R_UARTn_Interrupt_Error ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Start

Sets UART communication to standby mode.

[Classification]

r_serial.c

[Syntax]

```
void R_UARTn_Start ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UART*n*_Stop

Ends UART communication.

[Classification]

r_serial.c

[Syntax]

```
void R_UARTn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UARTn_Send

Starts UART data transmission.

- Remarks 1.** This API function repeats the byte-level UART transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** When performing a UART transmission, [R_UARTn_Start](#) must be called before this API function is called.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_UARTn_Send ( uint8_t *txbuf, uint16_t txnum );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| I | uint8_t * <i>txbuf</i> ; | Pointer to a buffer storing the transmission data |
| I | uint16_t <i>txnum</i> ; | Total amount of data to send |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_UARTn_Receive

Starts UART data reception.

- Remarks 1.** This API function performs byte-level UART reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 2.** Actual UART reception starts after this API function is called, and [R_UARTn_Start](#) is then called.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_UARTn_Receive ( uint8_t *rxbuf, uint16_t rxnum );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|--|
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |
| I | uint16_t <i>rxnum</i> ; | Total amount of data to receive |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_UART*n*_Callback_SendEnd

Performs processing in response to the UART transmission end interrupt INTST*n*.

Remark This API function is called as the callback routine of interrupt process [R_UART*n*_Interrupt_Send](#) corresponding to the UART transmission end interrupt INTST*n* (performed when number of transmission data specified by [R_UART*n*_Send](#) parameter *txnum* has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_UARTn_Callback_SendEnd ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UARTn_Callback_ReceiveEnd

Performs processing in response to the UART reception end interrupt INTSR n .

Remark This API function is called as the callback routine of interrupt process [R_UARTn_Interrupt_Receive](#) corresponding to the UART reception end interrupt INTSR n (performed when number of received data specified by [R_UARTn_Receive](#) parameter $rxnum$ has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_UARTn_Callback_ReceiveEnd ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_UARTn_Callback_Error

Performs processing in response to the reception error interrupt INTSRE n .

Remark This API function is called as the callback routine of interrupt process [R_UARTn_Interrupt_Error](#) corresponding to the reception error interrupt INTSRE n .

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_UARTn_Callback_Error ( uint8_t err_type );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|---------------------------|--|
| O | uint8_t <i>err_type</i> ; | Trigger for error interrupt 00000xx1B: Overrun error 00000x1xB: Parity error 000001xxB: Framing error |

[Return value]

None.

R_UARTn_Callback_SoftwareOverRun

Performs processing in response to detection of overrun error.

Remark This API function is called as the callback routine of interrupt process [R_UARTn_Interrupt_Receive](#) corresponding to the UART reception end interrupt INTSRn (process performed when the amount of data received is greater than the parameter *rxnum* specified for [R_UARTn_Receive](#)).

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_UARTn_Callback_SoftwareOverRun ( uint16_t rx_data );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|---------------------------|---|
| O | uint16_t <i>rx_data</i> ; | Receive data (greater than the parameter <i>rxnum</i> specified for R_UARTn_Receive) |

[Return value]

None.

R_CSImn_Create

Performs initialization of the serial interface (CSI) channel.

Remark This API function is used as an internal function of [R_SAUm_Create](#). For this reason, there is normally no need to call it from a user program.

[Classification]

r_serial.c

[Syntax]

```
void R_CSImn_Create ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Interrupt

Performs processing in response to the CSI communication end interrupt INTCSImn.

Remark This API function is called as the interrupt process corresponding to the CSI communication end interrupt INTCSImn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_CSImn_Interrupt ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Start

Sets CSI communication to standby mode.

[Classification]

r_serial.c

[Syntax]

```
void R_CSImn_Start ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Stop

Ends CSI communication.

[Classification]

r_serial.c

[Syntax]

```
void R_CSImn_Stop ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Send

Starts CSI data transmission.

- Remarks 1.** This API function repeats the byte-level CSI transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** When performing a CSI transmission, [R_CSImn_Start](#) must be called before this API function is called.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_CSImn_Send ( uint8_t *txbuf, uint16_t txnum );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------|---|
| I | uint8_t *txbuf; | Pointer to a buffer storing the transmission data |
| I | uint16_t txnum; | Total amount of data to send |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_CSImn_Receive

Starts CSI data reception.

- Remarks 1.** This API function performs byte-level CSI reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 2.** When performing a CSI reception, [R_CSImn_Start](#) must be called before this API function is called.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_CSImn_Receive ( uint8_t *rxbuf, uint16_t rxnum );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|--|
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |
| I | uint16_t <i>rxnum</i> ; | Total amount of data to receive |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_CSImn_Send_Receive

Starts CSI data transmission/reception.

- Remarks 1.** This API function repeats the byte-level CSI transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** This API function performs byte-level CSI reception the number of times specified by the parameter *txnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 3.** When performing a CSI reception, [R_CSImn_Start](#) must be called before this API function is called.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_CSImn_Send_Receive ( uint8_t *txbuf, uint16_t txnum, uint8_t *rxbuf );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| I | uint8_t * <i>txbuf</i> ; | Pointer to a buffer storing the transmission data |
| I | uint16_t <i>txnum</i> ; | Total amount of data to send/receive |
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_CSImn_Callback_SendEnd

Performs processing in response to the CSI transmission end interrupt INTCSImn.

Remark This API function is called as the callback routine of interrupt process [R_CSImn_Interrupt](#) corresponding to the CSI transmission end interrupt INTCSImn (performed when number of transmission data specified by [R_CSImn_Send](#) or [R_CSImn_Send_Receive](#) parameter *txnum* has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_CSImn_Callback_SendEnd ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Callback_ReceiveEnd

Performs processing in response to the CSI reception end interrupt INTCSImn.

Remark This API function is called as the callback routine of interrupt process [R_CSImn_Interrupt](#) corresponding to the CSI reception end interrupt INTCSImn (performed when number of received data specified by [R_CSImn_Receive](#) or [R_CSImn_Send_Receive](#) parameter *rxnum* has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_CSImn_Callback_ReceiveEnd ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_CSImn_Callback_Error

Performs processing in response to the CSI reception error interrupt INTSRE n .

Remark This API function is called as the callback routine of interrupt process [R_UARTn_Interrupt_Error](#) corresponding to the CSI reception error interrupt INTSRE n .

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_CSImn_Callback_Error ( uint8_t err_type );
```

Remark m is the unit number, and n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|---------------------------|--|
| O | uint8_t <i>err_type</i> ; | Trigger for error interrupt 0000xx1B: Overrun error |

[Return value]

None.

R_IICmn_Create

Performs initialization of the serial interface (simple IIC) channel.

Remark This API function is used as an internal function of [R_SAUm_Create](#). For this reason, there is normally no need to call it from a user program.

[Classification]

r_serial.c

[Syntax]

```
void R_IICmn_Create ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_Interrupt

Performs processing in response to the simple IIC communication end interrupt INTIICmn.

Remark This API function is called as the interrupt process corresponding to the simple IIC communication end interrupt INTIICmn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICmn_Interrupt ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_StartCondition

Generates start conditions.

Remark This API function is used as an internal function of [R_IICmn_Master_Send](#) and [R_IICmn_Master_Receive](#). For this reason, there is normally no need to call it from a user program.

[Classification]

r_serial.c

[Syntax]

```
void R_IICmn_StartCondition ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_StopCondition

Generates stop conditions.

[Classification]

r_serial.c

[Syntax]

```
void R_IICmn_StopCondition ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_Stop

Ends simple IIC communication.

[Classification]

r_serial.c

[Syntax]

```
void R_IICmn_Stop ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_Master_Send

Starts simple IIC master transmission.

Remark This API function repeats the byte-level simple IIC master transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

[Classification]

r_serial.c

[Syntax]


```
#include "r_cg_macrodriver.h"
void R_IICmn_Master_Send ( uint8_t adr, uint8_t *txbuf, uint16_t txnum );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| I | uint8_t <i>adr</i> ; | Device address |
| I | uint8_t * <i>txbuf</i> ; | Pointer to a buffer storing the transmission data |
| I | uint16_t <i>txnum</i> ; | Total amount of data to send |

Remark Below is shown the format for specifying device address *adr*.



[Return value]

None.

R_IICmn_Master_Receive

Starts simple IIC master reception.

Remark This API function performs byte-level simple IIC master reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

[Classification]

r_serial.c

[Syntax]


```
#include "r_cg_macrodriver.h"
void R_IICmn_Master_Receive ( uint8_t adr, uint8_t *rxbuf, uint16_t rxnum );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|--|
| I | uint8_t <i>adr</i> ; | Device address |
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |
| I | uint16_t <i>rxnum</i> ; | Total amount of data to receive |

Remark Below is shown the format for specifying device address *adr*.



[Return value]

None.

R_IICmn_Callback_Master_SendEnd

Performs processing in response to the simple IICmn master transmission end interrupt INTIICmn.

Remark This API function is called as the callback routine of interrupt process [R_IICmn_Interrupt](#) corresponding to the simple IICmn master transmission end interrupt INTIICmn (performed when number of transmission data specified by [R_IICmn_Master_Send](#) parameter *txnum* has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICmn_Callback_Master_SendEnd ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_Callback_Master_ReceiveEnd

Performs processing in response to the simple IICmn master reception end interrupt INTIICmn.

Remark This API function is called as the callback routine of interrupt process [R_IICmn_Interrupt](#) corresponding to the simple IICmn master reception end interrupt INTIICmn (performed when number of received data specified by [R_IICmn_Master_Receive](#) parameter *rxnum* has been completed).

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICmn_Callback_Master_ReceiveEnd ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICmn_Callback_Master_Error

Performs processing in response to detection of parity error (ACK error).

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_IICmn_Callback_Master_Error ( MD_STATUS flag );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-------------------------|---|
| O | MD_STATUS <i>flag</i> ; | Cause of communication error MD_NACK: Acknowledge not detected |

[Return value]

None.

R_IICAn_Create

Performs initialization of the serial interface (IICA).

Remark This API function is used as an internal function of [R_SAUm_Create](#). For this reason, there is normally no need to call it from a user program.

[Classification]

r_serial.c

[Syntax]

```
void R_IICAn_Create ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Create_UserInit

Performs user-defined initialization of the serial interface (IICA).

Remark This API function is called as the [R_IICAn_Create](#) callback routine.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Create_UserInit ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Interrupt

Performs processing in response to the IICA communication end interrupt INTIICAn.

Remark This API function is called as the interrupt process corresponding to the IICA communication end interrupt INTIICAn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Interrupt ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_StopCondition

Generates stop conditions.

[Classification]

r_serial.c

[Syntax]

```
void R_IICAn_StopCondition ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Stop

Ends IICA communication.

[Classification]

r_serial.c

[Syntax]

```
void R_IICAn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Set_PowerOff

Halts the clock supplied to the serial interface (IICA).

Remark Calling this API function changes the serial interface (IICA) to reset status. For this reason, writes to the control registers (e.g. IICA control register n : IICCTL n) after this API function is called are ignored.

[Classification]

r_serial.c

[Syntax]

```
void R_IICAn_Set_PowerOff ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Master_Send

Starts IICA master transmission.

Remark This API function repeats the byte-level IICA master transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_IICAn_Master_Send ( uint8_t adr, uint8_t *txbuf, uint16_t txnum, uint8_t wait );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| I | uint8_t <i>adr</i> ; | Slave address |
| I | uint8_t * <i>txbuf</i> ; | Pointer to a buffer storing the transmission data |
| I | uint16_t <i>txnum</i> ; | Total amount of data to send |
| I | uint8_t <i>wait</i> ; | Setup time of start conditions |

[Return value]

| Macro | Description |
|-----------|--------------------------|
| MD_OK | Normal completion |
| MD_ERROR1 | Bus communication status |
| MD_ERROR2 | Bus not released status |

R_IICAn_Master_Receive

Starts IICA master reception.

Remark This API function performs byte-level IICA master reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
MD_STATUS R_IICAn_Master_Receive ( uint8_t adr, uint8_t *rxbuf, uint16_t rxnum, uint8_t wait
);
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|--|
| I | uint8_t <i>adr</i> ; | Slave address |
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |
| I | uint16_t <i>rxnum</i> ; | Total amount of data to receive |
| I | uint8_t <i>wait</i> ; | Setup time of start conditions |

[Return value]

| Macro | Description |
|-----------|--------------------------|
| MD_OK | Normal completion |
| MD_ERROR1 | Bus communication status |
| MD_ERROR2 | Bus not released status |

R_IICAn_Callback_Master_SendEnd

Performs processing in response to the IICA master transmission end interrupt INTIICAn.

Remark This API function is called as the callback routine of interrupt process [R_IICAn_Interrupt](#) corresponding to the IICA master transmission end interrupt INTIICAn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Callback_Master_SendEnd ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Callback_Master_ReceiveEnd

Performs processing in response to the IICA master reception end interrupt INTIICAn.

Remark This API function is called as the callback routine of interrupt process [R_IICAn_Interrupt](#) corresponding to the IICA master reception end interrupt INTIICAn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Callback_Master_ReceiveEnd ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Callback_Master_Error

Performs processing in response to detection of IICA master communication error.

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_IICAn_Callback_Master_Error ( MD_STATUS flag );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------|--|
| I | MD_STATUS flag; | Cause of communication error MD_SPT: Stop condition detected MD_NACK: Acknowledge not detected |

[Return value]

None.

R_IICAn_Slave_Send

Starts IICA slave transmission.

Remark This API function repeats the byte-level IICA slave transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_IICAn_Slave_Send ( uint8_t *txbuf, uint16_t txnum );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------|---|
| I | uint8_t *txbuf; | Pointer to a buffer storing the transmission data |
| I | uint16_t txnum; | Total amount of data to send |

[Return value]

None.

R_IICAn_Slave_Receive

Starts IICA slave reception.

Remark This API function performs byte-level IICA slave reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

[Classification]

r_serial.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_IICAn_Slave_Receive ( uint8_t *rxbuf, uint16_t rxnum );
```

Remark *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|--|
| O | uint8_t * <i>rxbuf</i> ; | Pointer to a buffer to store the received data |
| I | uint16_t <i>rxnum</i> ; | Total amount of data to receive |

[Return value]

None.

R_IICAn_Callback_Slave_SendEnd

Performs processing in response to the IICA slave transmission end interrupt INTIICAn.

Remark This API function is called as the callback routine of interrupt process [R_IICAn_Interrupt](#) corresponding to the IICA slave transmission end interrupt INTIICAn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Callback_Slave_SendEnd ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Callback_Slave_ReceiveEnd

Performs processing in response to the IICA slave reception end interrupt INTIICAn.

Remark This API function is called as the callback routine of interrupt process [R_IICAn_Interrupt](#) corresponding to the IICA slave reception end interrupt INTIICAn.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Callback_Slave_ReceiveEnd ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_IICAn_Callback_Slave_Error

Performs processing in response to detection of IICA slave communication error.

[Classification]

r_serial_user.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_IICAn_Callback_Slave_Error ( MD_STATUS flag );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------|--|
| I | MD_STATUS flag; | Cause of communication error MD_ERROR: Address mismatch detected MD_NACK: Acknowledge not detected |

[Return value]

None.

R_IICAn_Callback_GetStopCondition

Performs processing in response to detection of stop condition.

[Classification]

r_serial_user.c

[Syntax]

```
void R_IICAn_Callback_GetStopCondition ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

C.3.5 A/D Converter

Below is a list of API functions output by the Code Generator for A/D converter use.

Table C-6. API Functions: [A/D Converter]

| API Function Name | Function |
|-------------------------|---|
| R_ADC_Create | Performs initialization necessary to control A/D converter functions. |
| R_ADC_Create_UserInit | Performs user-defined initialization relating to the A/D converter. |
| R_ADC_Interrupt | Performs processing in response to the A/D conversion end interrupt INTAD. |
| R_ADC_Set_ComparatorOn | Enables operation of voltage converter. |
| R_ADC_Set_ComparatorOff | Disables operation of voltage converter. |
| R_ADC_Start | Starts A/D conversion. |
| R_ADC_Stop | Ends A/D conversion. |
| R_ADC_Set_PowerOff | Halts the clock supplied to the A/D converter. |
| R_ADC_Set_ADChannel | Configures the analog voltage input pin for A/D conversion. |
| R_ADC_Set_SnoozeOn | Enables the switch from STOP mode to SNOOZE mode. |
| R_ADC_Set_SnoozeOff | Disables the switch from STOP mode to SNOOZE mode. |
| R_ADC_Set_TestChannel | Sets the operation mode of A/D converter. |
| R_ADC_Get_Result | Reads the results of A/D conversion (10-bit). |
| R_ADC_Get_Result_8bit | Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution). |

R_ADC_Create

Performs initialization necessary to control A/D converter functions.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Create_UserInit

Performs user-defined initialization relating to the A/D converter.

Remark This API function is called as the [R_ADC_Create](#) callback routine.

[Classification]

r_adc_user.c

[Syntax]

```
void R_ADC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Interrupt

Performs processing in response to the A/D conversion end interrupt INTAD.

Remark This API function is called as the interrupt process corresponding to the A/D conversion end interrupt INTAD.

[Classification]

r_adc_user.c

[Syntax]

```
void R_ADC_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_ComparatorOn

Enables operation of voltage converter.

- Remarks 1.** About 1 microsecond of stabilization time is required when changing the voltage converter from operation stopped to operation enabled status.
Consequently, about 1 micro second must be left free between the call to this API function and the call to [R_ADC_Start](#).
- 2.** On the [A/D Converter], in the [Comparator operation setting] area, if "Operation" is selected, then the voltage converter will be switched to "always on". There is thus no need to call this API function in this case.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Set_ComparatorOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_ComparatorOff

Disables operation of voltage converter.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Set_ComparatorOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Start

Starts A/D conversion.

Remark About 1 micro second of stabilization time is required when changing the voltage converter from operation stopped to operation enabled status.
Consequently, about 1 micro second must be left free between the call to [R_ADC_Set_ComparatorOn](#) and the call to this API function.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Stop

Ends A/D conversion.

Remark The voltage converter continues to operate after the process of this API function completes. Consequently, to stop the operation of the voltage converter, you must call [R_ADC_Set_ComparatorOff](#) after the process of this API function completes.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Stop ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_PowerOff

Halts the clock supplied to the A/D converter.

Remark Calling this API function changes the A/D converter to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_ADChannel

Configures the analog voltage input pin for A/D conversion.

Remark The value specified in parameter *channel* is set to analog input channel specification register (ADS).

[Classification]

r_adc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_adc.h"
MD_STATUS R_ADC_Set_ADChannel ( enum ADChannel channel );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|---------------------------------|--|
| I | enum ADChannel <i>channel</i> ; | Analog voltage input pin ADCHANNEL <i>n</i> : Input pin |

Remark See the header file r_cg_adc.h for details about the analog voltage input pin ADCHANNEL*n*.

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_ADC_Set_SnoozeOn

Enables the switch from STOP mode to SNOOZE mode.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Set_SnoozeOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_SnoozeOff

Disables the switch from STOP mode to SNOOZE mode.

[Classification]

r_adc.c

[Syntax]

```
void R_ADC_Set_SnoozeOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ADC_Set_TestChannel

Sets the operaiton mode of A/D converter.

[Classification]

r_adc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_adc.h"
MD_STATUS R_ADC_Set_TestChannel ( enum TestChannel channel );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------------------------|--|
| I | enum TestChannel <i>channel</i> ; | Operation mode of A/D converter ADNORMALINPUT : Normal mode (Normal A/D conversion) ADAVREFM : Test mode (AVREFM input) ADAVREFP : Test mode (AVREFP input) |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_ADC_Get_Result

Reads the results of A/D conversion (10-bit).

[Classification]

r_adc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_ADC_Get_Result ( uint16_t *buffer );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|-------------------|--|
| O | uint16_t *buffer; | Pointer to area in which to store read results of A/D conversion |

[Return value]

None.

R_ADC_Get_Result_8bit

Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution).

[Classification]

r_adc.c


[Syntax]

```
#include "r_cg_macrodriver.h"
void R_ADC_Get_Result_8bit ( uint8_t *buffer );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|------------------|--|
| O | uint8_t *buffer; | Pointer to area in which to store the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution) |

Remark Below is an example of the results of A/D conversion to be stored in *buffer*.



[Return value]

None.

C.3.6 D/A Converter

Below is a list of API functions output by the Code Generator for D/A converter use.
Sets the analog voltage output to the ANO n pin.

Table C-7. API Functions: [D/A Converter]

| API Function Name | Function |
|--|---|
| R_DAC_Create | Performs initialization necessary to control the D/A converter functions. |
| R_DAC_Create_UserInit | Performs user-defined initialization relating to the D/A converter. |
| R_DACn_Start | Starts D/A conversion. |
| R_DACn_Stop | Ends D/A conversion. |
| R_DAC_Set_PowerOff | Halts the clock supplied to the D/A converter. |
| R_DACn_Set_ConversionValue | Sets the analog voltage output to the ANO n pin. |

R_DAC_Create

Performs initialization necessary to control the D/A converter functions.

[Classification]

r_dac.c

[Syntax]

```
void R_DAC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_DAC_Create_UserInit

Performs user-defined initialization relating to the D/A converter.

Remark This API function is called as the [R_DAC_Create](#) callback routine.

[Classification]

r_dac_user.c

[Syntax]

```
void R_DAC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_DAC n _Start

Starts D/A conversion.

[Classification]

r_dac.c

[Syntax]

```
void R_DACn_Start ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DACn_Stop

Ends D/A conversion.

[Classification]

r_dac.c

[Syntax]

```
void R_DACn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DAC_Set_PowerOff

Halts the clock supplied to the D/A converter.

Remark Calling this API function changes the D/A converter to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_dac.c

[Syntax]

```
void R_DAC_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_DACn_Set_ConversionValue

Sets the analog voltage output to the ANOn pin.

[Classification]

r_dac.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_DACn_Set_ConversionValue ( uint8_t regvalue );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|-------------------|------------------------------------|
| I | uint8_t regvalue; | D/A conversion value (0x0 to 0xFF) |

[Return value]

None.

C.3.7 Timer

Below is a list of API functions output by the Code Generator for timer array unit and timer use.

Table C-8. API Functions: [Timer]

| API Function Name | Function |
|---------------------------------------|--|
| R_TAUm_Create | Performs initialization necessary to control timer array unit functions. |
| R_TAUm_Create_UserInit | Performs user-defined initialization relating to the timer array unit. |
| R_TAUm_Channeln_Interrupt | Performs processing in response to the timer interrupt INTT Mmn . |
| R_TAUm_Channeln_Higher8bits_Interrupt | Performs processing in response to the timer interrupt INTT $MmnH$. |
| R_TAUm_Channeln_Start | Starts the count for channel n . |
| R_TAUm_Channeln_Higher8bits_Start | Starts the count (higher 8-bit) for channel 1 or channel 3. |
| R_TAUm_Channeln_Lower8bits_Start | Starts the count (lower 8-bit) for channel 1 or channel 3. |
| R_TAUm_Channeln_Stop | Ends the count for channel n . |
| R_TAUm_Channeln_Higher8bits_Stop | Ends the count (higher 8-bit) for channel 1 or channel 3. |
| R_TAUm_Channeln_Lower8bits_Stop | Ends the count (lower 8-bit) for channel 1 or channel 3. |
| R_TAUm_Set_PowerOff | Halts the clock supplied to the timer array unit. |
| R_TAUm_Channeln_Get_PulseWidth | Captures the high/low-level width measured between pulses of the signal (pulses) input to the T lmn pin. |
| R_TAUm_Channeln_SoftwareTriggerOn | Generates the trigger (software trigger) for one-shot pulse output. |
| R_TMR_RDn_Create | Performs initialization necessary to control the timer RD n functions. |
| R_TMR_RDn_Create_UserInit | Performs user-defined initialization relating to the timer RD n . |
| R_TMR_RDn_Interrupt | Performs processing in response to the timer interrupt. |
| R_TMR_RDn_Start | Starts the count for timer RD n . |
| R_TMR_RDn_Stop | Ends the count for timer RD n . |
| R_TMR_RDn_Set_PowerOff | Halts the clock supplied to the timer RD n . |
| R_TMR_RDn_Get_PulseWidth | Reads the pulse width of the timer RD n . |
| R_TMR_RGn_Create | Performs initialization necessary to control the timer RG n functions. |
| R_TMR_RGn_Create_UserInit | Performs user-defined initialization relating to the timer RG n . |
| R_TMR_RGn_Interrupt | Performs processing in response to the timer interrupt. |
| R_TMR_RGn_Start | Starts the count for timer RG n . |
| R_TMR_RGn_Stop | Ends the count for timer RG n . |
| R_TMR_RGn_Set_PowerOff | Halts the clock supplied to the timer RG n . |
| R_TMR_RGn_Get_PulseWidth | Reads the pulse width of the timer RG n . |
| R_TMR_RJ0_Create | Performs initialization necessary to control the timer RJ0 functions. |
| R_TMR_RJ0_Create_UserInit | Performs user-defined initialization relating to the timer RJ0. |
| R_TMR_RJ0_Interrupt | Performs processing in response to the timer interrupt. |
| R_TMR_RJ0_Start | Starts the count for timer RJ0. |
| R_TMR_RJ0_Stop | Ends the count for timer RJ0. |
| R_TMR_RJ0_Set_PowerOff | Halts the clock supplied to the timer RJ0. |

| API Function Name | Function |
|--|---|
| R_TMR_RJ0_Get_PulseWidth | Reads the pulse width of the timer RJ0. |

R_TAUm_Create

Performs initialization necessary to control timer array unit functions.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Create ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Create_UserInit

Performs user-defined initialization relating to the timer array unit.

Remark This API function is called as the [R_TAUm_Create](#) callback routine.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TAUm_Create_UserInit ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channeln_Interrupt

Performs processing in response to the timer interrupt INTTM m n.

Remark This API function is called as the interrupt process corresponding to the timer interrupt INTTM m n.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TAUm_Channeln_Interrupt ( void );
```

Remark m is the unit number, and n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channeln_Higher8bits_Interrupt

Performs processing in response to the timer interrupt INTTM m nH.

Remark This API function is called as the interrupt process corresponding to the timer interrupt INTTM m nH.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TAUm_Channeln_Higher8bits_Interrupt ( void );
```

Remark m is the unit number, and n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channeln_Start

Starts the count for channel n .

Remark The time from the call to this API function to the start of counting depends on the type of the function in question (e.g. interval timer, square-wave output, or external event counter).

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Start ( void );
```

Remark m is the unit number, and n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channel*n*_Higher8bits_Start

Starts the count (higher 8-bit) for channel 1 or channel 3.

Remark This API function can only be called when the timer array unit is used as a 8-bit timer.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Higher8bits_Start ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channel*n*_Lower8bits_Start

Starts the count (lower 8-bit) for channel 1 or channel 3.

- Remarks 1.** This API function can only be called when the timer array unit is used as a 8-bit timer.
- 2.** The time from the call to this API function to the start of counting depends on the type of the function in question (e.g. interval timer, external event counter, or delay counter).

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Lower8bits_Start ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channeln_Stop

Ends the count for channel *n*.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Stop ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channel*n*_Higher8bits_Stop

Ends the count (higher 8-bit) for channel 1 or channel 3.

Remark This API function can only be called when the timer array unit is used as a 8-bit timer.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Higher8bits_Stop ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channel*n*_Lower8bits_Stop

Ends the count (lower 8-bit) for channel 1 or channel 3.

Remark This API function can only be called when the timer array unit is used as a 8-bit timer.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_Lower8bits_Stop ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Set_PowerOff

Halts the clock supplied to the timer array unit.

Remark Calling this API function changes the timer array unit to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Set_PowerOff ( void );
```

Remark *m* is the unit number.

[Argument(s)]

None.

[Return value]

None.

R_TAUm_Channeln_Get_PulseWidth

Captures the high/low-level width measured between pulses of the signal (pulses) input to the TImn pin.

[Classification]

r_timer.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_TAUm_Channeln_Get_PulseWidth ( uint32_t *width );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|------------------|--|
| O | uint32_t *width; | Pointer to an area to store the measurement width (0x0 to 0x1FFFF) |

[Return value]

None.

R_TAUm_Channeln_SoftwareTriggerOn

Generates the trigger (software trigger) for one-shot pulse output.

[Classification]

r_timer.c

[Syntax]

```
void R_TAUm_Channeln_SoftwareTriggerOn ( void );
```

Remark *m* is the unit number, and *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Create

Performs initialization necessary to control the timer RD n functions.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RDn_Create ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Create_UserInit

Performs user-defined initialization relating to the timer RD*n*.

Remark This API function is called as the [R_TMR_RDn_Create](#) callback routine.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RDn_Create_UserInit ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RD*n*_Interrupt

Performs processing in response to the timer interrupt.

Remark This API function is called as the interrupt process corresponding to the timer interrupt.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RDn_Interrupt ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Start

Starts the count for timer RD*n*.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RDn_Start ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Stop

Ends the count for timer RD n .

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RDn_Stop ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Set_PowerOff

Halts the clock supplied to the timer RD n .

Remark Calling this API function changes the timer RD n to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RDn_Set_PowerOff ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RDn_Get_PulseWidth

Reads the pulse width of the timer RDn.

- Remarks 1.** This API function can only be called when the timer RDn is being used for input capture function.
- 2.** If there is an overflow (2 pulses or more) during pulse-width measurement, then the pulse width will not be read correctly.

[Classification]

r_timer.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_timer.h"
MD_STATUS R_TMR_RDn_Get_PulseWidth ( uint32_t *activewidth, uint32_t *inactivewidth, enum
TMChannel channel );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| O | uint32_t *activewidth; | Pointer to an area storing the active level width that was read |
| O | uint32_t *inactivewidth; | Pointer to an area storing the inactive level width that was read |
| I | enum TMChannel channel; | Pin to read TMCHANNELA: TRDIOAn pin TMCHANNELB: TRDIOBn pin TMCHANNELC: TRDIOCn pin TMCHANNELD: TRDIODn pin |

[Return value]

| Macro | Description |
|-------|-------------------|
| MD_OK | Normal completion |

R_TMR_RGn_Create

Performs initialization necessary to control the timer RGn functions.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RGn_Create ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Create_UserInit

Performs user-defined initialization relating to the timer RGn.

Remark This API function is called as the [R_TMR_RGn_Create](#) callback routine.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RGn_Create_UserInit ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Interrupt

Performs processing in response to the timer interrupt.

Remark This API function is called as the interrupt process corresponding to the timer interrupt.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RGn_Interrupt ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Start

Starts the count for timer RGn.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RGn_Start ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Stop

Ends the count for timer RGn.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RGn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Set_PowerOff

Halts the clock supplied to the timer RGn.

Remark Calling this API function changes the timer RGn to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RGn_Set_PowerOff ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_TMR_RGn_Get_PulseWidth

Reads the pulse width of the timer RGn.

- Remarks 1.** This API function can only be called when the timer RGn is being used for input capture function.
- 2.** If there is an overflow (2 pulses or more) during pulse-width measurement, then the pulse width will not be read correctly.

[Classification]

r_timer.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_timer.h"
MD_STATUS R_TMR_RGn_Get_PulseWidth ( uint32_t *activewidth, uint32_t *inactivewidth, enum
TMChannel channel );
```

Remark n is the channel number.

[Argument(s)]

| I/O | Argument | Description |
|-----|--------------------------|---|
| O | uint32_t *activewidth; | Pointer to an area storing the active level width that was read from the TRGIOA pin |
| O | uint32_t *inactivewidth; | Pointer to an area storing the inactive level width that was read from the TRGIOA pin |
| I | enum TMChannel channel; | Pin to read TMCHANNELA: TRGIOAn pin TMCHANNELB: TRGIOBn pin |

[Return value]

| Macro | Description |
|-------|-------------------|
| MD_OK | Normal completion |

R_TMR_RJ0_Create

Performs initialization necessary to control the timer RJ0 functions.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RJ0_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Create_UserInit

Performs user-defined initialization relating to the timer RJ0.

Remark This API function is called as the [R_TMR_RJ0_Create](#) callback routine.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RJ0_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Interrupt

Performs processing in response to the timer interrupt.

Remark This API function is called as the interrupt process corresponding to the timer interrupt.

[Classification]

r_timer_user.c

[Syntax]

```
void R_TMR_RJ0_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Start

Starts the count for timer RJ0.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RJ0_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Stop

Ends the count for timer RJ0.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RJ0_Stop ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Set_PowerOff

Halts the clock supplied to the timer RJ0.

Remark Calling this API function changes the timer RJ0 to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_timer.c

[Syntax]

```
void R_TMR_RJ0_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_TMR_RJ0_Get_PulseWidth

Reads the pulse width of the timer RJ0.

- Remarks 1.** This API function can only be called when the timer RJ0 is being used for pulse width measurement mode / pulse period measurement mode.
- 2.** If there is an overflow (2 pulses or more) during pulse-width measurement, then the pulse width will not be read correctly.

[Classification]

r_timer.c

[Syntax]

```
#include "r_cg_macrodriver.h"
void R_TMR_RJ0_Get_PulseWidth ( uint32_t *activewidth );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|------------------------|---|
| O | uint32_t *activewidth; | Pointer to an area storing the active level width that was read from the TRJ0IO pin |

[Return value]

None.

C.3.8 Watchdog Timer

Below is a list of API functions output by the Code Generator for watchdog timer use.

Table C-9. API Functions: [Watchdog Timer]

| API Function Name | Function |
|---------------------------------------|--|
| R_WDT_Create | Performs initialization necessary to control watchdog timer functions. |
| R_WDT_Create_UserInit | Performs user-defined initialization relating to the watchdog timer. |
| R_WDT_Interrupt | Performs processing in response to the interval interrupt INTWDTI of watchdog timer. |
| R_WDT_Restart | Clears the watchdog timer counter and resumes counting. |

R_WDT_Create

Performs initialization necessary to control watchdog timer functions.

[Classification]

r_wdt.c

[Syntax]

```
void R_WDT_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_WDT_Create_UserInit

Performs user-defined initialization relating to the watchdog timer.

Remark This API function is called as the [R_WDT_Create](#) callback routine.

[Classification]

r_wdt_user.c

[Syntax]

```
void R_WDT_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_WDT_Interrupt

Performs processing in response to the interval interrupt INTWDTI of watchdog timer.

Remark This API function is called as the interrupt process corresponding to the interval interrupt INTWDTI.

[Classification]

r_wdt_user.c

[Syntax]

```
void R_WDT_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_WDT_Restart

Clears the watchdog timer counter and resumes counting.

[Classification]

r_wdt.c

[Syntax]

```
void R_WDT_Restart ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.9 Real-time Clock

Below is a list of API functions output by the Code Generator for real-time clock use.

Table C-10. API Functions: [Real-time Clock]

| API Function Name | Function |
|-----------------------------------|---|
| R_RTC_Create | Performs initialization necessary to control real-time clock functions. |
| R_RTC_Create_UserInit | Performs user-defined initialization relating to the real-time clock. |
| R_RTC_Interrupt | Performs processing in response to the real-time clock interrupt INTRTC. |
| R_RTC_Start | Starts the count of the real-time clock (year, month, weekday, day, hour, minute, second). |
| R_RTC_Stop | Ends the count of the real-time clock (year, month, weekday, day, hour, minute, second). |
| R_RTC_Set_PowerOff | Halts the clock supplied to the real-time clock. |
| R_RTC_Set_HourSystem | Sets the clock type (12-hour or 24-hour clock) of the real-time clock. |
| R_RTC_Set_CounterValue | Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock. |
| R_RTC_Get_CounterValue | Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock. |
| R_RTC_Set_ConstPeriodInterruptOn | Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function. |
| R_RTC_Set_ConstPeriodInterruptOff | Ends the cyclic interrupt function. |
| R_RTC_Callback_ConstPeriod | Performs processing in response to the cyclic interrupt INTRTC. |
| R_RTC_Set_AlarmOn | Starts the alarm interrupt function. |
| R_RTC_Set_AlarmOff | Ends the alarm interrupt function. |
| R_RTC_Set_AlarmValue | Sets the alarm conditions (weekday, hour, minute). |
| R_RTC_Get_AlarmValue | Reads the alarm conditions (weekday, hour, minute). |
| R_RTC_Callback_Alarm | Performs processing in response to the alarm interrupt INTRTC. |
| R_RTC_Set_RTC1HZOn | Enables output of the correction clock (1 Hz) to the RTC1HZ pin. |
| R_RTC_Set_RTC1HZOff | Disables output of the correction clock (1 Hz) to the RTC1HZ pin. |

R_RTC_Create

Performs initialization necessary to control real-time clock functions.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Create_UserInit

Performs user-defined initialization relating to the real-time clock.

Remark This API function is called as the [R_RTC_Create](#) callback routine.

[Classification]

r_rtc_user.c

[Syntax]

```
void R_RTC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Interrupt

Performs processing in response to the real-time clock interrupt INTRTC.

Remark This API function is called as the interrupt process corresponding to the real-time clock interrupt INTRTC.

[Classification]

r_rtc_user.c

[Syntax]

```
void R_RTC_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Start

Starts the count of the real-time clock (year, month, weekday, day, hour, minute, second).

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Stop

Ends the count of the real-time clock (year, month, weekday, day, hour, minute, second).

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Stop ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_PowerOff

Halts the clock supplied to the real-time clock.

Remark Calling this API function changes the real-time clock to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_HourSystem

Sets the clock type (12-hour or 24-hour clock) of the real-time clock.

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
MD_STATUS R_RTC_Set_HourSystem ( enum RTCHourSystem hoursystem );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|--|--|
| I | enum RTCHourSystem <i>hoursystem</i> ; | Clock type HOUR12: 12-hour clock HOUR24: 24-hour clock |

[Return value]

| Macro | Description |
|-------------|--|
| MD_OK | Normal completion |
| MD_BUSY1 | Executing count process (before change to setting) |
| MD_BUSY2 | Stopping count process (after change to setting) |
| MD_ARGERROR | Invalid argument specification |

Remark If MD_BUSY1 or MD_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC_WAITTIME macro defined in the header file "r_cg_rtc.h" larger.

R_RTC_Set_CounterValue

Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock.

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
MD_STATUS R_RTC_Set_CounterValue ( struct RTCCounterValue counterwriteval );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|--|---------------|
| I | struct RTCCounterValue <i>counterwriteval</i> ; | Counter value |

Remark Below is an example of the structure RTCCounterValue (counter value) for the real-time clock.

```
struct RTCCounterValue {
    uint8_t Sec; /* second */
    uint8_t Min; /* Minute */
    uint8_t Hour; /* Hour */
    uint8_t Day; /* Day */
    uint8_t Week; /* Weekday (0: Sunday, 6: Saturday) */
    uint8_t Month; /* Month */
    uint8_t Year; /* Year */
};
```

[Return value]

| Macro | Description |
|----------|--|
| MD_OK | Normal completion |
| MD_BUSY1 | Executing count process (before change to setting) |
| MD_BUSY2 | Stopping count process (after change to setting) |

Remark If MD_BUSY1 or MD_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC_WAITTIME macro defined in the header file "r_cg_rtc.h" larger.

R_RTC_Get_CounterValue

Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time clock.

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
MD_STATUS R_RTC_Get_CounterValue ( struct RTCCounterValue *counterreadval );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|--|---|
| O | struct RTCCounterValue *counterreadval; | Pointer to structure in which to store the counter value being read |

Remark See [R_RTC_Set_CounterValue](#) for details about the RTCCounterValue counter value.

[Return value]

| Macro | Description |
|----------|--|
| MD_OK | Normal completion |
| MD_BUSY1 | Executing count process (before reading) |
| MD_BUSY2 | Stopping count process (after reading) |

Remark If MD_BUSY1 or MD_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC_WAITTIME macro defined in the header file "r_cg_rtc.h" larger.

R_RTC_Set_ConstPeriodInterruptOn

Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function.

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
MD_STATUS R_RTC_Set_ConstPeriodInterruptOn ( enum RTCINTPeriod period );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|-----------------------------------|---|
| I | enum RTCINTPeriod <i>period</i> ; | Interrupt INTRTC cycle HALFSEC: 0.5 seconds ONESEC: 1 second ONEMIN: 1 minute ONEHOUR: 1 hour ONEDAY: 1 day ONEMONTH: 1 month |

[Return value]

| Macro | Description |
|-------------|--------------------------------|
| MD_OK | Normal completion |
| MD_ARGERROR | Invalid argument specification |

R_RTC_Set_ConstPeriodInterruptOff

Ends the cyclic interrupt function.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_ConstPeriodInterruptOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Callback_ConstPeriod

Performs processing in response to the cyclic interrupt INTRTC.

Remark This API function is called as the callback routine of interrupt process [R_RTC_Interrupt](#) corresponding to the cyclic interrupt INTRTC.

[Classification]

r_rtc_user.c

[Syntax]

```
void R_RTC_Callback_ConstPeriod ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_AlarmOn

Starts the alarm interrupt function.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_AlarmOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_AlarmOff

Ends the alarm interrupt function.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_AlarmOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_AlarmValue

Sets the alarm conditions (weekday, hour, minute).

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
void R_RTC_Set_AlarmValue ( struct RTCAlarmValue alarmval );
```

[Argument(s)]


| I/O | Argument | Description |
|-----|--------------------------------|--|
| I | struct RTCAlarmValue alarmval; | Alarm conditions (weekday, hour, minute) |

Remark Below is shown the structure RTCAlarmValue (alarm conditions).

```
struct RTCAlarmValue {
    uint8_t Alarmwm; /* Minute */
    uint8_t Alarmwh; /* Hour */
    uint8_t Alarmmw; /* Weekday */
};
```

- Alarmwm (Minute)


Below are shown the meanings of each bit of the structure member Alarmwm.



- Alarmwh (Hour)


Below are shown the meanings of each bit of the structure member Alarmwh. If the real-time clock is set to the 12-hour clock, then bit 5 has the following meaning.

- 0: AM
- 1: PM



- Alarmww (Weekday)

Below are shown the meanings of each bit of the structure member Alarmww.



[Return value]

None.

R_RTC_Get_AlarmValue

Reads the alarm conditions (weekday, hour, minute).

[Classification]

r_rtc.c

[Syntax]

```
#include "r_cg_macrodriver.h"
#include "r_cg_rtc.h"
void R_RTC_Get_AlarmValue ( struct RTCArmValue *alarmval );
```

Remark See [R_RTC_Set_AlarmValue](#) for details about RTCArmValue (alarm conditions).

[Argument(s)]

| I/O | Argument | Description |
|-----|-------------------------------|--|
| O | struct RTCArmValue *alarmval; | Pointer to structure in which to store the conditions being read |

[Return value]

None.

R_RTC_Callback_Alarm

Performs processing in response to the alarm interrupt INTRTC.

Remark This API function is called as the callback routine of interrupt process [R_RTC_Interrupt](#) corresponding to the alarm interrupt INTRTC.

[Classification]

r_rtc_user.c

[Syntax]

```
void R_RTC_Callback_Alarm ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_RTC1HZOn

Enables output of the correction clock (1 Hz) to the RTC1HZ pin.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_RTC1HZOn ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_RTC_Set_RTC1HZOff

Disables output of the correction clock (1 Hz) to the RTC1HZ pin.

[Classification]

r_rtc.c

[Syntax]

```
void R_RTC_Set_RTC1HZOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.10 Interval Timer

Below is a list of API functions output by the Code Generator for interval timer use.

Table C-11. API Functions: [Interval Timer]

| API Function Name | Function |
|--------------------------------------|--|
| R_IT_Create | Performs initialization necessary to control interval timer functions. |
| R_IT_Create_UserInit | Performs user-defined initialization relating to the interval timer. |
| R_IT_Interrupt | Performs processing in response to the interval timer interrupt INTIT. |
| R_IT_Start | Starts the count of the interval timer. |
| R_IT_Stop | Ends the count of the interval timer. |
| R_IT_Set_PowerOff | Halts the clock supplied to the interval timer. |

R_IT_Create

Performs initialization necessary to control interval timer functions.

[Classification]

r_it.c

[Syntax]

```
void R_IT_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_IT_Create_UserInit

Performs user-defined initialization relating to the interval timer.

Remark This API function is called as the [R_IT_Create](#) callback routine.

[Classification]

r_it_user.c

[Syntax]

```
void R_IT_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_IT_Interrupt

Performs processing in response to the interval timer interrupt INTIT.

Remark This API function is called as the interrupt process corresponding to the interval timer interrupt INTIT.

[Classification]

r_it_user.c

[Syntax]

```
void R_IT_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_IT_Start

Starts the count of the interval timer.

[Classification]

r_it.c

[Syntax]

```
void R_IT_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_IT_Stop

Ends the count of the interval timer.

[Classification]

r_it.c

[Syntax]

```
void R_IT_Stop ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_IT_Set_PowerOff

Halts the clock supplied to the interval timer.

Remark Calling this API function changes the interval timer to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_it.c

[Syntax]

```
void R_IT_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.11 Comparator

Below is a list of API functions output by the Code Generator for comparator use.

Table C-12. API Functions: [Comparator]

| API Function Name | Function |
|--|--|
| R_COMP_Create | Performs initialization necessary to control the comparator functions. |
| R_COMP_Create_UserInit | Performs user-defined initialization relating to the comparator. |
| R_COMPn_Interrupt | Performs processing in response to the comparator interrupt <i>INTCMPn</i> . |
| R_COMPn_Start | Begins comparison of reference input voltage and analog input voltage. |
| R_COMPn_Stop | Stops comparison of reference input voltage and analog input voltage. |

R_COMP_Create

Performs initialization necessary to control the comparator functions.

[Classification]

r_comp.c

[Syntax]

```
void R_COMP_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_COMP_Create_UserInit

Performs user-defined initialization relating to the comparator.

Remark This API function is called as the [R_COMP_Create](#) callback routine.

[Classification]

r_comp_user.c

[Syntax]

```
void R_COMP_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_COMP n _Interrupt

Performs processing in response to the comparator interrupt INTCMP n .

Remark This API function is called as the interrupt process corresponding to the comparator interrupt INTCMP n .

[Classification]

r_comp_user.c

[Syntax]

```
void R_COMP $n$ _Interrupt ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_COMP n _Start

Begins comparison of reference input voltage and analog input voltage.

[Classification]

r_comp.c

[Syntax]

```
void R_COMP $n$ _Start ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_COMP n _Stop

Stops comparison of reference input voltage and analog input voltage.

[Classification]

r_comp.c

[Syntax]

```
void R_COMP $n$ _Stop ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

C.3.12 Clock Output/Buzzer Output

Below is a list of API functions output by the Code Generator for clock output/buzzer output use.

Table C-13. API Functions: [Clock Output/Buzzer Output]

| API Function Name | Function |
|---|---|
| R_PCLBUZn_Create | Performs initialization necessary to control clock/buzzer output control circuit functions. |
| R_PCLBUZn_Create_UserInit | Performs user-defined initialization relating to the clock/buzzer output control circuits. |
| R_PCLBUZn_Start | Starts clock/buzzer output. |
| R_PCLBUZn_Stop | Ends clock/buzzer output. |

R_PCLBUZn_Create

Performs initialization necessary to control clock/buzzer output control circuit functions.

[Classification]

r_pclbuz.c

[Syntax]

```
void R_PCLBUZn_Create ( void );
```

Remark *n* is the output pin.

[Argument(s)]

None.

[Return value]

None.

R_PCLBUZn_Create_UserInit

Performs user-defined initialization relating to the clock/buzzer output control circuits.

Remark This API function is called as the [R_PCLBUZn_Create](#) callback routine.

[Classification]

r_pclbuz_user.c

[Syntax]

```
void R_PCLBUZn_Create_UserInit ( void );
```

Remark *n* is the output pin.

[Argument(s)]

None.

[Return value]

None.

R_PCLBUZ*n*_Start

Starts clock/buzzer output.

[Classification]

r_pclbuz.c

[Syntax]

```
void R_PCLBUZn_Start ( void );
```

Remark *n* is the output pin.

[Argument(s)]

None.

[Return value]

None.

R_PCLBUZ*n*_Stop

Ends clock/buzzer output.

[Classification]

r_pclbuz.c

[Syntax]

```
void R_PCLBUZn_Stop ( void );
```

Remark *n* is the output pin.

[Argument(s)]

None.

[Return value]

None.

C.3.13 Data Transfer Controller

Below is a list of API functions output by the Code Generator for data transfer controller use.

Table C-14. API Functions: [Data Transfer Controller]

| API Function Name | Function |
|---------------------------------------|--|
| R_DTC_Create | Performs initialization necessary to control the data transfer controller functions. |
| R_DTC_Create_UserInit | Performs user-defined initialization relating to the data transfer controller. |
| R_DTCn_Start | Enables operation of the data transfer controller. |
| R_DTCn_Stop | Disables operation of the data transfer controller. |
| R_DTC_Set_PowerOff | Halts the clock supplied to the data transfer controller. |

R_DTC_Create

Performs initialization necessary to control the data transfer controller functions.

[Classification]

r_dtc.c

[Syntax]

```
void R_DTC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_DTC_Create_UserInit

Performs user-defined initialization relating to the data transfer controller.

Remark This API function is called as the [R_DTC_Create](#) callback routine.

[Classification]

r_dtc_user.c

[Syntax]

```
void R_DTC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_DTC n _Start

Enables operation of the data transfer controller.

[Classification]

r_dtc.c

[Syntax]

```
void R_DTC $n$ _Start ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DTCn_Stop

Disables operation of the data transfer controller.

[Classification]

r_dtc.c

[Syntax]

```
void R_DTCn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DTC_Set_PowerOff

Halts the clock supplied to the data transfer controller.

Remark Calling this API function changes the data transfer controller to reset status. For this reason, writes to the control registers after this API function is called are ignored.

[Classification]

r_dtc.c

[Syntax]

```
void R_DTC_Set_PowerOff ( void );
```

[Argument(s)]

None.

[Return value]

None.

C.3.14 Event Link Controller

Below is a list of API functions output by the Code Generator for event link controller use.

Table C-15. API Functions: [Event Link Controller]

| API Function Name | Function |
|---------------------------------------|---|
| R_ELC_Create | Performs initialization necessary to control the event link controller functions. |
| R_ELC_Create_UserInit | Performs user-defined initialization relating to the event link controller. |
| R_ELC_Stop | Disables operation of the event link controller. |

R_ELC_Create

Performs initialization necessary to control the event link controller functions.

[Classification]

r_elc.c

[Syntax]

```
void R_ELC_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ELC_Create_UserInit

Performs user-defined initialization relating to the event link controller.

Remark This API function is called as the [R_ELC_Create](#) callback routine.

[Classification]

r_elc_user.c

[Syntax]

```
void R_ELC_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_ELC_Stop

Disables operation of the event link controller.

[Classification]

r_elc.c


[Syntax]

```
void R_ELC_Stop ( uint32_t event );
```

[Argument(s)]

| I/O | Argument | Description |
|-----|-------------------------|-----------------------|
| I | uint32_t <i>event</i> ; | Disabled event source |

Remark Below is shown the format for specifying disabled event source *event*.
 In case of setting the *event* to 0x01010101, the event link operations of event source 00, 08, 16, 24 are prohibited.



[Return value]

None.

C.3.15 DMA Controller

Below is a list of API functions output by the Code Generator for DMA (Direct Memory Access) controller use.

Table C-16. API Functions: [DMA Controller]

| API Function Name | Function |
|--|--|
| R_DMAn_Create | Performs initialization necessary to control DMA controller functions. |
| R_DMAn_Create_UserInit | Performs user-defined initialization relating to the DMA controller. |
| R_DMAn_Interrupt | Performs processing in response to the DMA transfer end interrupt INTDMA n . |
| R_DMAn_Start | Enables operation of channel n . |
| R_DMAn_Stop | Disables operation of channel n . |
| R_DMAn_SoftwareTriggerOn | Starts DMA transfer when DMA operation is enabled. |

R_DMAc n _Create

Performs initialization necessary to control DMA controller functions.

[Classification]

r_dmac.c

[Syntax]

```
void R_DMAc $n$ _Create ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DMAc n _Create_UserInit

Performs user-defined initialization relating to the DMA controller.

Remark This API function is called as the [R_DMAc \$n\$ _Create](#) callback routine.

[Classification]

r_dmac_user.c

[Syntax]

```
void R_DMAc $n$ _Create_UserInit ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DMAc n _Interrupt

Performs processing in response to the DMA transfer end interrupt INTDMA n .

Remark This API function is called as the interrupt process corresponding to the DMA transfer end interrupt INTDMA n .

[Classification]

r_dmac_user.c

[Syntax]

```
void R_DMAc $n$ _Interrupt ( void );
```

Remark n is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DMACHn_Start

Enables operation of channel *n*.

[Classification]

r_dmac.c

[Syntax]

```
void R_DMACHn_Start ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DMAn_Stop

Disables operation of channel *n*.

- Remarks**
1. This API function does not forcibly terminate DMA transfer.
 2. Before using this API function, you must confirm that transmission has ended.

[Classification]

r_dmac.c

[Syntax]

```
void R_DMAn_Stop ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

R_DMAn_SoftwareTriggerOn

Starts DMA transfer when DMA operation is enabled.

[Classification]

r_dmac.c

[Syntax]

```
void R_DMAn_SoftwareTriggerOn ( void );
```

Remark *n* is the channel number.

[Argument(s)]

None.

[Return value]

None.

C.3.16 Voltage Detector

Below is a list of API functions output by the Code Generator for voltage detector use.

Table C-17. API Functions: [Voltage Detector]

| API Function Name | Function |
|---|--|
| R_LVD_Create | Performs initialization necessary to control voltage detector functions. |
| R_LVD_Create_UserInit | Performs user-defined initialization relating to the voltage detector. |
| R_LVD_Interrupt | Performs processing in response to the voltage detection interrupt INTLVI. |
| R_LVD_InterruptMode_Start | Starts voltage detection (when in interrupt mode, and interrupt & reset mode). |

R_LVD_Create

Performs initialization necessary to control voltage detector functions.

[Classification]

r_lvd.c

[Syntax]

```
void R_LVD_Create ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_LVD_Create_UserInit

Performs user-defined initialization relating to the voltage detector.

Remark This API function is called as the [R_LVD_Create](#) callback routine.

[Classification]

r_lvd_user.c

[Syntax]

```
void R_LVD_Create_UserInit ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_LVD_Interrupt

Performs processing in response to the voltage detection interrupt INTLVI.

Remark This API function is called as the interrupt process corresponding to the voltage detection interrupt INTLVI.

[Classification]

r_lvd_user.c

[Syntax]

```
void R_LVD_Interrupt ( void );
```

[Argument(s)]

None.

[Return value]

None.

R_LVD_InterruptMode_Start

Starts voltage detection (when in interrupt mode, and interrupt & reset mode).

[Classification]

r_lvd.c

[Syntax]

```
void R_LVD_InterruptMode_Start ( void );
```

[Argument(s)]

None.

[Return value]

None.

APPENDIX D INDEX

A

A/D Converter ... 145

- R_ADC_Create ... 146
- R_ADC_Create_UserInit ... 147
- R_ADC_Get_Result ... 158
- R_ADC_Get_Result_8bit ... 159
- R_ADC_Interrupt ... 148
- R_ADC_Set_ADChannel ... 154
- R_ADC_Set_ComparatorOff ... 150
- R_ADC_Set_ComparatorOn ... 149
- R_ADC_Set_PowerOff ... 153
- R_ADC_Set_SnoozeOff ... 156
- R_ADC_Set_SnoozeOn ... 155
- R_ADC_Set_TestChannel ... 157
- R_ADC_Start ... 151
- R_ADC_Stop ... 152

[All Output Messages] tab ... 49

API functions ... 59

- A/D Converter ... 145
- Clock Generator ... 69
- Clock Output/Buzzer Output ... 242
- Comparator ... 236
- D/A Converter ... 160
- Data Transfer Controller ... 247
- DMA Controller ... 257
- Event Link Controller ... 253
- Interrupt ... 78
- Interval Timer ... 229
- Port ... 75
- Real-time Clock ... 208
- Serial ... 89
- Timer ... 167
- Voltage Detector ... 264
- Watchdog Timer ... 203

B

Browse For Folder dialog box ... 51

C

Clock Generator ... 69

- R_CGC_Create ... 70
- R_CGC_Create_UserInit ... 71
- R_CGC_Get_ResetSource ... 72
- R_CGC_Set_ClockMode ... 73
- R_CGC_Set_CRCon ... 74

Clock Output/Buzzer Output ... 242

- R_PCLBUZn_Create ... 243
- R_PCLBUZn_Create_UserInit ... 244
- R_PCLBUZn_Start ... 245
- R_PCLBUZn_Stop ... 246

Code Generator panel ... 41

Code Generator Preview panel ... 44

[Code Generator] tab ... 50

Comparator ... 236

- R_COMP_Create ... 237
- R_COMP_Create_UserInit ... 238
- R_COMPn_Interrupt ... 239
- R_COMPn_Start ... 240
- R_COMPn_Stop ... 241

D

D/A Converter ... 160

- R_DAC_Create ... 161
- R_DAC_Create_UserInit ... 162
- R_DACn_Set_ConversionValue ... 166
- R_DACn_Start ... 163
- R_DACn_Stop ... 164
- R_DAC_Set_PowerOff ... 165

Data Transfer Controller ... 247

- R_DTC_Create ... 248
- R_DTC_Create_UserInit ... 249
- R_DTCn_Start ... 250
- R_DTCn_Stop ... 251
- R_DTC_Set_PowerOff ... 252

DMA Controller ... 257

- R_DMAn_Create ... 258

- R_DMAcN_Create_UserInit ... 259
 - R_DMAcN_Interrupt ... 260
 - R_DMAcN_SoftwareTriggerOn ... 263
 - R_DMAcN_Start ... 261
 - R_DMAcN_Stop ... 262
- E**
- Event Link Controller ... 253
 - R_ELC_Create ... 254
 - R_ELC_Create_UserInit ... 255
 - R_ELC_Stop ... 256
- F**
- [File Setting] tab ... 40
 - Functions ... 11
 - Code Generator ... 11
- G**
- [Generation] tab ... 37
- I**
- Interrupt ... 78
 - R_INTC_Create ... 79
 - R_INTC_Create_UserInit ... 80
 - R_INTCn_Interrupt ... 81
 - R_INTCn_Start ... 82
 - R_INTCn_Stop ... 83
 - R_KEY_Create ... 84
 - R_KEY_Create_UserInit ... 85
 - R_KEY_Interrupt ... 86
 - R_KEY_Start ... 87
 - R_KEY_Stop ... 88
 - Interval Timer ... 229
 - R_IT_Create ... 230
 - R_IT_Create_UserInit ... 231
 - R_IT_Interrupt ... 232
 - R_IT_Set_PowerOff ... 235
 - R_IT_Start ... 233
 - R_IT_Stop ... 234
- M**
- [Macro Setting] tab ... 39
- Main window ... 28
- O**
- Output panel ... 47
 - [All Output Messages] tab ... 49
 - [Code Generator] tab ... 50
- P**
- Port ... 75
 - R_PORT_Create ... 76
 - R_PORT_Create_UserInit ... 77
 - Project Tree panel ... 31
 - Property panel ... 34
 - [File Setting] tab ... 40
 - [Generation] tab ... 37
 - [Macro Setting] tab ... 39
- R**
- R_ADC_Create ... 146
 - R_ADC_Create_UserInit ... 147
 - R_ADC_Get_Result ... 158
 - R_ADC_Get_Result_8bit ... 159
 - R_ADC_Interrupt ... 148
 - R_ADC_Set_ADChannel ... 154
 - R_ADC_Set_ComparatorOff ... 150
 - R_ADC_Set_ComparatorOn ... 149
 - R_ADC_Set_PowerOff ... 153
 - R_ADC_Set_SnoozeOff ... 156
 - R_ADC_Set_SnoozeOn ... 155
 - R_ADC_Set_TestChannel ... 157
 - R_ADC_Start ... 151
 - R_ADC_Stop ... 152
 - R_CGC_Create ... 70
 - R_CGC_Create_UserInit ... 71
 - R_CGC_Get_ResetSource ... 72
 - R_CGC_Set_ClockMode ... 73
 - R_CGC_Set_CRCon ... 74
 - R_COMP_Create ... 237
 - R_COMP_Create_UserInit ... 238
 - R_COMPn_Interrupt ... 239
 - R_COMPn_Start ... 240
 - R_COMPn_Stop ... 241

| | | | |
|---------------------------------|-----|--|-----|
| R_CSImn_Callback_Error ... | 117 | R_RTC_Set_RTC1HZOff ... | 228 |
| R_CSImn_Callback_ReceiveEnd ... | 116 | R_RTC_Set_RTC1HZOn ... | 227 |
| R_CSImn_Callback_SendEnd ... | 115 | R_RTC_Start ... | 212 |
| R_CSImn_Create ... | 108 | R_RTC_Stop ... | 213 |
| R_CSImn_Interrupt ... | 109 | R_RTC_Set_ConstPeriodInterruptOff ... | 219 |
| R_CSImn_Receive ... | 113 | R_RTC_Set_ConstPeriodInterruptOn ... | 218 |
| R_CSImn_Send ... | 112 | R_ELC_Create ... | 254 |
| R_CSImn_Send_Receive ... | 114 | R_ELC_Create_UserInit ... | 255 |
| R_CSImn_Start ... | 110 | R_ELC_Stop ... | 256 |
| R_CSImn_Stop ... | 111 | R_IICAn_Callback_GetStopCondition ... | 144 |
| R_DAC_Create ... | 161 | R_IICAn_Callback_Master_Error ... | 138 |
| R_DAC_Create_UserInit ... | 162 | R_IICAn_Callback_Master_ReceiveEnd ... | 137 |
| R_DACn_Set_ConversionValue ... | 166 | R_IICAn_Callback_Master_SendEnd ... | 136 |
| R_DACn_Start ... | 163 | R_IICAn_Callback_Slave_Error ... | 143 |
| R_DACn_Stop ... | 164 | R_IICAn_Callback_Slave_ReceiveEnd ... | 142 |
| R_DAC_Set_PowerOff ... | 165 | R_IICAn_Callback_Slave_SendEnd ... | 141 |
| R_DMACn_Create ... | 258 | R_IICAn_Create ... | 128 |
| R_DMACn_Create_UserInit ... | 259 | R_IICAn_Create_UserInit ... | 129 |
| R_DMACn_Interrupt ... | 260 | R_IICAn_Interrupt ... | 130 |
| R_DMACn_SoftwareTriggerOn ... | 263 | R_IICAn_Master_Receive ... | 135 |
| R_DMACn_Start ... | 261 | R_IICAn_Master_Send ... | 134 |
| R_DMACn_Stop ... | 262 | R_IICAn_Set_PowerOff ... | 133 |
| R_DTC_Create ... | 248 | R_IICAn_Slave_Receive ... | 140 |
| R_DTC_Create_UserInit ... | 249 | R_IICAn_Slave_Send ... | 139 |
| R_DTCn_Start ... | 250 | R_IICAn_Stop ... | 132 |
| R_DTCn_Stop ... | 251 | R_IICAn_StopCondition ... | 131 |
| R_DTC_Set_PowerOff ... | 252 | R_IICmn_Callback_Master_Error ... | 127 |
| Real-time Clock ... | 208 | R_IICmn_Callback_Master_ReceiveEnd ... | 126 |
| R_RTC_Callback_Alarm ... | 226 | R_IICmn_Callback_Master_SendEnd ... | 125 |
| R_RTC_Callback_ConstPeriod ... | 220 | R_IICmn_Create ... | 118 |
| R_RTC_Create ... | 209 | R_IICmn_Interrupt ... | 119 |
| R_RTC_Create_UserInit ... | 210 | R_IICmn_Master_Receive ... | 124 |
| R_RTC_Get_AlarmValue ... | 225 | R_IICmn_Master_Send ... | 123 |
| R_RTC_Get_CounterValue ... | 217 | R_IICmn_StartCondition ... | 120 |
| R_RTC_Interrupt ... | 211 | R_IICmn_Stop ... | 122 |
| R_RTC_Set_AlarmOff ... | 222 | R_IICmn_StopCondition ... | 121 |
| R_RTC_Set_AlarmOn ... | 221 | R_INTC_Create ... | 79 |
| R_RTC_Set_AlarmValue ... | 223 | R_INTC_Create_UserInit ... | 80 |
| R_RTC_Set_CounterValue ... | 216 | R_INTCn_Interrupt ... | 81 |
| R_RTC_Set_HourSystem ... | 215 | R_INTCn_Start ... | 82 |
| R_RTC_Set_PowerOff ... | 214 | R_INTCn_Stop ... | 83 |

| | | | |
|---------------------------------------|-----|---|-----|
| R_IT_Create ... | 230 | R_SAU0_Set_SnoozeOn ... | 94 |
| R_IT_Create_UserInit ... | 231 | R_SAUm_Create ... | 91 |
| R_IT_Interrupt ... | 232 | R_SAUm_Create_UserInit ... | 92 |
| R_IT_Set_PowerOff ... | 235 | R_SAUm_Set_PowerOff ... | 93 |
| R_IT_Start ... | 233 | R_TAUm_Channeln_Get_PulseWidth ... | 180 |
| R_IT_Stop ... | 234 | R_TAUm_Channeln_Higher8bits_Interrupt ... | 172 |
| R_KEY_Create ... | 84 | R_TAUm_Channeln_Higher8bits_Start ... | 174 |
| R_KEY_Create_UserInit ... | 85 | R_TAUm_Channeln_Higher8bits_Stop ... | 177 |
| R_KEY_Interrupt ... | 86 | R_TAUm_Channeln_Interrupt ... | 171 |
| R_KEY_Start ... | 87 | R_TAUm_Channeln_Lower8bits_Start ... | 175 |
| R_KEY_Stop ... | 88 | R_TAUm_Channeln_Lower8bits_Stop ... | 178 |
| R_LVD_Create ... | 265 | R_TAUm_Channeln_SoftwareTriggerOn ... | 181 |
| R_LVD_Create_UserInit ... | 266 | R_TAUm_Channeln_Start ... | 173 |
| R_LVD_Interrupt ... | 267 | R_TAUm_Channeln_Stop ... | 176 |
| R_LVD_InterruptMode_Start ... | 268 | R_TAUm_Create ... | 169 |
| R_PCLBUZn_Create ... | 243 | R_TAUm_Create_UserInit ... | 170 |
| R_PCLBUZn_Create_UserInit ... | 244 | R_TAUm_Set_PowerOff ... | 179 |
| R_PCLBUZn_Start ... | 245 | R_TMR_RDn_Create ... | 182 |
| R_PCLBUZn_Stop ... | 246 | R_TMR_RDn_Create_UserInit ... | 183 |
| R_PORT_Create ... | 76 | R_TMR_RDn_Get_PulseWidth ... | 188 |
| R_PORT_Create_UserInit ... | 77 | R_TMR_RDn_Interrupt ... | 184 |
| R_RTC_Callback_Alarm ... | 226 | R_TMR_RDn_Set_PowerOff ... | 187 |
| R_RTC_Callback_ConstPeriod ... | 220 | R_TMR_RDn_Start ... | 185 |
| R_RTC_Create ... | 209 | R_TMR_RDn_Stop ... | 186 |
| R_RTC_Create_UserInit ... | 210 | R_TMR_RGn_Create ... | 189 |
| R_RTC_Get_AlarmValue ... | 225 | R_TMR_RGn_Create_UserInit ... | 190 |
| R_RTC_Get_CounterValue ... | 217 | R_TMR_RGn_Get_PulseWidth ... | 195 |
| R_RTC_Interrupt ... | 211 | R_TMR_RGn_Interrupt ... | 191 |
| R_RTC_Set_AlarmOff ... | 222 | R_TMR_RGn_Set_PowerOff ... | 194 |
| R_RTC_Set_AlarmOn ... | 221 | R_TMR_RGn_Start ... | 192 |
| R_RTC_Set_AlarmValue ... | 223 | R_TMR_RGn_Stop ... | 193 |
| R_RTC_Set_CounterValue ... | 216 | R_TMR_RJ0_Create ... | 196 |
| R_RTC_Set_HourSystem ... | 215 | R_TMR_RJ0_Create_UserInit ... | 197 |
| R_RTC_Set_PowerOff ... | 214 | R_TMR_RJ0_Get_PulseWidth ... | 202 |
| R_RTC_Set_RTC1HZOff ... | 228 | R_TMR_RJ0_Interrupt ... | 198 |
| R_RTC_Set_RTC1HZOn ... | 227 | R_TMR_RJ0_Set_PowerOff ... | 201 |
| R_RTC_Start ... | 212 | R_TMR_RJ0_Start ... | 199 |
| R_RTC_Stop ... | 213 | R_TMR_RJ0_Stop ... | 200 |
| R_RTC_Set_ConstPeriodInterruptOff ... | 219 | R_UARTn_Callback_Error ... | 106 |
| R_RTC_Set_ConstPeriodInterruptOn ... | 218 | R_UARTn_Callback_ReceiveEnd ... | 105 |
| R_SAU0_Set_SnoozeOff ... | 95 | R_UARTn_Callback_SendEnd ... | 104 |

- R_UARTn_Callback_SoftwareOverRun ... 107
 R_UARTn_Create ... 96
 R_UARTn_Interrupt_Error ... 99
 R_UARTn_Interrupt_Receive ... 98
 R_UARTn_Interrupt_Send ... 97
 R_UARTn_Receive ... 103
 R_UARTn_Send ... 102
 R_UARTn_Start ... 100
 R_UARTn_Stop ... 101
 R_WDT_Create ... 204
 R_WDT_Create_UserInit ... 205
 R_WDT_Interrupt ... 206
 R_WDT_Restart ... 207
- S**
- Save As dialog box ... 52
 Serial ... 89
 R_CSImn_Callback_Error ... 117
 R_CSImn_Callback_ReceiveEnd ... 116
 R_CSImn_Create ... 108
 R_CSImn_Interrupt ... 109
 R_CSImn_Receive ... 113
 R_CSImn_Send ... 112
 R_CSImn_Callback_SendEnd ... 115
 R_CSImn_Send_Receive ... 114
 R_CSImn_Start ... 110
 R_CSImn_Stop ... 111
 R_IICAn_Callback_GetStopCondition ... 144
 R_IICAn_Callback_Master_Error ... 138
 R_IICAn_Callback_Master_ReceiveEnd ... 137
 R_IICAn_Callback_Master_SendEnd ... 136
 R_IICAn_Callback_Slave_Error ... 143
 R_IICAn_Callback_Slave_ReceiveEnd ... 142
 R_IICAn_Callback_Slave_SendEnd ... 141
 R_IICAn_Create ... 128
 R_IICAn_Create_UserInit ... 129
 R_IICAn_Interrupt ... 130
 R_IICAn_Master_Receive ... 135
 R_IICAn_Master_Send ... 134
 R_IICAn_Set_PowerOff ... 133
 R_IICAn_Slave_Receive ... 140
 R_IICAn_Slave_Send ... 139
 R_IICAn_Stop ... 132
 R_IICAn_StopCondition ... 131
 R_IICmn_Callback_Master_Error ... 127
 R_IICmn_Callback_Master_ReceiveEnd ... 126
 R_IICmn_Callback_Master_SendEnd ... 125
 R_IICmn_Create ... 118
 R_IICmn_Interrupt ... 119
 R_IICmn_Master_Receive ... 124
 R_IICmn_Master_Send ... 123
 R_IICmn_StartCondition ... 120
 R_IICmn_Stop ... 122
 R_IICmn_StopCondition ... 121
 R_SAU0_Set_SnoozeOff ... 95
 R_SAU0_Set_SnoozeOn ... 94
 R_SAUm_Create ... 91
 R_SAUm_Create_UserInit ... 92
 R_SAUm_Set_PowerOff ... 93
 R_UARTn_Callback_Error ... 106
 R_UARTn_Callback_ReceiveEnd ... 105
 R_UARTn_Callback_SendEnd ... 104
 R_UARTn_Callback_SoftwareOverRun ... 107
 R_UARTn_Create ... 96
 R_UARTn_Interrupt_Error ... 99
 R_UARTn_Interrupt_Receive ... 98
 R_UARTn_Interrupt_Send ... 97
 R_UARTn_Receive ... 103
 R_UARTn_Send ... 102
 R_UARTn_Start ... 100
 R_UARTn_Stop ... 101
- T**
- Timer ... 167
 R_TAUm_Channeln_Get_PulseWidth ... 180
 R_TAUm_Channeln_Higher8bits_Interrupt ... 172
 R_TAUm_Channeln_Higher8bits_Stop ... 177
 R_TAUm_Channeln_Interrupt ... 171
 R_TAUm_Channeln_Lower8bits_Start ... 175
 R_TAUm_Channeln_Lower8bits_Stop ... 178
 R_TAUm_Channeln_SoftwareTriggerOn ... 181
 R_TAUm_Channeln_Start ... 173

R_TAUm_Channeln_Stop ... 176
R_TAUm_Create ... 169
R_TAUm_Create_UserInit ... 170
R_TAUm_Set_PowerOff ... 179
R_TMR_RDn_Create ... 182
R_TMR_RDn_Create_UserInit ... 183
R_TMR_RDn_Get_PulseWidth ... 188
R_TMR_RDn_Interrupt ... 184
R_TMR_RDn_Set_PowerOff ... 187
R_TMR_RDn_Start ... 185
R_TMR_RDn_Stop ... 186
R_TMR_RGn_Create ... 189
R_TMR_RGn_Create_UserInit ... 190
R_TMR_RGn_Get_PulseWidth ... 195
R_TMR_RGn_Interrupt ... 191
R_TMR_RGn_Set_PowerOff ... 194
R_TMR_RGn_Start ... 192
R_TMR_RGn_Stop ... 193
R_TMR_RJ0_Create ... 196
R_TMR_RJ0_Create_UserInit ... 197
R_TMR_RJ0_Get_PulseWidth ... 202
R_TMR_RJ0_Interrupt ... 198
R_TMR_RJ0_Set_PowerOff ... 201
R_TMR_RJ0_Start ... 199
R_TMR_RJ0_Stop ... 200
R_TAUm_Channeln_Higher8bits_Start ... 174

V

Voltage Detector ... 264
R_LVD_Create ... 265
R_LVD_InterruptMode_Start ... 268
R_LVD_Create_UserInit ... 266
R_LVD_Interrupt ... 267

W

Watchdog Timer ... 203
R_WDT_Create ... 204
R_WDT_Create_UserInit ... 205
R_WDT_Interrupt ... 206
R_WDT_Restart ... 207
Window reference ... 27

Revision Record

| Rev. | Date | Description | |
|------|--------------|-------------|----------------------|
| | | Page | Summary |
| 1.00 | Jun 01, 2011 | - | First Edition issued |

CubeSuite+ V1.00.01
User's Manual: RL78 Design

Publication Date: Rev.1.00 Jun 01, 2011

Published by: Renesas Electronics Corporation

**SALES OFFICES**

Renesas Electronics Corporation

<http://www.renesas.com>Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.
2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.
Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited
1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH
Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.
Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

Renesas Electronics Hong Kong Limited
Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.
7F, No. 363 Fu Shing North Road Taipei, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.
1 harbourFront Avenue, #06-10, keppel Bay Tower, Singapore 098632
Tel: +65-6213-0200, Fax: +65-6278-8001

Renesas Electronics Malaysia Sdn.Bhd.
Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd.
11F., Samik Laviel'or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141

CubeSuite+ V1.00.01



Renesas Electronics Corporation

R20UT0548EJ0100