

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.



User's Manual

ID78K4-NS Ver. 2.52

Integrated Debugger

Operation

Target Device 78K4 Series

Document No. U16632EJ2V0UM00 (2nd edition)
Date Published July 2003 NS CP(K)

© NEC Electronics Corporation 2003

Printed in Japan

[MEMO]

Windows and WindowsNT are either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

PC/AT is a trademark of International Business Machines Corporation.

- **The information in this document is current as of May, 2003. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.**

- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

- (1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.
- (2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC Electronics product in your application, please contact the NEC Electronics office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

[GLOBAL SUPPORT]

<http://www.necel.com/en/support/support.html>

NEC Electronics America, Inc. (U.S.)
Santa Clara, California
Tel: 408-588-6000
800-366-9782

NEC Electronics (Europe) GmbH
Duesseldorf, Germany
Tel: 0211-65 03 01

NEC Electronics Hong Kong Ltd.
Hong Kong
Tel: 2886-9318

- **Sucursal en España**
Madrid, Spain
Tel: 091-504 27 87

NEC Electronics Hong Kong Ltd.
Seoul Branch
Seoul, Korea
Tel: 02-558-3737

- **Succursale Française**
Vélizy-Villacoublay, France
Tel: 01-30-67 58 00

NEC Electronics Shanghai, Ltd.
Shanghai, P.R. China
Tel: 021-6841-1138

- **Filiale Italiana**
Milano, Italy
Tel: 02-66 75 41

NEC Electronics Taiwan Ltd.
Taipei, Taiwan
Tel: 02-2719-2377

- **Branch The Netherlands**
Eindhoven, The Netherlands
Tel: 040-244 58 45

NEC Electronics Singapore Pte. Ltd.
Novena Square, Singapore
Tel: 6253-8311

- **Tyskland Filial**
Taeby, Sweden
Tel: 08-63 80 820

- **United Kingdom Branch**
Milton Keynes, UK
Tel: 01908-691-133

J03.4

PREFACE

Target Readers	This manual is intended for user engineers who design and develop application systems of the 78K4 Series.	
Purpose	This manual is intended for users to understand the functions of the ID78K4-NS in the organization below.	
Organization	This manual consists of the following chapters: <ul style="list-style-type: none">• OVERVIEW• STARTING AND TERMINATING• ASSOCIATION WITH PM plus• FUNCTIONS OF ID78K4-NS• OPERATION• WINDOW REFERENCE• COMMAND REFERENCE	
How to Use This Manual	It is assumed that the readers of this manual have general knowledge of electrical engineering, logic circuits, microcontrollers, C language, and assemblers. To understand the functions of the 78K4 Series → Refer to Hardware User's Manual for each product. To understand the instruction functions of the 78K4 Series → Refer to 78K/4 Series Instructions User's Manual (U10905E).	
Conventions	Data significance:	Higher digits on the left and lower digits on the right
	Note:	Footnote for item marked with Note in the text
	Caution:	Information requiring particular attention
	Remark:	Supplementary information
	Numerical representation:	Binary ... XXXX or XXXXB Decimal ... XXXX Hexadecimal ... 0XXXXX
	Prefix indicating the power of 2 (address space, memory capacity):	K (Kilo): $2^{10} = 1024$ M (Mega): $2^{20} = 1024^2$ G (Giga): $2^{30} = 1024^3$

Related Documents

Refer to the documents listed below when using this manual.

The related documents indicated in this publication may include preliminary versions.
However, preliminary versions are not marked as such.

Documents related to development tools (User's Manuals)

Document Name		Document No.
IE-78K4-NS In-Circuit Emulator		U13356E
RA78K4 Assembler Package	Operation	U16708E
	Assembly Language	U15255E
	Structured Assembler Preprocessor	U11743E
CC78K4 C Compiler Package	Operation	U16707E
	Language	U15556E
ID78K4-NS Ver. 2.52 Integrated Debugger	Operation	This manual
SM78K Series Ver.2.52 System Simulator	Operation	To be prepared
RX78K4 Real-Time OS	Fundamental	U10603E
	Installation	U10604E
PM plus Ver.5.10		U16569E

CONTENTS

CHAPTER 1 OVERVIEW ... 12

- 1.1 Overview ... 12
- 1.2 Features ... 12
- 1.3 System Configuration ... 13
 - 1.3.1 Example of system configuration ... 13
- 1.4 Operating Environment ... 13
 - 1.4.1 Hardware environment ... 13
 - 1.4.2 Software environment ... 14
- 1.5 Notes on Source-Level Debugging ... 14

CHAPTER 2 STARTING AND TERMINATING ... 15

- 2.1 Starting ... 15
- 2.2 Terminating ... 16

CHAPTER 3 ASSOCIATION WITH PM plus ... 17

- 3.1 Setting Build Mode ... 17
- 3.2 Registering Debugger to PM plus Project ... 17
 - 3.2.1 Selecting debugger ... 17
- 3.3 To Start ID78K4-NS from PM plus ... 18
 - 3.3.1 Restoring debugging environment ... 18
- 3.4 Auto Load ... 18
 - 3.4.1 Auto load by correcting source code ... 19
 - 3.4.2 Auto load by starting debugger ... 19

CHAPTER 4 FUNCTIONS OF ID78K4-NS ... 20

- 4.1 Mapping function ... 20
- 4.2 Setting Debugging Environment ... 20
- 4.3 Program Execution Function ... 21
 - 4.3.1 Real-time execution function ... 21
 - 4.3.2 Non-real-time execution function ... 22
- 4.4 Event function ... 23
 - 4.4.1 Using event function ... 23
 - 4.4.2 Event condition ... 23
 - 4.4.3 Event link condition ... 23
 - 4.4.4 Setting of various event conditions ... 24
- 4.5 Break function ... 24
- 4.6 Trace function ... 26
 - 4.6.1 Operation of trace ... 26
 - 4.6.2 Trace condition setting function ... 26
- 4.7 Register Manipulation Function ... 27
- 4.8 Memory Manipulation Function ... 27
- 4.9 Watch Function ... 27
- 4.10 Time Measurement Function ... 28
- 4.11 Load/Save Function ... 28
 - 4.11.1 View files ... 28
 - 4.11.2 Information files ... 29
 - 4.11.3 Environment files ... 29
- 4.12 Real-Time internal RAM Sampling Function ... 29

CHAPTER 5 OPERATION ... 31

- 5.1 Flow of Debugging Operations ... 31
- 5.2 Active Status and Static Status ... 33

- 5. 3 Jump Function ... 33
- 5. 4 Trace Result with Linking Window ... 34

CHAPTER 6 WINDOW REFERENCE ... 36

- 6. 1 Window List ... 36
- 6. 2 Explanation of Windows ... 38
 - Window/dialog name ... 39
 - Main window ... 40
 - Configuration dialog box ... 59
 - Extended Option dialog box ... 65
 - Debugger Option dialog box ... 68
 - Font dialog box ... 76
 - Project File Save dialog box ... 78
 - Project File Load dialog box ... 81
 - View File Save dialog box ... 83
 - View File Load dialog box ... 87
 - Environment File Save dialog box ... 90
 - Environment File Load dialog box ... 92
 - Download dialog box ... 94
 - Upload dialog box ... 98
 - Browse dialog box ... 101
 - Address Move dialog box ... 103
 - Source Text Move dialog box ... 105
 - Trace Move dialog box ... 108
 - Symbol To Address dialog box ... 111
 - Source window ... 114
 - Source Search dialog box ... 128
 - Assemble window ... 131
 - Assemble Search dialog box ... 138
 - Memory window ... 141
 - Memory Search dialog box ... 146
 - Memory Fill dialog box ... 149
 - Memory Copy dialog box ... 151
 - Memory Compare dialog box ... 153
 - Memory Compare Result dialog box ... 155
 - Watch window ... 157
 - Quick Watch dialog box ... 164
 - Add Watch dialog box ... 168
 - Change Watch dialog box ... 172
 - Local Variable window ... 175
 - Stack Trace window ... 178
 - Register window ... 182
 - SFR window ... 187
 - SFR Select dialog box ... 192
 - Add I/O Port dialog box ... 195
 - Trace window ... 198
 - Trace Search dialog box ... 205
 - Trace Data Select dialog box ... 212
 - Event Manager ... 215
 - Software Break Manager ... 223
 - Event dialog box ... 226
 - Event Link dialog box ... 234
 - Break dialog box ... 239
 - Trace dialog box ... 243
 - Timer dialog box ... 248
 - Timer Result dialog box ... 251
 - Delay Count dialog box ... 253
 - Reset Debugger dialog box ... 255
 - About dialog box ... 257
 - Exit Debugger dialog box ... 259
 - Console window ... 261

CHAPTER 7 COMMAND REFERENCE ... 262

- 7. 1 Command Line Rules ... 262
- 7. 2 Command List ... 262
- 7. 3 List of Variables ... 265
- 7. 4 List of Packages ... 265
- 7. 5 Key Bind ... 265
- 7. 6 Expansion window ... 265
- 7. 7 Callback Procedure ... 265
- 7. 8 Hook Procedure ... 266
- 7. 9 Related Files ... 267
- 7. 10 Cautions ... 268
- 7. 11 Commands ... 269
 - Command name ... 269
 - address ... 270
 - assemble ... 271
 - batch ... 272
 - breakpoint ... 273
 - dbgexit ... 275
 - download ... 276
 - extwin ... 277
 - finish ... 278
 - go ... 279
 - help ... 280
 - hook ... 281
 - jump ... 282
 - map ... 283
 - mdi ... 285
 - memory ... 286
 - module ... 288
 - next ... 289
 - refresh ... 290
 - register ... 291
 - reset ... 292
 - run ... 293
 - step ... 294
 - stop ... 295
 - upload ... 296
 - version ... 297
 - watch ... 298
 - where ... 299
 - wish ... 300
 - xtrace ... 301

APPENDIX A INPUT CONVENTIONS ... 303

- A. 1 Character set ... 303
- A. 2 Symbols ... 304
- A. 3 Numeric Values ... 305
- A. 4 Expressions and Operators ... 305
- A. 5 File Names ... 307

APPENDIX B EXPANSION WINDOWS ... 308

- B. 1 Overview ... 308
- B. 2 Activation ... 308
- B. 3 Explanation of each sample window ... 308
 - List window ... 309
 - Grep window ... 310
 - Hook window ... 311

APPENDIX C TERMINOLOGY ... 313

C. 1 Terminology ... 313

APPENDIX D MESSAGES ... 315

- D.1 Error/Warning Messages from ... 315
 - D.1.1 Display format of ... 315
 - D.1.2 Fatal error messages ... 315
 - D.1.3 Syntax error messages ... 319
 - D.1.4 Warning message or question message ... 330

APPENDIX E KEY FUNCTION LIST ... 332

- E. 1 Function List of Special Function Keys ... 332
- E. 2 Function List of Function Keys ... 333
- E. 3 Function List of Special Function Keys (Shift + key) ... 333
- E. 4 Function List of Function Keys (Shift + key) ... 334
- E. 5 List of Special Function Keys (Ctrl + key) ... 334
- E. 6 Function List of Function Keys (Ctrl + key) ... 334
- E. 7 Function List of Control Keys (Ctrl + key) ... 335
- E. 8 List of Special Function Keys (Ctrl + Shift + key) ... 335

APPENDIX F INDEX ... 337

CHAPTER 1 OVERVIEW

1.1 Overview

The Integrated debugger ID78K4-NS for the 78K4 Series (hereafter referred to as the ID78K4-NS) is a software tool developed for NEC Electronics's 78K4 Series of 8-bit microcontrollers for embedded control. This software tool is intended to enable efficient debugging of user programs.

The ID78K4-NS runs on a host machine that uses WindowsTM as the operating system and employs an easy-to-understand, easy-to-use GUI (Graphical User Interface).

The commands that are often used are displayed as buttons, so that they can be executed with a single mouse click. In this way, an environment with excellent operability can be provided.

1.2 Features

The ID78K4-NS has the following features.

(1) Source debugging

A C source program and source program in assembly language can be debugged.

(2) Using functions of in-circuit emulator

By using the detailed event setting function of an in-circuit emulator, break events can be set and the user program can be traced.

(3) Monitor function (automatic display updating function when execution is stopped)

If execution of the user program is stopped, the values of the window displayed on the screen are automatically updated.

(4) Saving/restoring debugging environment

The debugging environment including information on setting of breakpoints and events, downloading files, and display status and position of windows can be saved to a file (project file).

By loading this project file, the debugging environment can be restored.

(5) Function expansion by TIP

By combining with a task debugger (RD) and system performance analyzer (AZ) that support TIP (Tool Interface Protocol), the efficiency of user program debugging using a real-time OS (RX) can be drastically improved.

(6) Batch execution by command and creation of custom window

A console window that allows batch processing on the command line and creation of the user's own custom window has been added.


1.3 System Configuration

The supplies a comfortable debugging environment for the user program and target system developed for the 78K4 Series, by connecting the host machine and an in-circuit emulator with an interface board.

1.3.1 Example of system configuration

Figure 1-1 shows an example of the system configuration of the ID78K4-NS.

Figure 1-1 Example of ID78K4-NS System Configuration



1.4 Operating Environment

The ID78K4-NS has the following hardware and software requirements:

1.4.1 Hardware environment

- (1) **Host machine**
 - IBM PC/ATTM-compatible machine
- (2) **In-circuit emulator (any of the following)**
 - IE-78K4-NS
- (3) **Interface board (any of the following)**
 - IE-70000-PCI-IF-A (for PCI bus)

- IE-70000-CD-IF-A (for PCMCIA card slot)
- IE-70000-PC-IF-C (for ISA bus)

1. 4. 2 Software environment

(1) Operating system (any of the following)

Windows98, Windows2000, Windows NTTM4.0, Windows Me, Windows XP Home Edition, Windows XP Professional

Caution Regardless of which of the OSs above is used, we recommend that the latest Service Pack is installed.

(2) Device file

The device file of the target device to be used.

(3) Device driver

Device driver for interface board (supplied with the product)

Remark The driver can also be downloaded from the Online Delivery Service (ODS).

1. 5 Notes on Source-Level Debugging

To perform source-level debugging, specify an option (-g option) to generate debug information when the source file is compiled. (The -g option is specified by default.)

If this option is not specified, the source file cannot be debugged at the source level.

CHAPTER 2 STARTING AND TERMINATING


This chapter explains the procedure of starting and terminating the ID78K4-NS.

2.1 Starting

Start the ID78K4-NS as follows:


- 1 Turn on the power to the in-circuit emulator, and then turn on the power to the target system.
- 2 Select [Start] -> [Program] -> [NEC Tools32] -> [ID78K4-NS] from the Windows start menu to start the ID78K4-NS. The Configuration dialog box will be opened.
- 3 Set the items related to the operating environment of the ID78K4-NS in the Configuration dialog box. After setting each item, click the <OK> button in the dialog box.

Figure 2-1 Configuration Dialog Box



- 4 The Main window will be opened and the ID78K4-NS can be operated. Mainly use this window for debugging.

Figure 2-2 Main Window




2.2 Terminating

Terminate the ID78K4-NS as follows:

- 1 Select the [File] menu -> [Exit] on the Main window. The following Exit Debugger dialog box will be opened:


Figure 2-3 Exit Debugger Dialog Box



If the above operation is performed while the user program is being executed, the dialog box shown in Figure 2-4 is opened.

In this case, clicking the <Yes> button opens the Exit Debugger dialog box.

Figure 2-4 Message Box for Confirmation of Stopping Execution



- 2 To save the current debugging environment to a project file, click the <Yes> button. If the <No> button is clicked, all the windows are closed and the ID78K4-NS is terminated.

CHAPTER 3 ASSOCIATION WITH PM plus

This chapter explains the procedure and points to be noted when a function to associate the PM plus is used.

The ID78K4-NS can automatically perform a series of operations in development processes, such as **creating source files -> compiling -> debugging -> correcting source files**, in association with the PM plus.

The operation explained in this chapter requires a PM plus(V5.00 or later).

Caution If a load module file is created by using the Windows command prompt, the function to associate the ID78K4-NS with the PM plus cannot be used.

3. 1 Setting Build Mode

To debug the load module file created by the PM plus on the ID78K4-NS at the source level, build to output symbol information for debugging must be performed to create a load module file. This setting can be performed by selecting [Debug Build] on the PM plus.

3. 2 Registering Debugger to PM plus Project

The debugger to be used or the load module files to be downloaded can be specified for each project in the PM plus.

Select a debugger using the following procedure:

3. 2. 1 Selecting debugger

The procedure for selecting the debugger is as follows:

Creating a new workspace

- 1 Select [File] menu -> [New Workspace...] on the PM plus.
-> This opens the dialog box to create a new workspace using the wizard format.
- 2 Creating the necessary settings for the workspace with the wizard, the [New Workspace - Step 7/8 (Select Debugger)] dialog box will be opened. Specify [ID78K4-NS 78K/4 Integrated Debugger] in this dialog box.
-> For details of the setting, refer to the PM plus online help or user's manual.

Using an existing workspace

- 1 Select [Tool] menu -> [Debugger Settings...] on the PM plus.
-> The Debugger Settings dialog box will be opened.
- 2 Specify [ID78K4-NS 78K/4 Integrated Debugger] and click the <OK> button in this dialog box.

The ID78K4-NS is registered as the debugger of the active project.

The ID78K4-NS icon is displayed on the toolbar of the PM plus.

3.3 To Start ID78K4-NS from PM plus

The ID78K4-NS can be started from the PM plus as follows:

- Click the ID78K4-NS starting button on the toolbar of the PM plus.
- Select the [Build] menu -> [Debug] on the PM plus.
- Select the [Build] menu -> [Build and Debug] on the PM plus.
- Select the [Build] menu -> [Rebuild and Debug] on the PM plus.

If the debugging environment of the ID78K4-NS is saved to a project file currently being used by the PM plus, it will be started in the debugging environment saved in the project file.

If the debugging environment of the ID78K4-NS is not saved to a project file being used by the PM plus, the Configuration dialog box is opened. At this time, the device type (Chip name) cannot be changed.

3.3.1 Restoring debugging environment

The previous debugging environment can be restored by the following procedure when the ID78K4-NS is started from the PM plus:

- 1 Create a new workspace (project file : e.g., sample.prj) on the PM plus.

Caution In the ID78K4-NS and PM plus, the environment information is saved to a project file and referenced. The extension of the project file that can be used by the ID78K4-NS and PM plus is prj. For the information that is saved or restored by the project file, refer to the online help or the user's manual of each product.

- 2 Start the ID78K4-NS from the PM plus. Because a new project file is created, set items other than the device type (Chip name) in the Configuration dialog box in the same manner as when only the ID78K4-NS is started.
- 3 Download the load module file to be debugged with the Download dialog box of the ID78K4-NS.
- 4 Debug the load module file on the ID78K4-NS.
- 5 Click the <Yes> button on the Exit Debugger dialog box when the ID78K4-NS is terminated.
-> The debugging environment is saved to the project file (sample.prj) for the PM plus when the ID78K4-NS is terminated. (The debug environment can also be saved to the sample.prj file by overwriting the project file).
- 6 When the ID78K4-NS is next started up after the sample.prj file is read by PM plus, the debug environment at the point when the project file was saved is automatically restored.

3.4 Auto Load

If a bug is found while the load module file is being debugged by the ID78K4-NS, correct the source file using the following procedure. Compiling and re-downloading the file can be automatically executed (Refer to "Auto load by correcting source code (p.19)").

The load module is downloaded again to the ID78K4-NS by compiling and linking the file on the PM plus

with the activated ID78K4-NS (refer to "Auto load by starting debugger (p.19)").

3. 4. 1 Auto load by correcting source code

Correct the source file for auto load as follows:

- 1 Open the source file to be corrected in the Source window. Select [File] menu -> [Open] and specify the file to be corrected on the ID78K4-NS (if the file is already open in the Source window, that window is displayed in the forefront).
-> The specified file will be opened in the Source window.
- 2 Select [Edit] menu -> [Correct Source] on the ID78K4-NS.
-> An editor will be opened and the specified source file will be read.
- 3 Correct the source file on the editor.
- 4 Terminate the editor.

Caution The CPU reset is not performed when the load module file is automatically downloaded. The debug window that was opened when the editor was called, and each event setting will be restored. If the previously used line or symbol has been deleted as a result of correcting the source file, the following happens:

- A software break point may be deleted.
- A variable that was displayed is dimmed.
- The event mark of an event condition is displayed in yellow.

- 5 Select [Build] menu -> [Build and Debug], or [Build] -> [Rebuild and Debug] on the PM plus.

3. 4. 2 Auto load by starting debugger

If the following operation is performed on the PM plus with the ID78K4-NS started, the load module will be automatically downloaded to the ID78K4-NS.

- Selecting the [Build] menu -> [Build and Debug] on the PM plus.
- Selecting the [Build] menu -> [Rebuild and Debug] on the PM plus.

When downloading is completed, the CPU is automatically reset.

CHAPTER 4 FUNCTIONS OF ID78K4-NS

This chapter explains the basic debugging functions of the ID78K4-NS.

- Mapping function
- Setting Debugging Environment
- Program Execution Function
- Event function
- Break function
- Trace function
- Register Manipulation Function
- Memory Manipulation Function
- Watch Function
- Time Measurement Function
- Load/Save Function
- Real-Time internal RAM Sampling Function

4. 1 Mapping function

The following types of mapping functions that can be set in the Configuration dialog box are available:

(1) Internal ROM

A memory area specified as the internal ROM is equivalent to the on-chip internal ROM of the target device.

The target device accesses the memory in the in-circuit emulator.on-chip internal ROM

If the target device writes data to this memory area, a write protect break occurs.

4. 2 Setting Debugging Environment

Set a debugging environment with the Configuration dialog box that is opened when the debugger is started, or the Extended Option dialog box or Debugger Option dialog box.

By creating a file (project file) to which the current debugging environment is saved during debugging, and loading this file, the debugging environment when the project file is saved can be restored.

To manipulate the project file, use the Project File Save dialog box and Project File Load dialog box.

After the project file has been loaded, the size and position of the displayed window are returned to the previous size and status (refer to "Contents Saved to Project File (p.78)").

To load the project file when starting up the debugger, press the <Project...> button in the Configuration dialog box. It can also be specified that the project file is automatically loaded each time the debugger is started up (refer to "To automatically load a project file").

4.3 Program Execution Function

The program execution function is used to start execution of the user program by the CPU and operation of the tracer.

These functions can be executed by selecting the [Run] menu or the corresponding function button, and the execution formats are classified into real-time execution and non-real-time execution.

4.3.1 Real-time execution function

The following real-time execution functions are available:

- [Go]
- [Ignore break points and Go]
- [Start From Here] (Start function)
- [Go & Go]
- [Come Here] (Come function)
- [Restart]

(1) [Go]

The user program is executed starting from the address indicated by the current PC register and is stopped if a set break event condition is satisfied. Each analyzer prepares for operation as soon as execution of the user program is started, and is executed or stopped by a condition set as an event condition (break event condition or trace event condition).

(2) [Ignore break points and Go]

This command executes the user program starting from the address indicated by the current PC register. Execution of the user program continues, ignoring set breakpoints.

(3) [Start From Here] (Start function)

This command executes the user program starting from the specified address. Execution of the user program is stopped when a set break event condition is satisfied.

(4) [Go & Go]

This command executes the user program starting from the address indicated by the current PC register. When the set breakpoint conditions are realized, execution of the user program is paused, and after the contents of the various windows have been updated, execution of the user program is resumed from the address where execution was paused. This operation is repeated until the user executes [Stop].

(5) [Come Here] (Come function)

The user program is executed from the address indicated by the current PC register to the address selected in the line/address display area of the Source window or the Assemble window, and then a break occurs.

While the user program is being executed, the break event currently set does not occur.

(6) [Restart]

The CPU is reset and the user program is executed starting from address 0.

This is the same operation as "resetting the CPU before execution of the user program and executing [Go]".

4. 3. 2 Non-real-time execution function

The following non-real-time execution functions are available:

- [Step In]
- [Next Over]
- [Slow Motion]

(1) [Step In]

The operation differs depending on whether this function is executed in the Source window or the Assemble window.

In the Source window

Step execution of one line of the source text is performed starting from the current PC register value and the contents of each window are updated.

In the Assemble window

One instruction is executed from the current PC register value and the contents of each window are updated.

(2) [Next Over]

The operation differs depending on whether the instruction to be executed is the call/callt/callf instruction or another instruction.

call/callt/callf instruction

Next step execution is performed, assuming the function or subroutine called by the call/callt/callf instruction is one step. (Step execution continues until the nesting level becomes the same as when the call/callt/callf instruction was executed.)

Instruction other than call/callt/callf

The same processing as [Step In] is performed.

(3) [Slow Motion]

Step execution of one line is performed from the address indicated by the current PC register value in the source mode. In the instruction mode, step execution of one instruction is performed. The contents of each window are updated each time step execution is performed. This operation is repeated until the user executes [Stop].

4.4 Event function

An event is a specific status of the target system during user program execution, such as "address 0x1000 is fetched" or "data is written to address 0x2000".

The ID78K4-NS uses an event to trigger an action of functions such as break and trace functions. An event function is used to set, delete, and reference a specific status of the target system that triggers an action (debugging action) as an event condition.

4.4.1 Using event function

So that an action that is triggered by an event function in accordance with the user's debugging aim, the following various event conditions must be set.

Table 4-1 Various Event Conditions

Set Condition	Setting Dialog Box	Contents
Break event	Break dialog box	Condition in which the execution of the user program or the operation of the tracer is stopped.
Trace event	Trace dialog box	Condition in which the process of user program execution is saved to the trace memory.

These various event conditions are set independently as an "Event condition" or "Event link condition", or as a combination of these. To use the event function of the ID78K4-NS, therefore, first create the necessary "Event condition" and "Event link condition", and set the various event conditions shown in the Table 4-1 by using these conditions.

4.4.2 Event condition

Create an event condition in the Event dialog box.

Set an address condition, status condition, and data condition in this dialog box. Specify a combination of these as one event condition and name and register this event condition. The registered event condition can be used to set various event conditions. However, the number of event conditions that can be set is limited.

The event condition that is created when a breakpoint is set in the Source window or the Assemble window can also be used (Breakpoint setting/deletion function (p.116)).

4.4.3 Event link condition

An event link condition specifies sequential constraints for each event, so that two or more events are treated as a single event.

To create an event link condition, use the Event Link dialog box.

By arranging already registered event conditions in this dialog box, one event link condition can be named and registered. The registered event link condition can be used to set various event conditions in the same manner as the event condition. However, the number of event conditions that can be set is limited.

4. 4. 4 Setting of various event conditions

Various event conditions listed in Table 4-1 are individually created in the corresponding dialog box.

To create various event condition, drag and drop the event icon of an event condition or event link condition registered on the Event Manager to the condition area of each setting dialog box.

The created various event condition is set by clicking the <Set> or <OK> button in the setting dialog box. The mark of the event that has been set is displayed in red. After the event has been set, a debugging action occurs as various event condition.

Up to 256 various event conditions can be registered. The number of various event conditions that can be "set" differs depending on the various event condition (refer to "Table 6-26 Maximum number of Events Usable for Event Conditions (p.215)").

4. 5 Break function

The break function is used to stop execution of the user program by the CPU and operation of the tracer.

The following types of break functions are available:

- Event detection break
- Break by Come function
- Software break
- Break on satisfaction of condition of step execution
- Forced break
- Fail-safe break

Caution The event detection break and software break are not performed when [Come Here], [Step In], [Return Out], or [Next Over] described in "Program Execution Function" is executed.

(1) Event detection break

Event detection break is a function used to stop execution of the user program by detecting a set break event condition. This break is valid for [Go], [Go & Go], [Start From Here], and [Restart].

In the case of [Go & Go], however, the contents of each window are updated and the user program is executed again after the event detection break has occurred. Set a break event as follows:

- Set as an execution event in the Source window or Assemble window (refer to "Breakpoint setting/deletion function (p.116)").
- Set in the Break dialog box.

(2) Break by Come function

The Break by Come function is used to stop the user program that is executed by the [Come Here] command, by detecting an address specified in the Source window or Assemble window. When execution of the user program has been stopped, the breakpoint by the Come function is eliminated.

While the user program is being executed by using this function, a break event that has been set does not occur.

(3) Software break

Software break is a function to replace the instruction at the specified address with a debugger-dedicated software break instruction and stop the user program executed by the [Go], [Go & Go], [Start From Here], or [Restart] command.

As many software break events as necessary can be set (however, only 100 of them are valid).

Because the instruction at the specified address is rewritten, however, a software break event cannot be set on the external ROM or stopped by the access timing of a variable.

While one event detection break uses one hardware resource per event condition, the feature of a software break is that a breakpoint is set at two or more addresses.

Set a software break event in the Source window or Assemble window (refer to "Breakpoint setting/deletion function (p.116)").

The Software Break Manager manages software breaks (switching enable/disable, etc.).

(4) Break on satisfaction of condition of step execution

Break on satisfaction of condition of step execution is a function used to stop execution of the user program when the end condition of each command ([Step In], [Next Over], [Return Out], and [Slowmotion]) is satisfied.

Because one instruction is executed, stopped, and the condition is confirmed at one time, the processing time is longer than that of real-time execution.

(5) Forced break

Forced break is a function used to forcibly stop execution of the user program. It is valid for all the program execution commands. Force break includes the following:

- [Stop] command: Forcibly stops execution of the user program.

(6) Fail-safe break

A fail-safe break is a function for forcibly stopping the user program when the user program has executed a prohibited action on the memory and registers.

The types of fail-safe break functions are as follows:

Non-map break	This break occurs if an attempt is made to access a non-map area.
Write-protect break	This break occurs if an attempt is made to write to memory that must not be written to, such as ROM.
SFR Illegal access break	This break occurs if an attempt is made to access SFR illegally.
Stack Overflow	This break occurs as the result of stack overflow.
Relocation Break	This break occurs if a location instruction different from the default setting was executed.

Note that if a fail-safe break occurs, there may be a problem with the user program or the set environment of the ID78K4-NS may be wrong.

4.6 Trace function

The trace function is used to save the history of the data indicating the execution process of the user program to the trace memory.

The trace data saved to the trace memory can be checked in the Trace window.

The item to be displayed in the Trace window can be selected in the Trace Data Select dialog box.

To use the trace function, check that the trace function is valid by selecting the [Option] menu -> [Tracer ON]. The trace function is valid in the default status, and all data is unconditionally traced (unconditional trace) when the program is executed.

4.6.1 Operation of trace

The trace memory of the ID78K4-NS is a ring buffer with a capacity of 32,768 frames.

The operation of the tracer differs as indicated in (1) to (3) below, depending on the style of execution of the user program.

(1) Operation during real-time execution

The operation of the tracer differs depending on the specified trace mode.

All trace (Unconditional trace)	Trace is started when real-time execution of the program is specified, and ends when a break occurs.
Conditional trace	Trace is started or stopped by the condition set in the Trace dialog box (if a break occurs while a trace is being executed, however, trace is stopped immediately).

These trace modes can be set by selecting the [Run] menu -> [Conditional Trace /Unconditional Trace].

(2) Operation during Step In execution

The tracer operates every step execution, and trace data of one step is successively added to the trace memory.

(3) Operation during Next Over execution

The operation of the tracer differs depending on the instruction to which Next Over is to be executed.

Table 4-2 Operation of Tracer (During Next Over Execution)

Instruction	Tracer Operation
call/callt/callf instruction	The call/callt/callf instruction and the subroutine that was called are traced.
Other instructions	The same operation as that during Step In execution is performed.

4.6.2 Trace condition setting function

The following setting types of trace condition are available:

(1) Setting trace mode

Two trace modes, unconditional trace and conditional trace, are available.

(2) Setting of tracer control mode

The tracer has a ring structure.

The following operation modes of the tracer can be selected from the [Run] menu:

Non-Stop	Goes around the trace memory and overwrites data from the oldest frame (default).
Full Stop	Goes around the trace memory and then stops the tracer.

(3) Setting trace event condition

A trace event condition triggers starting/stopping trace execution when a conditional trace is set.

A trace event condition is set in the Trace dialog box.

The following types of trace event conditions can be specified:

Section trace	Executes a trace between two specified conditions (in a specific zone). A section trace (zone trace) can be executed by setting a trace start event and trace end event and executing a conditional trace.
Qualify trace	Executes a trace only when a condition is satisfied. If two or more events are set as qualify trace events, a qualify trace can be executed by executing a conditional trace. A qualify trace can be executed by setting a qualify trace event and executing a conditional trace.

4. 7 Register Manipulation Function

The register manipulation function is used to display or change the contents of the general-purpose registers, control registers, and SFR.

This function can be used in the Register window or SFR window. To change the register to be displayed in each window, use the SFR Select dialog box.

A user-defined I/O port can be displayed or changed by registering it to the Add I/O Port dialog box.

4. 8 Memory Manipulation Function

As a memory manipulation function, the memory contents can be displayed or changed by using mnemonic codes, hexadecimal codes, and ASCII codes.

This function can be used in the Memory window or Assemble window. The contents of memory can be copied, initialized, and compared.

4. 9 Watch Function

Data (variable) values can be checked or changed in the Watch window.

Local variables can be checked or changed in the Local Variable window.

The contents of a variable value can be easily referenced in the Source window or Assemble window by placing the mouse cursor on the selected variable (balloon watch function).

4. 10 Time Measurement Function

The time measurement function is used to measure the execution time for the section that is subject to section trace.

The maximum execution measurement time is about 14 minutes 33 seconds (resolution: 203.45 ns).

4. 11 Load/Save Function

The load/save function is used to load/save each file.

The ID78K4-NS loads/saves each file individually.

These three types of files can be handled:

view files	File recording the screen information when it is saved. By loading this file, a reference file is opened in the Source window.
Information file	File recording the set data and debugging environment as information on the user program and debugger.
Setting files	File recording the window information.

4. 11. 1 View files

The list of the view files to be handled is shown below:

These files can be manipulated in the View File Load dialog box and View File Save dialog box.

Table 4-3 List of View Files

File Type	Contents
Source Text (*.SVW)	Source window view file Records the source text in the Source window.
Assemble (*.DIS)	Assemble window view file Records the assembly information in the Assemble window.
Memory (*.MEM)	Memory window view file Records the memory information in the Memory window.
Register (*.RGW)	Register window view file Records the register information in the Register window.
Local Variable (*.LOC)	Local Variable window view file Records the local variable information in the Local Variable window.
Stack Trace (*.STK)	Stack Trace window view file Records the stack trace information in the Stack Trace window.
Trace (*.TVW)	Trace window view file Records the trace information in the Trace window.

Table 4-3 List of View Files

File Type	Contents
Watch (*.WCH)	Watch window view file Records the watch information in the Watch window.
SFR (*.SFR)	SFR window view file Records the SFR information in the SFR window.
Console (*.LOG)	Console window view file Records the information in the Console window.

4. 11. 2 Information files

The list of the information files to be handled is shown below.

Table 4-4 List of Information Files

File Name (Extension)	Contents	Dialog Box
Object file (*.HEX)	Stores the object codes of the user program.	Download dialog box, Upload dialog box
Project File (*.PRJ)	Stores the debugging environment	Project File Load dialog box, Project File Save dialog box
Binary file (*.BIN)	Records data in binary format.	Download dialog box, Upload dialog box

A project file sets the display information, size, and display position of a window or dialog box, and restores the debugging environment to the previous status (when the project file was saved) when it is loaded.

4. 11. 3 Environment files

The list of the environment files to be handled is shown below:

These files can be manipulated in the Environment File Load dialog box and Environment File Save dialog box.

Table 4-5 Types of Environment Files Handled

File Name (Extension)	Contents
Watch environment file (*.WCH)	Stores the watch setting contents of the Watch window.
SFR environment file (*.OR)	Stores the SFR setting contents of the SFR window.
Event environment file (*.EVN)	Stores the event setting contents of the Event Manager.

4. 12 Real-Time internal RAM Sampling Function

The following real-time RAM sampling function is available.

- Real-time internal RAM sampling function

The real-time RAM sampling function is used to read and display the memory contents, even during user program execution, if a variable allocated to a range in which the memory contents can be read, or the memory contents are displayed.

This function can be checked in the Watch window or Memory window.

Settings related to this function are performed in the Extended Option dialog box.

CHAPTER 5 OPERATION

This chapter explains the flow of basic debugging operations using the ID78K4-NS and the following functions:

- Flow of Debugging Operations
- Active Status and Static Status
- Jump Function
- Trace Result with Linking Window

5. 1 Flow of Debugging Operations

(1) Setting debugging environment

Prepare for debugging.

-> Mapping function

-> Configuration dialog box

Download a load module file to be debugged.

-> Download dialog box

(2) Displaying source program

By downloading a load module file with debug information, the corresponding source file is automatically displayed.

-> Source window

(3) Displaying disassemble result

The disassembled result of the downloaded user program is displayed.

-> Assemble window

(4) Setting breakpoint

Breakpoints can be set easily in the Source window, Assemble window, and Watch window.

-> Breakpoint setting/deletion function

-> To set a breakpoint for read/write access to a variable

(5) Setting event

Register event conditions and event link conditions.

-> Event dialog box, Event Link dialog box

Setting of various event conditions

Set a various event condition by using the Event Manager or an event icon in the event manager area on each various event setting dialog box.

Each various event condition corresponds to the following various event setting dialog box.

Break event condition -> Break dialog box

Trace event condition -> Trace dialog box

Checking setting status of various event conditions

-> Event dialog box or the event manager area in each various event setting dialog box

Checking setting status of software breakpoint

-> Software Break Manager

(6) Executing user program

By executing the user program, the PC advances to the set breakpoint, break event, or forced breakpoint (refer to "Program Execution Function (p.21)").

Use the execution control button or [Run] menu to execute the user program.

(7) Checking trace data

-> Trace window

(8) Editing, checking, and changing memory contents

-> Memory window, Memory Copy dialog box, Memory Fill dialog box, Memory Compare dialog box, Memory Compare Result dialog box

(9) Registering, checking, and changing variable value

-> Watch window, Quick Watch dialog box, Add Watch dialog box, Change Watch dialog box, Local Variable window

(10) Checking stack contents

-> Stack Trace window

(11) Checking and changing of registered contents of register value

-> Register window

The value of the PC register can also be checked in the Source window and Assemble window.

(12) Checking and changing SFR value

-> SFR window, SFR Select dialog box

(13) Registering, checking, and changing user-defined I/O port value

-> Add I/O Port dialog box, SFR window

(14) Changing mnemonic and executing online assembly (Assemble window only)

-> Assemble window, Source window

(15) Checking execution time of user program

-> Timer dialog box, Timer Result dialog box, Trace window

(16) Searching character string in each window

By clicking the < Search...> button in the window in which searching is to be executed, the following

types of searching dialog boxes are opened:

Source Search dialog box, Assemble Search dialog box, Memory Search dialog box, Trace Search dialog box

(17) Manipulating view file

-> View File Save dialog box, View File Load dialog box

(18) Uploading memory contents and coverage result

-> Upload dialog box

(19) Saving debugging environment to file

-> Project File Save dialog box, Environment File Save dialog box

(20) Terminating ID78K4-NS

-> Exit Debugger dialog box

5.2 Active Status and Static Status

The Source window, Assemble window, and Memory window have the following two window statuses:

Active status	<p>The display position and contents of the window in the active status are automatically updated in association with the current PC value.</p> <p>This window is also the jump destination of the jump function. If this window is linked with the Trace window, the contents displayed in the active window are updated in association with the Trace window. Only one window can be opened in the active status.</p> <p>Select this status by the [Window] menu.</p>
Static status	<p>The display position of the window in the static status does not move in association with the current PC value, but the displayed contents are updated.</p> <p>The static window is not used as the jump destination of the jump function. In addition, it is not linked with the Trace window.</p> <p>If an active window is already open, the next window is opened in the static status. Two or more static windows can be opened at the same time.</p> <p>Select this status by the [Window] menu.</p>

Because two or more static windows can be opened, the current status of the windows can be temporarily held.

5.3 Jump Function

The jump function is used to jump to Source window, Assemble window, or Memory window from a jump pointer that is the line or address on which the cursor is placed, and display the contents of the jump destination window from the jump pointer.

You can jump among the above windows, or from Trace window, Stack Trace window, Event Manager, and Register window to the above windows.

Jump method

- 1 Move the cursor to the line or address that is to be used as the jump pointer, on the window from which jumping is possible (select an event icon on the Event Manager).
- 2 Select the following menu item to which execution is to jump from the [Jump] menu.
 Source window->Select [Source].
 Assemble window->Select [Assemble].
 Memory window->Select [Memory].

Caution If a program code does not exist on the line at the cursor position, the first address of the line with a program code above or below that line is used as the jump pointer.

Details of jump source address

To jump from the following windows, the jump destination is as follows:

- To jump from the Trace window to the Memory window, the jump source address differs depending on the cursor position in the trace result display area.

If the cursor is at an access address, access data, or access status	-> Access address
Other than above	-> Fetch address
To jump to the Source window or Assemble window	-> Fetch address

- To jump from the Register window, move the cursor to a register value.
- To jump from the Stack Trace window, the jump destination is as follows:

[With current function]

- If the jump destination is the Source window -> Jumps to the current PC line.
- If the jump destination is a window other than the Source window -> Jumps to the current PC address.

[With function other than current function]

- If the jump destination is the Source window
-> Jumps to the line that calls a nested function.
- If the jump destination is a window other than the Source window
-> Jumps to the address next to the instruction that calls a nested function.

5.4 Trace Result with Linking Window

By linking Trace window with each window (Source window, Assemble window, or Memory window), the corresponding part can be displayed on the linked window, by using the address at the cursor position on the Trace window as a pointer.

If the cursor is moved on the Trace window, the corresponding part on the linked window is highlighted or indicated by the cursor position.

To link a window

- 1 Set the Trace window as the current window.
- 2 Select a window to be linked with the [View] menu -> [Window Synchronize].
Source window ->Select [Source].
Assemble window ->Select [Assemble].
Memory window ->Select [Memory].
- 3 Move the cursor to the line to be linked in the trace result display area of the Trace window.
- 4 Using the address of the line selected in 3 as a pointer, the corresponding part is highlighted (or indicated by the cursor position) in the display area of the window selected in 2.

Caution The linking source address differs as follows depending on the cursor position in the trace result display area if the Memory window is linked.

Access address, access data, access status -> Access address

Others -> Fetch address

When the Source window or Assemble window is linked, the fetch address is always used as the pointer.

CHAPTER 6 WINDOW REFERENCE

This chapter explains the details of the window/dialog box functions of the ID78K4-NS.

6.1 Window List

Table 6-1 lists the windows of the ID78K4-NS.

Table 6-1 Window List

Window Name	Contents
Main window (refer to p.40)	This window is displayed first, when the debugger is started. It controls execution of the user program. Various windows are opened from this window.
Configuration dialog box (refer to p.59)	Displays and sets the debugger operation environment.
Extended Option dialog box (refer to p.65)	This dialog box is used to display and set the extended options of the debugger.
Debugger Option dialog box (refer to p.68)	Displays and sets options.
Font dialog box (refer to p.76)	Displays the types of fonts displayed in the Source window and sets the size of the font.
Project File Save dialog box (refer to p.78)	Saves the debug environment.
Project File Load dialog box (refer to p.81)	Loads the debug environment.
View File Save dialog box (refer to p.83)	Saves the contents of the current window to a view file or event setting file.
View File Load dialog box (refer to p.87)	Reads the view file or source event setting file of each window.
Environment File Save dialog box (refer to p.90)	Saves the contents of the current window to a environment file or event setting file.
Environment File Load dialog box (refer to p.92)	Reads the environment file or source event setting file of each window.
Download dialog box (refer to p.94)	Loads an object file and binary file.
Upload dialog box (refer to p.98)	Saves the memory contents to a file.
Browse dialog box (refer to p.101)	Debugger Option dialog box, Select the file to be set in Source Search dialog box.
Source Text Move dialog box (refer to p.105)	This dialog box is used to specify a file to be displayed in Source window and the position from which displaying the file is to be started.
Address Move dialog box (refer to p.103)	Specifies the start address to display the contents of the Memory window, Assemble window or Coverage window.
Trace Move dialog box (refer to p.108)	Specifies the start address to display the contents of the Trace window.
Symbol To Address dialog box (refer to p.111)	Displays the addresses and symbol values of variables and functions.
Source window (refer to p.114)	Displays a source file or text file.
Source Search dialog box (refer to p.128)	Searches for a character string in a source file.
Assemble window (refer to p.131)	Disassembles the program and executes online assembly.

Table 6-1 Window List

Window Name	Contents
Assemble Search dialog box (refer to p.138)	Searches the contents of the Assemble window.
Memory window (refer to p.141)	Displays and modifies the contents of memory.
Memory Search dialog box (refer to p.146)	Searches the contents of the Memory window.
Memory Fill dialog box (refer to p.149)	Initializes the memory contents with specified data.
Memory Copy dialog box (refer to p.151)	Copies the memory.
Memory Compare dialog box (refer to p.153)	Compares the memory.
Memory Compare Result dialog box (refer to p.155)	Displays the result of comparing the memory.
Watch window (refer to p.157)	Displays and modifies variables.
Quick Watch dialog box (refer to p.164)	Temporarily displays and changes the value of a variable.
Add Watch dialog box (refer to p.168)	Registers a variable to be displayed in the Watch window.
Change Watch dialog box (refer to p.172)	Changes a variable to be displayed in the Watch window.
Local Variable window (refer to p.175)	Displays and changes the local variable in the current function.
Stack Trace window (refer to p.178)	Displays and changes the stack contents of the current user program.
Register window (refer to p.182)	Displays and changes the contents of the registers (general-purpose registers and control registers).
SFR window (refer to p.187)	Displays and changes the contents of the SFR.
SFR Select dialog box (refer to p.192)	Selects a SFR or I/O port to be displayed in the SFR window.
Add I/O Port dialog box (refer to p.195)	Registers an I/O port to be displayed in the SFR window.
Trace window (refer to p.198)	Displays trace results.
Trace Search dialog box (refer to p.205)	Searches trace data.
Trace Data Select dialog box (refer to p.212)	Selects items to be displayed in the Trace window.
Event Manager (refer to p.215)	Displays, enables/disables, and deletes each event condition.
Event dialog box (refer to p.226)	Registers and displays event conditions.
Event Link dialog box (refer to p.234)	Registers and displays event link conditions.
Break dialog box (refer to p.239)	Registers, sets, and displays break event conditions.
Trace dialog box (refer to p.243)	Registers, sets, and displays trace event conditions.
Timer dialog box (refer to p.248)	Displays execution time measurement result, and registers, sets, and displays timer event conditions.
Timer Result dialog box (refer to p.251)	Displays execution time measurement results.
Delay Count dialog box (refer to p.253)	Sets the delay count of a trace.
Software Break Manager (refer to p.223)	Display, enable or disable, and delete software breaks.
Reset Debugger dialog box (refer to p.255)	Initializes the ID78K4-NS, target CPU, and symbol information.
About dialog box (refer to p.257)	Displays the version of the ID78K4-NS.

Table 6-1 Window List

Window Name	Contents
Exit Debugger dialog box (refer to p.259)	Terminate the ID78K4-NS.
Console window (refer to p.261)	Inputs commands.
Error/Warning dialog box	Displays error/warning messages.

6.2 Explanation of Windows

This section explains each debug window as follows:

Window/dialog name

Briefly explains the function of the window or dialog box and points to be noted.

In addition, the display image of the window or dialog box is also illustrated.

Items of related operation are also explained.

Opening

Explains how to open the window or dialog box.

If two or more methods of opening are listed, the window or dialog box can be opened by any of them.

Explanation of each area

Explains items to be set to or displayed in each area of the window or dialog box.

Functions often used (right-click menu)

Explains the context menu that is displayed in the window when the right mouse button is clicked.

From the context menu, convenient functions often used in this window can be selected with a single action (window only).

Function buttons

Explains the operation of each button in the window or dialog box.

Related operations

Explains the operation of a window or dialog box related to this window or dialog box.

Main window


This window is automatically opened when the ID78K4-NS is started up and initialized. It exists on the screen until the ID78K4-NS is terminated. Other windows are manipulated from this window. Execution of the user program is controlled in this window.

Execution of the user program is controlled in the following three modes:

Source mode	Debugs the user program at the source level.
Instruction mode	Debugs the user program at the instruction level.
Auto mode	Automatically selects the source mode or instruction mode. Step execution is performed at the source level when the Source window is active (except in the mixed display mode), and at the instruction level when the Assemble window is active. When neither of these windows is active, step execution is performed at the source level.

The auto mode is set when the debugger is started up.

Figure 6-1 Main Window



This section explains the following items:

- Toolbar
- Menu bar
- Window display area
- Status bar

Toolbar

The toolbar is a collection of buttons that can execute often-used commands with a single action. Each

button is graphically displayed to indicate the image of its function. This toolbar can be displayed in the following two modes. The modes are selected in Debugger Option dialog box.

Figure 6-2 Toolbar with Only Graphics (default)













Figure 6-3 Toolbar with Graphics and Characters



Whether the toolbar is displayed or not can be specified by selecting [Option] -> [Tool Bar] from the menu bar. This toolbar can be moved inside or outside the main window by dragging and dropping with the mouse.

The meaning of each button on the toolbar is as follows. When the mouse cursor is placed on a button of the toolbar, a tool hint pops up several seconds later.

 Stop	Stops execution of the user program. Same function as [Run] -> [Stop] on the menu bar.
 ReGo	Resets the CPU and executes the user program. Same function as [Run] -> [Restart] on the menu bar.
 Go	Executes the user program from the current PC without resetting the CPU. Same function as [Run] -> [Go] on the menu bar.
 Go	Executes the user program without a break occurrence. Same function as [Run] -> [Ignore break points and Go] on the menu bar.
 Ret	The user program is real-time executed until execution returns. Same function as [Run] -> [Return Out] on the menu bar (This command is used for a function described in C language.)
 Step	Step execution (executes instructions in the program one by one.) If a function or subroutine is called, its instructions are executed one by one. Same function as [Run] -> [Step In] on the menu bar.
 Over	Next step execution (executes the program, assuming a function/call statement as one step.) If a function or subroutine is called, its instructions are not executed on a step-by-step basis. Same function as [Run] -> [Next Over] on the menu bar.
 Res	Resets the CPU. Same function as [Run] -> [CPU Reset] on the menu bar.
 Open	Opens View File Load dialog box. Same function as [File] -> [Open...] on the menu bar.
 Load	Opens Download dialog box. Same function as [File] -> [Download...] on the menu bar.

 Proj	Opens Project File Load dialog box. Same function as [File] -> [Project] -> [Open...] on the menu bar.
 Src	Displays the source text. Opens Source window. Same function as [Browse] -> [Source Text] on the menu bar.
 Asm	Displays the disassemble results. Opens Assemble window. Same function as [Browse] -> [Assemble] on the menu bar.
 Mem	Displays the contents of the memory. Opens Memory window. Same function as [Browse] -> [Memory] on the menu bar.
 Wch	Displays the watch contents. Opens Watch window. Same function as [Browse] -> [Watch] on the menu bar.
 Reg	Displays the register contents. Opens Register window. Same function as [Browse] -> [Register] on the menu bar.
 Sfr	Displays the contents of the SFR. Opens SFR window. Same function as [Browse] -> [Sfr] on the menu bar.
 Loc	Displays the local variable contents. Opens Local Variable window. Same function as [Browse] -> [Local Variable] on the menu bar.
 Stk	Displays the stack contents. Opens Stack Trace window. Same function as [Browse] -> [Stack Trace] on the menu bar.
 TrW	Displays the trace results. Opens Trace window. Same function as [Browse] -> [Trace] on the menu bar.
 Mgr	Opens Event Manager. Same function as [Event] -> [Event Manager] on the menu bar.
 Evn	Registers and sets events. Opens Event dialog box. Same function as [Event] -> [Event...] on the menu bar.
 Brk	Registers and sets break events. Opens Break dialog box. Same function as [Event] -> [Break...] on the menu bar.
 Trc	Registers and sets trace events. Opens Trace dialog box. Same function as [Event] -> [Trace...] on the menu bar.
 Tim	Registers and sets timer events. Opens Timer dialog box. Same function as [Event] -> [Timer...] on the menu bar.


Menu bar

The menu bar consists of the following menus:

- (1) [File] menu

- (2) [Edit] menu
- (3) [View] menu
- (4) [Option] menu
- (5) [Run] menu
- (6) [Event] menu
- (7) [Browse] menu
- (8) [Jump] menu
- (9) [Window] menu
- (10) [Help] menu

(1) [File] menu



Open...	Loads a view file, source file, or text file. Opens View File Load dialog box. The operation differs depending on the extension of the file selected in the dialog box.
Save As...	Saves the contents displayed on the current window to the file whose name is specified. Opens View File Save dialog box.
Close	Closes the current window.
Download...	Downloads a program. Opens Download dialog box.
Upload...	Uploads a program. Opens Upload dialog box.
Project	Manipulates a project file.
Open...	Opens a project file. Opens Project File Load dialog box.
Save	Overwrites the current status to the project file currently being read to the debugger.
Save As...	Saves the current status to a specified project file. Opens Project File Save dialog box.
Environment	Manipulates a environment file.

Open...	Opens a environmet file. Opens Environment File Load dialog box.
Save As...	Saves the current status to a specified environmet file. Opens Environment File Save dialog box.
Debugger Reset...	Initializes the target CPU, symbols, and debugger. Opens Reset Debugger dialog box.
Exit	Terminates the debugger. Opens Exit Debugger dialog box.
(Open file)	Lists the names of the files opened.

(2) [Edit] menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
	Cut		Ctrl+X						
	Copy		Ctrl+C						
	Paste		Ctrl+V						
	Write in		Enter						
	Restore		Esc						
	Memory								
	Edit Source								

Fill...
 Copy...
 Compare...

Cut	Cuts a selected character string and saves it to the clipboard buffer.
Copy	Copies a selected character string and saves it to the clipboard buffer.
Paste	Pastes the contents of the clipboard buffer to the text cursor position.
Write in	Writes the modified contents to the target.
Restore	Cancels the modification.
Memory	Manipulates the memory contents.
Fill...	Initializes the memory. Opens Memory Fill dialog box.
Copy...	Copies the memory. Opens Memory Copy dialog box.
Compare...	Compares the memory. Opens Memory Compare dialog box.
Edit Source	Opens the source file displayed in the active Source window with the editor specified by the PM plus when the PM plus runs.

(3) [View] menu


This menu displays different items depending on the window that is active. The following items may be displayed:

- Common items
- Source window-dedicated items
- Assemble window-dedicated items
- Memory window-dedicated items
- Watch window-dedicated items
- Register window-dedicated items
- SFR window-dedicated items
- Local Variable window-dedicated items, Stack Trace window-dedicated items
- Trace View window-dedicated items
- Event Manager-dedicated items


Common items

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
		Search...		Ctrl+G					
		Moye...		Ctrl+J					
		Quick Watch...		Ctrl+W					
		Add Watch...							
		View Watch							
		Change Watch...							
		Delete Watch		Del					
		Symbol...							


Search...	Performs a search. Opens the search dialog box corresponding to the current window. Same operation as the <Search> button. However, this item cannot be selected when the Trace window is open.
Moye...	Moves the display position. Opens the specification dialog box corresponding to the current window.
Quick Watch...	Temporarily displays the contents of the specified data. Opens Quick Watch dialog box.
Add Watch...	Registers the specified data to the Watch window. Opens Add Watch dialog box.
View Watch	Adds the selected data to the Watch window. If the data is a symbol, it is added in accordance with the setting of Debugger Option dialog box.
Change Watch...	Changes the data on the line selected by the Watch window. Opens Change Watch dialog box. This menu is valid only when a variable is selected in Watch window.
Delete Watch	Deletes the selected watch point from the Watch window. This menu is valid only when a variable is selected in Watch window.
Symbol...	Displays the address of the specified variable or function, or the value of the specified symbol. Opens Symbol To Address dialog box.

Source window-dedicated items

Create Break Event	Creates a break event by using the selected variable.
Break when <u>A</u> ccess to this Variable	Creates a break event that can be accessed for read/write.
Break when <u>W</u> rite to this Variable	Creates a break event that can be accessed for write.
Break when <u>R</u> ead from this Variable	Creates a break event that can be accessed for read.
<u>C</u> lear	Deletes a break event corresponding to the selected variable.
Event?	Displays the event information of a line at the cursor position or a selected variable name. If an event is set, Event dialog box is opened.
Mix	Specifies whether the results of assembly are displayed in mixed display mode, or not displayed. Checked: Mixed display Not checked: No display (default)

Assemble window-dedicated items

Event?	Displays the event information of the address at the cursor position. If an event is set, Event dialog box is opened.
---------------	--


Memory window-dedicated items

Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.

Hex	Displays hexadecimal numbers (default).
Nibble	Displays in 4-bit units.
Byte	Displays in 8-bit units (default).
Word	Displays in 16-bit units.
Double Word	Displays in 32-bit units.
Ascii	Selects whether ASCII characters are displayed or not. Checked: Displayed Not checked: No display (default)
Little Endian	Displays in little endian (default).
Big Endian	Displays in big endian.

Watch window-dedicated items

Only "selected items" can be manipulated in the Watch window.



Create Break Event	Creates a break event by using the selected item.
Break when Access to this Variable	Creates a break event that can be accessed for read/write.
Break when Write to this Variable	Creates a break event that can be accessed for write.
Break when Read from this Variable	Creates a break event that can be accessed for read.
Clear	Deletes a break event corresponding to the selected item.
Event?	Displays the event information of the variable selected. If an event is set, Event dialog box is opened.
Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers.

String	Displays character strings.
Proper	Displays the default value of each variable. Symbols are displayed in accordance with the setting of Debugger Option dialog box (default).
Byte	Displays in 8-bit units.
Word	Displays in 16-bit units.
General	Displays in 24-bit units.
Double Word	Displays in 32-bit units.
Adaptive	Displays the default value of each variable. Only this item is valid for a symbol in C language. Symbols are displayed in accordance with the setting of Debugger Option dialog box (default).
Up	Moves up one line.
Down	Moves down one line.
Compulsion Read	Forcibly reads the peripheral I/O registers that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in SFR window or Add I/O Port dialog box.

Register window-dedicated items

<input type="radio"/> Bin <input type="radio"/> Oct <input type="radio"/> Dec <input checked="" type="radio"/> Hex
<input type="radio"/> Absolute Name <input type="radio"/> Functional Name


Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (default).
Absolute Name	Displays register names as absolute names.
Functional Name	Displays register names as function names (default).

SFR window-dedicated items

<input type="radio"/> Bin <input type="radio"/> Oct <input type="radio"/> Dec <input checked="" type="radio"/> Hex
<input type="radio"/> Sort By Name <input checked="" type="radio"/> Sort By Address <input type="radio"/> UnSort
<input checked="" type="checkbox"/> Attribute
<input type="button" value="Pick Up"/> <input type="button" value="Select..."/>
<input type="button" value="Compulsion Read"/>


Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (default).
Sort By Name	Displays in alphabetical order.
Sort By Address	Displays in address order (default).
Unsort	Does not sort.
Attribute	Displays or does not display an attribute field (Attribute). Checked: Displayed (default) Not checked: Not displayed
Pick Up	Displays only the registers selected in SFR Select dialog box. Checked: Displays only the selected register. Not checked: Displays all the registers (default).
Select...	Opens SFR Select dialog box.
Compulsion Read	Forcibly reads the SFR that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in SFR window or Add I/O Port dialog box.

Local Variable window-dedicated items, Stack Trace window-dedicated items



Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays octal numbers.
String	Displays character strings.
Proper	Displays the default value of each variable (default).

Trace View window-dedicated items



Select...	Selects the contents to be displayed. Opens Trace Data Select dialog box.
Pick Up	Performs the setting for pickup display.
Off	Does not pick up and display (default).
Search	Picks up and displays a frame that satisfies the search condition.
BRM1	Picks up and displays the first M1 fetch frame after a program branch.
Mix	Specifies whether the results of assembly are displayed in mixed display mode, or not displayed. Checked: Mixed display Not checked: No display (default)
Window Synchronize	Sets linking between Trace window and the following windows. A checked window is linked.
Source Text	Links Source window.
Assemble	Links Assemble window.
Memory	Links Memory window.

Event Manager-dedicated items

Select <u>A</u> ll Event	Ctrl+A
Delete <u>E</u> vent	Del
Sort By <u>N</u> ame	
Sort By <u>K</u> ind	
• <u>U</u> nSort	
<u>D</u> etail	
• <u>O</u> verview	

Select <u>A</u> ll Event	Selects all the events registered to the Event Manager.
Delete <u>E</u> vent	Deletes a selected event.
Sort By <u>N</u> ame	Displays icons in the order of event names.
Sort By <u>K</u> ind	Displays icons in the order of event types.
<u>U</u> nSort	Does not sort icons (default).
<u>D</u> etail	Detailed display
<u>O</u> verview	List display (default)

(4) [Option] menu

<u>F</u> ile	<u>E</u> dit	<u>V</u> iew	<u>O</u>ption	<u>R</u> un	<u>E</u> vent	<u>B</u> rowse	<u>J</u> ump	<u>W</u> indow	<u>H</u> elp
			✓ <u>T</u> ool Bar ✓ <u>S</u> tatus Bar ✓ <u>B</u> utton						
			<u>S</u> ource Mode <u>I</u> nstruction Mode • <u>A</u> uto Mode						
			<u>C</u> onfiguration... <u>E</u> xtended Option... <u>D</u> ebugger Option... Add I/O <u>P</u> ort...						
			<u>T</u> race Clear						

Tool Bar	Selects whether the tool bar is displayed (default) or not.
Status Bar	Selects whether the status bar is displayed (default) or not.
Button	Selects whether the buttons on each window are displayed (default) or not.
Source Mode	Executes step execution at the source level (in line units).
Instruction Mode	Executes step execution at the instruction level (in instruction units).
Auto Mode	Automatically selects step execution at the source level or step execution at the instruction level (default). Step execution is performed at the source level (in a mode other than mixed display mode) if Source window is active. It is performed at the instruction level if Assemble window is active. If neither window is active, step execution is performed at the source level.
Configuration...	Sets the environment. Opens Configuration dialog box.
Extended Option...	Sets extended functions. Opens Extended Option dialog box.
Debugger Option...	Sets debugger options. Opens Debugger Option dialog box.
Add I/O Port...	Adds user-defined I/O ports. Opens Add I/O Port dialog box.
Trace Clear	Clears the trace data. This item is displayed only when Trace window is active.

(5) [Run] menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
				Restart	F4				
				Stop	F2				
				Go	F5				
				Ignore break points and Go	Ctrl+F5				
				Return Out	F7				
				Step In	F8				
				Next Over	F10				
				Start From Here	Shift+F6				
				Come Here	F6				
				Go & Go					
				Slowmotion					
				CPU Reset	F3				
				Change PC	Ctrl+F9				
				Break Point	F9				
				Software Break Point					
				Delete All Breakpoints					
				• Uncond. Trace ON					
				Cond. Trace ON					
				Tracer Start					

Restart	Resets the emulation CPU and executes the program. Same operation as the ReGo button
Stop	Forcibly stops program execution. Same operation as the Stop button
Go	Executes the program from the current PC. Same operation as the Go button
Ignore break points and Go	Executes the program, ignoring break points being set. Same operation as the GoN button
Return Out	The user program is real-time executed until execution returns. Same operation as the Ret button This menu item is available only for a function described in C language.
Step In	Executes the instructions in the program one by one (step execution). If a function or subroutine is called, its instructions are executed one by one. Same operation as the Step button
Next Over	Executes the instructions in the program one by one (Next step execution). If a function or subroutine is called, its instructions are not executed on a step-by-step basis. Same operation as the Over button
Start From Here	Executes the program from the cursor position on Source window or Assemble window (Start function).
Come Here	Executes the program from the current PC to the cursor position in the Source window or Assemble window (Come function).


Go & Go	Continues executing the program. If a break occurs because a break condition is satisfied, the window is updated and the program is executed again. Each time a break has occurred, the same operation as clicking the Go button is performed.
Slowmotion	Continues step execution. Each time step execution has been performed, the window is updated and then step execution is performed again. Same operation as clicking the Step each time a break has occurred.
CPU Reset	Resets the emulation CPU. Same operation as the Res button
Change PC	Sets the address at the cursor position in the Source window or Assemble window to the PC.
Break Point	Sets or cancels a breakpoint at the cursor position in the Source window or Assemble window.
Software Breakpoint	Sets or cancels a software breakpoint at the cursor position in the Source window or Assemble window.
Delete All Breakpoints	Deletes all software breakpoints that are set.
Uncond. Trace ON	Validates unconditional trace so that trace can always be executed during program execution (default). The trace mode cannot be changed while the tracer is activated.
Cond. Trace ON	Validates conditional trace and traces in accordance with the trace condition during program execution. The trace mode cannot be changed while the tracer is activated.
Tracer Start/Tracer Stop	Starts the tracer when it is stopped, or stops it when it is in progress. This item is invalid if the program is not being executed and if the trace function is OFF (if [Option] -> [Tracer ON] is not checked). Immediately after program execution has been started with the tracer function ON, the tracer is executed.

(6) [Event] menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
					Event Manager Software Break Manager				
					Event... Event Link... Break... Trace... Timer... Delay Count...				

Event Manager	Manages various event conditions. Opens Event Manager. Same operation as the Mgr button
Software Break Manager	Manages software break event conditions. Opens the Software Break Manager.

Event...	Registers an event condition. Opens Event dialog box. Same operation as the Ev n button
Event Link...	Registers an event link condition. Opens Event Link dialog box.
Break...	Registers and sets a break condition. Opens Break dialog box. Same operation as the Br k button
Trace...	Registers and sets a trace event condition. Opens Trace dialog box. Same operation as the Tr c button
Timer...	Displays a timer value. Opens Timer dialog box. Same operation as the Tim button
Delay Count...	Sets a delay count and displays the delay value. Opens Delay Count dialog box.

(7) **[Browse]** menu

Source Text	Displays a source text. Opens Source window. Same operation as the Src button If there is a Source Text window already open in the active status, it is opened in the static status.
Assemble	Displays the disassemble results. Opens Assemble window. Same operation as the Asm button If there is a Assemble window already open in the active status, it is opened in the static status.
Memory	Displays the contents of the memory. Opens Memory window. Same operation as the Mem button If there is a Memory window already open in the active status, it is opened in the static status.
Watch	Displays the watch contents. Opens Watch window. Same operation as the Wch button
Register	Displays the register contents. Opens Register window. Same operation as the Reg button

SFR	Displays the contents of the SFR. Opens SFR window. Same operation as the SFR button
Local Variable	Displays the local variable. Opens Local Variable window. Same operation as the Loc button
Stack Trace	Displays the stack trace results. Opens Stack Trace window. Same operation as the Stk button
Trace	Displays the trace results. Opens Trace window. Same operation as the TrW button
Console	Opens Console window.
Others	Displays other windows. Displays a user-defined window list. Refer to 7. 6 Expansion window(refer to p.265) and APPENDIX B EXPANSION WINDOWS (refer to p.308) for details.

(8) [[Jump](#)] menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
							SourceText	Ctrl+U	
							Assemble	Ctrl+D	
							Memory	Ctrl+M	

Source Text	Displays the corresponding source text and source line, using the data value selected in the current window as the jump destination address. If no line information is at the jump destination address, however, you cannot jump. Opens Source window. If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Disassembles and displays the results from the jump destination address specified by the data value selected in the current window. Opens Assemble window. If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents from the jump destination address specified by the data value selected in the current window. Opens Memory window. If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).

(9) [W]indow menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
									New Window Cascade Tile Arrange Icons Close All Refresh • Active Static 1 Trace View ✓ 2 Assemble

New Window	Opens a new window displaying the same contents as those of the current window. This menu is valid only when the current window is Source window, Assemble window, or Memory window.
Cascade	Cascade display of the windows in the Main window.
Tile	Tile display of the windows in the Main window.
Arrange Icons	Rearranges the icons in the Main window.
Close All	Closes all windows, except the Main window.
Refresh	Updates the contents of the window with the latest data.
Active	Sets the window in the active status. If the window is already in the active status, a check mark is shown on the left of this item.
Static	Sets the window in the static status. If the window is already in the static status, a check mark is shown on the left of this item.
(Open Window)	Lists the windows that are open. The window with the check mark shown on the side of the figure is the current window. By selecting a window name, the selected window is used as the current window.

(10) [H]elp menu

File	Edit	View	Option	Run	Event	Browse	Jump	Window	Help
									ID78K4-NS Help Command Reference Main Window Help Current Window Help F1 About...

ID78K4-NS Help	Displays the help of ID78K4-NS .
Command Reference	Opens the Help window of COMMAND REFERENCE.
Main Window Help	Displays the help of the Main window.
Current Window Help	Displays the help of the current window.

About...	Displays the version of the debugger. Opens About dialog box.
--------------------------	--

Window display area

This area (at the center) displays various debug windows.

The displayed window can be changed in size or an icon can be created in this area.

Status bar

The status bar is displayed at the bottom of the window and indicates the status of the debugger and In-circuit emulator.

While the user program is being executed, the status bar is displayed in red.

Whether the status bar is displayed or not can be selected by selecting [Option] -> [Status Bar] from the menu bar.

Figure 6-4 Status Bar



(1) Program name	Displays the program file name indicated by the PC value.
Source name	Displays the source file name indicated by the PC value.
Line number	Displays the line number indicated by the PC value.
(2) Function name	Displays the function name indicated by the PC value.
(3) PC value	Displays the current PC value.
(4) CPU status	Displays the status of the CPU (target device). (If there are two or more CPU statuses, they delimited with ' ' and displayed.) STANDBY... Standby mode RESET... Reset state
(5) IE status	Displays the status of the in-circuit emulator. (If there are two or more the statuses, they delimited with ' ' and displayed.) RUN... User program execution in progress (the color of the status bar changes). STEP... Step execution in progress TRC... Tracer operating TIM.. Timer operating BREAK... Break occurring.
(6) Break Cause	Displays Table 6-2 Break Cause.

(7) STEP mode	Displays the step execution mode. Displays that the following modes are selected from the [Option] menu: SRC ...Source mode INST ...Instruction mode AUTO ...Automatic mode
(8) Key input mode	Displays the key input mode. INS ... Insertion mode OVR ...Overwrite mode The Memory window is fixed to OVR mode.

Caution If the screen resolution is small (800 x 600, etc.), all the statuses may not be displayed.

Table 6-2 Break Cause

Display	Meaning
Manual Break	Forced break
Temporary Break	Temporary break
Event Break	Break by event
Software Break	Break due to software break event
Non Map Break	Non-mapped area is accessed.
Write Protect	An attempt has been made to write to a write-protected area.
SFR Illegal	An illegal access is made to a peripheral SFR.
Stack Overflow	Break due to stack overflow
Relocation Break	A location instruction different from the default setting was executed.

Configuration dialog box

This dialog box is used to display and set the operating environment of the in-circuit emulator.

This dialog box is automatically displayed after the debugger is started up.

To use the debugger, the operating environment of the in-circuit emulator must be first set in this dialog box.


However, no setting is required to read a project as the results of reading the project file are reflected in this dialog box.

For details of the mapping function, refer to "Mapping function (p.20)".

Caution Turn on the power to the target if even one of the following items is set in the Configuration dialog box.

- If Target is selected in Voltage (operating power supply selection area).
- If mapping to Target is specified in Memory Mapping (mapping setting area).

Figure 6-5 Configuration Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
 - Setting of memory mapping

- Function buttons

Opening

This dialog box can be opened as follows:


- Automatically opens when the debugger is started up while PM plus is running
- If starting up from PM plus, when using the debugger for the first time for that project
- Select [Option] -> [Configuration...] from the menu bar.
(or press Alt+O, and C in that order)

Explanation of each area

The Configuration dialog box consists of the following areas:

- (1) Chip (Emulation CPU selection area)
- (2) Internal ROM/RAM (internal ROM/internal RAM setting area)
- (3) Location (Location setting area)
- (4) Information (Information display area)
- (5) Clock (CPU clock source selection area)
- (6) Voltage (operating power supply selection area)
- (7) Mask (mask setting area)
- (8) Memory Mapping (mapping setting area)

(1) Chip (Emulation CPU selection area)




This area is used to select the Emulation CPU.

Only the chip names registered to a registry by the DFINST utility are listed.

Specify a chip name either from the drop-down list under **Name**, or directly type in the chip name.

A chip name can be specified only when the debugger is started up. The chip name selected at the previous startup is selected by default. If the chip name is not stored, the top chip name that is registered is selected by default.

(2) Internal ROM/RAM (internal ROM/internal RAM setting area)



This area is used to set the size of the internal RAM and internal ROM of the emulation CPU.

Setting of the internal RAM cannot be performed (always dimmed).

The default value is automatically displayed with "" suffixed, when **Chip** is selected.

To change the size of the internal RAM and internal ROM, select the size from the drop-down list under Internal RAM and Internal ROM.


If the selected size cannot be implemented because of the constraints of the in-circuit emulator, the debugger automatically adjusts the size (therefore, a size larger than that previously specified may be displayed when the Configuration dialog box is displayed again).

The settable sizes are as follows:

Internal ROM: 0 to 1024 (in 8KB units)

Caution If the internal ROM size of the selected chip does not match any of the above sizes, that size will also be displayed on the list.


(3) **Location** (Location setting area)



This area is used to set the location.

2 locations, 00H or 0fH, can be set. Select one of them according to the user environment.

(4) **Information** (Information display area)




This area is not displayed in the Configuration dialog box that appears immediately after the debugger is started up. It is displayed when the Configuration dialog box is opened by selecting from the menu after the debugger is started.

.

(MEM)	Size (number of bytes) of the mounted emulation memory
(TRC)	ON: Trace memory is mounted OFF: Trace memory is not mounted


(5) **Clock** (CPU clock source selection area)



This area is used to select a clock source to be input to the emulation CPU.

Internal	Uses the clock on the in-circuit emulator as the CPU clock.
External	Uses the target clock as the CPU clock. If External is selected, correctly set the parts board on the emulation board. Also, if External is selected and the power to the target is OFF, "Wrong Target Status (Power Off)" is displayed.

(6) [Voltage](#) (operating power supply selection area)




Select the power supply to be input to the emulation CPU.

Internal (default)	Uses the internal operating power supply of the in-circuit emulator (The operating voltage is fixed to 5 V.)
Target	Uses the target's power supply as the operating power supply. (The operating power supply can be varied within the device's specification range.) If Target is selected and the power to the target is OFF, "Wrong Target Status (Power Off)" is displayed.

Caution If [Target](#) is selected, be sure to connect a target (jig), and at the same time to apply the same power supply as the target's to the TPI pin.

If the setting is changed after startup, debugger reset is executed.

(7) [Mask](#) (mask setting area)




This area specifies a mask for the signal sent from the target.

The signal of the masked pin is not input to the in-circuit emulator.

Only mask pins when the operation of the target is unstable at the debugging stage.

The only pin whose signal can be masked is the RESET pin.

(8) Memory Mapping (mapping setting area)

This area is used to set mapping by specifying the memory attribute, and address.

Memory Attribute (mapping attribute specification)

The following mapping attributes can be selected. Select a mapping attribute according to the usage . However, in the case of a device without an external space, the [External ROM](#), [External RAM](#), and [I/O Protect](#) areas cannot be selected.

Emulation ROM	Selects the in-circuit emulator alternate ROM.
Emulation RAM	Selects the in-circuit emulator alternate RAM.
Target	Selects the target memory.
I/O Protect	Selects the I/O protect area. This area can be set only inside the area that is set as Target or inside the SFR area.

Caution The area set as [I/O Protect](#) cannot be read unless it has been registered as an I/O port in the SFR window, or registered in the Watch window. If it is necessary to read this area, execute a forcible read in these windows.

Mapping Address (mapping address specification)

Specify the address to be mapped.

Input the higher and lower addresses from the keyboard.

Setting of memory mapping

Specify [Memory Attribute](#) and [Mapping Address](#) and then click the <Add> button.

-> The attribute of [Memory Attribute](#), address range of [Memory Mapping](#), and memory mapping corresponding to the data of the bus width are set and displayed on a list.

For mapping attributes other than [I/O Protect](#), the mapping units are adjusted when the <Add> button is clicked. If the mapping unit does not match, the minimum settable range including the specified address is mapped.

The mapping unit varies depending on the address to be mapped. The mapping unit is shown below.

Table 6-3 Mapping Unit in Configuration Dialog Box

Mapping Area	Mapping Unit
0x000000-0x00ffff	4K byte
0x010000-0x0fffff	64K byte
0x0100000-0xffffffff	1M byte

The emulation ROM or RAM cannot be mapped at or after address 0x100000. Perform mapping by selecting [Target](#).

Deleting memory mapping

Select mapping to be deleted from the list and click the <Delete> button.

-> This deletes the selected mapping.


Function buttons

OK	Validates the current environment. Sets the environment and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the previous environment settings status before this dialog box was opened.
Project...	Opens the Project File Load dialog box. If an error occurs while a project file is being opened or read, the debugger can no longer continue and is terminated.
Help	Opens the Help window.

Extended Option dialog box

This dialog box is used to display and set the extended options of the debugger.

Figure 6-6 Extended Option Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening


This dialog box can be opened as follows:

- Select [Option] -> [Extended Option...] from the menu bar.
(or press Alt+O, and X in that order.)

Explanation of each area

The Extended Option dialog box consists of the following areas:

- (1) Software Break (software break setting area)
- (2) Internal RAM Monitor Redraw: (real-time internal RAM sampling time setting area)
- (3) Break Sound (beep sound specification area)
- (4) Flash Self Mode (Flash self mode setting area)
- (5) On Mouse Click (default break selection area)

(1) Software Break (software break setting area)

This area is used to select whether a software break is used or not.

When using a software break, one vector address of the callt instruction must be released to the debugger.

(2) Internal RAM Monitor Redraw: (real-time internal RAM sampling time setting area)

This area is used to specify the sampling time (msec) for real-time internal RAM sampling.

The internal RAM area can be sampled in real time during emulation.

The variables and data allocated to this area can be displayed in close to real time in Watch window and Memory window.

The sampling time can be specified in a range of 0 to 65500 in units of 100 msec. If 0 is specified, or if this area is blank, the sampling time is not displayed in real time.

(3) Break Sound (beep sound specification area)

This area is used to specify whether a beep sound is issued upon the occurrence of a break.

If the check box is checked, a beep sound is issued when a break occurs (default).

(4) Flash Self Mode (Flash self mode setting area)

This area is used to set the flash self mode (default: Off).

In the flash self mode, since one access event, one execution event, and one event link are reserved, the number of the events which can be used decreases.

When "On" is checked, all events will once become invalid, if at least one event is valid.

(5) On Mouse Click (default break selection area)

This area is used to select whether a software breakpoint or hardware breakpoint is set as the default breakpoint if a breakpoint is set in the point mark area by clicking the mouse button in the Source window or Assemble window.

Soft Break	Sets a software breakpoint The mark of the breakpoint is displayed in blue.
------------	--

Hard Break	Sets a hardware breakpoint The mark of the breakpoint is displayed in red.
------------	---


Function buttons

OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Help	Opens the Help window.

Debugger Option dialog box

This dialog box is used to display and set the extended options of the debugger.

Figure 6-7 Debugger Option Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [Option] -> [Debugger Option...] from the menu bar (or press Alt+O, and G in that order).

Explanation of each area

The Debugger Option dialog box consists of the following areas:

- (1) Source Path (source path specification area)
- (2) Default Extension (default extension specification area)
- (3) Open File History (open file history setting area)
- (4) Font (display font setting area)
- (5) Project File (project file setting area)
- (6) Tool Bar Pictures (toolbar display button setting area)
- (7) Kanji (Kanji code setting area)
- (8) Tab Size (tab size setting area)
- (9) Startup Routine (start-up symbol setting area)
- (10) DisAssemble (offset display setting area)
- (11) Watch Default (watch symbol setting area)

(1) **Source Path** (source path specification area)



This area is used to specify the directory in which a source file or text file is searched.

A path can be input from the keyboard or set by the <Browse...> button. A relative path can also be specified.

The directory that is the basis of a relative path is displayed on the right of **Base:**. The base directory is determined in the following sequence:

- Directory to which the project file has been loaded
- Directory to which a load module or hex file has been loaded last
- Current directory of Windows

To delimit paths, use ";" (semicolon) or "," (comma).

Japanese characters can be specified in a source path (Japanese version only).

Example: If a source is in the following directory

B:\src

C:\asm

The source path is specified as follows:


B:\src; C:\asm

Clicking the <Browse...> button displays the Add Source Path dialog box shown in Figure 6-8, and a source path can be added.

Reference Immediately after the Debugger Option dialog box has been opened, the base directory is selected and opened. When the dialog box is opened the second and subsequent times, the previously displayed directory is recorded and displayed again.

If the selected directory has already been set for the source path, a source path is not added.

Figure 6-8 Add Source path Dialog Box



(2) **Default Extension** (default extension specification area)

Default Extension

Source File:

Load Module:

Delimit extensions with " " (blank), ";" (semicolon) or "," (comma).

Source File	Set the extension of a source file that is displayed when the Browse dialog box is opened by selecting [File] -> [Open...] from the menu bar. The default extension is "*.C, *.S, *.ASM".
Load Module	Set the extension of a load module that is displayed when Download dialog box is opened. The default extension is "*.LNK, *.LMF".


(3) **Open File History** (open file history setting area)

Open File History


Max Number (0 - 10):

This area is used to set the number of histories (0 to 10) of the open file displayed in the bottom field of the [File] menu. If 0 is set, no history is displayed on the menu.

The default value is 4.

(4) Font (display font setting area)

This area is used to specify the font displayed on the Source window. Clicking the button opens the Font dialog box in which the font to be displayed and its size can be set.

(5) Project File (project file setting area)

This area is used to set automatic saving and loading of the project file.

Auto save

Sets whether the project file is automatically saved at the ID78K4-NS termination.

On	Automatically saves the project file at the ID78K4-NS termination.
Off	Does not automatically save the project file at the ID78K4-NS termination.
Query	Displays the Exit Debugger dialog box at the ID78K4-NS termination (default).

Auto Load

Sets whether the project file is automatically loaded at the ID78K4-NS start up.

On	Automatically loads the project file at the ID78K4-NS start up. Sets whether the Load Project File is automatically loaded.
Off	Does not automatically loads the project file at the ID78K4-NS start up. (default)

Load Project File

Specify the project file to be loaded automatically.

This item can be specified only when [On](#) is specified for [Auto Load](#).

Set a project file name by inputting from the keyboard or clicking the <Browse...> button. Clicking the <Browse...> button displays Browse dialog box.

(6) Tool Bar Pictures (toolbar display button setting area)

This area sets the buttons to be displayed on the toolbar.

Pictures and Text	Displays a button on which a graphic and character are displayed.
Pictures only	Displays a button with only graphic (default).

(7) Kanji (Kanji code setting area)

This area is used to specify Kanji codes to be displayed in the Source window and Trace window.

Kanji codes can be specified only on the Japanese Windows.

Sjis	Uses SJIS as Kanji codes (default).
Euc	Uses EUC as Kanji codes.

(8) Tab Size (tab size setting area)

Extension	Tab Size
**	8
*.asm	8
*.c	8
*.s	8

This area is used to set the tab size for each extension when files are displayed.

Extension

Set an extension. Input an extension from the keyboard, or select one from the drop-down list.

Tab Size

Select the tab size. Select how many spaces are displayed as a tab code.

2	Displays two spaces.
4	Displays four spaces.
8	Displays eight spaces (default).

Tab List

Displays the tab size set for each extension.

To change the tab size setting,

select **Extension** and **Tab Size** and click the <Add> button.

The selected tab size is changed to the tab size set in **Extension**.

To delete the tab size setting,

select the setting to be deleted from **Tab List** and click <Delete> button.

The setting of the extension currently selected will be deleted.

(9) Startup Routine (start-up symbol setting area)

This area is used to specify the first address and end address of the text area (code area) of the start-up routine by symbols.

Specify the symbol of the first address as **Begin label**, and the symbol of the last address as **End label**.

In this way, the source file can be automatically opened if an object file in the load module format is downloaded in Download dialog box. Specify the source file to be displayed at this time as **main() label**, as a display start symbol.

If the specified symbol is not correct, the source file cannot be opened until the PC reaches the address range of the corresponding source file. In addition, the start-up routine cannot be skipped by step execution.

Begin label	Symbol of first address (default: <code>_@cstart</code>)
End label	Symbol of end address (default: <code>_@cend</code>)
main() label	Display start symbol (default: <code>_main</code>)

Caution Be sure to specify this area. If this area is blank, the dialog box cannot be closed.

(10) DisAssemble (offset display setting area)

Performs the setting for disassemble display.

Show Offset

Specifies whether an offset (symbol + offset) is displayed during disassemble display.

When the offset is not displayed, only a symbol that matches a numeric value is displayed, if any. If no matching symbol is found, the numeric value is displayed as a hexadecimal number unchanged.

Label	Specifies whether the offset is displayed in the Label field. This check box is not checked in the default condition, and the offset is not displayed.
Mnemonic	Specifies whether the offset is displayed in the Mnemonic field. This check box is checked in the default condition, and the offset is displayed.

Register Name (register name display selection area)

This area is used to select the method of displaying register names in mnemonics during disassemble display.

Function Name	Displays register names as function names or nicknames.
Absolute Name	Displays register names as absolute names.

(11) Watch Default (watch symbol setting area)

Watch Default

Size: Radix:

Show Variable Type: ☐ On ☒ Off

Language: ☒ C ☐ ASM

This area is used to specify a symbol to be watched.

Size (default size specification)

Sets the display size of data if [Adaptive] is selected in Watch window.

Byte	8-bit display(default)
Word	16-bit display
Double Word	32-bit display

Radix (default radix specification)

Sets the default radix in which data is to be displayed if [Proper] is specified in Watch window.

Hex	Displays data in hexadecimal numbers (default).
Dec	Displays data in decimal numbers.
Oct	Displays data in octal numbers.
Bin	Displays data in binary numbers.
String	Character string

Show Variable Type (display/non-display of variable type)

Selects whether the type of a variable is displayed or not.

On	Displays the type of a variable.
----	----------------------------------

Off	Does not display the type of a variable (default).
-----	--

Language (display/non-display of type of variable)

Selects the display format of the base number.

C	Displays a C-like base number (default).
ASM	Displays an assembly language-like base number.


Function buttons

OK	Validates the settings and closes this dialog box.
Cancel	Cancels the settings and closes this dialog box.
Restore	Restores the previous settings before this dialog box was opened.
Help	Opens the Help window.

Font dialog box

This dialog box is used to select the font to be displayed in the Source window.

Figure 6-9 Font Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the button in Debugger Option dialog box.


Explanation of each area

The Font dialog box consists of the following areas:

- (1) Font Face: (font name specification area)
- (2) Size: (font size specification area)
- (3) Sample (sample display area)

(1) Font Face: (font name specification area)

Font Face:




This area is used to select a font from the fonts currently usable.

Only fonts with equal width (fonts with a constant stroke width and a fixed pitch) are enumerated.

When a font name is selected from the list, the font name is displayed in the text box, and the font size that can be used with that font is displayed under [Size](#).

(2) Size: (font size specification area)

Size:




This area is used to specify the font size.

On the drop-down list, the font size usable for the font specified in [Font Face](#) is displayed in point units.

When the font size is selected from the drop-down list, the selected font size is displayed in this area.

The font size can also be directly input to the text box from the keyboard.

(3) Sample (sample display area)

This area displays a sample character string of the specified font and size.

Function buttons

OK	Changes the font and its size in the Source window as specified, and closes this dialog box.
Cancel	Closes the dialog box without changing the font.


Project File Save dialog box

Saves the debug environment.

It is used to save a new project file or an existing file with the file name changed (refer to "Setting Debugging Environment (p.20)").

When a file is saved, the size and position of the window that has been displayed are also saved.

Figure 6-10 Project File Save Dialog Box



The following contents are saved to the project file:

Table 6-4 Contents Saved to Project File

Window Name	Set Data
Configuration dialog box	All items (target device, clock setting, pin mask setting, mapping information)
Main window	Display position, tool bar/status bar/button display information, execution mode, information, trace on/off information, coverage on/off information
Download dialog box	File information to be downloaded
Extended Option dialog box, Debugger Option dialog box	Set information
Source window	Display information, font information of window
Assemble window, Memory window	Display information of window, display start address

Table 6-4 Contents Saved to Project File

Window Name	Set Data
Stack Trace window, SFR window, Local Variable window, Trace window, Event Manager, Console window, Expansion window	Display information of window
Event dialog box	Display information of window, event information
Event Link dialog box	Display information of window, link event information
Break dialog box	Display information of window, break event information
Trace window	Display information of window, trace event information
Timer dialog box	Display information of window, timer event information
Register window	Display information of window, display bank information
Watch window	Display information of window, watch registration information
Add I/O Port dialog box	Added I/O port information
Software Break Manager	Display information of window, software break information
Delay Count dialog box	Delay count value

This section explains the following items:

- Opening
- Explanation of each area
- Function buttons
- Related operations
 - To automatically save a project file

Opening

This dialog box can be opened as follows:

- Select [File] -> [Project] -> [Save As...] from the menu bar
(or press Alt+F, J and A in that order).

To save a file of same name as a project file previously loaded or saved

- Select [File] -> [Project] -> [Save...] on the menu bar
(or press Alt+F, J and S in that order).

Explanation of each area

The Project File Save dialog box consists of the following areas:

- (1) Save in:, File name: (file selection area)

(2) Save as type: (extension selection area)

(1) Save in:, File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Save as type: (extension selection area)

This area is used to specify the extension (**.PRJ**) of the project file to be loaded.

If the extension is omitted, **.PRJ** is appended as the default extension.

Function buttons

Save	Saves the project information to the selected file. After saving, the dialog box is closed.
Cancel	Closes this dialog box without saving the file.
Help	Opens the Help window.

Related operations**To automatically save a project file**

Use Project File (project file setting area) in Debugger Option dialog box that is opened when [Option]

-> [Debugger Option...] is selected from the menu bar.

Select On for Auto Save in this area. The current environment will be automatically saved to the project file when the dialog box is closed.

Project File Load dialog box

This dialog box is used to return the debug environment to the previous environment.


After a file has been loaded, the size and position of the window is returned to the previous status (status saved to a project file) (refer to "Setting Debugging Environment (p.20)").

After a project file has been loaded, it is displayed on the top of an active Source window if any.

By loading the project file, the items to be saved in Table 6-4 Contents Saved to Project File (p.78) are set.

Caution If a project file different from the target device after the debugger has been loaded is loaded, the debugger loads the project file after it has been reset (the debugger is then used as the target device specified by the project file).

Figure 6-11 Project File Load Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons
- Related operations
 - To automatically load a project file

Opening

This dialog box can be opened as follows:

- Click the Proj button.
- Select [File] -> [Project] -> [Open...] on the menu bar (or press Alt+F, J and O in that order).

Explanation of each area

The Project File Load dialog box consists of the following areas:

- (1) Look In: , File name: (file selection area)
- (2) Files of type: (extension selection area)

(1) Look In: , File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Files of type: (extension selection area)

This area is used to specify the extension (.PRJ) of the project file to be loaded.

Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without loading the file.
Help	Opens the Help window.

Related operations

To automatically load a project file


Use Project File (project file setting area) in Debugger Option dialog box that is opened when [Option] -> [Debugger Option...] is selected from the menu bar.

Select On for Auto Load in this area and specify the name of the project file to be loaded automatically in the Load Project File area. The specified project file will be automatically loaded when the system is started next time.

View File Save dialog box

This dialog box is used to save the contents of the current window to a view file or event setting file when a dialog box is opened.

Figure 6-12 View File Save Dialog Box
View File Save Dialog Box (Example: to Save Memory Window)



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons
- Reference information
 - Regarding files saved in the View File Save dialog box

Opening

This dialog box can be opened as follows:

- When the window to be saved is the current window
Select [File] -> [Save As...] from the menu bar
(or press Alt+F and A in that order).

Explanation of each area

This dialog box consists of the following areas:

- (1) Save in:, File name: (file selection area)
- (2) Save as type: (extension selection area)
- (3) Save range (save range setting area)

(1) Save in:, File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

(2) Save as type: (extension selection area)

This area is used to specify the type (extension) of the file.

The extension of the file corresponding to the current window is displayed as follows:

Table 6-5 Extension Corresponding to Current Window

File Type (Extension)	Current Window Name
Source Text (*.SVW)	Source window
Assemble (*.DIS)	Assemble window
Memory (*.MEM)	Memory window
Watch(*.WCH)	Watch window
Register (*RGW)	Register window
SFR (*.SFR)	SFR window
Local Variable (*.LOC)	Local Variable window
Stack Trace (*.STK)	Stack Trace window
Trace (*.TVW)	Trace window
Console (*.LOG)	Console window
All (*.*)	All files

(3) Save range (save range setting area)

Save range

☐ All

☒ Screen shot

☐ Specify Address ~

This area is displayed if the current window to be saved is the Assemble window, Memory window, Source window, or Trace window.

Specify the range of data to be saved by selecting any of the following:

All	Saves the entire range, from the first line to the last line.
Screen shot	Saves the area visible on the screen, from the top line on the screen to the bottom line. If the Source window is in the mixed display mode, however, the window contents are saved from the source line that includes the area visible on the screen.
Specify Line Specify Frame Specify Address above any	Specify the start line and end line of the area to be saved. If the start line and end line are omitted, the first line and last line are assumed. For details, it is as follows.

Specify Line (if current window is Source window)

☒ Specify Line ~

Specify the range of the line numbers to be saved. The default radix for inputting a numeric value is decimal.

If the Source window is in the mixed display mode, the mixed displayed part on the specified line is also saved.

If a range of 100 lines or more is specified, a message dialog box is displayed to indicate the progress of saving. To stop saving midway, click the <Stop> button in the message dialog box.

Specify Frame (if current window is Trace window)

☒ Specify Frame ~

Specify the range of trace frames to be saved (for how to specify, refer to "Trace Move dialog box").

The default radix for inputting a numeric value is hexadecimal.

If a range of 100 frames or more is specified, a message dialog box is displayed to indicate the progress of saving. To stop saving midway, click the <Stop> button in the message dialog box.

Specify Address (if current window is Assemble window, Memory window)

☒ Specify Address ~

This area is used to specify the address range in which data is to be saved to the file. An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

If a range of 256 bytes or more is specified, a message dialog box is displayed to indicate the progress of saving. To stop saving midway, click the <Stop> button in the message dialog box.

Function buttons

Save	Saves the information of the current dialog box to the selected file. After saving, the dialog box is closed.
Cancel	Closes this dialog box without saving the file.
Help	Opens the Help window.
Restore	Restores the status before this dialog box was opened.

Reference information

Regarding files saved in the View File Save dialog box

Files are saved in the View File Save dialog box in text format. Therefore, these files can be displayed and printed with a regular text editor.

View File Load dialog box

This dialog box is used to read the view file, source file, text file, event setting file, watch setting file, or SFR setting file saved in the View File Save dialog box, and open a window.

The window to be opened and its status differ as follows, depending on the file to be loaded.

Loading source file to which symbol information has been read


If there is a Source window in the active status, it is opened in the static status; otherwise, the Source window is opened in the active status.

Loading source file to which symbol information has not been read, or view file

A window of text-format files is opened in the Source window in the static status.

Caution If an environment file is opened in the View File Load dialog box, it is opened as a text-format file in a static Source Text window.

Figure 6-13 View File Load Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the Open button.
- Select [File] -> [Open...] on the menu bar
(or press Alt+F and O in that order, or press Ctrl+O).

Explanation of each area

This dialog box consists of the following areas:

- (1) Look In: , File name: (file selection area)
- (2) Files of type: (extension selection area)

(1) Look In: , File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Files of type: (extension selection area)

This area is used to specify the type (extension) of the file to be loaded.

Table 6-6 Type of File That Can Be Loaded on View File Load Dialog Box

File Type (Extension)	Meaning
Source (*.C, *.S, *.ASM)	Source file The extension of the source (c, s, asm) can be changed in Debugger Option dialog box.
Text (*.TXT)	Text file
Source Text (*.SVW)	Source window/View files
Assemble (*.DIS)	Assemble window view files
Watch (*.WCH)	Watch window setting files
Memory (*.MEM)	Memory window view files
Register (*.RGW)	Register window view files
SFR (*.SFR)	SFR window setting files
Local Variable (*.LOC)	Local Variable window view files
Stack Trace (*.STK)	Stack Trace window view files
Trace (*.TVW)	Trace window view files
Console (*.LOG)	Console window
All (*.*)	All files


Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without loading the file.
Help	Opens the Help window.

Environment File Save dialog box

This dialog box is used to save the setting contents of the window that was current when this dialog box was opened (Watch window, SFR window, Event Manager) to an environment file.

Figure 6-14 Environment File Save Dialog Box
Environment File Save Dialog Box (Example: to Save Watch window)



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- When the window to be saved is the current window
Select [File] -> [Environment] -> [Save As...] from the menu bar
(or press Alt+F, E and A in that order).

Explanation of each area

This dialog box consists of the following areas:

- (1) Save in:, File name: (file selection area)
- (2) Save as type: (extension selection area)

(1) Save in:, File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

(2) Save as type: (extension selection area)

This area is used to specify the type (extension) of the file.

The extension of the file corresponding to the current window is displayed as follows:

Table 6-7 Extension Corresponding to Current Window

File Type (Extension)	Current Window Name
Watch(*.WCH)	Watch window
SFR (*.SFR)	SFR window
Event(*.EVN)	Event Manager

Function buttons

Save	Saves the information of the current dialog box to the selected file. After saving, the dialog box is closed.
Cancel	Closes this dialog box without saving the file.
Help	Opens the Help window.
Restore	Restores the status before this dialog box was opened.

Environment File Load dialog box

This dialog box is used to read the Watch window, SFR window, or Event Manager environment file saved in the Environment File Save dialog box and open a window.

The window to be opened and its status differ as follows, depending on the file to be loaded.

Loading event environment file

The Event Manager is opened, and the event setting contents will return to the previous environment.

Loading watch environment file


The Watch window is opened, and the watch setting contents will return to the previous environment.

Loading SFR environment file

The SFR window is opened, and the peripheral I/O register setting contents will return to the previous environment.

Caution If a view file is opened, an "Ff104: Illegal project file format" error occurs.

Figure 6-15 Environment File Load Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the Open button.
- Select [E]ile -> [E]nvironment -> [O]pen... on the menu bar (or press Alt+F, E and O in that order).

Explanation of each area

This dialog box consists of the following areas:

- (1) Look In: , File name: (file selection area)
- (2) Files of type: (extension selection area)

(1) Look In: , File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Files of type: (extension selection area)

This area is used to specify the type (extension) of the file to be loaded.

Table 6-8 Type of File That Can Be Loaded on Environment File Load Dialog Box

File Type (Extension)	Meaning
Watch (*.WCH)	Watch window environment files
SFR (*.SFR)	SFR window environment files
Event (*.EVN)	Event environment file

Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without loading the file.
Help	Opens the Help window.

Download dialog box

This dialog box is used to select the name and format of a file to be downloaded, and downloads memory contents to the in-circuit emulator or the target.


If an object file in the load module format has been downloaded, the corresponding source file is searched, and Source window is automatically opened.

Format of file that can be downloaded

- NEC load module format (XCOFF (.LNK, .LMF))
- Intel Hex format (standard, extended)
- Motorola Hex format S type (S0, S2, S3, S7, S8)
- Extended Tektronix Hex format
- Binary data format

Caution If a file other than an object file in the load module format is loaded, source debugging cannot be executed.

Figure 6-16 Download Dialog Box



This section explains the following items:

- Opening
- Explanation of each area

- Function buttons
- Cancel processing

Opening

This dialog box can be opened as follows:

- Click the **Load** button.
- Select [File] -> [Download...] on the menu bar (or press Alt+F, and D in that order).

Explanation of each area

- (1) Look In: , File name: (file selection area)
- (2) Files of type: (extension selection area)
- (3) Offset Address: (offset setting area)
- (4) Load (load condition specification area)
- (5) Reset (reset condition specification area)

(1) Look In: , File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Files of type: (extension selection area)

This area is used to specify the type (extension) of the file to be downloaded.

The contents displayed on the drop-down list are as follows:

Table 6-9 Type of File That Can Be Downloaded

Contents (extension)	Format
Load Module(*.LNK, *.LMF)	Load module format
Hex Format(*.HEX)	Hex format (automatic format identification)
Binary Data(*.BIN)	Binary data format

Reference These are default extensions; other extensions can also be used.

The default extension of the displayed load module can also be specified under Default Extension (default extension specification area) in Debugger Option dialog box.

(3) Offset Address: (offset setting area)

Offset Address:

This area is used to specify the offset address that is used when a file is loaded (for binary data, specify the start address). An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

(4) Load (load condition specification area)

Load

☒ Symbol

☒ Object

This area is used to set a load condition.

This setting is valid only if a file in the load module format is specified.

Symbol	Specifies whether symbol information is read (when checked, default) or not.
Object	Specifies whether object information is read (when checked, default) or not.

(5) Reset (reset condition specification area)

Reset

☒ Symbol

☐ CPU

This area is used to set a reset condition.

This setting is valid only if a file in the load module format is specified.

Symbol	Specifies whether symbol information is reset (when checked, default) or not.
CPU	Specifies whether the CPU is reset or not (not checked, default).

Function buttons

Open	Loads the selected file. After loading the file, this dialog box is closed.
Cancel	Closes this dialog box without loading the file.
Help	Opens the Help window.
Restore	Restores the input data to the original status.

Cancel processing


The following dialog box appears while downloading and the downloading can be cancelled at any time.

The progress of the download is displayed in the dialog box.

This dialog box is closed automatically after completing downloading.

If an error occurs during the download, an error message will be displayed in a new window.

Figure 6-17 The Progress of Download




Upload dialog box

This dialog box is used to set the name and format of the file to which memory contents or coverage results are to be saved.

Format of specifiable file

- Intel Hex format (expanded ... 20-bit address)
- Motorola Hex format (S0, S2, S8 ... 24-bit address)
- Extended Tektronix Hex format
- Binary data format

Figure 6-18 Upload Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [File] -> [Upload...] on the menu bar (or press Alt+F, and U in that order).

Explanation of each area

The Upload dialog box consists of the following areas:

- (1) Save in:, File name: (saved file name specification area)
- (2) Save as type: (extension selection area)
- (3) Save Address: (save range setting area)

(1) **Save in:, File name:** (saved file name specification area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 characters can be specified including the extension.

(2) **Save as type:** (extension selection area)

This area is used to specify the type (extension) of the file. The format of the data to be saved to the file is determined by the extension.

If "All (*.*)" is selected, however, the default Intel extended Hex format is selected. The contents displayed on the drop-down list are as follows:

Table 6-10 Type of File That Can Be Uploaded

Contents (extension)	Format
Intel Hex (*.HEX)	Intel expanded Hex format
Motorola Hex (*.HEX)	Motorola Hex format
Tektro Hex (*.HEX)	Extended Tektronix Hex format
Binary Data (*.BIN)	Binary data format
All (*.*)	All files

Reference These are default extensions; other extensions can also be used.

(3) **Save Address:** (save range setting area)

Save Address: ~

This area is used to specify the address range in which data is to be saved to the file. An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)").

The default radix for inputting a numeric value is hexadecimal.

Function buttons


Save	Saves data in the specified address range to the specified file and closes this dialog box. Closes this dialog box. The font of the Source window is changed to the specified font face and font size, and then the dialog box is closed
Cancel	Closes this dialog box without saving the data to the file.
Help	Opens the Help window.
Restore	Restores the input data to the original status.

Browse dialog box

This dialog box is used to select the file to be set in the Source Search dialog box or the Source Text Move dialog box.

Reference If this dialog box is opened for the first time after the system has been started up, the directory first specified by the source path is displayed. When the dialog box is opened the second and subsequent times, the previously displayed directory is recorded and displayed again. If the <Cancel> button is pressed, however, the previously displayed directory is not recorded.

Figure 6-19 Browse Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the <Browse...> button in the Source Search dialog box or the Source Text Move dialog box.

Explanation of each area

The Browse dialog box consists of the following areas:

- (1) Look In: , File name: (file selection area)
- (2) Files of type: (extension selection area)

(1) Look In: , File name: (file selection area)

This area is used to specify a file name. A file name can be directly input from the keyboard, or selected from the list at the upper part of this area.

Up to 64 character string with a extension can be specified.

(2) Files of type: (extension selection area)

This area is used to specify the type (extension) of the file to be opened.

Table 6-11 Type of File That Can Be Displayed in Browse Dialog Box

File Type (Extension)	Meaning
Source (*.C, *.S, *.ASM)	Source file The extension of the source (c, s, asm) can be changed in Debugger Option dialog box.
Text(*.TXT)	Text file
All(*.*)	All files

Function buttons

Open	Sets the selected file. After setting the file, closes this dialog box.
Cancel	Does not set the file and closes this dialog box.
Help	Opens the Help window.

Address Move dialog box

This dialog box is used to specify the address from which displaying memory contents, results of disassembly, results of coverage, or SFR are to be displayed. This dialog box is displayed if [View] -> [Move] is selected from the menu bar while the Memory window, the Assemble window, or the SFR window is opened, and enables the display start address of data to be changed.

Figure 6-20 Address Move Dialog Box
(Example: When Memory Window Is Open)



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When the Memory window, Assemble window, or SFR window is opened

- Select [View] -> [Move...] from the menu bar
(or press Alt+V and V in that order, or press Ctrl+J).

Explanation of each area

The Address Move dialog box consists of the following areas:

- (1) To (address specification area)

(1) To (address specification area)



This area is used to specify an address. In the default condition, the string selected in the window that called this dialog box, the current PC value (Memory window, Assemble window), or blank (SFR

window) is displayed.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

By displaying the input history, the contents previously input can be reused.

Up to 16 input histories can be recorded.

Function buttons


OK	Displays the memory contents, results of disassembly, or SFR.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Source Text Move dialog box

This dialog box is used to specify a file to be displayed in the Source window and the position from which displaying the file is to be started.

This dialog box is selected if [View] -> [Move...] is selected from the menu bar while the Source window is open, and enables the display start position of a file to be changed (a new window is not opened).

Figure 6-21 Source Text Move Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Specifying
 - Specifying a display start position by an address (or symbol).
 - Specifying a file to be displayed in the Source window
- Function buttons

Opening

This dialog box can be opened as follows:

When the Source window is active

- Select [View] -> [Move...]
(or press Alt+V and V in that order, or press Ctrl+J).

Explanation of each area

The Source Move dialog box consists of the following areas:

- (1) Option (input mode selection area)
- (2) To (file/address specification area)

(1) Option (input mode selection area)

The image shows a dialog box titled 'Option'. It contains two radio buttons: 'Address/Symbol' and 'Line/File'. The 'Line/File' radio button is selected. To the right of the radio buttons is a text field labeled 'File:' followed by a 'Browse...' button.

This area is used to select the input mode when the display start position is specified.

Address/Symbol	If the display start position is specified by an address (or symbol)
Line/File	If the display start position is specified by a line number (or file name)

(2) To (file/address specification area)

The image shows a text field labeled 'To:' containing the text 'main.c#50'. There is a small downward arrow icon on the right side of the field.

This area is used to specify the file name or address to be displayed. In the default condition, the character string selected in the window that called this dialog box is displayed in this area. If no character string has been selected, the first character string of the input history is displayed. If no input history is available, the current PC is displayed. As necessary, the character string displayed in this area can be changed by directly inputting a character string from the keyboard.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

Specifying

On this dialog box, the following two items can be specified.

- Specifying a display start position by an address (or symbol).
- Specifying a file to be displayed in the Source window

Specifying a display start position by an address (or symbol).

Select **Address/Symbol** under **Option** and specify the address from which display is to be started for **To**.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Clicking the <OK> button displays the source text so that the source line corresponding to the specified address value can be viewed.

Specifying a file to be displayed in the Source window

Select **Line/File** under **Option** and specify the name of the file to be displayed in the Source window for **To**. Specification can be made using only the file name, or using an absolute path or relative path.

If only the file name is specified, or if a relative path is specified, the files in the directory of the source path specified in Debugger Option dialog box are sequentially searched. The file that is found first as a result of searching is displayed.

In addition to a file name, a line number can be also specified as follows:

<<path name>file name#>line number

Delimit the file name from the line number with "#". Specify the line number in decimal. The file name may be omitted. The default radix for inputting a numeric value is hexadecimal.

Clicking the <OK> button displays the specified file with the specified line number as the first line. If the file name omitted, the file being displayed is displayed starting from the specified line. If the line number is omitted, the file is displayed starting from its first line.

Function buttons


Browse...	Opens the Browse dialog box.
OK	Starts displaying the source text from the specified position.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Trace Move dialog box

This dialog box is used to specify the position from which displaying the Trace window is started.

This dialog box is displayed if [View] -> [Move...] is selected from the menu bar while the Trace window is open, and enables the display start position of the trace results to be changed.

Figure 6-22 Trace Move Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When the Trace window is displayed

- Select [View] -> [Move...]
(or press Alt+V and V in that order, or press Ctrl+J).

Explanation of each area

The Trace Move dialog box consists of the following areas:

- (1) Frame selection area
- (2) Frame number specification area

(1) Frame selection area

☐ 1st frame of last block
☐ Trigger frame of last block
☐ Last frame of last block
☒ Frame No.

This area is used to specify the frame at the destination.

1st frame of last block	Moves the display start position to the to first frame in the newest block of trace data. The display start position is moved to the first frame of the trace data when using an in-circuit emulator without a block frame.
Trigger frame of last block	Moves the display start position to a trigger frame in the newest block frame of trace data.
Last frame of last block	Moves the display start position to the last frame of trace data.
Frame No.	Moves the display start position to the specified frame number. If 0 is specified, the display start position is moved to the first frame of trace data. If this item is checked, the focus moves to the text box on the side.

(2) Frame number specification area

☒ Frame No.

This area is used to specify a frame number if Frame No. is selected in the frame selection area. In the default condition, the character string selected in the window that called this dialog box or "Last" is selected. As necessary, however, this can be changed by directly inputting a character string from the keyboard.

The default radix for inputting a numeric value is hexadecimal.

A frame number can also be specified in the following format. The uppercase and lowercase characters of the input character string are not distinguished. In addition, a frame number can also be specified in abbreviated form.

Table 6-12 Frame Number Specification Format

Specification	Abbreviation	Contents
+numeric value	None	Moves backward (downward on screen) the display start position from the frame at the cursor by the specified number of frames (numeric value).
-numeric value	None	Moves forward (upward on screen) the display start position from the frame at the cursor by the specified number of frames (numeric value).
Top	O	Moves the display start position to the first frame of trace data.
First	S	Moves the display start position to the first frame of the current trace block. (Same as when Top is specified when using an in-circuit emulator without a block frame.)

Table 6-12 Frame Number Specification Format

Specification	Abbreviation	Contents
Trigger	T	Moves the display start position to the trigger frame of the current trace block.
Last	L	Moves the display start position to the last frame of the current trace block. (Same as when Bottom is specified when using an in-circuit emulator without a block frame.)
Bottom	B	Moves the display start position to the last frame of trace data.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

Function buttons

OK	Starts trace display from the specified position.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Symbol To Address dialog box

Displays the address of the specified variable or function, or the value of the specified symbol.

Figure 6-23 Symbol To Address Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:


- Select [View] -> [Symbol...] from the menu bar (or press Alt+V and Y in that order).

Explanation of each area

The Symbol To Address dialog box consists of the following areas:

- (1) Symbol: (symbol specification and conversion result display areas)
- (2) Radix (display radix specification area)

(1) **Symbol:** (symbol specification and conversion result display areas)



The upper area (symbol specification area) is used to specify the variable, function name, symbol name, or line number to be converted.

In addition, an I/O port name, SFR name, register name, PSW flag name, or expression can be also specified.

In the lower area (conversion result display area), the variable, address of the function, value of the symbol, address of the line number, or value of the expression specified under **Symbol** is displayed. The address value of an I/O port name or SFR name, the register contents of a register name, or flag value of a PSW flag name is displayed. The specification method is indicated below.

Table 6-13 Specifying Symbols

Conversion Target	Specification Method
Variable	var file#var (to specify a static function with file name) func#var (to specify a static function with function name) file#var (to specify a static function with file name and function name)
Function	func file#func (to specify a static function with file name)
Label	label file#label(to specify a local label with file name)
Line number of source file	prog\$file#var file#no
I/O Port	portname
SFR	sfrname
Register	regname
PSW Flag	pswname

Remark var: Variable name, func: Function name, file: File name, label: Label name, bitsym: Bit symbol name, portname: I/O port name, sfrname: SFR name, regname: Register, pswname: PSW flag name, no: Line number of source file

"#" is used as a separator for file names, variables, function names, and line numbers.

If a specified symbol is not found in the scope, all symbols (static variables, static functions, local labels) are searched.

In the default status, a symbol name takes precedence. To temporarily change the priority, prefixing "\$" to a symbol gives the priority to a register name.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string. The default radix for inputting a numeric value is decimal.

To change the contents of the symbol specification area, click the <OK> button. The conversion result will be displayed in the conversion result display area.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

(2) Radix (display radix specification area)

Radix: ☒ Hex ☐ Dec ☐ Oct ☐ Bin

This area is used to specify the radix of the data to be displayed in the conversion result display area.

Hex	Hexadecimal number (default).
Dec	Decimal number
Oct	Octal number
Bin	Binary number

Function buttons

OK	If the contents of the symbol specification area have been changed, converts the symbol. After conversion, closes the dialog box if the contents of the symbol specification area have not been changed.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status. If the <OK> button has already been clicked, the data is restored to the status immediately after the <OK> button was clicked.
Help	Opens the Help window.

Source window


This window displays source files or text files.

In Mixed display mode, the program can be disassembled and displayed and online assembly can be executed while source files are being displayed.

The Source window that is displaying the source file to which symbol information is read may be in two statuses: Active Status and Static Status.

Caution If program codes is described in an include file and these codes are included in multiple files, the line numbers and addresses do not correspond on a one-to-one bases. In such an include file, function that indicates the correspondence relationship between line numbers and addresses dose not correctly operate.

Figure 6-24 Source Window



This section explains the following items:

- Opening
- Explanation of each area
 - Breakpoint setting/deletion function
- Functions often used (right-click menu)
- Function buttons

- Related operations

Concerning display

- Mixed display mode
- To set a source path
- To change the display start position
- To display another source file
- To specify the default extension of a source file
- To convert a symbol
- To specify the symbol of a start-up routine
- To set an opened file history
- To set a beep sound to be issued upon break
- To change the displayed font
- To change the displayed tab size

Concerning operation

- Start function
- Come function
- Program counter setting function
- Jump function
- Watch function (referencing data value)
- To search in a source program
- To set a default breakpoint
- Drag & drop function (line/address)
- Drag & drop function (character string)

Opening

This window can be opened as follows:

- This window is automatically opened if the corresponding source file exists after the download module file has been downloaded.
- Click the **Src** button.
- Select [**B**rowse] -> [**S**ource] from the menu bar (or press Alt+B, and S in that order).
- Select [**J**ump] -> [**S**ource] from the menu bar (or press Alt+J and S in that order, or press Ctrl+U).
- Click the <Open> button with selecting a source file or text file in the View File Load dialog box.

Explanation of each area

The Source window consists of the following areas:

- (1) Point mark area

- (2) Current PC mark area
- (3) Line number/address display area
- (4) Source text display area

(1) Point mark area



This area displays the Breakpoint setting/deletion function, Event setting status, and Program code.

Breakpoint setting/deletion function

By clicking this area with the mouse, a breakpoint can be set or deleted. Whether a hardware breakpoint or software breakpoint is to be set or deleted can be selected by the right-click menu of this area (or by On Mouse Click in the Extended Option dialog box).

Setting a breakpoint

A breakpoint can be set on a line for which "*" is displayed in the point mark area (if "*" is not displayed for the line, the breakpoint is set on the line above or below the line, whichever has "*" displayed).

When a breakpoint has been set, 'B (blue: Software break point)', 'B (red: Hardware break point (after execution))', 'B (green: Hardware break point (before execution))', or 'B (black: Hardware break point (registered but not used))' is displayed.

If a breakpoint is set on a line on which an event breakpoint has already been set, "A" indicating that multiple events have been set is displayed.

Caution A software breakpoint cannot be set in an externally mapped ROM area.

Deleting a breakpoint

Click the position at which the breakpoint to be deleted is set.

If right-click menu -> [Software Breakpoint] is selected, "B (blue: Software break point)" is deleted. If right-click menu -> [Breakpoint] is selected, "B (red: Hardware break point)", "B (green: Hardware break point (before execution))", and "B (black: Hardware break point (registered but not used))" are

deleted. If another event remains, however, the mark of that event is displayed.

Table 6-14 Details of Setting/Deleting Breakpoint

Display Status of Line	On Mouse Click [right-click menu]	Operation on clicking
Blank or with mark other than B	Soft Break [Software Breakpoint]	Sets a software breakpoint. Blank -> Displays B(blue) mark Other than B mark -> Displays A mark (indicating setting of two or more events)
	Hard Break [Breakpoint]	Sets a hardware breakpoint Blank -> Displays B(red) mark Other than B mark -> Displays A mark (indicating setting of two or more events)
With B(blue) mark (Software breakpoint setting status)	Soft Break [Software Breakpoint]	Deletes a software breakpoint -> Blank
	Hard Break [Breakpoint]	Sets a hardware breakpoint -> Displays A mark (indicating setting of two or more events)
With B(red, green, black) mark (Hardware breakpoint setting status)	Soft Break [Software Breakpoint]	Sets a software breakpoint. -> Displays A mark (indicating setting of two or more events)
	Hard Break [Breakpoint]	Sets a software breakpoint -> Blank

The 'B' mark is displayed in the following colors, depending on the type and status of the breakpoint.

A breakpoint becomes valid as soon as it has been set in the point mark area.

Table 6-15 Display Color of Breakpoint and Its Meaning

Display Color	Meaning
B(blue)	Software breakpoint is set.
B (red)	Valid hardware breakpoint (after execution) is set.
B (green)	Valid hardware breakpoint (before execution) is set. This breakpoint is set, taking precedence over the hardware breakpoint after execution.
B (black)	Invalid hardware breakpoint is set (registered but not used). This hardware breakpoint can be validated on the Event Manager or in the Break dialog box.

Event setting status

The setting status of various events can be displayed.

If an execution event or access event is set on the corresponding line, a mark corresponding to the type of event is displayed.

If an address range is specified as the address condition of the event, the lower addresses of the range are displayed.

The mask specification of the address condition is not reflected.

Table 6-16 Meaning of Event Display Mark

Mark	Meaning
E	Setting of event condition
L	Setting of event for event link condition
B	Setting of break event
T	Setting of trace event
A	Setting of multiple events

Program code

The line marked '*' in the point mark area indicates that a program code corresponding to the line number exists. This program code is displayed only if a load module has been downloaded and symbol information has been read.

(2) Current PC mark area




The mark '>', which indicates the current PC value (PC register value), is displayed in this area.

Clicking this mark with the mouse displays a pop-up window that shows the PC register value.

By double-clicking the current PC mark area, the program can be executed up to a specified line.

(3) Line number/address display area



This area displays the line numbers of a source file or text file.

If a Program code corresponding to a line number of the source file exists, the character of the line number is displayed in red. If a program code does not exist, the character of the line number is displayed in black.

In the mixed display mode, disassembled addresses are displayed. The characters of an address are displayed in gray.

In this area, any position can be selected (highlighted) by clicking the mouse button. The selected line number of an address can be dragged to another window or area, so that its variable value can be displayed or the line number of the address can be specified as an event condition (refer to "Drag &

drop function (line/address) (p.125)").

(4) Source text display area

This area displays source files or text files.

A data value can be temporarily displayed by selecting (highlighting) a character string and placing the mouse cursor over it (Balloon watch function).

The current PC line and the line on which a breakpoint is set are emphasized for display, as follows:

Current PC line (Yellow)	This line is the source line or disassemble display line corresponding to the current PC value (indicated by '>'). In the mixed display mode, the color of only the disassemble display line is changed (the source line is displayed in the normal color).
Breakpoint setting line (red)	This line is the source line or a disassemble display line on which a valid breakpoint is set (indicated by a 'B' mark in red or green, or blue). In the mixed display mode, the color of only the disassemble display line is changed (the source line is displayed in the normal color).

In the mixed display mode, the color of only the disassemble display line is changed (the source line is displayed in the normal color).

In this area, the following functions can be used on the line or address on which the cursor is placed (start address of program code):

- > Start function
- > Come function
- > Program counter setting function
- > Jump function

Caution If a Program code does not exist on the source line, the top address of the line above or below the line on which a program code exists is manipulated by these functions.

These functions cannot be performed in the following cases. The corresponding menu will be dimmed and cannot be selected.

If a file other than a source file is displayed

While the user program is being executed

A character string selected in this area can be dragged and dropped to another window or dialog box (refer to "Drag & drop function (character string) (p.126)").

Caution Up to 319 characters can be displayed on 1 line.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal

procedure.

Move...	Moves the display position. Opens the Source Text Move dialog box.
Mix	Turns on/off mixed display of disassembly. Checked: Mixed display Not checked: No display (default)
Add Watch	Adds the specified data to the Watch window. Opens the Add Watch dialog box.
Symbol	Displays the address of the specified variable or function, or the value of the specified symbol. Opens the Symbol To Address dialog box.
Break when Access to this Variable ^{Note}	Creates a break event for a read/write access.
Break when Write to this Variable ^{Note}	Creates a break event for a write access.
Break when Read from this Variable ^{Note}	Creates a break event for a read access.
Clear	Deletes the selected break event condition.
Event?	Selects a line or variable name.
Come Here	Executes the program from the current PC to the cursor position (Come function).
Change PC	Sets the address at the cursor position to the PC.
Break Point	Sets or deletes a breakpoint at the cursor position.
Software Break Point	Sets a software break point at the cursor position.
Assemble	Disassembles and displays starting from the jump destination address specified by the data value at the cursor position. Opens the Assemble window. If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. Opens the Memory window. If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).

Note No breakpoint can be set for structure and union members, array members, bit field members, etc. In such a case, get the address in the Symbol To Address dialog box and then set a breakpoint for that address.

Function buttons

Search...	<p>Opens the Source Search dialog box and searches a character string of the source text.</p> <p>If a character string is selected in the source text display area, the Source Search dialog box is opened to search the character string. If no character string is selected, the Source Search dialog box is opened with nothing specified to be searched.</p> <p>Specify a search method in the Source Search dialog box. The result of search is highlighted in the Source window.</p> <p>This is the same operation as selecting [View] -> [Search...] from the menu bar.</p> <p>This button is invalid while the user program is executed.</p>
<<	<p>Searches forward (upward on screen) for the text that satisfies the search condition set in the Source Search dialog box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p> <p>This button is invalid while the user program is executed.</p>
>>	<p>Searches backward (downward on screen) for the text that satisfies the search condition set in the Source Search dialog box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p> <p>This button is invalid while the user program is executed.</p>
Stop (during search)	Stops searching.
Watch	<p>Adds the variables selected in the source text display area to the Watch window. If the Watch window is not opened, it is opened.</p> <p>If no text is selected in the source text display area, the Watch window is only opened.</p> <p>This is the same operation as selecting [View] -> [View Watch] from the menu bar.</p>
Quick...	<p>Temporarily displays the contents, such as a variable, selected in the source text display area in the Quick Watch dialog box. Opens the Quick Watch dialog box. If no text is selected in the source text display area, the Quick Watch dialog box is only opened.</p> <p>This is the same operation as selecting [View] -> [Quick Watch] from the menu bar.</p>
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

Mixed display mode

The normal display mode and mixed display mode can be alternately selected by selecting [View] -> [Mix] from the menu bar.

Normal display mode

	58	
*	59	TUM1 = 0x200;
*	60	CE1 = 1;
*	61	time_over = 0;

In the normal display mode, general text files can be displayed as well as source files.

Mixed display mode

	58		
*	59	TUM1 = 0x200;	
*	00000394	20660002	movea 0x200, r0, r12
*	00000398	606740f2	st.h r12, TUM1
*	60	CE1 = 1;	
*	0000039C	c03f42f2	set1 0x7, TMC1
*	61	time_over = 0;	
*	000003A0	440e0000	movhi 0x0, gp, r1
*	000003A4	61071184	st.w r0, -0x7bf0[r1]

In the mixed display mode, disassembly of programs combined with source files is displayed and online assembly is carried out. (This mode is valid only when a load module is being downloaded and symbol information is being read, and the source file that corresponds to the downloaded load module is displayed).

If a program code corresponds to the line of the displayed source file, the disassembly line is displayed next to the source line. In the disassembly line, an address label, a code data, and a disassembled mnemonic are displayed (the starting position for display of the mnemonic can be adjusted by the tab size setting value).

To execute online assembly, move the cursor to a mnemonic. The results of online assembly are also reflected in the Memory window.

The contents displayed in the mixed display mode can be saved as a view file.

Caution If it scrolls by the cursor key at the time of mixed display mode, excessive scrolling may occur.

By the cursor key, it may be unable to scroll to the last line.

To set a source path

Set a source path under Source Path (source path specification area) in the Debugger Option dialog box that is opened by selecting [Option] -> [Debugger Option] from the menu bar.

To change the display start position

Change the display start position in the Source Text Move dialog box that is opened when right-click menu -> [Move...] is selected in the Source window.

To display another source file

Select [File] -> [Open] from the menu bar and specify a file.

To specify the default extension of a source file

Set a source path under Default Extension (default extension specification area) in the Debugger Option dialog box that is opened by selecting [Option] -> [Debugger Option] from the menu bar.

To convert a symbol

Convert symbols in the Symbol To Address dialog box that is opened when right-click menu -> [Symbol...] is selected in the Source window.

To specify the symbol of a start-up routine

Specify the symbol of a start-up routine under Startup Routine (start-up symbol setting area) in the Debugger Option dialog box that is opened by selecting [Option] -> [Debugger Option...] from the menu bar. If the setting in this area is wrong, the source file cannot be opened.

To set an opened file history

Set an opened file history under Open File History (open file history setting area) in the Debugger Option dialog box that is opened by selecting [Option] -> [Debugger Option...] from the menu bar. The number of a history display of the opened files can be specified in this area.

To set a beep sound to be issued upon break

Set the beep sound under Break Sound (beep sound specification area) in the Extended Option dialog box that is opened by selecting [Option] -> [Extended Option...] from the menu bar.

To change the displayed font

Change the displayed font in the Font dialog box that can be opened by clicking the <Font...> button in the Debugger Option dialog box that is opened when [Option] -> [Debugger Option...] is selected from the menu bar.

To change the displayed tab size

The displayed tab size can be specified for each file extension under Tab Size (tab size setting area) in the Debugger Option dialog box that is opened when [Option] -> [Debugger Option...] is selected from the menu bar.

Start function

This function is used to execute the user program from the line on which the cursor is placed.

Method

Move the cursor to the line from which the program is to be executed, and select right-click menu -> [Start From Here].

Come function

This function is used to execute the user program to the line on which the cursor is placed (while the user program is being executed in this mode, the break event currently set does not occur).

Method

Move the cursor to the line on which the break is to occur, and select right-click menu -> [Come Here].

Program counter setting function

This function is used to set the address of the line on which the cursor is placed to the program counter (PC).

Method

Move the cursor to the line that is to be set to the PC, and select [Run] -> [Change PC] from the menu bar.

Jump function

This function is used to jump to the Memory window, using the selected variable as a jump pointer.

The jump destination window will be displayed from the vicinity of the jump pointer.

- 1 Select the name of variable as a jump pointer with the mouse.
 - 2 In the Main window, to jump to the Memory window
Select [Jump] -> [Memory] from the menu bar.
(or press Alt+J and E in that order, or press Ctrl+M).
- To jump from the Trace window to the Memory window, the jump source address differs as follows, depending on the cursor position in the trace result display area:

If the cursor is at an access address, access data, or access status	-> Access address
Other than above	-> Fetch address
To jump to the Source window or Assemble window	-> Fetch address

- To jump from the Register window, move the cursor to a register value.
- To jump from the Stack Trace window, the jump destination is as follows:

[With current function]

- If the jump destination is the Source window
-> Jumps to the current PC line.
- If the jump destination is a window other than the Source window
-> Jumps to the current PC address.

[With function other than current function]

- If the jump destination is the Source window
-> Jumps to the line that calls a nested function.
- If the jump destination is a window other than the Source window
-> Jumps to the address next to the instruction that calls a nested function.

Watch function (referencing data value)

Data values can be displayed as follows:

To temporarily display a value

The following two methods can be used:

- Select (highlight) a character string and put the mouse cursor on it then the data value is displayed (Balloon watch function).
- Select (highlight) a character string and click the <Quick> button. The Quick Watch dialog box will be opened to display the data value.

To trace the change of a data value

Register a variable or symbol to the Watch window in either of the following ways:

- Select (highlight) the character string whose data value is to be displayed, click the <Watch> button, or drag the character string to the Watch window and register it to the window (refer to "Drag & drop function (character string) (p.126)").
- Select (highlight) the character string whose a data value is to be displayed and register the data value from the Add Watch dialog box that is opened when right-click menu -> [Add Watch] is selected.

To search in a source program

Use the Source Search dialog box that is opened by clicking the <Search...> button in the Source window.

If the character string to be searched exists in the window, select that character string and click the <Search...> button. The selected character string will be opened in the specified format.

To set a default breakpoint

Set a default breakpoint under On Mouse Click (default break selection area) in the Extended Option dialog box that is opened when [Option] -> [Extended Option...] is selected from the menu bar. In this way, a default breakpoint that is assumed when the point mark area is clicked can be set.

Drag & drop function (line/address)

The line number or address selected and highlighted can be dragged to another window or area.

If the position of the line number or address selected in this area is dragged with the left mouse button, the shape of the mouse cursor changes from an arrow to '-'. When the cursor is moved to the window or area in which they can be dropped, the mouse cursor changes to 'OK'.

In the window in which the line number or address has been dropped, an operation is performed on the dropped address or the address that is obtained from the dropped line number. The operation to be performed after dropping the line number or address differs, depending on the window or area in which the line number or address has been dropped.

Table 6-17 Details of Drag & Drop Function (Line/Address)

Window/Area to Drop to	Operation After Drop
The Event Manager or the event manager area in each various event setting dialog box	Automatically creates an execution event condition by using the dropped line number or address as an address condition. Event condition names are automatically created as Evt00001, Evt00002, and so on. An external sense data condition and pass count are not specified. The address condition is set for the closest symbol in the format of symbol name + offset value.
Condition setting area in each various event setting dialog box (other than address and data setting areas)	Automatically creates an execution event condition by using the dropped line number or address as an address condition. The automatically created event condition is set in each condition setting area in which the line number or address has been dropped. Event condition names are automatically created as Evt00001, Evt00002, and so on. An external sense data condition and pass count are not specified. The address condition is set for the closest symbol in the format of symbol name + offset value.
Condition setting area in each various event setting dialog box (address and data setting areas)	The text of the dropped line number or address is set in the area in which the line number or address has been dropped. The address condition is set for the closest symbol in the format of symbol name + offset value.

Caution The various event setting dialog boxes includes the Event dialog box, Event Link dialog box, Break dialog box, and Trace dialog box.

Drag & drop function (character string)

A selected text can be moved to another window or area by dragging and dropping.

- 1 If the selected text is dragged by using the left mouse button, the shape of the mouse cursor changes from an arrow to 'I'.
- 2 When the cursor is moved to the window or area in which the text can be dropped, the mouse cursor changes to 'OK'.

The operation to be performed after dropping the text differs, depending on the window or area in which the text has been dropped.

Table 6-18 Details of Drag & Drop Function (Character String)

Window/Area to Drop to	Operation After Drop												
The Event Manager or the event manager area in each various event setting dialog box	<p>If the dropped text can be converted as a symbol into an address value, an event condition in the Access status (all access statuses) or Execute status is automatically created, using the converted address value as an address condition. Event condition names are automatically created as Evt00001, Evt00002, and so on. An external sense data condition and pass count are not specified. The address condition is set by the dropped text. The relationship between the event condition to be created and the symbol is as follows:</p> <table> <tr> <th>Symbol</th><th>Status</th></tr> <tr> <td>Variable</td><td>Access(R/W)</td></tr> <tr> <td>Function</td><td>Execute</td></tr> <tr> <td>Symbol in the data section</td><td>Access(R/W)</td></tr> <tr> <td>Symbol in the code section</td><td>Execute</td></tr> <tr> <td>Other</td><td>Access(R/W)</td></tr> </table>	Symbol	Status	Variable	Access(R/W)	Function	Execute	Symbol in the data section	Access(R/W)	Symbol in the code section	Execute	Other	Access(R/W)
Symbol	Status												
Variable	Access(R/W)												
Function	Execute												
Symbol in the data section	Access(R/W)												
Symbol in the code section	Execute												
Other	Access(R/W)												
Condition setting area in each various event setting dialog box (other than address and data setting areas)	<p>If the dropped text can be converted as a symbol into an address value, an event condition in the Access status (all access statuses) or Execute status is automatically created, using the converted address value as an address condition. The automatically created event condition is set in each condition setting area in which the line number or address has been dropped. Event condition names are automatically created as Evt00001, Evt00002, and so on. An external sense data condition and pass count are not specified. The address condition is set by the dropped text. The relationship between the event condition to be created and the symbol is as follows:</p> <table> <tr> <th>Symbol</th><th>Status</th></tr> <tr> <td>Variable</td><td>Access(R/W)</td></tr> <tr> <td>Function</td><td>Execute</td></tr> <tr> <td>Symbol in the data section</td><td>Access(R/W)</td></tr> <tr> <td>Symbol in the code section</td><td>Execute</td></tr> <tr> <td>Other</td><td>Access(R/W)</td></tr> </table>	Symbol	Status	Variable	Access(R/W)	Function	Execute	Symbol in the data section	Access(R/W)	Symbol in the code section	Execute	Other	Access(R/W)
Symbol	Status												
Variable	Access(R/W)												
Function	Execute												
Symbol in the data section	Access(R/W)												
Symbol in the code section	Execute												
Other	Access(R/W)												
Condition setting area in each various event setting dialog box (address and data setting areas)	The dropped text is set in the area.												
Watch window	If the dropped text is recognizable as a symbol, the contents of the symbol are displayed.												

Caution The various event setting dialog boxes includes the Event dialog box, Event Link dialog box, Break dialog box, and Trace window.


Source Search dialog box

This dialog box is used to search for the character string in the Source window.

By setting each item and then clicking the <Find Next> button, searching can be started.

By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Source window can be used for the search.

Figure 6-25 Source Search Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When Source window is displayed

- Click the <Search> button.
(or press Ctrl and G in that order).
- Select [View] -> [Search...]
(or press Alt+V, and S in that order).

Explanation of each area

The Source Search dialog box consists of the following areas:

- (1) Find What (search data specification area)
- (2) Match Case (search condition specification area)
- (3) Direction (search direction specification area)

(1) Find What (search data specification area)

This area is used to specify the data to be searched.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string.

Up to 256 character string can be specified.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

(2) Match Case (search condition specification area)

This area is used to specify whether uppercase and lowercase characters are distinguished, before searching is started.

Checked	Distinguished (default)
Not checked	Not distinguished

(3) Direction (search direction specification area)

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search (default). Searches data backward (downward on screen) from the current position of the cursor.

Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (during search)	Stops searching.

Cancel	Closes this dialog box. This button is displayed as the <Stop> button while data is being searched.
Help	Opens the Help window.


Assemble window

This window is used to disassemble and display programs. It is also used to execute online assembly.

To execute online assembly, move the cursor to a mnemonic. The results of online assembly are also reflected in the Memory window.

The Assemble window has two statuses: Active Status and Static Status.

Figure 6-26 Assemble Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
- Cautions

Concerning display

- To change the display start position
- To change the displayed offset and register name

Concerning operation

- Start function
- Come function
- Program counter setting function
- Jump function
- To change the disassembled contents
- Watch function (referencing data value)

- To search in the Assemble window
- To set a default breakpoint
- Drag & drop function (line/address)
- Drag & drop function (character string)

Opening

This window can be opened as follows:

- Click the **Asm** button.
- Select [B]rowse -> [A]ssemble from the menu bar (or press Alt+B, and A in that order).
- Select [J]ump -> [A]ssemble from the menu bar (or press Alt+J and A in that order, or press Ctrl+D).

Explanation of each area

The Assemble window consists of the following areas:

- (1) Point mark area
- (2) Current PC mark area
- (3) Address specification area
- (4) Disassemble display area

(1) Point mark area



This area is displayed the Breakpoint setting/deletion function and the Event setting status.

(2) Current PC mark area



The mark '>', which indicates the current PC value (PC register value), is displayed in this area.

By double-clicking the current PC mark area, the program can be executed up to a specified line.

(3) Address specification area

```

0015B
0015D
0015F
00162
00163
00165
00167

```

This area displays the disassembly start address. When this area is clicked, an address highlighted and selected.

This area has the Drag & drop function (line/address) (refer to p.125) and the Trace Result with Linking Window (refer to p.34) function.

Caution The end address (0xFFFFF) is not displayed.

(4) Disassemble display area

?R_INIS	61D0	SEL	RB0
	EE1C20FE	MOVW	SP, #0FE20H
	9A6D02	CALL	!_hdwinit
	100000	MOVW	AX, #0H
	0354FB	MOVW	!_errno, AX
	0340FB	MOVW	!_@FNCENT, AX
	0344FB	MOVW	!_@SEED+0x2, AX
	40	INC	X
	0342FB	MOVW	!_@SEED, AX
	1058FB	MOVW	AX, #0FB58H
	0356FB	MOVW	!_@ERKADR, AX
	168000	MOVW	HL, #80H
	1480FB	MOVW	DE, #0FB80H
	C6	MOVW	AX, HL
	EA8000	CMFW	AX, #80H
	AD06	EZ	\$_?R_INIS+0x31
	87	MOV	A, [HL]
	95	MOV	[DE], A
	86	INCW	HL
	84	INCW	DE
	FAF4	BR	\$_?R_INIS+0x25
	1678FB	MOVW	HL, #0FB78H
	C6	MOVW	AX, HL
	EA80FB	CMFW	AX, #0FB80H
	AD06	EZ	\$_?R_INIS+0x40
	1100	MOV	A, #0H

This area displays the labels and code data of addresses, and disassembled mnemonics.

The current PC line and breakpoint setting line are displayed in different colors for emphasis (refer to "Source text display area").

The disassembled mnemonics displayed in the mnemonic field can be changed (refer to "To change the disassembled contents (p.136)").

If the number of new instruction bytes is less than the number of previous instruction bytes as a result of changing, as many 'NOP' instructions as necessary are inserted. If the number of new instruction bytes is more than the number of previous instruction bytes, the next instruction is overwritten. In this case also, as many 'NOP' instructions as necessary are inserted. The same applies to instructions that straddle over source lines.

In this area, the following functions can be used on the line or address on which the cursor is placed (start address of program code):

- > Start function
- > Come function
- > Program counter setting function
- > Jump Function

A character string selected in this area can be dragged and dropped in another window or dialog box

(refer to "Drag & drop function (character string) (p.126)").

Caution Up to 319 characters can be displayed on 1 line.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Move...	Moves the display position. Opens the Address Move dialog box.
Add Watch	Adds the specified data to the Watch window. Opens the Add Watch dialog box.
Symbol	Displays the address of the specified variable or function, or the value of the specified symbol. Opens the Symbol To Address dialog box.
Come Here	Executes the program from the current PC to the cursor position (Come function).
Change PC	Sets the address at the cursor position to the PC.
Break Pont	Sets or deletes a breakpoint at the cursor position.
Software Break Point	Sets or cancels a software break point at the cursor position.
Source Text	Displays the corresponding source text and source line, using the data value at the cursor position as the jump destination address. If no line information exists at the jump destination address, however, you cannot jump. Opens the Source window. If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. Opens the Memory window. If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

Search...	<p>Opens the Assemble Search dialog box and searches for a character string of mnemonics.</p> <p>If a character string is selected in the disassemble display area, the Assemble Search dialog box is opened to search for the character string. If no character string is selected, the Assemble Search dialog box is opened with nothing specified to be searched.</p> <p>Specify a search method in the Assemble Search dialog box. The result of search is highlighted in the Assemble window.</p> <p>This is the same operation as selecting [View] -> [Search...] from the menu bar.</p>
<<	<p>Searches forward (upward on screen) for the contents that satisfy the search condition set in the Assemble Search dialog box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p>
>>	<p>Searches backward (downward on screen) for the contents that satisfy the search condition set in the Assemble Search dialog box, starting from the address at the cursor position.</p> <p>This button is displayed as the <Stop> button during a search.</p>
Stop (during search)	Stops searching.
Watch	<p>Adds the symbols selected in the disassemble display area to the Watch window. If the Watch window is not opened, it is opened.</p> <p>If no text is selected in the disassemble display area, the Watch window is only opened.</p> <p>This is the same operation as selecting [View] -> [View Watch] from the menu bar.</p>
Quick...	<p>Temporarily displays the contents, such as symbols, selected in the disassemble display area on the Quick Watch dialog box. Opens the Quick Watch dialog box.</p> <p>If no text is selected in the disassemble display area, the Quick Watch dialog box is only opened.</p> <p>This is the same operation as selecting [View] -> [Quick Watch...] from the menu bar.</p>
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To change the display start position

Change the display start position in the Address Move dialog box, which is opened when right-click menu -> [Move...] is selected in the Assemble window.

To change the displayed offset and register name

Change the display offset or register name under DisAssemble (offset display setting area) in the Debugger Option dialog box that is opened when [Option] -> [Debugger Option...] is selected from the menu bar. A function name or an absolute name can be selected as a register name.

Start function

For the operation, refer to "Start function (p.123)" in the Source window.

Come function

For the operation, refer to "Come function (p.123)" in the Source window.

Program counter setting function

For the operation, refer to "Program counter setting function (p.123)" in the Source window.

Jump function

For the operation, refer to "Jump function (p.123)" in the Source window.

To change the disassembled contents

To change the disassembled contents, move the cursor to the mnemonic field (the overwrite and insertion modes are alternately selected by pressing the Insert key).

If an attempt is made to move the cursor to another line after the disassembled contents have been changed in the mnemonic field, the new contents are checked. If the new contents are illegal, the code data on the line where the contents have been changed is indicated as "**". In this case, the new contents are not written to memory even if the cursor is moved to another line.

The contents changed in the mnemonic field are written into the memory by pressing the Enter key. When the Enter key is pressed, the new contents are checked and, if they are illegal, the code data on the illegal line is indicated by "**". If even one line is illegal, the new contents are not written into the memory.

In this case, correct the contents. To discard the contents, press the ESC key. If the contents are correct and if the Enter key is pressed, the contents are written into the memory, and then the cursor moves to the next line in the mnemonic field, so that the data on the next line can be changed.

Watch function (referencing data value)

For the operation, refer to "Watch function (referencing data value)" in the Source window.

To search in the Assemble window

Use the Assemble Search dialog box, which can be opened by clicking the <Search...> button in the Assemble window. If the character string to be searched is existed in the window, select that character string and click the <Search...> button. The selected character string is opened in the specified format.

To set a default breakpoint

For details, refer to "To set a default breakpoint (p.125)" described in the Source window.

Drag & drop function (line/address)

For the operation, refer to "Drag & drop function (line/address) (p.125)" in the Source window.

Drag & drop function (character string)

For the operation, refer to "Drag & drop function (character string) (p.126)" in the Source window.

Cautions

When moving the display contents forward (upward) by scrolling forward or searching, the contents may not be displayed correctly at the boundary between the previously-displayed topmost address and

the contents. In this case, try displaying again from the correct section start address or symbol by moving the address.

Assemble Search dialog box


This dialog box is used to search the contents of Assemble window.

Successive character strings included in an input character string and disassembler character string are compared as one blank character.

By setting each item and then clicking the <Find Next> button, searching can be started.

By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Assemble window can be used for the search.

Figure 6-27 Assemble Search Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When Assemble window is the current window

- Click the <Search> button.
(or press Ctrl+G).
- Select [View] -> [Search...]
(or press Alt+V, and S in that order).

Explanation of each area

The Assemble Search dialog box consists of the following areas:

- (1) Find What (search data specification area)
- (2) Match Case (search condition specification area)
- (3) Scan Whole Region (search condition specification area)
- (4) Direction (search direction specification area)

(5) Address (search range specification area)

(1) **Find What** (search data specification area)

Find What:

This area is used to specify the data to be searched.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string.

Up to 256 character string can be specified.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

(2) **Match Case** (search condition specification area)

☒ Match Case

This area is used to specify whether uppercase and lowercase characters are distinguished, before searching is started.

Checked	Distinguished (default)
Not checked	Not distinguished

(3) **Scan Whole Region** (search condition specification area)

☐ Scan Whole Region

This area is used to specify whether the specified range is fully searched or not.

Checked	Searches the entire range.
Not checked	Searches the remaining part of the range (default)

(4) **Direction** (search direction specification area)

Direction
☐ Up ☒ Down

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search (default). Searches data backward (downward on screen) from the current position of the cursor.

(5) Address (search range specification area)

Address: ---

This area is used to specify the address to be searched.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (during search)	Stops searching.
Cancel	Closes this dialog box. This button is displayed as the <Stop> button while data is being searched.
Help	Opens the Help window.

Memory window

This window is used to display and change the memory contents.


The display start position when the Memory window is opened is as follows:

First time	Display starts from the first address of the real-time RAM sampling area.
Second and subsequent times	Display starts from the address at which an active status window was closed (if an active status window has never been closed, display starts from the first display start position).

Even while the program is being executed, the range set in the Extended Option dialog box can be displayed in real time.

The Memory window has two statuses: Active Status and Static Status.

Figure 6-28 Memory Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To change the memory contents
 - To change the display start position
 - To search in the Memory window
 - To display ASCII characters
 - To initialize the memory contents with a specified code

- To copy the memory contents
- To compare the memory contents
- To verify and check a memory write

Opening

This window can be opened as follows:

- Click the **Mem** button.
- Select [Browse] -> [Memory...] from the menu bar (or press Alt+B, and M in that order).
- Select [Jump] -> [Memory...] from the menu bar (or press Alt+J, and M in that order).

Explanation of each area

The Memory window consists of the following areas:

- (1) Addr (address display area)
- (2) +0 +1 +2....(memory display area)
- (3) 0 1 2 3.... (ASCII display area)

(1) Addr (address display area)

```

Addr
FEE00
FEE10
FEE20
FEE30
FEE40
FEE50
FEE60
FEE70

```

This area displays memory addresses.

Address width changes at the time of memory bank use.

(2) +0 +1 +2....(memory display area)

+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+
00	20	00	00	00	00	08	00	00	00	d
00	00	04	00	00	00	00	00	0C	08	d
02	00	00	00	40	00	00	80	00	00	d
02	02	00	00	60	00	02	01	00	00	d
00	00	00	00	00	00	00	00	00	08	d
00	00	00	00	00	00	00	00	00	00	d

This area is used to display and change the memory contents.

Data into which the current memory contents are to be changed is displayed in red and is actually written to the target when the Enter key is pressed. The contents (displayed in red) can be canceled by the ESC key. Up to 256 bytes can be specified at one time.

This area is also used as a jump pointer of the jump function. In addition, it also has the Trace Result with Linking Window function.

(3) 0 1 2 3.... (ASCII display area)

```

0123456789ABCDEF
..P..?ª.Ø...4...
...»²HÁ.B.×...{o
.K.|.¼...4.G.¿\
É.O...]no..XI...
..w@..oÉ}....¿.B/
.....Pw....YÜ.-
¿-µ....ESB¼.-?l
Ü.¼...³..qy¼.¼.ØÜ
aD....m.....T..

```

This area is used to display and change the memory contents in ASCII characters.

This area is displayed when right-click menu -> [Ascii] is selected. Display of this area can be turned on/off by this menu item.

Data can be changed in this area in the same manner as in the memory display area.

This area is also used as a jump pointer of the jump function.

Caution Even if the cursor is placed on this area, once the focus is lost, the cursor position returns to the memory display area.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Move...	Moves the display position. Opens the Address Move dialog box.
Bin	Displays binary numbers.
Oct	Displays octal numbers.
Dec	Displays decimal numbers.
Hex	Displays hexadecimal numbers (default).
Nibble	Displays in 4-bit units.
Byte	Displays in 8-bit units (default).
Word	Displays in 16-bit units.
Double Word	Displays in 32-bit units.
Ascii	Turns on/off display of ASCII characters. Checked: Displayed Not checked: No display (default)

Function buttons

Search...	Opens the Memory Search dialog box and searches for character strings from the displayed memory contents, or memory contents. Selected data (a memory value) is displayed in the Memory Search dialog box as data to be searched. If the Memory Search dialog box is opened without data specified, specify data from the keyboard. The result of the search is highlighted in the Memory window.
<<	Searches the memory contents satisfying the search condition set in the Memory Search dialog box, forward (upward on screen) from the address at the cursor position. This button is displayed as the <Stop> button during a search.
>>	Searches the memory contents satisfying the search condition set in the Memory Search dialog box, backward (downward on screen) from the address at the cursor position. This button is displayed as the <Stop> button during a search.
Stop (during search)	Stops searching.
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To change the memory contents

To change the memory contents, move the cursor to the memory display area or ASCII display area in the window, and write data directly from the keyboard. The amount of memory contents that can be changed at one time is 256 bytes or less. To set the change, press the return key. To cancel the change, press the ESC key.

To change the display start position

Use the Address Move dialog box, which can be opened by selecting right-click menu -> [Move] in the Memory window.

To search in the Memory window

Use the Memory Search dialog box, which can be opened by clicking the <Search...> button in the Memory window. If the character string to be searched exists in the window, select that character string and click the <Search...> button. The selected character string is opened in the specified format. Non-mapped, SFR, and I/O protect areas are not searched.

To display ASCII characters

The memory contents are displayed in ASCII characters when right-click menu -> [Ascii] is selected in the Memory window.

To turn off display of ASCII characters, select [Ascii] again to remove the check mark.

To initialize the memory contents with a specified code

Initialize the memory contents with a specified code in the Memory Fill dialog box, which can be opened by selecting [Edit] -> [Memory] -> [Initialize] from the menu bar.

If verify check is enabled in the Extended Option dialog box, verify check is executed after initialization.

To copy the memory contents

Copy the memory contents in the Memory Copy dialog box, which can be opened by selecting [Edit] -> [Memory] -> [Copy] from the menu bar.

If verify check is enabled in the Extended Option dialog box, verify check is executed after copy.

To compare the memory contents

Compare the memory contents in the Memory Compare dialog box, which can be opened by selecting [Edit] -> [Memory] -> [Compare] from the menu bar.

If a difference is found as a result of comparison, the Memory Compare Result dialog box is opened and the details are displayed in this dialog box.

To verify and check a memory write

Use the Extended Option dialog box, which is opened by selecting [Option] -> [Extended Option] from the menu bar. To execute a verify check, check the [Verify] check box.

Memory Search dialog box

This dialog box is used to search the memory contents of the part of Memory window at which the cursor is located.


If the cursor is in the memory display area, the memory display area is searched for specified data, which is assumed to be a binary data string. If the cursor is in the ASCII display area, the ASCII display area is searched for specified data, which is assumed to be an ASCII character string.

By setting each item and then clicking the <Find Next> button, searching can be started.

By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Memory window can be used for the search.

Non-mapped, SFR, and I/O protect areas are not searched.

Figure 6-29 Memory Search Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When Memory window is the current window

- Click the <Search> button.
(or press Ctrl+G).
- Select [View] -> [Search...]
(or press Alt+V, and S in that order).

Explanation of each area

The Memory Search dialog box consists of the following areas:

- (1) Find What (search data specification area)
- (2) Unit (search condition specification area)
- (3) Scan Whole Region (search condition specification area)
- (4) Direction (search direction specification area)
- (5) Address (search range specification area)

(1) Find What (search data specification area)




This area is used to specify the data to be searched.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string.

When searching the memory display area, up to 16 data items can be specified. Delimit each data with a "blank character". When searching the ASCII display area, data of up to 256 characters can be specified. A "blank character" in the data is treated as a blank character.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.


(2) Unit (search condition specification area)



This area is used to specify the number of bits of the data to be searched in the memory display area.


Byte	Searches the data as 8-bit data (default).
Word	Searches the data as 16-bit data.
Double Word	Searches the data as 32-bit data.

(3) Scan Whole Region (search condition specification area)



This area is used to specify whether the specified range is fully searched or not.

Checked	Searches the entire range.
Not checked	Searches the remaining part of the range (default)

(4) Direction (search direction specification area)

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search (default). Searches data backward (downward on screen) from the current position of the cursor.

(5) Address (search range specification area)

This area is used to specify the address to be searched.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.


Function buttons

Find Next	Searches the specified data in accordance with a given condition. If the specified character string is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.
Stop (during search)	Stops searching.
Cancel	Closes this dialog box. This button is displayed as the <Stop> button while data is being searched.
Help	Opens the Help window.

Memory Fill dialog box

This dialog box is used to initialize the memory contents in the Memory window with specified codes.

Figure 6-30 Memory Fill Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [Edit] -> [Memory] -> [Fill] from the menu bar.
(or press Alt+E, M and F in that order).

Explanation of each area

The Memory Fill dialog box consists of the following areas:

- (1) Address (address range specification area)
- (2) fill code (data specification area)

(1) Address (address range specification area)

Address
From: 0 -- 0

This area is used to specify the memory address range whose contents are to be initialized.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Input the first address to be initialized and then the last address to be initialized.

(2) fill code (data specification area)

fill code =>

This area is used to specify the data with which the memory contents are to be initialized.

Up to 16 binary data strings (byte data strings) can be specified.

Delimit each data with a "blank character".


Function buttons

OK	Initializes the memory.
Stop (during initialization)	Stops initialization. While initialization is in progress, the <Cancel> button is replaced by the <Stop> button.
Cancel	Closes this dialog box. While memory contents are being initialized, this button is replaced by the <Stop> button.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Memory Copy dialog box

This dialog box is used to copy the memory contents in the Memory window.

Figure 6-31 Memory Copy Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [Edit] -> [Memory] -> [Copy] from the menu bar.
(or press Alt+E, M and C in that order).

Explanation of each area

The Memory Copy dialog box consists of the following area:

- (1) Address (address range specification area)

(1) Address (address range specification area)



This area is used to specify the copy source and copy destination addresses.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

From	Specify the address range of the copy source. Input the first address of the copy source and then the end address.
To	Specify the first address of the copy destination.


Function buttons

OK	Copies the memory.
Stop (during copying)	Stops copying. While copying is in progress, the <Cancel> button is replaced by the <Stop> button.
Cancel	Closes this dialog box. While copying is in progress, this button is replaced by the <Stop> button.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Memory Compare dialog box

This dialog box is used to compare the memory contents in the Memory window.

Figure 6-32 Memory Compare Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:


- Select [E]dit -> [M]emory -> [C]ompare from the menu bar.
(or press Alt+E, M and P in that order).

Explanation of each area

The Memory Compare dialog box consists of the following area:

- (1) Address (comparison range specification area)

(1) Address (comparison range specification area)




This area is used to specify the comparison source address and comparison destination address.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Mem1	Specify the address range of the comparison source. Input the first address of the comparison source and then the end address.
Mem2	Specify the first address of the comparison destination.

Function buttons


OK	<p>Compares the memory. If no difference is found as a result of comparison, a confirmation dialog box is displayed. If a difference is found, Memory Compare Result dialog box is opened.</p> <p style="text-align: center;">Figure 6-33 Confirmation Dialog Box</p>  <p>Clicking the <OK> button ends memory comparison.</p>
Stop (during comparison)	<p>Stops memory comparison. While comparison is in progress, the <Cancel> button is replaced by the <Stop> button.</p>
Cancel	<p>Closes this dialog box. While comparison is in progress, this button is replaced by the <Stop> button.</p>
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Memory Compare Result dialog box

Displays the result of comparing the memory.

This dialog box is displayed if any difference is found in the memory contents when the memory has been compared in Memory Compare dialog box.

Figure 6-34 Memory Compare Result Dialog Box



This section explains the following items:

- Explanation of each area
- Function buttons

Explanation of each area

The Memory Compare Result dialog box consists of the following area:

- (1) Mem1, Mem2 (comparison result display area)

- (1) **Mem1**, **Mem2** (comparison result display area)

Mem1 Addr	Memory		Mem2 Addr
00080	7F	8F	00120
00081	FF	3E	00121
00082	70	9F	00122
00083	ED	FE	00123
00084	BF	9F	00124
00085	E7	9E	00125
00086	7F	37	00126
00087	5E	DC	00127
00088	95	D7	00128
00089	FF	FF	00129

This area displays the results of comparing the memory. Only differences that have been found as a

result of comparison are displayed.

Mem1 Addr	Displays a comparison source address in which a difference has been found.
Memory	Displays the data in which a difference has been found. Left: Comparison source data Right: Comparison destination data
Mem2 Addr	Displays the comparison destination address at which a difference has been found.

Function buttons

Close	Closes this dialog box.
Help	Opens the Help window.

Watch window

This window is used to display and change specified data.


The result of updating and rewriting data in this window will be reflected in the Memory window.

This window can also display wide-ranging data (such as global variables and public symbols) in real time even during program execution, in the same way as the Memory window.

To set a breakpoint for read/write access to a variable can be performed by a single action from the menu that is displayed by clicking the right mouse button.

Caution If a local variable and a global variable exist with the same name, the local variable takes priority.

Figure 6-35 Watch Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To add/delete displayed data (variable)
 - To change data on the selected line
 - To temporarily display a data (variable) value
 - To display/change a local variable value
 - To set a breakpoint for read/write access to a variable
 - To change displayed radix/size

Opening

This window can be opened as follows:

- Click the **Wch** button.
Select **[Browse]** -> **[Watch]** from the menu bar,
(or press Alt+B, and W in that order).

Select data in the Source window or Assemble window,

- Select **[View]** -> **[View Watch]** from the menu bar,
(or press Alt+ V, and I in that order),
or click the <Watch> button.

In the Quick Watch dialog box or Add Watch dialog box dialog box,


- Click the <Add> button.

Explanation of each area

The Watch window consists of the following areas:

- Left field (symbol name display area)
- Right field (data value display/setting area)

(1) Left field (symbol name display area)



This area is used to display variable names, symbol names and types, and tag names of structures or unions.

Refer to "Name (symbol specification area)" in the Add Watch dialog box for details on the displayed contents.

'+' is prefixed to the displayed arrays, pointer variables, and structures or unions. These variables are expanded and displayed as follows when they are double-clicked:

Array	All the elements of the variable are displayed in accordance with the type of the array variable.
-------	---

Pointer variable	The data indicated by the pointer is displayed.
Structure/union	<p>All the members of the structure/union are displayed in accordance with the type of the member variable.</p> <p>If a structure or union is defined in the structure or union, the structure name or union name of the internal structure or union is also displayed.</p> <p>The internal structure or union can be also expanded by using '+'. </p>


'+' of the variable that has been expanded and displayed changes to '-'. If the variable is double-clicked in this status, the expanded display is canceled. Expanded display can be also specified or canceled by selecting a variable with the arrow keys and then pressing the Enter key.

If an access breakpoint is set for a variable or a symbol in the Watch window, the symbol name display area is highlighted in gold.

Caution Up to 319 characters can be displayed on 1 line.

Reference If an array has too many variables and takes too long to expand, a warning message is displayed.

(2) Right field (data value display/setting area)



This area is used to display and change data values.

A value is updated when execution is stopped. To save a value, select [File] -> [Save As...] from the menu bar when the Save window is the current window. This area is blank if getting data has failed.

'?' is displayed for data that has been invalidated because of a change in the scope or optimized compiling. The contents of the change are written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

The display format is as follows:

Table 6-19 Data Display Format (Watch-Related)

Display Data	Contents
Integer	Displayed in the same manner as the language specified in the Debugger Option dialog box. C-like (value: xxxx) Hexadecimal (0 xxxx) Decimal (xxxx) Octal (0 xxxx) Binary (0 bxxxx) Assembly language-like (value: xxxx) Hexadecimal (xxxx H) Decimal (xxxx T) Octal (xxxx Q) Binary (0 bxxxx Y)
Enumeration type	Member name
If scope is specified	Displayed in accordance with specified scope
Floating-point type	Single precision/double precision supported The input/display format is as follows: [+ -] inf [+ -] nan [+ -] integer e [+ -]exponent [+ -] integer.fraction [e [+ -]exponent

The size and radix of a data value can be specified on the [View] menu for each variable.

However, the display size cannot be selected if the display size is fixed, such as for variables in C or bit symbols or registers of the assembler.

If [View] -> [Adaptive] or [View] -> [Proper] from the menu bar is selected, the size and radix specified in the Debugger Option dialog box are used for display (refer to "To change displayed radix/size").

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Break when Access to this Variable ^{Note}	Creates a break event that occurs if the selected variable is accessed for read/write.
Break when Write to this Variable ^{Note}	Creates a break event that occurs if the selected variable is accessed for write.
Break when Read from this Variable ^{Note}	Creates a break event that occurs if the selected variable is accessed for read.
Clear	Deletes the break event corresponding to the selected variable.
Event?	Displays the event information of the line at the cursor position or the selected variable. If an event is set, Event dialog box is opened.

Change Watch...	Changes the selected data.
Delete Watch	Deletes the selected watch point from the window.
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable. Symbols are displayed in accordance with the setting of Debugger Option dialog box (default).
Byte	Displays the selected line in 8-bit units.
Word	Displays the selected line in 16-bit units.
General	Displays the selected line in 24-bit units.
Double Word	Displays the selected line in 32-bit units.
Adaptive	Displays the selected line as the default value of each variable. Only this item is valid for a symbol in C language. Symbols in assembly language are displayed in accordance with the setting of Debugger Option dialog box (default).
Up	Moves the selected line one line up.
Down	Moves the selected line one line down.

Note No breakpoint can be set for structure and union members, array members, bit field members, etc. In such a case, get the address in the Symbol To Address dialog box and then set a breakpoint for that address.

Function buttons

Add...	Opens the Add Watch dialog box. If data is specified and the <Add...> button is clicked in the Add Watch dialog box, the specified data is added to the Watch window.
Delete	Deletes the specified data from the Watch window. The DEL key performs the same operation.
Up	Moves the selected data one line up.
Down	Moves the selected data one line down.
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To add/delete displayed data (variable)

Addition method (any of the following)

- Select a variable name or symbol name and click the <Watch> button in the Source window or Assemble window.
- Select a variable name or symbol name in the Source window or Assemble window, and drag it to the Watch window.
- Specify a variable name or symbol name and click the <Add> button in the Quick Watch dialog box or Add Watch dialog box.

Deletion method

- Click a variable name or symbol name (two or more variable or symbol names can be selected using the Shift or Ctrl key), and click the <Delete> button. A line with an expanded hierarchy, such as the elements of an array, and members of structures and unions cannot be changed.

To change data on the selected line

To change data (variables), select a line to be changed in the Watch window and select right-click menu -> [Change Watch...]. The Change Watch dialog box will be opened to change the data.

A line with an expanded hierarchy, such as the elements of an array, and members of structures and unions cannot be deleted.

To temporarily display a data (variable) value

A data (variable) value can be temporarily displayed in the following two ways:

To display using the balloon watch function

Select data (a variable name) in the Source window or Assemble window. Then place the mouse cursor on the selected character string. The value of the selected data will be displayed.

To display in the Quick Watch dialog box

Select data (a variable name) in the Source window or Assemble window. Then click the <Quick...> button. The value of the selected data will be displayed in the Quick Watch dialog box.

To display/change a local variable value

A local variable value can be checked or changed in the Local Variable window, which is opened when the **Loc** button is clicked.

In this window, the local variable in the current function is automatically displayed and the displayed variable cannot be added or deleted.

To change a local variable value, move the cursor to the local variable value display/changing area on the window and write a value in this area directly from the keyboard.

To determine the displayed contents, use the Enter key. To cancel, use the ESC key.

To set a breakpoint for read/write access to a variable

Select a variable in the Watch window and select [Break when Access to this Variable], [Break when Write to this Variable] or [Break when Read from this Variable] from the right-click menu. In this way, a hardware break event will be created in the valid status in accordance with the selected item.

Whether the event has been correctly created can be confirmed on the Event Manager.

To change displayed radix/size**Changing each data (variable) at any time**

Select a data (variable) name to be changed in the Watch window or Quick Watch dialog box, and select the radix and size from the right-click menu.

Specifying default condition

Adaptive (when display size is specified) or Proper (when display radix is specified) for watching a symbol that specifies a default value can be set as the default assumption.


This is done in the Watch Default area of the Debugger Option dialog box, which is opened when [Option] -> [Debugger Option...] is selected from the menu bar.

The size specified under Size is displayed when Adaptive is specified, and the radix specified under Radix is displayed when Proper is specified.

Quick Watch dialog box

This dialog box is used to temporarily display or change specified data.

Figure 6-36 Quick Watch Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [View] -> [Quick Watch...]
(or press Alt+V, and Q in that order).
- Click the <Quick> button in Source window.
(or press Ctrl+W).
- Click the <Quick> button in Assemble window.
(or press Ctrl+W).

Explanation of each area

The Quick Watch dialog box consists of the following areas:

- (1) Name (symbol specification area)
- (2) Symbol name display area
- (3) Data value display/setting area
- (4) Display radix selection area (upper left field)

- (5) Display size selection area (second upper left field)
- (6) Number (display number specification area)

(1) Name (symbol specification area)

Name:


This area is used to specify the data to be displayed.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string. This area is blank if no character string is selected.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

If the contents of **Name** have been changed, the data specified in **Name** can be displayed in the field below by clicking the <View> button.

(2) Symbol name display area




This area is used to display the variable name and the symbol name.

The displayed contents are the same as those of Name (symbol specification area) in the Add Watch dialog box.

Caution Up to 319 characters can be displayed on 1 line.

(3) Data value display/setting area



This area is used to display and change data values. The displayed contents and display method are the same as those of Watch window.

The displayed contents are the same as those of Right field (data value display/setting area) in the Watch window.

(4) Display radix selection area (upper left field)

This area is used to select the display radix.

The display radix of the data name selected in the symbol name display area will be changed.

Proper	Variable The default value of each variable is displayed. Symbol Displays data with the radix set in Debugger Option dialog box.
Hex	Displays data in hexadecimal numbers (0xxxxx)
Dec	Displays data in decimal numbers (xxxx)
Oct	Displays data in octal numbers (0xxxxx)
Bin	Displays data in binary numbers (0bxxxxx)
String	Displays character strings.

(5) Display size selection area (second upper left field)

This area is used to select the display size.

The display size of the data selected in the symbol name display area will be changed.

If the display size is fixed, such as when a variable in C or register is to be displayed, it cannot be changed.

Adaptive	Variable The default value of each variable is displayed. Symbol Displays data with the size set in Debugger Option dialog box.
Byte	Displays data in 8 bits.
Word	Displays data in 16 bits.
General	Displays data in 24 bits.
Double Word	Displays data in 32 bits.

(6) Number (display number specification area)

Number:

This area is used to specify the number of data to be displayed.

Specify blank or a number of 1 to 256.

If this area is blank, data is displayed as a simple variable.

If a number of 1 or more is specified, data is displayed as an array variable.

If an array variable is displayed, '+' is prefixed to the data. By double-clicking this '+', all the elements of the data are expanded and displayed in accordance with the type of the data ('-' is prefixed to the

expanded data. If this '-' is double-clicked, the expanded display is canceled).

If the number of data to be displayed is fixed, such as when a variable in C or register is to be displayed, the specified number of data is invalid.

Function buttons


View	Displays the data specified in Name in the field below.
Add	Displays the data specified in Name to the Watch window.
Close	Closes this dialog box. Data that has not actually been written to the target will be canceled.

Add Watch dialog box

This dialog box is used to register data to be displayed in the Watch window.

Multiple data with the same symbol name can be registered.

Figure 6-37 Add Watch Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [View] -> [Add Watch...] from the menu bar (or press Alt+V, and W in that order).
- Click the <Add> button in Watch window.

Explanation of each area

The Add Watch dialog box consists of the following areas:

- (1) Name (symbol specification area)
- (2) Radix (display radix selection area)
- (3) Size (display size specification area)
- (4) Number (display number specification area)

(1) Name (symbol specification area)

This area is used to specify data to be added to the Watch window.

In the default condition, the character string selected in the window that called this dialog box is displayed. As necessary, input data from the keyboard to change the character string. This area is blank if no character string is selected.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

The format in which a variable can be input and how a variable is handled when a scope is specified are as follows:

- Variable Name

Variable expression : Variable Name

|Variable expression[Constant value | Variable Name] Elements of array

|Variable expression . Member name Entity members of structure/union

|Variable expression -> Member name Members of structure/union indicated by pointer

|*Variable expression Value of pointer variable

|&Variable expression Address where variable is located


- Register name
- SFR name, SFR bit name
- Label and address of immediate value
- Register name . bit
- Label name . bit , address of immediate value . bit
- Specification of scope

Scope Specification	Program name	File name	Function name	Variable Name
prog\$file#func#var	prog	file	func	var
prog\$file#var	prog	file	Global	var
prog\$func#var	prog	Global	func	var
prog\$var	prog	Global	Global	var
file#func#var	Current	file	func	var
file#var	Current	file	Global	var
func#var	Current	Current	func	var
var	Current	Current	Current	var

(2) Radix (display radix selection area)

This area is used to change the radix of the data to be displayed.

Proper	Variable The default value of each variable is displayed. Symbol Displays data with the radix set in Debugger Option dialog box.
Hex	Displays data in hexadecimal numbers (0 xxxxx)
Dec	Displays data in decimal numbers (xxxx)
Oct	Displays data in octal numbers (0 xxxx)
Bin	Displays data in binary numbers (0b xxxx)
String	Displays character strings.

(3) Size (display size specification area)

This area is used to change the size of data to be displayed.

If the display size is fixed, such as when a variable in C or a bit symbol or register of the assembler is to be displayed, it cannot be changed.

Adaptive	Variable The default value of each variable is displayed. Symbol Displays data with the size set in Debugger Option dialog box.
Byte	Displays data in 8 bits.
Word	Displays data in 16 bits.
General	Displays data in 24 bits.
Double Word	Displays data in 32 bits.

(4) Number (display number specification area)

This area is used to specify the number of data to be displayed.

Specify blank or a number of 1 to 256.

If this area is blank, data is displayed in Watch window as a simple variable.

If a number of 1 or more is specified, data is displayed in the Watch window as an array variable.

The maximum number of lines that can be displayed in the Watch window is 10,000.

If an array variable is displayed, '+' is prefixed to the data. By double-clicking this '+', all the elements of the data are expanded and displayed in accordance with the type of the data ('-' is prefixed to the

expanded data. If this '-' is double-clicked, the expanded display is canceled).

If the number of data to be displayed is fixed, such as when a variable in C or register is to be displayed, the number of data is invalid in the Watch window even if it has been changed.

Function buttons

Add	Adds the specified data to the Watch window. The dialog box remains open.
OK	Adds the specified data to the Watch window. Closes this dialog box.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Change Watch dialog box


This window is used to change the data on a line selected in the Watch window.

A line with an open hierarchy, such as the elements of an array, and members of structures and unions cannot be changed.

When watch data is changed, the contents of the selected line are replaced with the new data.

The symbol name can be changed even if it results in duplication of a name already in use with existing data.

Figure 6-38 Change Watch Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When the Watch window is open or a line is selected

- Select [View] -> [Change Watch...] from the menu bar (or press Alt+V, and G in that order).

Explanation of each area

The Change Watch dialog box consists of the following areas:

- (1) Name (symbol specification area)
- (2) Radix (display radix selection area)
- (3) Size (display size specification area)
- (4) Number (display number specification area)

(1) Name (symbol specification area)

This area is used to change a symbol name.

By displaying the input history, the contents previously input can be reused. Up to 16 input histories can be recorded.

The format in which a symbol name can be input is the same as that of Name (symbol specification area) in the Add Watch dialog box.

(2) Radix (display radix selection area)

This area is used to change the radix of data to be displayed.

Proper	Variable The default value of each variable is displayed. Symbol Displays data with the radix set in Debugger Option dialog box.
Hex	Displays data in hexadecimal numbers (0 xxxx)
Dec	Displays data in decimal numbers (xxxx)
Oct	Displays data in octal numbers (0 xxxx)
Bin	Displays data in binary numbers (0b xxxx)
String	Displays character strings.

(3) Size (display size specification area)

Displays and modifies variables.

If the display size is fixed, such as when a variable in C or register is to be displayed, it cannot be changed.

Adaptive	Variable The default value of each variable is displayed. Symbol Displays data with the size set in Debugger Option dialog box.
Byte	Displays data in 8 bits.
Word	Displays data in 16 bits.
General	Displays data in 24 bits.
Double Word	Displays data in 32 bits.

(4) Number (display number specification area)

This area is used to specify the number of data to be displayed.

Specify blank or a number of 1 to 256.

If this area is blank, data is displayed in Watch window as a simple variable.

If a number of 1 or more is specified, data is displayed in the Watch window as an array variable.

The maximum number of lines that can be displayed in the Watch window is 10,000.

If an array variable is displayed, '+' is prefixed to the data. By double-clicking this '+', all the elements of the data are expanded and displayed in accordance with the type of the data ('-' is prefixed to the expanded data. If this '-' is double-clicked, the expanded display is canceled).

If the number of data to be displayed is fixed, such as when a variable in C or register is to be displayed, the number of data is invalid in the Watch window even if it has been changed.

Function buttons


Add	Cannot be selected.
OK	Replaces the registration contents currently selected with the specified data, and then closes this dialog box. Closes this dialog box.
Cancel	Closes this dialog box.
Restore	Restores the input data to the original status.
Help	Opens the Help window.

Local Variable window

This window is used to display and change the local variable in the current function.

This window automatically displays the local variable in the current function. It is linked with the jump function of the Stack Trace window, and displays the local variable in the function jumped when jumping to the Source window. Variables cannot be added or deleted.

Figure 6-39 Local Variable Window,



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons

Opening


This window can be opened as follows:

- Click the **Loc** button.
- Select [Browse] -> [Local Variable] from the menu bar, (or press Alt,+B, and L in that order).

Explanation of each area

The Local Variable window consists of the following areas:

- (1) Left field (local variable name display area)
- (2) Right field (local variable value display/setting area)

(1) Left field (local variable name display area)


This area displays local variable name.

Auto, internal Static, and Register variables can be displayed.

The display format is the same as that of the Watch window.

This area cannot be edited directly.

Caution Up to 319 characters can be displayed on 1 line.

(2) Right field (local variable value display/setting area)

This area displays local variable values.

The display format of the variable value is the same as that of the Watch window.

The display radix of variables can be switched by the menu selection in accordance with each variable.

The new value is written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Add Watch	Registers a selected character string to the Watch window. Opens the Add Watch dialog box.
-----------	---

Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable. Symbols are displayed in accordance with the setting of Debugger Option dialog box (default).

Function buttons

Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.


Stack Trace window

This window is used to display or change the current stack contents of the user program.

From this window, you can also jump to the Source window, Assemble window, and Memory window corresponding to the stack contents.

Caution The stack trace display function may not operate correctly if there is a frame pointer in a stack (function that does not push WHL (noauto, norec function, etc.)), or if the -qf option has been set as an optimization option during compiling. In addition, [ERROR] may be displayed during prologue or epilogue processing of a function.

Figure 6-40 Stack Trace Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons

Opening

This window can be opened as follows:

- Click the **Stk** button.
- Select [Browse] -> [Stack Trace] from the menu bar, (or press Alt+B , and K in that order).

Explanation of each area

The Stack Trace window consists of the following areas:

- (1) Left field (stack frame number display area)
- (2) Center field (stack frame contents display area)
- (3) Right field (stack contents display/setting area)


(1) Left field (stack frame number display area)



This area assigns numbers to and displays the stack contents.

A stack frame number is a natural number starting from 1. The shallower the nesting of the stack, the higher the number. This means that a function having stack number one higher than that of a certain function is the function that calls the certain function.

(2) Center field (stack frame contents display area)



This area displays the stack frame contents.

It displays function names or local variable names. Note, however, that this area cannot be directly edited.

If the stack contents consist of a function, they are displayed as follows:

program name\$file name#function name (argument list) #line number

If this line is double-clicked, the operation will be the same as jumping to the Source window of the jump function (i.e., the local variable in the function to which execution has jumped will be displayed in the Local Variable window).


If the function has a local variable, the local variable will be displayed on the next and subsequent lines.

If the stack contents consist of a local variable, its type and name are displayed. These are displayed in the same manner as in the Watch window. Note that the internal Static and Register variables are

not displayed.

Caution Up to 319 characters can be displayed on 1 line.

(3) Right field (stack contents display/setting area)



This area is used to display or change the stack contents.

'-' or a local variable value is displayed. If the stack contents are a function '-' is displayed and the function cannot be changed.

If the stack contents are a local variable, the variable value is displayed in the same manner as in the Watch window.

The display radix of variables can be switched by the menu selection in accordance with each variable.

A variable value can be changed. The new value is written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

This area is used as the jump source area of the jump function.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper	Displays the selected line as the default value of each variable. Symbols are displayed in accordance with the setting of Debugger Option dialog box (default).

Source Text	<p>Displays the corresponding source text and source line from the jump destination address specified by the data value at the cursor position (the local variable in the function to which you have jumped is displayed in the Local Variable window).</p> <p>If no line information exists at the jump destination address, however, you cannot jump.</p> <p>Opens the Source window.</p> <p>If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).</p>
Assemble	<p>Disassembles and displays starting from the jump destination address specified by the data value at the cursor position.</p> <p>Opens the Assemble window.</p> <p>If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).</p>
Memory	<p>Displays the memory contents starting from the jump destination address specified by the data value at the cursor position.</p> <p>Opens the Memory window.</p> <p>If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).</p>


Function buttons

Refresh	Updates the contents of the window with the latest data.
Shrink<<<	Collapses the local variable list of the selected function.
Expand>>>	Displays the local variable list of the selected function.
Close	Closes this window.

Register window

This window is used to display and change the contents of registers (general-purpose registers and control registers).

Figure 6-41 Register Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To change a register value

Opening

This window can be opened as follows:

- Click the **Reg** button.
- Select [Browse] -> [Register] from the menu bar, (or press Alt+B, and R in that order).


Explanation of each area

The Register window consists of the following areas:

- (1) Register bank setting area

- (2) Upper left field (general-purpose register display area)
- (3) Lower left field (control register display area)


(1) Register bank setting area



This area is used to display or change the bank number of the general-purpose registers.

Register Bank	Displays and sets the register bank to be displayed in the general-purpose register display area.
Current Bank	Displays the register bank number that is currently set as the target (current bank).

(2) Upper left field (general-purpose register display area)



This area is used to display or change the register of the bank number displayed in the Register Bank field in the register bank setting area.

The new value is written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

This area is also used as a jump pointer of the jump function.

When displaying in register pairs, the value of WP, UUP, TDE, WHL, RG4, RG5, RG6, or RG7 is a jumper pointer for the jump from the area of VP, UP, DE, HL, RP4, RP5, RP6, or RP7, respectively.

For the general-purpose register display method, absolute name display and function name display can be switched with [View] in the menu bar.

Caution If the width of the data value display/setting area is too narrow, display problems may occur. In this case, increase the width of the window.

Function Name			Absolute Name		
Pair Register		Register	Pair Register		Register
ax	x		rp0	r0	
	a			r1	
bc	c		rp1	r2	
	b			r3	
ax_	x_		rp2	r4	
	a_			r5	
bc_	c_		rp3	r6	
	b_			r7	
vvp	v		rg4	v	
	vp	r8		rp4	r8
		r9			r9
uup	u		rg5	u	
	up	r10		rp5	r10
		r11			r11
tde	t		rg6	t	
	de	d		rp6	r12
		e			r13
whl	w		rg7	w	
	hl	h		rp7	r14
		l			r15

When selecting [View] -> [Function Name] from the menu bar, this area is used to display or change the register of the bank number displayed in the Register Bank field in the register bank setting area of A, X, B, C, AX, and BC according to the RSS bit value.

Register	RSS=0	RSS=1
R0	X	X_
R1	A	A_
R2	C	C_
R3	B	B_
R4	X_	X
R5	A_	A
R6	C_	C
R7	B_	B

Register	RSS=0	RSS=1
RP0	AX	AX_
RP1	BC	BC_
RP2	AX_	AX
RP3	BC_	BC

(3) Lower left field (control register display area)

PC	000002
SP	0016FD
+PSW	0040

This area is used to display or change the contents of control registers.

The new value is written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

If the name of a register with '+' prefixed is double-clicked, the names and values of its flags are displayed, and '+' changes to '-'. This '+' can be also changed to '-' by selecting a register name with the arrow keys and pressing the Enter key.

This area is also used as a jump pointer of the jump function.

Caution If the width of the data value display/setting area is too narrow, display problems may occur. In this case, increase the width of the window.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Add Watch	Registers a selected character string to the Watch window. Opens the Add Watch dialog box.
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers (default).

Function buttons

Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To change a register value

To change the value of a register, move the cursor to the control register display area or general-purpose register display area in the window, and directly write a value from the keyboard.

Press the return key to set the new value. To cancel the change, press the ESC key.


SFR window

This window is used to display and change the contents of SFR and the I/O ports that have been registered in the Add I/O Port dialog box.

Note, however, that the values of read-only SFR and I/O ports cannot be changed. In addition, the SFR and I/O ports that cause the device to operate when they are read are read-protected and therefore cannot be read.

To read these registers, select a register, and select and execute [Compulsion Read] from the right-click menu.

Figure 6-42 SFR Window



Name	Attribute	Value
P0	R/W 1, 8 FFF00	00
P1	R 1, 8 FFF01	00
P2	R/W 1, 8 FFF02	00
P3	R/W 1, 8 FFF03	00
P4	R/W 1, 8 FFF04	00
P5	R/W 1, 8 FFF05	00
P6	R/W 1, 8 FFF06	00
P7	R/W 1, 8 FFF07	00
P12	R/W 1, 8 FFF0C	00
P13	R/W 1, 8 FFF0D	00
TM0	R 16 FFF10	0000
CR00	R/W 16 FFF12	0000
CR01	R/W 16 FFF14	0000
CRC0	R/W 1, 8 FFF16	00
TMC0	R/W 1, 8 FFF18	00
OVF0	R/W 1 FFF18.0	0
TOC0	R/W 1, 8 FFF1A	00

This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To change a SFR value
 - To select a SFR or I/O port to be displayed
 - To change the display sequence
 - To change the display radix
 - To add, change the contents of, and delete a user-defined I/O port
 - To change the display start position

Opening

This window box can be opened as follows:


- Click the **SFR** button.
- Select [Browse] -> [SER] from the menu bar (or press Alt,+B, and F in that order).

Explanation of each area

The SFR window consists of the following areas:

- (1) Name (SFR name display area)
- (2) Attribute (attribute display area)
- (3) Value (SFR contents display area)

(1) Name (SFR name display area)



This area displays the names of SFR and I/O ports.

If the value of an I/O port address is not defined, the I/O port name displayed in light color.

(2) Attribute (attribute display area)

Attribute		
R/W	1,8	FFF00
R	1,8	FFF01
R/W	1,8	FFF02
R/W	1,8	FFF03
R/W	1,8	FFF04
R/W	1,8	FFF05
R/W	1,8	FFF06
R/W	1,8	FFF07
R/W	1,8	FFF0C
R/W	1,8	FFF0D
R	16	FFF10
R/W	16	FFF12
R/W	16	FFF14
R/W	1,8	FFF16
R/W	1,8	FFF18
R/W	1	FFF18.0
R/W	1,8	FFF1A
R/W	1,8	FFF1C

This area displays the read/write attributes, access types, and absolute addresses of the SFR and I/O ports. when the bit SFR is displayed, bit-offset value is also displayed.

It can be specified whether this area is displayed or not, by selecting [View] -> [Attribute] from the

menu bar. As an attribute, the following contents are displayed.


Read/Write Attribute

R	Read only
W	Write only
R/W	Read/write
*	<p>Register that is read via an emulation register to prevent the device from operating when this register is read.</p> <p>To read this attribute directly from a SFR, execute [View] -> [Compulsion Read] from the menu bar.</p> <p>Even a write-only SFR can also be read via an emulation register.</p> <p>However, some devices do not support this function.</p>

Access Type

1	Can be accessed in bit units.
8	Can be accessed in byte units.
16	Can be accessed in word units.
32	Can be accessed in double word units.

(3) **Value** (SFR contents display area)



This area is used to display and change the contents of a SFR and I/O port.

The contents are displayed differently as follows, depending on the attribute:

Black Display	Read only or read/write
--	Write only
**	Value changes if read

The new value is written into the target when the Enter key is pressed. The previous value can be canceled by the ESC key.

The value of read-protected SFR and I/O ports can be read by selecting right-click menu -> [Compulsion Read].

Caution If the width of this area is too narrow, display problems may occur. In this case, increase the width of the window.

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal procedure.

Move...	Moves the display position. Opens the Address Move dialog box.
Add Watch	Registers a selected character string to the Watch window. Opens the Add Watch dialog box.
Add I/O Port ...	Adds user-defined I/O ports. Opens the Add I/O Port dialog box.
Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers (default).
Sort By Name	Displays in alphabetical order.
Sort By Address	Displays in address order (default).
Unsort	Does not sort.
Attribute	Displays or does not display an attribute area (Attribute). Checked: Displayed (default) Not checked: Not displayed
Pick Up	Displays only the registers selected in SFR Select dialog box. Checked: Displays only the selected register. Not checked: Displays all the registers (default).
Select...	Opens the SFR Select dialog box.
Compulsion Read	Forcibly reads the SFR that are disabled from being read because their values will be changed, or the data of the I/O ports and I/O protect area added in Add I/O Port dialog box.

Function buttons

Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To change a SFR value

To change the contents of a SFR or I/O port, move the cursor to the Value area on the window, and write a value directly from the keyboard.

Press the return key to set the new value. To cancel the change, press the ESC key.

Note that the values of read-only SFR and I/O ports cannot be changed.

To select a SFR or I/O port to be displayed

Use the SFR Select dialog box, which can be opened by selecting right-click menu -> [Select...] in the SFR window.

To change the display sequence

The display sequence can be changed by selecting right-click menu -> [Sort By Name/Sort By Address/Unsort].

To change the display radix

Select the line whose radix is to be changed, and select right-click menu -> [Bin/Oct/Dec/Hex].

To add, change the contents of, and delete a user-defined I/O port

To manipulate an I/O port, use the Add I/O Port dialog box, which can be opened by selecting right-click menu -> [Add I/O Port...] in the SFR window.


To change the display start position

Use the Address Move dialog box, which can be opened by selecting right-click menu -> [Move...] in the SFR window.

SFR Select dialog box

This dialog box is used to select SFR and I/O ports that are not displayed the SFR window.
It is also used to specify the sequence in which registers and ports are displayed.

Figure 6-43 SFR Select Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:


When SFR window is the current window

- Select [View] -> [Select...] from the menu bar
(or press Alt+V, and E in that order).

Explanation of each area

The SFR Select dialog box consists of the following areas and buttons:

- (1) Display, Pick Up, No Display (display SFR selection area)
- (2) Arrange (display sequence specification button)
- (3) Sort by (No Display list display sequence change button)

(1) Display, Pick Up, No Display (display SFR selection area)

This area is used to select registers and I/O ports that are displayed or not displayed on the SFR window.

Display	Registers and I/O ports are displayed in the SFR window
No Display	Registers and I/O ports are not displayed in the SFR window

To display or not display a register or I/O port in the SFR window, select the name of the register or I/O port from these lists, and click the <<<Show> or <Hide>>> button. To display all the peripheral I/O registers, click the <<<Show All> button; to not display any of the registers, click the <Hide All>>> button.

<< Show	Moves the register or I/O port selected from the No Display list to Display .
Hide >>	Moves the register or I/O port selected from the Display list to No Display .
<< Show All	Moves all the registers and I/O ports to Display .
Hide All >>	Moves all the registers and I/O ports to No Display .

When selecting a SFR from the list, two or more registers can be selected by clicking any of the above buttons with the Ctrl or Shift key held down.


(2) Arrange (display sequence specification button)

This button sets the sequence in which the registers and I/O ports are displayed in the [Display](#) list. A SFR or I/O port selected in the [Display](#) list can be moved to the top of the list by pressing the <Top> button, or to the bottom of the list by pressing the <Bottom> button. The <Up> button moves the

register or port one line up. The <Down> button moves the register or port one line down.

Top	Moves the selected SFR or I/O port to the top of the list.
Up	Moves the selected SFR or I/O port one line up.
Down	Moves the selected SFR or I/O port one line down.
Bottom	Moves the selected SFR or I/O port to the bottom of the list.

(3) Sort by (No Display list display sequence change button)



This button selects the sequence in which SFR and I/O ports are displayed in the [No Display](#) list. Pressing the <Name> button sorts the registers and ports into alphabetical order. The <Address> button sorts them into address order.

Name	Displays in alphabetical order.
Address	Displays in address order.


Function buttons

OK	Reflects the selection in this dialog box in SFR window and closes this dialog box.
Cancel	Cancels the changes and closes this dialog box.
Restore	Restores the original status.
Help	Opens the Help window.

Add I/O Port dialog box

This dialog box is used to register an I/O port to be added to the SFR window.

Figure 6-44 Add I/O Port Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [Option] ->[Add I/O Port...] from the menu bar (or press Alt+O, and P in that order).

Explanation of each area

The Add I/O Port dialog box consists of the following areas:

- (1) I/O Port List: (I/O port selection area)
- (2) Name: (I/O port name specification area)
- (3) Address: (I/O port address specification area)
- (4) Access (access size specification area)
- (5) Read / Write (access attribute specification area)

(1) I/O Port List: (I/O port selection area)

I/O Port List:



This area lists the I/O ports currently registered.

If a new I/O port is registered, it is added to this list. In addition, an I/O port already registered can be selected and changed or deleted.

(2) Name: (I/O port name specification area)Name:

This area is used to specify an I/O port name to be added. An I/O port name can be up to 15 characters long.

(3) Address: (I/O port address specification area)Address:

This area is used to specify the address of the I/O port to be added.

Only an address in one of these areas can be specified: Target area, SFR area

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

(4) Access (access size specification area)


This area is used to specify the access size of the I/O port to be added.

Only SFR or external SFR can specify Word access.

Byte	8 bits (default)
Word	16 bits
Double Word	32 bits

(5) Read / Write (access attribute specification area)

Read / Write

☐ Read Only ☐ Write Only

☐ Read Protect

This area is used to specify the access attribute of the I/O port to be added.

In the default condition, all the attributes are not checked (i.e., the I/O port can be both read and written).

Read Only	Read only
Write Only	Write only
Read Protect	Read-protected

Function buttons

OK	Reflects the result of addition in SFR window and closes this dialog box.
Cancel	Cancels changes and closes this dialog box.
Restore	Restores the original status.
Help	Opens the Help window.
Add	Adds an I/O port of the specified address.
Change	Changes the setting of the I/O port selected in I/O Port List .
Delete	Deletes the I/O port selected in I/O Port List .

Trace window

The Trace window displays the trace results.


This window is only in the active status and is updated when a break occurs or step execution is performed. The source file can also be displayed with the trace results (refer to "Normal display and mixed display (p.201)").

The tracer is enabled by selecting [Option] -> [Tracer On] from the menu bar.

To manipulate the tracer during program execution, select [Run] -> [Tracer Start/Stop] from the menu bar.

For details of the trace function, refer to "Trace function (p.26)".

Figure 6-45 Trace Window



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To make the trace function usable
 - To set a section trace event and quality trace event
 - To change the display start position
 - To search trace data
 - To clear trace data
 - To turn on/off the tracer during program execution
 - For pick up display
 - To display the source text (mixed display mode)
 - To select the display item and change the display radix
 -

Opening

This window can be opened as follows:

- Click the **TrW** button.
- Select **[Browse] -> [Trace]** from the menu bar (or press Alt+B, and T in that order).

Explanation of each area

The Trace window consists of the following areas:

- (1) Point mark display area
- (2) Trace mode display area
- (3) Trace result display area

(1) Point mark display area

This area displays Event setting status.

If an execution event or access event is set at the corresponding trace address, the mark corresponding to the type of the event is displayed.

The mark displayed is not that during trace but an event mark that is set when the trace result is displayed.

(2) Trace mode display area

This area displays the types of trace modes.

"T" is also displayed in the frame where the display trigger occurred.

If a qualify trace condition is satisfied while a section trace condition is satisfied, 'Q' is displayed.

A	Fully or section traced frame
Q	Qualify traced frame
S	Step executed frame
T	Delay trigger frame

(3) Trace result display area

	(a)	(b)		(c)		(d)		
	Frame	Address	Data	Status	Address	Data	Status	DisAsm
A	82751	00170	E4	OP	FFE68	0064	WP	
A	82752							
A	82753			IF				
A	82754	00171	07	IF				
A	82755			IF				
A	82756	00155	06	BRM1				MOVW AX, [UUP+8H]

This area displays the trace results.

This area has two display modes: Normal display and mixed display. In addition, Jump Function and Trace Result with Linking Window can be used in this area.

Whether each of the following sub-areas is displayed or not can be selected in the Trace Data Select dialog box.

(a) Frame (trace frame number display)

This area displays trace frame numbers.

(b) Address Data Status (fetch access display)

This area displays the result of fetching the program.

The display contents of **Address** and **Data** differ depending on the **Status** display.

Status

The following types of statuses are available:

Program fetch display

BRM1	Fetching of first byte of first instruction after branch A line is displayed in blue for emphasis if the fetched address is the top of a symbol.
M1	Fetching of first byte of instruction A line is displayed in blue for emphasis if the fetched address is the top of a symbol.
OP	Opcode fetch of 2nd and subsequent bytes
IF	Invalid fetch or status unknown

No display

Other	Nothing is displayed. (Blank line is displayed.)
--------------	--

Address Data

Displays addresses and data. The display contents differ as follows, depending on the **Status** display.

Program fetch display

Address	Displays the fetch address
Data	Displays the fetch data

(c) Address Data Status (data access display)

This area displays the result of accessing data.

Status

VECT	Vector read
RWP	Memory read/write via user program
RP	Memory read via user program

WP	Memory write via user program
RWM	Memory read/write via macro service
RM	Memory read via macro service
WM	Memory write via macro service

(d) DisAsm (mnemonic display)

This area displays the result of disassembly (only when the status of fetch access display is BRM1 or M1).

Normal display and mixed display

In the normal display mode, only the trace result is displayed.

In the mixed display mode, the source file is also displayed along with the trace result.

If a program code corresponds on the program fetch address to be displayed, a source file line is displayed before the line indicating the result of tracing that program fetch address.

Frame	Time	Address	Data	Status	Address	Data	Status	ExtProbe	DisAsm
32757	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32758	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32759	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						
32760	3	000005A2	85058505	BRM1				00	br _main+0x21a
			while(1);						

The source file line is displayed, emphasized in green.

The display mode can be alternately changed by selecting [View] -> [Mix] from the menu bar.

Caution The mixed display mode is valid only when the load module has been downloaded and symbol information is read, and when a fetch address, fetch data, fetch status, or result of disassembly is displayed.

Jump function

This function allows you to jump to the Source window, Assemble window or Memory window, using the cursor position as a jump pointer (refer to "Jump Function (p.33)").

To jump from the Trace window, the jump pointer changes as follows, depending on the area in which the cursor is positioned:

Table 6-20 Cursor Position and Jump Pointer

Cursor Position	Jump Pointer
Access Address Display Area	Access address (If the jump destination is the Source window or Assemble window, the fetch address is always used as the jump pointer.)
Access Data Display Area	
Access Status Display Area	
Other	Fetch address

Cause of stopping tracer

The tracer may be stopped by the following types of causes:

Table 6-21 Status When Tracer Is Stopped

Cause	Meaning
Event Break	Break by event
Software Break	Break by software event
Non Map Break	A non-mapped break has been accessed.
Write Protect	An attempt has been made to write to a write-protected area.
SFR Illegal	An illegal access is made to a SFR.
Relocation Break	A relocation instruction different from the initial setting has been executed.
Step Break	Step execution break
Compulsory Break	Manual break
Trace Stop	Trace stop

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button.

In this way, the same function can be used more easily than with the normal procedure.

Move...	Moves the display position. Opens the Trace Move dialog box.
Trace Clear	Clears the trace data.
Select	Selects the contents to be displayed. Opens the Trace Data Select dialog box.
Pick Up	Performs the setting for pickup display.
Off	Does not pick up and display (default).
Search	Picks up and displays a frame that satisfies the search condition.
BRM1	Picks up and displays the first M1 fetch frame after a program branch.
Mix	Specifies whether the results of assembly are displayed in mixed display mode, or not displayed. Checked: Mixed display Not checked: No display (default)
Window Synchronize	Links the Trace window with the following windows:
Source Text	Links the Source window.
Assemble	Links the Assemble window.
Memory	Links the Memory window.

Source Text	Displays the corresponding source text and source line, using the data value at the cursor position as the jump destination address. If no line information exists at the jump destination address, however, you cannot jump. Opens the Source window. If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Disassembles and displays starting from the jump destination address specified by the data value at the cursor position. Opens the Assemble window. If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents starting from the jump destination address specified by the data value at the cursor position. Opens the Memory window. If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

Search...	Opens the Trace Search dialog box and searches or picks up trace results. The searched result will be highlighted in the Trace window. This button cannot be selected when a snap frame or BRM1 frame is picked up and displayed. This is the same operation as selecting [View] -> [Search...] from the menu bar.
<<	Searches forward (upward on screen) for a trace result that satisfies the search condition set in the Trace Search dialog box. This button cannot be selected while pickup display is being performed.
>>	Searches backward (downward on screen) for a trace result that satisfies the search condition set in the Trace Search dialog box. This button cannot be selected while pickup display is being performed.
Refresh	Updates the contents of the window with the latest data.
Close	Closes this window.

Related operations

To make the trace function usable

Select and check [Option] -> [Tracer On] from the menu bar. To invalidate the tracer, select [Tracer On] again and remove the check mark.

To set a section trace event and quality trace event

Use the Trace dialog box which can be opened by clicking the **Trc** button.

To change the display start position

Use the Trace Move dialog box that can be opened by selecting right-click menu -> [Move...] in the Trace window.

To search trace data

Select right-click menu -> [Pick Up] -> [Off] in the Trace window and click the <Search...> button. The Trace Search dialog box will be opened, enabling trace results to be searched.

To clear trace data

Select the right-click menu -> [Trace Clear] in the Trace window.

This will clear the trace buffer (display contents of the Trace window).

To turn on/off the tracer during program execution

To temporarily stop coverage, select [Run] -> [Tracer Stop] from the menu bar during program execution. To resume tracer operation, select [Tracer Start].

This operation can be performed only while the program is being executed.

It cannot be performed if the tracer function is disabled (when [Option] -> [Tracer On] is not checked).

For pick up display

Only specific trace data can be picked up and displayed in the Trace window.

A snap frame, M1 fetch frame, and picking up a frame that satisfies a given search condition can be selected as pickup conditions.

To pick up and display M1 fetch frame

Select right-click menu-> [BRM1] in the Trace window. A snap frame or M1 fetch frame will be picked up and displayed in the Trace window.

To pick up and display only a frame that satisfies the search condition

Select right-click menu -> [Search] in the Trace window and click the <Search> button. The Trace Search dialog box will be opened, enabling data to be picked up to be set.

To display the source text (mixed display mode)

Select the right-click menu -> [Mix] in the Trace window.

To select the display item and change the display radix

Use the Trace Data Select dialog box, which can be opened by selecting the right-click menu -> [Select...] in the Trace window.

The display radix can be changed in the fetch data display area and access data display area.

Trace Search dialog box

This dialog box is used to search or pick up trace data in Trace window.


This dialog box is used to search trace data if it is opened by selecting [View] -> [Pick Up] -> [Off] from the menu bar. It is used to pick up and display trace data if it is opened by selecting [View] -> [Pick Up] -> [Search] from the menu bar.

By setting each item and then clicking the <Find Next> button, searching can be started.

By clicking the <Set Find> button, the direction buttons ("<<" and ">>") in the Trace window can be used for the search.

Caution The Trace Search dialog box cannot be called if picking up the first M1 fetch frame (BRM1) after program branch is specified using the menu bar or in Trace Data Select dialog box.

Figure 6-46 Trace Search Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When Trace window is the current window

- Click the <Search> button.
(or press Ctrl+G).

- Select [V]iew -> [S]earch...
(or press Alt+V, and S in that order).

Explanation of each area

The Trace Search dialog box consists of the following areas:

- (1) Event Status (status selection area)
- (2) Access Size (access size selection area)
- (3) Address, Mask (address setting area)
- (4) Data, Mask (data setting area)
- (5) Scan Whole Region (search condition specification area)
- (6) Direction (search direction specification area)
- (7) Frame (search range specification area)

(1) Event Status (status selection area)

Event Status: 

This area is used to set and select a status condition.

A status condition can also be specified in abbreviated form. Uppercase and lowercase characters are not distinguished.

If a status condition is omitted, all frames (All status) are searched.

Table 6-22 Types of Status Conditions

Status	Abbreviation	Meaning
All status	ALL	All frames (default)
BRM1 Fetch	BRM1	First M1 fetch after program branch
M1 Fetch	M1	M1 fetch (including BRM1)
Opcode Fetch	OP	Opcode fetch (including M1 and BRM1)
R/W by Macro	RWM	Memory read/write via macro service (including RM and WM)
Read by Macro	RM	Memory read via macro service
Write by Macro	WM	Memory write via macro service
R/W by Program	RWP	Memory read/write via program (including RM and WM)
Read by Program	RP	Memory read via program
Write by Program	WP	Memory write via program
Vector Read	VECT	Vector read via interrupt

(2) Access Size (access size selection area)

Access Size:

This area is used to set and select an access size condition.

By specifying an access size condition, the access width of a data condition to be detected by an access event is determined.

An access size condition can also be specified in abbreviated form. Uppercase and lowercase characters are not distinguished.

Table 6-23 List of Access Size Conditions (Trace)

Size	Abbreviation	Meaning
Byte	B	Searches for a data condition with 8-bit width (only during 8-bit access).
Word	W	Searches for a data condition with 16-bit width (only during 16-bit access).
No Condition	NC	Does not search based on access size (nothing can be input to the Data area).
Bit	1	<p>Searches for a data condition with 1-bit width (only during 8-bit access).</p> <p>In this case, a search is made for a data condition with 1-bit width. Because of the operation of the emulator, access to a bit is not directly detected; the debugger searches a dummy bit access by internally setting address conditions and data conditions as follows:</p> <p>Input example: Address: FE20.1 Data: 1</p> <p>Setting of trace search Address: FE20 Data: 00000010B Mask: 11111101B</p> <p>If another bit of the same address is accessed or if all the 8 bits of the same address are accessed, therefore, an event is detected in accordance with the specified status if the address and bit match the specified value of [address.bit].</p>

Caution If an access event is specified as a status condition, the alternative of Bit is not displayed. If Bit or 1 is specified, an error occurs.

If no access size condition is specified, a judgment is automatically made from the address condition and data condition, and the following is set:

- [Bit](#) if the address condition is set in bit units
- [Byte](#) if the data condition is set in 8-bit units
- [Word](#) if the data condition is set in 16-bit units
- [No Condition](#) if no data condition is specified

(3) Address, Mask (address setting area)

Address: - Mask:

Address, which sets an address value and **Mask**, which sets the mask value of an address value, are set as address conditions.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Both the address and mask may be omitted.

The following can be set:

Table 6-24 Settable Range of Address Condition

Settable range	Condition
0 =< address value =< 0xFFFFFFFF 0 =< mask value =< 0xFFFFFFFF	Execution type events, fetch type events
0 =< address value =< 0xFFFFFFFFFF 0 =< mask value =< 0xFFFFFFFFFF	Data access type events

Address

Set an address condition.

The following can be set:

Set Point	Set a value to only the lower address, or set the same value to the lower address and the higher address. Mask can be set.
Set Range	Set a value to the lower address and the higher address. Mask cannot be set.
Setting of Bit	Set a value to only the lower address, or set the same value to the lower address and the higher address. Specify a value in the form of address.bit . Mask cannot be set. The value of bit, which indicates the bit position, must be 0 =< bit =< 7.

Mask

Set a mask value for an address value (only when a point is specified).

The address value of a bit whose mask value is 1 may be 0 or 1.

Example 1:

Address	0x4000 to 0x4000
Mask	0xFF

With this setting, addresses 0x4000 to 0x40FF satisfy the condition.

Example 2:

Address	0x4000 to 0x4000
Mask	0x101

With this setting, addresses 0x4000, 0x4001, 0x4100, and 0x4101 satisfy the condition.

(4) [Data](#), [Mask](#) (data setting area)

[Data](#): [Mask](#):

[Data](#), which sets an data value, and [Mask](#), which sets the mask value of an data value, are set as data conditions.

The default radix for inputting a numeric value is hexadecimal.

Both the data and mask may be omitted.

The settable range differs as follows depending on the access size condition specified in the [Access Size](#) area.

Table 6-25 Settable Range of Data Condition

Access Size	Settable range
Byte	0 =< data value =< 0xFF 0 =< mask value =< 0xFF
Word	0 =< data value =< 0xFFFF 0 =< mask value =< 0xFFFF
Bit	Data value = 0 or 1 Mask value = Cannot be specified.

[Data](#)

Set a data value. Specify a value within the settable range.

A symbol or expression can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)").

[Mask](#)

Set a mask value for the data value.

When a mask is set, the data value for the bit whose mask value is 1 may be 0 or 1.

The data value for a bit whose mask value is 1 may be 0 or 1.

Example 1:

Data	0x4000
Mask	0xFF

With this setting, addresses 0x4000 to 0x40FF satisfy the condition.

Example 2:

Data	0x4000
Mask	0x101

With this setting, addresses 0x4000, 0x4001, 0x4100, and 0x4101 satisfy the condition.

(5) Scan Whole Region (search condition specification area)

☐ Scan Whole Region

This area is used to specify whether the specified range is fully searched or not.

Checked	Searches the entire range.
Not checked	Searches the remaining part of the range (default)

(6) Direction (search direction specification area)

Direction

☐ Up ☒ Down

This area is used to specify the direction of the search.

Up	Forward search. Searches data forward (upward on screen) from the current position of the cursor.
Down	Backward search (default). Searches data backward (downward on screen) from the current position of the cursor.

(7) Frame (search range specification area)

Frame: ---

This area is used to specify a frame number to be searched.

For how to specify a frame number, refer to "Table 6-12 Frame Number Specification Format (p.109)".

The default radix for inputting a numeric value is decimal.

Function buttons


Find Next	Searches the specified data in accordance with a given condition. If the specified frame is found as a result of a search, it is highlighted. To continue searching, click this button again.
Set Find	Sets the specified condition as the search condition and closes this dialog box.

Pick Up (Stop (during search))	Picks up according to the specified condition of data search. If a frame that satisfies the condition is found as a result of a search, it is picked up. To pick up a frame that satisfies a different condition, press this button again.
Cancel	Closes this dialog box.
Help	Opens the Help window.

Trace Data Select dialog box

This dialog box is used to select items to be displayed in the Trace window.

Figure 6-47 Trace Data Select Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

When Trace window is the current window

- Select [View] -> [Select...] from the menu bar (or press Alt+ V, and E in that order).

Explanation of each area

The Trace Data Select dialog box consists of the following areas:

- (1) Item (trace display item selection area)
- (2) Radix (trace display radix selection area)
- (3) Pick Up (pickup selection area)

(1) Item (trace display item selection area)

Item

- ☒ Frame
- ☒ Instruction Fetch Address
- ☒ Instruction Fetch Data
- ☒ Instruction Fetch Status
- ☒ Memory Access Address
- ☒ Memory Access Data
- ☒ Memory Access Status
- ☒ DisAssemble

This area is used to select items to be displayed in the Trace window. Displaying the following items may or may not be selected. The field checked is displayed.

Frame	Frame number display field
Instruction Fetch Address	Fetch address display field
Instruction Fetch Data	Fetch data display field
Instruction Fetch Status	Fetch status display field
Memory Access Address	Access address display field
Memory Access Data	Access data display field
Memory Access Status	Access status display field
DisAssemble	Disassemble display field

(2) Radix (trace display radix selection area)

Radix

Instruction Fetch Data:

Memory Access Data:

This area is used to select the radix in which data is to be displayed. Displaying the following items may or may not be selected.

Display field

Instruction Fetch Data	Fetch data display field
Memory Access Data	Access data display field

Display radix

HEX	Hexadecimal display
DEC	Displays decimal numbers.
OCT	Displays octal numbers.
BIN	Displays binary numbers.

(3) Pick Up (pickup selection area)

Pick Up

☒ Pick Up Off

☐ Pick Up Search Frame

☐ Pick Up BRM1 Frame

This area is used to select a pick up condition.

Pick Up Off	No pick up display
Pick Up Search Frame	Picks up and displays a frame that satisfies the search condition.
Pick Up BRM1 Frame	Picks up and displays the first M1 fetch frame after a program branch

Function buttons

OK	Reflects the results of selection in this dialog box in Trace window.
Cancel	Closes this dialog box.
Restore	Restores the original status.
Help	Opens the Help window.

Event Manager

This window is used to display, enable or disable, and delete various event conditions.

It is also used to register the various event conditions and manage the event conditions for setting them.

Up to 256 conditions can be registered as event conditions or various event conditions. However, the number of event conditions that can be used (enabled) at the same time is limited as follows:


Table 6-26 Maximum number of Events Usable for Event Conditions

IE Using	Event		Event link	Break	Trace	Snapshot	Timer	DMM
	Execution	Access						
IE-78K4-NS	4 ^{Note1}	3 ^{Note1}	1	7 ^{Note2}	1	-	-	-

Notes1. One event reserved in flash self mode

2. Two events reserved in flash self mode

Figure 6-48 Event Manager



This section explains the following items:

- Opening
- Explanation of each area
- Functions often used (right-click menu)
- Function buttons
- Related operations
 - To save/restore event information
 - To enable/disable an event
 - To change the display sequence of event icons
 - To display details of event condition
 - To delete an event

- To manage a software break event
- To create an event condition
- To create an event link condition
- To set an event condition and event link condition as various event condition

Opening

This window can be opened as follows:

- Click the **Mgr** button.
- Select [Event] -> [Event Manager] from the menu bar (or press Alt+N, and M in that order).

In the Source window

Move the cursor to the source line in the source text display area where an event is set, or to the disassemble line in the mixed display mode.

- Select [View] -> [Event?] from the menu bar (or press Alt+V, and E in that order).

In the Assemble window

Move the cursor to the line in the mnemonic display/change area where an event is set.

- Select [View] -> [Event?] from the menu bar (or press Alt+V, and E in that order).

In the Event dialog box

- Click the <Manager> button (or press Alt+G).

In the Event dialog box

- Click the <Manager> button. (or press Alt+M).


Explanation of each area

The Event Manager consists of the following areas:

- (1) Event display area
- (2) Event details display area

(1) Event display area

[When list is displayed]



The event display area displays the icons (event icons) of the registered event, event link, break event, and trace event conditions.

An event icon consists of a mark indicating the type of event, and an event name.

By selecting the right click menu -> [Detail], the details can be displayed (refer to "Event details display area (p.219)").

The meaning of each mark is as follows:

Table 6-27 Marks of Event Icon

Mark	Meaning
E.	Event condition
L.	Event link condition
B.	Break event condition
T.	Trace event condition

The color of the character on the mark indicates the set status of the event.

Table 6-28 Color of Character on Mark and its Meaning

Character Color	Mark	Meaning
Red	E. L.	Indicates that the various event condition using this event condition or event link condition is enabled.
	B. T.	Indicates that this various event condition is enabled. This various event occurs when its condition is satisfied.
Black	E. L.	Indicates that this various event condition using this event condition or event link condition is disabled.
	B. T.	Indicates that this various event condition is disabled. This various event does not occur even when its condition is satisfied.
Yellow	E. L.	Indicates that the symbol specified for this event is held pending because it cannot be recognized by the program currently loaded.
	B. T.	Indicates that this various event is held pending. The various event does not occur even when its condition is satisfied.

This area also has the following four functions:

Jump function

If the selected icon is that of an event condition, you can jump to the Source window, Assemble window, or Memory window, using an address condition as the jump pointer. You can jump easily by using the right click menu.

The jump pointer will be as follows, depending on the set address condition.

Table 6-29 Address Condition and Jump Pointer

Setting of Address Condition	Jump Pointer
Setting as a point	Specified address
Setting as a range	Lower address (Point address before the mask if a mask is specified)
Setting as a bit	Address at the bit position

The jump destination window will be displayed from the jump pointer.

Open function

Opens the event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition.

Operation

- Double-click the icon, or click the <Open> button with selecting the icon.

Enable/disable status switch function

Enables/disables events corresponding to the selected icon.

The break and trace (but not the event and event link conditions) can be manipulated via their icons.

Operation

- 1 Click on the mark of the icon using the left mouse button.
- 2 Click the <Enable> or <Disable> button.

If the event was enabled, it is disabled (black). If the event was disabled, it is enabled (red). The <Enable> button is displayed when an icon that has been disabled is selected. The <Disable> button is displayed when an icon that has been enabled is selected.

Deletion function

The registered event and set contents of the selected icon can be deleted.

Operation

- 1 Select an icon. Two or more icons can be selected by using Shift and Ctrl keys. To select all the icons, select [View] -> [Select All] from the menu bar.
- 2 Click the <Delete> button or press the DEL key.

Caution An event condition or event link condition can be deleted only when it is not being used for another event condition. If it is being used for another event, delete the event that is using the event condition or event link condition, and then delete the event

condition or event link condition.

(2) Event details display area

[In detailed display mode]

E	Evt00001	[S]EX [A]main.c#82(0x44e)
E	Evt00002	[S]EX [A]main.c#94(0x4be)
E	time_o01	[S]W [Z]W [A]time_over(0x100410)
B	Brk00001	[B]Evt00001
B	Brk00002	[B]Evt00002
B	time_o02	[B]time_o01

This area displays the detailed information corresponding to each event icon.

This area is displayed only in the detailed display mode.

Contents are displayed by using the following key information as a separator.

Table 6-30 Separator for Displaying Event Details

Key Information	Contents
Event condition	
[S]	Status condition
[Z]	Access size condition
[A]	Address condition Symbol or expression: (actual address)
[D]	Data condition Symbol or expression: (actual address)
[M]	Mask condition
Event link condition	
[P1] - [P4]	Event link condition on "n"th line
[D]	Disable condition
Break condition	
[B]	Break condition
Trace condition	
[M]	Trace mode
[S]	Trace start condition
[E]	Trace end condition
[Q]	Qualify trace condition

Functions often used (right-click menu)

In this window, functions that are often used can be selected from the menu that is displayed by clicking the right mouse button. In this way, the same function can be used more easily than with the normal

procedure.

Sort By Name	Displays icons in the order of event names.
Sort By Kind	Displays icons in the order of event types.
Unsort	Does not sort icons (default).
Detail	Displays the details.
Overview	Displays a list (default).
Source Text	Displays the corresponding source text and source line, using the position of the selected event as the jump destination address. If no line information exists at the jump destination address, however, you cannot jump. Opens the Source window. If an active Source window is open, that window is displayed in the forefront (so that it can be manipulated).
Assemble	Displays the Assemble window from the position of the selected event, which is used as the jump destination address. Opens the Assemble window. If an active Assemble window is open, that window is displayed in the forefront (so that it can be manipulated).
Memory	Displays the memory contents from the position of the selected event, which is used as the jump destination address. Opens the Memory window. If an active Memory window is open, that window is displayed in the forefront (so that it can be manipulated).

Function buttons

New...	Opens the dialog box to create new event condition. By clicking each button, the corresponding event setting dialog box can be opened (with the new event name set). After the event setting dialog box has been opened, this dialog box is closed.
Open	Opens the event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition. This button is invalid if no event condition is selected or if two or more event conditions are selected. The Enter key performs the same operation.
Enable/ Disable	Enables or disables the selected various event condition (except event conditions and event link conditions). This button is invalid if an enabled/disabled event condition is not selected.
Delete	Deletes the selected event condition. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as a various event condition. This button is invalid if no event condition is selected.
Delete All	Deletes all event conditions.
Info...	Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.

Sort by Name	Sorts events into name order.
Sort by Kind	Sorts events into type order.
Unsort	Displays events in the order in which they have been registered without sorting the events.
Detail	Sets the detailed display mode.
Overview	Sets the list display mode.
Cancel	Closes this dialog box (same as ESC key).
Close	Closes this window.

Related operations

To save/restore event information

Use this window as the current window, and open the Environment File Save dialog box by selecting [File] -> [Environment] -> [Save As...] from the menu bar.

To restore the set status of an event, open the Environment File Load dialog box by clicking the **Open** button. By loading an event setting file (*.evn), the previously set event information can be restored.

To enable/disable an event

An event can be enabled or disabled by clicking the mark of the event to be changed. By clicking Enable (**red**), the event is disabled (black); by clicking Disable (black), the event is enabled (**red**).

This change can be also performed on the Event Manager or in each event setting dialog box.

To change the display sequence of event icons

Select the right-click menu -> [Sort B Name/Sort By Kind/Unsort] on the Event Manager.

To display details of event condition

Select the right-click menu -> [Detail] on the Event Manager.

By selecting [Overview], the list can be displayed again.

To delete an event

Select the icon of the event to be deleted, and click the <Delete> button.

Caution An event condition or event link condition cannot be deleted if it is being used for an event. Delete the event first, and then delete the event condition or event link condition.

To manage a software break event

Use the Software Break Manager, which is opened by selecting [Event] -> [Software Break Manager] from the menu bar.

To create an event condition

Create an event condition in the Event dialog box, which can be opened by clicking the **Evn** button. In

addition, an event condition that is created when a hardware break is set in the source can also be used (refer to "Breakpoint setting/deletion function (p.116)").

To create an event link condition

Create an event link condition in the Event Link dialog box, which can be opened by selecting [Event] - > [Event Link] from the menu bar.

To set an event condition and event link condition as various event condition

Set an event condition or event link condition as a various event condition in the Break dialog box, Trace dialog box, or Timer dialog box, which can be opened by clicking the corresponding button, such as <Break...> and <Trace...> in the Event dialog box or Event Link dialog box.

By dragging and dropping the event condition to be set from the Event Manager area at the lower part of the screen to the condition setting area on each event setting dialog box, the event condition can be easily set.

Each event setting dialog box can also be opened by selecting from the [Event] menu.


Software Break Manager

This window is used to display, enable or disable, and delete software breaks.

Up to 100 software break events can be enabled at the same time.

Software breakpoints cannot be set in this window; they can be set in the Source window or Assemble window.

Figure 6-49 Software Break Manager



The section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening


This window can be opened as follows:

- Select [Event] -> [Software Break Manager] from the menu bar (or press Alt+N, and M in that order).

Explanation of each area

The Software Break Manager consists of the following areas:

- (1) Name (event name display area)
- (2) Brk (break mark display area)
- (3) File#Line / Symbol+Offset (breakpoint display area)
- (4) Address (address display area)

(1) Name (event name display area)

This area displays the names of the registered events and the check boxes that indicate whether each event is enabled or disabled.


An event name is displayed in the form of **Swb+[number]** in the default condition. It can be changed to an alphanumeric string of up to 256 characters.

To change an event name, select and click a name. Then directly edit the name. To set the editing, press the Enter key.


When an event is enabled, the check box is checked.

Furthermore, the name jumps to the Source window by double-clicking an event name if the event name corresponds to the source line, whereas the name jumps to the Assemble window if it does not correspond to the source line.

Reference By clicking Name (on the label), the character strings of the displayed items can be compared and sorted lexicographically (in alphabetical order). Whether the character strings are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

(2) Brk (break mark display area)

The '>' mark is displayed for a software break event that is set at the current PC position (so that the software break event that caused a break can be easily identified).

(3) File#Line / Symbol+Offset (breakpoint display area)


This area displays the location at which a software break event was set as follows:

If the event corresponds to the source line.	Program\$file name#line number
If the event dose not correspond to the source line.	Program\$file name#symbol+offset

Events are evaluated based on this when a symbol is re-downloaded.

Reference By clicking File#Line/Symbol+Offset (on the label), the character strings of the displayed items can be compared and sorted lexicographically (in alphabetical order). Whether the character strings are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

(4) **Address** (address display area)



This area displays the address at which a software break event is set.

Reference By clicking **Address** (on the label), the numeric values of the displayed items can be compared and sorted. Whether the values are compared or sorted in ascending or descending order can be alternately selected by clicking the mouse.

Function buttons

Enable	Enables the selected event.
Disable	Disables the selected event.
Delete	Deletes the selected event.
Delete ALL	Deletes all the set software break events.
Close	Closes this window.

Event dialog box

Registers and displays event conditions.

An event condition registered in this dialog box will be automatically registered to the Event Manager.

As an event condition, one event can be set for two or more event conditions (break, trace, and event link).

Up to 256 event conditions can be registered. However, the number of event conditions that can be simultaneously used is limited (refer to "Table 6-26 Maximum number of Events Usable for Event Conditions (p.215)").

Caution Event conditions used for break cannot be used for trace, including those that are used via event link. Similarly, the event conditions used for trace cannot be used for break, including those that are used via event link.

An event condition for which an address range is specified internally uses two event conditions. Therefore, the number of event conditions that can be used decreases by the number of event conditions for which an address range is specified.

Figure 6-50 Event Dialog Box

The Event Dialog Box contains the following elements:

- Title Bar:** Event
- Buttons:** OK, New, Set, Restore, Cancel, Help
- Fields:**
 - Event Name: Evt0001
 - Event Status: [Dropdown]
 - Access Size: [Dropdown]
 - Address: [Text] - [Text] Mask: [Text]
 - Data: [Text] Mask: [Text]
 - Pass Count: 1
- Buttons (Right Side):** Event Link..., Break..., Trace..., Manager
- Buttons (Bottom Right):** Shrink <<<, Open, Remove, Info...
- Event Manager:** [List Box]

This section explains the following items:

- Opening
- Explanation of each area

- Function buttons

Opening

This dialog box can be opened as follows:

In normal mode

If the Event dialog box is opened as follows, an event condition can be registered without its purpose being specified.

- Click the **Ev_n** button.
- Select [Event] -> [Event...] from the menu bar
(or press Alt+N, and E in that order).

In select mode

If the <OK> button is pressed when the Event dialog box has been opened as follows, an event condition can be registered in the setting dialog box from which this dialog box was opened.

- In each event setting dialog box
Click the <Add Event> button.
(or press Alt and E in that order).
In the select mode, the setting dialog box from which the Event dialog box was opened is displayed on the title bar.

Explanation of each area

The Event dialog box consists of the following areas:

- (1) Event Name (event name setting area)
- (2) Event Status (status selection area)
- (3) Access Size (access size selection area)
- (4) Address, Mask (address setting area)
- (5) Data, Mask (data setting area)
- (6) Pass Count (pass count setting area)
- (7) Event Manager (event manager area)

(1) Event Name (event name setting area)

Event Name: 

This area is used to set a event name.

Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event condition, select from the drop-down list.

In the select mode, the selected event condition can be set in the event condition setting area of the setting dialog box that called the Event dialog box.

The mark on the left of this area indicates the utilization status of events (refer to "Table 6-28 Color of

Character on Mark and its Meaning (p.217)"). The gray E. mark indicates that the event condition is being edited and has not been registered yet.

(2) **Event Status (status selection area)**

Event Status:

This area is used to select a status condition.

By specifying a status condition, the type of the execution event and an access event is determined (if an execution event is specified, nothing can be input to the [Access Size](#), [Address Mask](#), and [Data](#) areas).

The status conditions that can be specified are listed below. A status condition can also be specified in abbreviated form.

Uppercase and lowercase characters are not distinguished in the input status condition.

Table 6-31 List of Status Conditions

<Execution event>

Status	Abbreviation	Meaning
Execution	EX	Program execution ^{Note}

Note The address range can be specified, but the start address must be an even address and the end address must be an odd address.

<Access event>

Status	Abbreviation	Meaning
Opcode Fetch	OP	Opcode fetch (including prefetch) ^{Note}
R/W	RW	Memory read/write
Read	R	Memory read
Write	W	Memory write
R/W by Macro	RWM	Memory read/write via macro service
Read by Macro	RM	Memory read via macro service
Write by Macro	WM	Memory write via macro service
R/W by Program	RWP	Memory read/write via program
Read by Program	RP	Memory read via program
Write by Program	WP	Memory write via program
Vector Read	VECT	Vector read via interrupt
Access	AC	All access statuses
External Trigger	Trigger-1	External trigger (1 bit)

Note The address of a space other than a 1 MB space cannot be specified.

(3) Access Size (access size selection area)

Access Size:

This area is used to set and select an access size condition.

By specifying an access size condition, the access width of a data condition to be detected by an access event is determined.

The access size conditions that can be specified are listed below. An access size condition can also be specified in abbreviated form. Uppercase and lowercase characters are not distinguished in the input access size condition.

Table 6-32 List of Access Size Conditions (Event)

Size	Abbreviation	Meaning
Byte	B	Detects data condition with 8-bit width (only during 8-bit access).
Word	W	Detects data condition with 32-bit width (only during 32-bit access).
No Condition	NC	Does not detect access size (nothing can be input to the Data area).
Bit	1	<p>Detects data condition with 1-bit width (only during 8-bit access). In this case, a data condition is detected with 1-bit width. Because of the operation of the , access to a bit is not directly detected; the detects a dummy bit access by internally setting address conditions and data conditions as follows:</p> <p>Input example: Address: fe20 Data: 1</p> <p>Setting to) Address: fe20 Data: 00000010B Mask: 11111101B</p> <p>If another bit of the same address is accessed or if all the 8 bits of the same address are accessed, therefore, an event is detected in accordance with the specified status if the address and bit match the specified value of [address.bit].</p>

Because of the operation of the device, all the 8 bits are read or written when writing bits, but if Read or R/W is specified as the status condition, an event occurs for this read operation if the address and bit match the specified value of [address.bit].

If no access size is specified, judgment is automatically made from the address condition and data condition, and the following is set:

- Bit if the address condition is set in bit units
- Byte if the address condition is set in 8-bit units
- Word if the address condition is set in 32-bit units
- No Condition if no data condition is specified

(4) Address, Mask (address setting area)

Address:	<input type="text"/>	Mask:	<input type="text"/>
	- <input type="text"/>		

Address, which sets the address value, and **Mask**, which sets the mask value of the address value, are set as the address conditions.

Both the Address and the Mask settings may be omitted.

An address can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)"). The default radix for inputting a numeric value is hexadecimal.

Settable range

(Execution type event)

0 =< address value =< 0xFFFFF

0 =< mask value =< 0xFFFFF

(Access type event)

0 =< address value =< 0xFFFFF

0 =< mask value =< 0xFFFFF

Address

Set an address condition (lower address - higher address).

The following can be set:

Set Point	Set a value to only the lower address, or set the same value to the lower address and the higher address.Mask can be set.
Set Range	Set a value to the lower address and the higher address. Mask cannot be set.
Set Bit	Set a value to only the lower address, or set the same value to the lower address and the higher address. Specify a value in the form of address.bit . Mask cannot be set. The value of bit, which indicates the bit position, must be 0 =<bit =<7.

Mask

Set a mask value for the address value.

When a mask is set, the data value for the bit whose mask value is 1 may be 0 or 1.

The data value for a bit whose mask value is 1 may be 0 or 1.

Example 1:

Address	0x4000-0x4000
Mask	0xFF

With this setting, addresses 0x4000 to 0x40FF satisfy the condition.

Example 2:

Address	0x4000-0x4000
Mask	0x101

With this setting, addresses 0x4000, 0x4001, 0x4100, and 0x4101 satisfy the condition.

(5) **Data, Mask** (data setting area)

Data: Mask:

Data, which sets an data value, and **Mask**, which sets the mask value of an data value, are set as data conditions.

The default radix for inputting a numeric value is hexadecimal.

Both the data and mask may be omitted.

The setting range is as follows.

Table 6-33 Settable Range of Data Condition

Access Size	Settable range
Byte	0 ≤ data value ≤ 0xFF 0 ≤ mask value ≤ 0xFF

Data

Set a data value. Specify a value within the settable range.

A symbol or expression can be also specified by a symbol or expression (refer to "Table 6-13 Specifying Symbols (p.112)").

Mask

Set a mask value for the data value.

When a mask is set, the data value for the bit whose mask value is 1 may be 0 or 1.

The data value for a bit whose mask value is 1 may be 0 or 1.

Example 1:

Data	0x40
Mask	0x0F

With this setting, addresses 0x40 to 0x4F satisfy the condition.

(6) **Pass Count** (pass count setting area)

Pass Count:


The pass count condition is set in this area (settable range: 1 to 255).

Pass Count is an area that specifies the number of times that an event condition must be satisfied in order to satisfy a condition during user program execution.

If 1 is specified, the condition is satisfied when the event condition is satisfied.

Omitting this setting means 1 is specified.

(7) **Event Manager** (event manager area)



This area displays a list of break, trace and other registered events.

In this area, the following operations can be performed.

Displaying set contents

Select an event and click the <Open> button or double-click the event. The setting dialog box corresponding to the selected event will be opened and the set contents of the event will be displayed.

Delete

A selected event can be deleted by selecting the icon of the event and clicking the <Delete> button or pressing the DEL key while focussing on the event manager area.

Changing display mode and sorting

The display mode of and sorting in the event manager area can be selected by clicking the <Info...> button.

Function buttons

Setting-related buttons	
OK	Automatically registers the event condition being edited, if any, and closes this dialog box. In the select mode An event condition is selected and the setting dialog box (indicated on the title bar) that called the Event dialog box is displayed again. If the calling dialog box has already been closed, the select mode is returned to the normal mode, and the Event dialog box is not closed. Otherwise, this dialog box will be closed.
New	Newly creates an event condition in this dialog box. An event name is automatically created and a new event condition is prepared.
Set (when a new event is created or an event is changed)	Registers each event condition. Because the dialog box is not closed even after an event has been registered, new event conditions can be registered. In the select mode An event condition is selected. If there is an event being edited, it is automatically registered and selected.
Clear (when an event is not edited)	Clears the contents of the event condition. This button is displayed when an event condition has not been edited. This button and the <Restore> button are alternately displayed.

Restore (when an event is edited)	Restores the contents of an edited event condition. If an event condition not registered is displayed, all the fields other than the event name field are blank or the default values are set. This button and the <Clear> button are alternately displayed.
Cancel Close	Closes this dialog box. Even if an event condition is being edited, it is not registered and the dialog box is closed. <Cancel> is displayed if a condition is not created, changed, or deleted; <Close> is displayed if it is.
Help	Opens the Help window.
Buttons for opening each event setting dialog box	
Event Link...	Opens the Event Link dialog box.
Break...	Opens the Break dialog box.
Trace...	Opens the Trace dialog box.
Timer...	Opens the Timer dialog box.
Manager	Opens the Event Manager.
Buttons in event manager area	
Shrink <<< (When area is displayed)	Turns off display of the event manager area. At this time, the size of the dialog box is reduced.
Expand >>> (When area is not displayed)	Displays the event manager area. At this time, the size of the dialog box is expanded.
Open (When only one event is selected)	Opens the event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition. The Enter key performs the same operation.
Remove (When event is selected)	Deletes the selected event condition. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as an event condition.
Info...	Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.
Sort by Name	Sorts events into type order.
Sort by Kind	Sorts events into type order.
Unsort	Displays events in the order in which they have been registered without sorting the events.
Detail	Sets the detailed display mode.
Overview	Sets the list display mode.
Cancel	Closes this dialog box (same as ESC key).

Event Link dialog box

This dialog box is used to register and display event link conditions.

A event link condition registered in this dialog box will be automatically registered to the Event Manager.

An event link condition is an event condition that is generated only if the user program is executed in the sequence specified by a set event condition.

Up to four sequences can be specified. However, if a disable condition is detected in the middle of the sequence, the satisfied event conditions up to that time are initialized, and detection will start from the first event condition. Note that if an event link condition and a disable condition are detected at the same time, the disable condition has priority.


An event link condition can be used for multiple various event conditions. The following various event conditions can use event link conditions:

Table 6-34 Various Event Conditions for Which Event Link Condition Can Be Use

Using IE	Break condition (execution break only)	Trace condition
IE-78K4-NS	OK	NG

Up to 256 event link conditions can be registered. However, the number of event link conditions that can be simultaneously used (valid) is limited (refer to "Table 6-26 Maximum number of Events Usable for Event Conditions (p.215)").

Figure 6-51 Event Link Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

In normal mode

If the Event Link dialog box is opened as follows, an event link condition can be registered without its purpose being specified.

- Select [Event] -> [Event Link...] from the menu bar
(or press Alt+N, and L in that order).

In select mode

If the <OK> button is pressed when the Event Link dialog box has been opened as follows, an event link condition can be registered in the setting dialog box from which this dialog box was opened.

- In each various event setting dialog box
Click the <Add Link...> button.
(or press Alt+L, and L in that order).
In the select mode, the setting dialog box from which the Event Link dialog box was opened is displayed on the title bar.

Explanation of each area

The Event Link dialog box consists of the following areas:

- (1) Link Name (event link name setting area)
- (2) Phase1, Phase2, Phase3, Phase4 (link condition setting area)
- (3) Event Manager (event manager area)

(1) Link Name (event link name setting area)

Link Name: The image shows a text input field with a small square icon on the left containing the letter 'L'. The text 'Lnk00001' is entered in the field, and a drop-down arrow is visible on the right side of the field.


This area is used to set a event link name.

Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event link condition, select from the drop-down list.

In the select mode, the selected event condition can be set in the event link condition setting area of the setting dialog box that called the Event Link dialog box.

The mark on the left of this area indicates the utilization status of event link condition (refer to "Table 6-28 Color of Character on Mark and its Meaning (p.217)"). The mark "L" in gray indicates that an event link condition is being edited and has not been registered yet.

(2) **Phase1, Phase2, Phase3, Phase4** (link condition setting area)

This area is used to specify the sequence in which event conditions and events are detected.

Set Phase 1 -> Phase 2 -> Phase 3 -> Phase 4, in that order. Phase 4 does not have to be set.

In this case, an event occurs when the event condition set for the last phase has been detected. An event condition can be set for only Phase 1 or the same event condition can be set for two or more Phases.

The number of event conditions that can be set for each phase in this area is only 1 for each phase.

Caution Execution type events are the only type of event condition that can be set for each phase.


Setting event condition in each area

Select an event condition in the [Event Manager](#) area, and click the <Add> button or drag and drop an event condition. An event link condition can also be set by dragging and dropping not only in this dialog box, but also in the Event Manager area of each various event setting dialog box or the Event Manager.

In addition, the Event dialog box can be opened in "select mode" by clicking the <Add Event...> button, and the event condition to be set can be selected.

In the event condition setting area in this dialog box, an event condition can be alternately copied or moved by dragging and dropping.

- If an event condition is dropped only by the mouse, it is moved.
- If an event condition is dropped with the Shift key held down, it is moved.
- If an event condition is dropped with the Ctrl key held down, it is copied.

(3) **Event Manager** (event manager area)

This area displays a list of break, trace and other registered various event conditions.

For details, refer to "Event Manager (event manager area) (p.232)".

Function buttons

Setting-related buttons	
OK	<p>Automatically registers the event condition being edited, if any, and closes this dialog box.</p> <p>In the select mode An event condition is selected and the setting dialog box (indicated on the title bar) that called the Event Link dialog box is displayed again. If the calling dialog box has already been closed, the select mode is returned to the normal mode, and the Event dialog box is not closed. Otherwise, this dialog box will be closed.</p>
New	<p>Newly creates an event link condition in this dialog box. An event link condition name is automatically created and a new event link condition is prepared.</p>
Set (when a new event link is created or an event link is changed)	<p>Registers the various event condition. Because the dialog box is not closed even after an event has been registered, new event link conditions can be registered.</p> <p>In the select mode An event condition is selected. If there is an event being edited, it is automatically registered and selected.</p>
Clear (when an event is not edited)	<p>Clears the contents of the event link condition. This button is displayed when an event link condition has not been edited. This button and the <Restore> button are alternately displayed.</p>
Restore (when an event is edited)	<p>Restores the contents of an edited event link condition. If an event link condition not registered is displayed, all the fields other than the event name field are blank or the default values are set. This button and the <Clear> button are alternately displayed.</p>
Cancel Close	<p>Closes this dialog box. Even if an event link condition is being edited, it is not registered and the dialog box is closed. <Cancel> is displayed if a condition is not created, changed, or deleted; <Close> is displayed if it is.</p>
Help	Opens the Help window.
Buttons for opening each event setting dialog box	
Add Event...	Opens the Event dialog box in the select mode, and selects or newly creates an event condition to be set. The event condition will be added to the area selected when the < Add Event...> button is pressed.
Other...	Opens the dialog box for selecting the event type. By pressing each of the above buttons, each event setting dialog box can be opened in the new creation status.
Buttons in event manager area	
Shrink <<< (When area is displayed)	<p>Turns off display of the event manager area. At this time, the size of the dialog box is reduced.</p>
Expand >>> (When area is not displayed)	<p>Displays the event manager area. At this time, the size of the dialog box is expanded.</p>

Open (When only one event is selected)	Opens the event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition. The Enter key performs the same operation.
Remove (When event is selected)	Deletes the selected event condition. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as a various event condition.
Info...	Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.
Sort by Name	Sorts events into type order.
Sort by Kind	Sorts events into type order.
Unsort	Displays events in the order in which they have been registered without sorting the events.
Detail	Sets the detailed display mode.
Overview	Sets the list display mode.
Cancel	Closes this dialog box (same as ESC key).

Break dialog box

This dialog box is used to register, set, and display break event conditions.


A break event condition registered in this dialog box will be automatically registered to the Event Manager.

A break event condition automatically becomes valid when it has been registered.

Up to 256 break event conditions can be registered. However, the number of break event conditions that can be simultaneously used is limited (refer to "Table 6-26 Maximum number of Events Usable for Event Conditions (p.215)"). If the maximum number of break event conditions that can be used at the same time is exceeded or if the number of event conditions or event link conditions used exceeds the maximum limit, therefore, register a break event condition in the disabled state.

If [Run] -> [Ignore Break Point] is selected from the menu bar, a break event condition does not operate even if it is valid.

Figure 6-52 Break Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the **Brk** button.

- Select [Event] -> [Break...] from the menu bar (or press Alt+N, and B in that order).

Explanation of each area

The Break dialog box consists of the following areas:

- (1) Break Name (break event name setting area)
- (2) Break Event (break condition setting area)
- (3) Event Manager (event manager area)

(1) Break Name (break event name setting area)

Break Name:  time_o02

This area is used to set a break event name.


Directly input an alphanumeric string of up to eight characters as a name.

To display the contents of an already created event condition, select from the drop-down list.

The mark on the left of this area indicates the utilization status of events (refer to "Table 6-28 Color of Character on Mark and its Meaning (p.217)"). The gray mark indicates that an event condition is being edited and has not been registered yet.

By clicking the left mark, an event condition can be validated or invalidated.

(2) Break Event (break condition setting area)

Break Event: 

This area is used to set an event condition for break.

The number of event conditions that can be set in this area, combining execution events and access events, is as follows:

Table 6-35 Number of Events Settable in Break Condition Setting Area

IE Using	Total (execution/access)
IE-78K4-NS	7 ^{Note1} (4 ^{Note2} /3 ^{Note2})

Note1. Two events reserved in flash self mode

2. One event reserved in flash self mode

The number of event link conditions is up to the maximum number of events that can be used for various event conditions, as long as the used event conditions do not exceed the number that can be

simultaneously used.

Setting event condition and event link condition in each area

Select an event condition or event link condition in the [Event Manager](#) area, and click the <Add> button or drag and drop an event condition or event link condition. An event condition or event link condition can also be set by dragging and dropping not only in this dialog box, but also in the Event Manager area of each event setting dialog box and from the Event Manager.

In addition, Event dialog box or Event Link dialog box can be opened in "select mode" by clicking the <Add Event...> or <Add Link...> button, and the event condition or event link condition to be set can be selected.

In the event condition setting area in this dialog box, an event condition can be alternately copied or moved by dragging and dropping.

- If an event condition is dropped only by the mouse, it is moved.
- If an event condition is dropped with the Shift key held down, it is moved.
- If an event condition is dropped with the Ctrl key held down, it is copied.

(3) [Event Manager](#) (event manager area)

This area displays a list of break, trace and other registered events.

For details, refer to "Event Manager (event manager area) (P232)".

Function buttons

Setting-related buttons	
OK	Automatically registers the event condition being edited, if any, and closes this dialog box. The event condition becomes valid as soon as it has been registered.
New	Newly creates an event condition in this dialog box. An event name is automatically created and a new event condition is prepared.
Set (when a new event is created or an event is changed)	Registers each event condition. Because the dialog box is not closed even after an event has been registered, new event conditions can be registered. Each event condition becomes valid as soon as it has been registered. If an already registered event condition is displayed, the <Enable> or <Disable> button is alternately displayed.
Enable/Disable (when a registered event is displayed)	Validates (enables) or invalidates (disables) the selected event condition. However, event conditions and event link conditions cannot be enabled or disabled. This button and the <Set> button are alternately displayed.
Clear (when an event is not edited)	Clears the contents of the event condition. This button is displayed when an event condition has not been edited. This button and the <Restore> button are alternately displayed.
Restore (when an event is edited)	Restores the contents of an edited event condition. If an event condition not registered is displayed, all the fields other than the event name field are blank or the default values are set. This button and the <Clear> button are alternately displayed.

Cancel Close	Closes this dialog box. Even if an event condition is being edited, it is not registered and the dialog box is closed. <Cancel> is displayed if a condition is not created, changed, or deleted; <Close> is displayed if it is.
Help	Opens the Help window.
Buttons for opening each event setting dialog box	
Add Event...	Opens the Event dialog box in the select mode, and selects or newly creates an event condition to be set. The event condition will be added to the area selected when the < Add Event...> button is pressed.
Add Link...	Opens the Event Link dialog box in the select mode, and selects or newly creates an event link condition. The event link condition will be added to the area selected when the <Add Link...> button is pressed.
Other...	Opens the Select Event Type dialog box. By pressing each of the above buttons, each event setting dialog box can be opened in the new creation status.
Buttons in event manager area	
Shrink <<< (When area is displayed)	Turns off display of the event manager area. At this time, the size of the dialog box is reduced.
Expand >>> (When area is not displayed)	Displays the event manager area. At this time, the size of the dialog box is expanded.
Open (When only one event is selected)	Opens the event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition. The Enter key performs the same operation.
Remove (When event is selected)	Deletes the selected event condition. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as an event condition.
Info...	Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.
Sort by Name	Sorts events into name order.
Sort by Name	Sorts events into type order.
Unsort	Displays events in the order in which they have been registered without sorting the events.
Detail	Sets the detailed display mode.
Overview	Sets the list display mode.
Cancel	Closes this dialog box (same as ESC key).

Trace dialog box

This dialog box is used to register, set, and display trace event conditions.

In this dialog box, the following types of trace event conditions can be set:

- Event condition for starting section trace
- Event condition for ending section trace
- Event condition for qualify trace

To use the above trace event conditions, select [Run] -> [Cond. Trace ON] from the menu bar.


A trace event condition registered in this dialog box will be automatically registered to the Event Manager.

A trace event condition automatically becomes valid when it has been registered.

Up to 256 trace event conditions can be registered. However, the number of trace event conditions that can be simultaneously used is only 1 (refer to "Table 6-26 Maximum number of Events Usable for Event Conditions (p.215)").

If the maximum number of trace event conditions that can be used at the same time is exceeded or if the number of event conditions or event link conditions used exceeds the maximum limit, therefore, register a trace event condition in the disabled state.

Figure 6-53 Trace Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the **Trc** button.
- Select [Event] -> [Trace...] from the menu bar (or press Alt+N, and T in that order).
- Click the <Trace> button in the Event dialog box (or press Alt+T in that order).

Explanation of each area

The Trace dialog box consists of the following areas:

- (1) Trace Name (trace event name setting area)
- (2) Section Start, Section End (section trace range condition setting area)
- (3) Qualify (qualify trace condition setting area)
- (4) Event Manager (event manager area)

(1) Trace Name (trace event name setting area)

Trace Name:  Trc00001

This area is used to set a trace event name.


Directly input an alphanumeric string of up to eight characters as a name.


To display the contents of an already created event condition, select from the drop-down list.

The mark on the left of this area indicates the utilization status of events (refer to "Table 6-28 Color of Character on Mark and its Meaning (p.217)"). The gray mark indicates that an event condition is being edited and has not been registered yet.

By clicking the left mark, an event condition can be validated or invalidated.

(2) Section Start, Section End (section trace range condition setting area)

Section Start:  Evt00001

Section End:  Evt00002

This area is used to set event conditions for starting and stopping a section trace.

By setting a trace start event condition as [Section Start](#) and a trace end event condition as [Section End](#), a section trace (zone trace) can be performed.

The number of event conditions that can be set in this area, combining execution events and access events, is as follows:

IE Using	Total (execution/access)
IE-78K4-NS	1

To set an event condition, drag the icon of the event to be set from the [Event Manager](#) area, and drop it in this area. For details, refer to "Setting event condition and event link condition in each area (p.241)".

(3) [Qualify](#) (qualify trace condition setting area)

Qualify:



This area is used to set an event condition for a qualify trace.

In a qualify trace, a trace is performed only when a trace condition is satisfied.

If two or more events are set, trace is performed when each event occurs.


The number of event conditions that can be set in this area, combining execution events and access events, is as follows:

IE Using	Total (execution/access)
IE-78K4-NS	4 (only access event can be used)

To set an event condition, drag the icon of the event to be set from the [Event Manager](#) area, and drop it in this area. For details, refer to "Setting event condition and event link condition in each area (p.241)".

(4) [Event Manager](#) (event manager area)

Event Manager:



This area displays a list of break, trace and other registered various event conditions.

For details, refer to "Event Manager (event manager area) (p.232)".

Function buttons

Setting-related buttons	
OK	Automatically registers the event condition being edited, if any, and closes this dialog box. The event condition becomes valid as soon as it has been registered.
New	Newly creates an event condition in this dialog box. An event condition name is automatically created and a new event condition is prepared.
Set (when a new event link is created or an event link is changed)	Registers the various event condition. Because the dialog box is not closed even after an event has been registered, new event conditions can be registered. Each event condition becomes valid as soon as it has been registered. If an already registered event condition is displayed, the <Enable> or <Disable> button is alternately displayed.
Enable/Disable (when a registered event is displayed)	Validates (enables) or invalidates (disables) the selected event condition. However, event conditions and event link conditions cannot be enabled or disabled. This button and the <Set> button are alternately displayed.
Clear (when an event is not edited)	Clears the contents of the event condition. This button is displayed when an event condition has not been edited. This button and the <Restore> button are alternately displayed.
Restore (when an event is edited)	Restores the contents of an edited event condition. If an event condition not registered is displayed, all the fields other than the event name field are blank or the default values are set. This button and the <Clear> button are alternately displayed.
Cancel Close	Closes this dialog box. Even if an event condition is being edited, it is not registered and the dialog box is closed. <Cancel> is displayed if a condition is not created, changed, or deleted; <Close> is displayed if it is.
Help	Opens the Help window.
Buttons for opening each event setting dialog box	
Add Event...	Opens the Event dialog box in the select mode, and selects or newly creates an event condition to be set. The event condition will be added to the area selected when the < Add Event...> button is pressed.
Add Link... (Always disabled)	Opens the Event Link dialog box in the select mode, and selects or newly creates an event link condition. The event link condition will be added to the area selected when the <Add Link...> button is pressed.
Other...	Opens the dialog box for selecting the event type. By pressing each of the buttons, each various event setting dialog box can be opened in the new creation status.
Buttons in event manager area	
Shrink <<< (When area is displayed)	Turns off display of the event manager area. At this time, the size of the dialog box is reduced.
Expand >>> (When area is not displayed)	Displays the event manager area. At this time, the size of the dialog box is expanded.

Open (When only one event is selected)	Opens the various event setting dialog box corresponding to the selected event condition. Each setting dialog box displays the contents of the selected event condition. The Enter key performs the same operation.
Remove (When event is selected)	Deletes the selected event condition. When an event condition or an event link condition is to be deleted, an error occurs and the event condition or event link condition cannot be deleted if the event is used as a various event condition.
Info...	Opens the Select Display Information dialog box. This dialog box is used to change the display mode and rearrange event names.
Sort by Name	Sorts events into type order.
Sort by Kind	Sorts events into type order.
Unsort	Displays events in the order in which they have been registered without sorting the events.
Detail	Sets the detailed display mode.
Overview	Sets the list display mode.。
Cancel	Closes this dialog box (same as ESC key).


Timer dialog box

This dialog box is used to display the execution time measurement result.

About Section event

Section is a timer event name given to a timer event condition that measures the execution time from when a section trace starts until it ends. This is registered by default.

Figure 6-54 Timer Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Click the **Tim** button.
- Select [Event] -> [Timer...] from the menu bar (or press Alt+N, and I in that order).
- Click the <Timer... > button in the Event dialog box. (or press Alt+I).

Explanation of each area

The Timer dialog box consists of the following areas:

- (1) Timer Name (timer event name setting area)
- (2) Time (timer display unit selection area)
- (3) Execution time display area

(1) Timer Name (timer event name setting area)

Timer Name: 

In the case of the IE-78K4-NS, The timer event name cannot be set. It is fixed to Section.

The timer event name [Section] that displays the start and end of a section trace is registered in the default condition, but is not displayed on the Event Manager.

(2) Time (timer display unit selection area)

This area is used to select the unit in which the timer measurement result is to be displayed.

nsec	Nanoseconds (default)
usec	Microseconds
msec	Milliseconds
sec	Seconds
min	Minutes

(3) Execution time display area

Pass: 1 time(s)
 Total: 8100 nsec
 Average: 8100 nsec

Copy

View Allways

This area displays the result of measuring the execution time of the program.

Pass	Number of passes from when a section trace start condition occurs until the end condition or a break occurs. (measurable execution count: 65535 max.)
Total	Total execution time in the measurement zone specified by start event and end event conditions (measurable execution time: Approx. 14 minutes 33seconds max. Note)
Average	Average execution time When step execution is performed, the same value as Total is displayed.

Note Resolution: 203.45ns

The following two methods are available to obtain the measurement results.

- In the case of step execution, the execution time for the last assembler instruction executed is displayed. Also, in the case of step execution, the execution count is always displayed as 1.
- Measures the time from when a section trace start condition occurs until the end condition or a break occurs.
The time is not measured if a section trace start condition does not occur.
The execution count is updated when a section trace start condition occurs. However, if another section trace start condition occurs during measurement (before a timer stop condition occurs), the execution count is not updated.

Buttons to manipulate execution time display area

Copy	Copies the measurement result to the clipboard in text format.
View Always	Displays the Timer Result dialog box is displayed.


Function buttons

Setting-related buttons	
OK	Automatically registers the event condition being edited, if any, and closes this dialog box. The event condition becomes valid as soon as it has been registered.
Help	Opens the Help window.

Timer Result dialog box

This dialog box displays the result of measuring the execution time.

Figure 6-55 Timer Result Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- In the Timer dialog box
Click the <View Always> button.
(or press Alt+V).

Explanation of each area

The Timer Result dialog box consists of the following areas:

- (1) Execution time display area

(1) Execution time display area

This area displays the result of measuring the execution time of the program (refer to the section describing the Execution time display area (p.249) of the Timer dialog box).

Function buttons


Copy	Copies the measurement result to the clipboard in text format.
Close	Closes this dialog box.
Help	Opens the Help window.

Delay Count dialog box

This dialog box is used to set or display delay count values.

By setting a delay count, it is possible to perform tracing of the number of frames corresponding to the specified delay count value after a break condition occurs, and then stop program execution and tracer operation.

Figure 6-56 Delay Count Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [Event] -> [Delay Count...] from the menu bar (or press Alt+N and Y in that order).

Explanation of each area

This dialog box consists of the following areas:

- (1) Delay Count (delay count setting area)

(1) Delay Count (delay count setting area)



This area is used to set or display a delay count value (unit: frames).

The delay count can be set between 0 (default) and 32767.

Function buttons


OK	Sets the specified delay count and closes this dialog box.
Restore	Restores the previous delay count.
Cancel	Closes this dialog box.
Help	Opens the Help window.

Reset Debugger dialog box

This dialog box is used to initialize the debugger, emulation CPU, and symbol information.

Specify what is to be initialized by using the check box. In the default condition, the debugger is initialized.

Figure 6-57 Reset Debugger Dialog Box



This section explains the following items:

- Opening
- Explanation of each area
- Function buttons

Opening

This dialog box can be opened as follows:


- Select [File] -> [Debugger Reset...] on the menu bar (or press Alt+F, and R in that order).

Explanation of each area

The Reset Debugger dialog box consists of the following areas:

- (1) Reset subject selection area

(1) Reset subject selection area



This area is used to select what is to be initialized.

Debugger	Initializes the debugger (default).
Symbol	Initializes the symbol information.
Target CPU	Initializes the emulation CPU.

Function buttons

OK	Initializes the debugger, symbol information, or CPU.
Cancel	Ignores the setting and closes this dialog box.
Help	Opens the Help window.


About dialog box

This dialog box displays the version information of the debugger and in-circuit emulator (the year is displayed in 4 digits).

The following version information is displayed:

- Product version of debugger
- Version of device file
- Version of GUI
- Version of debugger DLL
- Version of assembler DLL
- Version of executor
- Version of Packet DLL

Figure 6-58 About Dialog Box



This section explains the following items:

- Opening
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [H]elp->[A]bout
(or press Alt+H, and A in that order).

Function buttons


OK	Closes this dialog box.
----	-------------------------

Exit Debugger dialog box


This dialog box is used to select whether the current debug environment is saved to a project file or not before terminating the debugger.

It can be specified in the Debugger Option dialog box that the debugger is terminated without this confirmation dialog box being opened.

Figure 6-59 Exit Debugger Dialog Box



Reference If an attempt is made to terminate the debugger while the user program is being executed, the following message is displayed and the program execution can be stopped.



<Yes> button is selected

Execution of the user program is stopped and then the Exit Debugger dialog box is displayed.

If it is specified in the Debugger Option dialog box that the Exit Debugger dialog box is not to be displayed, however, the debugger is terminated.

<No> button is selected

Execution of the user program is not stopped and the Exit Debugger dialog box is not displayed. The debugger is not terminated.

This section explains the following items:

- Opening
- Function buttons

Opening

This dialog box can be opened as follows:

- Select [E]ile -> [E]xit from the menu bar (or press Alt+F, and X in that order).
- Press the Alt+F4 keys simultaneously.
- If forcible termination, such as to terminate the application, has been executed on the task list that terminates Windows.

Function buttons

Yes	Saves the current debug environment to a project file, closes all the windows, and terminates the debugger. If a project file name is not specified, the Project File Save dialog box is opened. If the < Cancel> button is selected on the Project File Save dialog box, the environment is neither saved to a project file nor is the debugger terminated. If a project file is loaded or saved during debugger operation, this button has the default focus.
No	Closes all the windows and terminates the debugger. If a project file is not loaded or saved during debugger operation, this button has the default focus.
Cancel	Closes this dialog box without executing anything.

Console window

This window is used to input commands that control the debugger.


Because the key bind is Emacs-like, the accelerator key is not acknowledged if the Console window is active.

However, the F1 key displays the help of the Console window.

While the Console window is open, an error message window with only an <OK> button is displayed in the Console window.

Refer to "CHAPTER 7 COMMAND REFERENCE (p.262)" for details on the command specifications.

Figure 6-60 Console window



This section explains the following items:

- Opening

Opening

This window can be opened as follows:

- Select [Browse] -> [Console] from the menu bar
(or press Alt+B, and N in that order).

CHAPTER 7 COMMAND REFERENCE

This section explains the command functions of the ID78K4-NS in detail.

7.1 Command Line Rules

The specification of command lines has the following rules:

- Command name, option, and argument are specified for command line.
- To divide words, a space (space key or tab key) is used.
- At the end of a line, a line feed character or a semicolon is used.
- When a command name and an option are entered to the point of identifiability, they are recognized.
- In script, command names have to be entered completely.

Command format

command -options arg1 arg2 arg3 ...

7.2 Command List

The list of ID78K4-NS commands is shown in Table 7-1 and Table 7-2 .

Table 7-1 List of Debugger Control Commands

Command Name	Function
address	Evaluation of address expression Converts the address expression specified with expression into address.
assemble	Disassemble/line assemble (a) Assembles the character strings specified with code from the address specified with address.
batch	Executing batch (with echo) Executes in batch displaying files specified with scriptname on the screen.
breakpoint	Setting/deletion of breakpoint (b) Operates breakpoint specified with options and address.
dbgexit	Terminating debugger Terminates the debugger.
download	Download of files (l) Downloads files specified with filename according to options.
extwin	Creation of expansion window Creates expansion window with scriptfile.
finish	Returning from function Executes until it returns to the program that called the current function.
go	Continuous execution (g) Executes program continuously.
help	Display of help Displays help of Dcl.

Table 7-1 List of Debugger Control Commands

Command Name	Function
hook	Setting of hook Sets the procedure for hook with scriptfile.
jump	Jump to window (j) Displays the window specified with options.
map	Setting/deletion of memory mapping Sets, deletes, and displays memory mapping.
mdi	Setting of expansion window Sets the size and title name of the expansion window.
memory	Display/setting of memory (m) Sets value in the memory of the address specified with address according to options.
module	Display of the list of files and functions Displays the list of files and functions of the load module specified with progname.
next	Procedure step (n) Executes the procedure steps.
refresh	Redrawing of window Redraws the window and updates the data.
register	Display/setting of register value and I/O register value Sets value in the register specified with regname.
reset	Reset Resets CPU, debugger or symbols.
run	Reset and execution of CPU (r) Resets program and executes it.
step	Step execution (s) Executes step execution.
stop	Stop execution Stops the program forcibly.
upload	Upload Saves the memory data or coverage data within the specified range in a file.
version	Display of the version information Displays the version information of the debugger.
watch	Display/setting of variables (w) Displays and sets the variables.
where	Trace of stack Executes the back-trace of the stack.
wish	Start of Tclet Starts the script using Tk (Tclet).
xtrace	Operation of tracer Operates tracer.

Table 7-2 List of Console/Tcl Commands

Command Name	Function
alias	Creation of another name
cd	Change of directory
clear	Clears the screen
echo	Echo
exit	Close/end
history	Display of history
ls	Display of files
pwd	Check of the directory
source	Execution of batch
time	Measurement of time for commands
tkcon	Console control
unalias	Deletion of another name
which	Display of the command path or another name
Other commands	Based on Tcl/Tk 8.1

7.3 List of Variables

- dcl(chip) - Chip name read only
- dcl(prjfile) - Project file name read only
- dcl(srcpath) - Source path read only
- dcl(ieid) - IE type read only
- dcl(iestat) - IE status read only
- dcl(bkstat) - Break status read only
- env(LANG) - Language
- dcl_version - Dcl version read only

7.4 List of Packages

- tcltest - Restoration test
- cwind - Automatic window control
- BWidget - Toolkit

7.5 Key Bind

- tcsh + emacs like
- Complement of command name [Tab]
- Complement of file name [Tab]
- HTML help [F1]

7.6 Expansion window

The expansion windows can be created using Tk.

In the expansion windows, Widget is allocated with '.dcl' as a root instead of '.'.

When the following script files are allocated in bin/itcl/tools/, an expansion window is added on selecting [Browse] -> [Others] from the menu bar.

The mdi command, an exclusive command for expansion windows, has been added.

```
# Sample.tcl
wm protocol .dcl WM_DELETE_WINDOW { exit }
mdi geometry 100 50
button .dcl.b -text Push -command exit
pack .dcl.b
```

In expansion windows, Tk menu commands cannot be used because of the restrictions of MDI windows.

7.7 Callback Procedure

Expansion windows can hold dcl_asyncproc procedures called by asynchronous messages.

```

proc dcl_asyncproc {mid} {
    if {$mid == 19} {
        redraw
    }
}

```

The asynchronous message ID is passed for the argument of the dcl_asyncproc procedure.

The message IDs are shown below:

Table 7-3 Message ID

Message ID	Meaning
9	After changing configuration
10	After registering event
11	After deleting event
12	Before executing
13	After breaking
14	After resetting CPU
15	After resetting debugger
17	After changing extended option
18	After changing debugger option
19	After downloading
20	After changing memory or register
36	Before starting tracer
37	After stopping tracer
42	After clearing trace
45	After resetting symbol

7.8 Hook Procedure

A hook can be set in the debugger using the hook procedure.

The hook procedures are shown below:

BeforeDownload	Hook before downloading
AfterDownload	Hook after downloading
AfterCpuReset	Hook after resetting CPU
BeforeCpuRun	Hook before starting execution
AfterCpuStop	Hook after breaking

By using hook procedures, register values can be changed before downloading programs or after resetting the CPU.

An actual example of the procedure is shown below. A hook is valid till the debugger is closed.

[When hook is set with debugger control command]

- 1 Create script file^{Note} with an editor.

Note Be sure that the script file name is the same as the project file.

Example:

The script file corresponding to test.prj is test.tcl.

Allocate test.prj, test.pri, and test.tcl in the same directory.

- 2 Start up the ID78K4-NS, select [Browse] menu -> [Console], and open the Console window.
- 3 If the script file is executed in the window as below, the hook in the script file is set.
%hook test.tcl

[When hook is set on downloading of project file]

- 1 Create script file^{Note} a. with an editor.

Note Be sure that the script file name is the same as the project file.

- 2 Start up the ID78K4-NS and read test.prj.
The hook in the script file is set.

An example of the contents of a script file is shown as below.

```
proc BeforeDownload {} {
    register MM 0x7
    register PMC8 0xff
    register PMC9 0xff
    register PMCX 0xe0
}

proc AfterCpuReset {} {
    register MM 0x7
    register PMC8 0xff
    register PMC9 0xff
    register PMCX 0xe0
}
```

7.9 Related Files

- Executes when the aliases.tcl console is opened.
Sets the default alias etc.
- Executes when the project file name.tcl project is opened.
The hook of BeforeDownload, AfterCpuReset, BeforeCpuRun and AfterCpuStop can be used.

- Executes when the load module name.tcl load module is downloaded.
The hook of BeforeDownload, AfterCpuReset, BeforeCpuRun and AfterCpuStop can be used.

7. 10 Cautions

- The separator for file and path is a slash (/).
- When a console or an expansion window is active, the accelerator key cannot be acknowledged.
- When a console is open, error messages are output to the console.
- When the [F1] key on the console is pressed, the HTML format help is opened (not opened from the menu).
- To terminate the command forcibly, close the console.
- The execution of external commands (DOS commands) is OFF by default.

7. 11 Commands

In this section, each command is explained using the format shown below.

Command name

Gives a brief explanation of the function of the command.

Name

Describes the command name.

Input format

Describes the input format of the command.

Functions

Explains the functions of the command.

Usage example

Shows an example of the usage of the command.

address

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

address - Evaluation of address expression

Input format

address *expression*

Functions

Converts the address expression specified by ***expression*** into address.

Usage example

```
(IDCON) 1 % address main
0xaa
(IDCON) 2 % address main+1
0xab
```

assemble

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

assemble - Disassemble/line assemble

Input format

assemble *?options? address ?code?*

Functions

Assembles the character strings specified by **code** from the **address** specified by address.

When '.' is specified for address, it is understood as an **address** continuing from the immediately previous assemble.

When **code** is omitted, it is assembled from the **address** specified by address.

The followings are **options**. They are ignored for assembly.

- code** Command code is also displayed. It is ignored for assembly.
- number number** *number* line is displayed. It is ignored for assembly.

Usage example

```
(IDCON) 1 % assemble -n 5 main
0x000000aa B7      PUSH HL
0x000000ab B1      PUSH AX
0x000000ac 891C    MOVW AX,SP
0x000000ae D6      MOVW HL,AX
0x000000af A100    MOV  A,#0H
(IDCON) 2 % assemble main mov a,b
(IDCON) 3 % assemble . mov a,b
```

batch

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

batch - Executing batch (with echo)

Input format

batch scriptname

Functions

Executes in batch with displaying files specified by ***scriptname*** on the screen.

Nesting is possible.

Usage example

(IDCON) 1 % clear

(IDCON) 2 % batch bat_file.tcl

(IDCON) 3 % tkcon save a:/log.txt

breakpoint

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

breakpoint - Setting/deletion of breakpoint

Input format

breakpoint *?options? ?address1? ?address2?*

breakpoint *-delete brkno*

breakpoint *-enable brkno*

breakpoint *-disable brkno*

breakpoint *-information*

Functions

Operates the breakpoint specified by **options** and **address**.

If a breakpoint can be set correctly, the breakpoint number is returned.

The following are **options**:

-software	A software break is specified.
-hardware	A hardware break is specified (default).
-execute	The address execution break is set (default).
-beforeexecute	The break before address execution is set.
-read	An address memory read break is set.
-write	An address memory write break is set.
-access	An address memory access break is set.
-size size	The access size is set (8, 16, or 32).
-data value	The data condition is set.
-datamask value	The data mask is set.
-extprobe value	The external sense data condition is set.

-extprobemask <i>value</i>	The external sense data mask is set.
-passvalue	The pass count is set.
-information	The list of breakpoints is displayed.
-delete	The breakpoint whose number is specified is deleted.
-disable	The breakpoint whose number is specified is disabled.
-enable	The breakpoint whose number is specified is enabled.

Usage example

```
(IDCON) 1 % breakpoint main
1
(IDCON) 2 % breakpoint -i
1 Brk00001 enable rammon.c#17

(IDCON) 3 % breakpoint -software sub
2
(IDCON) 4 % breakpoint -i
1 Brk00001 enable rammon.c#17
2 Brk00001 enable rammon.c#8

(IDCON) 5 % breakpoint -disable 2
(IDCON) 6 % breakpoint -i
1 Brk00001 enable rammon.c#17
2 Brk00001 disable rammon.c#8

(IDCON) 7 % breakpoint -delete 1
2 Brk00001 disable rammon.c#8
```

dbgexit

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

dbgexit - Terminating debugger

Input format

dbgexit *?options?*

Functions

Terminates the debugger.

The following are **options**:

-saveprj	Project is saved on terminating debugger.
-----------------	---

Usage example

(IDCON) 1 % dbgexit -saveprj

download

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

download - Download of files

Input format

download *?options? filename ?offset?*

Functions

Downloads file specified by **filename** according to **options**.

If **offset** is specified, the address is shifted by the **offset** (if the data is in binary format, the load start address is specified for **offset**).

-binary	Binary format data is downloaded.
-append	Additional download is executed.
-nosymbol	Download is executed. Symbol information is not read.
-symbolonly	Symbol information only is read.
-reset	CPU is reset after download.
-information	Download information is displayed.

Usage example

(IDCON) 1 % download test.lmf

extwin

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

extwin - Creation of expansion window

Input format

extwin *scriptfile*

Functions

Creates expansion window with ***scriptfile***.

Usage example

(IDCON) 1 % extwin d:/foo.tcl

finish

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

finish - Returning from function

Input format

finish

Functions

Executes until it returns to the program that called the current function.

Usage example

(IDCON) 1 % finish

go

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

go - continuous execution

Input format

go ?options?

Functions

Executes the program continuously. When -waitbreak is specified, it waits for the program to stop.

The following are *options*:

-ignorebreak	Breakpoint is ignored.
-waitbreak	The command waits for the program to stop.

Usage example

(IDCON) 1 % go -w

help

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

help - Display of help

Input format

help

Functions

Displays Dcl help.

Usage example

(IDCON) 1 % help

hook

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

hook - Setting of hook

Input format

hook *scriptfile*

Functions

Sets the procedure for hook with ***scriptfile***.

Usage example

(IDCON) 1 % hook d:/foo.tcl

jump

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

jump - Jump to window

Input format

jump *-source -line filename ?line?*

jump *?options? address*

Functions

Displays the window specified by **options**.

-source	The Source window is displayed from the address specified by address .
-assemble	The Assemble window is displayed from the address specified by address .
-memory	The Memory window is displayed from the address specified by address .
-line	The command is moved to the line specified by line .

Usage example

(IDCON) 1 % jump -s main

(IDCON) 2 % jump -s -l mainfile.c 10

(IDCON) 3 % jump -m array

map

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

map - Setting/deletion of memory mapping

Input format

map *options address1 address2 ?acsize?*

Functions

Sets, deletes, and displays memory mapping.

The access size of 8, 16, or 32 is specified by **acsize** (the default is 8).

The following are **options**:

-erom	Alternate ROM is mapped.
-eram	Alternate RAM is mapped.
-target	Target area is mapped.
-protect	I/O protect area is mapped.
-clear	All the settings for the mapping are deleted.
-information	Refer to the setting for the mapping.

Usage example

```
(IDCON) 1 % map -i
1: 0 0x7fff 8 {IROM}
2: 0x8000 0x87ff 8 {Target RRM}
3: 0x8800 0x9fff 8 {Target}
4: 0xa000 0xf7ff 8 {NonMap}
5: 0xf800 0xfaff - {NonMap}
```

6: 0xfb00 0xfedf 8 {Saddr}

7: 0xfe0 0xfeff 8 {Register}

8: 0xff00 0xffff 8 {SFR}

(IDCON) 2 % map -erom 0x100000 0x10ffff

(IDCON) 3 % map -c

mdi

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

mdi - Setting of expansion window

Input format

mdi *geometry* ?x y? *width height*

mdi *title string*

Functions

Sets the size and title name of the expansion window.

The command can be used only from the expansion window.

Usage example

(IDCON) 1 % mdi geometry 0 0 100 100

(IDCON) 2 % mdi title foo

memory

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

memory - Display/setting of memory

Input format

memory *?options? address ?value?*

memory *?options? -fill address1 address2 value*

memory *?options? -copy address1 address2 address3*

Functions

Sets **value** in the memory of the **address** specified by address according to **options**.

If **value** is omitted, display the value of the memory of the address specified by **address**.

If -fill is specified, value is filled from address1 to address2.

If -copy is specified, data from address1 to address2 is copied to address3.

The following are **options**:

-byte	Displayed/set in one-byte units (default).
-word	Displayed/set in word units.
-fill	The data is filled in.
-copy	The data is copied.
-noverify	Verification is not executed on writing.

Usage example

(IDCON) 1 % memory 100

0x10

(IDCON) 2 % memory 100 2

(IDCON) 3 % memory 100

0x02

(IDCON) 4 % memory -fill 0 1ff 0

module

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

module - Display of the list of files and functions

Input format

module *progrname* *?filename?*

Functions

Displays the list of files and functions of the load module specified by ***progrname***.

If filename is not specified, the list of files is displayed.

If filename is specified, the list of functions of the specified files is displayed.

Usage example

(IDCON) 1 % module rammon.lmf

1: rammon.c

(IDCON) 2 % module rammon.lmf rammon.c

1: rammon.c sub1

2: rammon.c main

next

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

next - Procedure step

Input format

next *?options?*

Functions

Executes the procedure steps. If functions are called, the step stops after executing function.

The following are *options*:

-source	Command is executed in source line units (default).
-instruction	Command is executed in command units.

Usage example

(IDCON) 1 % next -i

(IDCON) 2 % next -s

refresh

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

refresh - Redrawing of window

Input format

refresh

Functions

Redraws the window and updates the data.

Usage example

(IDCON) 1 % batch foo.tcl

(IDCON) 2 % refresh

register

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

register - Display/setting of register value and I/O register value

Input format

register *?options? regname ?value?*

Functions

Sets **value** in the register specified with **regname**.

If **value** is omitted, displays the value of the register specified by **regname**.

The following are **options**:

- | | |
|------------------------------|---------------------------------|
| -force | Compulsory reading is executed. |
| -bankno <i>bankno</i> | A bank number is specified. |

Usage example

(IDCON) 1 % register pc
0x100
(IDCON) 2 % register pc 200
(IDCON) 3 % register pc
0x200

reset

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

reset - Reset

Input format

reset *?options?*

Functions

Resets the CPU, debugger or symbols.

If options are omitted, the CPU is reset.

The following are **options**:

-cpu	CPU is reset (default).
-debugger	Debugger is reset.
-symbol	Symbol is reset.
-event	Event is reset.

Usage example

(IDCON) 1 % reset

run

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

run - Reset and execution of CPU

Input format

run *?options?*

Functions

Resets the program and executes it.

If -waitbreak is not specified, the command does not wait until the program stops.

The following are **options**:

-waitbreak

The command waits for the program to stop.

Usage example

(IDCON) 1 % run

(IDCON) 2 % run -w

step

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

step - Step execution

Input format

step *?options?*

Functions

Executes step execution.

If functions are called, the command stops at the head of the functions.

The following are **options**:

- | | |
|---------------------|---|
| -source | The command is executed in source line units (default). |
| -instruction | The command is executed in command units. |

Usage example

(IDCON) 1 % step -i

(IDCON) 2 % step -s

stop

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

stop - Stop executing

Input format

stop

Functions

Stops the program forcibly.

Usage example

(IDCON) 1 % run
(IDCON) 2 % stop

upload

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

upload - Upload

Input format

upload *?options? filename address1 address2*

Functions

Saves the memory data within the specified range in a file.

The following are **options**:

-binary	The data is saved in binary format.
-intel	The data is saved in Intel HEX format (default).
-motorola	The data is saved in Motorola HEX format.
-tektronix	The data is saved in Tektronix HEX format.
-force	The file is overwritten.

Usage example

(IDCON) 1 % upload -b foo.hex 0 0xffff

(IDCON) 2 % upload -c -f foo.cov 0 0xffff

version

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

version - Display of the version information

Input format

version

Functions

Displays the version information of the debugger.

Usage example

(IDCON) 1 % version

GUI : E2.00y [31-May-99]

Devicefile : 78K4[uPD784225] E1.01a

Debugger : 78K/4 Debugger E2.50c [02-Apr-99]

Executer : 78K/4 Executer E1.3c

Packet translator : 78K/4 Packet E2.00w

Assembler : 78K/4 Asm/Disasm E1.15a [01-Apr-99]

Tcl/Tk : 8.1.1

watch

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

watch - Display/setting of variables

Input format

watch *?options? variable ?value?*

Functions

Displays and sets the variables.

The following are **options**:

-binary	The value is displayed in binary digits.
-octal	The value is displayed in octal digits.
-decimal	The value is displayed in decimal digits.
-hexdecimal	The value is displayed in hexadecimal digits.
-string	The value is displayed in character strings.
-sizeof	The size, instead of the value, of variables is displayed in decimal digits.

Usage example

(IDCON) 1 % watch var

0x10

(IDCON) 2 % watch -d var

16

(IDCON) 3 % watch array\[0\] 0xa

where

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

where - Trace of stack

Input format

where

Functions

Executes the back-trace of the stack.

Usage example

```
(IDCON) 1 % where
1: test2.c#sub2(int i)#13
2: test.c#num(int i)#71
3: test.c#main()#82
```

wish

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

wish - Startup of Tclet

Input format

wish *scriptname*

Functions

Starts up the script using Tk (Tclet).

The expansion window can be created with Tclet.

Usage example

(IDCON) 1 % wish test.tcl

xtrace

The following items are explained here.

- Name
- Input format
- Functions
- Usage example

Name

xtrace - Operation of tracer

Input format

xtrace *-dump ?-append? frameno ?filename?*

xtrace *-start*

xtrace *-stop*

xtrace *-clear*

xtrace *-addup bool*

xtrace *-mode mode*

Functions

Operates tracer.

The following are **options**:

-start	The tracer starts on executing the program.
-stop	The tracer stops on executing the program.
-clear	The trace data is dumped (default).
-dump	The dump result is redirected to the console window. If the file name is specified, the dump result is written in the file.
-append	The dump result is added to a file.
-addup <i>bool</i>	Whether the time tag is integrated or not is selected.
-mode <i>mode</i>	The trace control mode (any one of: all, cond, nonstop, fullstop, fullbreak, delaystop, delaybreak, machine, or event) is selected.

Usage example

```
(IDCON) 1 % xtrace -start
(IDCON) 2 % xtrace -stop
(IDCON) 3 % xtrace -dump 3
_01685 2 000000BC M1 br _sub2+0x2
_01686 4 0000009A BRM1 st.w r6, 0x8[sp]
_01687 3 0000009E BRM1 st.w r0, 0x0[sp]
(IDCON) 4 % xtrace -clear
(IDCON) 5 % xtrace -addup true
```

APPENDIX A INPUT CONVENTIONS

This appendix explains the input conventions of the following items:

- Character set
- Symbols
- Numeric Values
- Expressions and Operators
- File Names

A. 1 Character set

The characters listed in Table A-1 can be used as the character set.

The characters listed in Table A-2 can be used as special characters.

Specify a line number as an integer constant, starting from 1.

Table A-1 Usable Character Set

Classification	Character
Alphabetic characters	Uppercase characters: A B C D E F G H I J K L M N O P Q R S T U V X W Z Lowercase characters: a b c d e f g h i j k l m n o p q r s t u v x w z
Numerals	0123456789
Character equivalent to alphabetic character	@?_

Table A-2 List of Special Characters

Character	Name	Usage
(Left parenthesis	Changes operation order.
)	Right parenthesis	Changes operation order.
+	Plus	Addition operator or positive sign
-	Minus	Subtraction operator or negative sign
*	Asterisk	Multiplication operator or indirect reference operator
/	Slash	Division operator
%	Percent	Remainder operator
~	Tilde	Complement operator
	Vertical line	Bit sum operator
^	Circumflex	Bit difference operator
&	Ampersand	Bit product operator or address operator

Table A-2 List of Special Characters

Character	Name	Usage
[Left bracket	Array subscript operator or base register specification symbol
]	Right bracket	Array subscript operator or base register specification symbol
.	Period	Direct member operator or bit position specifier
,	Comma	Delimiter between operands

A. 2 Symbols

The following rules apply to symbols:

- 1 A symbol consists of characters A to Z, a to z, @, _ (underbar), . (period), ?, and 0 to 9.
- 2 A symbol must start with a character other than numerals 0 to 9.
- 3 Uppercase characters (A to Z) and lowercase characters (a to z) are distinguished.
- 4 A symbol must be no more than 2048 characters long (if a symbol of more than 256 characters is defined, only the first 2048 characters are valid).
- 5 A symbol is defined by loading a load module file.
- 6 Symbols are classified into the following types by the valid range:
 - Global symbol (assembly language, C language)
 - Static symbol (C language)
 - In-file static symbol
 - In-function static symbol
 - Local symbol (C language)
 - In-module local symbol (assembly language)
 - In-file local symbol
 - In-function local symbol
 - In-block local symbol
- 7 The following symbols are available for each language used:
 - Assembly language
 - Label name, constant name, bit symbol name
 - C language
 - Variable name (including pointer function name, enumeration type variable name, array name, structure name, and union name)
 - Function name, label name
 - Array element, structure element, union element, bit field (if the symbol is an array, structure, or union)
- 8 A symbol can be described instead of an address or numeric value.
- 9 The valid range of a symbol is determined based on the source debug information when the source file is assembled or compiled.
- 10 Describe only the symbol name of a global symbol.
- 11 A local symbol is expressed in pairs with a file name.

A. 3 Numeric Values

The following four types of numeric values can be used. The input format of each type is as shown below.

The suffix (bold) and the alphabetic characters of hexadecimal numbers may be uppercase or lowercase characters. If the first character is A to F, 0 must be prefixed to it.

In the input field of the debugger, decimal numbers or hexadecimal numbers are alternately selected, depending on the default radix.

Table A-3 Input Format of Numeric Values

numeric value	Input format
Binary number	n Y n...n Y (n=0,1)
Octal number	n O n...n O (n=0,1,2,3,4,5,6,7) n Q n...n Q (n=0,1,2,3,4,5,6,7)
Decimal number	n n...n n T n...n T (n=0,1,2,3,4,5,6,7,8,9)
Hexadecimal numbers	n n...n n H n...n H 0xn 0xn ...n (n=0,1,2,3,4,5,6,7,8,9,A,B,C,D,E,F)

A. 4 Expressions and Operators

Expressions

An expression consists of constants, register names, SFR names, and symbols coupled by operators.

If an SFR name, label name, function name, or variable name is described as a symbol, an address is calculated as the value of the symbol.

The elements making up an expression, except operators, are called terms (constants and labels).

Terms are called the first term, the second term, and so on, starting from the left.

Operators

The following operators of the C language can be used:

Table A-4 List of Operators

Symbol	Meaning	Explanation
Operators		
+	Addition	Returns the sum of the first and second terms.

Table A-4 List of Operators

Symbol	Meaning	Explanation
-	Subtraction	Returns the difference between the first and second terms..
*	Multiplication	Returns the product of the first and second terms.
/	Division	Divides the value of the first term by the value of the second term, and returns the integer of the result.
MOD %	Remainder	Divides the value of the first term by the value of the second term, and returns the remainder of the result.
- sign	Unary operator (negative)	Returns 2's complement of the value of the term.
+ sign	Unary operator (positive)	Returns the value of the term.
Logical operator		
NOT ~	Negation	Logically negates each bit of the term, and returns the result.
AND &	Logical product	Obtains the logical product of the values of the first and second terms on each bit, and returns the result.
OR 	Logical sum	Obtains the logical sum of the values of the first and second terms on each bit, and returns the result.
XOR ^	Exclusive logical sum	Obtains the exclusive logical sum of the values of the first and second terms on each bit, and returns the result.
Shift operator		
SHR >>	Right shift	Shifts the value of the first term by the value (number of bits) of the second term to the right, and returns the result. As many 0s as the number of shifted bits are inserted in the higher bits.
SHL <<	Left shift	Shifts the value of the first term by the value (number of bits) of the second term to the left, and returns the result. As many 0s as the number of shifted bits are inserted in the lower bits.
Byte separation operator		
HIGH	Higher byte	Of the lowest 16 bits of the term, returns the higher 8 bits.
LOW	Lower byte	Of the lowest 16 bits of the term, returns the lower 8 bits.
Word separation operator		
HIGHW	Higher word	Of the 32 bits of the term, returns the higher 16 bits.
LOWW	Lower word	Of the 32 bits of the term, returns the lower 16 bits.
Other		
(Left parenthesis	Performs the operation in () before the operation outside (). '(' and ')' are always used in pairs.
)	Right parenthesis	

Rules of operation

Operations are performed according to the priority of the operators.

Table A-5 Operator Priority

Priority	Operators
1 Higher	(,)
2	+ sign, - sign, NOT, , HIGH, LOW, HIGHW, LOWW
3	*, /, MOD, %, SHR, >>, SHL, <<
4	+, -
5	AND, &
6 Lower	OR, , XOR, ^

- If the priorities of the operators are the same, the operation is performed from the left toward the right.
- Performs the operation in () before the operation outside ().
- Each term in an operation is treated as unsigned 32-bit data.
- All operation results are treated as unsigned 32-bit data.
- If an overflow occurs during operation, the lower 32 bits are valid, and the overflow is not detected.

Terms

To describe a constant for a term, the following numeric values can be described.

Table A-6 Range of Radixes

Radix	Range
Binary number	0Y <= value <= 11111111111111111111111111111111Y (32 digits)
Octal number	0O <= value <= 37777777777O
Decimal number	-2147483648 <= value <= 4294967295 (A negative decimal number is internally converted into a 2's complement.)
Hexadecimal numbers	0H <= value <= 0FFFFFFFH

A. 5 File Names

The following rules apply to source file names and execution module file names.

- 1 Source file names and execution module file names consist of any combination of A to Z, a to z, _ (underbar), and 0 to 9.
- 2 Uppercase characters (A to Z) and lowercase characters (a to z) are not distinguished.

APPENDIX B EXPANSION WINDOWS

This chapter explains the following item about Expansion Window.

- Overview
- Activation
- Explanation of each sample window

B. 1 Overview

With the ID78K4-NS, the user can create custom windows in addition to the existing windows.

The Tcl (Tool Command Language) interpreter and the commands for controlling the debugger are implemented in the ID78K4-NS. Users can create windows using this Tcl.

The ID78K4-NS is supplied with samples of the following expansion windows.

Table B-1 List of Expansion Window

Window Name	Function
List window	Displays a list of the source files and functions.
Grep window	Searches a character string.
Hook window	Sets the hook procedure.

Caution When the ID850 (SP850 Ver.3.0 or later) is installed, the "RRM Window" and "Memory Mapped I/O Window" can be selected. However, these windows cannot be used in the ID78K4-NS.

B. 2 Activation

The expansion window can be activated by selecting List, Grep, RRM, Hook, or Memory in [Others] on the [Browse] menu.


Reference Each .tcl file is installed in NECTools32\BIN\idctl\tools.

B. 3 Explanation of each sample window

List window

The lists of the source files and functions are displayed in a tree format in this window. When a function name in the list is clicked, the corresponding source is displayed.

Figure B-1 List Window




Grep window

Search for a character string is performed in the files under the source path.

When the search result is clicked, the corresponding source is displayed.

Figure B-2 Grep Window



Object	Function
Pattern	Input the character string to be searched.
<Mark> button	Marks the searched character string.
<Clear> button	Clears the marking
<Jump> button	Put the cursor on a section in the search result and click this button to open the corresponding file
Match Case	Select whether or not to distinguish uppercase and lowercase.
Filter	Specify the type of the file to be searched.

Hook window

This window is used to set a hook to the debugger, using a hook procedure.

The hook procedure enables changing the register value before downloading a program, or after a CPU reset.

On this window, a hook can be set by using the following four tabs.

[BeforeDownload] tab: Hook before downloading

[AfterCpuReset] tab: Hook after CPU reset

[BeforeCpuRun] tab: Hook before start of execution

[AfterCpuStop] tab: Hook after break


By setting a SFR by using the [BeforeDownload] tab before downloading the load module, for example, downloading can be executed at high speeds. Access to the external memory is also facilitated by using this tab.

In addition, please make reference Following URL (microcomputer home page FAQ) about a setup of SFR.

<http://www.necel.com/micro/>

If the setting is saved as "project-file-name.tcl" in the directory where the project is stored, the setting is executed when the project is next opened.

Figure B-3 Hook Window



Object	Function
[BeforeDownload] tab	Hook before downloading Before downloading is performed, the register values input to the tab are automatically overwritten by the specified value.
[AfterCpuReset] tab	Hook after resetting CPU after resetting CPU, the register values input to the tab are automatically overwritten by the specified value.

Object	Function
[BeforeCpuRun] tab	Hook before starting execution before starting execution, the register values input to the tab are automatically overwritten by the specified value.
[AfterCpuStop] tab	Hook after breaking After breaking, the register values input to the tab are automatically overwritten by the specified value.
<Test> button	All the commands described on the tabs are tested.
<Save> button	Saves all the tab contents to a file. If the ID78K4-NS was activated from a project file, the file is saved as "project-file-name.tcl".
<Clear> button	Clears all the descriptions on the tabs.

Caution Specify the program register and the SFR for the register name.

APPENDIX C TERMINOLOGY

The major terms used throughout this manual are as follows:

- Current window
- Delimiter (separator)
- Program
- File
- Function
- Structure
- Stack frame number
- Line

C. 1 Terminology

Current window

The current window is the window you are now in and operating by means of key input and menu selection.

Delimiter (separator)

The following separators can be used as the delimiter of file names, function names, variable names, and line numbers.

Table C-1 Delimiter

Delimiter	Meaning
#	Used as a separator of file names, variable names, function names, and line numbers.
\$	Used as a separator of load module names, file names, variable names, and function names.

Program

A program is the execution unit to be debugged. The debugger manages each one of the load module files specified on downloading as a program.

To specify a program name, use a load module file name on downloading.

Current program

The current program is the program that contains the instruction currently breaking execution (instruction indicated by the PC).

When specifying a file in the current program, the program name may be omitted.

File

Up to 127 characters can be handled in a file name with path.

Depending on the type of file, however, a file name of more than 127 characters can be specified.

Current file

The current file is the source file that contains the instruction currently breaking execution (instruction indicated by the program counter (PC)).

When specifying a line or function in the current file, the file name may be omitted.

Function

Indicates the functions constituting a C source program.

Current function

The current function is the function that contains the instruction currently breaking execution (instruction indicated by the program counter (PC)).

When accessing a local variable in the current function, specifying the function name may be omitted.

Structure

Structures and unions in C language are called structures.

The name structure is used if a structure or union variable is used without members explicitly specified.

Stack frame number

The stack frame number is a decimal integer starting from 1 and is assigned to the stack contents. The shallower the nesting level of the stack, the higher the number. A function having a stack number one less than that of a certain function is the function that calls the certain function.

Line

A line is specified in order to identify one line in the source file.

Specify a line number as an integer constant, starting from 1.

APPENDIX D MESSAGES

This appendix explains the messages displayed in the Error/Warning dialog box of the debugger.


D.1 Error/Warning Messages from

D. 1. 1 Display format of

Messages are generated and output to the Error/Warning dialog box when "information that should be informed to users (fatal error, syntax error, and warning or questions)" is detected while the debugger is executing processing.

The product name is displayed on the title bar of the dialog box.

Figure D-1 Error/Warning Messages



There are three types of messages in the debugger (fatal error message, syntax error message, and warning message or question message).

A : Fatal error messages

When a fatal error is detected in the debugger, a message is output to the Error dialog box before aborting the processing and terminating the debugger.

F : Syntax error messages

When a syntax error is detected in the debugger, a message is output to the Error dialog box before aborting the processing. At this time, opened windows and dialog boxes are closed.

W : Warning message or question message

When a warning or question is detected in the debugger, a message is output to the Warning dialog box before aborting the processing.

D. 1. 2 Fatal error messages

A list of the messages that are output when fatal errors are detected while the debugger is executing processing is shown below in numerical order.

Table D-1 Fatal error messages

Error No.	Message
A0101	Can not find initialization file (expc.ini).

Table D-1 Fatal error messages

Error No.	Message
A0102	Host name not found.
A0105	Failed in reading device file (d4xxx.78k). Necessary files may be damaged. Reinstall the device file.
A0106	Illegal data received. Countermeasure Check the power of the in-circuit emulator, cable connections, and setting of the interface board and restart the debugger.
A01a1	Failed in reading EX78K4.OM0.
A01a2	Break board is not connected.
A01a3	Emulation board is not connected.
A01a4	Board configuration of ICE is not consistent.
A01a5	POD/EM1 board is not connected.
A01a6	Executor is running.
A01a7	Failed in reading micro program file (m4xxx.78k).
A01a8	Failed in reading initialization file (expc.ini).
A04a1	Not enough memory for emulation.
A0600	Not enough memory for buffer. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A1000	Failed in initializing ICE.
A1001	No entry exists for specified number.
A1002	Can not relocate internal RAM.
A1005	Illegal relocation address.
A1007	Not enough memory on ICE.
A1008	Not enough memory for tables. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A1009	Already initialized.
A100a	Not initialized.
A10ff	Can not communicate with ICE.
A1dbe	Error occurred inside debugger.
A2001	Illegal address.
A2009	Device file is damaged or error is in file.
A200b	Can not copy.
A200c	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A20ff	Can not communicate with ICE.
A2222	Illegal condition.
A3012	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.

Table D-1 Fatal error messages

Error No.	Message
A30ff	Can not communicate with ICE.
A4011	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A4018	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A5000	Illegal device file type.
A5001	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A5002	Can not open device file.
A5003	Reading of device file went wrong.
A5004	Can not close device file.
A5005	Illegal device file format. Countermeasure Necessary files may be damaged. Reinstall the device file.
A5006	Failed in initializing ICE.
A5007	Device file has broken or error is in a file.
A500c	Failed in reading expc.ini.
A500d	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A5300	Illegal device file type.
A5301	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A5302	Can not open database file. Countermeasure Necessary files may be damaged. Reinstall the and device file.
A5303	Reading of database file went wrong.
A5304	Can not close database file.
A5305	Illegal database file format. Countermeasure Necessary files may be damaged. Reinstall the debugger or simulator, and device file.
A5306	Database information has been already initialized.
A5307	Database information does not exist.
A7012	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
A70fe	Bus hold error. Countermeasure CPU is in the bus-hold status. Reset the debugger.
A70ff	Can not communicate with ICE.
A7f03	Failed in canceling RUN/STEP.
A9000	Specified register symbol does not exist.

Table D-1 Fatal error messages

Error No.	Message
A9001	Specified register symbol ID does not exist.
A9003	Illegal condition.
A9004	Too large register size.
Aa005	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
Aa00b	Can not close file.
Aa00c	Failed in reading file. Countermeasure The file is damaged or does not exist. Recreate the file.
Aa010	Can not communicate with ICE.
Aa013	Reading of file went wrong.
Ab009	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
Ab00d	Current function does not exist.
Ab00e	Current line does not exist.
Ab00f	Tag not found.
Ab010	Failed in loading symbol table.
Ab011	Illegal line number.
Ab015	Reading of file went wrong. Countermeasure The file is damaged or does not exist. Recreate the file.
Ab016	Can not open file. Countermeasure The file is damaged or does not exist. Recreate the file.
Ab017	Failed in writing file. Countermeasure The file is damaged or does not exist. Recreate the file.
Ab019	Reading of file went wrong.
Ab01a	Can not close file.
Ab01c	Too many entries of the task kind .
Ab023	Current stack frame is not active.
Ab024	Different section.
Ab02a	Can not communicate with ICE.
Ab030	Monitor timed out. Countermeasure Check the power of the in-circuit emulator, cable connections, and setting of the interface board and restart the debugger.
Ab031	Already set in memory.
Ab032	Out of scope.
Ab033	LP is not stored.
Ab039	Failed in loading debug information.
Ab03a	No more section information.
Ab041	Specified file is not load module.

Table D-1 Fatal error messages

Error No.	Message
Ac002	Can not close file.
Ac003	Reading of file went wrong. Countermeasure The file is damaged or does not exist. Recreate the file.
Ac004	Reading of file went wrong.
Ac009	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
Ac010	Can not communicate with ICE.
Ad000	Error occurred inside debugger.
Ad001	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.
Ad002	Failed in reading initialization file (expc.ini).
Ad003	ICE is not connected.
Ae008	Not enough memory Countermeasure There is not enough system memory. Close the applications being executed and the open files.
Af000	Not enough memory. Countermeasure There is not enough system memory. Close the applications being executed and the open files.

D. 1. 3 Syntax error messages

A list of the messages that are output when syntax errors are detected while the debugger is executing processing is shown below in numerical order.

Table D-2 Syntax error messages

Error No.	Message
F0002	This feature is not supported.
F0100	Can not communicate with ICE. Please confirm the installation of the device driver for the PC interface board.
F0103	Data transfer to ICE is timed out. Please confirm the power of ICE, connection of the interface cable, or I/O address of the PC interface board.
F0104	Data receive from ICE is timed out. Please confirm the power of ICE, connection of the interface cable, or I/O address of the PC interface board.
F01a0	No response from the emulation CPU. Please confirm the signal.
F0200	No mapped address was accessed. Countermeasure External memory could not be accessed, as it is not set. Change the register values necessary for accessing the external memory using the SFR window or Hook Procedure before download.
F02a0	Bus hold error. Countermeasure CPU is in the bus-hold status. Reset the debugger.
F02a2	CPU is in the bus-hold status. Reset the debugger.
F0300	User program is running.

Table D-2 Syntax error messages

Error No.	Message
F0301	User program is being breaked.
F0302	User program is being traced.
F0303	Not traced.
F0304	Trace memory is not set.
F0306	No trace block exists.
F0307	No event condition exists.
F0308	No timer measurement is done.
F0309	No trigger frame exists.
F030a	Tracer is being stopped.
F030b	Specified snap-event has not been registered.
F030c	Specified stub-event has not been registered.
F030d	Timer is running.
F030e	Memory copy area is overlapped.
F030f	Trace has been already set.
F0310	Event condition is not set.
F0311	Too many valid timer event conditions.
F0312	Specified timer event is not set.
F0313	illegal map range. Countermeasure Check the setting in "Memory Mapping (mapping setting area)" in the Configuration dialog box. When mapping to external memory has been performed, change the register values necessary for accessing the external memory using the SFR window or Hook Procedure before download.
F0315	Delay trigger cannot set with trace full mode.
F03a1	Step execution is being done.
F03a2	Timer and Tracer are running.
F03d2	Back-trace execution point overrun oldest frame.
F03d3	Register status or Memory status cannot be set up other than Phase1 of event link.
F03d4	No back-trace information exists.
F03d5	Last command can not be backstepped.
F0400	Illegal condition. Countermeasure Settings of the used in-circuit emulator and those of the Configuration dialog box may not match. Check the Chip selection of "Chip (Emulation CPU selection area)".
F0401	Result of timer measurement overflowed.
F0402	Too many event conditions with pass count.
F0403	Too many address range conditions.
F0404	Too many simultaneously-usable-event conditions.
F0405	Too many snap-events.
F0406	Too many stub-events.

Table D-2 Syntax error messages

Error No.	Message
F0407	Too many initialization data.
F0408	Too large search data (> 16 byte).
F0409	Too large search data (> search range).
F040a	Too many Linking-event conditions.
F04a0	Too many software breaks (> 100).
F04a2	Too many partition of bus size.
F04a3	Too many execution-event conditions.
F04a4	Too many bus-event conditions.
F0b00	Cannot open FPGA file(GXXXX.78K).
F0b01	Error is in form of FPGA file(GXXXX.78K).
F0b02	FPGA board Broken.
F0b03	No match device file of version.
F0b04	Target power mode mismatch.
F0b20	This event number can not be used.
F0b21	Timeout break condition has not set up.
F0b22	Timer event condition has not set up.
F0b23	Specified event has been already used at option/main.
F0b24	Cannot use the delay count and the software breaks at the same time.
F0b40	Can not execute specified tracer.
F0b60	External Trigger event conditions overflow.
F0b61	Section Trace event conditions overflow.
F0b62	Break before execute event conditions overflow.
F0b63	Specified event has been already use.
F0b64	Event conditions number overflow.
F0b65	Option/Main event conditions overflow.
F0b80	Reset by hardware error.
F1003	Illegal relocation address.
F1004	Illegal condition
F1006	Illegal address.
F100b	User program is running.
F100c	Different bus size has been already specified.
F100d	Too large bus size.
F100e	Too large bus partition size.
F100f	Target is not turned on.
F1010	Illegal map range.
F1011	Failed in setting internal ROM and RAM.

Table D-2 Syntax error messages

Error No.	Message
F1012	This feature is not supported.
F1013	No terminal name.
F1017	I/O Protect mapping is possible a target attribute only.
F1018	Illegal Internal ROM size.
F1019	Illegal Internal ROM size or Internal RAM size.
F2000	Illegal SFR name.
F2002	User program is running.
F2003	Illegal SFR number.
F2004	Illegal bit number.
F2006	Hidden SFR was specified.
F2007	SFR of ban read/write was specified.
F2008	SFR not existing was specified.
F200a	Illegal value specified for SFR.
F3000	<p>No mapped address was accessed.</p> <p>Countermeasure The allocation addresses of the program and the addresses of the debugger may not match. Set the mapping to the external memory in "Memory Mapping (mapping setting area)" in the Configuration dialog box according to the allocation addresses specified in the link directive file on compilation. When mapping to external memory has been executed, change the register values necessary for accessing the external memory using the SFR window or Hook Procedure before download.</p>
F3001	Memory has different value.
F3002	Illegal start address.
F3003	Illegal end address
F3004	Illegal start address and end address.
F3005	Illegal condition.
F3006	User program is running.
F3007	Verification error.
F3008	No condition specified.
F3009	Parameter size does not align with access size alignment.
F300a	Specified address does not align with access size alignment.
F300b	Source address does not align with access size alignment.
F300c	Destination address does not align with access size alignment.
F300d	Illegal end address.
F300e	Different access size in specified area.
F300f	Different access size both in source and destination areas.
F3010	Different access size in destination area.
F3011	Different access size, source & destination.
F3013	Failed in writing DMM.

Table D-2 Syntax error messages

Error No.	Message
F3014	Overflowed mapping area.
F3015	Processing was interrupted.
F3016	This feature is not supported.
F4000	Can not delete specified event. Countermeasure The specified event cannot be deleted as it is being used under another condition. Invalidate it for other usages before deleting.
F4001	Illegal table number.
F4002	Illegal start address.
F4003	Illegal end address.
F4004	Illegal status.
F4005	Illegal data.
F4006	Specified event number has been already used.
F4007	Too many same events are registered.
F4008	Specified event has not been registered.
F4009	Illegal data size.
F400a	Illegal mode.
F400b	Setting value is inaccurate.
F400c	Event link conditions cannot be used for section trace conditions.
F400d	Too many identical events are registered (≥ 32767).
F400e	Specified event condition does not exist.
F400f	Illegal event link condition.
F4010	Function not found.
F4012	Timer is being disabled.
F4014	Can not use software break.
F4015	Can not use event condition specifying address range.
F4016	Can not change event condition.
F4017	Can not access word at odd address.
F4019	This feature is not supported.
F401a	No Event.
F401b	Can not use tag-event.
F401d	Start event and end event of timer are not made to the same setup.
F401e	Too many trace-events.
F401f	Pass count cannot be set up.
F4020	Address range cannot be set up in event before execution.
F4021	Event conditions number overflow.
F4022	Software DMM conditions number overflow.
F4023	Real-time call conditions number overflow.

Table D-2 Syntax error messages

Error No.	Message
F4024	Software break call conditions number overflow.
F4318	Illegal memory bank setting.
F5008	Can not open device file. Countermeasure Necessary files may be damaged. Reinstall the device file.
F5009	Can not open EX78K4.OM0.
F500a	Specified device file is illegal version. Countermeasure Necessary files may be damaged. Reinstall the device file.
F5308	Can not open specified database file. Countermeasure Necessary files may be damaged. Reinstall debugger or simulator.
F5309	Specified database file is illegal version. Countermeasure Necessary files may be damaged. Reinstall the debugger or simulator, and the device file.
F6000	Current function does not exist.
F6001	Illegal symbol name.
F6002	Illegal condition.
F6003	Illegal function name.
F6004	Overflowed output buffer size.
F6005	Illegal expression.
F7000	Illegal mode.
F7001	User program is running.
F7002	User program has been stopped.
F7003	Trace enabled.
F7004	Trace memory is not set.
F7005	Function return address does not exist, can not do step execution.
F7801	End waiting state of step execution was canceled.
F7802	End waiting state of step execution was canceled.
F7f00	Aborted step execution.
F7f02	Suspended step execution.
F7f04	Can not execute non-mapped area.
F7f05	This feature is not supported.
F8000	Specified file was not found.
F8001	Illegal line number.
F8002	Current information is not set.
F8003	Illegal address.
F8004	This feature is not supported.
F9002	Illegal value.
F9005	This feature is not supported.
Fa001	Illegal expression.

Table D-2 Syntax error messages

Error No.	Message
Fa002	Start address is bigger than the end address.
Fa003	Illegal source path.
Fa004	Too long expression.
Fa006	Illegal argument.
Fa007	Illegal program number.
Fa008	Source path is not set.
Fa009	File not found.
Fa00a	Can not open file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fa00d	Not source file of load module.
Fa00e	Illegal line number.
Fa00f	Variable does not exist.
Fa011	Can not access register.
Fa012	Can not access memory.
Fa014	It was going to open the binary file.
Fa015	Can not get temporary path. Countermeasure The disk is full. Delete or move unnecessary files and increase the available memory in the disk.
Fa016	Can not create temporary file. Countermeasure The disk is full. Delete or move unnecessary files and increase the available memory in the disk.
Fa017	Can not remove temporary file.
Fa020	This feature is not supported.
Fa021	Symbol assigned to register cannot be specified.
Fb000	Illegal command line.
Fb001	Program information does not exist in specified load module file.
Fb002	File not found.
Fb003	Function not found.
Fb004	Selected load module different from kind(Chip) was loaded.
Fb005	Symbol not found. Countermeasure The address could not be found. Specify a location holding address information.
Fb008	Illegal expression.
Fb00a	Illegal symbol in load module file.
Fb00b	Current program does not exist.
Fb00c	Current file does not exist.
Fb012	Too large line number.
Fb01b	Too long load module file name.
Fb01d	Address not found.

Table D-2 Syntax error messages

Error No.	Message
Fb01f	Can not find structure member.
Fb020	Can not find value.
Fb021	No debug information exists in load module file. Countermeasure To create a load module with appended debug information, execute build in build mode of Debug Build.
Fb022	Illegal line number.
Fb026	Too many array dimensions (> 4).
Fb027	Found end of file. Countermeasure The specified file may be damaged. Recreate the file.
Fb028	This feature is not supported.
Fb029	Illegal address.
Fb02b	Can not stack trace with current PC value.
Fb02c	Too many blocks for one function.
Fb02d	Illegal argument.
Fb02e	The file does not exist in the SOURCE PATH. Countermeasure On stopping the program, the source that the debugger tried to display could not be found. Check if the path connects to the source (using "Source Path (source path specification area)" in the Debugger Option dialog box), or check if the source is in the same directory as the out file. Refer to the Assemble window on which the error message is displayed, and check if the corresponding path connects.
Fb02f	Information has been deleted because of optimization.
Fb034	Return execution from present PC position cannot be performed.
Fb037	Too Many Line-Numbers Information.
Fb038	Compiler version mismatch. Countermeasure Recreate the load module with the latest compiler.
Fb040	Specified file is not load module. Countermeasure This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker.
Fb32e	Illegal port number.
Fb32f	Illegal port name.
Fb330	Illegal port position.
Fb331	Illegal increment number.
Fb332	Port for memory bank is not set.
Fb333	Illegal bank number.
Fb334	Area for memory bank is not set.
Fc001	Can not open file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fc005	Illegal file type.
Fc006	Kind(Chip) of load module is illegal.

Table D-2 Syntax error messages

Error No.	Message
Fc007	Specified file is not load module. Countermeasure This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker.
Fc008	Specified load module file (COFF) is old version.
Fc00a	No mapped address was accessed.
Fc00b	Load module is not loaded.
Fc00c	Illegal argument.
Fc00d	User program is running.
Fc00e	User program is being traced.
Fc00f	Interrupted.
Fc011	Illegal load module file format.
Fc012	Check sum error.
Fc013	Too wide address range to upload (> 1M byte).
Fc014	Failed in writing file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fc015	Illegal program number.
Fc016	Load information is full.
Fc018	Specified file is not load module. Countermeasure This is not a linker output file. Source debug cannot be executed with the load module before output from the linker. Specify the load module output from the linker.
Fc019	Failed in writing memory.
Fc01a	No mapped address was accessed.
Fc100	This feature is not supported.
Fd004	Can not find Dynamic Link Library.
Fe000	Illegal argument.
Fe001	Illegal start address.
Fe002	Illegal end address.
Fe003	Too large size.
Fe004	Can not open file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fe005	Failed in reading file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fe006	Reading of file went wrong.
Fe007	Failed in writing file. Countermeasure The file is damaged or does not exist. Recreate the file.
Fe009	Illegal file format.
Fe00a	Verification error.
Fe010	This feature is not supported.
Ff001	[XXX] not found.

Table D-2 Syntax error messages

Error No.	Message
Ff004	Missing parameter.
Ff005	Illegal function name.
Ff006	Illegal number.
Ff007	Start address is bigger than end address.
Ff008	Illegal symbol or expression.
Ff009	[XXX] This file is illegal type.
Ff100	Disk cannot write or full.
Ff101	File not found.
Ff102	File not Create.
Ff103	Old project file version.
Ff104	Illegal project file format.
Ff105	This file is a project file for [XXX].Please select a correct file.
Ff201	Memory mapping error.
Ff202:	Verify error. Countermeasure External memory could not be accessed, as it is not set. Change the register values necessary for accessing the external memory using the SFR window or Hook Procedure before download.
Ff301	The symbol being used on the event condition can't be evaluated.
Ff306	This name is too long.
Ff307	There is the same name in other kinds.
Ff308	An address can't be omitted.
Ff309	Illegal address mask.
Ff30a	Illegal data mask.
Ff30b	Illegal ext probe mask.
Ff30c	Illegal ext probe data.
Ff30d	Illegal pass count.
Ff30e	Illegal register name.
Ff310	Illegal delay count.
Ff312	[XXX] is already there.
Ff313	Event number already exist.
Ff314	Event name is not set.
Ff315	[XXX] is already there.
Ff316	Max number of enabled [XXX] event is over. Please disable other enabled [YYY] event.
Ff317	Max number of set event is over.
Ff31e	Illegal start address.
Ff31f	Illegal end address.
Ff322	Illegal count rate.
Ff324	Section and Qualify can not be specified at the same time.

Table D-2 Syntax error messages

Error No.	Message
Ff350	There is a phase which event are not in the middle.
Ff351	The same event is contained in Link and Disable.
Ff352	An event isn't specified.
Ff357	AND event is in Phase.
Ff500	Illegal symbol.
Ff501	Illegal value.
Ff502	Illegal parameter.
Ff503	Max number of symbol is over.
Ff504	<p>This variable cannot be set as a break.</p> <p>Countermeasure Break cannot be set for the following variables.</p> <ul style="list-style-type: none"> • Local variables, static variables • Array variables, member variables of structures/unions • Register/SFR • Variable expressions
Ff802	All events are deleted. because the use of external probe was changed.
Ff803	This event address is invalid on current configuration.
Ff804	Invalid PC value.
Ff805	Cannot set temporary break on this address.
Ff806	External data is being used by Debugger.
Ff900	Illegal I/O port name.
Ff901	<p>Memory mapping error.</p> <p>Countermeasure The specification of the address is illegal. The addresses that can be specified are in either the Target area or SFR area. Check in "Address: (I/O port address specification area)" in the Add I/O Port dialog box.</p>
Ff902	Illegal access size.
Ff903	Illegal access type.
Ff904	There is the same name.
Ffa00	<p>The [XXX] function of current program in PC position not found.</p> <p>Countermeasure The symbol specified in main() label: in "Startup Routine (start-up symbol setting area)" in the Debugger Option dialog box could be found. Set a symbol of the main routine of the program. Default is _main.</p>
Ffa01	<p>The line information on PC position not found.</p> <p>Countermeasure The source file corresponding to program counter (PC) value when the program was stopped could not be found. The following reasons are possible.</p> <ol style="list-style-type: none"> 1 The source file exists in a location that the source path does not connect to. 2 The program stopped where the source files, such as library or RX, do not exist. 3 The program looped, jumped to an address that is not used by the program, and stopped there.

Table D-2 Syntax error messages

Error No.	Message
Ffc00	Help window cannot be started. Please install HTML Help environment with reference to a users manual.
Ffff	Interrupted.

D. 1. 4 Warning message or question message

A list of the messages that are output when warnings or questions are detected while the debugger is executing processing is shown below in numerical order.

Table D-3 Warning message or question message

Error No.	Message
W03a0	Target is not turned on.
W1014	Data is not exist.
W2005	SFR of Read Protect attribute was specified.
W200d	No initialize data for SFR.
W4013	Access size is different from its mapped bus size.
W401c	Software break can not be set on this area.
W500b	Specified device file does not relocate IRAM.
W7010	No source information exists.
W7011	Unknown result of step execution.
Wb01e	No debug information (not compiled in Debug Build mode).
Wb036	Out of variable region.
Wb042	Symbol module is not initialized.
Wb335	Too long symbol name.
Wc017	Symbol information is duplicated, please reset symbols.
Wc01d	Selected load module different from kind(Chip) was loaded.
Wf002	Not found [XXX]. Search from the beginning?
Wf003	Already exceed search region.
Wf106	CPU in the Project File was Changed. You must exit the debugger for the new CPU. Do you exit the Debugger?
Wf107	CPU in the Project File was Changed. Do you start the Debugger with this CPU?
Wf108	Selected project file different [YYY] from chip [XXX] was opened. Does it open, although the chip cannot be changed?
Wf109	Project Manager cannot be used with the debugger of this version. Please use PMplus.
Wf200	No differences encountered.
Wf203	When a program is running, while rewriting a memory, program execution stops for a moment. Do you wish to rewrite a memory?
Wf300	Would you like to save the changes made in [XXX]?
Wf302	Delete: [XXX]

Table D-3 Warning message or question message

Error No.	Message
Wf303	[XXX] is edited. Delete: [YYY]?
Wf304	[XXX] is edited. Save: [YYY]?
Wf305	[XXX] is already exist. Do you replace it?
Wf311	Only one [XXX] can be enabled. Do you make this [YYY] to enable?
Wf600	Save project file?
Wf601	When connecting the target system, please turn on the target system. Countermeasure When a target is not connected, simply click the <OK> button.
Wf602	Please change a MODE mask condition or connect the target system.
Wf700	Do you want to download Load Module File?
Wf905	[XXX] is already exist. Do you replace it?
Wf906	Would you like to register the change made in [XXX]?
Wfb00	User program is running. Do you want to stop user program?
Wfe0b	It shift to the flash mode. Is it completely cleared but is the present event.

APPENDIX E KEY FUNCTION LIST

Debugging can be efficiently executed by using special function keys.

Note that, in the following explanation, ordinary key representation (generic key representation) is used because the key representation differs depending on the type of keyboard.

Table E-1 through Table E-8 list the functions of the respective keys.

E. 1 Function List of Special Function Keys

Table E-1 Function List of Special Function Keys

Key	Function
BackSpace	Deletes one character before the cursor and moves the cursor to the position of the deleted character. At this time, the character string following the cursor moves forward.
Delete	Deletes one character after the cursor and move the character string following the cursor forward. Deletes a various event condition selected in the Event Manager or each event dialog box. Deletes the data selected in the Watch window.
Insert	Alternately selects the insert mode and overwrite mode in the Source window and Assemble window. However, this key is invalid in the Memory, Register, and SER windows, and only the overwrite mode can be used as an input mode.
PrintScreen	Loads the entire display screen to the clipboard as a bitmap image (function of Windows).
Esc	Closes the pull-down menu. Closes the modal dialog box. Restores the input data.
Alt	Moves the cursor to the menu bar.
End	Moves the cursor to the end of the line.
Home	Moves the cursor to the beginning of the line.
PageUp	Scrolls the screen one screen up. The cursor also moves up to the top of the screen.
PageDown	Scrolls the screen one screen down. The cursor also moves up to the top of the screen.
Space	Inserts one blank character.
Tab	Moves the cursor to the next item.
Up arrow key	Moves the cursor up. If the cursor is at the bottom of the screen, scrolls the screen up one line at a time.
Down arrow key	Moves the cursor down. If the cursor is at the top of the screen, scrolls the screen down one line at a time.
Right arrow key	Moves the cursor to the left. If the cursor is at the leftmost position on the screen, scrolls the screen one column to the right.

Table E-1 Function List of Special Function Keys

Key	Function
Left arrow key	Moves the cursor to the right. If the cursor is at the rightmost position on the screen, scrolls the screen one column to the left.
Enter	Sets the input data. Presses the default push button.

E. 2 Function List of Function Keys

Table E-2 Function List of Function Keys

Key	Function
F1	Opens the Help window.
F2	Forcibly stops program execution. Same function as [Run] -> [Stop] on the menu bar.
F3	Resets the emulation CPU. Same function as [Run] -> [CPU Reset] on the menu bar.
F4	Resets the emulation CPU and executes the program. Same function as [Run] -> [Restart] on the menu bar.
F5	Executes the program. Same function as [Run] -> [Go] on the menu bar.
F6	Executes the program to the cursor position in the Source or Assemble window. Same function as [Run] -> [Come Here] on the menu bar
F7	The user program is real-time executed until execution returns. Same function as [Run] -> [Return Out] on the menu bar
F8	Step execution. Same function as [Run] -> [Step In] on the menu bar.
F9	Sets a breakpoint at cursor position in Source or Assemble window. Same function as [Run] -> [Break Point] on the menu bar.
F10	Next step execution. Same function as [Run] -> [Next Over] on the menu bar.
F11	Sets or deletes a software breakpoint. Same function as [Run] -> [Software Break Point] on the menu bar .

E. 3 Function List of Special Function Keys (Shift + key)

Table E-3 Function List of Special Function Keys (Shift + key)

Key	Function
End	Expands the selection range to the end of the line.
Home	Expands the selection range to the beginning of the line.
Left arrow key	Expands the selection range one character to the left.

Table E-3 Function List of Special Function Keys (Shift + key)

Key	Function
Right arrow key	Expands the selection range one character to the right.

E. 4 Function List of Function Keys (Shift + key)

Table E-4 Function List of Function Keys (Shift + key)

Key	Function
F6	Executes the program from the cursor position in the Source or Assemble window. Same function as [Run] -> [Start From Here] on the menu bar.
F9	Resets the emulation CPU. Same function as [Run] -> [CPU Reset] on the menu bar.

E. 5 List of Special Function Keys (Ctrl + key)

Table E-5 List of Special Function Keys (Ctrl + key)

Key	Function
End	Displays the last line. The cursor will also move to the last line.
Home	Displays the first line. The cursor will also move to the first line.
Left arrow key	Moves the cursor one word to the left. If the cursor at the leftmost position on the screen, scrolls the screen one column to the right.
Right arrow key	Moves the cursor one word to the right. If the cursor at the rightmost position on the screen, scrolls the screen one column to the left.

E. 6 Function List of Function Keys (Ctrl + key)

Table E-6 Function List of Function Keys (Ctrl + key)

Key	Function
F5	Ignores break points being set, and executes the program. Same function as [Run] -> [Ignore break points and Go] on the menu bar.
F9	Sets the address at the cursor position in the Source window or Assemble window to the PC. Same function as [Run] -> [Change PC] on the menu bar.

E. 7 Function List of Control Keys (Ctrl + key)

Table E-7 Function List of Control Keys (Ctrl + key)

Key	Function
A	Selects all the events registered to the Event Manager. Same function as [View] -> [Select All Event] on the menu bar in the Event Manager.
C	Copies a selected character string and saves it to the clipboard buffer.
D	Disassembles and displays the results from the jump destination address specified by the data value selected in the current window. Opens the Assemble window. Same function as [Jump] -> [Assemble] on the menu bar.
E	Opens the source file displayed in the active Source window with the editor specified by the PM plus when the PM plus is running. Same function as [Edit] -> [Edit Source] on the menu bar.
G	Performs a search. Opens the search dialog box corresponding to the current window. Same function as [View] -> [Search...] on the menu bar.
J	Moves the display position. Opens the Source Move, Address Move, or Trace Move dialog box, depending on the current window. Same function as [View] -> [Move...] on the menu bar.
M	Displays the memory contents from the jump destination address specified by the data value selected in the current window. Opens the Memory window. Same function as [Jump] -> [Memory...] on the menu bar.
O	Loads a view file, source file, or text file. Opens the View File Load dialog box. The operation will differ depending on the extension of the file. view file: Displays the file in the corresponding window. Others: Displays the file in the Source window. Same function as [File] -> [Open...] on the menu bar.
S	Saves the data displayed in the current window to the view file. Same function as [View] -> [Save...] on the menu bar.
U	Displays the corresponding source text and source line, using the data value selected in the current window as the jump destination address. Opens the Source window. Same function as [Jump] -> [Source Text] on the menu bar.
V	Pastes the contents of the clipboard buffer to the text cursor position.
W	Temporarily displays the contents of the specified data. Opens the Quick Watch dialog box. Same function as [View] -> [Quick Watch...] on the menu bar.
X	Cuts a selected character string and saves it to the clipboard buffer. Same function as [Edit] -> [Cut...] on the menu bar.

E. 8 List of Special Function Keys (Ctrl + Shift + key)

Table E-8 List of Special Function Keys (Ctrl + Shift + key)

Key	Function
Left arrow key	Expands the selection range one word to the left.

Table E-8 List of Special Function Keys (Ctrl + Shift + key)

Key	Function
Right arrow key	Expands the selection range one word to the right.

APPENDIX F INDEX

A

About dialog box ... 257
Active status ... 33
Add I/O Port dialog box ... 195
Add Watch dialog box ... 168
address ... 262, 270
Address Move dialog box ... 103
All trace ... 26
ASCII display ... 143
assemble ... 262, 271
Assemble Search dialog box ... 138
Assemble window ... 131
Auto Load ... 82
Auto load ... 18, 71
Auto save ... 71, 80

B

Balloon watch function ... 28, 119, 162
batch ... 262, 272
Break dialog box ... 239
Break function ... 24
breakpoint ... 262, 273
Breakpoint for read/write access ... 162
Breakpoint setting/deletion function ... 116
Browse dialog box ... 101
Build mode ... 17

C

Callback procedure ... 265
Cause of stopping tracer ... 202
Change Watch dialog box ... 172
Character set ... 303
Color of character on event mark ... 217
Come function ... 21, 24, 123
Command ... 12, 261
Command line ... 262
Command list ... 262
Command reference ... 262
Compulsion read ... 187, 189
conditional trace ... 26
Configuration dialog box ... 15, 59
Console window ... 261
Contents Saved to Project File ... 78
Control register ... 185
Current window ... 313

D

Data display format ... 160
dbgexit ... 262, 275
Debugger Option dialog box ... 68
Debugging environment ... 20
Delay count ... 253
Delimiter ... 313
Device file ... 14
Display color of breakpoint ... 117
Display files ... 28

Displaying Event Details ... 219
download ... 262, 276
Download dialog box ... 94
Drag & drop function ... 125, 126

E

Environment File Load dialog box ... 92
Environment File Save dialog box ... 90
Error message ... 315
Error/warning message ... 315
Event condition ... 23
Event dialog box ... 226
Event display mark ... 118
Event function ... 23
Event link condition ... 23
Event Link dialog box ... 234
Event Manager ... 215
Exit Debugger dialog box ... 259
Expansion windows ... 308
Expressions ... 305
Extended Option dialog box ... 65
extwin ... 262, 277

F

Fail-safe break ... 25
Fatal error message ... 315
File ... 313
finish ... 262, 278
Flow of debugging operations ... 31
Font ... 71
Font dialog box ... 76
Format of file that can be downloaded ... 94
Format of specifiable file ... 98
Full stop ... 27
Function ... 314

G

-g option ... 14
go ... 262, 279

H

help ... 262, 280
hook ... 263, 281
Hook procedure ... 266
Host machine ... 13

I

I/O Port ... 187, 195
Illegal access break ... 25
Information files ... 29
initialized ... 255
Input conventions ... 303

J

jump ... 263, 282
 Jump function ... 33, 123

K

Kanji code ... 72
 Key function list ... 332

L

Linking window ... 34
 Load/save function ... 28
 Local Variable window, ... 175

M

Main window ... 15, 40
 map ... 263, 283
 mapping function ... 20
 Mapping unit ... 64
 Marks of Event Icon ... 217
 mask ... 62, 209, 230, 231
 Maximum number of valid events ... 215
 mdi ... 263, 285
 memory ... 263, 286
 Memory Compare dialog box ... 153
 Memory Compare Result dialog box ... 155
 Memory Copy dialog box ... 151
 Memory Fill dialog box ... 149
 Memory manipulation function ... 27
 Memory Search dialog box ... 146
 Memory window ... 141
 Menu bar ... 42
 Messages ... 315
 Display format ... 315, 331
 Fatal error message ... 315
 Syntax error message ... 315, 319
 Warning message or question message ... 315, 330
 Mixed display ... 121, 201
 mnemonic ... 201
 module ... 263, 288

N

next ... 263, 289
 Non map break ... 25
 Non-real-time execution function ... 22
 Non-stop ... 27
 Normal mode ... 227, 235

O

Offset setting ... 96
 Online assembly ... 131
 Operating environment ... 13
 Operating system ... 14
 Operators ... 305

P

Pick up ... 214

Pickup display ... 204
 PM plus ... 17
 Point mark area ... 116, 132
 Program ... 313
 Program code ... 118, 119
 Program counter setting ... 123
 Program execution function ... 21
 Project file ... 20, 71, 259
 Project File Load dialog box ... 81
 Project File Save dialog box ... 78

Q

Qualify trace ... 27, 245
 Quick Watch dialog box ... 164

R

Range of radices ... 307
 Real-time execution ... 21
 real-time internal RAM sampling function ... 30
 refresh ... 263, 290
 register ... 263, 291
 Register manipulation function ... 27
 Register window ... 182
 Registering debugger ... 17
 reset ... 263, 292
 Reset Debugger dialog box ... 255
 Right-click menu ... 39
 run ... 263, 293
 Run menu ... 21

S

Section event ... 248
 Section trace ... 27, 244
 Select mode ... 227, 232, 235, 237
 Selecting debugger ... 17
 Setting event condition in each area ... 236
 Setting files ... 29
 SFR Select dialog box ... 192
 SFR window ... 187
 Show offset ... 73
 software break ... 25
 Software Break Manager ... 223
 Source Move dialog box ... 105
 Source Path ... 69
 Source Search dialog box ... 128
 Source window ... 114
 Specification of scope ... 169
 Specifying Symbols ... 112
 Stack frame ... 179, 314
 Start function ... 21, 123
 Start-up symbol ... 73
 Static status ... 33
 Status bar ... 57
 step ... 263, 294
 stop ... 263, 295
 Structure ... 314
 Symbol To Address dialog box ... 111
 Symbols ... 304
 Syntax error message ... 315, 319
 System simulator ... 12

T

Tab size ... 72
Terminology ... 313
Time measurement function ... 28
Timer Result dialog box ... 251
Toolbar ... 40
Trace condition ... 26
Trace Data Select dialog box ... 212
Trace dialog box ... 243
Trace function ... 26
Trace memory ... 26
Trace Move dialog box ... 108
Trace Search dialog box ... 205
Trace window ... 198
Tracer control mode ... 27

U

Unconditional trace ... 26
upload ... 263, 296
Upload dialog box ... 98

V

version ... 263, 297
View file ... 28
View File Load dialog box ... 87
View File Save dialog box ... 83

W

Warning message ... 315
Warning message or question message ... 315,
330
watch ... 263, 298
Watch function ... 27, 124
Watch symbol setting ... 74
Watch window ... 157
where ... 263, 299
Window lists ... 36
Window reference ... 36
wish ... 263, 300
Write-protect break ... 25

X

xtrace ... 263, 301