

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

USER'S MANUAL

IE-70732-BX-A
IN-CIRCUIT EMULATOR

TARGET DEVICES
V805™
V810™

This equipment is classified as Information Equipment I (information equipment for use in commercial and industrial fields), and complies with the VCCI standard (committee on self-imposed control of electromagnetic interference from information processing equipment) created in order to reduce electromagnetic interference in commercial and industrial areas. Therefore, use of this equipment in residential or adjacent areas may cause faulty reception of radio, television, and other electromagnetic signals.
Operate this equipment according to the instructions provided in the User's Manual.

The information in this document is subject to change without notice.

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Corporation. NEC Corporation assumes no responsibility for any errors which may appear in this document.

NEC Corporation does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from use of a device described herein or any other liability arising from use of such device. No license, either express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Corporation or of others.

INTRODUCTION

- Readers** This manual is intended for user engineers who design and develop application systems using the μ PD70731 (V805).
- Organization** This manual contains the following information:
- General
 - Installation
 - Start-up
 - Notes on Designing Hardware
- Purpose** This manual is designed to introduce the functions of the IE-70732-BX-A which is used to design and develop application systems using the V805, V810.
- How to Read this Manual** It is assumed that the readers of this manual have general knowledge of electric engineering, logic circuits, and microcontrollers.
- To understand the basic specifications,
→ read **CHAPTER 1 GENERAL**.
 - To perform setting and connections,
→ read **CHAPTER 2 INSTALLATION**.
 - To check how to turn power on/off, attach/detach the emulation probe, and operate,
→ read **CHAPTER 3 START-UP**.
 - To check the points to be noted on designing the hardware,
→ read **CHAPTER 4 NOTES ON DESIGNING HARDWARE**.
 - To understand the overall functions of the in-circuit emulator,
→ read through the manual in the order of the Table of Contents.

Related Documents

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

Document related to network interface board for BX series in-circuit emulator

Product name	Document name	Document number
IE-70000-BX-SV1	User's Manual	EEU-870 ^{Note}

Documents related to V805 and V810

Product name	Document name	Document number
V805	Data Sheet	ID-3292
V810	Data Sheet	ID-3293
V805, V810	User's Manual Hardware	U10661E
V810 Family TM	User's Manual Architecture	U10082E

Documents related to development tools

Product name	Document name		Document number
C Compiler (CA732)	User's Manual	Operation, UNIX base	EEU-1484
		Operation, MS-DOS TM base PC DOS TM base	EEU-1482
		ANSI-C Language	EEU-1483
		Assembly Language	EEU-1485
Source Debugger (ID732)	User's Manual	Operation, UNIX base	EEU-5021 ^{Note}
		Installation, UNIX base	EEU-5022 ^{Note}
		Operation, WINDOWS	In preparation
		Installation, WINDOWS	In preparation

Note This document number is that of Japanese version.

CONTENTS

CHAPTER 1 GENERAL	1
1.1 Function Overview	1
1.2 Features	1
1.3 Probe Tip Dimensions	4
1.4 System Configuration	6
1.5 Hardware Configuration	9
1.6 List of Optional and Related Products	10
CHAPTER 2 INSTALLATION	11
2.1 Unpacking	11
2.2 Connecting IE	12
2.2.1 Connecting power cable	12
2.2.2 Connecting external logic probe (option)	12
2.2.3 Connecting trigger out probe (general-purpose)	13
2.2.4 Connecting expansion emulation memory (option)	13
2.3 Setting Host Machine (when personal computer is used)	14
2.3.1 Connecting IE-70732-BX-A to PC-9800 series	14
2.3.2 Setting interface board	17
2.3.3 Setting environmental variables	20
2.4 Setting Host Machine (workstation)	21
2.4.1 Outline of system operation	21
2.4.2 Connecting network	23
2.4.3 Setting IE	23
2.4.4 Setting jumper switches	24
2.4.5 Incorporating SV1 board	28
2.4.6 Setting network information	31
2.4.7 Starting initialization program	32
2.4.8 Confirming operation	44
2.4.9 Connecting RS-232C cable	45
2.4.10 Connecting network cable	47
2.5 Connecting Target System	49
2.6 Setting Probe Jumper Switch	51
CHAPTER 3 START-UP	53
3.1 Start-up Procedure	54
3.2 Turning Power on/off	55
3.3 Attaching/Detaching Emulation Probe	55
CHAPTER 4 NOTES ON DESIGNING HARDWARE	57
4.1 Timing Design	57
4.2 I/O Signals of Emulator	58

[MEMO]

LIST OF FIGURES

Fig.	Title	Page
1-1	Drawing of Emulation Pod and Emulation Probe	4
1-2	Drawing of Emulation Probe Tip	5
1-3	Personal Computer-Based System	6
1-4	Workstation-Base System (in case of Ethernet™)	7
1-5	Workstation-Based System (in case of Cheapernet)	8
2-1	Connecting Power Cable	12
2-2	Connecting External Logic probe	12
2-3	Connecting Trigger Out Probe	13
2-4	Connecting Expansion Emulation Memory	13
2-5	Rear Panel of PC-9800 Series	14
2-6	Inserting Interface Board	15
2-7	Connecting Interface Cable	15
2-8	Connecting Interface Cable to Emulator	16
2-9	Setting DIP Switch 1 (PC-9800 series)	17
2-10	Setting DIP Switch 2 (PC-9800 series)	17
2-11	Setting Jumper Switch (PC-9800 series)	18
2-12	Setting DIP Switch 1 (IBM PC series)	18
2-13	Setting DIP Switch 2 (IBM PC series)	19
2-14	Setting Jumper Switch (IBM PC series)	19
2-15	Outline of Operations	22
2-16	Factory-Set Conditions of SV1 Board (Board)	25
2-17	Factory-Set Conditions of SV1 Board (Panel)	26
2-18	Removing Back Panel	28
2-19	Mounting SV1 Board	29
2-20	Tightening Screws of Back Panel	30
2-21	Start Message	32
2-22	Setting Menu	33
2-23	Operation Screen	44
2-24	Connecting RS-232C Cable	45
2-25	Pin Connections of RS-232C Cable	46
2-26	Connecting to Cheapernet (10BASE2)	47
2-27	Connecting to Ethernet (10BASE5)	48
2-28	Connecting Target System (with PGA)	49
2-29	Connecting Target System (with QFP)	50
2-30	Probe Jumper Switch (factory-set conditions)	51
3-1	Start-up Procedure	54
4-1	Generating Bus Strobe Signals	57
4-2	Clock Delay between Target System and Emulator	58
4-3	Output Delay in Relation to Target System When Only Target Memory Is Used	59
4-4	Output Delay in Relation to Target System When Emulation Memory or Guard Area Is Used (in write cycle)	61

[MEMO]

LIST OF TABLES

Table	Title	Page
1-1	Functional Specifications	2
1-2	Hardware Configuration	9
1-3	Necessary Optional Products	9
1-4	Optional Products	10
2-1	Functions of Jumper Switches	24
2-2	Setting of JP2	27
2-3	Setting of JP3 - JP8	27
2-4	Setting of Switches on Panel	27
2-5	Setting of RS-232C	46
4-1	Clock Delay between Target System and Emulator	58
4-2	Output Delay in Relation to Target System When Only Target Memory Is Used	60
4-3	Output Delay in Relation to Target System When Emulation Memory or Guard Area Is Used (in write cycle)	62

[MEMO]

CHAPTER 1 GENERAL

This chapter describes the system configuration and function specifications of the IE-70732-BX-A.

1.1 Function Overview

The IE-70732-BX-A is an in-circuit emulator that efficiently debugs the hardware and software of a system using the V805, V810.

This in-circuit emulator is controlled by a host machine to which the emulator is connected.

As the host machine, a workstation (UNIX operating system) or a personal computer (in the NEC PC-9800 series or IBM PC series) can be used.

When a workstation is used as the host machine, connect the in-circuit emulator to the workstation via a network. To use a personal computer, insert a dedicated interface board into an expansion slot of the computer.

To perform actual debugging, a debugger is necessary. For details, refer to the **ID732 User's Manual**.

Remarks The in-circuit emulator is sometimes referred to as IE in this manual.

1.2 Features

- Operates with a source debugger (ID732)
- Supports target systems with power supply voltage as low as 3 V
- Real mode and logical mode operation possible
 - Real mode Mode in which only target system memory is accessed, without specification of emulation memory or card area
 - Real-time emulation with 25-MHz no wait is possible
 - Logical mode ... Mode in which program is executed with specification of emulation memory or card area
 - 25-MHz operation: Emulation with 1 wait and user waits is possible
- CPU status indication by LED indicators
RUN, NORDY, HOLD, HALT
- Event break function
 - [Event condition] address, memory fetch/read/write, I/O read/write
 - [Number of events] 16 max.
- Real-time trace at 33 MHz
- Step execution
 - Up to 65,535 instructions can be executed at a time on a step-by-step basis.
- Emulation memory: 1 Mbytes (standard)
2 Mbytes (expandible)
 - During 25-MHz operation: Emulation is possible with 2 waits + user waits

Table 1-1 shows the functional specifications of the IE-70732-BX-A.

Table 1-1 Functional Specifications (1/2)

Parameter	Specifications	Remarks
Target CPU	μPD70731 (V805)	• 100-pin QFP (with socket conversion adapter)
	μPD70732 (V810)	• 176-pin PGA • 120-pin QFP (with socket conversion adapter)
Operating clock	V805 External : 64 KHz to 20 MHz Internal : 25 MHz (at 5 V) 16 MHz (at 3 V)	• Internal/external clock selectable by command • External clock using a crystal oscillator is not possible • Internal clock conversion is possible
	V810 External : 64 KHz to 20 MHz Internal : 25 MHz (at 5 V) 16 MHz (at 3 V)	
Target system power supply voltage	2.7 to 5.5 V	• Low power supply voltage supported
CPU mounting position	<1> Probe tip <2> Top of pod	• AC characteristics improved • Target system must be connected
CPU status indication	LEDs on front panel <1> RUN <2> NORDY <3> HOLD <4> HALT	<1> Lights while user program is executed (green) <2> Lights if bus cycle cannot end because READY signal is not input from target system (red) <3> Lights during bus hold status (red) <4> Lights while HALT instruction is executed (red) Above statuses <1> through <4> can also be read from host computer
Mask function	Set by following commands: <1> HLD \overline{RQ} <2> RE \overline{SET} <3> NMI <4> SZ \overline{RQ} <5> SIZ16B <6> ICHEEN	• Each control signal from target system can be masked
Emulation memory	960 Kbytes (standard) (can be divided into 15 blocks)	• Capacity: 960 Kbytes (64 Kbytes are used as monitor area) • 1 wait (@ 25-MHz) • Expansion emulation memory (option): Memory capacity can be expanded up to 2 Mbytes
Memory mapping function	• Emulation memory: 1 block, can be assigned in 64-Kbyte units	• Can be assigned in 64-Kbyte boundary to 4-Gbyte formal memory space • Target memory area, emulation memory area, and guard area can be mapped
I/O mapping function	Not provided (all external)	• I/O space mapping is not managed

Table 1-1 Functional Specifications (2/2)

Parameter	Specifications	Remarks
Break function ^{Note}	<ul style="list-style-type: none"> <1> Event break Up to 16 events Event condition: Combination of A1 - A31, D0 - D31, \overline{MRQ}, $\overline{BE0}$ - $\overline{BE3}$, ST0, ST1, R/\overline{W}, EXDAT0 - EXDAT7, and ADRSERR ◀ Number of software break points: 100 max. <3> Forced break <4> Break on accessing guard area <5> Trace full break 	<ul style="list-style-type: none"> • Event break condition is combination of address, data, and status • Address range can be specified (up to two ranges) • Data and external sense data can be selected • Break point can be specified by formal address • Forced break can be accepted even in HALT mode • Break occurs when area specified as guard area is accessed, or when fetched instruction is executed • Break executed when memory is full
Trace function ^{Note}	<p>Width : 160 bits Depth : 16 K frames</p> <p>Start/stop condition setting</p> <p>Trace result display during program execution</p> <p>Trace result search function</p>	<ul style="list-style-type: none"> • Real-time trace at up to 25 MHz of CPU clock • Executed instruction can be disassembled for display • Program execution time can be displayed • Up to 16 start and stop trigger conditions can be set • Trace memory full stop • Can be manually started/stopped • Trace contents can be displayed even while user program is executed • Specified address can be searched from trace result for display
Program execution	<ul style="list-style-type: none"> • Execution possible from any address • Stepped execution possible 	<ul style="list-style-type: none"> • Program execution possible from any address • Stepped execution of up to 65,535 instructions possible • Instruction execution trace and reverse assemble display
Supply voltage	AC 100 V AC 220 V	<ul style="list-style-type: none"> • Internal power supply (with automatic AC 100 V/220 V selection function)
Dimensions	Emulator : H327.5 × W122 × D320 (mm) Pod : H65 × W95 × D160 (mm)	<ul style="list-style-type: none"> • Common BX series housing is used • Power supply is incorporated • Power supplied from Emulator
Weight	Approx. 10 kg	<ul style="list-style-type: none"> • Handle is provided for easy transportation
Power dissipation	80 W max.	<ul style="list-style-type: none"> • With fan for forced air cooling
Operating temperature range	10 to 40 °C 10 to 80 % RH	<ul style="list-style-type: none"> • Without condensation
Storage temperature range	-15 to + 45 °C 10 to 80 % RH	<ul style="list-style-type: none"> • Without condensation

Note These contents are the hardware specifications of the emulator. For the contents during operation, refer to the ID732 USER'S MANUAL.

1.3 Probe Tip Dimensions

Fig. 1-1 shows a drawing of the emulation pod and emulation probe, and Fig. 1-2 shows a drawing of the emulation probe tip.

Fig. 1-1 Drawing of Emulation Pod and Emulation Probe





Fig. 1-2 Drawing of Emulation Probe Tip


(Unit: mm)



1.4 System Configuration

Figs. 1-3 through 1-5 show the configuration of a system using the IE-70732-BX-A.

Fig. 1-3 Personal Computer-Based System



Caution Although the interface board (IE-70000-98-IF-B/IE-70000-PC-IF-B) is sold separately, it is essential for system configuration.

Fig. 1-4 Workstation-Base System (In case of Ethernet™)





Fig. 1-5 Workstation-Based System (In case of Cheapernet)



1.5 Hardware Configuration

Table 1-2 shows the hardware configuration of the IE-70732-BX-A.

Table 1-3 shows the optional products necessary for system configuration.

Table 1-2 Hardware Configuration

No.	Name	Contents
<1>	Emulator	<ul style="list-style-type: none"> • V810 emulation board (EM1 board) • Real-time trace board (TR board)
↔	Emulation pod	Mounts CPU, emulation probe, and internal clock oscillator
↔	Interface cable	Connects interface board to emulator (length: approx. 2 m)
<4>	Emulation probe	Connects emulator to target system. <ul style="list-style-type: none"> • 176-pin PGA (V810) can be used. • 120-pin QFP can also be used with optional socket conversion adapter. • 100-pin QFP (V805) can also be used with optional socket conversion adapter.

Table 1-3 Necessary Optional Products

No.	Name	Contents
<1>	Personal computer interface board (IE-70000-98-IF-B: for PC-9800 series) (IE-70000-PC-IF-B: for IBM PC series)	Board connecting personal computer with IE (inserted into expansion slot of personal computer)
↔	Network interface board (IE-70000-BX-SV1)	Board connecting Ethernet with IE (inserted into expansion slot of IE)

1.6 List of Optional and Related Products

Table 1-4 lists the optional products that can be connected to the IE-70732-BX-A.

Table 1-4 Optional Products

No.	Name	Contents
<1>	External logic probe (IE-70000-BX-EP)	Consists of GND (1) and external inputs (8) and can use external inputs as triggers or display trace result
<2>	Expansion emulation memory (IE-70000-BX-MM2)	<ul style="list-style-type: none"> • Inserted into dedicated slot of IE • 2-Mbyte high-speed SRAM mounted • During 25-MHz operation 2 waits + user waits
<3>	V805: Socket conversion adapter ^{Note 1} (LVC-PG177-TQF100-V805 ^{Note 2} ADP-PG177-TQF100-V805 ^{Note 2})	Conversion adapter from 176-pin PGA to 100-pin QFP Accessories: TQPACK100SD ^{Note 3} , TQSOCKET100SDW ^{Note 3}
	V810: Socket conversion adapter ^{Note 1} (LVC-PG177-QF120-V810 ^{Note 2} ADP-PG177-QF120-V810 ^{Note 2})	Conversion adapter from 176-pin PGA to 120-pin QFP Accessories: TQPACK120SA ^{Note 3} , TQSOCKET120SAW ^{Note 3}

Notes 1. Use either LVC or ADP. Each product is provided with one TQPACK and one TQSOCKET.

LVC: Package conversion, supports 3 V

ADP: Package conversion only

2. Please direct inquiries to: Midas Lab., Inc. Tel : 03-3357-2589

Fax: 03-3357-8029

3. Please direct inquiries to: Daimaru Kogyo Corp. Tel: 03-3820-7112, 06-244-6672

CHAPTER 2 INSTALLATION

This chapter describes how to unpack the carton box containing the IE-70732-BX-A, and connect each part of the in-circuit emulator.

2.1 Unpacking

When unpacking the carton box containing the IE-70732-BX-A, confirm that the following items are included:

	Qty.
(1) Emulator	1
(2) Accessories	
(a) User's Manual (this manual)	1
(b) Interface cable ^{Note}	1
(c) Fuse	1
(d) Power cable	1
(e) Accessory list	1
(f) AC power cable adapter	1
(g) Packing specifications	1


Note The interface board is optional and must be purchased separately.

2.2 Connecting IE

2.2.1 Connecting power cable

Connect the power cable to the emulator as shown in Fig. 2-1.


Fig. 2-1 Connecting Power Cable



2.2.2 Connecting external logic probe (option)

When using the external logic probe, connect it to the emulator as shown in Fig. 2-2. In doing so, be sure to turn off power to the emulator.

Fig. 2-2 Connecting External Logic probe




2.2.3 Connecting trigger out probe (general-purpose)

The trigger out pin is connected to an external device with a coaxial cable with BNC connectors. When using the trigger out probe, connect the probe to the emulator as shown in Fig. 2-3.

This probe is not available from NEC. Use a probe supplied with a logic analyzer, etc.

The trigger out signal is a TTL-level output signal and goes low during break, and high during user program execution.


Fig. 2-3 Connecting Trigger Out Probe



2.2.4 Connecting expansion emulation memory (option)

When using the expansion emulation memory, connect the memory to the emulator as shown in Fig. 2-4.

Fig. 2-4 Connecting Expansion Emulation Memory



Remove the screws and detach the metal plate. Insert the connector of the expansion emulation memory in CN103, and put back the metal plate.

2.3 Setting Host Machine (when personal computer is used)

When using a personal computer as the host machine, an optional interface board is necessary.

No special hardware setting is necessary. However, if the I/O board that handshakes between the IE-70732-BX-A with the computer has already been used by another expansion board, either disconnect the board or change the assignment to a vacant I/O address by changing the setting of the interface board.

- **When using PC-9800 series**

The PC-9800 series is provided with V30™ and 80286/386 modes. The in-circuit emulator operates in both modes; therefore, no setting is necessary.

- **When using IBM PC series**

No mode has to be set with the IBM PC series, regardless of whether PC/AT™ or PC/XT™ is used.

2.3.1 Connecting IE-70732-BX-A to PC-9800 series


This section describes an example of connecting the IE-70732-BX-A to a PC-9800 series personal computer.

When using an IBM PC series computer, connect the in-circuit emulator in the same manner.

Connect the in-circuit emulator to the personal computer by following the steps below.


- (1) Turn off power to the personal computer.
- (2) Remove the cover of the slot bus as shown in Fig. 2-5.

Fig. 2-5 Rear Panel of PC-9800 Series




- (3) Insert the interface board.
- (4) Secure the interface board by tightening the screws, as shown in Fig. 2-6.

Fig. 2-6 Inserting Interface Board




(5) Connect the interface cable as shown in Fig. 2-7.

Fig. 2-7 Connecting Interface Cable



(6) Connect the interface cable to the emulator as shown in Fig. 2-8.

Fig. 2-8 Connecting Interface Cable to Emulator



2.3.2 Setting Interface board

The I/O address of the IE-70732-BX-A must be set by using the DIP switches on the interface board to handshake the in-circuit emulator with the host machine, which is a PC-9800 series or IBM PC series personal computer.

(1) When PC-9800 series is used (setting of IE-70000-98-IF-B)

The I/O address is set by using the DIP switches 1 (SW1) and 2 (SW2) on the interface board.

SW1 and SW2 are switches that set a handshake bus address.

Set the switch pins 1 through 8 of SW1 as shown in Fig. 2-9, and set the switch pins 5 through 8 of SW2 as shown in Fig. 2-10 (addresses 00D0H through 00DBH are set).

Fig. 2-9 Setting DIP Switch 1 (PC-9800 series)




Fig. 2-10 Setting DIP Switch 2 (PC-9800 series)





Fig. 2-11 Setting Jumper Switch (PC-9800 series)



(2) When IBM PC series is used (setting of IE-70000-PC-IF-B)

The I/O address is set by using the DIP switches 1 (SW1) and (SW2) on the interface board.

SW1 and SW2 are switches that set a handshake bus address.

Set the switch pins 1 through 8 of SW1 as shown in Fig. 2-12, and set switch pins 1 through 4 of SW2 as shown in Fig. 2-13 (addresses 0220H through 022DH are set.)

Fig. 2-12 Setting DIP Switch 1 (IBM PC series)




Fig. 2-13 Setting DIP Switch 2 (IBM PC series)





Fig. 2-14 Setting Jumper Switch (IBM PC series)



2.3.3 Setting environmental variables

- **Change handshake bus address**

The default handshake bus address value is as follows when no environmental variable is set:

PC-9800 series : address 00DXH

IBM PC series : address 022XH

If the above address cannot be used, the address can be changed to the one specified by using environmental variable "IE70732_BASE". At this time, the setting of the DIP switch must be accordingly changed (refer to **2.3.2 Setting interface board**).

Example A>SET IE70732_BASE=01D0

In this example, the base address is set to address 01DX.

Although the lower 4 bits of the set value are don't care bits, they must be described.

Input the value as a hexadecimal number. If a character other than those of hexadecimal number is used, the default value is assumed.

For specific environment setting of the host machine, refer to the **ID732 USER'S MANUAL**.

2.4 Setting Host Machine (workstation)

2.4.1 Outline of system operation

The in-circuit emulator is provided with a ROM storing a TCP/IP program and an initialization program that routes a network.


The emulator connected to a network transfers and receives debug commands and data through TCP/IP.

When starting the system or initializing the emulator, an emulator control program is downloaded from the host machine.

All the other programs controlling the emulator are downloaded from the host machine after the program that connects the emulator to the network has been started; therefore, these programs are not provided to the emulator.

The program downloaded to the emulator is erased when the power to the emulator is turned off. To turn the power back on again, restart the software of the host machine, and then load the emulator control program again. Fig. 2-15 outlines the operations, including starting the system and accepting commands.

Fig. 2-15 Outline of Operations



2.4.2 Connecting network

Connect the IE-70732-BX-A to the network by using the network interface board (IE-70000-BX-SV1)^{Note}.

The network interface board (hereafter referred to as SV1 board) is provided with two types of external interfaces conforming to IEEE802.3 (10BASE5 and 10BASE2), and can be connected to either Ethernet or Cheapernet. However, the two networks cannot be used at the same time.

Selection of 10BASE5 or 10BASE2 is made by setting the jumper on the SV1 board.

For specific connection of each network cable, refer to **2.4.10 Connecting network cable**.

For the details on the SV1 board, refer to **2.4.4 Setting jumper switches** and **2.4.5 Incorporating SV1 board**.

Note This board is optional. for details, refer to the **IE-70000-BX-SV1 USER'S MANUAL**.

2.4.3 Setting IE

To connect the IE-70732-BX-A to a network, initialization must be performed. The following sections describe how to perform the initialization.

Before performing the initialization, make sure that the following items are at hand:

- <1> IE-70732-BX-A
- ↔ IE-70000-BX-SV1 (SV1 board)^{Note 1}
- <3> Terminal (terminal with RS-232C terminal for personal computer)^{Note 2}
- <4> RS-232C cable (For specifications and connections, refer to **2.4.9 Connecting RS-232C cable**.)

Notes 1. The transceiver, transceiver cable, coaxial cable , and RS-232C cable are optional. Separately order these cables according to your system.

2. The terminal and RS-232C cable are necessary for initializing the SV1 board.

2.4.4 Setting Jumper switches

It is not necessary to set the jumper switches of the emulator. This section focuses on setting the jumpers on the SV1 board.

Figs. 2-16 and 2-17 show the location and factory-set conditions of the jumper switches on the SV1 board. Change the setting of these jumper switches in accordance with your system.

Table 2-1 shows the functions of the jumper switches.

Table 2-1 Functions of Jumper Switches

Jumper switch		Function	Factory-set condition
Board side	JP1	Selection of terminal power feed of SCSI (fixed to factory-set condition)	1-2
	JP2	Used to connect terminal necessary for initialization Selects baud rate of RS-232C	1-2 (9600 bps)
	JP3 - JP8	Selects network connection standard (Cheapernet/Ethernet)	1-2 (Connects Cheapernet)
	SW4	Reserved (fixed to factory-set condition)	OFF
Panel side	MASTER	Host connection select switch Selects whether host is connected to emulator via network (SV) or personal computer interface (EM)	SV (via network)
	CONF.	Initialization switch Selects whether initialization modes or TCP/IP program start mode is set on power application	1 (initialization mode)

Fig. 2-16 Factory-Set Conditions of SV1 Board (Board)





Fig. 2-17 Factory-Set Conditions of SV1 Board (Panel)



(1) Setting of Jumper switches on board

Set the jumper switches in accordance with your system.

JP1: Not used with this system. Leave this switch as factory-set.

JP2: Change setting of this switch according to the baud rate of the terminal used to set network information.

Table 2-2 Setting of JP2

Baud rate	Setting
9600 bps	1-2 shorted (factory-set condition)
4800 bps	2-3 shorted

JP3 - JP8: Change the setting of these switches according to the standards of the network cable to which the emulator is to be connected.

Table 2-3 Setting of JP3 - JP8

Network standard	Setting
Cheapernet (10BASE2)	1-2 shorted (factory-set condition)
Ethernet (10BASE5)	2-3 shorted

Caution Set all JP3 - JP8 in the same manner.

Short-circuiting 1-2 and 2-3 at the same time may cause malfunctioning of the emulator.

SW4: This switch is not used with this system. Leave this switch as factory-set.

(2) Switches on panel

Set the switches on the panel as indicated below.

Table 2-4 Setting of Switches on Panel

Switch	Setting
MASTER	Set this switch to SV position (factory-set condition)
CONF.	Set this switch to position "1" (factory-set condition) when network information is not set or when resetting is to be performed. Set the switch to position "0" if setting of network information has been done.


2.4.5 Incorporating SV1 board

Incorporate the SV1 board to the emulator by following steps (1) through (3) below.

(1) Remove the back panel of the emulator. In doing so, bear in mind the following points:

- Do not lose the mounting screws of the panel because they are used again.
- The emulator has four slots. The slot to which the SV1 board is to be mounted is fixed. Do not mount the board to any other slots.


Fig. 2-18 Removing Back Panel



(2) Mount the SV1 board into the emulator. In doing so, bear in mind the following points:

- Make sure that the power to the emulator has been turned OFF.
- Confirm that the jumper switches are correctly set.
- Mount the SV1 board in the correct direction (the direction of the component side).
- Make sure that the bottom edge of the board is correctly inserted into the groove of the card rail.


Fig. 2-19 Mounting SV1 Board



(3) Secure the panel by tightening the screws. In doing so, keep in mind the following points:

- Make sure that the connector of the board is correctly connected to the connector on the chassis.
- Secure the SV1 board to the chassis by using the mounting screws of the back panel.

Fig. 2-20 Tightening Screws of Back Panel



2.4.6 Setting network information

To connect the emulator to a network, information on the network must be set on the host machine and in the emulator.

For information on how to set the network information on the host machine, refer to the **IS732 User's Manual**.

To set the network information, information set when environments were set on the host machine is necessary.

This information is provided by the manager of the UNIX operating system on the host machine or network manager.

The items of the network information necessary for setting the environments are as follows:

- **IP address (LOCAL IP ADDRESS)**

Peculiar network address assigned to emulator

(This address is a decimal number delimited by a period on the host machine, but is set as a continuous 8-digit hexadecimal number on the emulator.)

- **Host name (LOCAL HOST NAME)**

Set the name same as the one set on the host machine (alphanumeric string of 16 characters or less).

- **Port number (LOCAL PORT NO.)**

Set a 4-digit hexadecimal number other than 0 (usually, 0401 or higher).

2.4.7 Starting initialization program

Start the network information setting program on the SV1 board to set the network information.

Confirm the following points before turning on the power to the emulator:

- Whether the terminal is connected to the RS-232C port of the emulator
- Whether the "CONF." switch on the rear panel of the SV1 board is set to position "1" (If this switch is set to position "0", the network information setting program cannot be started.)

When the power to the emulator is turned on, or when the emulator is reset, the message shown in Fig. 2-21 is displayed on the screen of the terminal. Following the message, a prompt is displayed, indicating that the system is waiting for a command to be input.

Fig. 2-21 Start Message

```
8088/86 Modular BIOS Ver  x.xx  mm/dd/yy
Copyright(c)1984-89 Award Software Inc.
IBM Compatible DSIF-BIOS (c) Digital electronics Corp.
SIZING SYSTEM MEMORY.....640K FOUND

MEMORY-DISK BIOS VERSION x.xx
Copyright (C) 1990 Digital Electronics Corporation
MEMORY-DISK INSTALLED DRIVE A:

DSIF : VIDEO RESOURCES      <OPTIMIZING>
DSIF : KEYBOARD RESOURCES   <OPTIMIZING>
      entry TCP/IP System Driver. <OPTIMIZING>
TCP/IP Driver Verx.xx

A>BREAK ON

A>CONF

A>IF ERRORLEVEL 1 GOTO END

A>
A>
```

After confirming the output of the prompt, input "ENET" to start the initialization program.

Accurately set the network information obtained in advance according to the setting menu shown in Fig. 2-22. For details on the initialization program, refer to the **IE-70000-BX-SV1 User's Manual**.

Fig. 2-22 Setting Menu

```
A>ENET

  --- SETUP NETWORK INFORMATION ---
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
  2. LOCAL IP ADDRESS        XXXXXXXXX
  3. LOCAL HOST NAME         XXXXXXXXXXXXXXXXX
  4. LOCAL PORT NO.         XXXX
  5. REMOTE ETHERNET ADDRESS XXXXXXXXXXXXX
  6. REMOTE IP ADDRESS       XXXXXXXXX
  7. REMOTE HOST NAME       XXXXXXXXXXXXXXXXX
  8. REMOTE PORT NO.        XXXX
  9. ROUTER ADDRESS         XXXXXXXXX
 10. SUBNET ADDRESS MASK    XXXXXXXXX
 11. EXIT

-----
FUNCTION NO. >>■
```

(1) Setting LOCAL ETHERNET ADDRESS

A universal address is factory-set as the local Ethernet address (1: LOCAL ETHERNET ADDRESS).

The universal address is an address peculiar to the board and cannot be changed by the user; therefore, function number 1 cannot be selected.

The value set on this menu is written to the EEPROMTM; therefore, it is not lost even after the power has been turned off.

(2) Setting LOCAL IP ADDRESS

[Function]

Sets the IP address of the IE-70000-BX-SV1. One IP address is assigned to each node. Set the address provided by the network manager.

[Input format]

Input the IP address as an 8-digit hexadecimal number.

[Input example]

```

      :
11. EXIT
-----
FUNCTION NO. >>2 
                                     Select function number 2.

LOCAL IP ADDRESS           >XXXXXXXX           Displays current IP address.
NEW LOCAL IP ADDRESS       >12345678        Input new IP address.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
      :
  2. LOCAL IP ADDRESS        12345678           Displays new IP address.
      :
11. EXIT
-----
FUNCTION NO. >>■

```

(3) Setting of LOCAL HOST NAME

[Function]

Sets the host name (node name) of the IE-70000-BX-SV1.

[Input format]

Input the host name as a alphanumeric string of 16 characters or less.

Set the host name provided by the network manager.

[Input example]

```

      :
11. EXIT
-----
FUNCTION NO. >>3
                                     Select function number 3.

LOCAL HOST NAME          >XXXXXX      Displays current host name.
NEW LOCAL HOST NAME      >LOCALHOSTNAME
                                     Input new host name.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXX
      :
  3. LOCAL HOST NAME        LOCALHOSTNAME
      :
11. EXIT
-----
FUNCTION NO. >>

```

(4) Setting LOCAL PORT NO.

[Function]

Sets the port number of the IE-70000-BX-SV1.

[Input format]

Input the port number as a 4-digit hexadecimal number other than 0. Usually, set 0401 (1025 in decimal) or higher.

[Input example]

```

:
11. EXIT
-----
FUNCTION NO. >>4
Select function number 4.

LOCAL PORT NO. >XXXX Displays current port number.
NEW LOCAL PORT NO. >0401
Input new port number.

--- SETUP NETWORK INFORMATION --- Displays menu.
  1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX
  :
  4. LOCAL PORT NO. 0401 Displays new port number.
  :
11. EXIT
-----
FUNCTION NO. >>

```


(5) Setting REMOTE ETHERNET ADDRESS

[Function]

Set the Ethernet address of the host machine that operates the in-circuit emulator.

[Input format]

Input the address as a 12-digit hexadecimal number.

If the host machine is not specified, set FFFFFFFF. Usually, Input FFFFFFFF.

[Input example]

```

      :
      :
11. EXIT
-----
FUNCTION NO. >>5 [F4]
                                     Select function number 5.

REMOTE ETHERNET ADDRESS >XXXXXXXXXXXX
NEW REMOTE ETHERNET ADDRESS >0123456789AB [F4]
                                     Displays current Ethernet address.
                                     Input new Ethernet address.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS XXXXXXXXXXXX
      :
  5. REMOTE ETHERNET ADDRESS 0123456789AB
      :
11. EXIT
-----
FUNCTION NO. >>■
    
```

(6) Setting REMOTE IP ADDRESS

[Function]

Set the IP address of the host machine.

[Input format]

Input the IP address as an 8-digit hexadecimal number.

If the host machine is not specified, set 0. Usually, input 0.

[Input example]

```

      :
11. EXIT
-----
FUNCTION NO. >>6
                                     Select function number 6.

REMOTE IP ADDRESS                   >XXXXXXXX           Displays current IP address.
NEW REMOTE IP ADDRESS                >12345678           Input new IP address.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
      :
  6. REMOTE IP ADDRESS       12345678           Displays new IP address.
      :
11. EXIT
-----
FUNCTION NO. >>

```

(7) Setting REMOTE HOST NAME

[Function]

Sets the host name (node name) of the host machine.

[Input format]

Input the host name as an alphanumeric string of 16 characters or less.

If the host machine is not specified, input only the carriage return. Usually, input only the carriage return.

[Input example]

```

      :
11. EXIT
-----
FUNCTION NO. >>7 
                                     Select function number 7.

REMOTE HOST NAME          >XXXXXX      Displays current host name.
NEW REMOTE HOST NAME      >REMOTEHOSTNAME   Input new host name.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXX
      :
  7. REMOTE HOST NAME        REMOTEHOSTNAME  Displays new host name.
      :
11. EXIT
-----
FUNCTION NO. >> 

```

(8) Setting REMOTE PORT NO.

[Function]

Sets the port number of the host machine.

[Input format]

Input the port number as a 4-digit hexadecimal number.

If the host machine is not specified, input 0. Usually, input 0.

[Input example]

```

      :
11. EXIT
-----
FUNCTION NO. >>8 [F4]
                                     Select function number 8.

REMOTE PORT NO.          >XXXX      Displays current port number.
NEW REMOTE PORT NO.     >0123 [F4]   Input new port number.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXX
      :
  8. REMOTE PORT NO.        0123      Displays new port number.
      :
11. EXIT
-----
FUNCTION NO. >>■
    
```

(9) Setting ROUTER ADDRESS

[Function]

Sets the IP address of the router. Set this address when the emulator is connected to the host machine via router.

[Input format]

Input the address as an 8-digit hexadecimal number.

Input 0 if routing is not necessary.

[Input example]

```
      :
      :
11. EXIT
-----
FUNCTION NO. >>9 [4]          Select function number 9.

ROUTER ADDRESS                >XXXXXXXX          Displays current router address.
NEW ROUTER ADDRESS            >12345678 [4]        Input new router address.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
      :
  9. ROUTER ADDRESS          12345678             Displays new router address.
      :
11. EXIT
-----
FUNCTION NO. >>■
```

(10) Setting SUBNET ADDRESS MASK

[Function]

Sets the address mask field of the subnet.

[Input format]

Input the address mask field as an 8-digit hexadecimal number with the bit that indicates the address position of the subnet set to 1.

Input 0 if the subnet address mask is not set.

[Input example]

The following is an example when the higher 24 bits of the IP address are used to recognize the subnet, and the lower 8 bits are used to recognized the host:

```

      :
      :
11. EXIT
-----
FUNCTION NO. >>10 [F]          Select function number 10.

SUBNET ADDRESS MASK           >XXXXXXXX          Displays current subnet address mask.
NEW SUBNET ADDRESS MASK       >FFFFFF00 [F]       Input new subnet address mask.

--- SETUP NETWORK INFORMATION ----- Displays menu.
  1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
      :
10. SUBNET ADDRESS MASK      FFFFFFF00           Displays new subnet address mask.
      :
11. EXIT
-----
FUNCTION NO. >> [ ]

```

(11) EXIT

[Function]

Terminates the network information setting menu, and updates the EEPROM contents with the set values.

[Input format]

Input S, Q, or C.

S: Writes the set network information to the EEPROM and terminates the menu.

Q: Does not write the set network information to the EEPROM and terminates the menu.

C: Continues setting the network information. Returns to the menu.

[Input example]

<1> When S is Input

```

      :
      11. EXIT
-----
FUNCTION NO. >>11[ ]
                                     Select function number 11.

Save & quit / Quit / Continue >S[ ]
                                     Writes network information to EEPROM and
                                     terminates.

A>■
    
```

<2> When Q is Input

```

      :
      11. EXIT
-----
FUNCTION NO. >>11[ ]
                                     Select function number 11.

Save & quit / Quit / Continue >Q[ ]
                                     Terminates without network information
                                     written to EEPROM.

A>■
    
```

<3> When C is Input

```

      :
      11. EXIT
-----
FUNCTION NO. >>11[ ]
                                     Select function number 11.

Save & quit / Quit / Continue >C[ ]
                                     Continues setting network information.

--- SETUP NETWORK INFORMATION ---
      1. LOCAL ETHERNET ADDRESS  XXXXXXXXXXXXX
      :
      11. EXIT
-----
FUNCTION NO. >>■
    
```

2.4.8 Confirming operation

After the initialization has been finished, confirm the operation.

Confirm the following points with the power to the emulator turned off:

- Whether the terminal is connected to the RS-232C port of the emulator
- Whether the "CONF." switch on the rear panel of the SV1 board is set to position "0" (If this switch is set to position 1, the TCP/IP program cannot be automatically executed.)

Turn on power to the emulator, and confirm that the message shown in Fig. 2-23 is displayed on the screen of the terminal.

Fig. 2-23 Operation Screen

```
8088/86 Modular BIOS Ver  x.xx  mm/dd/yy
Copyright(c)1984-89 Award Software Inc.
IBM Compatible DSIF-BIOS (c) Digital electronics Corp.
SIZING SYSTEM MEMORY.....640K FOUND

MEMORY-DISK BIOS VERSION x.xx
Copyright (C) 1990 Digital Electronics Corporation
MEMORY-DISK INSTALLED DRIVE A:

DSIF : VIDEO RESOURCES      <OPTIMIZING>
DSIF : KEYBOARD RESOURCES   <OPTIMIZING>
  entry TCP/IP System Driver. <OPTIMIZING>
TCP/IP Driver Verx.xx

A>BREAK ON

A>CONF

A>IF ERRORLEVEL 1 GOTO END

A>EXELOAD -C
A>
```

This is the end of setting at the emulator side.

2.4.9 Connecting RS-232C cable

Connect the RS-232C cable to the emulator as shown in Fig. 2-24.

Table 2-5 shows the specifications of the RS-232C, and Fig. 2-25 shows the pin configuration of the cable.

Fig. 2-24 Connecting RS-232C Cable





Table 2-5 Setting of RS-232C

Parameter	Contents
Character length	8 bits
Parity check	None
Stop bit	2 bits
Baud rate ^{Note}	4800 or 9600 bps

Note The baud rate can be selected by a jumper on the SV1 board.

Fig. 2-25 Pin Connections of RS-232C Cable



- Notes**
1. The connector of the RS-232C cable at the SV1 board side is male.
 2. Make sure that the right connector is used for the terminal to be used.

2.4.10 Connecting network cable

Connect the network cable to the emulator as shown in Figs. 2-26 and 2-27, according to the type of the cable to be used.

Fig. 2-26 Connecting to Cheapernet (10BASE2)





Fig. 2-27 Connecting to Ethernet (10BASE5)



2.5 Connecting Target System

The emulator and the target system are connected with the emulation probe attached to the emulation pod.

This emulation probe is designed to connect a 176-pin PGA package; therefore, an optional socket conversion adapter is necessary for connecting a target system designed to be QFP.

Fig. 2-28 shows an example of connecting a PGA package, and Fig. 2-29 shows an example of connecting a QFP.

Care must be exercised so that the emulation probe does not interfere when the emulator and the target system are connected.

Connect the emulation probe to the PGA socket in the correct direction.

Fig. 2-28 Connecting Target System (with PGA)






Fig. 2-29 Connecting Target System (with QFP)

(a) When target CPU is 100-pin QFP (V805)



Caution Before connecting the emulation probe, make sure that the A1 pin index is positioned over the A1 pin mark of the conversion adapter.

(b) When target CPU is 120-pin QFP (V810)




Caution Before connecting the emulation probe, make sure that the A1 pin index is positioned over the A1 pin mark of the conversion adapter.

2.6 Setting Probe Jumper Switch

The emulation probe tip contains 7 jumper switches. Use these jumper switches with their factory-set conditions.

Fig. 2-30 Probe Jumper Switch (factory-set conditions)



[MEMO]


CHAPTER 3 START-UP

This chapter describes how to turn the power on or off, attach/detach the emulation probe, and confirm operations.

3.1 Start-up Procedure

Fig. 3-1 illustrates the start-up procedure.

Fig. 3-1 Start-up Procedure



Note Necessary when a network is used.

3.2 Turning Power on/off

After connecting the power cable, network cable, and target system, turn on power in the following sequence:

(1) To turn on

<1> IE-70732-BX-A

↔ Target system

(2) To turn off

<1> Target system

↔ IE-70732-BX-A

3.3 Attaching/Detaching Emulation Probe

To attach/detach the emulation probe to/from the target system, be sure to turn off the power to the target system.

Because the emulator is provided with a circuit that senses the supply voltage to the target system, the emulator makes all the output signals inactive when the power to the target system has been turned off. Therefore, it is not necessary to turn off the power to the emulator when the emulation probe is attached/detached, if the power to the target system has been turned off.

Confirm that the residual charge is completely discharged immediately after turning off the power to the target system.

When connecting/disconnecting the target system, either terminate the operation of the debugger or execute the reset or initialization command to prevent the deadlock of the emulator due to changes in the environments.

[MEMO]

CHAPTER 4 NOTES ON DESIGNING HARDWARE

This chapter describes points to be noted in designing the hardware of the V805, V810 system on the assumption that the emulator is connected.


4.1 Timing Design

The AC characteristics of the emulator significantly differ from those of the actual chip.

In all, the delay time of the output signal in relation to the clock is considerably slower than that of the actual chip. Take this into consideration in controlling access to the I/O and designing a bus control circuit.

Especially, generate bus strobe signals such as the $\overline{\text{READY}}$ signal and I/O select signals in a handshaking procedure of the kind shown in Fig. 4-1.

Fig. 4-1 Generating Bus Strobe Signals



4.2 I/O Signals of Emulator

(1) Fig. 4-2 and Table 4-1 show the delay of the target system's clock behind the internal clock of the emulator.

Fig. 4-2 Clock Delay between Target System and Emulator




Table 4-1 Clock Delay between Target System and Emulator

($T_A = 25\text{ }^\circ\text{C}$, $V_{DD} = 5\text{ V}$, $f = 25\text{ MHz}$)

Symbol	Parameter	Installing on CPU tip	Installing on top of CPU pod
		TYP. (ns)	TYP. (ns)
t _{cyk}	Clock cycle	40	40
t _{dKH}	Clock rising delay	2	11
t _{dKL}	Clock falling delay	2	11

(2) Fig. 4-3 and Table 4-2 show the output delay (in write cycle) in relation to the target system when only the target memory is used.

Fig. 4-3 Output Delay in Relation to Target System When Only Target Memory Is Used




Table 4-2 Output Delay in Relation to Target System When Only Target Memory Is Used

($T_A = 25\text{ }^\circ\text{C}$, $V_{DD} = 5\text{ V}$, $f = 25\text{ MHz}$ ($t_{CYK} = 40\text{ ns}$))

Symbol	Parameter	Installing on probe tip	Installing on top of pod
		TYP. (ns)	TYP. (ns)
t_{DKA}	Active output delay (A1 - A31)	12	21
t_{HKA}	Inactive output delay (A1 - A31)	13	21
t_{DKB}	Active output delay ($\overline{BE0} - \overline{BE3}$)	12	21
t_{HKB}	Inactive output delay ($\overline{BE0} - \overline{BE3}$)	12	21
t_{DKS}	Active output delay (ST0, ST1)	21	29
t_{HKS}	Inactive output delay (ST0, ST1)	21	28
t_{DKDT}	Active output delay (D0 - D31)	18	24
t_{HKDT}	Inactive output delay (D0 - D31)	17	28
t_{DKR}	Active output delay ($\overline{R/\overline{W}}$)	12	21
t_{HKR}	Inactive output delay ($\overline{R/\overline{W}}$)	12	21
t_{DKBC}	Active output delay (\overline{BCYST})	22	29
t_{HKBC}	Inactive output delay (\overline{BCYST})	21	28
t_{DKDA}	Active output delay (\overline{DA})	24	30
t_{HKDA}	Inactive output delay (\overline{DA})	22	28

(3) Fig. 4-4 and Table 4-3 show the output delay (in write cycle) in relation to the target system when the emulation memory or guard area is used.

Fig. 4-4 Output Delay in Relation to Target System When Emulation Memory or Guard Area Is Used (In write cycle)




Table 4-3 Output Delay in Relation to Target System When Emulation Memory or Guard Area Is Used (in write cycle) $(T_A = 25\text{ }^\circ\text{C}, V_{DD} = 5\text{ V}, f = 25\text{ MHz (}t_{CYK} = 40\text{ ns)})$

Symbol	Parameter	Installing on probe tip	Installing on top of pod
		TYP. (ns)	TYP. (ns)
t_{DKA}	Active output delay (A1 - A31)	12	21
t_{HKA}	Inactive output delay (A1 - A31)	12	21
t_{DKB}	Active output delay ($\overline{BE0} - \overline{BE3}$)	12	20
t_{HKB}	Inactive output delay ($\overline{BE0} - \overline{BE3}$)	12	20
t_{DKS}	Active output delay (ST0, ST1)	26	32
t_{HKS}	Inactive output delay (ST0, ST1)	25	32
t_{DKDT}	Active output delay (D0 - D31)	18	24
t_{HKDT}	Inactive output delay (D0 - D31)	17	28
t_{DKR}	Active output delay ($\overline{R/\overline{W}}$)	12	21
t_{HKR}	Inactive output delay ($\overline{R/\overline{W}}$)	12	21
t_{DKBC}	Active output delay (\overline{BCYST})	26	26
t_{HKBC}	Inactive output delay (\overline{BCYST})	24	24
t_{DKDA}	Active output delay (\overline{DA})	28	28
t_{HKDA}	Inactive output delay (\overline{DA})	26	35