

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

USER'S MANUAL

RENESAS

IE-78310A-R

HARDWARE

USER'S MANUAL

NEC

IE-78310A-R

HARDWARE

V30 is a trademark of NEC Corporation.

Concurrent CP/M (abbreviated CCP/M) and CP/M-86 are trademarks of Digital Research, Inc.

MS-DOS is a trademark of Microsoft Corporation.

PC/AT and PC DOS are trademarks of IBM Corporation.

The IE-78310A-R conforms to the standards of VCCI which restricts radio disturbance in commercial and industrial areas.

Since the IE-78310A-R used in residential districts or their neighboring districts may cause radio and TV disturbance, follow the IE-78310A-R Manual.

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Corporation. NEC Corporation assumes no responsibility for any errors which may appear in this document.

NEC Corporation does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from use of a device described herein or any other liability arising from use of such device. No license, either express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Corporation or of others.

MAJOR CHANGES

| Page | Description |
|---------------------|---|
| Before the CONTENTS | CAUTIONS has been added. |
| P. 1-2 | The description stating that the MD series or PG-2000 is not manufactured has been added. |
| PP. B-1 to B-29 | APPENDIX B has been added. |

CAUTIONS

This part describes the cautions for the IE-78310A-R.

Read this part before developing an application system. The number enclosed in parentheses represents the page on which the caution is described.

(1) Cautions in Chapter 4

- To disconnect the target system temporarily when connecting the MD-116FD-20/HD-21 to the IE-78310A-R, follow the procedure below: (pp. 4-31, 4-32)
 - ① Execute an RES_H command.
 - ② The following message appears. (Do not enter anything.)
Power on target system (Y/N)
 - ③ Turn off the power switch of the target system, then disconnect the target system.
 - ④ Connect the target system, then turn on the power switch.
 - ⑤ Enter Y <cr>.

(2) Cautions in Chapter 5

- Always connect a device in the terminal mode to a device in the modem mode through the RS-232-C interface. Never connect two devices both in the terminal mode or both in the modem mode. (p. 5-8)

- Always set the RTS DIP switch to the RTSN setting except when a pro-typewriter is connected. (pp. 5-17, 5-30)
- The IE-78310A-R can be connected to the PG-2000 both in the modem mode because the cable attached to the PG-2000 is internally modified to accommodate such connection. Be sure to use the cable attached to the PG-2000 to connect them. Never use other cables. (This caution also applies to the PG-1500.) (p. 5-28)
- Always connect handshake signals before selecting hardware handshaking. (p. 5-39)

(3) Cautions in Chapter 6

- At shipment, the basic clock is set so as to use an external clock (input at pin 30 of the target probe). When an external clock is not used, set the clock by software (commands) so as to use the internal clock. (p. 6-3)
- A ∇ mark, which indicates the position of pin 1, is marked on the SHRINK DIP type target probe. Fit the target probe into the self-diagnostic socket so that the mark is aligned with pin 1 of the self-diagnostic socket.

The ground clip of the target probe need not be connected to pin GND.

Great care should be taken that the target probe is not fitted in reverse and the pins are not broken or bent. Otherwise, the target interface circuit of the IE-78310A-R will be destroyed. (p. 6-8)

- At shipment, the part base which contains the wiring for the external clock signal (input at pin 30 of the target probe) is already fitted on the emulation board. Using this base, the clock signal used in the target system can also be used as the basic clock signal in the IE-78310A-R.

When the crystal oscillator is directly connected to pins X1 and X2 (pins 30 and 31) of the uPD78312A or uPD78310A in the target system, this oscillation signal cannot be supplied to the IE-78310A-R. In this case, install a crystal oscillator on the emulation board using the part base. (p. 6-11)

- If the external sense clips are connected to signal lines other than TTL-level signal lines, the IE-78310A-R cannot sense signal lines correctly and the sensor of the IE-78310A-R may be destroyed, depending on the voltage level. (p.6-20)
- When the target probe is fitted into the CPU socket of the target system (p. 6-22)

- ① Fit the target probe into the CPU socket of the target system so that the IC mark of the target probe is aligned with the first-pin mark. Care should be taken that the target probe is not fitted in reverse. Otherwise, the target interface circuit of the IE-78310A-R will be destroyed.
- ② Care must be taken that the pins of the target probe are not broken or bent.
- ③ The ground clip of the target probe shall be connected to pin GND.

- When the external sense clips are connected to the target system (p. 6-22)
 - ① Be sure to connect an external sense clip to a signal line. If it is connected to a power line, a failure occurs.
 - ② Use an IC clip to connect the external sense clips.

CONTENTS

| | |
|--|------|
| CHAPTER 1 INTRODUCTION | 1-1 |
| 1.1 Use of the IE-78310A-R Manual | 1-3 |
| 1.2 Configuration of the IE-78310A-R Manual | 1-4 |
| CHAPTER 2 FUNCTION OVERVIEW | 2-1 |
| 2.1 Overview | 2-1 |
| 2.2 Basic Specifications | 2-2 |
| 2.3 System Configuration | 2-4 |
| 2.4 Appearance | 2-6 |
| 2.5 Configuration | 2-7 |
| CHAPTER 3 INSTALLATION | 3-1 |
| 3.1 Overview | 3-1 |
| 3.2 Unpacking | 3-2 |
| 3.3 Confirmation | 3-3 |
| 3.4 Installation | 3-7 |
| 3.5 Setting | 3-12 |
| 3.6 Setting of Jumpers on Control/Trace Board | 3-15 |
| CHAPTER 4 CONFIGURING THE SYSTEM | 4-1 |
| 4.1 Overview | 4-1 |
| 4.2 Peripheral Equipment | 4-2 |
| 4.3 Connecting Peripheral Equipment | 4-7 |
| 4.3.1 Connecting MD-910TM | 4-9 |
| 4.3.2 Connecting MD-116FD-20/HD-21 | 4-20 |
| 4.3.3 Connecting MD-116FD-10 or MD-086FD(HD)-10 | 4-32 |
| 4.3.4 Connecting MD-086FD | 4-51 |
| 4.3.5 Connecting PG-1500 | 4-66 |
| 4.3.6 Connecting PG-2000 | 4-75 |

| | | |
|-----------|--|------|
| CHAPTER 5 | FUNCTIONS OF THE SC-232-C INTERFACE | 5-1 |
| 5.1 | Overview | 5-1 |
| 5.2 | Terminal Mode & Modem Mode | 5-2 |
| 5.3 | Signal Lines Used by IE-78310A-R | 5-9 |
| 5.4 | Channel 1 Functions | 5-15 |
| 5.4.1 | RTS setting | 5-17 |
| 5.4.2 | Baud rate selection | 5-19 |
| 5.4.3 | Handshaking | 5-20 |
| 5.4.4 | Character specifications | 5-26 |
| 5.5 | Channel 2 Functions | 5-27 |
| 5.5.1 | Terminal mode/modem mode selection | 5-27 |
| 5.5.2 | RTS setting | 5-30 |
| 5.5.3 | Baud rate selection | 5-32 |
| 5.5.4 | Handshaking | 5-33 |
| 5.5.5 | Character specifications | 5-40 |
| CHAPTER 6 | CONNECTING THE TARGET SYSTEM | 6-1 |
| 6.1 | Overview | 6-1 |
| 6.2 | Debugging Software | 6-2 |
| 6.2.1 | Setting the basic clock of the IE-78310A-R ... | 6-3 |
| 6.2.2 | Connecting the target probe | 6-7 |
| 6.3 | Connecting the Target System | 6-10 |
| 6.3.1 | Setting the basic clock of the IE-78310A-R ... | 6-12 |
| 6.3.2 | Connecting the target probe..... | 6-17 |
| 6.3.3 | Connecting the external sense clips | 6-19 |
| 6.3.4 | Power-on sequence | 6-21 |
| 6.3.5 | Power-off sequence | 6-21 |
| 6.4 | Differences between the Real Device and Target Interface Circuit of the IE-78310A-R | 6-23 |
| 6.5 | Latch-up | 6-29 |

| | |
|--|---------|
| APPENDIX A | A-1 |
| (1) Overview of installation | A-1 |
| (2) Connectable peripheral equipment | A-2 |
| (3) Functions and the setting of switches on the main unit | A-2 |
| (4) Jumper connections on the control/trace board | A-3 |
| (5) RS-232-C interface circuit | A-4 |
| (6) Connecting the target system | A-5 |
| (7) Commands | A-6 |
| (8) Error messages | A-11 |
| (9) Differences between the IE-78310A-R and real devices | A-19 |
| (10) Notes on using the debugger | A-20 |
| (11) Execution examples | A-21 |
| APPENDIX B | B-1 |
| PART I SYSTEM SOFTWARE FOR PC-9800 SERIES | |
| (CP/M-86) | B-2 |
| CHAPTER 1 OVERVIEW | B-3 |
| 1.1 System Configuration | B-3 |
| 1.2 System Software Distribution | B-4 |
| CHAPTER 2 CONNECTION | B-5 |
| CHAPTER 3 STARTING THE SYSTEM SOFTWARE | B-6 |
| CHAPTER 4 NOTES ON USE | B-8 |
| 4.1 Terminating the IE78310 | B-8 |
| 4.1.1 RS-232-C mode alteration | B-8 |
| 4.1.2 Key code alteration | B-8 |
| CHAPTER 5 DIFFERENCES FROM SYSTEM SOFTWARE RUNNING UNDER MD-086/116 | B-9 |

| | | |
|-----------|--|------|
| PART II | SYSTEM SOFTWARE FOR PC-9800 SERIES | |
| | (MS-DOS) | B-10 |
| CHAPTER 1 | OVERVIEW | B-11 |
| 1.1 | System Configuration | B-11 |
| 1.2 | System Software Distribution | B-12 |
| CHAPTER 2 | CONNECTION | B-13 |
| CHAPTER 3 | STARTING THE SYSTEM SOFTWARE | B-14 |
| CHAPTER 4 | NOTES ON USE | B-16 |
| 4.1 | Terminating the IE78310 | B-16 |
| 4.1.1 | RS-232-C mode alteration | B-16 |
| 4.1.2 | Key code alteration | B-16 |
| 4.2 | Using the DIR Command | B-16 |
| 4.3 | Using File Manipulation Commands | B-17 |
| 4.4 | Creating an STR File | B-17 |
| 4.5 | Control Keys | B-17 |
| CHAPTER 5 | DIFFERENCES FROM SYSTEM SOFTWARE RUNNING | |
| | UNDER MD-086/116 | B-18 |
| PART III | SYSTEM SOFTWARE FOR IBM PC/AT (PC DOS) | B-19 |
| CHAPTER 1 | OVERVIEW | B-20 |
| 1.1 | System Configuration | B-20 |
| 1.2 | System Software Distribution | B-21 |
| CHAPTER 2 | CONNECTION | B-22 |
| CHAPTER 3 | STARTING THE SYSTEM SOFTWARE | B-24 |
| CHAPTER 4 | NOTES ON USE | B-27 |
| 4.1 | Creating an STR File | B-27 |
| 4.2 | Control Keys | B-27 |
| CHAPTER 5 | DIFFERENCES FROM SYSTEM SOFTWARE RUNNING | |
| | UNDER MD-086/116 | B-28 |

CHAPTER 1 INTRODUCTION

The IE-78310A-R is an in-circuit emulator which has been developed to efficiently debug hardware and software using a uPD78312A or uPD78310A.

The IE-78310A-R Manual explains the unpacking of an IE-78310A-R, debugging, and applications. The IE-78310A-R Manual consists of the following two parts: Hardware and Software.

Hardware:

- Chapter 1 Introduction(Note)
- Chapter 2 Function Overview
- Chapter 3 Installation
- Chapter 4 Configuring the System
- Chapter 5 RS-232-C Interface Functions
- Chapter 6 Connecting the Target System
- Appendix A(Note)
- Appendix B

Software:

- Chapter 1 Introduction(Note)
- Chapter 2 Function Overview
- Chapter 3 Basic Operating Instructions
- Chapter 4 Description of Commands
- Chapter 5 Applications
- Appendix(Note)

Note: Chapter 1 and the Appendix of the IE-78310A-R Manual (Hardware) are the same as those of the IE-78310A-R Manual (Software).

This manual is intended for users who are using the MD series (Concurrent CP/MTM). Users not using the MD series (i.e. users using the PC-9800 series or IBM PC/ATTM) should also refer to Appendix B.

Remark: The MD series or PG-2000 is not manufactured.

1.1 Use of the IE-78310A-R Manual

This section explains the relationship between the procedure from installation of the IE-78310A-R to debugging and gives the chapters to be referred to.

| Work | Chapters to be referred to |
|---------------------------------------|-------------------------------|
| Start: ↓ | Chapter 1 (Hardware/Software) |
| Unpacking: ↓ | Chapter 3 (Hardware) |
| Installation: ↓ | Chapter 3 (Hardware) |
| Connecting peripheral equipment: ↓ | Chapter 4 (Hardware) |
| Connecting the target system: ↓ | Chapter 6 (Hardware) |
| Debugging: | Chapters 2 and 3 (Software) |

- . For the basic specifications and appearance of the IE-78310A-R as a debugger, refer to Chapter 2 (Hardware).
- . To know more about the RS-232-C interface of the IE-78310A-R, refer to Chapter 5 (Hardware).
- . To know more about the IE-78310A-R commands, refer to Chapter 4 (Software).
- . To learn the efficient debugging method, refer to Chapter 5 (Software).

1.2 Configuration of the IE-78310A-R Manual

| |
|----------|
| Hardware |
|----------|

Chapter 2: Function Overview

Explains the basic specifications and appearance of the IE-78310A-R as a debugger.

Skim through this chapter before using the IE-78310A-R.

Chapter 3: Installation

Describes unpacking the IE-78310A-R, connecting the accessories, and setting the main unit in detail. Read this chapter before using the IE-78310A-R.

Chapter 4: Configuring the System

Describes how to connect peripheral equipment such as a host machine, terminal, or PROM programmer to the IE-78310A-R in detail. Refer to the sections corresponding to your peripheral equipment.

After an IE-78310A-R is installed according to Chapter 3 (Hardware), read this chapter to connect peripheral equipment to the IE-78310A-R.

Chapter 5: RS-232-C Interface Functions

Describes the serial interface functions (channels 1 and 2) of the IE-78310A-R as an RS-232-C interface in detail.

This chapter may be skipped when you use peripheral equipment manufactured by NEC. Read this chapter when you connect an IE-78310A-R serial interface to a device manufactured by a company other than NEC.

Chapter 6: Connecting the Target System

Describes in detail how to connect the target system in which the uPD78312A or uPD78310A is used to the IE-78310A-R.

After peripheral equipment is connected to the IE-78310A-R according to Chapter 4, read this chapter to connect the target system to the IE-78310A-R.

| |
|----------|
| Software |
|----------|

Chapter 2: Function Overview

Gives details of the IE-78310A-R functions for the stand-alone system and system software.

Skim through this chapter before debugging.

Each IE-78310A-R function described in this chapter corresponds to a command.

Chapter 3: Basic Operating Instructions

Explains the debugging procedure of the IE-78310A-R and how to use commands.

Read this chapter before debugging.

This chapter explains the debugging procedure and commands used for each operation. An example of execution using a sample program is also explained in detail.

This chapter will aid the user in debugging.

Chapter 4: Description of Commands

Details all the IE-78310A-R commands. This chapter may be skipped.

Read this chapter to learn more about the commands.

Chapter 5: Applications

Explains the advanced functions of the IE-78310A-R.

Read this chapter to learn the efficient debugging method.

CHAPTER 2 FUNCTION OVERVIEW

2.1 Overview

This chapter explains the basic specifications and appearance of the IE-78310A-R as a debugger. Refer to Chapter 2 in the IE-78310A-R Manual (Software) for the debugger functions.

Chapter 2 consists of the following five sections.

Section 2.1 outlines the IE-78310A-R functions.

Section 2.2 explains the basic specifications of the IE-78310A-R as a debugger.

Section 2.3 explains the system configuration of the IE-78310A-R.

Section 2.4 explains the appearance and electrical specifications of the IE-78310A-R.

Section 2.5 explains the configuration of the IE-78310A-R using a block diagram.

2.2 Basic Specifications

| Item | | Contents |
|-------------------------------|---------------------------|---|
| Target CPU | | uPD78312A, uPD78310A |
| CPU clock | | Up to 6 MHz, (external oscillation for 12 MHz) |
| Built-in memory | Alternate memory capacity | 64K bytes (expansion memory) plus 16K bytes (internal ROM alternate memory) |
| | Mapping unit | Internal ROM: 0, 4K, 8K, or 16K bytes Expansion memory: 256 bytes |
| Break function | Break address | 5 points or 5 partitions |
| | Break register | BRA, BRD, BRE, BRT |
| | Break factor | 1. Address 2. Data 3. Status 4. Loop count 5. External data 6. Number of steps 7. Timer 8. Forced break (manual break, non-map break, write-protect break) |
| Realtime trace | Trace capacity | 44 bits x 2K words |
| | Trace mode | Entire trace, qualify trace |
| | Trace contents | Addresses (16 bits), data (8 bits), one of ports 0 to 5, external signal, I-buffer status, read/write macro service status |
| Command function | | Online assembling, disassembling |
| | | Symbolic debugging |
| | | Console redirection, line edition, help commands |
| External interface (RS-232-C) | | Number of channels: 2 Baud rate: 300, 600, 1200, 2400, 4800, 9600, 19200 (bps) |

(to be continued)

(Cont'd)

| Item | Contents |
|----------------------------------|--|
| External interface (RS-232-C) | <p>Character specifications:</p> <p>For channel 1</p> <p>Character length: 8 bits</p> <p>Parity bit: None</p> <p>Stop bit length: 2 bits</p> <p>For channel 2</p> <p>Character length: 7 or 8 bits</p> <p>Parity bit: Even, odd, none</p> <p>Stop bit length: 1 or 2 bits</p> <p>Data transfer:</p> <p>For channel 1</p> <p>Single-character handshaking and flow control handshaking</p> <p>For channel 2</p> <p>Single-character handshaking or flow control handshaking</p> <p>Equipment to be connected:</p> <p>For channel 1</p> <p>Console and host machine</p> <p>For channel 2</p> <p>PROM programmer (PG-1500, PG-2000)</p> |
| Others | <ul style="list-style-type: none">. Stand-by function is supported.. Latch-up protection circuit is built in. |


2.3 System Configuration

The IE-78310A-R can be used by itself or in conjunction with a host machine.

When the IE-78310A-R is to be used by itself, connect it as shown in Figure 2-1.

This is called the stand-alone mode.


Fig. 2-1 Example of Connecting the IE-78310A-R in the Stand-alone Mode



When the IE-78310A-R is used with a host machine, connect them as shown in Figure 2-2.

This is called the system mode.


Fig. 2-2 Example of Connecting the IE-78310A-R in the System Mode



2.4 Appearance

Appearance

Fig. 2-3 IE-78310A-R



Dimensions

Depth: 395 mm

Width: 291 mm

Height: 217 mm

Weight

10.5 kg

Rating

100 VAC, 50 or 60 Hz, 5 A

Operating temperature

10° C to 40° C

Storage temperature

-20° C to +45° C

Ambient humidity

10% to 90% (RH)

2.5 Configuration

Figure 2-4 shows the basic hardware configuration of the IE-78310A-R.

Fig. 2-4 IE-78310A-R Hardware Configuration





Figure 2-5 is the block diagram of a driver module.
Figure 2-6 is the block diagram of a control/trace module.

Target system

Fig. 2-5 Block Diagram of Driver Module



Control/trace module

Port emulator

The port emulator emulates the ports (P1, P4, and P5) on a uPD78312A or uPD78310A, but not on the uPD78319A (evaluation chip) in the external circuit.

Break controller

The IE-78310A-R is provided with various break functions.

A combination of break conditions enables different break condition to be set.

The break controller controls the break conditions.

Trace controller

The IE-78310A-R is provided with various trace functions.

A combination of trace conditions enables different trace condition to be set.

The trace controller controls such trace conditions.

Self-diagnostic section

The self-diagnostic section diagnoses the IE-78310A-R functions when the target probe is inserted into the self-diagnostic socket.

The self-diagnostic section has circuits for diagnosing the IE-78310A-R internal circuits, checking port inputs and outputs, checking the data and address buses in the extended mode, and checking analog inputs.

Latch-up warning section

When a latch-up occurs on the evaluation chip, the latch-up warning section turns off the power of the evaluation chip, the CMOS around the evaluation chip, and the TTL device before the CMOS.

Alternator, system memory section

The alternator and system memory section control basic operations when the evaluation chip is inoperative.

Emulation memory section

The IE-78310A-R has a 64K-byte memory which can be accessed by the uPD78310A or uPD78312A.


When the target system has not been developed, the software can be debugged logically by using this memory.

Internal ROM

The uPD78312A has an internal ROM, which enables faster operation than an external memory. The IE-78310A-R also has a memory equivalent to an internal ROM which enables high-speed operation, in addition to an emulation memory.

An internal ROM of 0, 4K, 8K, or 16K bytes can be used.

Fig. 2-6 Block Diagram of Control/Trace Module



Dual port RAM

The dual port RAM is the work area for the control CPU and the communication area for the multiple buses and the control CPU.

Driver control circuit

The driver control circuit interfaces with a driver module.

Serial interface circuit

The serial interface circuit has an RS-232-C interface (two channels).

Trace RAM

The trace RAM retains trace data of up to 2047 steps for each event.

Memory selector

The memory selector selects a ROM, DRAM, dual port RAM, trace RAM, or driver memory by switching the memory bank.

CHAPTER 3 INSTALLATION

3.1 Overview

This chapter describes unpacking the IE-78310A-R, connecting the accessories, and setting the main unit in detail.

Read this chapter before using the IE-78310A-R.

Refer to Chapter 4 for details of how to connect peripheral equipment to the IE-78310A-R.

Section 3.2 explains unpacking the IE-78310A-R.

Section 3.3 explains the IE-78310A-R main unit and its accessories.

Section 3.4 explains how to connect accessories to the IE-78310A-R main unit, and gives notes about the installation location.


Section 3.5 explains the setting method and functions of the switches on the IE-78310A-R main unit, and describes the setting method using commands.

Section 3.6 explains the setting of jumpers on the control/trace board. Normally, this section may be skipped.

3.2 Unpacking

The IE-78310A-R main unit and accessory box are packed in a box (refer to Figure 3-1).

Fig. 3-1 Package




3.3 Confirmation

Confirm that the box contains the following parts.

1. Main unit

Remove the five screws on the right side of the IE-78310A-R main unit to open the cover.

Fig. 3-2 Right-Side View of IE-78310A-R



- a) Self-check board: 1
- b) Emulation board: 1
- c) Break board: 1
- d) Control/interface board: 1
- e) Control/trace board: 1

Fig. 3-3 Location of the Boards







Fig. 3-4 Boards of Main Unit




Self-check board




Emulation board



Break board



Control/interface board





Control/trace board

2. a) SHRINK DIP target probe: 1
- b) QUIP target probe: 1
- c) Target probe cable: 2
- d) External sense clip unit: 1
- e) Hardware Instruction Manual: 1
- f) Software Instruction Manual: 1
- g) System floppy disk (with case): 1


| | | |
|----|--------------------------------|---|
| h) | Program product contract form: | 1 |
| i) | Power cord: | 1 |
| j) | RS-232-C interface cable: | 1 |
| k) | Ground lead: | 1 |
| l) | Spare fuse: | 1 |
| m) | Part base: | 2 |
| n) | AC adapter: | 1 |
| o) | Accessory list: | 1 |
| p) | Check certificate: | 1 |
| q) | Warranty: | 1 |
| r) | List of packed contents: | 1 |

Fig. 3-5 Accessories







Power cord (AC adapter)



Ground lead



Part base



Fuse



System floppy disk

3.4 Installation

First, connect accessories to the IE-78310A-R main unit.

(1) Connecting the target probe

- . Probe cable
- . SHRINK DIP probe unit
- . QUIP probe unit

The type of probe unit used (SHRINK DIP or QUIP) depends upon the type of package of the target system (uPD78312A or uPD78310A).


- ① Remove the five screws on the right side of the IE-78310A-R main unit to open the cover, and remove the fittings securing the drawer to dismount the emulation board (second board from the top). To dismount the board, pull the card pullers on either side of the board toward you.
- ② Insert the connectors (CN1 and CN2) of the target probe cable into the connectors (CN1 and CN2) on the emulation board (refer to the figure below).

Emulation board $\left[\begin{array}{cc} \text{CN1} \leftarrow \rightarrow \text{CN1} \\ \text{CN2} \leftarrow \rightarrow \text{CN2} \end{array} \right]$ Target probe

Be sure that the connectors are connected correctly.

If an incorrect connection is made, the IE-78310A-R main unit may be damaged.

Fig. 3-6 Connection Diagram of the Target Probe Cable



③ Connect the probe cable to the probe unit.

. When a SHRINK DIP probe is used, connect it as follows.


Probe cable $\left[\begin{array}{c} \text{CN3} \leftarrow \rightarrow \text{CN3 (lower)} \\ \text{CN4} \leftarrow \rightarrow \text{CN4 (upper)} \end{array} \right]$ Probe unit

Probe unit $\left[\text{CN5} \leftarrow \rightarrow \text{CN5} \right]$ Pin terminal

Be sure that the connection is correct.

If an incorrect connection is made, the IE-78310A-R main unit may be damaged.

Fig. 3-7 Connection Diagram of SHRINK DIP Probe Unit



- When a QUIP DIP probe is used, connect it as follows.


Probe cable $\left[\begin{array}{l} \text{CN3} \longleftrightarrow \text{CN3 (lower)} \\ \text{CN4} \longleftrightarrow \text{CN4 (upper)} \end{array} \right]$ Probe unit

Probe unit $\left[\begin{array}{l} \text{CN5 (lower)} \longleftrightarrow \text{CN5} \\ \text{CN6 (upper)} \longleftrightarrow \text{CN6} \end{array} \right]$ Pin

Be sure that the connection is correct.

If an incorrect connection is made, the IE-78310A-R main unit may be damaged.

Fig. 3-8 Connection Diagram of the QUIP Probe Unit




- ④ Insert the emulation board into the IE-78310A-R.

(2) Connecting the external sense clip

- ① Remove the five screws on the right side of the IE-78310A-R main unit to open the cover, and remove the fittings securing the drawer to dismount the break board (third board from the top). To dismount the board, pull the card pullers on either side of the board toward you.
- ② Insert the connector of the external sense clip into the connector (CN1) on the break board.
- ③ Insert the break board into the IE-78310A-R.


Fig. 3-9 Connection Diagram of External Sense Clip



(3) Connecting the power cord

Connect the AC adapter (power cord) to the AC IN jack on the rear of the IE-78310A-R main unit.


Fig. 3-10 Connection Diagram of Power Cord



(4) Connecting the RS-232-C interface cable

Connect the RS-232-C interface cable to the CH1 or CH2 connector on the front of the IE-78310A-R main unit.

Fig. 3-11 Connection Diagram of RS-232-C Interface Cable




(5) Location

Install the IE-78310A-R main unit in a place free from dust.


Do not place any obstructions near the air intake.

3.5 Setting

Fig. 3-12 IE-78310A-R



Front



Rear


| | |
|--|--|
| Power cord | When connecting the AC adapter to a wall outlet, the power switch of the IE-78310A-R main unit must be turned off. |
| Power switch | This is a push button switch having a power-on display LED. Pressing this switch when the LED is off turns on the power of the IE-78310A-R main unit and lights the LED. Pressing this switch in the on state turns off the power of the IE-78310A-R main unit and turns off the LED. |
| Reset switch | This is also a push-button switch. Pressing this switch resets the IE-78310A-R. |
| To set the following RS-232-C mode setting switches, open the front cover. | |
| Terminal/modem mode setting switch | This is a slide switch. Sliding the switch from right to left, when viewed from the front panel, sets the modem mode. Sliding the switch from left to right sets the terminal mode. This switch is factory-set to the modem mode. |
| RTS setting switch | This is a DIP switch. Sliding the switches upward sets them ON. Sliding the switches downward sets them OFF. RTS is set by switches 1 to 3. Switch 1 is factory-set to ON and switches 2 and 3 are factory-set to OFF (RTS selection). |
| Frame ground (FG) setting switch | This is a DIP switch. Sliding the switch upward sets it ON. Sliding the switch downward set it OFF. FG is set by switch 4. Switch 4 is factory-set to OFF. (The frame ground (FG) and signal ground (SG) are in the open state.) |
| Baud rate setting switch | <ul style="list-style-type: none"> . This is a micro DIP switch. Turning the switch clockwise or counterclockwise sets the baud rate. . This switch has 10 (0 to 9) positions. Position 7, which corresponds to 0 bps, must not be used. . This switch is used to set the baud rate of channel 1. This switch is factory-set to position 5 (9600 bps). To set the baud rate of channel 2, use a command. <p>For details, refer to the MOD command in the IE-78310A-R Manual (Software).</p> |

(to be continued)

(Cont'd)

| | |
|---|---|
| Handshaking setting switch | Channel 1 is set for both hardware (single character) handshaking and software (flow control) handshaking. Channel 2 is set for either hardware (single character) handshaking or software (flow control) handshaking using a command. For details, refer to the explanation of the MOD command in the IE-78310A-R Manual (Software). |
| Character specifications setting switch | Setting for channel 1 Character length: 8 bits Parity bit: None Stop bit length: 2 bits Channel 2 can be set using a command. Character length: 7 or 8 bits Parity bit: Even, odd, none Stop bit length: 1 or 2 bits For details, refer to the explanation of the MOD command in the IE-78310A-R Manual (Software). |

Fig. 3-13 RS-232-C Mode Setting Switches on IE-78310A-R Front Panel




3.6 Setting of Jumpers on Control/Trace Board

Normally, skip this chapter. Do not change the factory-set jumpers on the control/trace board.

If the settings are changed, the IE-78310A-R may not operate normally.


- ① Remove the five screws on the right side of the IE-78310A-R main unit to open the cover, and remove the fittings securing the drawer.
- ② Disconnect the three RS-232-C cables and two flat cables connecting the control/interface board and control/trace board.
- ③ Dismount the control/trace board (fifth board from the top). To dismount the board, pull the card pullers on either side of the board toward you.

Fig. 3-14 Location of Control/Trace Board



Note: When connecting the RS-232-C cables, follow the figure below.

Fig. 3-15 Location of RS-232-C Sockets on the Control/Trace Board




④ Factory settings of jumpers

| Jumper number | Setting |
|---------------|----------------------------|
| JP2 | Short 1 and 6. |
| JP3 | Short 1 and 6. |
| JP4 | Open |
| JP5 | Open between 1 and 6(Note) |
| | Open between 2 and 5(Note) |
| | Short 3 and 4. |
| JP6 | Short 1 and 2. |
| JP7 | Short 1 and 2. |

Note: When a memory board other than the SB-0512 is used for an expansion slot, short 1 and 6, and 2 and 5 of JP5.

Fig. 3-16 Location of Jumpers on the Control/Trace Board



CHAPTER 4 CONFIGURING THE SYSTEM

4.1 Overview

Chapter 4 explains the methods for connecting the IE-78310A-R and peripheral equipment. Read this chapter before starting connection.

The chapter illustrates the connection methods with explanations of actual host machines and PROM programmers. This chapter also explains action to be taken in the event of a failure.

Section 4.2 outlines peripheral equipment that can be connected to the IE-78310A-R.

Section 4.3 deals in detail with the methods of connecting the IE-78310A-R and each of the peripheral equipment mentioned in Section 4.2.

Section 4.4 illustrates procedures for handling failures with flow charts.

4.2 Peripheral Equipment

The following equipment may be connected to the IE-78310A-R:

- . Host machine: MD-116FD-20/HD-21
MD-116FD(HD)-10
MD-086FD(HD)-10
MD-086FD
PC-9800 Series(Note)
IBM PC/AT
- . PROM programmer: PG-1500
- . Terminal: MD-910TM

Note: The following models can be used as a host machine in the PC-9800 series.

Models Usable as a Host Machine in the PC-9800 Series

| Support models \ CPU | 8086/V30 TM | 80286 | 80386 |
|-------------------------|---|---|--|
| PC-9801 | No mark E F _{1/2/3} M _{2/3} VF ₂ VM _{0/2/4/21/11} U ₂ UV _{2/21/11} CV ₂₁ UR _{/20} UF XL _{model 1/2/4} VX _{0/2/4/01/21/41} | XL _{model 1/2/4} VX _{0/2/4/01/21/41} UX _{21/41} RX _{2/4/21/51} EX _{2/4} DX _{2/5/U2/U5} LX _{2/4/5/5C} | XL ² RL _{2/5/21/51} RA _{2/5/21/51} ES _{2/5} RS _{21/51} T _{model W2/W5} W _{7/S5/F5/F51/} F ₇₁ DS _{2/5/U2/U5} DA _{2/5/7/U2/U5/} U ₇ CS _{2/5/5W} US _{/40/80} |

(to be continued)

(Cont'd)

| Support models \ CPU | 8086/V30™ | 80286 | 80386 |
|-------------------------|--|-------|--|
| PC-9801 | UX _{21/41} RX _{2/4/21/51} EX _{2/4} XL ₂ RL _{2/5/21/51} RA _{2/5/21/51} ES _{2/5} RS _{21/51} T _{model} W2/W5/W7/ S5/F5/F51/F71 LV _{21/22} LX _{2/4/5/5C} LS _{2/5} N NV NL | | FS _{2/5/7/U2/U5/} U7 FX _{2/5/U2/U5} LS _{2/5} NS _{/20} NS/E _{/20/40} NS/T _{/20/40} NS/L _{/20/40} NC _{/40} |
| PC-H98 | | | model170-002/100 model60-002/ 040/100 modelU60-002/ 040/100 |

Remark: Products in the above table can be used with the emulator only in the normal mode.

Caution: 640K bytes or more are required for internal memory.

[PC-9800 Series software products]

| Media \ OS | MS-DOS™ | CP/M-86™ |
|------------|-------------------|-------------------|
| 8" 2D | uS5A1IE78310-P01 | uS6A1IE78310-P01 |
| 5.25" 2HD | uS5A10IE78310-P01 | uS6A10IE78310-P01 |
| 3.5" 2HD | uS5A13IE78310 | - |

MD-910™

Character display terminal MD-910™ is a standard CRT terminal that may be used as a system console for the MD Series Model 10, as an additional console of the MD-116/086 Series host machine, or as an EVAKIT or IE Series console.

The MD-910™ has the ANSI.x3.64 control sequence, DEC's VT52 control sequence, and Anritsu Electric's DDY86B control sequence facilities.

MD-116FD-20 and MD-116HD-21

The MD-116FD-20/HD-21 is a powerful microcomputer development system. It has the uPD70116, a 16-bit microprocessor (with a clock rate of approximately 10 MHz), and uses concurrent CP/M™ (called CCP/M), an operating system that enables multitasking and accommodates multiple users.

In addition, the system has another processor (I/O processor) to control various system I/O devices. The system controls the system console separately from I/O control, which reduces the I/O processor load, allowing high-speed operation.

| |
|------------------------------------|
| MD-116FD(HD)-10 MD-086FD(HD)-10 |
|------------------------------------|

The MD-086FD(HD)-10 is a microcomputer development system. It has the uPD8086, a 16-bit microprocessor (with a clock rate of 5 MHz), and uses CCP/M, an operating system that enables multitasking and accommodates multiple users.

In addition, the system has another processor (I/O processor) to control various system I/O devices. The MD-086FD-10 controls the system console separately from I/O control, which reduces the I/O processor load, allowing high-speed operation.

The MD-116FD(HD)-10 uses the uPD70116-10, a faster 16-bit microprocessor (with a clock rate of approximately 10 MHz) with a special bus for memory, to speed up operation.

| |
|----------|
| MD-086FD |
|----------|

The MD-086FD is a powerful microcomputer development system. It has the uPD8086, a 16-bit microprocessor (with a clock rate of 5 MHz) and uses CCP/M, an operating system that enables multitasking and accommodates multiple users.

In addition, the system has a special I/O processor (8-bit microprocessor uPD780) to control various system I/O devices.

The MD-086FD is equipped with a green monitor display, JIS keys, a ten-key pad, screen control keys, and functions keys.

PG-1500

When the PG-1500 is connected to a supplied board or optional socket board, it can be used as a program writer for typical 256K-bit to 4M-bit PROMs, and 4/8/16-bit single-chip microcomputers. □

The PG-1500 has key panel switches and a serial interface, so it can operate as a stand-alone PROM programmer or can be operated through a console connected to the serial interface. When connecting the PG-1500 to the IE-78310A-R, use the RS-232-C interface cable supplied with the PG-1500.

PG-2000

The PG-2000 has 32K bytes of write buffer memory, and can be used as a PROM writer for up to 256K-bit PROMs.

The PG-2000 has key panel switches and a serial interface, so it can operate as a stand-alone PROM programmer or can be operated through a console connected to the serial interface. When connecting the PG-2000 to the IE-78310A-R, use the RS-232-C interface cable supplied with the PG-2000.

4.3 Connecting Peripheral Equipment

The IE-78310A-R is connected to peripheral equipment via the RS-232-C interface.

The IE-78310A-R has two RS-232-C interfaces, one of which is used according to the peripheral equipment connected.




Table 4-1 lists the features of channel 1, and Table 4-2 lists the features of channel 2. (For details, see Chapter 5.)

Table 4-1 Features of Channel 1

| Item | | Setting |
|--------------------------|------------------|--|
| Mode selection | | Terminal/modem mode |
| Baud rate | | |
| Handshaking | | |
| Character specifications | Character length | |
| | Parity bit | |
| | Stop bit length | |
| | | 300, 600, 1200, 2400, 4800, 9600, 19200 (bps) |
| | | Hardware (1 character) and software (flow control) handshaking |
| | | 8 bits Most significant bit (MSB) is set to 0 if output, and is ignored if input. |
| | | None |
| | | 2 bits |

Table 4-2 Features of Channel 2

| Item | | Setting |
|--------------------------|-----------------|--|
| Mode selection | | Terminal/modem mode, switch-selected |
| Baud rate | Set by software | 300, 600, 1200, 2400, 4800, 9600, 19200 (bps) |
| Handshaking | | Hardware (1 character) or software (flow control) handshaking mode |
| Character specifications | | 7 or 8 bits When 8-bit length is specified, most significant bit (MSB) must be 0 if output and is ignored if input. |
| | | Even parity/odd parity/none |
| | | 1 bit/2 bits |

The subsequent sections explain how to connect individual equipment to the IE-78310A-R. In these explanations, the baud rate is assumed to be 9600 bps.

4.3.1 Connecting MD-910TM

When connecting the MD-910TM to the IE-78310A-R, follow the following procedure:

- ① Turn off power to the IE-78310A-R and MD-910TM.
- ② Set channel 1 of the IE-78310A-R as shown in Table 4-3 to connect the MD-910TM to this channel.

Table 4-3 IE-78310A-R Channel 1 Setting

| Item | Switch No. | Switch setting |
|----------------|------------|---|
| Mode selection | MODE | Modem mode |
| Baud rate | BAUDRATE | Position 5 |
| Frame ground | FG | Set pin 4 to OFF. |
| RTS select | RTS SELECT | Set pin 1 to ON, and pins 2 and 3 to OFF. |

- ③ Set the MD-910TM as shown in Table 4-4, to connect the MAIN PORT connector of the MD-910TM to the IE-78310A-R.

Table 4-4 MD-910TM Setting

| Item | | Setting |
|---------------------|-----------------|-----------------------------------|
| Bit configuration | Data length | 8 bits |
| | Parity | None |
| | Stop bit length | 2 bits |
| Modem control | | Full duplex without modem control |
| Baud rate | | 9600 bps |
| MAIN PORT interface | | RS-232-C interface |

- ④ Connect the MD-910TM to the IE-78310A-R.

Connect the MAIN PORT connector of the MD-910TM and channel 1 of the IE-78310A-R with the RS-232-C interface cable supplied with the MD-910TM.

- ⑤ Turn on the MD-910TM, then turn on the IE-78310A-R.

Settings in the MD-910TM and the IE-78310A-R are explained below in detail.

- (1) Setting the MD-910TM

The settings for the MD-910TM are performed in the setup mode in which terminal parameters are entered from the keyboard.

There are four setup modes: SETUP A to SETUP D modes. Some items that must be set are selected from these setup modes and explained below:

- (a) Setting bit configuration (data length, parity, stop bit length)

The bit configuration is set in the SETUP B mode.

Table 4-5 Setting of Bit Configuration

| Group name | Key operation | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|--|---|----|-------------|--------|----|---|------|----|---|-------|----|---|-----|----|---|------|----|---|------|----|---|-----|----|---|------|----|---|------|
| P | Press [SHIFT] and [P] simultaneously. | <p>Changes data length and parity.</p> <table> <tr> <th>P=</th><th>Data length</th><th>Parity</th></tr> <tr> <td>7M</td><td>7</td><td>Mark</td></tr> <tr> <td>7S</td><td>7</td><td>Space</td></tr> <tr> <td>7O</td><td>7</td><td>Odd</td></tr> <tr> <td>7E</td><td>7</td><td>Even</td></tr> <tr> <td>7N</td><td>7</td><td>None</td></tr> <tr> <td>8O</td><td>8</td><td>Odd</td></tr> <tr> <td>8E</td><td>8</td><td>Even</td></tr> <tr> <td>8N</td><td>8</td><td>None</td></tr> </table> | P= | Data length | Parity | 7M | 7 | Mark | 7S | 7 | Space | 7O | 7 | Odd | 7E | 7 | Even | 7N | 7 | None | 8O | 8 | Odd | 8E | 8 | Even | 8N | 8 | None |
| P= | Data length | Parity | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7M | 7 | Mark | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7S | 7 | Space | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7O | 7 | Odd | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7E | 7 | Even | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7N | 7 | None | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8O | 8 | Odd | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8E | 8 | Even | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8N | 8 | None | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STOP BIT | Position cursor at this item, then press [6] on the keyboard. | Selects one of the three stop bit lengths, 1, 1.5, or 2. | | | | | | | | | | | | | | | | | | | | | | | | | | | |

For connection to the IE-78310A-R, select 8N and 2.

(b) Setting modem control

The modem control method is set in the SETUP B mode.

Table 4-6 Modem Control Setting

| Group name | Key operation | Description |
|------------------|---|---|
| MODEM CONTROL | Press [SHIFT] and [M] simul- taneously. | Modem control method FDX A: Full duplex without modem control FDX B: Full duplex with modem control HDX: Half duplex Line is switched by control code. |

For connection to the IE-78310A-R, select FDX
A.

(c) Selecting the baud rate

The baud rate is selected in the SETUP B mode.

Table 4-7 Baud Rate Setting

| Group name | Key operation | Description |
|------------|--------------------------------------|--|
| T | Press [7] on the keyboard. | Changes the transmission baud rate. One of the following baud rates may be selected: 50, 75, 110, 134.5, 150, 200, 300, 600, 1200, 1800, 2000, 2400, 3600, 4800, 9600, or 19200 |
| R | Press [8] on the keyboard. | Changes the transmission baud rate. One of the following baud rates may be selected: 50, 75, 110, 134.5, 150, 200, 300, 600, 1200, 1800, 2000, 2400, 3600, 4800, 9600, or 19200 |

For connection to the IE-78310A-R, a baud rate
of up to 9600 bps must be selected.

(d) MAIN PORT interface

The interface is selected in the SETUP C mode.

Table 4-8 Interface Setting

| Group name | | Key operation | Description |
|------------|-----------|---|---|
| I | INTERFACE | Position cursor at this item, then press 6 on the keyboard. | Selects interface. <ul style="list-style-type: none">. RS-232-C. Current loop. TTL serial |

Select RS-232-C.

Figure 4-1 shows the MD-910TM, and Figures 4-2 and 4-3 give examples of SETUP B and SETUP C setting.

Fig. 4-1 MD-910 TM





Fig. 4-2 SETUP B



SET-UP C



(2) Setting IE-78310A-R

For connection to the MD-910TM, use channel 1 of the IE-78310A-R.

(a) Setting the terminal/modem mode

The terminal/modem mode is switched with the CHANNEL1 MODE slide switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-910TM which operates in the terminal mode, the modem mode must be set for the IE-78310A-R.

(b) Setting the baud rate

The baud rate is set with the micro DIP switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-910TM, the same baud rate must be set for the MD-910TM and the IE-78310A-R.

Table 4-9 shows micro DIP switch settings and the corresponding baud rates.

Table 4-9 Baud Rate Settings

| Switch No. | Baud rate (bps) |
|------------|-----------------|
| 0 | 300 |
| 1 | 600 |
| 2 | 1200 |
| 3 | 2400 |
| 4 | 4800 |
| 5 | 9600 |
| 6 | 19200 |
| 7 | 0 |
| 8 | 300 |
| 9 | 600 |

(c) Setting the frame ground

Set whether the frame ground and signal ground are connected or open.

The frame ground is set with the CHANNEL1 FG DIP switch (pin 4 switch) on the front panel of the unit.


When connecting the IE-78310A-R to the MD-910TM, the switch must be set for the open state.

(d) Setting RTS

One of the pins 4, 11, or 21 of the RS-232-C interface cable is selected so that RTS is to be connected to that pin.


For connection to the MD-910TM, connect RTS to pin 4.

Fig. 4-4 CHANNEL1 DIP Switch Setting



| Pin No. | Screen output | Printer output |
|---------|---------------|----------------|
| 1 | ON | OFF |
| 2 | OFF | OFF |
| 3 | OFF | ON |
| 4 | OFF | OFF |

Fig. 4-5 Setting CHANNEL1 on IE-78310A-R Front Panel




Settings in the IE-78310A-R are then completed.

Next, connection is performed.

Use the RS-232-C interface cable to connect the IE-78310A-R and MD-910TM.

Connect the MAIN PORT connector of the MD-910TM to channel 1 of the IE-78310A-R. Then, turn the power on.

Fig. 4-6 Connecting IE-78310A-R and MD-910TM



The power-on/off sequence is explained below.

(3) Power-on sequence

Either of the MD-910TM or IE-78310A-R may be turned on first.

(4) Power-off sequence

Either of the MD-910TM or IE-78310A-R may be turned off first.

4.3.2 Connecting MD-116FD-20/HD-21

Channel 1 or channel 2 of the MD-116FD-20/HD-21 is connected to channel 1 of the IE-78310A-R.

- ① Turn off the IE-78310A-R and the MD-116FD-20/HD-21.
- ② Set channel 1 of the IE-78310A-R as shown in Table 4-10.

Table 4-10 IE-78310A-R Channel 1 Setting

| Item | Switch name | Setting |
|----------------|-------------|--|
| Mode selection | MODE | Terminal mode |
| Baud rate | BAUDRATE | Position 5 |
| Frame ground | FG | Set pin 4 to OFF. |
| RTS select | RTS SELECT | Set pin 1 to ON and pins 2 and 3 to OFF. |

- ③ Set channel 1 or 2 of the MD-116FD-20/HD-21 as shown in Table 4-11.

Table 4-11 MD-116FD-20/HD-21 Setting

| Item | Channel 1 | Channel 2 | Switch/jumper setting |
|---------------------------|---------------------|-----------|--|
| RS-232-C/TTL selection | SW1 | SW1 | OFF RS-232-C |
| Mode selection | JP3 | JP6 | Short 1-2, 3-4, 5-6, 7-8, 9-10, and 11-12 |
| Baud rate | Set by the software | | |
| Frame ground | JP1 | JP4 | Open |
| RTS select (SC2 board) | SW1 | SW1 | OFF RxRDY supply |

- ④ Connect the MD-116FD-20/HD-21 to the IE-78310A-R.

Connect channel 1 of the IE-78310A-R to channel 1 or 2 of the MD-116FD-20/HD-21 with the RS-232-C interface cable supplied with the IE-78310A-R.

- ⑤ Turn on the MD-116FD-20/HD-21, then turn on the IE-78310A-R.

Below is a detailed explanation of how to set the MD-116FD-20/HD-21 and the IE-78310A-R, with the relevant circuit diagram and other illustrations.


(1) Setting the MD-116FD-20/HD-21

The MD-116FD-20/HD-21 has four serial interfaces, each for a channel (channel 1 to channel 4). Each interface has RS-232-C and TTL-compatible interface circuits.

When IE-78310A-R is connected, channel 1 or 2 of the MD-116FD-20/HD-21 is used.

Figure 4-7 gives a circuit diagram for these channels.

Fig. 4-7 MD-116FD-20/HD-21 Channel 1/2 Circuit Diagram



First, the interface selection switch SW1 is explained.

(a) RS-232-C/TTL-compatible selection switch

Either RS-232-C or TTL-compatible interface can be selected as the standard serial interface.


To connect to the IE-78310A-R, select RS-232-C.

The switch on the board must be set to OFF.

| Channel No. | Switch | Setting |
|-------------|--------|---------|
| 1, 2 | SW1 | OFF |

Figure 4-8 shows the location of the switch on the I/O interface board.


Fig. 4-8 Location of the Switch on I/O Interface Board




The mode is set according to the jumper connections.

(b) Mode selection jumpers

The mode selection jumpers set the mode of the MD-116FD-20/HD-21, either the terminal or modem mode. To connect the equipment to the IE-78310A-R, select the modem mode.



(Modem mode)




(Terminal mode)

Use an appropriate jumper as follows for the jumper connections:

| Channel No. | Mode selection jumper |
|-------------|-----------------------|
| 1 | JP3 |
| 2 | JP6 |

Figure 4-9 shows the locations of the jumpers on the I/O interface board.

Fig. 4-9 Locations of the Mode Selection Jumpers



The baud rate is switched by the software.

For details, refer to the software manual for the MD-116FD-20/HD-21.


The frame ground jumper is connected as follows:

(c) Frame ground jumpers


Whether the frame ground signal and signal ground signal are connected is determined according to the state of the state of the frame ground jumper.

Generally, JP1 or JP4 on the I/O interface board is set to the open state.

Fig. 4-12 MD-116FD-20/HD-21




MD-116FD-20




MD-116HD-21

MD-116FD-20/HD-21

External view




MD-116FD-20




MD-116HD-21

Back



When the back panel is opened

I/O interface
board



Settings for channel 1 or 2 of the MD-116FD-20/HD-21 are then completed.

After the connection is completed, supply the power.

When turning on the devices connected, be careful of the power-on sequence.

(2) Power-on sequence

- ① Turn on the power switch of the MD-116FD-20/HD-21.
- ② Turn on the power switch of the IE-78310A-R.
- ③ Turn on the power switch of the target system.

(3) Power-off sequence

- ① To terminate the system, execute the EXT command to exit the system software and return to the OS.
- ② Turn off the power switch of the target system.
- ③ Turn off the power switch of the IE-78310A-R.
- ④ Remove the floppy disk from the MD-116FD-20/HD-21.
- ⑤ Turn off the power switch of the MD-116FD-20/HD-21.

Caution: To disconnect the target system temporarily, follow the procedure below:

- ① Execute an RES_H command.
- ② The following message appears.
(Do not enter anything.)

Power on target system (Y/N)

- ③ Turn off the power switch of the target system, then disconnect the target system.
- ④ Connect the target system, then turn on the power switch.
- ⑤ Enter Y <cr>.

4.3.3 Connecting MD-116FD-10 or MD-086FD(HD)-10

This section explains the procedure for connecting channel 1 of the IE-78310A-R to one of the channels 1 to 4 of the MD-116/086FD(HD)-10.

- ① Turn off the IE-78310A-R and MD-116/086FD(HD)-10.
- ② Set channel 1 of the IE-78310A-R as shown in Table 4-12.

Table 4-12 IE-78310A-R Channel 1 Setting

| Item | Switch name | Setting |
|----------------|-------------|--|
| Mode selection | MODE | Terminal mode |
| Baud rate | BAUDRATE | Position 5 |
| Frame ground | FG | Set pin 4 to OFF. |
| RTS select | RTS SELECT | Set pin 1 to ON and pins 2 and 3 to OFF. |

- ③ Set channel 1 or 2 of the MD-086FD-10 as shown in Table 4-13.

Table 4-13 MD-086FD-10 Setting

| Item | Channel 1 | Channel 2 | Jumper connection |
|------------------------|-----------|-----------|--|
| RS-232-C/TTL selection | J10 | J15 | Open (RS-232-C) |
| Mode selection | J22 | J24 | Short 1-2, 3-4, 5-6, 7-8, 9-10, and 11-12 |
| Baud rate | Row 0 | Row 1 | Short 1-9 |
| Frame ground | J21 | J20 | Open |
| RTS select | J4 | J3 | Short pins 1-2 RxRDY supply |

- ④ Connect the MD-116/086FD(HD)-10 to the IE-78310A-R.

Connect channel 1 of the IE-78310A-R to one of the channels 1 to 4 of the MD-116/086FD(HD)-10.

Use the RS-232-C interface cable supplied with the IE-78310A-R for connection.

- ⑤ Turn on the IE-78310A-R, then turn on the MD-116/086FD(HD)-10.

The following explains how to set the MD-116/086FD(HD)-10 and the IE-78310A-R in detail, giving the relevant circuit diagram and other illustrations.

(1) Setting the MD-116/086FD(HD)-10


The MD-116/086FD(HD)-10 has four serial interfaces, each for one channel (channel 1 to channel 4). Each interface has RS-232-C and TTL-compatible interface circuits. When an optional expansion board is installed, four additional RS-232-C interfaces (for channel 5 to channel 8) are available.

In addition, another RS-232-C interface is provided for channel 9.

Channel 1 to channel 4 of the MD-116/086FD(HD)-10 may be used for connecting the equipment to the IE-78310A-R. Note that a channel other than these channels cannot be used for connection to the IE-78310A-R.

For these channels, interface selection, baud rate change, and mode selection are set by jumper connections. Figure 4-7 shows a circuit diagram of channels 1 to channel 4 of the MD-116/086FD(HD)-10.

MD-116/086FD (HD) -10



J15) are explained.

(a) RS-232-C/TTL-compatible selection jumper

interface can be selected as the standard serial interface.


IE-78310A-R, select RS-232-C.

Set the relevant jumper to the open state.

| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J10 | Open |
| 2 | J15 | Open |

Figure 4-14 shows the locations of the jumpers on the I/O interface board.


Fig. 4-14 Locations of the Jumpers on the I/O Interface Board




The mode is set according to the jumper connections.

(b) Mode selection jumpers

The mode selection jumpers are used to set the MD-116/086FD(HD)-10 to either the terminal or modem mode. To connect the equipment to the IE-78310A-R, select the modem mode.



(Modem mode)




(Terminal mode)

Use the appropriate jumper for jumper connections:

| Channel No. | Mode selection jumper |
|-------------|-----------------------|
| 1 | J22 |
| 2 | J24 |


Figure 4-15 shows the locations of the jumpers on the I/O interface board.

Fig. 4-15 Location of the Mode Selection Jumpers on the I/O Interface Board



The baud rate is set by jumper connections.

(c) Baud rate select jumper



Jumper pins are arranged as shown in the figure on the left. Pins 9 to 16 are used for reception, and pins 1 to 8 are for clock input.

Connect only one pair of jumper pins according to the desired baud rate. If there are more than one pair of pins connected, a malfunction may result. Before connecting the jumpers, be sure to disconnect the current connection. The same baud rate as for the IE-78310A-R must be selected.


The baud rate is determined according to the jumper connection as follows:

| Jumper | 1-9 | 2-10 | 3-11 | 4-12 | 5-13 | 6-14 | 7-15 | 8-16 |
|-----------------|------|------|------|------|------|------|------|------|
| Baud rate (bps) | 9600 | 4800 | 2400 | 1200 | 600 | 300 | 150 | 75 |

| Channel No. | Row |
|-------------|-----|
| 1 | 0 |
| 2 | 1 |

Figure 4-16 shows the jumper locations on the I/O interface board.

Fig. 4-16 Location of the Baud Rate Select Jumpers on the I/O Interface Board



The frame ground jumper connections are explained below.


(d) Frame ground jumper

Whether the frame ground signal and signal ground signal are connected is set with a frame ground jumper.

Generally, the jumper is set in the open state.

| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J21 | Open |
| 2 | J20 | Open |

Fig. 4-17 Location of the Frame Ground Jumpers on the I/O Interface Board



RTS select jumper connections are explained below.


(e) RTS select jumpers

The RTS select jumper is used to determine whether RxRDY is applied to RTS derived from the uPD8251AFC when RTS is connected to the CTS output in the modem mode or to the RTS output in the terminal mode.

To connect the equipment to the IE-78310A-R, connect pins 1 and 2 in J3 or J4 to supply RxRDY.


| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J4 | Short 1-2 |
| 2 | J3 | Short 1-2 |

Fig. 4-18 Location of RTS Select Jumper on
the I/O Interface Board




RTS select jumper

Fig. 4-19 MD-116/086FD(HD)-10




MD-116/086FD(HD)-10

External view




Back



When the back panel is opened

I/O interface
board



Settings for channel 1 to 4 of the
MD-116/086FD(HD)-10 are then completed.

(2) Setting IE-78310A-R

Use channel 1 of the IE-78310A-R to connect it
to the MD-116/086FD(HD)-10.

(a) Setting the terminal/modem mode

The terminal/modem mode is switched with the CHANNEL1 MODE slide switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-116/086FD(HD)-10 which operates in the modem mode, the terminal mode must be set for the IE-78310A-R.

(b) Setting the baud rate

The baud rate is set with the micro DIP switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-116/086FD(HD)-10, the same baud rate must be set for the MD-116/086FD(HD)-10 and the IE-78310A-R.

Table 4-14 shows micro DIP switch settings and selected baud rates.

Table 4-14 Baud Rate Setting

| Switch No. | Baud rate (bps) |
|------------|-----------------|
| 0 | 300 |
| 1 | 600 |
| 2 | 1200 |
| 3 | 2400 |
| 4 | 4800 |
| 5 | 9600 |
| 6 | 19200 |
| 7 | 0 |
| 8 | 300 |
| 9 | 600 |

(c) Setting the frame ground

Set whether the frame ground and signal ground are connected or open.

The frame ground is set with the DIP switch (pin 4 switch) on the front panel of the unit.

When connecting the IE-78310A-R to the MD-116/086FD(HD)-10, the switch must be set for the open state.

(d) Setting RTS

One of the pins 4, 11, or 21 of the RS-232-C interface cable is selected so that RTS is connected to that pin.

For connection to the MD-116/086FD(HD)-10, set the pins 1 to 3 of the DIP switch on the front panel of the unit so that RTS is connected to pin 4.

Figure 4-20 shows how to set the DIP switch.

Fig. 4-20 CHANNEL1 DIP Switch Setting





Fig. 4-21 Setting CHANNEL1 on the IE-78310A-R Front Panel




Settings in the IE-78310A-R are then completed.

Next, connection is performed.

Connect channel 1 of the IE-78310A-R to one of the channels, channel 1 to channel 4, of the MD-116/086FD(HD)-10 with the RS-232-C interface cable supplied with the IE-78310A-R.

Fig. 4-22 Connecting IE-78310A-R and MD-116/086FD(HD)-10



When the units are connected, turn on the power.

When supplying power, be careful of the power sequence as follows:

(3) Power-on sequence

- ① Turn on the power switch of the IE-78310A-R.
- ② Turn on the power switch of the MD-116/086FD(HD)-10.

(4) Power-off sequence

- ① Remove the floppy disk from the MD-116/086FD(HD)-10.
- ② Turn off the power switch of the MD-116/086FD(HD)-10.
- ③ Turn off the power switch of the IE-78310A-R.

4.3.4 Connecting MD-086FD

Channel 1 of the IE-78310A-R is connected to channel 1 or 2 of the MD-086FD.

Connect them in the following sequence:

- ① Turn off power to the IE-78310A-R and the MD-086FD.
- ② Set channel 1 of the IE-78310A-R as shown in Table 4-15 to connect the MD-086FD to this channel.

Table 4-15 IE-78310A-R Channel 1 Setting

| Item | Switch | Setting |
|----------------|------------|---|
| Mode selection | MODE | Terminal board |
| Baud rate | BAUDRATE | Position 5 |
| Frame ground | FG | Set pin 4 to OFF. |
| RTS select | RTS SELECT | Set pin 1 to ON, and pins 2 and 3 to OFF. |

- ③ Connect the IE-78310A-R to MD-086FD channel 1 or 2 which has a serial interface. Set channel 1 or 2 of the MD-086FD as shown in Table 4-16.

Table 4-16 MD-086FD Setting

| Item | Channel 1 | Channel 2 | Jumper connection |
|----------------|-----------|-----------|--|
| Mode selection | J17 | J19 | Short 1-2, 3-4, 5-6, 7-8, 9-10, 11-12, 13-14 and 15-16 |
| Baud rate | Row 0 | Row 1 | Short 1-9 |
| Frame ground | J16 | J15 | Open |
| RTS select | J9 | J7 | Short 1-2 to supply RxRDY |
| External clock | J8 | J6 | Short 2-3 |

- ④ Connect the MD-086FD to the IE-78310A-R.

Connect channel 1 of the IE-78310A-R to one of the channels 1 and 2 of the MD-086FD. Use the RS-232-C interface cable supplied with the IE-78310A-R.

- ⑤ Turn on the IE-78310A-R, then turn on the MD-086FD.

The following explains how to set the MD-086FD and the IE-78310A-R in detail, giving the relevant circuit diagram and other illustrations.


(1) Setting the MD-086FD

The MD-086FD has five serial interfaces, each for one channel (channel 1 to channel 4, and channel 9). In addition, there are four optional channels.

Channel 1 or channel 2 of the MD-086FD may be used for connecting the equipment to the IE-78310A-R. Note that a channel other than these channels cannot be used for connection to the IE-78310A-R.

For these channels, mode selection, baud rate change, and other settings are made by jumper connections. Figure 4-23 shows a circuit diagram of channels 1 and 2 of the MD-086FD.


Fig. 4-23 Circuit Diagram of Channels 1 and 2 of MD-086FD



The mode is set according to the jumper connections.

(a) Mode selection jumpers

The mode selection jumpers are used to set the MD-086FD to either the terminal or modem mode. To connect the equipment to the IE-78310A-R, select the modem mode.




(Modem mode)

(Terminal mode)


| Channel No. | Mode selection jumper |
|-------------|-----------------------|
| 1 | J17 |
| 2 | J19 |

Fig. 4-24 Locations of the Mode Selection Jumpers on the I/O Interface Board



The baud rate is set by jumper connections.

(b) Baud rate select jumper



Jumper pins are arranged as shown in the figure on the left. Pins 9 to 16 are used for reception, and pins 1 to 8 are for clock input.

Connect only one pair of jumper pins according to the desired baud rate. If there are more than one pair of pins connected, a malfunction may result. Before connecting the jumpers, be sure to disconnect the current connection. The same baud rate as for the IE-78310A-R must be selected.


The baud rate is determined according to the jumper connection as follows:

| Jumper | 1-9 | 2-10 | 3-11 | 4-12 | 5-13 | 6-14 | 7-15 | 8-16 |
|-----------------|------|------|------|------|------|------|------|------|
| Baud rate (bps) | 9600 | 4800 | 2400 | 1200 | 600 | 300 | 150 | 75 |

| Channel No. | Row |
|-------------|-----|
| 1 | 0 |
| 2 | 1 |

Figure 4-25 shows the jumper locations on the I/O interface board.

Fig. 4-25 Location of the Baud Rate Select Jumpers on the I/O Interface Board



The frame ground jumper connections are explained below.


(c) Frame ground jumper

Whether the frame ground signal and signal ground signal are connected is set with a frame ground jumper.

Generally, the jumper is set in the open state.

| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J16 | Short 1-2 |
| 2 | J15 | Short 1-2 |

Fig. 4-26 Locations of the Frame Ground Jumpers on the I/O Interface Board



RTS select jumper connections are explained.


(d) RTS select jumpers

The RTS select jumper is used to determine whether RxRDY is applied to RTS derived from the uPD8251AFC when RTS is connected to the CTS output in the modem mode or to the RTS output in the terminal mode.

To connect the equipment to the IE-78310A-R, connect pins 1 and 2 in J7 or J9 to supply RxRDY.

| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J9 | Short 1-2 |
| 2 | J7 | Short 1-2 |

Fig. 4-27 Locations of RTS Select Jumpers on the I/O Interface Board



External clock jumper connections are explained below.

(e) External clock jumpers

The external clock jumpers are used to select a clock, for supplying clock pulses to USART, either an internal or external clock.

To connect the equipment to the IE-78310A-R, connect pins 2 and 3 in J8 or J6 to use the internal clock.

| Channel No. | Jumper | Connection |
|-------------|--------|------------|
| 1 | J8 | Short 2-3 |
| 2 | J6 | Short 2-3 |

Fig. 4-28 Locations of External Clock Jumpers on the I/O Interface Board






Fig. 4-29 MD-086FD

MD-086FD


(i) External view



(ii) Back



(iii) When the back panel is opened



Settings for channel 1 or 2 of the MD-086FD are then completed.

(2) Setting IE-78310A-R

Use channel 1 of the IE-78310A-R to connect it to the MD-086FD.

(a) Setting the terminal/modem mode

The terminal/modem mode is switched with the CHANNEL1 MODE slide switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-086FD which operates in the modem mode, the terminal mode must be set for the IE-78310A-R.

(b) Setting the baud rate

The baud rate is set with the micro DIP switch on the front panel of the unit.

When connecting the IE-78310A-R to the MD-086FD, the same baud rate must be set for the MD-086FD and the IE-78310A-R. Table 4-17 shows micro DIP switch settings and selected baud rates.

Table 4-17 Baud Rate Setting

| Switch No. | Baud rate (bps) |
|------------|-----------------|
| 0 | 300 |
| 1 | 600 |
| 2 | 1200 |
| 3 | 2400 |
| 4 | 4800 |
| 5 | 9600 |
| 6 | 19200 |
| 7 | 0 |
| 8 | 300 |
| 9 | 600 |

(c) Setting the frame ground

Set whether the frame ground and signal ground are connected or open.

The frame ground is set with the CHANNEL1 FG DIP switch (pin 4 switch) on the front panel of the unit.

When connecting the IE-78310A-R to the MD-086FD, the DIP switch must be set for the open state.

(d) Setting RTS

One of the pins 4, 11, or 21 of the RS-232-C interface cable is selected so that RTS is connected to that pin.

For connection to the MD-086FD, set the pins 1 to 3 of the DIP switch on the front panel of the unit so that RTS is connected to pin 4.

Figure 4-30 shows how to set the DIP switch.

Fig. 4-30 CHANNEL1 DIP Switch Setting





Fig. 4-31 Setting CHANNEL1 on the IE-78310A-R Front Panel




Settings in the IE-78310A-R are then completed.

Next, connection is performed.

Use the RS-232-C interface cable supplied with the IE-78310A-R.

Connect channel 1 of the IE-78310A-R to channel 1 or 2 of the MD-086FD.

Fig. 4-32 Connecting IE-78310A-R and MD-086FD



When the units are connected, turn on the power.

When supplying power, be careful of the power sequence as follows:

(3) Power-on sequence

- ① Turn on the power switch of the IE-78310A-R.
- ② Turn on the power switch of the MD-086FD.

(4) Power-off sequence

- ① Remove the floppy disk from the MD-086FD.
- ② Turn off the power switch of the MD-086FD.
- ③ Turn off the power switch of the IE-78310A-R.

4.3.5 Connecting PG-1500

When connecting the PG-1500 to the IE-78310A-R, follow the following procedure:

- ① Turn off power to the IE-78310A-R and PG-1500.
- ② Set channel 2 of the IE-78310A-R as shown in Table 4-18.

Table 4-18 IE-78310A-R Channel 2 Setting

| Item | | Switch | Setting |
|----------------------------------|-------------|--------------------|--|
| Mode selection | | MODE | Terminal mode |
| Frame ground | | RTS, FG SELECT | Set pin 4 to OFF. |
| RTS select | | | Set pin 1 to ON, and pins 2 and 3 to OFF. |
| Handshaking | | Set by software | CHAR |
| Baud rate | | | 9600 |
| Character specifi- cations | Data length | | 8 |
| | Parity bit | | NON |
| | Stop bit | | 2 |

- ③ Connect the PG-1500 to the IE-78310A-R.

Connect channel 2 of the IE-78310A-R to the serial interface connector of the PG-1500 with the RS-232-C cable.

- ④ Turn on the PG-1500, then turn on the IE-78310A-R.

Settings in the PG-1500 and the IE-78310A-R are explained below in detail.

- ⑤ Set the mode of the PG-1500 by entering keys on the PG-1500 panel.

Table 4-19 PG-1500 Mode Setting

| Item | | | Setting |
|--------------------------|-------------|----|---------|
| Baud rate | | BR | 9600 |
| Character specifications | Parity bit | P | NON |
| | Data length | B | 8 |
| | Stop bit | SB | 2 |
| Handshaking | | XN | OFF |
| Pre-check function | | PC | OFF |

(1) Setting PG-1500

The settings for the PG-1500 are performed by pressing keys on the panel of the unit.

(a) PG-1500 key switch section



Figure 4-33 shows the key switch section. Use keys indicated by  to set the PG-1500 mode.


Fig. 4-33 PG-1500 Key Switch Section




(b) Setting procedure

The following is an example for mode setting with keys.

. Mode setting




. Remote control mode setting




The PG-1500 will then be controlled by the IE-78310A-R.


Fig. 4-34 PG-1500




Left side




Front panel




Right side



Rear panel



27A adapter



04A adapter

27A adapter

The 27A adapter is a socket adapter designed for typical 256K- to 4M-bit, PROM (27xxx) products. □

To write a program into a 78K Series PROM product, mount the 27A adapter on the PG-1500 front panel.

04A adapter

To write a program into a 4-bit single-chip microprocessor containing PROM, mount the 04A adapter on the PG-1500 front panel.

(2) Setting IE-78310A-R

For connection to the PG-1500, use channel 2 of the IE-78310A-R.

(a) Setting the terminal/modem mode

The terminal/modem mode is switched with the CHANNEL2 MODE switch on the front panel of the unit.

When connecting the IE-78310A-R to the PG-1500, the terminal mode must be set for the IE-78310A-R.

(b) Setting the frame ground

Set whether the frame ground and signal ground are connected or open.


The frame ground is set with the CHANNEL2 FG DIP switch (pin 4 switch) on the front panel of the unit. When connecting the IE-78310A-R to the PG-1500, the DIP switch must be set for the open state.

(c) Setting RTS

One of the pins 4, 11, or 21 of the RS-232-C interface cable is selected so that RTS is to be connected to that pin.

For connection to the PG-1500, set the pins 1 to 3 of the DIP switch on the front panel of the unit so that RTS is connected to pin 4.

Fig. 4-35 CHANNEL2 DIP Switch Setting



(d) Setting handshaking

Whether hardware handshaking (CHAR) or software handshaking (FLOW) is performed is set with a command. For the PG-1500, select hardware handshaking.

For how to set the handshaking, see "Setting Channel 2 Mode."

(e) Setting the baud rate

The baud rate is set with a command. The same baud rate must be set for the PG-1500 and the IE-78310A-R.

For how to set the baud rate, see "Setting Channel 2 Mode."

(f) Character specifications (data, parity bit, stop bit)

Character specifications are set with a command.

Set the data length to 8 bits, and set the same parity bit as for the PG-1500.

Set the stop bit length to 2 bits.

For how to set the character specifications, see "Setting Channel 2 Mode."

Setting channel 2 mode

$$\text{MOD}[_{\text{MODE}} = \left\{ \begin{array}{c} \text{CHAR} \\ \text{FLOW} \end{array} \right\}] [_{\text{BAUD}} = \left\{ \begin{array}{c} 19200 \\ 9600 \\ 4800 \\ 2400 \\ 1200 \\ 600 \\ 300 \end{array} \right\}] [_{\text{LONG}} \left\{ \begin{array}{c} 7 \\ 8 \end{array} \right\}] [_{\text{PAR}} = \left\{ \begin{array}{c} \text{NON} \\ \text{EVEN} \\ \text{ODD} \end{array} \right\}] [_{\text{STOP}} = \left\{ \begin{array}{c} 1 \\ 2 \end{array} \right\}]$$

MODE: Select handshaking mode.
BAUD: Select the baud rate.
LONG: Select the character length.
PAR: Select the parity bit.
STOP: Select the stop bit length.

The MOD command sets the operating conditions of serial channel 2. If operands in the command are omitted, the conditions may be set interactively.

Initially, 1-character handshaking, 9600 baud, 8-bit character without parity bit, and 2 stop bits are set.

Example


*MOD MODE=CHAR BAUD=4800 LONG=8 PAR=NON STOP=2 <cr>
*

1-character handshaking, 4800 baud, character of 8 bits, no parity bit, and 2 stop bits are set.

| | |
|-----------------------|--|
| *MOD <cr> | + Sets channel 2 operating conditions interactively. |
| MODE CHAR = FLOW <cr> | + Changes the mode to the buffer control mode. |
| BAUD 4800 = 9600 <cr> | + Changes the baud rate to 9600 baud. |
| LONG 8 = <cr> | + The character length remains unchanged. |
| PAR NON = EVEN <cr> | + Changes to even parity check. |
| STOP 2 = 1 <cr> | + Changes the stop bit length to 1. |

*

Fig. 4-36 Setting CHANNEL2 on the IE-78310A-R Front Panel



When supplying power, be careful of the power-on sequence.

(3) Power-on sequence

- ① Turn on the power switch of the PG-1500.
- ② Turn on the power switch of the IE-78310A-R.

(4) Power-off sequence

- ① Turn off the power switch of the PG-1500.
- ② Turn off the power switch of the IE-78310A-R.

4.3.6 Connecting PG-2000

When connecting the PG-2000 to the IE-78310A-R, follow the following procedure:

- ① Turn off power to the IE-78310A-R and PG-2000.
- ② Set channel 2 of the IE-78310A-R as shown in Table 4-23.

Table 4-23 IE-78310A-R Channel 2 Setting

| Item | | Switch | Setting |
|----------------------------------|-------------|--------------------|--|
| Mode selection | | MODE | Modem mode |
| Frame ground | | RTS, FG SELECT | Set pin 4 to OFF. |
| RTS select | | | Set pin 1 to ON, and pins 2 and 3 to OFF. |
| Handshaking | | Set by software | CHAR |
| Baud rate | | | 9600 |
| Character specifi- cations | Data length | | 8 |
| | Parity bit | | NON |
| | Stop bit | | 2 |

- ③ Connect the serial interface connector of the PG-2000 to the IE-78310A-R. Settings in the PG-2000 are set with an 8-bit and 4-bit DIP switches located at the bottom of the PG-2000 (see Table 4-24).

Table 4-24 PG-2000 Setting

| | | |
|-----------------|--------|---------------------|
| Baud rate | 1 to 3 | 1: OFF, 2-3: ON |
| Parity check | 4, 5 | 4: OFF 5: ON/OFF |
| Stop bit length | 6, 7 | 6-7 ON |
| Handshaking | 8 | OFF |

- ④ Connect the PG-2000 to the IE-78310A-R.

Connect channel 2 of the IE-78310A-R to the serial interface connector of the PG-2000 with a cable supplied with the PG-2000 (be sure not to use a cable other than the supplied cable).

- ⑤ Turn on the PG-2000, then turn on the IE-78310A-R.

Settings in the PG-2000 and the IE-78310A-R are explained below in detail.

(1) Setting PG-2000

Set the 8-bit DIP switch on the bottom of the PG-2000.

(a) Setting the baud rate

The baud rate is set with switches 1 to 3 of the 8-bit DIP switch, as shown in Table 4-25.

Table 4-25 Baud Rate Setting

| Switch No. Baud rate | 1 | 2 | 3 |
|-------------------------|-----|-----|-----|
| 110 | OFF | OFF | OFF |
| 300 | ON | OFF | OFF |
| 600 | OFF | ON | OFF |
| 1200 | ON | ON | OFF |
| 2400 | OFF | OFF | ON |
| 4800 | ON | OFF | ON |
| 9600 | OFF | ON | ON |

For connection to the IE-78310A-R, the same baud rate as for the IE-78310A-R must be set for the PG-2000.

(b) Setting the parity check

The parity check is set with switches 4 and 5 of the 8-bit DIP switch as shown in Table 4-26.

Table 4-26 Parity Check Setting

| Switch No. Parity check | 4 | 5 |
|----------------------------|-----|------------------|
| Even | ON | ON |
| Odd | ON | OFF |
| None | OFF | ON/OFF (Note) |

Note: Either ON/OFF may be set.

For connection to the IE-78310A-R, the same parity as for the IE-78310A-R must be set.

(c) Setting the stop bit length

The stop bit length is set with switches 6 and 7 of the 8-bit DIP switch as shown in Table 4-27.

Table 4-27 Stop Bit Length Setting

| Switch No. Stop bit length | 6 | 7 |
|-------------------------------|-----|-----|
| 1 bit | ON | OFF |
| 1.5 bits | OFF | ON |
| 2 bits | ON | ON |

The same stop bit length as for the IE-78310A-R must be set.

(d) Setting the handshaking mode


The handshaking mode is set with switch 8 of the 8-bit DIP switch as shown in Table 4-28.

Table 4-28 Setting of Handshaking


| Switch No. Hand shaking | 8 |
|----------------------------|-----|
| CHAR (without X-ON/X-OFF) | OFF |
| FLOW (with X-ON/X-OFF) | ON |

Set CHAR (without X-ON/X-OFF).


Fig. 4-37 PG-2000



Front panel




Rear panel



Bottom panel

Fig. 4-38 Rear Panel



- ① Power switch

Rocker switch. Pressing the left side of the switch on the rear panel turns power off.

- ② AC input connector

1A fuses are provided in the AC input connector and fuse holder.

- ③ GND terminal

- ④ Serial interface connector

This connector is designed for the RS-232-C interface. The mating connector is a 25-pin D-SUB connector.

Fig. 4-39 Bottom





Figure 4-39 shows the switches on the bottom of the PG-2000. These switches are used to change the serial interface operating mode.

Fig. 4-40 Switches on Bottom



(Note 1)

- Notes 1. 1 indicates that a switch is in the ON position (the switch is turned left), and 0 indicates that a switch is in the OFF position (the switch is turned right). x may be either ON or OFF position.
2. The figure shows the factory-set switch state.
3. The 4-bit DIP switch is used for factory inspection. All the switches in that DIP switch must be set in the OFF position.

Settings for the PG-2000 are then completed.
Next, the IE-78310A-R is set.

(2) Setting IE-78310A-R

Use channel 2 of the IE-78310A-R to connect it to the PG-2000.

(a) Setting the terminal/modem mode

The terminal/modem mode is switched with the CHANNEL2 MODE switch on the front panel of the unit.

When connecting the IE-78310A-R to the PG-2000, set the modem mode for the IE-78310A-R.

(b) Setting the frame ground

Set whether the frame ground and signal ground are connected or open.


The frame ground is set with the CHANNEL2 FG DIP switch (pin 4 switch) on the front panel of the unit. When connecting the IE-78310A-R to the PG-2000, the switch must be set for the open state.

(c) Setting RTS

One of the pins 4, 11, or 21 of the RS-232-C interface cable is selected so that RTS is connected to that pin.

For connection to the PG-2000, set the pins 1 to 3 of the DIP switch on the front panel of the unit so that RTS is connected to pin 4.

Fig. 4-41 CHANNEL2 DIP Switch Setting



(d) Setting the handshaking mode

Select the handshaking mode, either hardware handshaking (CHAR) or software handshaking (FLOW), with a command.

For the PG-2000, select the hardware handshaking mode.

For how to set the handshaking, see "Setting Channel 2 Mode."

(e) Setting the baud rate

Set the baud rate with a command. The same baud rate must be set for the PG-2000 and the IE-78310A-R.

For how to set the baud rate, see "Setting Channel 2 Mode."

(f) Character specifications (data length, parity bit, stop bit)

Character specifications are set with a command.

Set the data length to 8 bits, and set the same parity bit and stop bit length as for the PG-2000.

For how to set the character specifications, see "Setting Channel 2 Mode."

Setting channel 2 mode

$$\text{MOD[_MODE= } \left\{ \begin{array}{l} \text{CHAR} \\ \text{FLOW} \end{array} \right\}][_\text{BAUD= } \left\{ \begin{array}{l} 19200 \\ 9600 \\ 4800 \\ 2400 \\ 1200 \\ 600 \\ 300 \end{array} \right\}][_\text{LONG } \left\{ \begin{array}{l} 7 \\ 8 \end{array} \right\}][_\text{PAR= } \left\{ \begin{array}{l} \text{NON} \\ \text{EVEN} \\ \text{ODD} \end{array} \right\}][_\text{STOP} \\ = \left\{ \begin{array}{l} 1 \\ 2 \end{array} \right\}]$$

MODE: Select handshaking mode.
BAUD: Select the baud rate.
LONG: Select the character length.
PAR: Select the parity bit.
STOP: Select the stop bit length.

The MOD command sets the operating conditions of serial channel 2. If operands in the command are omitted, the conditions may be set interactively.

Initially, 1-character handshaking, 9600 baud, 8-bit character without parity bit, and 2 stop bits are set.


Example

```
*MOD MODE=CHAR BAUD=4800 LONG=8 PAR=NON STOP=2 <cr>
*
```

1-character handshaking, 4800 baud, character of 8 bits, no parity bit, and 2 stop bits are set.

```
*MOD <cr>          + Sets channel 2 operating conditions interactively.
MODE CHAR = FLOW <cr> + Changes the mode to the buffer control mode.
BAUD 4800 = 9600 <cr> + Changes the baud rate to 9600 baud.
LONG 8 = <cr>       + The character length remains unchanged.
PAR MON = EVEN <cr> + Changes to even parity check.
STOP 2 = 1 <cr>     + Changes the stop bit length to 1.
*
```

Fig. 4-42 Setting CHANNEL2 on the IE-78310A-R Front Panel



When supplying power, be careful of the power-on sequence.

(3) Power-on sequence

- ① Turn on the power switch of the PG-2000.
- ② Press the REM key, then press the START key on the front panel of the PG-2000.
- ③ Turn on the power switch of the IE-78310A-R.

(4) Power-off sequence

- ① Turn off the power switch of the PG-2000.
- ② Turn off the power switch of the IE-78310A-R.

CHAPTER 5 FUNCTIONS OF THE SC-232-C INTERFACE

5.1 Overview

This chapter describes in detail the functions of the RS-232-C interface (channel 1 and channel 2) for the IE-78310A-R. The instructions given in Section 4.3 are sufficient for operating the RS-232-C interface connected to the host machine or PROM program.

Read this chapter to learn more about the functions of channel 1 and channel 2.

Section 5.2 differentiates terminal mode from modem mode, which are often confused by Users of the RS-232-C interface.

Section 5.3 describes the RS-232-C interface signal lines used by the IE-78310A-R.

Section 5.4 describes the channel 1 functions in detail.


Section 5.5 describes the channel 2 functions in detail.

This chapter does not cover any RS-232-C interface standards. It only presents the functions of the RS-232-C interface for the IE-78310A-R.

5.2 Terminal Mode & Modem Mode

The RS-232-C interface was originally designed to connect a terminal to a modem. (See Figure 5-1.)

Fig. 5-1 The RS-232-C Interface



In addition, the RS-232-C interface is used to connect a terminal to a microcomputer system or to connect two microcomputer systems.

The RS-232-C interface serves the IE-78310A-R in the following way.

Fig. 5-2 Connecting the IE-78310A-R in the Stand-alone Mode





Figure 5-2 shows how to connect the IE-78310A-R in the stand-alone mode. This is an example of connecting a terminal to a microcomputer system through the RS-232-C interface.

Compare Figure 5-1 with Figure 5-2 and study the devices hooked up to the RS-232-C interface. The terminal in Figure 5-1 corresponds to the terminal in Figure 5-2, and the modem in Figure 5-1 corresponds to the IE-78310A-R in Figure 5-2. In other words, the IE-78310A-R is functioning as a modem.

In such situations, the IE-78310A-R is said to be in modem mode.

Fig. 5-3 Connecting the IE-78310A-R in the System Mode



This is an example of connecting a microcomputer system to another microcomputer system through the RS-232-C interface.

Compare Figure 5-1 with Figure 5-3 and study the devices hooked up to the RS-232-C interface.

First take a look at the part above the dotted lines in Figure 5-3.

The host machine is connected in this manner because it is frequently used with a terminal via a sub-channel.

The terminal in Figure 5-1 corresponds to the terminal in Figure 5-3, and the modem in Figure 5-1 corresponds to the host machine in Figure 5-3.

In other words, the host machine is functioning as a modem. In such situations, the host machine is said to be in modem mode.

Next take a look at the part below the dotted lines in Figure 5-3.

The IE-78310A-R in the system mode is connected to the host machine via the sub-channel.

The terminal in Figure 5-1 corresponds to the IE-78310A-R in Figure 5-3 and the modem in Figure 5-1 corresponds to host machine in Figure 5-3.

In other words, the IE-78310A-R is functioning as a terminal and the host machine is functioning as a modem. In such situations, the IE-78310A-R is said to be in terminal mode and the host machine is said to be in modem mode.

Thus, the RS-232-C interface is used to connect a terminal to a modem or a microcomputer system in the terminal mode to another microcomputer system in the modem mode.


Keep in mind that ordinary microcomputer systems provide selection between terminal mode and modem mode.

For instance, the IE-78310A-R is in the modem mode in Figure 5-2 and the terminal mode in Figure 5-3.

Let's see what is going to happen if the IE-78310A-R in Figure 5-3 is erroneously set to the modem mode.

Since the host machine is in the modem mode, the RS-232-C interface ends up with two modems at both ends. (See Figure 5-4.)


Fig. 5-4 Example of Erroneous Connection



The RS-232-C is erroneously connected, resulting in abnormal operation.


Another factor causing abnormal operation is that the individual RS-232-C signals only accept one-way transmission, thus carrying signals either from a modem to a terminal or vice versa. (See Figure 5-5.) This is further described in Section 5.3.

Fig. 5-5 Individual Signal Lines of the RS-232-C Interface



Now let's see what is going to happen if a modem is connected to another modem as shown in Figure 5-4. (See Figure 5-6.)

Fig. 5-6 Example of Erroneous Connection



Signals sent from the two modems, both destined for a terminal, clash with each other, resulting in a breakdown of one of the two interface drivers.

An erroneous terminal-to-terminal connection also results in a breakdown similar to the above modem-to-modem case.

Always connect a device in the terminal mode to a device in the modem mode through the RS-232-C interface. Never connect two devices both in the terminal mode or both in the modem mode.

The above section introduces the two modes, terminal and modem, provided in the IE-78310A-R.

The paragraph below clarifies how one device could function both as a terminal and modem, though the two are entirely different types of devices.

The signals sent from the terminal to the modem and the signals sent from the modem to the terminal can be paired because they have exactly the same meaning (except that the transmitter and receiver are switched around).

The pair of signal lines are symmetrical thus enabling the IE-78310A-R to switch with ease between the terminal mode and the modem mode.

The next section explains the RS-232-C signal lines used by the IE-78310A-R and also covers the terminal mode and modem mode.

5.3 Signal Lines Used by IE-78310A-R

In this section, a device in the terminal mode is called a terminal and a device in the modem mode is called a modem.

Table 5-1 summarizes the signal lines used by the IE-78310A-R.

Table 5-1 Signal Lines

| Line | Signal name | Symbol | Function | Direction | | Pin Number |
|------|---------------------|--------|--|-----------|----------|------------|
| | | | | Modem | Terminal | |
| 1 | Frame Ground | FG | Ground for safety | | | 1 |
| | Signal Ground | SG | Ground for signal | | | 7 |
| 2 | Transmitted Data | TxD | Line for transmitting data from terminal to modem | ← | | 2 |
| | Received Data | RxD | Line for transmitting data from modem to terminal | | → | 3 |
| 3 | Data Set Ready | DSR | Line for reporting modem ready state | | → | 6 |
| | Data Terminal Ready | DTR | Line for reporting terminal ready state | ← | | 20 |
| 4 | Request To Send | RTS | Line permitting modem to transmit data to terminal | ← | | 4* |
| | Clear To Send | CTS | Line permitting terminal to transmit data to modem | | → | 5 |

* The signals are divided into three groups in an actual circuit depending on the connected devices. See Sections 5.4 and 5.5 for details.

| Pin number | Signal name | Device connected |
|------------|-------------|---|
| 4 | RTSN | Host machine, PROM programmer, MD-910TM |
| 11 | RTSP | Pro-typer |
| 21 | RTSD | DDY-86 |

The IE-78310A-R transfers data on these eight signals. Signal lines are classified into four types.

1. Ground
2. Data
3. Static handshake
4. Dynamic handshake

Signal lines belonging to data, static handshake, or dynamic handshake work in pairs. The paired lines carry signals having the same meaning except that the transmitter and receiver are switched around.

The IE-78310A-R can transfer data, if the ground signal lines and the data signal lines are connected correctly, through software handshaking, which is further described in Sections 5.4 and 5.5.

When the static handshake signal lines and the dynamic handshake signal lines are connected in addition to the ground and data signal lines, the IE-78310A-R transfers data through hardware handshaking, which is further described in Sections 5.4 and 5.5.

The IE-78310A-R linked to an NEC machine (host machine or PROM programmer) performs hardware handshaking with all four types of lines connected.

The IE-78310A-R linked to a non-NEC machine may not be able to connect its two handshake lines.

Nevertheless, the IE-78310A-R can transfer data through software handshaking.

A description of each signal is set out below.

The ground type signals are classified into frame ground (FG) and signal ground (SG).

The FG signal equalizes the potential of the device chassis. Different FG values do not affect the RS-232-C interface transferring data.

The SG signal equalizes the potential of device signal line grounds. In order for the RS-232-C to successfully transfer data, this signal must be connected for making the ground voltage uniform, which is the basic signal between devices.

The SG signal is a very important basic signal for the RS-232-C interface.

Now let's move on to the data type signals.

The data signals are classified into transmit data (TxD) and receive data (RxD).

The TxD signal transmits data from a terminal to a modem.

The RxD signal transmits data from a modem to a terminal.

The three signals, TxD and RxD, which transmit/receive data, plus the SG make data transmission/reception possible. Faster and more accurate data transmission/reception between the IE-78310A-R and the host machine or PROM programmer can be realized by means of the static handshake signals and dynamic handshake signals, which are explained below.

The static handshake signals are classified into data set ready (DSR) and data terminal ready (DTR).

The DSR signals report to the terminal that the modem is ready, and the DTR signals report to modem that the terminal is ready.

Set both static handshake signals to valid at initialization and maintain that status, otherwise data cannot be transmitted or received.

The dynamic handshake signals are classified into request to send (RTS) and clear to send (CTS).

The RTS signal reports to the modem that the terminal is ready to receive data, and the CTS signal reports to the terminal that the modem is ready to receive data.

The crucial factor discriminating the two handshake signals is that the DSR and DTR signals indicate the state of the devices, and the RTS and CTS signals give permission to transfer data one by one. Control the RTS and CTS signals to transfer data by handshaking.




The above description indicates that

TxD and RxD (data signals)
RTS and CTS (dynamic handshake signals)
DTR and DSR (static handshake signals)

mean the same thing except that the transmitter and receiver are switched around.

The following part explains how to set the IE-78310A-R to the terminal mode or modem mode.

The following signal lines are provided in the RS-232-C interface of the IE-78310A-R.

| | | |
|--|---|-------------------------|
| Line for transmitting data to external device (output) |  | Data lines |
| Line for receiving data from external device (input) | | |
| Line for permitting to transmit data to external device (output) |  | Dynamic handshake lines |
| Line for permitting external device to transmit data (input) | | |
| Line for reporting ready state to external device (output) |  | Static handshake lines |
| Line for reporting external device ready state (input) | | |

Using data lines as an example, to set the IE-78310A-R to the terminal mode, connect the "line for transmitting data to external device" to the RS-232-C's TxD and the "line for receiving data from external device" to the RS-232-C's RxD. To set the IE-78310A-R to the modem mode, connect the "line for transmitting data to external device" to the RS-232-C's RxD and the "line for receiving data from external device" to the RS-232-C's TxD.

Fig. 5-7 Connecting Modem Mode IE-78310A-R





Fig. 5-8 Connecting Terminal Mode IE-78310A-R



The symmetrically paired signal lines facilitate mode selection between terminal and modem. Specific selection instructions are given in Sections 5.4 and 5.5.

5.4 Channel 1 Functions

| Function | | Setting |
|--------------------------|------------------|--|
| Mode selection | by switch | Terminal/modem mode |
| Baud rate | | 300, 600, 1200, 2400, 4800, 9600, 19200 (bps) |
| Handshaking | | Hardware (1 character)/software (flow control) handshaking |
| Character specifications | Character length | 8 bits. The most significant bit (MSB) is 0 at output and ignored at input. |
| | Parity bit | None |
| | Stop bit length | 2 bits |


Use channel 1 to connect the IE-78310A-R to the terminal (console) or host machine through the RS-232-C interface cable.

Each table column is explained in detail.

Terminal mode/modem mode selection

Select the terminal mode or modem mode by sliding the switch on the front panel of the IE-78310A-R. (See Figure 5-9.)


Fig. 5-9 Channel 1 Setting on the Front Panel of the IE-78310A-R



| | |
|-------------------------------|------------------|
| Device connected | IE-78310A-R mode |
| Terminal (MD-910TM, etc.) | Modem |
| Host machine (MD-086FD, etc.) | Terminal |

Figure 5-10 is an example of a circuit diagram showing how the slide switch works.

Fig. 5-10 Channel 1 Circuit



* See Section 5.5.2.

5.4.1 RTS setting

Pin #4 is assigned for RTS in the RS-232-C interface. But in other devices, pin No.4 is left active and another pin is assigned for signal lines having the equivalent RTS function.

Pins other than #4 should be able to be connected to RTS for hardware handshaking with such devices.

The IE-78310A-R accepts connection to a pro-typer, one of such devices.

Follow Figure 5-11 for RTS setting.



Always set the corresponding DIP switch to the RTSN setting except when a pro-typer is connected.

Set to RTSN for MD-910TM connection.

The baud rate for this particular connection is up to 9600 bps.

To conclude, fixed setting to RTSN is satisfactory for connecting the host machine to the IE-78310A-R in system mode using the MD-910TM console in the stand-alone mode.

Fig. 5-11 Channel 1 Setting on IE-78310A-R Front Panel



| RTS name selection | RTS, FG setting (CH 1) | | | | Device connected |
|--------------------|------------------------|-----|-----|-----|---|
| | 1 | 2 | 3 | 4* | |
| RTSN | ON | OFF | OFF | OFF | Host machine, PROM programmer, MD-910TM |
| RTSP | OFF | ON | OFF | OFF | Pro-typer |
| RTSD | OFF | OFF | ON | OFF | DDY-86 |

Use this setting for ordinary use.

* Channel 1 DIP switch #4 sets signal ground (SG) and frame ground (FG) to common (ON) or open (OFF). Ordinary setting is open (OFF).


5.4.2 Baud rate selection

Use the same baud rate for the IE-78310A-R and the terminal or host machine to be connected.

Select the baud rate by sliding the micro DIP switch.

Figure 5-12 shows how to select the baud rate.

Fig. 5-12 Channel 1 Baud Rate Setting on the Front Panel of the IE-78310A-R



| Switch position | Baud rate (bps) |
|-----------------|-----------------|
| 0 | 300 |
| 1 | 600 |
| 2 | 1200 |
| 3 | 2400 |
| 4 | 4800 |

| Switch position | Baud rate (bps) |
|-----------------|-----------------|
| 5 | 9600 |
| 6 | 19200 |
| 7 | 0* |
| 8 | 300 |
| 9 | 600 |

* Do not set to this position as data cannot be transferred because no pulse is generated.

5.4.3 Handshaking

This section describes the hardware handshaking function with the CTS, DSR, and DTR handshake signals connected and the software handshake function with those signals disconnected, taking modem-mode operation as an example.

(a) Hardware handshaking

Data transmission

When both RTS and DTR are active, the IE-78310A-R assumes that the terminal is ready to receive data and transmits data to RxD.

Data reception

Always keep DSR in the active state. Set CTS to the inactive state while data reception is not yet ready. Reset CTS to the active state when data can be accepted. The IE-78310A-R then receives data from TxD.

The IE-78310A-R reverses the RxRDY pin on the uPD8251AF IC, which is used as the RS-232-C interface, and outputs the data to CTS.

When the data is transferred from the RS-232-C to the reception buffer, the RxRDY pin is set to 1. When the data is transferred from this buffer to the IE-78310A-R CPU, the RxRDY pin is reset to 0.


This function controls CTS so that the terminal does not transmit the succeeding data until the reception buffer is emptied.

The dynamic handshake signals, which are used to control data byte by byte, are also called 1-character handshake signals.

Figure 5-13 and Figure 5-14 are flowcharts for hardware handshaking.

Fig. 5-13 Handshaking

Modem-to-terminal
transfer




- | | |
|---|---|
| ① Turn on the power to turn DSR on. | ① Turn on the power to turn DTR on. |
| ② Monitor the DTR pin. OFF is error and ON means go to the next step. | ② Monitor the DTR pin. OFF is error and ON means go to the next step. |
| ③ Set the data to be transferred. | ③ Turn RTS on and permit data to be transferred to the external device. |
| ④ Do not start transferring data until the RTS comes on. | ④ Check by polling to see if data reception is completed. |
| ⑤ Transfer the data. | ⑤ Read the data. |

* Turn RTS on to pulse.

Fig. 5-14 Handshaking

Terminal-to-modem
transfer



- | | |
|---|---|
| ① Turn on the power to turn DSR on. | ① Turn on the power to turn DTR on. |
| ② Monitor the DTR pin. OFF is error and ON means go to the next step. | ② Monitor the DTR pin. OFF is error and ON means go to the next step. |
| ③ Turn CTS on and permit data to be transferred to the external device. | ③ Set the data to be transferred. |
| ④ Check by polling to see if data reception is completed. | ④ Do not start transferring the data until CTS comes on. |
| ⑤ Read the data. | ⑤ Transfer the data. |

* Turn CTS on to pulse.

(b) Software handshaking

Data transmission

The IE-78310A-R assumes that the terminal is always ready to receive data and transmits data to RxD. It stops transmitting data when it receives Ctrl-S from the terminal via TxD.

Channel 1 of the IE-78310A-R stops transmitting data 4 or 5 characters after receiving Ctrl-S.

The IE-78310A-R resumes data transmission when it receives Ctrl-Q from the terminal via TxD.

Data reception

The IE-78310A-R always accepts data. It receives data by interrupt processing and saves the received data in the buffer. When the buffer is about to overflow, it transmits Ctrl-S to the terminal via RxD requesting to stop transmitting data for a while. The data transmitted immediately after this request is accepted in the buffer.

Then the IE-78310A-R transfers the buffer data to its CPU. When the buffer is almost empty, it transmits Ctrl-Q to the terminal via RxD requesting the resumption of data transmission.

The IE-78310A-R channel 1 issues Ctrl-S when its 128-byte buffer is 50% full.

Then the IE-78310A-R channel 1 issues Ctrl-Q when the buffer is 35% filled with data.

Therefore, some data may be lost when the terminal connected to channel 1 is the kind that transmits 128/2 bytes or more data, after receiving Ctrl-S.

Unlike hardware handshaking, which controls data byte by byte, the software handshaking function controls data by blocks.

The software handshaking is also called flow control.

Channel 1 employs both hardware handshaking and software handshaking to transfer data. Channel 1 is provided with a 128-byte data buffer for saving serial data. When the buffer is 50% full, channel 1 issues Ctrl-S requesting to stop data transmission, and when the buffer is 35% full it issues Ctrl-Q requesting the resumption data transmission.

The hardware handshaking function eliminates overwriting of data by adjusting the hardware. Moreover, it manipulates CTS signals to completely stop the hardware from transferring data when the buffer is almost full.

Therefore, when the handshake signals are connected, the data will never be lost.

When the hardware signals are disconnected, the software handshaking function alone is effective. Be aware of the buffer capacity, which cannot hold 128/2 bytes or more data transferred after receiving Ctrl-S. In this case, some data may be lost.

5.4.4 Character specifications

The character specifications at data transmission/reception are as follows.

(a) Character length

The character length is fixed to 8 bits.

The most significant bit (MSB) is always 0 for IE-78310A-R output.

The most significant bit (MSB) is ignored and always assumed to be 0 for IE-78310A-R input.

(b) Parity bit

No parity bit is provided.

(c) Stop bit

The stop bit is fixed to 2 bits.

5.5 Channel 2 Functions

| Function | | Setting | |
|--------------------------|-----------------|----------------------------------|--|
| Mode selection | | Terminal/modem mode by switching | |
| Baud rate | | Software switching | 300, 600, 1200, 2400, 4800, 9600, 19200 (bps) |
| Handshaking | | | Hardware (1-character) handshaking or software (flow-control) handshaking |
| Character specifications | Character | | 7 bits or 8 bits. For 8-bit specification, the most significant bit (MSB) is 0 at output and ignored at input. |
| | Parity bit | | Even parity/odd parity/no parity |
| | Stop bit length | | 1 bit/2 bits |

Use channel 2 to connect the IE-78310A-R to the PROM programmer.


All channel 2 settings, except for the terminal mode/modem mode selection, can be done by means of software (commands), thus enhancing the choice of devices to be connected.

Each table column is explained in detail.

5.5.1 Terminal mode/modem mode selection

Select the terminal mode or modem mode by sliding the switch on the front panel of the IE-78310A-R. (See Figure 5-15.)

Fig. 5-15 Channel 2 Setting on the Front Panel of the
IE-78310A-R



Mode setting instructions are given supposing that the PROM programmer (PG-2000) is connected. (This also applies to PG-1500.)

The PG-2000 is a device with the modem mode interface function.

Use the attached cable to connect the PG-2000 to the IE-78310A-R in the modem mode.

Caution: The IE-78310A-R can be connected to the PG-2000 both in the modem mode because the cable attached to the PG-2000 is internally modified to accommodate such connection. Be sure to use the cable attached to the PG-2000 to connect them. Never use other cables.

Figure 5-16 shows connection by the cable attached to the PG-2000.

Fig. 5-16 Connection by the Cable Attached to PG-2000





Figure 5-17 is an example of a circuit diagram showing how the slide switch works.

Fig. 5-17 Channel 2 Circuit



* See Section 5.5.2.

5.5.2 RTS setting



Pin #4 is assigned for RTS in the RS-232-C interface. But in other devices, pin No.4 is left active and another pin is assigned for signal lines having the equivalent RTS function. Pins other than #4 should be able to be connected to RTS for hardware handshaking with such devices.

The IE-78310A-R accepts connection to a pro-typer, one of such devices.

Follow Figure 5-18 for RTS setting.

Always set the corresponding DIP switch to the RTSN setting except when a pro-typer is connected.

Fig. 5-18 Channel 2 Setting on IE-78310A-R Front Panel



| RTS name selection | RTS, FG setting (CH 2) | | | | Device connected |
|--------------------|------------------------|-----|-----|-----|---|
| | 1 | 2 | 3 | 4* | |
| RTSN | ON | OFF | OFF | OFF | Host machine, PROM programmer, MD-910TM |
| RTSP | OFF | ON | OFF | OFF | Pro-typer |
| RTSD | OFF | OFF | ON | OFF | DDY-86 |

Use this setting for ordinary use.

* Channel 2 DIP switch #4 sets signal ground (SG) and frame ground (FG) to common (ON) or open (OFF). Ordinary setting is open (OFF).

5.5.3 Baud rate selection

Use the same baud rate for the IE-78310A-R and the terminal or host machine to be connected.

Select the baud rate by means of software (commands).

Enter commands in the terminal (console) connected to the IE-78310A-R channel 1.

The following shows the baud rate setting.

Channel 2 mode setting command

$$\text{MOD}[_{\text{MODE}} = \left\{ \begin{array}{c} \text{CHAR} \\ \text{FLOW} \end{array} \right\}] [_{\text{BAUD}} = \left\{ \begin{array}{c} 19200 \\ 9600 \\ 4800 \\ 2400 \\ 1200 \\ 600 \\ 300 \end{array} \right\}] [_{\text{LONG}} = \left\{ \begin{array}{c} 7 \\ 8 \end{array} \right\}] [_{\text{PAR}} = \left\{ \begin{array}{c} \text{NON} \\ \text{EVEN} \\ \text{ODD} \end{array} \right\}] [_{\text{STOP}} = \left\{ \begin{array}{c} 1 \\ 2 \end{array} \right\}]$$

MODE: Handshaking mode selection
BAUD: Baud rate selection
LONG: Character length selection
PAR: Parity bit selection
STOP: Stop bit length selection

Use the MOD command to specify the operating state of serial channel 2. If the command operand has been omitted, the interactive mode is available for setting the operating state.

The initial settings are 1-character handshaking, 9600 bauds, 8-bit length, no parity bit, and 2 stop bits.

Example:

```
*MOD MODE=CHAR BAUD=4800 LONG=8 PAR=NON STOP=2 <cr>  
*
```

This command sets character handshaking to 1, the baud rate to 4800, the character length to 8 bits, the parity bit to unavailable, and the stop bit to 2 .

```
*MOD <cr>                + Sets channel 2 operating state by interactive  
                        mode  
_MODE _CHAR_ = _FLOW <cr> + Resets to buffer control mode  
_BAUD_ 4800 = _9600 <cr> + Resets baud rate to 9600  
_LONG_ 8 = <cr>          + Does not reset character length  
_PAR_ NON = _EVEN <cr>   + Resets to even parity check  
_STOP_ 2 = _1 <cr>      + Resets stop bit length to 1  
*
```

5.5.4 Handshaking

This section describes the hardware handshaking function with the CTS, DSR, and DTR handshake signals connected and the software handshake function with those signals disconnected, taking modem-mode operation as an example.

(a) Hardware handshaking

Data transmission

When both RTS and DTR are active, the IE-78310A-R assumes that the terminal is ready to receive data and transmits data to RxD.

Data reception

Always keep DSR in the active state. Set CTS to the inactive state while data reception is not yet ready. Reset CTS to the active state when data can be accepted. The IE-78310A-R then receives data from TxD.

The IE-78310A-R reverses the RxRDY pin on the uPD8251AF IC, which is used as the RS-232-C interface, and outputs the data to CTS.

When the data is transferred from the RS-232-C to the reception buffer, the RxRDY pin is set to 1. When the data is transferred from this buffer to the IE-78310A-R CPU, the RxRDY pin is reset to 0.


This function controls CTS so that the terminal does not transmit the next data until the reception buffer is emptied.

The dynamic handshake signals, which are used to control data byte by byte, are also called 1-character handshake signals.

Figure 5-19 and Figure 5-20 are flowcharts for hardware handshaking.

Fig. 5-19 Handshaking

Modem-to-terminal
transfer




- | | |
|---|---|
| ① Turn on the power to turn DSR on. | ① Turn on the power to turn DTR on. |
| ② Monitor the DTR pin. OFF is error and ON means go to the next step. | ② Monitor the DTR pin. OFF is error and ON means go to the next step. |
| ③ Set the data to be transferred. | ③ Turn RTS on and permit data to be transferred to the external device. |
| ④ Do not start transferring data until the RTS comes on. | ④ Check by polling to see if data reception is completed. |
| ⑤ Transfer the data. | ⑤ Read the data. |

* Turn RTS on to pulse.

Fig. 5-20 Handshaking

Terminal-to-modem
transfer



- | | |
|---|---|
| ① Turn on the power to turn DSR on. | ① Turn on the power to turn DTR on. |
| ② Monitor the DTR pin. OFF is error and ON means go to the next step. | ② Monitor the DSR pin. OFF is error and ON means go to the next step. |
| ③ Turn CTS on and permit data to be transferred to the external device. | ③ Set the data to be transferred. |
| ④ Check by polling to see if the data reception is completed. | ④ Do not start transferring the data until CTS comes on. |
| ⑤ Read the data. | ⑤ Transfer the data. |

* Turn CTS on to pulse.

(b) Software handshaking

Data transmission

The IE-78310A-R assumes that the terminal is always ready to receive data and transmits data to RxD. It stops transmitting data when it receives Ctrl-S from the terminal via TxD.

Channel 2 of the IE-78310A-R stops transmitting data 4 or 5 characters after receiving Ctrl-S.

The IE-78310A-R resumes data transmission when it receives Ctrl-Q from the terminal via TxD.

Data reception

The IE-78310A-R always accepts data. It receives data by interrupt processing and saves the received data in the buffer. When the buffer is about to overflow, it transmits Ctrl-S to the terminal via RxD requesting to stop transmitting data for a while. The data transmitted immediately after this request is accepted in the buffer.

Then the IE-78310A-R transfers the buffer data to its CPU. When the buffer is almost empty, it transmits Ctrl-Q to the terminal via RxD requesting the resumption of data transmission.

The IE-78310A-R channel 2 issues Ctrl-S when its 96-byte buffer is 50% full. It issues Ctrl-Q when the buffer is 35% filled with data.

Therefore, some data may be lost when the terminal connected to channel 2 is the kind that transmits 96/2 bytes or more data after receiving Ctrl-S.

Unlike hardware handshaking, which controls data byte by byte, the software handshaking function controls data by blocks.

The software handshaking is also called flow control.

Channel 2 employs either hardware handshaking or software handshaking to transfer data.

The two handshaking methods can be specified in the command setting shown below.

Channel 2 mode setting command

$$\text{MOD}[_{\text{MODE}} = \left\{ \begin{array}{c} \text{CHAR} \\ \text{FLOW} \end{array} \right\}] [_{\text{BAUD}} = \left\{ \begin{array}{c} 19200 \\ 9600 \\ 4800 \\ 2400 \\ 1200 \\ 600 \\ 300 \end{array} \right\}] [_{\text{LONG}} = \left\{ \begin{array}{c} 7 \\ 8 \end{array} \right\}] [_{\text{PAR}} = \left\{ \begin{array}{c} \text{NON} \\ \text{EVEN} \\ \text{ODD} \end{array} \right\}] [_{\text{STOP}} = \left\{ \begin{array}{c} 1 \\ 2 \end{array} \right\}]$$

MODE: Handshaking mode selection
BAUD: Baud rate selection
LONG: Character length selection
PAR: Parity bit selection
STOP: Stop bit length selection

Use the MOD command to specify the serial channel 2 operating state. If the command operand has been omitted, interactive mode is available for setting the operating state.

The initial settings are 1-character handshaking, 9600 bauds, 8 bit length, no parity bit, and 2 stop bits.

Example:

```
*MOD MODE=CHAR BAUD=4800 LONG=8 PAR=NON STOP=2 <cr>  
*
```

This command sets character handshaking to 1, the baud rate to 4800, the character length to 8 bits, the parity bit to unavailable, and the stop bit to 2.

```
*MOD <cr>                ← Sets channel 2 operating state by interactive  
                        mode  
MODE CHAR = FLOW <cr>    ← Resets to buffer control mode  
BAUD 4800 = 9600 <cr>    ← Resets baud rate to 9600 baud  
LONG 8 = <cr>           ← Does not reset character length  
PAR NON = EVEN <cr>     ← Resets to even parity check  
STOP 2 = 1 <cr>         ← Resets stop bit length to 1  
*
```

Be aware that the hardware handshaking (1-character handshaking: CHAR) does not have any buffer. So if this is selected without connecting the handshake signals, handshaking cannot be executed correctly.

Always connect handshake signals before selecting hardware handshaking.

When the software handshaking (flow (buffer) control: FLOW) is selected, the 96-byte buffer is available for saving serial data. When the buffer is 50% filled with data, channel 2 issues Ctrl-S requesting to stop data transmission, and when the buffer is 35% full, it issues Ctrl-Q requesting the resumption of data transmission.

When 96/2 bytes or more data are transferred after receiving Ctrl-S, which is over the buffer capacity, some data may be lost.

5.5.5 Character specifications

(a) Character length

Select 7 bits or 8 bits by means of software (commands).

When 8 bits is selected, the most significant bit (MSB) is always 0 for IE-78310A-R output and is ignored and assumed to be always 0 for IE-78310A-R input.

(b) Parity bit

Select even parity/odd parity/no parity by means of software (commands).

(c) Stop bit length

Select 1 bit or 2 bits by means of software (commands).

CHAPTER 6 CONNECTING THE TARGET SYSTEM

6.1 Overview

Chapter 6 explains the method for connecting the target system using the uPD78312A or uPD78310A to the IE-78310A-R.

Be sure to read this chapter before connecting the target system.

Chapter 6 consists of the following sections.

6.2 Debugging Software

6.3 Connecting the Target System

6.4 Differences between Real Device and Target
Interface Circuit of IE-78310A-R

6.5 Latch-up

If the hardware of the target system is not developed at all, debugging logic can be used for the software in the IE-78310A-R.

Section 6.2 describes how to set the IE-78310A-R for debugging only software.

To debug the developed hardware or both the software and hardware of the target system, connect the target probe of the IE-78310A-R to the target system.

Section 6.3 describes how to set the IE-78310A-R for debugging the hardware or both the software and hardware of the target system.

If debugging is started after the target system is connected to the IE-78310A-R, the IE-78310A-R emulates the target system as if the real device (uPD78312A or uPD78310A) operates.

In particular, since the target interface circuit of the IE-78310A-R emulates the operation of the real device, both will differ in small points.

Section 6.4 describes the differences between the real device and the target interface circuit of the IE-78310A-R.

Section 6.5 describes latch-up.

6.2 Debugging Software

When the IE-78310A-R is used to debug software, the same signal as the clock signal to be used in the target system can be set as the basic clock signal of the IE-78310A-R.

If the same element as the oscillator used in the target system is connected to the part base on the emulation board, software operation can be emulated at the same frequency as in the target system.

When the clock is already set internally by software (commands), the basic clock signal is generated from the crystal oscillator (12 MHz) on the emulation board of the IE-78310A-R.

Since the $\overline{\text{EA}}$ terminal goes high while the software is being debugged, emulation in the ROMLESS mode cannot be performed.

The following setting procedure shall be performed to debug the software:

- ① Turn off the power switch of the IE-78310A-R.
- ② Set the basic clock of the IE-78310A-R.
- ③ Connect the target probe of the IE-78310A-R to the self-diagnostic socket of the IE-78310A-R. (Use the target probe for SHRINK DIP.)

The ground clip of the target probe need not be connected to pin GND.

Caution


At shipment, the basic clock is set so as to use an external clock (input at pin 30 of the target probe).

When an external clock is not used, set the clock by software (commands) so as to use the internal clock.

6.2.1 Setting the basic clock of the IE-78310A-R

(1) Using a ceramic or crystal oscillator

- ① Connect the pins with resistor Rx, capacitor Ca, and capacitor Cb which conform to the oscillator to be used for the accessory base and the oscillating frequency.



Pin combination number


Ceramic or crystal
oscillator
Resistor Rx
Capacitor Ca
Capacitor Cb
Jumper lead

5-12
6-11
4-13
3-14
9-10



[Part base]

[Connection]

The circuit diagram for the above connection is as follows:




- ② Turn off the power switch of the IE-78310A-R.
- ③ Open the cover at the right of the IE-78310A-R and remove the emulation board.



[Emulation board]

- ④ Fit the part base into the socket (IC96) on the emulation board.

Note: Pay careful attention to the direction of the IC mark in this step.




- ⑤ Install the emulation board in the IE-78310A-R.

This completes the setting procedure. Turn on the power to the IE-78310A-R.

The oscillator fitted by the above setting generates the basic clock signal to the IE-78310A-R.


This circuit diagram is as follows:



(2) Using a crystal oscillator

- ① Check whether the pins of the crystal oscillator to be used correspond to the socket pins as shown in the following figure.

Note: Be sure to use the crystal oscillator whose pins are arranged as shown in the following figure.



- ② Turn off the power switch of the IE-78310A-R.
- ③ Open the cover at the right of the IE-78310A-R and remove the emulation board.
- ④ Fit the crystal oscillator to be used into the socket on the emulation board.


Note: Pay careful attention to the direction of the IC mark in this step.

- ⑤ Install the emulation board in the IE-78310A-R.

This completes the setting procedure. Turn on the power to the IE-78310A-R.

The oscillator fitted by the above setting generates the basic clock signal to the IE-78310A-R.

This circuit diagram is as follows:



6.2.2 Connecting the target probe

Since the self-diagnostic socket on the self-check board is a SHRINK DIP type, use the target probe which is a SHRINK DIP type.

- ① Turn off the power switch of the IE-78310A-R.
- ② Open the cover at the top of the IE-78310A-R and pull the lever at the left of the self-diagnostic socket.
- ③ Fit the target probe into the self-diagnostic socket and push the lever.


This completes the connection procedure. Turn on the power to the IE-78310A-R.

Caution A ∇ mark, which indicates the position of pin 1, is marked on the SHRINK DIP type target probe. Fit the target probe into the self-diagnostic socket so that the mark is aligned with pin 1 of the self-diagnostic socket. (See Figure 6-1.)

The ground clip of the target probe need not be connected to pin GND.


Great care should be taken that the target probe is not fitted in reverse and the pins are not broken or bent. Otherwise, the target interface circuit of the IE-78310A-R will be destroyed.

Fig. 6-1 Debugging Software



The pin status during software debugging is as shown in Figure 6-2.

Fig. 6-2 Pin Status during Software Debugging



6.3 Connecting the Target System

The same clock generating source as used in the target system can be set as the basic clock signal of the IE-78310A-R when the IE-78310A-R is used to debug both the hardware and software of the target system.

If the same oscillating element as in the target system is connected to the part base on the emulation board, operation can be emulated at the same frequency as in the target system.

If the clock signal existing in the target system is used by the uPD78312A or uPD78310A, it can be generated as is.

When the clock pulse is already set internally by software (commands), the basic clock signal is generated from the crystal oscillator (12 MHz) on the emulation board to the IE-78310A-R.

This section describes how to set the basic clock generating source of the IE-78310A-R and gives the required information to connect the target probe to the target system. Be sure to follow the caution given below. Otherwise there is danger of serious problems, such as destruction of the target system. The target system is connected in the same way whether the CPU of the target system is uPD78312A or uPD78310A.

Caution

At shipment, the part base which contains the wiring for the external clock signal (input at pin 30 of the target probe) is already fitted on the emulation board. Using this base, the clock signal used in the target system can also be used as the basic clock signal in the IE-78310A-R.

When the crystal oscillator is directly connected to pins X1 and X2 (pins 30 and 31) of the uPD78312A or uPD78310A in the target system, this oscillation signal cannot be supplied to the IE-78310A-R. In this case, install a crystal oscillator on the emulation board using the part base.


To debug both hardware and software, follow the following procedure.

- ① Turn off the power switch of the IE-78310A-R.
- ② Set the basic clock signal of the IE-78310A-R. The default in hardware is the clock signal (input at pin 30 of the target probe) in the target system.
- ③ Fit the target probe of the IE-78310A-R into the self-diagnostic socket of the IE-78310A-R.

6.3.1 Setting the basic clock of the IE-78310A-R

(1) Using a ceramic or crystal oscillator in the target system


- ① Connect the pins with resistor Rx, capacitor Ca, and capacitor Cb, which conform to the oscillator to be used for the accessory part base and the oscillating frequency.




[Part base]

[Connection]

The circuit diagram for the above connection is as follows:




- ② Turn off the power switch of the IE-78310A-R.
- ③ Open the cover at the right of the IE-78310A-R and remove the emulation board.



- ④ Fit the part base into the socket (IC96) on the emulation board.

Note: Pay careful attention to the direction of the IC mark in this step.




- ⑤ Install the emulation board in the IE-78310A-R.

This completes the setting procedure. Turn on the power to the IE-78310A-R.

The oscillator fitted by the above setting generates the basic clock signal to the IE-78310A-R.


This circuit diagram is as follows:



(2) Using a crystal oscillator

- ① Check whether the pins of the crystal oscillator to be used correspond to the socket pins as shown in the following figure.

Note: Be sure to use the crystal oscillator whose pins are arranged as shown in the following figure.



[Crystal oscillator]

[Socket]

[Connection]

- ② Turn off the power switch of the IE-78310A-R.
- ③ Open the cover at the right of the IE-78310A-R and remove the emulation board.

- ④ Fit the crystal oscillator to be used into the socket on the emulation board.


Note: Pay careful attention to the direction of the IC mark in this step.

- ⑤ Install the emulation board in the IE-78310A-R.

This completes the setting procedure. Turn on the power to the IE-78310A-R.


The oscillator fitted by the above setting generates the basic clock signal to the IE-78310A-R.

This circuit diagram is as follows:



(3) Using an external clock signal

- ① Connect the pins of the accessory part base using leads as shown in the figure below:



Pin combination number

| | |
|------|------|
| Lead | 7-9 |
| | 5-13 |

[Connection]

Note: The part base for which wiring is performed as shown in the figure at the left is already mounted on the board at delivery.

- ② Turn off the power switch of the IE-78310A-R.
- ③ Open the cover at the right of the IE-78310A-R and remove the emulation board.
- ④ Fit the part base into the part base socket on the emulation board.


Note: Pay careful attention to the direction of the IC mark in this step.

- ⑤ Install the emulation board in the IE-78310A-R.

This completes the setting procedure. Turn on the power to the IE-78310A-R.

The clock signal in the target system is used as the basic clock signal of the IE-78310A-R in accordance with the above setting.

This circuit diagram is as follows:



6.3.2 Connecting the target probe

The following parts are provided for the target probe.

- Probe cable
- SHRINK DIP probe unit
- QUIP probe unit

Use the parts appropriate to the uPD78312A or uPD78310A package.


- ① When the SHRINK DIP type probe is used

Make the following connections:

| | | |
|-------------|--|--------------|
| Probe cable | $\left[\begin{array}{l} \text{CN3} \longleftrightarrow \text{CN3 (lower)} \\ \text{CN4} \longleftrightarrow \text{CN4 (upper)} \end{array} \right]$ | Probe unit |
| Probe unit | $\left[\text{CN5} \longleftrightarrow \text{CN5} \right]$ | Pin terminal |

Do not connect the wrong connectors, otherwise the IE-78310A-R may be destroyed.

Fig. 6-3 Connecting the Target Probe (SHRINK DIP Type)




② When the QUIP type probe is used

Make the following connections:

| | | |
|-------------|--|--------------|
| Probe cable | $\left[\begin{array}{l} \text{CN3} \longleftrightarrow \text{CN3 (lower)} \\ \text{CN4} \longleftrightarrow \text{CN4 (upper)} \end{array} \right]$ | Probe unit |
| Probe unit | $\left[\begin{array}{l} \text{CN5 (lower)} \longleftrightarrow \text{CN5} \\ \text{CN6 (upper)} \longleftrightarrow \text{CN6} \end{array} \right]$ | Pin terminal |

Do not connect the wrong connectors, otherwise the IE-78310A-R may be destroyed.

Fig. 6-4 Connecting the Target Probe (QUIP Type)



6.3.3 Connecting the external sense clips

The signals at the pins of the CPU (uPD78312A or uPD78310A) as well as any signal line in the target system can be observed in real time by the IE-78310A-R.

This signal line can be broken as a trigger signal and the trace can be qualified.

The status of the signal line can be traced while the real-time tracer operates.

For this purpose, the IE-78310A-R has eight external sense clips.

These sense clips shall be connected only to the TTL-level signal lines.

If the sense clips are connected to other level signal lines, the IE-78310A-R cannot sense signal lines correctly and the sensor of the IE-78310A-R may be destroyed, depending on the voltage level.


Connect the external sense clips as follows:

- ① Turn off power to the IE-78310A-R and the target system.
- ② Set an IC clip at the IC to be sensed in the target system.
- ③ Connect the external sense clips to the set IC clip.

Use the IC clip as often as possible to connect sense clips.

Figure 6-5 shows the above connection.

Fig. 6-5 Connecting the External Sense Clips



This completes the connection between the target probe and the target system. Turn on power. Note the power-on sequence below:

6.3.4 Power-on sequence

① Turn on the power switch to the IE-78310A-R.

② The following message is then displayed.

Power on target system (Y/N)

③ Turn on the power switch of the target system.

④ Enter Y <cr> and press the return key.

Be careful of this sequence, because the IE-78310A-R does not operate normally or may be destroyed if the sequence is wrong.

6.3.5 Power-off sequence

① Turn off the power switch of the target system.

② Turn off the power switch of the IE-78310A-R.

Be careful of this sequence, because the IE-78310A-R may be destroyed if the sequence is wrong.

Cautions for connection

- (1) When the target probe is fitted into the CPU socket of the target system
 - ① Fit the target probe into the CPU socket of the target system so that the IC mark of the target probe is aligned with the first-pin mark. Care should be taken that the target probe is not fitted in reverse. Otherwise, the target interface circuit of the IE-78310A-R will be destroyed.
 - ② Care must be taken that the pins of the target probe are not broken or bent.
 - ③ The ground clip of the target probe shall be connected to pin GND.
- (2) When the external sense clips are connected to the target system
 - ① Be sure to connect an external sense clip to a signal line. If it is connected to a power line, a failure occurs.
 - ② Use an IC clip to connect the external sense clips.

6.4 Differences between the Real Device and Target Interface Circuit of the IE-78310A-R

The target interface circuit consists of the evaluation chip (uPD78319A) and the emulation circuit including the TTL.

Signal lines of the target interface are classified into three types. Section 6.4 describes the individual differences between the types and the corresponding signal lines of the real device.

Figure 6-6 shows the circuit equivalent to the emulation circuit.

- (1) Signals sent out directly from the evaluation chip (Port 0, port 2, port 3, analog-to-digital converter related, and refresh signals)

These signal lines operate in completely the same way as those in the real device.

Note: 100- Ω resistors are inserted in series for signals other than analog-to-digital converter related signals

- (2) Signals sent out from the evaluation chip through gates ($\overline{\text{RESET}}$, clock input, $\overline{\text{RD}}$, $\overline{\text{WR}}$, and ALE signals)

- 1) The input signal from the target system is received by the TTL gate of the emulation circuit and input to the evaluation chip.

The target interface circuit therefore differs a little in its DC characteristics from the real device.

They differ also in the AC characteristics, as the signal is delayed through the TTL. (The signal must be input to the target interface circuit at a faster timing than to the real device.)

- 2) The output signal to the target system is output from the evaluation chip through the TTL gate of the emulation circuit.

The target interface circuit therefore differs a little in its DC characteristics from the real device.

They differ also in the AC characteristics, as the signal is delayed through the TTL.

The target interface circuit must be more strictly designed than the real device to provide the appropriate timing of these signals.

- (3) Signals set out from the emulation circuit (V_{DD} , \overline{EA} , P1, P4, and P5)

The signals at terminals V_{DD} and \overline{EA} are sensed by the TTL of the emulation circuit.

The power to the evaluation chip is supplied from the power source in the IE.


The V_{DD} signal of the target system is not connected to the evaluation chip.

The P1, P4, and P5 signals are sent out from each port emulator of the emulation circuit. The output to the target system is the LS TTL. The input from the target system is the HCT logic.





The target interface circuit differs a little in both DC and AC characteristics from the real device.

Fig. 6-6 Diagram of Equivalent Circuit to Emulation Circuit

(1) Signals sent out directly from the evaluation chip




(2) Signals sent out from the evaluation chip through gates



(3) Signals sent out from the emulation circuit

At probe

At IE-78310A-R



6.5 Latch-up

When latch-up occurs in the evaluation chip and the neighboring CMOS, the power is turned off to the evaluation chip, the neighboring CMOS, and the TTL before the CMOS. This is done by the latch-up warning circuit in the IE-78310A-R.

When the latch-up warning circuit operates, the following message is displayed at the terminal (console):

Emulation CPU latchup!

As soon as this message is displayed, turn off power first to the target system and then to the IE-78310A-R.

APPENDIX A

(1) Overview of installation

Attaching the accessories to the IE-78310A-R main unit

- . To connect the target probe to the IE-78310A-R main unit, draw the emulation board (the second board from the top) from the right side of the IE-78310A-R main unit, and insert the connector of the target probe into connectors CN1 and CN2 on the emulation board.
- . To connect the external sense clip to the IE-78310A-R main unit, draw the break board (the third board from the top) from the right side of the IE-78310A-R main unit, and insert the connector of the external sense clip into connector CN1 on the break board.
- . Insert the power cable into the AC inlet on the back of the IE-78310A-R main unit.
- . Insert the RS-232-C interface cable into CH1 or CH2 on the front panel of the IE-78310A-R main unit.

When accessories have been attached, install the IE-78310A-R in place.

Small quantities of foreign particles and dust may be allowed at the installation place.

Do not place anything around the air intake.

(2) Connectable peripheral equipment

Host machines: MD-116HD-21, MD-116FD-20, MD-086HD-10,
MD-086FD-10, and MD-086FD
PC-9800 series
IBM PC/AT

PROM programmers: PG-1500 and PG-2000

Terminal: MD-910TM

(3) Functions and the setting of switches on the main unit

. Power switch: Turns the IE-78310A-R power on and off.

. Reset switch: Resets the IE-78310A-R.

. Terminal/modem mode selection switch:
Puts the RS-232-C interface in the
terminal or modem mode.

. RTS setting switch:
DIP switch for switching the RTS pin
number of the RS-232-C interface.
Normally, switch number 1 is set to ON,
and 2 and 3 are set to OFF.

. Frame ground setting switch:
DIP switch for setting whether the frame
and signal grounds of the RS-232-C
interface are common or open.
Normally, this switch is set to open.
Switch number 4 is set to OFF.

. Baud rate selection switch:

Micro DIP switch for setting the baud rate for channel 1 of the RS-232-C interface

(4) Jumper connections on the control/trace board

Use jumpers on the control/trace board factory-connected as they are.

If a connection is changed, the jumpers may operate abnormally.

Table A-1 Jumper Connections on the Control/Trace Board on Shipment

| Jumper number | Connection |
|---------------|----------------|
| JP 2 | 1-6 short |
| JP 3 | 1-6 short |
| JP 4 | Open |
| JP 5 | 1-6 open(Note) |
| | 2-5 open(Note) |
| | 3-4 short |
| JP 6 | 1-2 short |
| JP 7 | 1-2 short |


Note: Short 1-6 and 2-5 of JP5 when a memory board other than SB-0512 is used in the expansion slot.

(5) RS-232-C interface circuit

The IE-78310A-R incorporates two channels (channels 1 and 2) of the RS-232-C interface connectors on the front panel of the main unit. The following figure is an internal circuit diagram of the channels.

The interface circuits of channels 1 and 2 are the same.

Fig. A-1 RS-232-C Interface Circuit Diagram



(6) Connecting the target system

- o Inserting the target probe in the CPU socket of a target system
 - . Insert the target probe in the CPU socket of a target system with the IC mark and No.1 pin mark aligned.
 - . Connect the ground clip of the target probe to the signal ground line of the target system.
- o Connecting the external sense clip to a target system
 - . Connect the external sense clip to the signal line and signal ground line.
 - . Use an IC clip for connection.
- o Power-on procedure
 - ① Turn on the IE-78310A-R power switch.
 - ② Turn on the target system power switch.

Note that the IE-78310A-R may not operate normally or may be destroyed if the power-on procedure is not performed properly.

- o Power-off procedure
 - ① Turn off the target system power switch.
 - ② Turn off the IE-78310A-R power switch.

Note that the IE-78310A-R may be destroyed if the power-off procedure is not performed properly.

(7) Commands

The tables on the following pages list commands.

A command whose command body is marked with * is valid only when system software is used.

A command whose command body is marked with ** is valid only in the stand-alone mode.

| Command type | Command body | Subcommand | Operand |
|----------------------------------|---|------------|---|
| Line assembler | ASM | None | [word] (Assembler starting address) |
| Physical break condition setting | Hardware break condition setting | BRA | None |
| | | | <div> <div> <div>[A=addr][V=mask]</div> <div> <div>↓</div> <div>(Break address) data</div> </div> </div> <div> <div>↓</div> <div>(Break data)</div> </div> </div> <div> <div> <div>C=</div> <div> <div>OP (Operand fetch)</div> <div>RW (Data read/write)</div> <div>R (Data read)</div> <div>W (Data write)</div> <div>RWP (Data read/write by program)</div> <div>RP (Data read by program)</div> <div>WP (Data write by program)</div> <div>RWM (Data read/write by macro service)</div> <div>RM (Data read by macro service)</div> <div>WM (Data write by macro service)</div> <div>NC (All read/write including operand fetch)</div> </div> </div> <div> <div>↓</div> <div>(Break status)</div> </div> </div> <div> <div>(Input operands separated by _.)</div> </div> |
| | External signal break condition setting | BRD | None |
| | Instruction count break condition setting | BRE | None |
| | Timer break condition setting | BRT | None |

(to be continued)

(Cont'd)

| Command type | Command body | Subcommand | Operand |
|---------------------------------|--------------------------|----------------------|---|
| Logical break condition setting | BRM | None | [BRA][BRD][BRE][BRT][BR0][BR1][BR2][BR3] (Break register name) |
| | BR0 BR1 BR2 BR3 | None | [BRA][BRD][BRE][BRT] (Physical break register name) |
| Clock selection | CLK | [{U I}] | None (U: User system clock; I: IE internal clock) |
| Command file creation | COM * | None | [{LST: CON: file (Command file name)}] |
| Disassembler | DAS | None | [{word (Disassembler starting address) partition (Disassembler starting and ending addresses)}] |
| Self-diagnosis | DIG | None | None |
| Directory display | DIR * | None | [file] (File name) |
| System mode end | EXT * | None | None |
| Command history display | HIS * | None | None |
| Help | HLP * | None | [command] (Command body of command on which information is to be displayed) |
| Object load | LOD** | None | [{TTY1 (Channel 1)} {TTY2 (Channel 2)}] |
| Object/symbol load | LOD * | None | file(Object/symbol file name){module name\...}[{C(Object specification)} (Module name) [S(Symbol specification)}} |
| Output device redirect | LST * | None | [{LST: CON: file (output file name)}] |
| Mapping | MAP | [{W R U K}] | [partition] (Mapping range) (W: Internal mapping; R: Write-protected internal mapping; U: User mapping; K: Mapping release) |
| Arithmetic | MAT | None | word (Normally write an expression.) |

(to be continued)

(Cont'd)

| Command type | Command body | Subcommand | Operand |
|---|--------------|------------------|--|
| Mode register operation | MDR | [D] (Display) | [mode register name] |
| | | C (Change) | [mode register name] |
| Memory Operation | MEM | C (Change) | [word] (Change starting address) |
| | | [D] (Display) | [{word (Display starting address) partition (Display starting and ending addresses)}] |
| | | F (Initialize) | partition_data string <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Setting of initialize data (8 bits)) (Initialize starting and ending addresses) |
| | | G (Search) | partition_data string <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Setting of search data (8 bits)) (Search starting and ending addresses) |
| | | M (Copy) | partition_word <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Copy destination starting address) (Copy source starting and ending addresses) |
| | | X (Exchange) | partition_word <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Exchange destination starting address) (Exchange source starting and ending addresses) |
| | | V (Compare) | partition_word <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Compare destination starting address) (Compare source starting and ending addresses) |
| | | E (Test) | [partition] (Test starting and ending addresses) |
| Channel 2 mode setting | MOD | None | <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> $\left[\begin{matrix} \text{MODE} = \{ \text{CHAR} \\ \text{FLOW} \} \end{matrix} \right]$ <div style="border-left: 1px solid black; height: 50px; margin: 0 auto; width: 10px;"></div> (Handshaking mode) </div> <div style="text-align: center;"> $\left[\begin{matrix} \text{BAUD} = \{ 19200 \\ 9600 \\ 4800 \\ 2400 \\ 1200 \\ 600 \\ 300 \} \end{matrix} \right]$ <div style="border-left: 1px solid black; height: 50px; margin: 0 auto; width: 10px;"></div> (Baud rate) </div> <div style="text-align: center;"> $\left[\begin{matrix} \text{LONG} = \{ 7 \\ 8 \} \end{matrix} \right]$ <div style="border-left: 1px solid black; height: 50px; margin: 0 auto; width: 10px;"></div> (Character length) </div> <div style="text-align: center;"> $\left[\begin{matrix} \text{PAR} = \{ \text{NON} \\ \text{EVEN} \\ \text{ODD} \} \end{matrix} \right]$ <div style="border-left: 1px solid black; height: 50px; margin: 0 auto; width: 10px;"></div> (Parity bit) </div> <div style="text-align: center;"> $\left[\begin{matrix} \text{STOP} = \{ 1 \\ 2 \} \end{matrix} \right]$ <div style="border-left: 1px solid black; height: 50px; margin: 0 auto; width: 10px;"></div> (Stop bit length) </div> </div> |
| Internal-to-user/user-to-internal memory transfer | MOV | {I} {U} | partition_word <div style="margin-left: 100px;"> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> <div style="display: inline-block; width: 100px; border-bottom: 1px solid black; margin-bottom: 2px;"></div> </div> (Copy destination starting address) (Copy source starting and ending addresses) (U: Internal to user; I: User to internal) |
| Terminal mode | PGM | None | None |

(to be continued)

(Cont'd)

| Command type | Command body | Subcommand | Operand |
|----------------------------|--------------|------------------|--|
| Register Operation | REG | C (Change) | [register name] |
| | | [D] (Display) | [register name] |
| Emulation Operation | RUN | N | [word] (Execution starting address) (N: Real-time execution with no break) |
| | | B | [word] (Execution starting address) (B: Real-time execution with breaks) |
| | | S | [word][,word] (S: Real-time execution with number of steps specified) └─(Number of steps) └─(Execution starting address) |
| | | T | <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>[word][,(*)][_TRD][_REG]]</p> <p>└─(Register display specification)</p> <p>└─(Trace display specification)</p> <p>└─(Break condition; *: Register condition word: Number of steps)</p> </div> <div> <p>* register name</p> <p>{ mask } > < => >= =< <= >< <></p> <p>{ wmask }</p> </div> </div> <p>(T: Trace execution)</p> |
| Reset | RES | [H] | None (H: When omitted, resets only evaluation chip. When specified, resets all IEs.) |
| Object save | SAV** | None | { TTY1 (Channel 1) } [_partition][_partition]...[_partition] { TTY2 (Channel 2) } └────────── Up to five ─────────┘ |
| | SAV * | None | file (Input file name)[_partition][_partition]...[_partition] └────────── Up to five ─────────┘ |
| Special register operation | SPR | C (Change) | [special register name] |
| | | [D] (Display) | [special register name] |
| Input device redirect | STR * | None | file (Input file name) |
| Suffix specification | SUF | None | { H (Hexadecimal) T (Decimal) Q (Octal) Y (Binary) } |

(to be continued)

(Cont'd)

| Command type | Command body | Subcommand | Operand |
|-----------------------------|--------------|------------------|---|
| Append symbol operation | SYM | {D} (Display) | None |
| | | X (Delete) | None (Deletes all append symbols.) |
| | | A (Append) | symbol_word └─ (Symbol value) └─ (Append symbol name) |
| | | C (Change) | symbol_word └─ (Change symbol value) └─ (Append symbol name) |
| | | E (Delete) | {symbol} └─ (Append symbol name to be deleted) |
| | SYM * | L (Load) | None |
| | | S (Save) | None |
| Symbol operation | SYM * | {D} (Display) | {module (Module specification)} {PUBLIC (Public specification)} |
| Current module modification | SYM | M (Modify) | None |
| Trace mode setting | TRM | None | {NON (Non-trace) ALL (All trace) TRX (Qualify trace)} |
| Qualify condition setting | TRX | None | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> [A=addr]{V=mask} ↓ (Qualify address) (Qualify data) </div> <div style="margin-right: 10px;"> C= <div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; flex-direction: column; align-items: center;"> OP (Operand fetch) RW (Data read/write) R (Data read) W (Data write) RWP (Data read/write by program) RP (Data read by program) WP (Data write by program) RWM (Data read/write by macro service) RM (Data read by macro service) WM (Data write by macro service) NC (All read/write including operand fetch) </div> ↓ (Qualify status) </div> </div> </div> <div style="margin-right: 10px;"> [TRQ=mask] ↓ (Qualify port/external data) </div> |

(to be continued)

(Cont'd)

| Command type | Command body | Subcommand | Operand |
|------------------------------|--------------|---|--|
| Qualify data selection | TRQ | None | $\left[\begin{array}{l} \text{TRS (Port selection)} \\ \text{EXT (External signal selection)} \end{array} \right]$ |
| Trace/qualify port selection | TRS | None | $\left[\begin{array}{l} \text{P0 (Port 0)} \\ \text{P1 (Port 1)} \\ \text{P2 (Port 2)} \\ \text{P3 (Port 3)} \\ \text{P4 (Port 4)} \\ \text{P5 (Port 5)} \end{array} \right]$ |
| Trace pointer operation | TRP | None | $\left[\begin{array}{l} \text{word (Distance pointer is to be moved)} \\ 0 \text{ (Places pointer at the beginning.)} \\ N \text{ (Places pointer at the end.)} \end{array} \right]$ |
| Trace display | TRD | $\left[\begin{array}{l} F \\ I \\ M \end{array} \right]$ | $\left[\begin{array}{l} \text{word (Number of steps to be displayed)} \\ \text{ALL (Displays all trace results.)} \end{array} \right]$ (F: Frame mode; I: Instruction mode; M: Instruction mode with macro service) |
| Object verify | VRV** | None | $\left\{ \begin{array}{l} \text{TTY1 (Channel 1)} \\ \text{TTY2 (Channel 2)} \end{array} \right\}$ |
| | VRV * | None | file (Input file name) |

(8) Error messages

The error messages are given below.

(1) Unrecognized command

A command keyword is invalid.

(2) Command format error

Command keywords are valid, but an operand is invalid.

(3) Command/Data too long

An entered command or data line consists of 128 characters or more.

(4) Mapping error

An unmapped memory area was found in the specified address range.

(5) Input data error

Invalid data was entered.

(6) System mode command

A command in the system mode was entered in the stand-alone mode.

(7) Non map area access

An attempt was made to access an unmapped memory area during execution of a command.

(8) Check sum error

A checksum error was detected while loading/saving an object.

(9) Bad character

An invalid character was detected while loading/saving an object.

(10) aborted

The INTERRUPT key was pressed while loading/saving an object.

(11) Warning double define

A module name was specified by the LOD command twice or more.

(12) Bad file entry

An invalid file name was described.

(13) File overflow

The number of symbol files specified in the LOD command exceeded the limit.

(14) Illegal record

A symbol table file with an invalid record format was specified in the LOD command.

(15) load failed

An error was detected while loading a symbol by the LOD command.

(16) module overflow

The number of modules specified in the LOD command exceeded the limit.

(17) Not loaded symbol

No symbol has been loaded.

(18) Not found module record

The module name specified by the LOD command cannot be found in the symbol table file.

(19) file not found

A nonexistent file name was specified.

(20) Slave CPU communication error

No command can be written for the slave CPU (8742) at channel 2.

(21) double define append symbol symbol-name

A registered symbol was loaded as an append symbol by the LOD command. (The append symbol will be deleted.)

(22) double define append symbol

An attempt was made to register a registered symbol by the SYM A or SYM L command.

(23) symbol table full

There is no free symbol save area for the LOD command.

(24) append symbol table full

There is no free append symbol save area for the SYM A or SYM L command.

(25) double define loaded symbol

A loaded symbol was loaded by the LOD, SYM A, or SYM L command.

(26) symbol record format error

A symbol table file with an invalid record format was specified in the LOD or SYM L command.

(27) reserved word symbol

A reserved word was defined as a symbol by the SYM A command.

(28) double define module name module-name

The displayed module name has been already loaded.

(29) module buffer full

The number of modules specified in the LOD command exceeded the limit.

(30) not found symbol

A nonexistent symbol was specified by the SYM C or SYM E command.

(31) no symbol of append

There is no append symbol for the SYM D or SYM S command.

- (32) Can not execute HLP command !

The help file (IE78310.HLP) or help overlay file (IE78310.OV2) cannot be found on the current disk.

- (33) No .HLP file on the default drive

While executing the HLP command, the help file (IE78310.HLP) or help overlay file (IE78310.OV2) could not be found on the current disk.

- (34) Keyword Error

An invalid command keyword was specified by the HLP command.

- (35) Can not use command abbreviation !

The abbreviated overlay file (IE78310.OV2) cannot be found on the current disk.

- (36) File already exists.

An attempt was made to create a file having a SYS or R/O attribute with the same name.

- (37) Reserved file name

A file name reserved for the system software was specified.

- (38) File name is used by other process

The name of a file already opened was specified.

(39) Can not close file-name

The file displayed could not be closed.

(40) Disk write error file-name

A write error was detected in the displayed file.

(41) Disk read error file-name

A read error was detected in the displayed file.

(42) Can not open file-name

The specified file could not be opened.

(43) File make error file-name

The displayed file could not be created.

(44) Can not close file-name.Cancel xxx command

The displayed file could not be closed during
execution of command xxx. (xxx: STR, LST, or COM)

(45) Disk write error file-name.Cancel xxx command

A write error was detected in the displayed file
during execution of command xxx. (xxx: LST or COM).

(46) Disk read error file-name.Cancel STR command

A read error was detected in the displayed file
during execution of the STR command.

- (47) List device is used by other process

Another process is using the list device. (The list device was specified by both the COM and LST commands, or for CCP/M, a process other than an IE-78310A-R process is using the list device.)

- (48) Append symbol file not found

For the SYM L command, the append symbol file (IE78310.SYM) could not be found on the current disk.

- (49) Illegal append symbol file

An append symbol file in an invalid format was specified by the SYM L command.

- (50) Communication error

The IE could not communicate normally with the host machine.

- (51) Not found memories

Although an external memory area was specified, it could not be used.

- (52) Non map area access!

An attempt was made to access an unmapped memory area during execution of the ASM command.

- (53) Assemble area over!

The range of memory accessed by the ASM command exceeded the limit.

(54) Disassemble area over!

The range of memory accessed by the DAS command exceeded the limit.

(55) Caution!

A generic object was created. This message is displayed in other cases if the system is cautioning the user.

(56) Error!

No object code could be generated. This message is displayed in other cases if an error occurs.

(9) Differences between the IE-78310A-R and real devices

The real devices, uPD78312A and uPD78310A, are CMOS products. The IE-78310A-R target interface circuit consists of the evaluation chip (uPD78319A) and emulation circuit containing TTL and others.

The target interface signal lines are divided into three types. The signals differ from those for the real devices in operation, as follows.

① Signals sent out directly from the evaluation chip

The refresh signal and signals related to ports 0, 2, and 3 and A/D converter operate as in the real devices.

Note: Except for signals related to the A/D converter, signals are sent out through a 100- Ω resistor in series.

② Signals sent out from the evaluation chip through gates

The $\overline{\text{RESET}}$, Clock Input, $\overline{\text{RD}}$, $\overline{\text{WR}}$, and ALE signals are delayed when compared with those for the real devices because the signals are sent out through TTLs.

③ Signals sent out from the emulation circuit

The V_{DD} and $\overline{\text{EA}}$ pins are detected by TTL in the emulation circuit. The emulation chip power is supplied by the IE. V_{DD} in the target system is not connected to the evaluation chip.

P1, P4, and P5 are sent out from each port emulator in the emulation circuit. Signals are output from LS TTL to the target, and input from the target to HCT logic.

Therefore, the IE is slightly different from the real device in both DC and AC characteristics.

(10) Notes on using the debugger

o RS-232-C interface

- . Do not connect a terminal to a terminal nor a modem to a modem. When PG-1500 or PG-2000 is connected, put the IE-78310A-R in the modem mode. Use the RS-232-C interface cable attached to PG-1500 or PG-2000 to connect it.
- . Set RTS to RTSN, except for the Pro-typer. Handshaking is divided into hardware handshaking and software handshaking. Channel 1 is shared by both hardware handshaking and software handshaking.

For channel 2, hardware handshaking can be switched to software handshaking and vice versa by a command. Adjust the handshaking to suit the device connected.

- . Adjust the baud rate to that for a device connected.

- o Target probe

- . Connect the ground clip of the target probe to the signal ground line of the target system.

- o External sense clip

- . Connect the external sense clip only to the TTL-level signal line.

(11) Execution examples

The execution examples in Chapter 3 in Software Instruction Manual are given below.

In these examples, data input from the keyboard is underlined.

A>IE78310 <cr>
XX:XX:XX A:IE78310.CMD

IE-78310 CONTROLLER (MD-086/116 SERIES) Vx.x [Dd Mmm Yy]
Copyright (C) 1985 by NEC Corporation

Do you want to use COMMAND LINE EDITOR (Y or N) : Y <cr>

Window off !

Select port NO. (1 to 4) : 1 <cr>

IE-78310A Monitor Vx.x [Dd Mmm Yy]

Copyright (C) 1985 by NEC Corporation

Power on target system (Y/N) Y <cr>

Create new set up mode (Y or N) : N <cr>

Internal ROM size (4K,8K,16K) = 8K <cr>

Tracer initialize (Message indicating trace memory initialization)

Breaker initialize (Message indicating initialization of break
condition and others)

Do you have Memory Board on IE-78310A? (Y/N)= N <cr>

1>CLK I <cr>

1>RES <cr>

1>MAP <cr>

0000-1FFF R/O 2000-FDFF Non

1>MAP W 2000,0FDFF <cr>

1>MAP <cr>

0000-1FFF R/O 2000-FDFF R/W

1>MEM F 0,1FFF 00 <cr>

1>LOD SORT <cr>

object load complete

symbol table loading

MODULE01 load complete

1>LOD SORT.HEX C <cr>

object load complete

1>SYM K <cr>

1>LOD SORT.SYM S <cr>

symbol table loading

MODULE01 load complete

1>MEM D 100,12F <cr>

| | | |
|------|---|-------------------|
| 0100 | 3A 20 01 3A 21 00 20 4A 9F 21 80 08 6F 20 00 00 | : ..!. J.!...o .. |
| 0110 | 00 00 14 FB B8 00 67 42 FE D8 88 E8 59 16 5F 83 |gB....Y._. |
| 0120 | 07 81 05 16 34 55 26 20 26 21 14 DA 00 00 00 00 |4U& &!..... |

```

1>MEM D 100 <cr>
0100 3A 20 01 3A 21 00 20 4A 9F 21 80 08 6F 20 00 00 : .:!. J.!..o ..
0110 00 00 14 FB B8 00 67 42 FE D8 88 E8 59 16 5F 83 .....gB....Y._.
0120 07 81 05 16 34 55 26 20 26 21 14 DA 00 00 00 00 ....4U& &!.....
0130 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0140 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0150 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0160 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0170 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0180 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
0190 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
01A0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..
1>MEM D <cr>
01B0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
01C0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
01D0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
01E0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
01F0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0200 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0210 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0220 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0230 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0240 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0250 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
1>MEM <cr>
0260 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0270 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0280 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0290 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02A0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02B0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02C0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02D0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02E0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
02F0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0300 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
1>MAP <cr>
0000-1FFF R/O 2000-FDFF R/W
1>MAP K 2000,0FDFF <cr>
1>MAP <cr>
0000-1FFF R/O 2000-FDFF Non
1>MEM D 2000,0FDFF <cr>
Mapping error

```

1>DAS 100,12B <cr>

| Addr | Object | Mnemonic |
|------|----------|---------------------|
| | | ORG MODULE01 \ SORT |
| | | MODULE01 \ SORT: |
| 0100 | 3A 20 01 | MOV OFE20H,#1H |
| 0103 | 3A 21 00 | MOV OFE21H,#0H |
| | | MODULE01 \ COMP: |
| 0106 | 20 4A | MOV A,0FE4AH |
| 0108 | 9F 21 | CMP A,0FE21H |
| 010A | 80 08 | BNZ \$CONT |
| 010C | 6F 20 00 | CMP OFE20H,#0H |
| | | MODULE01 \ STOP: |
| 010F | 00 | NOP |
| 0110 | 00 | NOP |
| 0111 | 00 | NOP |
| 0112 | 14 FB | BR \$STOP |
| | | MODULE01 \ CONT: |
| 0114 | B8 00 | MOV R1,#0H |
| 0116 | 67 42 FE | MOVW RP7,#0FE42H |
| 0119 | D8 | XCH A,R0 |
| 011A | 88 E8 | ADDW RP7,RP0 |
| 011C | 59 | MOV A,[HL+] |
| 011D | 16 5F | CMP A,[HL] |
| 011F | 83 07 | BC \$INCI |
| 0121 | 81 05 | BZ \$INCI |
| 0123 | 16 34 | XCH A,[HL-] |
| 0125 | 55 | MOV [HL],A |
| 0126 | 26 20 | INC OFE20H |
| | | MODULE01 \ INCI: |
| 0128 | 26 21 | INC OFE21H |
| 012A | 14 DA | BR \$COMP |
| | | END |

1>DAS 100 <cr>

| Addr | Object | Mnemonic |
|------|----------|---------------------|
| | | ORG MODULE01 \ SORT |
| | | MODULE01 \ SORT: |
| 0100 | 3A 20 01 | MOV OFE20H,#1H |
| 0103 | 3A 21 00 | MOV OFE21H,#0H |
| | | MODULE01 \ COMP: |
| 0106 | 20 4A | MOV A,0FE4AH |
| 0108 | 9F 21 | CMP A,0FE21H |
| 010A | 80 08 | BNZ \$CONT |
| 010C | 6F 20 00 | CMP OFE20H,#0H |
| | | END |

1>DAS <cr>

| Addr | Object | Mnemonic |
|------|----------|---------------------|
| | | ORG MODULE01 \ STOP |
| | | MODULE01 \ STOP: |
| 010F | 00 | NOP |
| 0110 | 00 | NOP |
| 0111 | 00 | NOP |
| 0112 | 14 FB | BR \$STOP |
| | | MODULE01 \ CONT: |
| 0114 | B8 00 | MOV R0,#0H |
| 0116 | 67 42 FE | MOVW RP7,#0FE42H |
| | | END |

1>SYM A SW 0FE20 <cr>

1>SYM A I 0FE21 <cr>

1>SYM A STACK 0FE80 <cr>

1>SYM A LIST 0FE42 <cr>

1>SYM A N 0FE4A <cr>

1>MEM F 0FE00,0FE7F 0 <cr>

1>MEM C 0FE42 <cr>

FE42 00 05 <cr>

FE43 00 03 <cr>

FE44 00 04 <cr>

FE45 00 0A <cr>

FE46 00 08 <cr>

FE47 00 82 <cr>

FE48 00 0A <cr>

FE49 00 04 <cr>

FE4A 00 08 <cr>

FE4B 00 . <cr>

1>MEM D 0FE20,0FE4A <cr>

FE20 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE30 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE40 00 00 05 03 04 0A 08 82 0A 04 08

1>MEM D SW,N <cr>

FE20 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE30 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE40 00 00 05 03 04 0A 08 82 0A 04 08

1>MEM D 0FE20,N <cr>

FE20 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE30 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE40 00 00 05 03 04 0A 08 82 0A 04 08

1>MEM D SW,0FE4A <cr>

FE20 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE30 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

FE40 00 00 05 03 04 0A 08 82 0A 04 08

```

1>BRA <cr>
  A 0H,0FFFFH = MODULE01\ STOP <cr>
  V OXXXXXXXXY = <cr>
    OPcode fetch      (OP)
    Read Write        (RW)
    Read              (R)
    Write              (W)
    Read Write by Program (RWP)
    Read by Program    (RP)
    Write by Program   (WP)
    Read Write by Macro service (RWM)
    Write by Macro service (WM)
    No Condition       (NC)
  C NC = OP <cr>
  L 1H = <cr>
1>BRM BRA <cr>
1>BRM <cr>
  BRA <cr>
1>REG C PC <cr>
  PC      0000 = 100 <cr>
  SP      FE72 = 0FE80 <cr>
1>RUN B 100 <cr>
  User-system Vcc-ON      Emulation start at 0100
  Standard break terminated
  PC  SP  PSW: RBS2 RBS1 RBS0 IE  S  Z  RSS  AC  UF  P/V  SUB  CY
0112 FE80      0  0  0  0  0  0  0  0  0  0  0  1  0
  R0  R1  R2  R3  R4  R5  R6  R7  RP4  RP5  RP6  RP7
  X  A  C  B  FF  FF  FF  FB  VP  UP  DE  HL
  00  00  CB  F7  FF  FF  FF  FB  FFFF  F6FF  FFFF  FE43
  One step emulation standby Press the ESC key.
1>MEM D SW,N <cr>
  FE20  03 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  FE30  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
  FE40  00 00 03 05 04 0A 08 82 0A 04 00 .....
1>MEM C LIST <cr>
  FE42  03 05 <cr>
  FE43  05 03 <cr>
  FE44  04 <cr>
  FE45  0A <cr>
  FE46  08 <cr>
  FE47  82 <cr>
  FE48  0A <cr>
  FE49  04 <cr>
  FE4A  00 08 <cr>
  FE4B  08 00 <cr>
  FE4C  00 . <cr>
1>REG C PC <cr>
  PC      0112 = 100 <cr>
  SP      FE80 = . <cr>

```


1>RUN T .6 REG <cr>

User-system Vcc-ON Emulation start at 0100

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0103 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 00 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0106 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 00 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0108 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 08 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 010A | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 08 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0114 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 08 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0116 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 08 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE43 |

terminated

Frame Status Address Data Label Mnemonic

P0 EX

MODULE01\ CONT:

B0 FF

0000 0114 MOV R0,#0H

One step emulation standby Press the key.

Frame Status Address Data Label Mnemonic

P0 EX

0000 0116 MOVW RP7,#LIST

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 0119 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| X | A | C | B | | | | | | VP | | UP | | DE | HL |
| 00 | 08 | CB | F7 | FF | FF | FF | FB | | FFFF | | F6FF | | FFFF | FE42 |

One step emulation standby Press the ESC key.

1>ASM MODULE01 CONT <cr>

```

0114  MODULE01\ CONT: <cr>
0114          MOV      R0,#0H
          = BR $12C <cr>
          14 16
0116          MOVW     RP7,#LIST
          = ORG 12CH <cr>
012C          NOP
          = MOV A,I <cr>
          20 21
012E          NOP
          = MOV R0,#0H <cr>
          B8 00
0130          NOP
          = BR $116 <cr>
          14 E4
0132          NOP
          = END <cr>

```

1>DAS 114,116 <cr>

| Addr | Object | Mnemonic |
|------|----------|--------------------|
| | | ORG MODULE01\ CONT |
| | | MODULE01\ CONT: |
| 0114 | 14 16 | BR \$12CH |
| 0116 | 67 42 FE | MOVW RP7,#LIST |
| | | END |

1>DAS 12C,131 <cr>

| Addr | Object | Mnemonic |
|------|--------|------------|
| | | ORG 12CH |
| 012C | 20 21 | MOV A,I |
| 012E | B8 00 | MOV R0,#0H |
| 0130 | 14 E4 | BR \$116H |
| | | END |

1>RUN B 100 <cr>

User-system Vcc-ON Emulation start at 0100

Non map area access break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 011D | FE80 | | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 0 | 1 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| | | | | X | A | C | B | | VP | | UP | | DE | HL |
| BD | FE | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | | FFFF | FD00 |

One step emulation standby Press ESC key.

1>MEM D SW,N <cr>

| | | |
|------|--|--------|
| FE20 | 73 BD 00 00 00 00 00 00 00 00 00 00 00 00 00 | S..... |
| FE30 | 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 | |
| FE40 | 00 00 03 04 05 08 0A 0A 04 08 00 | |

1>REG C RSS <cr>

RSS 1 = 0 <cr>

1>REG <cr>

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|-----|------|------|
| 011D | FE80 | | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 1 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | | RP6 | RP7 |
| | | | | X | A | C | B | | VP | | UP | | DE | HL |
| BD | FE | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | | FFFF | FD00 |

```

1>ASM 10C <cr>
010C                                CMP      SW,#0H
                                = BR $132 <cr>
                                14 24
010E                                NOP
                                = NOP <cr>
                                00
010F MODULE01\ STOP: <cr>          NOP
                                = END <cr>

1>ASM 132 <cr>
0132                                NOP
                                = CMP SW,#0H <cr>
                                6F 20 00
0135                                NOP
                                = BNZ $MODULE01\ CONT <cr>
                                80 DD
0137                                NOP
                                = BR $MODULE01\ STOP <cr>
                                14 D6
0139                                NOP
                                = END <cr>

1>DAS 10C,10E <cr>
Addr  Object      Mnemonic
010C  14 24      BR      $132H
010E  00          NOP
                        END

1>DAS 132,138 <cr>
Addr  Object      Mnemonic
0132  6F 20 00    CMP      SW,#0H
0135  80 DD      BNZ      $CONT
0137  14 D6      BR      $STOP
                        END

1>DAS MODULE01\ CONT <cr>
Addr  Object      Mnemonic
                        ORG      MODULE01\ CONT
MODULE01\ CONT:
0114  14 16      BR      $12CH
0116  67 42 FE    MOVW     RP7,#LIST
0119  D8          XCH      A,R0
011A  88 E8      ADDW     RP7,RP0
011C  59          MOV      A,[HL+]
011D  16 5F      CMP      A,[HL]
011F  83 07      BC      $INCI
                        END

1>MEM F LIST,N 5,3,4,0A,8,82,0A,4,8 <cr>
1>BRA A=11F C=0P <cr>

```

1>RUN B 100 <cr>

User-system Vcc-ON Emulation start at 0100

Standard break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|-----|------|
| 0125 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 00 | 03 | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | FFFF | | FE42 |

One step emulation standby Press the key.

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | | |
|-------|--------|---------|------|-------|------------|----|----|---|------|----|------|------|-----|------|
| 0000 | | 0125 | | | MOV [HL],A | | | | | | | | | |
| 0004 | WR | FE42 | 03 | | | B0 | FF | | | | | | | |
| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 0126 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 00 | 03 | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | FFFF | | FE42 |

One step emulation standby Press the key.

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | | |
|-------|--------|---------|------|-------|----------|----|----|---|------|----|------|------|-----|------|
| 0000 | | 0126 | | | INC SW | | | | | | | | | |
| 0003 | RD | FE20 | 01 | | | B0 | FF | | | | | | | |
| 0004 | WR | FE20 | 02 | | | B0 | FF | | | | | | | |
| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 0128 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 00 | 03 | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | FFFF | | FE42 |

One step emulation standby Press the key.

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | | |
|-------|--------|---------|------|-------|-----------------|----|----|---|------|----|------|------|-----|------|
| | | | | | MODULE01\ INCI: | | | | | | | | | |
| 0000 | | 0128 | | | INC I | B0 | FF | | | | | | | |
| 0003 | RD | FE21 | 00 | | | B0 | FF | | | | | | | |
| 0004 | WR | FE21 | 01 | | | B0 | FF | | | | | | | |
| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 012A | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 00 | 03 | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | FFFF | | FE42 |

One step emulation standby Press the ESC key.

1>MEM D LIST.LIST+7 <cr>

FE42 03 05 04 0A 08 82 0A 04

.....

1>MEM D I,I <cr>

FE21 01

1>RUN T ,1 <cr>

User-system Vcc-ON Emulation start at 012A
terminated

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | |
|-------|--------|-----------|------|-------|----------|----|----|------|------|------|------|-----|----|
| 0000 | | 012A | | BR | \$COMP | | | | | | | | |
| PC | SP | PSW: RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 0106 | FE80 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | RP4 | RP5 | RP6 | RP7 | | |
| X | A | C | B | | | | | VP | UP | DE | HL | | |
| 00 | 03 | CB | F7 | FF | FF | FB | FF | FFFF | FFF6 | FFFF | FE42 | | |

One step emulation standby Press the <cr> key.

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | |
|-------|--------|-----------|------|-------|-----------------|----|----|------|------|------|------|-----|----|
| | | | | | MODULE01\ COMP: | | | | | | | | |
| 0000 | | 0106 | | MOV | A,N | | | | | | | | |
| 0003 | RD | FE4A | 08 | | | | | | | | | | |
| PC | SP | PSW: RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 0108 | FE80 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | RP4 | RP5 | RP6 | RP7 | | |
| X | A | C | B | | | | | VP | UP | DE | HL | | |
| 00 | 08 | CB | F7 | FF | FF | FB | FF | FFFF | FFF6 | FFFF | FE42 | | |

One step emulation standby Press the ESC key.

1>BRA A=MODULE01\ INCI C=OP <cr>

1>RUN B <cr>

User-system Vcc-ON Emulation start at 0108
Standard break terminated

| PC | SP | PSW: RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|-----------|------|------|----|----|----|------|------|------|------|-----|----|
| 0106 | FE80 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | RP4 | RP5 | RP6 | RP7 | | |
| X | A | C | B | | | | | VP | UP | DE | HL | | |
| 01 | 04 | CB | F7 | FF | FF | FB | FF | FFFF | FFF6 | FFFF | FE43 | | |

One step emulation standby Press the ESC key.

1>MEM D I,I <cr>

FE21 02

1>MEM D LIST,LIST+7 <cr>

FE42 03 04 05 0A 08 82 0A 04

.....

1>RUN T ,1 <cr>

User-system Vcc-ON Emulation start at 0106
terminated

| Frame | Status | Address | Data | Label | Mnemonic | P0 | EX | | | | | | |
|-------|--------|-----------|------|-------|-----------------|----|----|------|------|------|------|-----|----|
| | | | | | MODULE01\ COMP: | | | | | | | | |
| 0000 | | 0106 | | MOV | A,N | | | | | | | | |
| 0003 | RD | FE4A | 08 | | | | | | | | | | |
| PC | SP | PSW: RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
| 0108 | FE80 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | RP4 | RP5 | RP6 | RP7 | | |
| X | A | C | B | | | | | VP | UP | DE | HL | | |
| 01 | 08 | CB | F7 | FF | FF | FB | FF | FFFF | FFF6 | FFFF | FE43 | | |

One step emulation standby Press the ESC key.

1>RUN B <cr>

User-system Vcc-ON Emulation start at 0108

Standard break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|------|----|
| 0106 | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | RP7 | |
| X | A | C | B | | | | | | VP | | UP | DE | HL | |
| 02 | 05 | CB | F7 | FF | FF | FB | FF | | FFFF | | FFF6 | FFFF | FE45 | |

One step emulation standby Press the ESC key.

1>MEM D I,I <cr>

FE21 03

1>MEM D LIST,LIST+7 <cr>

FE42 03 04 05 0A 08 82 0A 04

1>BRA A=MODULE01\ STOP 132 C=OP <cr>

1>RUN B <cr>

User-system Vcc-ON Emulation start at 0106

Non map area access break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|------|----|
| 011D | FE80 | | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 0 | 1 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | RP7 | |
| | | | | X | A | C | B | | VP | | UP | DE | HL | |
| BD | FE | CB | F7 | FF | FF | FF | FF | | F6FF | | FFFF | FFFF | FD00 | |

One step emulation standby Press the ESC key.

1>MEM D LIST,N <cr>

FE42 03 04 05 08 0A 0A 04 08 00

1>REG C RSS <cr>

RSS 1 = 0

1>REG <cr>

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|------|----|
| 011D | FE80 | | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 1 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | RP7 | |
| | | | | X | A | C | B | | VP | | UP | DE | HL | |
| BD | FE | CB | F7 | FF | FF | FF | FF | | F6FF | | FFF6 | FFFF | FD00 | |

1>MEM F LIST,N 5,3,4,0A,8,82,0A,4,8 <cr>

1>DAS 126,12B <cr>

| Addr | Object | Mnemonic |
|------|--------|-----------------|
| | | ORG 126H |
| 0126 | 26 20 | INC SW |
| | | MODULE01\ INCI: |
| 0128 | 26 21 | INC I |
| 012A | 14 DA | BR \$COMP |
| | | END |

1>BRA A=126 C=OP <cr>

1>RUN B 100 <cr>

User-system Vcc-ON Emulation start at 0100

Standard break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|------|----|
| 012A | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | RP7 | |
| X | A | C | B | | | | | | VP | | UP | DE | HL | |
| 00 | 03 | CB | F7 | FF | FF | FF | FF | | F6FF | | FFFF | FFFF | FE42 | |

One step emulation standby Press the ESC key.

1>MEM D I,I <cr>

FE21 01

```

1>MEM D LIST,LIST+7 <cr>
FE42      03 05 04 0A 08 0A 04      .....
1>RUN T ,1 <cr>
User-system Vcc-ON      Emulation start at 012A
terminated
Frame Status Address Data Label Mnemonic PO EX
0000      012A      BRC      $COMP
PC      SP      PSW: RBS2 RBS1 RBS0 IE      S      Z      RSS      AC      UF      P/V      SUB      CY
0106      FE80      0      0      0      0      0      0      0      0      0      1      0      0      0
R0      R1      R2      R3      R4      R5      R6      R7      RP4      RP5      RP6      RP7
X      A      C      B      VP      UP      DE      HL
00      03      CB      F7      FF      FF      FF      FF      F6FF      FFFF      FFFF      FE42
One step emulation standby Press the ESC key.
1>RUN B <cr>
User-system Vcc-ON      Emulation start at 0106
Standard break      terminated
PC      SP      PSW: RBS2 RBS1 RBS0 IE      S      Z      RSS      AC      UF      P/V      SUB      CY
012A      FE80      0      0      0      0      0      0      0      0      0      1      0      0      0
R0      R1      R2      R3      R4      R5      R6      R7      RP4      RP5      RP6      RP7
X      A      C      B      VP      UP      DE      HL
01      04      CB      F7      FF      FF      FF      FF      F6FF      FFFF      FFFF      FE43
One step emulation standby Press the ESC key.
1>MEM D I,I <cr>
FE21      02
1>MEM D LIST,LIST+7 <cr>
FE42      03 04 05 0A 08 82 0A 04      .....
1>RUN T ,1 <cr>
User-system Vcc-ON      Emulation start at 012A
terminated
Frame Status Address Data Label Mnemonic PO EX
0000      012A      BR      $COMP
PC      SP      PSW: RBS2 RBS1 RBS0 IE      S      Z      RSS      AC      UF      P/V      SUB      CY
0106      FE80      0      0      0      0      0      0      0      0      0      1      0      0      0
R0      R1      R2      R3      R4      R5      R6      R7      RP4      RP5      RP6      RP7
X      A      C      B      VP      UP      DE      HL
01      04      CB      F7      FF      FF      FF      FF      F6FF      FFFF      FFFF      FE43
One step emulation standby Press the ESC key.
1>RUN B <cr> User-system Vcc-ON      Emulation start at 0106
Standard break      terminated
PC      SP      PSW: RBS2 RBS1 RBS0 IE      S      Z      RSS      AC      UF      P/V      SUB      CY
012A      FE80      0      0      0      0      0      0      0      0      0      1      0      0      0
R0      R1      R2      R3      R4      R5      R6      R7      RP4      RP5      RP6      RP7
X      A      C      B      VP      UP      DE      HL
03      08      CB      F7      FF      FF      FF      FF      F6FF      FFFF      FFFF      FE45
One step emulation standby Press the ESC key.
1>MEM D I,I <cr>
FE21      04
1>MEM D LIST,LIST+7 <cr>
FE42      03 04 05 08 0A 82 0A 04      .....
1>MEM D SW,SW <cr>
FE20      04

```

1>ASM 135 <cr>

```
0135                                BNZ      $COMP
                                = BNZ $MODULE01 \ SORT <cr>

                                80 C9

0137                                BR       $STOP
                                = END <cr>
```

1>DAS 135,136 <cr>

| Addr | Object | Mnemonic |
|------|--------|------------|
| | | ORG 135H |
| 0135 | 80 C9 | BNZ \$SORT |
| | | END |

1>MEM F LIST,N 5,3,4,0A,8,82,0A,4,8 <cr>

1>TRM ALL <cr>

1>BRA A=MODULE01 \ COMP L=9 C=OP <cr>

1>RUN B 100 <cr>

User-system Vcc-ON Emulation start at 0100

Standard break terminated

| PC | SP | PSW: | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|------|------|------|------|----|----|---|------|----|------|------|-----|------|
| 010A | FE80 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 07 | 82 | CB | F7 | FF | FF | FF | FF | | F6FF | | FFFF | FFFF | | FE49 |

One step emulation standby Press the ESC key.

1>MEM D N,N <cr>

FE4A 82

1>MEM D I,I <cr>

FE21 08

1>MEM D LIST,LIST+7 <cr>

FE42 03 04 05 08 0A 0A 04 08

1>TRD I ALL <cr>

| Frame | Status | Address | Data | Label | Mnemonic |
|------------------|--------|---------|------|-------|-----------|
| MODULE01 \ SORT: | | | | | |
| 0000 | | 0100 | | MOV | SW,#1H |
| 0004 | WR | FE20 | 01 | | |
| 0003 | | 0103 | | MOV | I,#0H |
| 0008 | WR | FE21 | 00 | | |
| MODULE01 \ COMP: | | | | | |
| 0007 | | 0106 | | MOV | A,N |
| 0011 | RD | FE4A | 08 | | |
| 0010 | | 0108 | | CMP | A,I |
| 0014 | RD | FE21 | 00 | | |
| 0013 | | 010A | | BNZ | \$CONT |
| MODULE01 \ CONT: | | | | | |
| 0018 | | 0114 | | BR | \$12CH |
| 0022 | | 012C | | MOV | A,I |
| 0025 | RD | FE21 | 00 | | |
| 0024 | | 012E | | MOV | R0,#0H |
| 0027 | | 0130 | | BR | \$116H |
| 0031 | | 0116 | | MOVW | RP7,#LIST |
| 0034 | | 0119 | | XCH | A,R0 |
| 0035 | | 011A | | ADDW | RP7,RP0 |
| 0037 | | 011C | | MOV | A,[HL+] |
| 0041 | RD | FE42 | 05 | | |
| 0038 | | 011D | | CMP | A,[HL] |

| | | | | | |
|------------------|----|------|----|------|-----------|
| 0043 | RD | FE43 | 03 | | |
| 0040 | | 011F | | BC | \$INCI |
| 0044 | | 0121 | | BZ | \$INCI |
| 0046 | | 0123 | | XCH | A,[HL-] |
| 0050 | RD | FE43 | 03 | | |
| 0051 | WR | FE43 | 05 | | |
| 0048 | | 0125 | | MOV | [HL],A |
| 0054 | WR | FE42 | 03 | | |
| 0049 | | 0126 | | INC | SW |
| 0055 | RD | FE20 | 01 | | |
| 0056 | WR | FE20 | 02 | | |
| MODULE01 \ INCI: | | | | | |
| 0053 | | 0128 | | INC | I |
| 0059 | RD | FE21 | 00 | | |
| 0060 | WR | FE21 | 01 | | |
| 0058 | | 012A | | BR | \$COMP |
| MODULE01 \ COMP: | | | | | |
| 0064 | | 0106 | | MOV | A,N |
| 0067 | RD | FE4A | 08 | | |
| 0066 | | 0108 | | CMP | A,I |
| 0070 | RD | FE21 | 01 | | |
| 0069 | | 010A | | BNZ | \$CONT |
| MODULE01 \ CONT: | | | | | |
| 0074 | | 0114 | | BR | \$12CH |
| 0078 | | 012C | | MOV | A,I |
| 0081 | RD | FE21 | 01 | | |
| 0080 | | 012E | | MOV | R0,#0H |
| 0083 | | 0130 | | BR | \$116H |
| 0087 | | 0116 | | MOVW | RP7,#LIST |
| 0090 | | 0119 | | XCH | A,R0 |
| 0091 | | 011A | | ADDW | RP7,RP0 |
| 0093 | | 011C | | MOV | A,[HL+] |
| 0097 | RD | FE43 | 05 | | |
| 0094 | | 011D | | CMP | A,[HL] |
| 0099 | RD | FE44 | 04 | | |
| 0096 | | 011F | | BC | \$INCI |
| 0100 | | 0121 | | BZ | \$INCI |
| 0102 | | 0123 | | XCH | A,[HL-] |
| 0106 | RD | FE44 | 04 | | |
| 0107 | WR | FE44 | 05 | | |
| 0104 | | 0125 | | MOV | [HL],A |
| 0110 | WR | FE43 | 04 | | |
| 0105 | | 0126 | | INC | SW |
| 0111 | RD | FE20 | 02 | | |
| 0112 | WR | FE20 | 03 | | |
| MODULE01 \ INCI: | | | | | |
| 0109 | | 0128 | | INC | I |
| 0115 | RD | FE21 | 01 | | |
| 0116 | WR | FE21 | 02 | | |
| 0114 | | 012A | | BR | \$COMP |
| MODULE01 \ COMP: | | | | | |
| 0120 | | 0106 | | MOV | A,N |
| 0123 | RD | FE4A | 08 | | |
| 0122 | | 0108 | | CMP | A,I |

| | | | | |
|------|----|------|----|-----------------|
| 0126 | RD | FE21 | 02 | |
| 0125 | | 010A | | BNZ \$CONT |
| | | | | MODULE01\ CONT: |
| 0130 | | 0114 | | BR \$12CH |
| 0134 | | 012C | | MOV A,I |
| 0137 | RD | FE21 | 02 | |
| 0136 | | 012E | | MOV RO,#0H |
| 0139 | | 0130 | | BR \$116H |
| 0143 | | 0116 | | MOVW BP7,#LIST |
| 0146 | | 0119 | | XCH A,RO |
| 0147 | | 011A | | ADDW RP7,RP0 |
| 0149 | | 011C | | MOV A,[HL+] |
| 0153 | RD | FE44 | 05 | |
| 0150 | | 011D | | CMP A,[HL] |
| 0155 | RD | FE45 | 0A | |
| 0152 | | 011F | | BC \$INCI |
| | | | | MODULE01\ INCI: |
| 0158 | | 0128 | | INC I |
| 0161 | RD | FE21 | 02 | |
| 0162 | WR | FE21 | 03 | |
| 0160 | | 012A | | BR \$COMP |
| | | | | MODULE01\ COMP: |
| 0166 | | 0106 | | MOV A,N |
| 0169 | RD | FE4A | 08 | |
| 0168 | | 0108 | | CMP A,I |
| 0172 | RD | FE21 | 03 | |
| 0171 | | 010A | | BNZ \$CONT |
| | | | | MODULE01\ CONT: |
| 0176 | | 0114 | | BR \$12CH |
| 0180 | | 012C | | MOV A,I |
| 0183 | RD | FE21 | 03 | |
| 0182 | | 012E | | MOV RO,#0H |
| 0185 | | 0130 | | BR \$116H |
| 0189 | | 0116 | | MOVW RP7,#LIST |
| 0192 | | 0119 | | XCH A,RO |
| 0193 | | 011A | | ADDW RP7,RP0 |
| 0195 | | 011C | | MOV A,[HL+] |
| 0199 | RD | FE45 | 0A | |
| 0196 | | 011D | | CMP A,[HL] |
| 0201 | RD | FE46 | 08 | |
| 0198 | | 011F | | BC \$INCI |
| 0202 | | 0121 | | BZ \$INCI |
| 0204 | | 0123 | | XCH A,[HL-] |
| 0208 | RD | FE46 | 08 | |
| 0209 | WR | FE46 | 0A | |
| 0206 | | 0125 | | MOV [HL],A |
| 0212 | WR | FE45 | 08 | |
| 0207 | | 0126 | | INC SW |
| 0213 | RD | FE20 | 03 | |
| 0214 | WR | FE20 | 04 | |
| | | | | MODULE01\ INCI: |
| 0211 | | 0128 | | INC I |
| 0217 | RD | FE21 | 03 | |
| 0218 | WR | FE21 | 04 | |

| | | | | | |
|------|----|------|----|------------------|-----------|
| 0216 | | 012A | | BR | \$COMP |
| | | | | MODULE01 \ COMP: | |
| 0222 | | 0106 | | MOV | A,N |
| 0225 | RD | FE4A | 08 | | |
| 0224 | | 0108 | | CMP | A,I |
| 0228 | RD | FE21 | 04 | | |
| 0227 | | 010A | | BNZ | \$CONT |
| | | | | MODULE01 \ CONT: | |
| 0232 | | 0114 | | BR | \$12CH |
| 0236 | | 012C | | MOV | A,I |
| 0239 | RD | FE21 | 04 | | |
| 0238 | | 012E | | MOV | R0,#0H |
| 0241 | | 0130 | | BR | \$116H |
| 0245 | | 0116 | | MOVW | RP7,#LIST |
| 0248 | | 0119 | | XCH | A,R0 |
| 0249 | | 011A | | ADDW | RP7,RP0 |
| 0251 | | 011C | | MOV | A,[HL+] |
| 0255 | RD | FE46 | 0A | | |
| 0252 | | 011D | | CMP | A,[HL] |
| 0257 | RD | FE47 | 82 | | |
| 0254 | | 011F | | BC | \$INCI |
| | | | | MODULE01 \ INCI: | |
| 0260 | | 0128 | | INC | I |
| 0263 | RD | FE21 | 04 | | |
| 0264 | WR | FE21 | 05 | | |
| 0262 | | 012A | | BR | \$COMP |
| | | | | MODULE01 \ COMP: | |
| 0268 | | 0106 | | MOV | A,N |
| 0271 | RD | FE4A | 08 | | |
| 0270 | | 0108 | | CMP | A,I |
| 0274 | RD | FE21 | 05 | | |
| 0273 | | 010A | | BNZ | \$CONT |
| | | | | MODULE01 \ CONT: | |
| 0278 | | 0114 | | BR | \$12CH |
| 0282 | | 012C | | MOV | A,I |
| 0285 | RD | FE21 | 05 | | |
| 0284 | | 012E | | MOV | R0,#0H |
| 0287 | | 0130 | | BR | \$116H |
| 0291 | | 0116 | | MOVW | RP7,#LIST |
| 0294 | | 0119 | | XCH | A,R0 |
| 0295 | | 011A | | ADDW | RP7,RP0 |
| 0297 | | 011C | | MOV | A,[HL+] |
| 0301 | RD | FE47 | 82 | | |
| 0298 | | 011D | | CMP | A,[HL] |
| 0303 | RD | FE48 | 0A | | |
| 0300 | | 011F | | BC | \$INCI |
| 0304 | | 0121 | | BZ | \$INCI |
| 0306 | | 0123 | | XCH | A,[HL-] |
| 0310 | RD | FE48 | 0A | | |
| 0311 | WR | FE48 | 82 | | |
| 0308 | | 0125 | | MOV | [HL],A |
| 0314 | WR | FE47 | 0A | | |
| 0309 | | 0126 | | INC | SW |
| 0315 | RD | FE20 | 04 | | |

| | | | | |
|------|----|------|----|-----------------|
| 0316 | WR | FE20 | 05 | |
| 0313 | | 0128 | | MODULE01\ INCI: |
| 0319 | RD | FE21 | 05 | INC I |
| 0320 | WR | FE21 | 06 | |
| 0318 | | 012A | | BR \$COMP |
| | | | | MODULE01\ COMP: |
| 0324 | | 0106 | | MOV A,N |
| 0327 | RD | FE4A | 08 | |
| 0326 | | 0108 | | CMP A,I |
| 0330 | RD | FE21 | 06 | |
| 0329 | | 010A | | BNZ \$CONT |
| | | | | MODULE01\ CONT: |
| 0334 | | 0114 | | BR \$12CH |
| 0338 | | 012C | | MOV A,I |
| 0341 | RD | FE21 | 06 | |
| 0340 | | 012E | | MOV R0,#0H |
| 0343 | | 0130 | | BR \$116H |
| 0347 | | 0116 | | MOVW RP7,#LIST |
| 0350 | | 0119 | | XCH A,R0 |
| 0351 | | 011A | | ADDW RP7,RP0 |
| 0353 | | 011C | | MOV A,[HL+] |
| 0357 | RD | FE48 | 82 | |
| 0354 | | 011D | | CMP A,[HL] |
| 0359 | RD | FE49 | 04 | |
| 0356 | | 011F | | BC \$INCI |
| 0360 | | 0121 | | BZ \$INCI |
| 0362 | | 0123 | | XCH A,[HL-] |
| 0366 | RD | FE49 | 04 | |
| 0367 | WR | FE49 | 82 | |
| 0364 | | 0125 | | MOV [HL],A |
| 0370 | WR | FE48 | 04 | |
| 0365 | | 0126 | | INC SW |
| 0371 | RD | FE20 | 05 | |
| 0372 | WR | FE20 | 06 | |
| | | | | MODULE01\ INCI: |
| 0369 | | 0128 | | INC I |
| 0375 | RD | FE21 | 06 | |
| 0376 | WR | FE21 | 07 | |
| 0374 | | 012A | | BR \$COMP |
| | | | | MODULE01\ COMP: |
| 0380 | | 0106 | | MOV A,N |
| 0383 | RD | FE4A | 08 | |
| 0382 | | 0108 | | CMP A,I |
| 0386 | RD | FE21 | 07 | |
| 0385 | | 010A | | BNZ \$CONT |
| | | | | MODULE01\ CONT: |
| 0390 | | 0114 | | BR \$12CH |
| 0394 | | 012C | | MOV A,I |
| 0397 | RD | FE21 | 07 | |
| 0396 | | 012E | | MOV R0,#0H |
| 0399 | | 0130 | | BR \$116H |
| 0403 | | 0116 | | MOVW RP7,#LIST |
| 0406 | | 0119 | | XCH A,R0 |

| | | | | | |
|--------------------|------------------------------------|------|----|------------------|-----------------|
| 0407 | | 011A | | ADDW | RP7,RP0 |
| 0409 | | 011C | | MOV | A,[HL+] |
| 0413 | RD | FE49 | 82 | | |
| 0410 | | 011D | | CMP | A,[HL] |
| 0415 | RD | FE4A | 08 | | |
| 0412 | | 011F | | BC | \$INCI |
| 0416 | | 0121 | | BZ | \$INCI |
| 0418 | | 0123 | | XCH | A,[HL-] |
| 0422 | RD | FE4A | 08 | | |
| 0423 | WR | FE4A | 82 | | |
| 0420 | | 0125 | | MOV | [HL],A |
| 0426 | WR | FE49 | 08 | | |
| 0421 | | 0126 | | INC | SW |
| 0427 | RD | FE20 | 06 | | |
| 0428 | WR | FE20 | 07 | | |
| MODULE01 \ INCI: | | | | | |
| 0425 | | 0128 | | INC | I |
| 0431 | RD | FE21 | 07 | | |
| 0432 | WR | FE21 | 08 | | |
| 0430 | | 012A | | BR | \$COMP |
| MODULE01 \ COMP: | | | | | |
| 0436 | | 0106 | | MOV | A,N |
| 0439 | RD | FE4A | 82 | | |
| 0438 | | 0108 | | CMP | A,I |
| 0442 | RD | FE21 | 08 | | |
| 1>DAS 106,109 <cr> | | | | | |
| Addr | Object | | | Mnemonic | |
| | | | | ORG | MODULE01 \ COMP |
| | | | | MODULE01 \ COMP: | |
| 0106 | 20 4A | | | MOV | A,N |
| 0108 | 9F 21 | | | CMP | A.I |
| | | | | END | |
| 1>ASM 106 <cr> | | | | | |
| 0106 | <u>MODULE01 \ COMP: <cr></u> | | | | |
| 0106 | | | | MOV | A,I |
| | | | | = BR \$139 <cr> | |
| | 14 31 | | | | |
| 0108 | | | | CMP | A,I |
| | | | | = END <cr> | |

```

1>ASM 139
0139          NOP
              = MOV A,N <cr>
              20 4A
013B          NOP
              = DEC R1 <cr>
              C9
013C          NOP
              = CMP A,I <cr>
              9F 21
013E          NOP
              = BNZ $MODULE01\ CONT <cr>
              80 D4
0140          NOP
              = BR $10C <cr>
              14 CA
0142          NOP
              = END <cr>

```

```

1>ASM MODULE01\ SORT <cr>
0100 MODULE01\ SORT:
0100          MOV      SW,#1H
              = MOV SW,#0H <cr>
              3A 20 00
0103          MOV      I,#0H
              = END <cr>

```

1>SYM C LIST OFE22 <cr>

1>SYM C N OFE2A <cr>

1>SYM E STACK <cr>

1>MEM C 117 <cr>

0117 42 22 <cr>

0118 FE . <cr>

1>MEM C 13A <cr>

013A 4A 2A <cr>

013B C9 . <cr>

1>DAS 100,141 <cr>

| Addr | Object | Mnemonic |
|------|----------|--------------------|
| | | ORG MODULE01\ SORT |
| | | MODULE01\ SORT: |
| 0100 | 3A 20 00 | MOV SW,#0H |
| 0103 | 3A 21 00 | MOV I,#0H |
| | | MODULE01\ COMP: |
| 0106 | 14 31 | BR \$139H |
| 0108 | 9F 21 | CMP A,I |
| 010A | 80 08 | BNZ \$CONT |
| 010C | 14 24 | BR \$132H |
| 010E | 00 | NOP |
| | | MODULE01\ STOP: |
| 010F | 00 | NOP |
| 0110 | 00 | NOP |
| 0111 | 00 | NOP |
| 0112 | 14 FB | BR \$STOP |
| | | MODULE01\ CONT: |
| 0114 | 14 16 | BR \$12CH |
| 0116 | 67 22 FE | MOVW RP7,#LIST |

```

0119 D8          XCH      A,R0
011A 88 E8      ADDW     RP7,RP0
011C 59          MOV      A,[HL+]
011D 16 5F      CMP      A,[HL]
011F 83 07      BC        $INCI
0121 81 05      BZ        $INCI
0123 16 34      XCH      A,[HL-]
0125 55          MOV      [HL],A
0126 26 20      INC      SW

```

MODULE01 \ INCI:

```

0128 26 21      INC      I
012A 14 DA      BR        $COMP
012C 20 21      MOV      A,I
012E B8 00      MOV      R0,#0H
0130 14 E4      BR        $116H
0132 6F 20 00   CMP      SW,#0H
0135 80 C9      BNZ      $SORT
0137 14 D6      BR        $STOP
0139 20 2A      MOV      A,N
013B C9          DEC      R1
013C 9F 21      CMP      A,I
013E 80 D4      BNZ      $CONT
0140 14 CA      BR        $10CH

```

END

1>MEM F LIST,N 5,3,4,0A,8,82,0A,4,8 <cr>

1>BRA A=MODULE01 \ STOP C=0P <cr>

1>RUN B 100 <cr>

User-system Vcc-ON Emulation start at 0100

Standard break terminated

| PC | SP | PSW | RBS2 | RBS1 | RBS0 | IE | S | Z | RSS | AC | UF | P/V | SUB | CY |
|------|------|-----|------|------|------|----|----|---|------|----|------|------|-----|------|
| 0112 | FE80 | | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 |
| R0 | R1 | R2 | R3 | R4 | R5 | R6 | R7 | | RP4 | | RP5 | RP6 | | RP7 |
| X | A | C | B | | | | | | VP | | UP | DE | | HL |
| 06 | 07 | CB | F7 | FF | FF | FF | FF | | F6FF | | FFFF | FFFF | | FE29 |

One step emulation standby Press the ESC key.

1>MEM D LIST,LIST+7 <cr>

FE22 03 04 04 05 08 0A 0A 82

.....

1>MEM D N,N <cr>

FE2A

08

.

1>MEM D SW,I <cr>

FE20 00 07

1>SAV SORT01.HEX 100,141 <cr>

..

object save complete

1>VRY SORT01.HEX <cr>

object verify complete

1>

APPENDIX B



This appendix describes how the system software for use under CP/M-86, MS-DOS, and PC DOSTM differs from that designed for use under MD-086/116 when a host computer other than the MD Series (PC-9800 Series, IBM PC/AT) is used.

Appendix B is divided into three parts:

Part I: System Software for PC-9800 Series (CP/M-86)

Part II: System Software for PC-9800 Series (MS-DOS)

Part III: System Software for IBM PC/AT (PC DOS)

When a series or model name, listed in the left-hand column of the table below, appears in this manual, it should be substituted with the corresponding series or model name listed on the right.

| | | |
|-----------------|----|----------------|
| . PC-9800 | -> | PC-9800 Series |
| . IBM PC Series | } | -> IBM PC/AT |
| . IBM PC | | |
| . IE-78310-R | -> | IE-78310A-R |

PART I SYSTEM SOFTWARE FOR PC-9800 SERIES (CP/M-86)

CHAPTER 1 OVERVIEW

The system software runs under CP/M-86 on the PC-9800 Series, and enables the PC-9800 Series to provide the same development environment as that supported by the conventional MD-086/116 Series.

This instruction manual describes how this software differs from the system software for the MD-086/116 Series, distributed with the IE-78310-R. For details of the commands, refer to the instruction manual provided with the IE-78310-R.

1.1 System Configuration

To run the system software, the system must be configured as follows.

(1) Host computer

PC-9800 Series, other than PC-98XA

(2) Operating system (OS)

CP/M-86 V1.1, or CP/M-86 V1.1, Japanese language version

(3) Console

Keyboard and CRT display unit provided with the PC-9801

(4) Connection with the IE-78310-R

RS-232-C interface built into the PC-9801 main unit

1.2 System Software Distribution

(1) File names

The system software includes the following files:

- . IE78310.CMD (Main system software for the PC-9800 Series)
 - . IE78310.OV1
 - . IE78310.OV2
 - . IE78310.HLP
- } (System software overlay files)

(2) Distribution media

- . 8" 2D (Product name: uS6A1IE78310-P01)
- . 5" 2HD (Product name: uS6A10IE78310-P01)

CHAPTER 2 CONNECTION

This chapter describes how to connect the PC-9801 to the IE-78310-R.

- (1) Turn off the power of the PC-9801 and IE-78310-R.
- (2) Set CH1 on the IE-78310-R as shown in Figure 2-1.

Then, set the following:


Baud rate: 9600 bps

Mode: Modem

RTS: Standard

- (3) Connect the standard RS-232-C interface on the back of the PC-9801 main unit to CH1 of the IE-78310-R, using the cable supplied with the IE-78310-R.
- (4) Turn on the power of the PC-9801 and IE-78310-R.

Fig. 2-1 Setting CH1



CHAPTER 3 STARTING THE SYSTEM SOFTWARE

Start the system software as described below.

- (1) Start CP/M-86 on the PC-9801.
- (2) Set the RS-232-C channel mode by executing the SPEED command of CP/M-86.

Set the RS-232-C channel as follows:

Baud rate: 9600 bps

Character length: 8 bits

Parity: None

Stop bits: 2

XON/XOFF: Either XON or XOFF

- (3) Insert the IE78310 system disk into a floppy drive.
- (4) Perform a warm boot by pressing Ctrl-C.
- (5) Change the current drive to that into which the IE78310 system disk is inserted.
- (6) Key in "IE78310 <cr>". Then, the system software starts.

An example of starting the system software is given below.
In this example, the SPEED command is entered from drive A, and the IE78310 system disk is in drive B.

```

Prompt when CP/M-86 starts
A>SPEED <cr> ← Executes the SPEED command.
SPEED Version X.X
RS232C-0 XXXX BITS-X PARITY-XXX STOP-X XXXX ← Displays the current mode
                                                of the RS-232C channel.
-RS232C-0 9600BITS-8 PARITY-NONE STOP-2 <cr> ← Resets the mode for
                                                IE-78310-R connection.
A>↑C ← Performs a warm boot after the IE78310 system disk
A>B: <cr> ← has been inserted into drive B.
B>IE78310 <cr> ← Changes the current drive.
                  Starts the system software.

IE-78310 CONTROLLER (PC-9800 SERIES) Vx.x [DD Mmm YY]
Copyright (C) 1985 by NEC Corporation

IE-78310 Monitor Vx.x [DD Mmm YY]
Copyright (C) 1985 by NEC Corporation

Power on target system (Y/N) Y <cr>
Create new set up mode (Y or N) : N <cr>
Internal ROM size (4K,8K,16K) = 8K <cr>
Tracer initialize
Breaker initialize
Do you have Memory Board on IE-78310 ? (Y/N) = N <cr>
0>

```

For information about the setting of this portion, refer to Chapter 3 of "IE-78310A-R User's Manual, Software (EEU-637)."

Even when the IE-78310-R is connected, the following indication will appear if there is an RS-232-C interface mismatch between the IE-78310-R and PC-9801:

No connect!

Abort (Y/N):

In this case, type "Y" to abort connection to the IE78310 and return to CP/M-86. Then, by executing the SPEED command, match the mode setting with that of the RS-232-C interface of the IE-78310-R.

CHAPTER 4 NOTES ON USE

When using the IE78310 with CP/M-86 running on the PC-9801, pay particular attention to the following.

4.1 Terminating the IE78310

4.1.1 RS-232-C mode alteration

The changed RS-232-C interrupt mode is used in the IE-78310. So, reset the RS-232-C channel mode by executing the SPEED command when the RS-232-C channel is to be used with another application program after the IE78310 is terminated.

When, however, the IE78310 is to be reexecuted after being terminated once, the SPEED command need not be executed.

4.1.2 Key code alteration

The changed key codes are used for keys, DEL, <-, and ->, in the IE78310. When the default key codes are needed for these keys after terminating the IE78310, reset the key codes by using suitable supported key commands.

The following key codes are set when the IE78310 is terminated:

DEL: 7FH

<- : 1DH

-> : 1CH

CHAPTER 5 DIFFERENCES FROM SYSTEM SOFTWARE RUNNING UNDER MD-086/116

The IE78310 for CP/M-86 running on the PC-9801 differs from the IE78310 for MD-086/116, as described below.

- (1) The console detach/attach function is not supported.

The console detach/attach function is a Concurrent CP/MTM function. CP/M-86, running on the PC-9801, is a single-task operating system. Therefore, this function is not supported.

- (2) Channel number setting is not required.

With the MD-086/116, four RS-232-C channels are provided as standard, and up to eight RS-232-C channels can be used. The PC-9801, however, allows only one RS-232-C channel to be used (as standard). Only this one standard channel is used, eliminating the need for channel number setting.

PART II SYSTEM SOFTWARE FOR PC-9800 SERIES (MS-DOS)

CHAPTER 1 OVERVIEW

The system software runs under MS-DOS on the PC-9800 Series, and enables the PC-9800 Series to provide the same development environment as that supported by the conventional MD-086/116 Series.

This instruction manual describes how this software differs from the system software for the MD-086/116 Series, distributed with the IE-78310-R. For details of the commands, refer to the instruction manual provided with the IE-78310-R.

1.1 System Configuration

To run the system software, the system must be configured as follows.

(1) Host computer

PC-9800 Series, other than PC-98XA

(2) Operating system (OS)

MS-DOS V3.30/3.30A/3.30B/3.30C/3.30D/5.00(Note)/
5.00A(Note)

Note: The task swapping function of V5.00 and V5.00A cannot be used with the system software.

(3) Console

Keyboard and CRT display unit provided with the PC-9801

(4) Connection with the IE-78310-R

RS-232-C interface built into the PC-9801 main unit

1.2 System Software Distribution

(1) File names

The system software includes the following files:

- . IE78310.COM (Main system software for the PC-9800 Series)
 - . IE78310.OM0
 - . IE78310.OV1
 - . IE78310.OV2
 - . IE78310.HLP
- (System software overlay files)

(2) Distribution media

- . 8" 2D (Product name: uS5A1IE78310-P01)
- . 5" 2HD (Product name: uS5A10IE78310-P01)
- . 3.5" 2HD (Product name: uS5A13IE78310)

CHAPTER 2 CONNECTION

This chapter describes how to connect the PC-9801 to the IE-78310-R.

- (1) Turn off the power of the PC-9801 and IE-78310-R.
- (2) Set CH1 on the IE-78310-R as shown in Figure 2-1.

Then, set the following:


Baud rate: 9600 bps

Mode: Modem

RTS: Standard

- (3) Connect the standard RS-232-C channel on the back of the PC-9801 main unit to CH1 of the IE-78310-R, using the cable supplied with the IE-78310-R.
- (4) Turn on the power of the PC-9801 and IE-78310-R.

Fig. 2-1 Setting CH1



CHAPTER 3 STARTING THE SYSTEM SOFTWARE

Start the system software as described below.

- (1) Start MS-DOS on the PC-9801.
- (2) Set the RS-232-C channel mode by executing the SPEED command of MS-DOS.

Set the RS-232-C channel as follows:

Baud rate: 9600 bps

Character length: 8 bits

Parity: None

Stop bits: 2

XON/XOFF: Either XON or XOFF.

- (3) Insert the IE78310 system disk into a floppy drive.
- (4) Change the current drive to that into which the IE78310 system disk is inserted.
- (5) Key in "IE78310 <cr>". Then, the system software starts.

An example of starting the system software is given below.
 In this example, the SPEED command is entered from drive A, and
 the IE78310 system disk is in drive B.

```

Prompt when MS-DOS starts
Executes the SPEED command.
A>SPEED <cr>
SPEED Version X.X
RS232C-0 XXXX BITS-X PARITY-XXX STOP-X XXXX
-RS232C-0 9600 BITS-8 PARITY-NONE STOP-2 <cr>
A>B: <cr>
B>IE78310 <cr>
  
```

Displays the current mode of the RS-232C channel.

Resets the mode for IE-78310-R connection.

Changes the current drive after the IE78310 system disk has been inserted into drive B.

Starts the system software.

```

IE-78310 CONTROLLER (PC-9800 SERIES) Vx.x [DD Mmm YY]
Copyright (C) 1985 by NEC Corporation

IE-78310 Monitor Vx.x [DD Mmm YY]
Copyright (C) 1985 by NEC Corporation

Power on target system (Y/N) Y <cr>
Create new set up mode (Y or N) : N <cr>
Internal ROM size (4K,8K,16K) = 8K <cr>
Tracer initialize
Breaker initialize
Do you have Memory Board on IE-78310 ? (Y/N) = N <cr>
0>
  
```

For information about the setting of this portion, refer to Chapter 3 of "IE-78310A-R User's Manual, Software (EEU-637)."

Even when the IE-78310-R is connected, the following indication will appear if there is an RS-232-C interface mismatch between the IE-78310-R and PC-9801:

No connect!

Abort (Y/N):

In this case, type "Y" to abort connection to the IE78310 and return to MS-DOS. Then, by executing the SPEED command, match the mode setting with that of the RS-232-C interface of the IE-78310-R.

CHAPTER 4 NOTES ON USE

When using the IE78310 with MS-DOS running on the PC-9801, pay particular attention to the following.

4.1 Terminating the IE78310

4.1.1 RS-232-C mode alteration

The changed RS-232-C interrupt mode is used in the IE-78310. So reset the RS-232-C channel mode by executing the SPEED command when the RS-232-C channel is to be used with another application program after the IE78310 is terminated.

When, however, the IE78310 is to be reexecuted after being terminated once, the SPEED command need not be executed.

4.1.2 Key code alteration

The changed key codes are used for keys, DEL, <-, and ->, in the IE78310. When the default key codes are needed for these keys after terminating the IE78310, reset the key codes by using suitable supported commands.

The following key codes are set when the IE78310 is terminated:

DEL: 7FH
<- : 1DH
-> : 1CH

4.2 Using the DIR Command

The DIR command allows only the contents of the current directory, present when the IE78310 is started, to be referenced.

4.3 Using File Manipulation Commands

With a file manipulation command such as LOD, SAV, VRY, LST, or STR, only the files under the current directory, present when the IE78310 is started, can be referenced. Files can be created only under the current directory.

4.4 Creating an STR File

In most cases, an STR file created under MS-DOS should operate normally. However, if a problem occurs near the last line of an STR file, perform the following check.

An STR file is a text file created using an editor. A fault will occur if any text ends with other than an EOF code (1AH). Ensure that EOF codes are always present at the end of any text. Add an EOF code if necessary.

4.5 Control Keys

Some control keys used with the system software differ from those used with the system software for the MD-086/116. For details, see Chapter 5.

CHAPTER 5 DIFFERENCES FROM SYSTEM SOFTWARE RUNNING UNDER MD-086/116

The IE78310 for MS-DOS running on the PC-9801 differs from the IE78310 for the MD-086/116, as described below.

- (1) The console detach/attach function is not supported.

The console detach/attach function is a Concurrent CP/MTM function. MS-DOS, running on the PC-9801, is a single-task operating system. Therefore, this function is not supported.

- (2) Channel number setting is not required.

With the MD-086/116, four RS-232-C channels are provided as standard, and up to eight RS-232-C channels can be used. The PC-9801, however, allows only one RS-232-C channel to be used (as standard). Only this one standard channel is used, eliminating the need for channel number setting.

- (3) Some control keys are different.

Two key sequences, Ctrl-C and Ctrl-S, used with the MD-based system software are used by MS-DOS itself. So, these key sequences cannot be used with the system software for MS-DOS. Instead, the key sequences listed below are used.

| Key sequence | Function |
|--------------|-----------------------------|
| ↑ B (↑C) | Aborts the system software. |
| ↑ T (↑S) | Suspends command execution. |

The key sequences in parentheses are the corresponding MD-based key sequences.

PART III SYSTEM SOFTWARE FOR IBM PC/AT (PC DOS)

CHAPTER 1 OVERVIEW

The system software runs under PC DOS on the IBM PC Series, and enables the IBM PC Series to provide the same development environment as that supported by the conventional MD-086/116 Series.

1.1 System Configuration

To run the system software, the system must be configured as follows.

(1) Host computer

IBM PC/AT

(2) Operating system (OS)

PC DOS V3.10

(3) Console

Keyboard and CRT display unit provided with the IBM PC

(4) Connection with the IE-78310-R

Asynchronous communications adapter, available as an option for the IBM PC

1.2 System Software Distribution

(1) File names

The system software includes the following files:

| | |
|---------------|---|
| . IE78310.COM | (Main system software for the IBM PC Series) |
| . IE78310.OM0 | [(System software overlay files) |
| . IE78310.OV1 | |
| . IE78310.OV2 | |
| . IE78310.HLP | |

(2) Distribution media

5" 2HC (Product name: uS7B10IE78310)

CHAPTER 2 CONNECTION

This chapter describes how to connect the IBM PC to the IE-78310-R.

- (1) Turn off the power of the IBM PC and IE-78310-R.
- (2) Set CH1 on the IE-78310-R as shown in Figure 2-1.

Then, set the following:

Baud rate: 9600 bps

Mode: Modem

RTS: Standard

- (3) Set the asynchronous communications adapter as shown in Figure 2-2.

The system software supports the first serial port (No. 0) only.

- (4) Connect the RS-232-C interface on the asynchronous communications adapter of the IBM PC to CH1 of the IE-78310-R, using the RS-232-C cable for the IBM PC. (See Figure 2-3.)
- (5) Turn on the power of the IBM PC and IE-78310-R.

Fig. 2-1 Setting CH1




Fig. 2-2 Setting the Asynchronous Communications Adapter





Fig. 2-3 Cable Connection



CHAPTER 3 STARTING THE SYSTEM SOFTWARE

Start the system software as described below.

- (1) Start PC DOS on the IBM PC.
- (2) Set COM1 by executing the MODE command of PC DOS.

Set COM1 as follows:

Baud rate: 9600 bps

Character length: 8 bits

Parity: None

Stop bits: 2

- (3) Insert the IE78310 system disk into a floppy drive.
- (4) Change the current drive to that into which the IE78310 system disk is inserted.
- (5) Key in "IE78310 <cr>". Then, the system software starts.

An example of starting the system software is given below.
In this example, the MODE command is entered from drive A, and the IE78310 system disk is in drive B.

Start the PC DOS system.

```
Current date is Sat 2-20-1988
Enter new date (nn-dd-yy): [Enter date] <cr>
Current time is 10:24:16.22
Enter new time: [Enter time] <cr>

The IBM Personal Computer DOS
Version 3.30 (C)Copyright International Business Machines Corp 1981, 1987
(C)Copyright Microsoft Corp 1981, 1986

A>MODE COM1:mode <cr>
COM1: xxxx,x,x,x,-
A>B: <cr>
B>IE78310 <cr>

Note
Changes the current drive to drive B after
the IE78310 system disk has been inserted
into drive B.
Starts the system software.

IE-78310 CONTROLLER (IBM PC SERIES) Vx.x [DD Mmm YY]
Copyright (C) 1986 by NEC Corporation
IE-78310 Monitor Vx.x [DD Mmm YY]
Copyright (C) 1985 by NEC Corporation

Power on target system (Y/N) Y <cr>
Create new set up mode (Y or N): N <cr>
Internal ROM size (4K,8K,16K) = 8K <cr>
Tracer initialize
Breaker initialize
Do you have Memory Board on IE-78310? (Y/N) = N <cr>

0>_
```

Even when the IE-78310-R is connected, the following indication will appear if there is an RS-232-C interface mismatch between the IE-78310-R and IBM PC:


No connect!

Abort (Y/N):

In this case, type "Y" to abort the connection to the IE78310, and return to PC DOS. Then, by executing the MODE command, match the mode setting with that of the RS-232-C interface of the IE-78310-R.

Remark: Mode setting (for a baud rate of 9600 bps, no parity, a data length of 8 bits, and 2 stop bits)

Enter "MODE COM1:96,N,8,2 <cr>"



Stop bits

Data length

Parity

Baud rate

CHAPTER 4 NOTES ON USE

When using the IE78310 with PC DOS running on the IBM PC, pay particular attention to the following.

4.1 Creating an STR File

In most cases, an STR file created under PC DOS should operate normally. However, if a problem occurs near the last line of an STR file, perform the following check.

An STR file is a text file created using an editor. A fault will occur if any text ends with other than an EOF code (1AH). Ensure that EOF codes are always present at the end of any text. Add an EOF code if necessary.

4.2 Control Keys

Some control keys used with the system software differ from those used with the system software for the MD-086/116. For details, see Chapter 5.

CHAPTER 5 DIFFERENCES FROM SYSTEM SOFTWARE RUNNING UNDER MD-086/116

The IE78310 for PC DOS running on the IBM PC differs from the IE78310 for the MD-086/116, as described below.

- (1) The console detach/attach function is not supported.

The console detach/attach function is a Concurrent CP/MTM function. PC DOS, running on the IBM PC, is a single-task operating system. Therefore, this function is not supported.

- (2) Channel number setting is not required.

With the MD-086/116, four RS-232-C channels are provided as standard, and up to eight RS-232-C channels can be used. The IBM PC, however, allows only one RS-232-C channel to be used (as standard). Only this one standard channel is used, eliminating the need for channel number setting.


- (3) Some control keys are different.

Two key sequences, Ctrl-C and Ctrl-S, used with the MD-based system software are used by PC DOS itself. So, these key sequences cannot be used with the system software for PC DOS. Instead, the key sequences listed below are used.

| Key sequence | Function |
|--------------|-----------------------------|
| ↑ B (↑C) | Aborts the system software. |
| ↑ T (↑S) | Suspends command execution. |

The key sequences in parentheses are the corresponding MD-based key sequences.

- (4) Of the command line edit functions, the addition mode function cannot be used.



(

(

(