

License Manager V2.05.00

User's Manual

Target Device

78K0 Microcontroller

RL78 Family

78K0R Microcontroller

V850 Family

RX Family

RH850 Family

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/

How to Use This Manual

This manual describes the role of the license for developing applications and systems for 78K0 microcontrollers, RL78 family, 78K0R microcontrollers, V850 family, RX family, and RH850 family, and provides an outline of its features.

Readers This manual is intended for users who wish to using the IDE (CS+ or e² studio) and design software and hardware application systems.

Purpose This manual is intended to give users an understanding of the floating license to use for reference in developing the hardware or software of systems using these devices.

Organization This manual can be broadly divided into the following units.

- [1.GENERAL](#)
- [2.FUNCTIONS](#)
- [3.MESSAGE](#)

How to Read This Manual It is assumed that the readers of this manual have general knowledge of electricity, logic circuits, and microcontrollers.

Conventions	Data significance:	Higher digits on the left and lower digits on the right
	Active low representation:	XXX (overscore over pin or signal name)
	Note:	Footnote for item marked with Note in the text
	Caution:	Information requiring particular attention
	Remarks:	Supplementary information
	Numeric representation:	Decimal ... XXXX
		Hexadecimal ... 0xXXXX

TABLE OF CONTENTS

1.	GENERAL	5
1.1	Introduction	5
1.2	Operating Environment	8
2.	FUNCTIONS.	11
2.1	Installing License Manager	11
2.2	Uninstalling License Manager	11
2.3	Using a License Manager	12
2.3.1	Launching a License Manager	12
2.3.2	Confirming the status	12
2.3.3	Confirming information on the expiration of annual licenses	15
2.3.4	Add a node locked license	16
2.3.5	Delete a node locked license	18
2.3.6	Setting up the floating license.	19
2.3.7	Acquiring a floating license.	21
2.3.8	Acquiring a floating license for use in offline mode.	21
2.3.9	Ending use of a floating license in offline mode	23
2.3.10	Indicating mismatches between versions registered with the license manager and the floating license server25	
2.3.11	Change options.	26
2.4	Resetting When the Server Is Changed	27
3.	MESSAGE	28
3.1	Message Types	28
3.2	Internal Errors	29
3.3	Fatal Errors	29
3.4	Information.	33
3.5	Choices	35
3.6	Warning	36
	Revision Record	C - 1

1. GENERAL

This manual describes how to manage the license of development environment for developing applications and systems for the microcontrollers.


This manual describes how to manage floating licenses on the client side. For managing floating licenses on the server side, refer to the "Floating License Server V2.04.00 User's Manual".

1.1 Introduction

The license manager provides facilities for managing node locked licenses and floating licenses which are required to use tools related to the CS+ and e² studio integrated development environments for microcontrollers from Renesas.

A node locked license is a form of license where the license manager on a client manages the software license. If a license key is registered, functionality corresponding to the license is available; e.g. the manager eliminates restrictions on the amount of code for which linkage is possible on that client.


Figure 1.1 System Structure for Node Locked Licenses



- (1) Install development tool
- (2) Register license key
- (3) Launch development tool
- (4) License if confirmed
- (5) Confirmed or not

Floating licensing is a licensing approach in which a limited number of licenses for a software are managed by the server and any computer connected to the server can use the software within the number of the licenses.


Figure 1.2 System Structure of Floating License



- (1)Launch
- (2)Request for license
- (3)Request for floating license
- (4)Floating license is granted
- (5)License is confirmed
- (A)License key is added

A floating license cannot be used unless the computer is connected to the server. Offline mode is a mechanism that occupies the license for a certain period in order to use the license in a state disconnected from the network environment.

Figure 1.3 System Structure of Floating License (Offline Mode)



- (1) Request for floating license (offline mode)
- (2) Request for floating license (offline mode)
- (3) Floating license (offline mode) is granted
- (4) Take out
- (5) Launch
- (6) Request for license
- (7) License is confirmed
- (A) License key is added

For both node locked and floating licenses, some licenses have no limit on the period of validity, while for others, the period is one year. Once the period of a time-limited license has expired, the development tool covered by the license cannot be used. To distinguish between the periods of validity, we denote the licenses with and without time limits as annual and permanent, respectively.

- Node Locked License (permanent)
- Node Locked License (annual)
- Floating License (permanent)
- Floating License (annual)

1.2 Operating Environment

A floating license operates in the following environment.

- Hardware
 - Processor of 1 GHz or higher
 - Main memory: Min. 1 Gbyte (Min. 2 Gbytes for 64-bit Windows), at least 2 Gbytes are recommended
 - Display: Resolution of 1024 x 768 or higher, at least 65536 colors
- OS
 - Windows 8.1 (32 bits and 64 bits)
 - Windows 10 (32 bits and 64 bits)
- Runtime library
 - .NET Framework 4.5.2
- Development environment
 - Node Locked License (permanent)
 - CA850
 - CX
 - CA78K0
 - CA78K0R
 - CC-RL
 - CC-RX
 - CC-RH
 - Node Locked License (annual)
 - CC-RL V1.01.00 or later
 - CC-RX V2.03.00 or later
 - CC-RH V1.02.00 or later
 - Floating License (permanent and annual)
 - CC-RL V1.01.00 or later
 - CC-RX V2.03.00 or later
 - CC-RH V1.02.00 or later
- License
 - Compiler V1 for RL78,78K (CA78K0R,CA78K0)
Node Locked License (permanent)
 - Compiler V1 for V850 (CA850,CX)
Node Locked License (permanent)
 - Compiler V1 for RL78 (CC-RL)
Standard edition Node Locked License (permanent)
Standard edition Node Locked License (annual)
Standard edition Floating License (permanent)
Standard edition Floating License (annual)
Professional edition Node Locked License (permanent)
Professional edition Node Locked License (annual)
Professional edition Floating License (permanent)
Professional edition Floating License (annual)
Upgrade (edition) Professional edition Node Locked License (permanent)
 - Compiler V1 for RX (CC-RX)
Node Locked License (permanent)
 - Compiler V2 for RX (CC-RX) or later

- Standard edition Node Locked License (permanent)
- Standard edition Node Locked License (annual)
- Standard edition Floating License (permanent)
- Standard edition Floating License (annual)
- Professional edition Node Locked License (permanent)
- Professional edition Node Locked License (annual)
- Professional edition Floating License (permanent)
- Professional edition Floating License (annual)
- Upgrade (edition) Professional edition Node Locked License (permanent)
- Compiler V1 for RH850 (CC-RH)
 - Standard edition Node Locked License (permanent)
 - Standard edition Node Locked License (annual)
 - Standard edition Floating License (permanent)
 - Standard edition Floating License (annual)
 - Professional edition Node Locked License (permanent)
 - Professional edition Node Locked License (annual)
 - Professional edition Floating License (permanent)
 - Professional edition Floating License (annual)
 - Upgrade (edition) Professional edition Node Locked License (permanent)
- Compiler V2 for RH850 (CC-RH) or later
 - Standard edition Node Locked License (permanent)
 - Standard edition Node Locked License (annual)
 - Standard edition Floating License (permanent)
 - Standard edition Floating License (annual)
 - Professional edition Node Locked License (permanent)
 - Professional edition Node Locked License (annual)
 - Professional edition Floating License (permanent)
 - Professional edition Floating License (annual)
 - Upgrade (edition) Professional edition Node Locked License (permanent)
 - Upgrade (version) Standard edition Node Locked License (permanent)
 - Upgrade (version) Professional edition Node Locked License (permanent)
 - Upgrade (version) Standard edition Floating License (permanent)
 - Upgrade (version) Professional edition Floating License (permanent)

Registering the Upgrade (edition) Professional edition node locked license (permanent) and the Standard edition node locked license (permanent) for a given compiler with the license manager allows you to use the corresponding Professional edition node locked license (permanent).

Caution The Upgrade (edition) Professional edition node locked license (permanent) does not work in combination with the Standard edition floating license or Standard edition node locked license (annual).

Registering an Upgrade (version) Node Locked License (permanent) and a Node Locked License (permanent) as the source of the upgrade with the license manager allows you to use the functions enabled by a Node Locked License (permanent) at the destination of the upgrade.

Upgrade (version) Node Locked License (permanent)	Node Locked License (permanent) that is the source of the upgrade	Node Locked License (permanent) that is the destination of the upgrade
Compiler Upgrade (version) Standard V2 for RH850 (CC-RH)	Compiler Standard V1 for RH850 (CC-RH)	Compiler Standard V2 for RH850 (CC-RH)
	Compiler Professional V1 for RH850 (CC-RH)	
Compiler Upgrade (version) Professional V2 for RH850 (CC-RH)	Compiler Professional V1 for RH850 (CC-RH)	Compiler Professional V1 for RH850 (CC-RH)
	Compiler Standard V1 for RH850 (CC-RH) and Compiler Upgrade (edition) Professional V1 for RH850 (CC-RH)	

- Example** When “Compiler Upgrade (version) Standard V2 for RH850 (CC-RH)” and “Compiler Professional V1 for RH850 (CC-RH)” are registered with the license manager, the state is the same as that after the following licenses have been registered.
- Compiler Professional V1 for RH850 (CC-RH)
 - Compiler Standard V2 for RH850 (CC-RH)
- Caution** An Upgrade (version) Node Locked License (permanent) cannot be used in combination with a floating license or a Node Locked License (permanent).

2. FUNCTIONS

This chapter describes functions of a license manager.

2.1 Installing License Manager

Install the license manager which is included in the installer for the CS+ IDE, or with a package for a stand-alone language tool.

The preparing for installation window automatically appears. If this does not happen, double-click on "Setup.exe" in the root directory of the CD.

Caution The floating license client setup must be conducted with administrator privileges.

2.2 Uninstalling License Manager

You can uninstall the license manager using [Programs and Features] in the control panel. Select "Renesas MCU Tools License Manager" and click the [Uninstall] button.

Caution Uninstalling the floating license client must be conducted with administrator privileges.

2.3 Using a License Manager

This section describes how to use a license manager.

2.3.1 Launching a License Manager

The License Manager window is started as follows.


- From the [Start] menu of Windows, select [Programs] >> [Renesas Electronics Utilities] >> [Renesas License Manager].

Remark In Windows 8.1, select [Renesas License Manager] on the start screen.
In Windows 10, select Windows [Start] menu >> [All apps] >> [Renesas Electronics Utilities] >> [Renesas License Manager].

2.3.2 Confirming the status

When the License Manager window opens, it displays a list of valid registered licenses in the licenses area.

Figure 2.1 License Manager Window




The license name is displayed by a bold font, and the license status is indicated by an icon.

	In use as a Node Locked License (permanent).
	In use as a Node Locked License (annual).

	In use as a Node Locked License (annual) (the expiration date is approaching).
	This Node Locked License (annual) is no longer available because it is out of date.
	Using as the floating license.
	Using as the offline license.


If the displayed contents of the GUI are old, click the [Refresh] button to update the displayed information.

Figure 2.2 Refresh the Displayed Information



And click the license name. The license status is displayed in the bottom part of the window.


Figure 2.3 Detailed Information for the License Status



2.3.3 Confirming information on the expiration of annual licenses

The user is informed of the approaching expiration of an annual license by display of the  icon and  balloon help.

Figure 2.4 [Expiration of an Annual License] Information Icon



Clicking on the  icon or  balloon help shows information on the license that will soon expire.

The user is informed of the approaching expiry of annual licenses at the following times: one month, two weeks, and one day before expiration.

However, if the date of expiration is within one of the above periods before the previous period has been indicated, the earlier notification is skipped. For example, if there are two weeks until expiration but the notification of one month until expiration has not been given, the latter notification is skipped and two weeks until expiration is indicated. If an annual license becomes out of date before the notification of one day before expiration has been displayed, the notification is that the license is already out of date.

2.3.4 Add a node locked license

In the License Manager window, click the [Add license] button, and enter a license key in the [Add following License keys] text box, then click the [Add] button to add the license.

Figure 2.5 License Manger Window





Figure 2.6 Add Node Locked License Dialog Box



The SOFTWARE LICENSE AGREEMENT dialog box appears if you have not yet accepted the license agreement for addition of a node locked license.

Figure 2.7 SOFTWARE LICENSE AGREEMENT Dialog Box




Select [Accept] and click on the [OK] button. The node locked license you have added is now available.

2.3.5 Delete a node locked license

In the License Manager window, select the license you wish to delete from the licenses area, then click the [Remove License] button to delete the license.

Figure 2.8 License Manger Window



Caution While an Upgrade (version) Node Locked License (permanent) is registered, the Node Locked License (permanent) that is the source of the upgrade cannot be deleted. Start by deleting the Upgrade (version) Node Locked License (permanent).


2.3.6 Setting up the floating license

The following initial settings are required to use a floating license.

Caution Set up the client after the server settings was finished.

- (1) Open the License Manager Option dialog box
In the License Manager window, click the [Option] button

Figure 2.9 License Manger Window




The License Manager Option dialog box will open.

- (2) Connect the license server
Enter the IP address (example: 192.168.0.1) or host name (example: license.example.com) of the license server into [Server Address], the port number specified by the license server administrator into [Port]. If you don't know, please contact the license server administrator.


Click the [Enable] button.

Figure 2.10 License Manager Option Dialog Box (Disabled)



When connection to the license server is successful, the display changes to that shown on the below.

Figure 2.11 License Manager Option Dialog Box (Enabled)



Click the [OK] button to close the dialog box.

2.3.7 Acquiring a floating license

You don't need to take a particular action to acquire a floating license.

Starting the software subject to licensing automatically acquires a floating license. The term of validity is 30 minutes from the time that the license is acquired.

The license will be returned automatically when the term of validity expires. If the license will be required, the software subject to licensing automatically acquires a floating license again.


2.3.8 Acquiring a floating license for use in offline mode

A floating license cannot be used unless the computer is connected to the server. Offline mode is a mechanism that occupies the license for a certain period in order to use the license in a state disconnected from the network environment.

- (1) Open the Get into offline mode dialog box

When the client is connected to the server, click the [Get into offline mode] button in the License Manager window.


Figure 2.12 License Manager Window Before Acquiring an Floating License (Offline Mode)



The Get into offline mode dialog box will open.


- (2) Select the license name and enter the license period
Select the license name, enter the period of use in offline mode (max. 99 days) in [Licensing Period], and click on the [OK] button.

Figure 2.13 Get into Offline Mode Dialog Box



The floating license (offline mode) is acquired from the server and the License Manager window is updated. During the valid period of the offline license, the license can be ongoingly used even in a circumstance where the license server cannot be connected.

Figure 2.14 License Manager Window after Acquiring an Offline License




The license will be returned automatically when the license was out of date.

2.3.9 Ending use of a floating license in offline mode

The acquired floating license (offline mode) is automatically returned to the server when it expires. You can also manually end usage in the offline mode and return the floating license before it expires.


When the client is connected to the server, click the license name and the [Stop offline mode] button in the License Manager window.

Figure 2.15 License Manager Window Before Releasing an Floating License (Offline Mode)



An floating license (offline mode) is returned to the server, and the displayed information in License Manager window is updated.

Figure 2.16 License Manager Window After Releasing an Floating License (Offline Mode)



2.3.10 Indicating mismatches between versions registered with the license manager and the floating license server

The  balloon help that pops up from the  icon indicates mismatches between versions registered with the license manager and the floating license server.

Figure 2.17 [Notification regarding the version of the license manager] Information Icon





Figure 2.18 [Notification regarding the version of the floating license server] Information Icon




Clicking on the  icon or  balloon help will produce a message dialog box.

2.3.11 Change options

Below is the description of other options of the floating license client.
In the License Manager window, click the [Option] button.
The License Manager Option dialog box will open.

Figure 2.19 License Manager Option Dialog Box



In this dialog box, the following options can be changed.

- [Logging status of use] checkbox
If this checkbox is selected, the states of usage of the licenses are recorded in a log file. If this checkbox is not selected, a log file is not saved.
- [Folder for saving log file] text box
Specifies the path for the folder in which the log files are to be saved. If the [Browse] button is clicked, the folder can be specified in the [Browse for folder] dialog box.
Logs are recorded with the numerical part of the file name changed for every 3 Mbytes with a file name of "FloatingLicense.xxx.log" (xxx is a 3-digit numerical value).
- [Max log file size] spin box
Specifies the maximum size of log files. When recording a log immediately after the maximum size has been reached, the oldest log file is deleted to keep the file size within the size of this setting.
- [Save detailed status] checkbox
If this checkbox is selected, details of the internal operation of the programs are also recorded. If this checkbox is not selected, only the requests from clients and the responses are recorded.

2.4 Resetting When the Server Is Changed

When the server has been changed due to a failure or replacement, enter the new server's [Server Address] and [Port] in the License Manager Option dialog box. After the settings have been changed, all existing licenses are revoked.

3. MESSAGE

This chapter describes internal error messages, fatal error messages, abort error messages, information messages, choice messages and warning messages that Floating License outputs.

The message is output to the Message dialog box or log file, etc...

3.1 Message Types

The message types (1 alphabetic character) when Floating License is operated are as follows.

Table 3.1 Message Type

Message Type		Description
C	Internal error	Processing terminated (suspended) due to internal error.
E	Fatal error	Processing terminated (suspended) due to fatal error.
M	Information	Informational message. Check the message and continue the process.
Q	Choice	This type of message is displayed when a choice is necessary in order to carry on with the next operation. It performs the selected action.
W	Warning	Warning message. Check the message and continue the process.

3.2 Internal Errors

Table 3.2 Internal Errors

C0171000	[Message]	An internal error occurred. Failed to get a license. XXX
C0171001	[Message]	An internal error occurred. Failed to send license request. XXX
C0171002	[Message]	An internal error occurred. Failed to send license request.
C0171003	[Message]	An internal error occurred. Failed to respond to a license request. XXX
C0190000	[Message]	Specified device is invalid.
C0190001	[Message]	XXX is empty.
C0190002	[Message]	XXX is too large.
C0190003	[Message]	XXX is too small.

3.3 Fatal Errors

Table 3.3 Fatal Errors

E0172000	[Message]	Getting a license is timed out.
E0172001	[Message]	Command-line option is invalid.
E0172002	[Message]	Failed to load license file.
E0172003	[Message]	Failed to load option file. XXX
E0172004	[Message]	Failed to load option file. XXX
E0172005	[Message]	Failed to save option file. XXX
E0172006	[Message]	Failed to save option file. XXX
E0172007	[Message]	Failed to load license information. XXX
E0172008	[Message]	Server address or port settings is invalid. XXX
E0172009	[Message]	Failed to save license information. XXX
E0172010	[Message]	Server address or port settings is invalid. XXX
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.

E0172011	[Message]	Failed to receive response from license server. XXX
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172012	[Message]	Failed to save CSV file. XXX
E0172013	[Message]	No log file in log folder.
E0172020	[Message]	Response from license server is invalid.
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172021	[Message]	Response from license server is invalid.
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172022	[Message]	No available license in license server.
E0172023	[Message]	No available license in license server. But upper level license is available.
E0172024	[Message]	License server respond invalid server.
	[Action by User]	Disable the floating license in the option dialog box and enable it again.
E0172025	[Message]	License server respond invalid client.
	[Action by User]	Disable the floating license in the option dialog box and enable it again.
E0172026	[Message]	Clock gap between server and client is too large.
	[Action by User]	Check the client PC's clock. If the clock is correct, ask the floating license server administrator to check the server PC's clock.
E0172027	[Message]	License server respond unknown license.
	[Action by User]	The licence server version may be old. Ask the floating license server administrator to check the version of the floating license.
E0172028	[Message]	License is out of date.
E0172040	[Message]	Failed to connect license server. License server respond XXX.
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172041	[Message]	A connection with the server has timed out.
	[Action by User]	- Check [Server Address] and [Port] in the option dialog box. Ask the floating license server administrator to check that the service is running. - A request may be blocked by the server PC's firewall. Ask the floating license server administrator to check that the client request is allowed. - A request may be blocked by the client PC's personal firewall or other security software. Allow to conduct http and https communication.

E0172042	[Message]	A connection with the server could not be established. Cannot find server or DNS error.
	[Action by User]	Check [Server Address] in the option dialog box. If this does not resolve the problem, please specify [Server Address] by the IP address.
E0172043	[Message]	Failed to connect license server.
	[Action by User]	Check [Server Address] and [Port] in the option dialog box. If this does not resolve the problem, ask the floating license server administrator to check that the service is running.
E0172044	[Message]	A connection with the server was denied.
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172045	[Message]	The server returned an error (XXX).
	[Action by User]	Check [Server Address] and [Port] in the option dialog box.
E0172046	[Message]	A connection with the proxy server could not be established. Cannot find server or DNS error.
	[Action by User]	Check [Internet Option] in the control panel to bypass a proxy server. Ask your network administrator about proxy settings.
E0172047	[Message]	A connection with the proxy server could not be established.
	[Action by User]	Check [Internet Option] in the control panel to bypass a proxy server. Ask your network administrator about proxy settings.
E0174010	[Message]	Failed to load option file. XXX
E0174011	[Message]	Failed to save option file. XXX
E0174012	[Message]	Failed to load license information. XXX
E0174013	[Message]	Failed to save license information. XXX
E0174014	[Message]	Failed to start license service. XXX
E0174015	[Message]	Failed to receive request from client. XXX
E0174016	[Message]	Client request is invalid.
E0174017	[Message]	No available license.
E0174018	[Message]	No available license. But upper level license is available.
E0174019	[Message]	A request is send to invalid server.
E0174020	[Message]	A request is send from unknown client.
E0174021	[Message]	Clock gap between server and client is too large.
E0174022	[Message]	A request is required unknown license.
E0174023	[Message]	License is out of date.

E0174100	[Message]	This license key is invalid. XXX
E0174101	[Message]	This license key is already registered. XXX
E0174102	[Message]	Can not delete the license in use. XXX
E0180000	[Message]	This license key is invalid.
E0180001	[Message]	XXX This license key is already registered.
E0180010	[Message]	Failed to add the following license. To add an Upgrade (version) License, the license that is the source of the upgrade must be registered. XXX
E0180011	[Message]	Failed to delete the license. The license that is the source of the upgrade cannot be deleted before the Upgrade (version) License is deleted.
E0182000	[Message]	Could not write the license information to XXX.
E0190000	[Message]	Failed to start License Manager.
E0190001	[Message]	Failed to start License Manager. Can not find the folder to store the license information.
E0190002	[Message]	Managing the floating license server requires administrator privileges.

3.4 Information

Table 3.4 Information

M0190000	[Message]	Failed to read license information. The file is broken. Please re-enter license keys.
M0190010	[Message]	The version of the license manager you are using is older than that assumed by the floating license server. Update the license manager.
M0190011	[Message]	The version of the floating license server you are using is older than that assumed by the license manager. Update the floating license server.
M0191000	[Message]	Critical Error : XXX
M0191100	[Message]	Critical Error : XXX
M0191200	[Message]	Error : XXX
M0191300	[Message]	Error : XXX
M0191400	[Message]	Warning : XXX
M0191500	[Message]	Warning : XXX
M0191600	[Message]	Required license : XXX
M0191601	[Message]	Local license found.
M0191602	[Message]	Needs renewal.
M0191603	[Message]	Expired.
M0191604	[Message]	Invalid.
M0191605	[Message]	Released.
M0191606	[Message]	Upper level licesne : XXX
M0191607	[Message]	Get new licesne : XXX
M0191608	[Message]	Supported : XXX licenses
M0191700	[Message]	Request : XXX
M0191701	[Message]	Add client : XXX
M0191702	[Message]	Delete client : XXX
M0191703	[Message]	Client unknown.
M0191704	[Message]	Server id is invalid.
M0191705	[Message]	Target license is empty.
M0191706	[Message]	Upper level license is available
M0191707	[Message]	Assigned license (XXX/XXX) : XXX
M0191708	[Message]	Expired license : (XXX/XXX) : XXX
M0191709	[Message]	Released license : (XXX/XXX) : XXX
M0191800	[Message]	Command : XXX
M0191801	[Message]	Getting license : XXX
M0191802	[Message]	Connecting : XXX

M0191803	[Message]	Getting upper level license : XXX
M0191804	[Message]	Getting supported licenses : XXX
M0191805	[Message]	Getting license as offline mode : XXX
M0191806	[Message]	Releasing license : XXX
M0191900	[Message]	Starting service.
M0191901	[Message]	Starting HTTP listener.
M0191902	[Message]	Received HTTP request.
M0191903	[Message]	Received next request.
M0191904	[Message]	Getting license list.
M0191950	[Message]	Stop service.
M0191951	[Message]	Stop HTTP listener.
M0191952	[Message]	Bad HTTP request.
M0191953	[Message]	Unknown request.
M0191954	[Message]	Unkown client.
M0191955	[Message]	Invalid server ID.
M0191956	[Message]	Invalid : XXX
M0191957	[Message]	Released : XXX

3.5 Choices

Table 3.5 Choices

Q0174110	[Message]	This function should be used when a client cannot release a license because there was trouble in the client's PC. Normally, a license should be released from the client. Do you still want to continue?
----------	-----------	--

3.6 Warning

Table 3.6 Warning

W0190002	[Message]	Failed to read license information from XXX. The file is broken.
W0190003	[Message]	Failure in reading license information. The file is corrupted.

Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	Jun 01, 2022	-	First Edition issued

License Manager V2.05.00 User's Manual:

Publication Date: Rev.1.00 Jun 01, 2022
Published by: Renesas Electronics Corporation

License Manager V2.05.00