

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

M306NAT2-RPD-E

User's Manual

Emulation Pod for M16C/6N Group M306NA and
M306NB

- IC61-1004-051 is a product of Yamaichi Electronics Co., Ltd.
- NQPACK, YQPACK, YQSOCKET, YQ-Guide, HQPACK, TQPACK and TQSOCKET are products of Tokyo Eletech Corporation.

Keep safety first in your circuit designs!

- Renesas Technology Corporation and Renesas Solutions Corporation put the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection of the Renesas Technology product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation, Renesas Solutions Corporation or a third party.
- Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation and Renesas Solutions Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors. Please also pay attention to information published by Renesas Technology Corporation and Renesas Solutions Corporation by various means, including the Renesas home page (<http://www.renesas.com>).
- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation and Renesas Solutions Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation or Renesas Solutions Corporation for further details on these materials or the products contained therein.

Precautions to be taken when using this product

- This product is a development supporting unit for use in your program development and evaluation stages. In mass-producing your program you have finished developing, be sure to make a judgment on your own risk that it can be put to practical use by performing integration test, evaluation, or some experiment else.
- In no event shall Renesas Solutions Corporation be liable for any consequence arising from the use of this product.
- Renesas Solutions Corporation strives to renovate or provide a workaround for product malfunction at some charge or without charge. However, this does not necessarily mean that Renesas Solutions Corporation guarantees the renovation or the provision under any circumstances.
- This product has been developed by assuming its use for program development and evaluation in laboratories. Therefore, it does not fall under the application of Electrical Appliance and Material Safety Law and protection against electromagnetic interference when used in Japan.

For inquiries about the contents of this document or product, fill in the text file the installer of the emulator debugger generates in the following directory and email to your local distributor.

\\SUPPORT\Product-name\SUPPORT.TXT

Renesas Tools Homepage <http://www.renesas.com/en/tools>

Preface

The M306NAT2-RPD-E is an emulation pod for the M16C/6N Group M306NA and M306NB of 16-bit MCUs. It is used with a PC4701 emulator.

This user's manual mainly describes specifications of the M306NAT2-RPD-E emulation pod and how to setup it. For details on the following products, which are used with the M306NAT2-RPD-E, refer to each product's user's manual or online manual.

- Emulator: PC4701 User's Manual
- Emulator debugger: M3T-PD30 User's Manual

All the components of this product are shown in "Table 2.1 Package components" (page 22) of this user's manual. If there is any question or doubt about this product, contact your local distributor.

To use the product properly

Precautions for Safety



- In both this user's manual and on the product itself, several icons are used to insure proper handling of this product and also to prevent injuries to you or other persons, or damage to your properties.
- The icons' graphic images and meanings are given in "Chapter 1. Precautions for Safety" (page 7). Be sure to read this chapter before using the product.

When using outside Japan



- When using in Europe, the United States, or Canada, be sure to use both the emulator and the emulation pod which meet local standards. EMI standards are not met when this product is used with the PC4700H or PC4700L emulator.

Contents

Chapter 1. Precautions for Safety	7
1.1 Safety Symbols and Meanings	8
Chapter 2. Preparation	21
2.1 Package Components	22
2.2 Other Tool Products Required for Development	22
2.3 Name of Each Part	23
(1) System Configuration	23
(2) Inside of the Emulation Pod	24
2.4 When Using the Emulator for the First Time	25
Chapter 3. Setting Up	27
3.1 Removing the Upper Cover	28
3.2 Setting Switches and Pullup Resistors	29
3.3 Selecting Clock Supply	33
(1) Using the Oscillator Circuit on the Target System	34
(2) Changing the Internal Oscillator Circuit of the Emulation Pod	35
(3) Replacing the Oscillator Circuit Boards	36
3.4 A-D Conversion Bypass Capacitor	37
3.5 Connecting the PC4701	38
(1) Connecting the Cable to the PC4701	38
(2) Connecting the Cable to the Emulation Pod	39
3.6 Connecting the Target System	40
(1) Connecting to a 100-pin 0.65-mm-pitch LCC Socket	41
(2) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 1)	42
(3) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 2)	43
(4) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 3)	44
Chapter 4. Usage	45
4.1 Making an MCU File for M3T-PD30	46
4.2 Turning On the Power	46
(1) Checking the Connection of Emulator System	46
(2) Turning On the Power	46
(3) LED Display When PC4701 Starts Up Normally	47
4.3 Downloading Firmware	48
(1) When It is Necessary to Download Firmware	48
(2) Downloading Firmware in Maintenance Mode	48
4.4 Self-check	49
(1) Self-check Procedure	49
(2) If an Error is Detected in the Self-check	49

Chapter 5. Specifications	51
5.1 Specifications	52
5.2 Operation Timing in Memory Expansion Mode and Microprocessor Mode	53
(1) Separate Bus, No-wait	53
(2) Separate Bus, With Wait, Accessing External Memory Area	55
(3) Multiplex Bus, With Wait, Accessing External Memory Area	57
(4) Timing Requirements	59
5.3 Electrical Characteristics	61
5.4 Connection Diagram	62
5.5 External Dimensions	63
(1) External Dimensions of the Emulation Pod	63
(2) External Dimensions of the Converter Board M3T-FLX-100LCC	64
(3) Reference Dimensional Drawing for 100-pin 0.65-mm-pitch QFP Foot Pattern	64
Chapter 6. Troubleshooting	65
6.1 Flowchart to Remedy the Troubles	66
6.2 When the Emulator Debugger Does Not Start Up Properly	67
(1) When LED Display of the PC4701 is Abnormal	67
(2) Program Window Does Not Appear at Debugger Startup (target connected)	68
(3) Program Window Does Not Appear at Debugger Startup (target not connected) .	69
(4) Errors Occur at Debugger Startup (target connected)	69
6.3 Operation Differs from That of Actual MCUs	70
(1) Cannot Reset from the Target System	70
(2) Data Values of ROM Area at Power-on Are Different	70
(3) HOLD* Control	70
(4) A-D Conversion Values are Different from Expected Values	70
(5) Outputs of ALE, Address and Others are Different from Those of Actual MCUs .	70
Chapter 7. Maintenance and Guarantee	71
7.1 Maintenance	72
7.2 Guarantee	72
7.3 Repair Provisions	72
7.4 How to Request for Repair	73

Terminology

Some specific words used in this user's manual are defined as follows:

Emulator system

This means an emulator system built around the PC4701 emulator. The PC4701 emulator system is configured with an emulator main unit, emulation pod, host machine and emulator debugger.

Emulator main unit (Hereafter PC4701)

This means a generic name for emulators for M16C, 7700, 740 Families. For details on specific models of PC4701, visit the Renesas Tools Homepage at <http://www.renesas.com/en/tools>

Emulation pod

This means the M306NAT2-RPD-E (this product). This emulation pod is for M16C/6N Group M306NA and M306NB.

Host machine

This means a personal computer used to control the emulator and emulation pod.

Emulator debugger

This means a software tool M3T-PD30 to control the emulator from the host machine through an interface.

Firmware

Program that analyzes contents of communication with the emulator debugger and controls the emulator hardware. This program is installed in the EEPROM. This program is downloadable from the emulator debugger to upgrade the firmware or to support other MCUs.

Software break

A software break is a function to break the program before the system executes an instruction at the specified address. The instruction at the preset address will not be executed.

Hardware break

A hardware break is a function to break the program when the system detects a write/read of data to/from memory or a rise/fall edge of the signal entered from the external trace cable. The former break function is called data break; and the latter break function is called trigger break. While the instruction at the address where the software break is set is not executed, a hardware break is performed after the specified instruction is executed.

Evaluation MCU

This means the microcomputer mounted on the emulation pod which is operated in the specific mode for tools.

Target MCU

This means the microcomputer you are going to debug.

Target system

This means a user's application system using the microcomputer to be debugged.

*

In this user's manual, this symbol is used to show active LOW. (e.g. RESET*: Reset signal)

Chapter 1. Precautions for Safety

This chapter describes precautions for using this product safely and properly. For precautions for the emulator main unit and the emulator debugger, refer to each user's manual included with your product.



1.1 Safety Symbols and Meanings	8
WARNING Warning for Installation	9
Warnings for Use Environment	9
CAUTION Caution to Be Taken for Modifying This Product	9
Cautions to Be Taken for Handling This Product	9
IMPORTANT Note on Malfunctions in the PC4701 System	9
Notes on Downloading Firmware	10
Note on When the Emulator Debugger Ends	10
Note on Final Evaluation	10
Notes on Target System	10
Notes on MAP References and Settings	11
Note on Setting the Work Area	11
Note on RESET* Input	12
Note on HOLD* Input	12
Note on RDY* Input	12
Notes on NMI* Input	12
Notes on Interrupts	12
Note on Oscillation Stop Detection Function (On-chip Oscillator)	13
Note on Accessing Address 00000h	13
Note on Stop and Wait Modes	13
Note on Software Reset	13
Note on BRK Instruction and BRK Instruction Interrupt	13
Notes on Address Match Interrupt	13
Note on Commands that Access the Single-step Interrupt Vector Area	14
Notes on Software Breaks and Hardware Breaks	14
Note on Protect Register (PRC2)	14
Notes on Pullup Control Register	14
Note on Reading Internal Resources of an MCU	15
Notes on Watchdog Function	15
Notes on Stack Area	15
Note on DMA Transfer	15
Note on Clock Supply to the MCU	16
Note on Differences between Actual MCU and Emulator	17

Chapter 1. Precautions for Safety


In both the user's manual and on the product itself, several icons are used to insure proper handling of this product and also to prevent injuries to you or other persons, or damage to your properties.


This chapter describes the precautions which should be taken in order to use this product safely and properly. Be sure to read this chapter before using this product.


1.1 Safety Symbols and Meanings

	WARNING	If the requirements shown in the "WARNING" sentences are ignored, the equipment may cause serious personal injury or death.
	CAUTION	If the requirements shown in the "CAUTION" sentences are ignored, the equipment may malfunction.
	IMPORTANT	It means important information on using this product.

In addition to the three above, the following are also used as appropriate.

△ means WARNING or CAUTION.
Example:  **CAUTION AGAINST AN ELECTRIC SHOCK**

⊘ means PROHIBITION.
Example:  **DISASSEMBLY PROHIBITED**

● means A FORCIBLE ACTION.
Example:  **UNPLUG THE POWER CABLE FROM THE RECEPTACLE.**

The following pages describe the symbols "WARNING", "CAUTION", and "IMPORTANT".

WARNING

Warning for Installation:



- Do not set this product in water or areas of high humidity. Spilling water or some other liquid into the main unit can cause an unreparable damage.

Warnings for Use Environment:



- The emulation pod is air-cooled with the ventilation slot. Therefore, do not block the ventilation slot. When heated to high temperatures, the emulation pod may not work properly.
- This equipment is to be used in an environment with a maximum ambient temperature of 35°C. Care should be taken that this temperature is not exceeded.

CAUTION

Caution to Be Taken for Modifying This Product:



- Do not disassemble or modify this product. Disassembling or modifying this product can cause damage. Disassembling and modifying the product will void your warranty.

Cautions to Be Taken for Handling This Product:



- Use caution when handling the main unit. Be careful not to apply a mechanical shock.
- Do not touch the connector pins of the emulator main unit and the target MCU connector pins. Static electricity may damage the internal circuits.
- Do not pull the emulation pod main unit by the flexible cable (FLX120-RPD) for connecting to the emulator main unit or the flexible cable (FLX64, FLX100, FLX160 or M3T-FLX160C) for connecting the target system. The cable may cause a break.
- Flexible cable (FLX120-RPD) for connecting to the emulator main unit and the flexible cable (FLX64, FLX100, FLX160 or M3T-FLX160C) for connecting the target system are different from earlier models. The slits make them more flexible. However, excessive flexing or force may break conductors.
- Do not use inch-size screws for this equipment. The screws used in this equipment are all ISO (meter-size) type screws. When replacing screws, use same type screws as equipped before.

IMPORTANT

Note on Malfunctions in the PC4701 System:

- If the emulator malfunctions because of interference like external noise, do the following to remedy the trouble.
 - (1) Press the RESET switch on the emulator front panel.
 - (2) If normal operation is not restored after step (1), shut OFF power to the emulator once and then reactivate it.

IMPORTANT

Notes on Downloading Firmware:

- Before using this product for the first time, it is necessary to download the dedicated firmware (control software for the emulation pod built into the PC4701). Please note that, to do this, it is necessary to start up the PC4701 in maintenance mode. For firmware download procedures, see "4.3 Downloading Firmware" (page 48). Once the firmware has been downloaded, the product can be used by simply turning on the power.
- Do not shut off the power while downloading the firmware. If this happens, the product will not start up properly. If power is shut off unexpectedly, redownload the firmware.
- Except when a target status error occurs, if the self-check is not complete successfully, there may be trouble with the product. In such case, contact your sales representative. However, perform the self-check in the below setup.

- (1) Target system: Not connected
- (2) Emulation pod internal switches: At their factory settings

Note on When the Emulator Debugger Ends:

- To restart the emulator debugger after it ends, always shut power to the emulator module off once and then on again.

Note on Final Evaluation:

- Be sure to evaluate your system with an actual MCU. Before starting mask production, evaluate your system and make final confirmation with a CS (Commercial Sample) version MCU.

Notes on Target System:

- The Vcc pin of the emulator is connected to the target system to observe the voltage of the target system. Therefore design your system so that the emulator MCU is powered by the target system.
 - The voltage of the target system should be within the range of the MCU specification (4.2--5.5 V).
 - Do not change the voltage of the target system after turning on the power.
 - Before powering on your emulator system, check that the host machine, the emulator main unit, the converter board and target system are all connected correctly. Next, turn on the power to each equipment following the procedure below.
 - (1) Turn ON/OFF the target system and the PC4701 emulator as simultaneously as possible.
 - (2) When the PC4701 and emulator debugger start up, check the target status LEDs on the emulator main unit's front panel to see if this product is ready to operate.
 - Is the power supplied? Check target status LED (POWER) is ON.
 - Is the reset is released? Check target status LED (RESET) is OFF.
- For details, refer to "Chapter 4. Usage" (page 45).

IMPORTANT

Notes on MAP References and Settings:

- For details on referencing and setting MAP information, see the user's manual of the emulator debugger M3T-PD30.

MAP settings are as follows:

(1) MAP = INT

Emulation memory in this product becomes effective.

Set this to debug internal ROM and internal RAM of an MCU.

(2) MAP = EXT

Emulation memory in this product is not used.

Set this to use MCU internal resources (SFR) or resources on the target system.

- Be sure to set the SFR area to EXT.
- When setting 0FFFCh to 0FFFFh to EXT:
This product uses the 4 bytes area 0FFFCh--0FFFFh as the stack area. If this 4 bytes memory cannot be read or written to, reset cannot be properly effected. As a result, you need to alter the map settings if either of the two conditions given below is met.

(1) With the system which shifts from single-chip mode to memory expansion (or microprocessor) mode, using the 4 bytes area of 0FFFCh--0FFFFh set to EXT.

(2) With the system which starts up in microprocessor mode, using the 4 bytes area of 0FFFCh--0FFFFh set to EXT and there is not enough memory to read or write.

The procedures to alter the MAP settings when the conditions (1) or (2) above are met are shown below.

(1) Set the 4 bytes area of 0FFFCh--0FFFFh to INT.

(2) Execute the RESET command of the emulator debugger M3T-PD30.

(3) Set the stack pointer.

(Example)

RESET:

```
FCLR    I
```

```
LDC     #0480H, SP <-- Set the stack pointer.
```

(Program stops after executing this instruction.)

(4) Set the 4 bytes area 0FFFCh--0FFFFh to EXT.

Note on Setting the Work Area:

- To use this product, it is necessary to set the work area in the internal reserved area of the MCU. However, do not set it in the last 10 bytes of the internal reserved area. And be sure to set the internal reserved area to INT. (Set the work area by the Init dialog box of the emulator debugger M3T-PD30.)

For M306NA and M306NB, set this area at address 2C00h. The emulator uses 10 bytes area of 02C00h to 02C09h.

IMPORTANT

Note on RESET* Input:

- The RESET* input from the target system is accepted only while a user program is being executed (only while the RUN status LED on the PC4701's front panel is lit).

Notes on HOLD* Input:

- Be sure to input "Low" to the HOLD* pin of the target system during the user program executing (while the RUN status LED on the PC4701's front panel is lit). Inputting "Low" to the HOLD* pin when stopping the user program may cause a malfunction of the emulator.
- When inputting "Low" to the HOLD* pin to run into the HOLD state, P00 to P52 will be in the HOLD state delaying by 2.5 cycles than the actual MCU (see Table 5.5 and Figure 5.5).

Note on RDY* Input:

- Be sure to input "Low" to the RDY* pin of the target system during the user program executing (while the RUN status LED on the PC4701's front panel is lit). Inputting "Low" to the RDY* pin when stopping the user program may cause a malfunction of the emulator.

Notes on NMI* Input:

- NMI* input from the target system is accepted only while a user program is being executed (only while the RUN status LED on the PC4701's front panel is lit).
- The NMI* interrupt is generated in the following situations.
 - (1) Immediately after the NMI* pin changes from "High" to "Low" level during target program execution
 - (2) After the reset is released by the target system when the NMI* pin is "Low" level during target program execution
 - (3) Immediately after program execution starts with the NMI* pin "Low" level, following the reset input from the debug software or emulator main unit
 - (4) Immediately after program execution starts when the NMI* pin is "High" level immediately before the target program stops and changes to "Low" level when target program execution starts

Notes on Interrupts:

- Even when the target program is not being executed (while the target program is stopped or during runtime debugging), the evaluation MCU keeps running so as to control the emulation pod. Therefore, note that timers and other components do not stop running even though the target program is not being executed.
- If a maskable interrupt request is generated when the target program is not being executed (while the target program is stopped or during runtime debugging), the request is not accepted because the emulator disables all interrupts. If an interrupt request is generated when the target program is not being executed, but the target program enables that interrupt, it will be accepted immediately after program execution starts.

IMPORTANT

Note on Oscillation Stop Detection Function (On-chip Oscillator):

- Take note that you can not debug a program using the oscillation stop detection function (on-chip oscillator). To use this function, be sure to evaluate a system with an actual MCU.
- This product is equipped with an M16C/62A MCU as an emulation MCU. Because the M16C/62A MCU does not have an oscillation stop detection register, when the register is read out, undefined values are read out. To use the oscillation stop detection function (on-chip oscillator), be sure to evaluate your system with an actual MCU.

Note on Accessing Address 00000h:

- With the M16C/60 Group MCUs, when a maskable interrupt is generated, the interrupt data (interrupt No. and interrupt request level) stored in address 00000h is read out. Also, the interrupt request bit is cleared when address 00000h is read out. Consequently, when the address 00000h readout instruction is executed or when address 00000h is read out in the cause of a program runaway, a malfunction occurs in that the interrupt is not executed despite the interrupt request, because the request bit of the highest priority interrupt factor enabled is cleared.

For this malfunction, when the reading out to the address 00000h is generated excluding the interrupt, the yellow LED lights up to alarm. When this LED lights, there is a possibility of wrong access to address 00000h, therefore check the program. This LED is turned off by the RESET switch of the emulator main unit.

Note on Stop and Wait Modes:

- Do not perform step execution at addresses in the stop or wait mode. It may cause communication errors.

Note on Software Reset:

- Do not use a software reset. It may not operate correctly.

Note on BRK Instruction and BRK Instruction Interrupt:

- With this emulator system, BRK instructions and BRK instruction interrupts are exclusively used for software break functions. Therefore, you can not use them for your program.

Notes on Address Match Interrupt:

- Do not set software breaks at the same addresses as address-match interrupts as the program may run out of control. Therefore, to debug address-match interrupts, set software and hardware breaks at the top address of an address-match interrupt processing.
- Do not set a hardware break within 4 instructions before an address at which an address-match interrupt occurs. If you do set a hardware break in this range, the program cannot be controlled from the emulator.
- When an address at which an address-match interrupt occurs is executed in one-step mode, the program stops after executing the first instruction after returning from the address-match interrupt processing.

IMPORTANT

Note on Commands that Access the Single-step Interrupt Vector Area:

- Do not perform the below debugging operations with the single step interrupt vector area (addresses FFFECh--FFFEFh).
 - (1) Step execution of commands that access the single step interrupt vector area
 - (2) Program execution using commands that access the single step interrupt vector area when a software breakpoint is set in those commands

Notes on Software Breaks and Hardware Breaks:

- Software breaks generate BRK interrupts by substituting the proper instruction to the BRK instruction. Therefore, when referencing the result of a trace in bus mode, "00h" is displayed for the instruction fetch address where a software break is set, and when referencing in reverse assemble mode, "BRK" instruction is displayed.
- It is not possible to use a software break and a hardware break at the same time. If doing so, it may not operate normally.
- In the area where the MAP setting is EXT, software breaks cannot be used.

Note on Protect Register (PRC2):

- Make note of the fact that the protect is not canceled when protect register (PRC2), which enables writing in the port P7 and port P9 direction registers and the SI/O3 control register, is changed with the below procedure.
 - (1) Step execution of the "instruction for setting ("1") PRC2"
 - (2) Execution from the instruction setting "1" to PRC2 where a software breakpoint is set
 - (3) Setting the break point from the "instruction for setting ("1") PRC2" to when the "setting the register for the protect"
 - (4) Setting ("1") PRC2 from the dump window or script window

Notes on Pullup Control Register:

- Ports P00 to P57 are not pulled up by the pullup control register.

When pulling up ports P00 to P57, apply a resistance to the inside of the emulator. How to apply it, refer to "3.2 Setting Switches and Pullup Resistors" (page 29).

Note: Ports P60 to P107 are pulled up by the pullup control register.
Note: The pullup control register can read and write from P00 to P107 properly.
- When the pullup control register 1 (bit 1 of address 3FDh = PU11) of ports P44--P47 is set to "1" (pulled up), ports P15--P17 are pulled up regardless of the value of the pullup control register 0 (bit 3 of address 3FCh = PU03) of ports P14--P17.

IMPORTANT

Note on Reading Internal Resources of an MCU:

- When the registers that are listed in Table 1.1 are read with an emulator, those results will be the following (the data in the MCU are not effected).

(1) Results of real-time trace

The data values of the cycles read are not displayed correctly.

(2) Real-time RAM monitor

The data values read are not displayed correctly.

Table 1.1 Registers and symbols not displayed normally

Register	Symbol
DMA source pointers 0, 1	SAR0, SAR1
DMA destination pointers 0, 1	DAR0, DAR1
DMA transfer counters 0, 1	TCR0, TCR1
DMA control registers 0, 1	DM0CON, DM1CON

Notes on Watchdog Function:

- The MCU's watchdog timer can be used only while programs are being executed. To use it otherwise, disable the watchdog timer.
- If the reset circuit of the target system has a watchdog timer, disable it when using the emulator.

Notes on Stack Area:

- With this product, a maximum 8 bytes of the user stack is consumed.
- If the user stack does not have enough area, do not use areas which cannot be used as stack (SFR area, RAM area which stores data, or ROM area) as work area. Using areas like this is a cause of user program crashes and destabilized emulator control. Therefore, ensure the +8 bytes maximum capacity used by the user program as the user stack area.

Note on DMA Transfer:

- With this product, the program is stopped with a loop program to a specific address. Therefore, if a DMA request is generated by a timer or other source while the program is stopped, DMA transfer is executed. However, make note of the fact that DMA transfer while the program is stopped may not be performed correctly. Also note that the below registers have been changed to generate DMA transfer as explained here even when the program is stopped.

DMA0 transfer counter register: TCR0

DMA1 transfer counter register: TCR1

IMPORTANT

Note on Clock Supply to the MCU:

- Clock can be supplied to the evaluation MCU in one of the following two ways. This is determined by emulator debugger clock selection.

(1) When Internal is selected:

The clock generated by the oscillation circuit in the emulation pod is supplied to the evaluation MCU. The clock is continually supplied to the evaluation MCU regardless of "target system clock status" and "user program execution status".

(2) When External is selected:

Clock supply to the evaluation MCU depends on oscillation status (oscillate/off) of the target system.

IMPORTANT

Note on Differences between Actual MCU and Emulator:

- Operations of the emulator system differ from those of actual MCUs as listed below.
 - (1) Reset condition
Set the rise time (0.2 V_{CC} to 0.8 V_{CC}) 1 μs or less.
 - (2) Data values of ROM and RAM areas at power-on
 - (3) Internal memories (ROM and RAM) capacities etc.
With this emulator system, "INT" (emulation memory ON) is the default for mapping areas other than the SFR area (addresses 000h--3FFh). For this reason, the emulation memory can read and write in areas other than the SFR, internal RAM and internal ROM.
 - (4) Oscillator circuit
 - Make note of the fact that in the oscillator circuit where a resonator is connected between the X_{IN} and X_{OUT} pins, oscillation does not occur because a flexible cable, buffer IC and other devices are used between the evaluation MCU and the target system. It is same for sub-clock oscillator circuits (X_{CIN} and X_{COU}T).
 - For note on when using the oscillator circuit on the target system, refer to "3.3 (1) Using the Oscillator Circuit on the Target System" (page 34).
 - (5) Characteristics of ports P00 to P57
With this product, ports P00 to P57 are connected via emulation circuit. The device used for the port emulation circuit is as follows.

Device: M60081L-0142FP

- (6) Characteristics of port P10
With this product, parts of I/O ports (P10) is connected to the target system via analog switch circuit. Therefore the electrical characteristics are slightly different from those of actual MCUs.
- (7) HOLD* control
When inputting "Low" to the HOLD* pin to run into the HOLD state, P00 to P52 will be in the HOLD state delaying by 2.5 cycles than the actual MCU (see Figure 5.5 and Table 5.5).
- (8) DBC, Single-step and BRK instruction interrupt vector table addresses
As the emulator uses the DBC, Single-step and BRK instruction interrupt vector table addresses, when reading these addresses, the downloaded data cannot be read (see Table 1.2).

Table 1.2 Vector table addresses for the emulator

Factor of interruption	Vector table addresses	Data for reading
DBC* ¹	FFFF4h--FFFF7h	Indefinite
Single-step* ¹	FFFECh--FFFEFh	Indefinite
BRK instruction	FFFE4h--FFFE7h	Indefinite

*¹ Interruption for the debugger only

- (9) A-D conversion
As a analog switch, flexible cable, pitch converter board and other devices are used between the evaluation MCU and the target system, some characteristics are slightly different from those of the actual MCU.
- (10) Oscillation stop detection function
With this product, you can not debug the oscillation stop detection function.
- (11) Accessing to oscillation stop detection register
With this product, when the register is read out, undefined values are read out.
- (12) On-chip oscillator operation
With this product, you cannot use on-chip oscillator operation.

IMPORTANT

(13) A-D input group select function

When using the A-D input group select function, the following settings are required.

i) When selecting port P0 for A-D input

- Set the whole 8-bit of direction registers P100--P107 to input.
- Set the pullup control registers of P100--P107 to no-pullup.
- P100--P107 cannot be used as an input pin of I/O port and key input interrupt function.

ii) When selecting port P2 for A-D input

- Set the whole 8-bit of direction registers P100--P107 to input.
- Set the pullup control registers of P100--P107 to no-pullup.
- P100--P107 cannot be used as input pins of I/O port and key input interrupt function.

iii) When selecting port P10 for A-D input

- There is no restriction.

(14) Outputs of the actual MCU and this product

Table 1.3 Differences of outputs between actual MCU and this product (when executing program)

Access area	Signal	Actual MCU	This product	* for difference
SFR area (MAP = EXT)	Address BHE*	Outputs	Outputs	
	Data	Outputs (floating during read cycle)	Outputs (floating during read cycle)	
	RD* WR*	Outputs ("Low" at write cycle, "Low" at read cycle)	Outputs ("Low" at write cycle, "Low" at read cycle)	
	CS*	Does not output (fixed to "High")	Does not output (fixed to "High")	
	ALE	Does not output (fixed to "Low")	Outputs	*
Internal RAM Internal ROM	Address BHE*	Retains previous status	Outputs	*
	Data	Floating	Floating	
	RD* WR*	Does not output (fixed to "High")	Does not output (fixed to "High")	
	CS*	Does not output (fixed to "High")	Does not output (fixed to "High")	
	ALE	Does not output (fixed to "Low")	Outputs	*
External area	Address BHE*	Outputs	Outputs	
	Data	Outputs (inputs external data at read cycle)	Outputs (inputs external data at read cycle)	
	RD* WR*	Outputs ("Low" at write cycle, "Low" at read cycle)	Outputs ("Low" at write cycle, "Low" at read cycle)	
	CS*	Outputs	Outputs	
	ALE	Outputs	Outputs	

IMPORTANT

Table 1.4 Differences of outputs between actual MCU and this product (in stop mode)

Access area	Signal	Actual MCU	This product	* for difference
-	Address BHE*	Retains previous status	Retains previous status	
	Data	Retains previous status	Floating	*
	RD* WR*	Does not output (fixed to "High")	Does not output (fixed to "High")	
	CS*	Retains previous status	Retains previous status	
	ALE	Does not output (fixed to "High")	Does not output (fixed to "High")	

Table 1.5 Differences of outputs between actual MCU and this product (in wait mode)

Access area	Signal	Actual MCU	This product	* for difference
-	Address BHE*	Retains previous status	Retains previous status	
	Data	Retains previous status	Floating	*
	RD* WR*	Does not output (fixed to "High")	Does not output (fixed to "High")	
	CS*	Retains previous status	Retains previous status	
	ALE	Does not output (fixed to "High")	Does not output (fixed to "High")	

Table 1.6 Outputs of this product when the user program is stopping

Signal	This product
Address BHE*	Outputs
Data	Floating
RD* WR*	Only RD* outputs (WR* is fixed to "High")
CS*	Outputs
ALE	Outputs

MEMO

Chapter 2. Preparation

This chapter describes the package components, the system configuration and the preparation for using this product for the first time.

2.1 Package Components	22
2.2 Other Tool Products Required for Development	22
2.3 Name of Each Part	23
(1) System Configuration	23
(2) Inside of the Emulation Pod	24
2.4 When Using the Emulator for the First Time	25

Chapter 2. Preparation

2.1 Package Components

The M306NAT2-RPD-E package consists of the following items. When unpacking, check to see if your M306NAT2-RPD-E contains all of these items.

Table 2.1 Package components

Item	Quantity
M306NAT2-RPD-E emulation pod main unit	1
FLX120-RPD flexible cable for connecting PC4701	1
M3T-FLX-100LCC converter board for connecting target system	1
OSC-3 16 MHz oscillator circuit board for main clock (premounted)	1
OSC-2 oscillator circuit board	1
IC61-1004-051 100-pin LCC socket	1
Resistor arrays for pulling up ports P00--P57 (51 kΩ)	12
Hardware tool user registration FAX sheet (English)	1
Hardware tool user registration FAX sheet (Japanese)	1
M306NAT2-RPD-E user's manual (this manual)	1
M306NAT2-RPD-E user's manual (Japanese)	1

Please keep the M306NAT2-RPD-E's packing box and cushion material in your place for reuse at a later time when sending your product for repair or other purposes. Always use these packing box and cushion material when transporting this product.

If any of these items are missing or found faulty, please contact your local distributor. Also, if there is any question or doubt about the packaged product, contact your local distributor.

For details on the IC61-1004-051, contact Yamaichi Electronics Co., Ltd.

2.2 Other Tool Products Required for Development

To bring forward programs development on the M16C/6N Group MCUs, the products listed below are necessary in addition to those contained package above. Get them separately.

Table 2.2 Other tool products

Product	Product name	Notes
Emulator main unit	PC4701	Required
Emulator debugger	M3T-PD30	Required
Converter boards	M3T-DUMMY100S	Required according to the foot pattern of the target system (see 3.6 "Connecting the Target System" on page 40)
	M3T-DIRECT100S	
	M3T-FLX-100NRB	
100-pin 0.65-mm-pitch QFP (100P6S-A)		

* To purchase these products, contact your local distributor.

2.3 Name of Each Part

(1) System Configuration




Figure 2.1 System configuration

(1) to (4) in Figure 2.1 are included in this product package.

(1) Emulation pod M306NAT2-RPD-E

This emulation pod contains an evaluation MCU, emulation memory and circuits to feature the debugging functions.

(2) Flexible cable FLX120-RPD

This is a 120-pin flexible cable for connecting the PC4701 emulator and the emulation pod.

(3) Flexible cable FLX100

This is a 100-pin flexible cable for connecting the emulation pod and the target system.

(4) Converter board

This is a converter board for connecting to the target system. For details, refer to "3.6 Connecting the Target System" (page 40).

(2) Inside of the Emulation Pod




Figure 2.2 Internal view of the emulation pod

(1) MCU-dependent board

Board grouping parts (pins and added functions) which vary according to MCU model.

(2) Base board

Board for the M16C Series MCUs which controls the interface with the PC4701 and the evaluation MCU.

(3) Memory board

Board for the M16C Series MCUs on which the emulation memory (1 MB) and the map memory (4 bit × 1 M) are mounted.

(4) Oscillator circuit board

Oscillator circuit board on which the oscillation module device (16 MHz) is mounted. It is possible to change the operating frequency by replacing it with a separately prepared oscillator circuit board.

2.4 When Using the Emulator for the First Time

If you have purchased this emulation pod newly, it is necessary to download the firmware. The download procedure is given in Figure 2.3.

Before attempting to download the firmware, check the emulator debugger is installed and the emulator is connected to the host machine. For more information, see each user's manual of the emulator debugger and the PC4701.




Figure 2.3 Firmware download procedure when using the emulator for the first time

To make sure the emulation pod works properly, run the self-check. For self-check procedure, see "4.4 Self-check" (page 49).

MEMO

Chapter 3. Setting Up

This chapter describes switch settings required for using this product and how to connect this product to the PC4701 and the target system.

3.1 Removing the Upper Cover	28
3.2 Setting Switches and Pullup Resistors	29
3.3 Selecting Clock Supply	33
(1) Using the Oscillator Circuit on the Target System	34
(2) Changing the Internal Oscillator Circuit of the Emulation Pod.....	35
(3) Replacing the Oscillator Circuit Boards	36
3.4 A-D Conversion Bypass Capacitor.....	37
3.5 Connecting the PC4701	38
(1) Connecting the Cable to the PC4701	38
(2) Connecting the Cable to the Emulation Pod	39
3.6 Connecting the Target System.....	40
(1) Connecting to a 100-pin 0.65-mm-pitch LCC Socket	41
(2) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 1)	42
(3) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 2)	43
(4) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 3)	44

Chapter 3. Setting Up

To use this emulation pod with your target system, it is necessary to set as follows. Set the following after removing the upper cover.

- Change the oscillation frequency in the emulation pod.
- Set the switches according to the target system.
- Install pullup resistors to ports P00 to P57.
- Install the A-D conversion bypass capacitor.

3.1 Removing the Upper Cover

The procedure of removing the upper cover is shown below.

- (1) Remove the four screws of both sides of this product and lift off the upper cover. (see Figure 3.1)
- (2) Set the jumper switches and others as described below.
- (3) Replace the upper cover and secure the four screws.




Figure 3.1 Removing the upper cover

CAUTION

When Removing the Upper Cover:



- Always shut OFF power when removing the upper cover or setting the switches.
- Do not touch the connector pins of the emulator main unit and the target MCU connector pins. Static electricity may damage the internal circuits.

3.2 Setting Switches and Pullup Resistors

Figure 3.2 shows the positions of switches and a position for installing pullup resistors. Tables 3.1, 3.2 list how to set each switch and Figure 3.3 shows how to install pullup resistors.











Figure 3.2 Positions of switches and their factory-settings

Table 3.1 Switch settings of the M306NAT2-RPD-E (1/2)

Signal	Switch	Setting	Description
CNV _{SS}	SW1	<p>H OPEN L SW1 CNVSS (Factory-setting)</p>	Pulls down pin CNV _{SS} of MCU with a resistance of 33 kΩ. Be sure to set this when the target system is not connected in single-chip mode or memory expansion mode.
		<p>H OPEN L SW1 CNVSS</p>	Connects pin CNV _{SS} to the target system. Be sure to set this when the target system is connected.
		<p>H OPEN L SW1 CNVSS</p>	Pulls up pin CNV _{SS} of MCU with a resistance of 33 kΩ. Be sure to set this when the target system is not connected in microprocessor mode.
BYTE	SW2	<p>8 OPEN 16 SW2 BYTE (Factory-setting)</p>	Pulls down pin BYTE of MCU with a resistance of 33 kΩ. Be sure to set this when the target system is not connected in 16-bit bus mode.
		<p>8 OPEN 16 SW2 BYTE</p>	Connects pin BYTE to the target system. Be sure to set this when the target system is connected.
		<p>8 OPEN 16 SW2 BYTE</p>	Pulls up pin BYTE of MCU with a resistance of 33 kΩ. Be sure to set this when the target system is not connected in 8-bit bus mode.
X _{OUT}	SW3	<p>XOUT OPEN SW3 XOUT (Factory-setting)</p>	Does not connect pin X _{OUT} of MCU to the target system.
		<p>XOUT OPEN SW3 XOUT</p>	Connects pin X _{OUT} of MCU to the target system.

Table 3.2 Switch settings of the M306NAT2-RPD-E (2/2)

Signal	Switch	Setting	Description
P86/X _{COU} T	SW4	 <p>X_{COU}T OPEN P86 SW4 P86/X_{COU}T (Factory-setting)</p>	Connects pin P86/X _{COU} T of MCU to the target system. (Uses pin P86/X _{COU} T as port P86)
		 <p>X_{COU}T OPEN P86 SW4 P86/X_{COU}T</p>	Does not connect pin P86/X _{COU} T of MCU. (Uses P86/X _{COU} T pin as X _{COU} T and opens X _{COU} T.)
		 <p>X_{COU}T OPEN P86 SW4 P86/X_{COU}T</p>	Connects pin P86/X _{COU} T of MCU to the target system. (Uses pin P86/X _{COU} T as X _{COU} T and connect X _{COU} T to the target system.)
P87/X _{CIN}	SW5	 <p>X_{CIN} P87 SW5 P87/X_{CIN} (Factory-setting)</p>	Connects the P87/X _{CIN} pin of MCU to the target system. (Uses P87/X _{CIN} pin as port P87)
		 <p>X_{CIN} P87 SW5 P87/X_{CIN}</p>	Uses pin P87/X _{CIN} as X _{CIN} .
	JP2	 <p>L ○ ○ ○ H JP2 (Factory-setting)</p>	Only this setting is available.
		 <p>L ○ ○ H JP2</p>	Do not set in this way.

IMPORTANT

Note on Switch Settings:

- Switches CNV_{SS} (SW1) and BYTE (SW2) are used for debugging operation without connecting the target system. When the target system is connected, set both of them "OPEN" (middle).

It is not possible to control the pullup by the pullup control registers of ports P00 to P57 (possible to read and write the pullup control registers).

However, as this product has sockets for installing the pullup resistors, it is possible to pull up by mounting the resistor arrays included with this product. For the positions for installing them, see Figure 3.3.




Figure 3.3 Positions for installing the pullup resistors

3.3 Selecting Clock Supply

There are two ways to supply a clock to the MCU, using the oscillator circuit of the emulation pod or using the oscillator circuit on the target system. Table 3.3 lists the factory-settings of each clock supply.

Table 3.3 Clock supply to the MCU

Clock	Description	Display of emulator debugger	Default setting
X _{IN} -X _{OUT}	Internal oscillator circuit of emulation pod (OSC-3: 16 MHz)	Internal	Yes
	Target System	External	-
X _{CIN} -X _{COU}	Internal oscillator circuit of emulation pod (32.768 kHz)	Internal	-
	Target System	External	Yes

IMPORTANT

Notes on Changing the Clock Supply:

- The clock supply can be set by the Init dialog box when starting up the emulator debugger or inputting CLK command on the script window.
- For X_{CIN}-X_{COU}, it is necessary to set switches in the emulation pod. For details, refer to "3.2 Setting Switches and Pullup Resistors" (page 29).

(1) Using the Oscillator Circuit on the Target System

When turning on the power supply, the internal clock of the emulation pod is selected to supply the clock to the MCU. To use the external clock on the target system, change the clock by the Init dialog box when starting up the emulator debugger or the CLK command on the script window. (For details, refer to the user's manual of the emulator debugger.)




Figure 3.4 External oscillator circuit




Figure 3.5 Circuit in which oscillation does not occur (same for X_{CIN} - X_{COUT})

IMPORTANT

Notes on External Clock:

- To operate the emulation pod with an external clock, construct the oscillator circuit as shown in Figure 3.4 in the target system and input the oscillator output at 50% duty (within the operating range of the evaluation MCU) into the X_{IN} pin. And the X_{OUT} pin should be open.
- Make note of the fact that in the oscillator circuit shown in Figure 3.5 where a resonator is connected between the X_{IN} and X_{OUT} pins, oscillation does not occur because a flexible cable, pitch converter board and other devices are used between the evaluation MCU and the target system. It is same for sub-clock oscillator circuits (X_{CIN} and X_{COUT}).

(2) Changing the Internal Oscillator Circuit of the Emulation Pod

An oscillator circuit board for 16 MHz is mounted on this product. To use the emulation pod at a frequency other than 16 MHz, build the desired oscillator circuit on the included OSC-2 oscillator circuit board (bare board) and replace the board installed in the emulation pod when shipped from the factory.

Figure 3.6 shows a view of the OSC-2 oscillator circuit board (bare board) and where connector pins are located. Figure 3.7 shows the circuitry of the OSC-2 oscillator circuit board (bare board). Use the number of oscillator circuits recommended by the oscillator manufacturer.




Figure 3.6 External view of the oscillator circuit board (OSC-2) and connector pin assignment




Figure 3.7 Circuit of the oscillator circuit board (OSC-2)

(3) Replacing the Oscillator Circuit Boards

Figure 3.8 shows how to replace the oscillator circuit boards. For the position of the oscillator circuit board, see Figure 2.2.




Figure 3.8 Replacing the oscillator circuit boards

3.4 A-D Conversion Bypass Capacitor

The emulation pod has foot patterns on the board for mounting a bypass capacitor. Mount a suitable bypass capacitor as occasion demands.

Figure 3.9 shows where the bypass capacitors are mounted, whereas Figure 3.10 shows an enlargement of the foot patterns.




Figure 3.9 Position for mounting A-D conversion bypass capacitor (underside of the M30620T2-PRT)




Figure 3.10 Foot patterns of an A-D conversion bypass capacitor

IMPORTANT

Note on the A-D Converter:

- Because a flexible board and other devices are used between the evaluation MCU and the target system, the A-D converter operates differently from the actual MCU. Make the final evaluation of the A-D converter from the actual MCU.

3.5 Connecting the PC4701

To connect the emulation pod to the PC4701, use the FLX120-RPD 120-pin flexible cable included in this product package. Connect the PC4701 side connector of the FLX120-RPD to the cable connector of the PC4701, then secure with screws the FLX120-RPD.

(1) Connecting the Cable to the PC4701

Figure 3.11 shows how to connect the PC4701 and FLX120-RPD.




Figure 3.11 Connecting the PC4701 and FLX120-RPD

CAUTION

Notes on Connecting the Cable:



- To connect the FLX120-RPD, be sure to hold the both sides of the PC4701 side connector horizontally with the "UPSIDE" facing up.
- Always shut OFF power before connecting the cable. The power ON state could destroy internal circuits.

Note on Securing the Screws:



- After connecting the cable to the emulator main unit PC4701, be sure to secure the screws mounted in both sides of the connector.

(2) Connecting the Cable to the Emulation Pod

Figure 3.12 shows how to connect the FLX120-RPD and the emulation pod.




Figure 3.12 Connecting the FLX120-RPD and emulation pod

CAUTION

Note on Connecting the Cable:



- Always shut OFF power before connecting the cable. Otherwise, internal circuits may be damaged.

Note on Securing the Screws:



- After connecting the cable to the emulation pod, be sure to secure the screws.

3.6 Connecting the Target System

Figure 3.13 shows how to connect this product to the target system.




Figure 3.13 Connecting the emulation pod and target systems

CAUTION

Notes on Connecting the Target System:



- Take care not to attach the converter board in a wrong direction. It may cause a fatal damage to the emulation pod.

(1) Connecting to a 100-pin 0.65-mm-pitch LCC Socket

When connecting the emulation pod probe to a 100-pin LCC socket (Yamaichi Electronics Co., Ltd. IC61-1004-051 etc.) on the target system, following the procedure below.

- (1) Attach the FLX100 to the M3T-FLX-100LCC.
- (2) Attach the M3T-FLX-100LCC to the 100-pin LCC socket.




Figure 3.14 Connecting a 100-pin 0.65-mm-pitch LCC socket

CAUTION

Notes on Connecting Target System:



- Take care not to attach the converter board in a wrong direction. It may cause a fatal damage to the emulation pod.
- The small connectors of the M3T-FLX-100LCC are guaranteed for only 20 insertion/removal iterations.
- The IC61-1004-051 included this product is guaranteed for only 20 insertion/removal iterations.
- For purchasing the IC61-1004-051 and for any inquiry for it, contact Yamaichi Electronics Co., Ltd.

(2) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 1)

Figure 3.15 shows how to connect the emulation pod probe to a 100-pin 0.65-mm-pitch QFP (100P6S-A) foot pattern on the target system with the M3T-DUMMY100S (not included), and here following is its procedure. For details on the M3T-DUMMY100S, refer to its user's manual.

- (1) Attach the M3T-DUMMY100S to the target system.
- (2) Attach the M3T-FLX-100LCC to the M3T-DUMMY100S.




Figure 3.15 Connecting a 100-pin 0.65-mm-pitch foot pattern (part 1)

CAUTION

Notes on Connecting the Target System:



- Take care not to attach the converter board in a wrong direction. It may cause a fatal damage to the emulation pod.
- The small connectors of the M3T-DUMMY100S are guaranteed for only 20 insertion/removal iterations.

(3) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 2)

Figure 3.16 shows how to connect the emulation pod probe to a 100-pin 0.65-mm-pitch QFP (100P6S-A) foot pattern on the target system with the M3T-DIRECT100S (not included), and here following is its procedure. For details on the M3T-DIRECT100S, refer to its user's manual.

- (1) Attach the M3T-DIRECT100S to the target system.
- (2) Attach the M3T-FLX-100LCC to the M3T-DIRECT100S.




Figure 3.16 Connecting a 100-pin 0.65-mm-pitch foot pattern (part 2)

CAUTION

Notes on Connecting the Target System:



- Take care not to attach the converter board in a wrong direction. It may cause a fatal damage to the emulation pod.
- The small connectors of the M3T-DIRECT100S are guaranteed for only 20 insertion/removal iterations.

(4) Connecting to a 100-pin 0.65-mm-pitch Foot Pattern (Part 3)

Figure 3.17 shows how to connect the emulation pod probe to a 100-pin 0.65-mm-pitch QFP (100P6S-A) foot pattern on the target system with the M3T-FLX-100NRB (not included), and here following is its procedure. For details on the M3T-FLX-100NRB, refer to its user's manual.

- (1) Attach the M3T-FLX-100NRB to the target system.
- (2) Attach the M3T-FLX-100LCC to the M3T-FLX-100NRB.




Figure 3.17 Connecting a 100-pin 0.65-mm-pitch foot pattern (part 3)

CAUTION

Notes on Connecting the Target System:



- Take care not to attach the converter board in a wrong direction. It may cause a fatal damage to the emulation pod.
- The small connectors of the M3T-FLX-100NRB are guaranteed for only 20 insertion/removal iterations.

Chapter 4. Usage

This chapter describes from turning on the power of this product to starting up the emulator debugger.

4.1 Making an MCU File for M3T-PD30	46
4.2 Turning On the Power	46
(1) Checking the Connection of Emulator System	46
(2) Turning On the Power	46
(3) LED Display When PC4701 Starts Up Normally	47
4.3 Downloading Firmware	48
(1) When It is Necessary to Download Firmware	48
(2) Downloading Firmware in Maintenance Mode	48
4.4 Self-check	49
(1) Self-check Procedure	49
(2) If an Error is Detected in the Self-check	49

Chapter 4. Usage

4.1 Making an MCU File for M3T-PD30

It is necessary to change the contents of the MCU file according to the MCU to be developed. Make the MCU file "M306NA.MCU" for M306NA, "M306NB.MCU" for M306NB and store it in the "mcufile" folder in the directory same as emulator debugger M3T-PD30 is stored.

The contents of the MCU file (SFR area, internal RAM area, internal ROM area, name of the firmware file) are shown below. Change the settings according to the MCU to be debugged. Use your text editor for changing the contents of the MCU file.

Examples of MCU files are shown below.

(1) M306NAMCT-XXXFP (RAM: 5 KB, ROM: 128 KB, file name: M306NA.MCU)

0	:	SFR area	Start address
3FF	:		End address
400	:	Internal RAM	Start address
17FF	:		End address
E0000	:	Internal ROM	Start address
FFFFFF	:		End address
M30620B	:	Name of firmware	(Do not change.)
0	:	Expansion No.	M3T-PD30 V.4.00 or later required (Do not change.)

(2) M306NAFGT (RAM: 10 KB, ROM: 256 KB, file name: M306NA.MCU)

0	:	SFR area	Start address
3FF	:		End address
400	:	Internal RAM	Start address
2BFF	:		End address
C0000	:	Internal ROM	Start address
FFFFFF	:		End address
M30620B	:	Name of firmware	(Do not change.)
0	:	Expansion No.	M3T-PD30 V.4.00 or later required (Do not change.)

4.2 Turning On the Power

(1) Checking the Connection of Emulator System

Before turning the power ON, check the connection of the PC4701, emulation pod, converter board and target system.

(2) Turning On the Power

Power ON/OFF the target system and the PC4701 as simultaneously as possible.

CAUTION

Notes on Power Supply:



- The emulator's V_{cc} pin is connected to the target system in order to monitor target system voltage. For this reason, the emulator cannot supply power to the target system. Therefore, provide the target system with a separate power supply from that of the emulator.
- Keep target system power supply voltage within the MCU's specified range (4.2 to 5.5 V).
- Do not change target system power supply voltage after power has been activated.

(3) LED Display When PC4701 Starts Up Normally

After the emulator starts up, check the status of the LEDs on the front panel to see whether emulation pod operation is enabled or not. Figure 4.1 shows front panel LED lighting status when the emulator is turned ON.




Figure 4.1 LED display when the power turned on

IMPORTANT

Note on Microprocessor Mode:

- To use or microprocessor mode, be sure to set pins RDY* and HOLD* so that they are not active at startup. Otherwise the emulator system will not function correctly.

Note on CLOCK LED:

- If CLOCK LED does not turn on, check the following:
 - (1) Immediately after starting PC4701 (before starting the emulator debugger)
--> Check if the oscillation circuit within the emulation pod oscillates normally.
 - (2) After starting up the emulator debugger (after setting the Init dialog box)
--> Check the oscillation circuit set in the Init dialog box oscillates normally.

4.3 Downloading Firmware

(1) When It is Necessary to Download Firmware

It is necessary to download firmware when:

- (1) you use this product for the first time
- (2) firmware has been upgraded
- (3) emulator debugger has been upgraded
- (4) you use this product with a PC4701 which was used with another emulation pod before

(2) Downloading Firmware in Maintenance Mode

Download the firmware in maintenance mode as explained here following. **The target system must not be connected when downloading the firmware.**

- (1) Within 2 seconds of activating power to the emulator, press the RESET switch on the emulator front panel. This will switch the emulator to maintenance mode.
- (2) Start up the emulator debugger. When the Init dialog box setup is complete, the dialog which urges to download the firmware will appear. Download the firmware following messages. Required time for downloading the firmware depends on the connection of the interface.
 - For the USB interface About 20 seconds
 - For the LPT interface About 20 seconds
 - For the parallel interface About 30 seconds
 - For the serial interface About 5 minutes




Figure 4.2 Downloading firmware in maintenance mode

IMPORTANT

Note on Downloading Firmware:

- Do not shut OFF power while the firmware is being downloaded. Doing so, the emulator will not start up properly. If power is shut OFF by mistake, redownload the firmware in maintenance mode.

4.4 Self-check

(1) Self-check Procedure

To run the emulator self-check, do so as explained here below. While the self-check is in progress, LEDs will change as shown in Figure 4.4.

- (1) Set the switches in the emulation pod same as the factory-setting (see Figure 4.3).
- (2) When the target system is connected, disconnect the target system.
- (3) Within 2 seconds of activating power to the emulator, press the RESET switch on the emulator front panel to switch the emulator to maintenance mode.
- (4) Check the "SAFE" LED starts blinking and then press the RESET switch again.
- (5) The self-check will start. If the normal result is displayed in about 40 seconds, the self-check terminated normally.




Figure 4.3 Switch settings when running the self-check (factory-settings)

(2) If an Error is Detected in the Self-check

If the self-check does not result normally (system status error or target status error shown in Figure 4.4), check the following.

- Check the connection of the emulation pod and the PC4701.
- Download the proper firmware.
- Check if the switches in this product are set same as the factory-settings (Figure 4.3).

IMPORTANT

Note on the Self-check:

- If the self-check does not result normally (excluding target system errors), the emulation pod may be damaged. Then contact your local distributor.




Figure 4.4 Self-check procedure

Chapter 5. Specifications

This chapter describes specifications of this product.

5.1 Specifications	52
5.2 Operation Timing in Memory Expansion Mode and Microprocessor Mode	53
(1) Separate Bus, No-wait	53
(2) Separate Bus, With Wait, Accessing External Memory Area	55
(3) Multiplex Bus, With Wait, Accessing External Memory Area	57
(4) Timing Requirements	59
5.3 Electrical Characteristics	61
5.4 Connection Diagram	62
5.5 External Dimensions	63
(1) External Dimensions of the Emulation Pod	63
(2) External Dimensions of the Converter Board M3T-FLX-100LCC	64
(3) Reference Dimensional Drawing for 100-pin 0.65-mm-pitch QFP Foot Pattern	64

Chapter 5. Specifications

5.1 Specifications

Table 5.1 lists the specifications of the M306NAT2-RPD-E.

Table 5.1 Specifications of the M306NAT2-RPD-E

Emulator	PC4701	
Applicable MCU	M16C/6N Group M306NA and M306NB	
Evaluation MCU	M30622SAFP x1, M306NAMCT-TOOL x1	
Usable mode	Single-chip mode Memory expansion mode Microprocessor mode	
Emulation memory	1 MB	
Maximum operating frequency	16 MHz (no-dividing)	
Clock supply	X _{IN} -X _{OUT}	Internal oscillator circuit board (OSC-3) Switchable to external oscillator input
	X _{CIN} -X _{COUT}	Internal oscillator circuit board Switchable to external oscillator input
Operating voltage	4.2 to 5.5 V	
Operating temperature	5 to 35°C (no dew)	
Storage temperature	-10 to 60°C (no dew)	
Power supply to emulation pod	Supplied from PC4701	
Connection to target system See "3.6 Connecting the Target System" (page 40).	<ul style="list-style-type: none"> • 100-pin 0.65-mm-pitch QFP (100P6S-A): <ul style="list-style-type: none"> (1) M3T-FLX-100LCC (included) + M3T-DUMMY100S (separately available) (2) M3T-FLX-100LCC (included) + M3T-DIRECT100S (separately available) (3) M3T-FLX-100NRB (separately available) • 100-pin LCC socket: M3T-FLX-100LCC (included) 	
	<ul style="list-style-type: none"> • U.S. EMI standards (FCC part 15 Class A) • CE marking (EN55022, EN55024) 	
Overseas standards	<ul style="list-style-type: none"> • U.S. EMI standards (FCC part 15 Class A) • CE marking (EN55022, EN55024) 	

5.2 Operation Timing in Memory Expansion Mode and Microprocessor Mode

(1) Separate Bus, No-Wait

Table 5.2 and Figure 5.1 show the bus timing in memory expansion mode and the microprocessor mode (separate bus, no-wait).

Table 5.2 Memory expansion mode and microprocessor mode (separate bus, no-wait)


Symbol	Item	Actual MCU (ns)		This product (ns)	
		Min.	Max.	Min.	Max.
Td (BCLK-AD)	Address output delay time		25		See left
Th (BCLK-AD)	Address output hold time (BCLK standard)	4		See left	
Th (RD-AD)	Address output hold time (RD standard)	0		See left	
Th (WR-AD)	Address output hold time (WR standard)	0		See left	
Td (BCLK-CS)	Chip-select output delay time		25		See left
Th (BCLK-CS)	Chip-select output hold time (BCLK standard)	4		See left	
Td (BCLK-ALE)	ALE signal output delay time		25		See left
Th (BCLK-ALE)	ALE signal output hold time	-4		See left	
Td (BCLK-RD)	RD signal output delay time		25		See left
Th (BCLK-RD)	RD signal output hold time	0		See left	
Td (BCLK-WR)	WR signal output delay time		25		See left
Th (BCLK-WR)	WR signal output hold time	0		See left	
Td (BCLK-DB)	Data output delay time (BCLK standard)		40		See left
Th (BCLK-DB)	Data output hold time (BCLK standard)	4		See left	
Td (DB-WR)	Data output delay time (WR standard)	(*1)		See left	
Th (WR-DB)	Data output hold time (WR standard)	0		See left	

*1 Calculated by the following formula according to the frequency of BCLK.


$$T_d(\text{DB-WR}) = \frac{10^9}{f(\text{BCLK}) \times 2} - 40 \text{ (ns)}$$

Memory expansion mode and microprocessor mode (no-wait)

Read timing



Write timing



Conditions:

- $V_{CC} = 5\text{ V}$
- Input timing voltage: $V_{IL} = 0.8\text{ V}$, $V_{IH} = 2.5\text{ V}$
- Output timing voltage: $V_{OL} = 0.8\text{ V}$, $V_{OH} = 2.0\text{ V}$

Figure 5.1 Memory expansion mode and microprocessor mode (no-wait)

(2) Separate Bus, With Wait, Accessing External Memory Area

Table 5.3 and Figure 5.2 show the bus timing in memory expansion mode and microprocessor mode (with wait, accessing external memory area).

Table 5.3 Memory expansion mode and microprocessor mode (with wait, external memory area)


Symbol	Item	Actual MCU (ns)		This product (ns)	
		Min.	Max.	Min.	Max.
Td (BCLK-AD)	Address output delay time		25		See left
Th (BCLK-AD)	Address output hold time (BCLK standard)	4		See left	
Th (RD-AD)	Address output hold time (RD standard)	0		See left	
Th (WR-AD)	Address output hold time (WR standard)	0		See left	
Td (BCLK-CS)	Chip-select output delay time		25		See left
Th (BCLK-CS)	Chip-select output hold time (BCLK standard)	4		See left	
Td (BCLK-ALE)	ALE signal output delay time		25		See left
Th (BCLK-ALE)	ALE signal output hold time	-4		See left	
Td (BCLK-RD)	RD signal output delay time		25		See left
Th (BCLK-RD)	RD signal output hold time	0		See left	
Td (BCLK-WR)	WR signal output delay time		25		See left
Th (BCLK-WR)	WR signal output hold time	0		See left	
Td (BCLK-DB)	Data output delay time (BCLK standard)		40		See left
Th (BCLK-DB)	Data output hold time (BCLK standard)	4		See left	
Td (DB-WR)	Data output delay time (WR standard)	(*1)		See left	
Th (WR-DB)	Data output hold time (WR standard)	0		See left	

*1 Calculated by the following formula according to the frequency of BCLK.


$$T_d(\text{DB-WR}) = \frac{10^9}{f(\text{BCLK})} - 40 \text{ (ns)}$$

Memory expansion mode and microprocessor mode (with wait, accessing external memory area)

Read timing



Write timing



Conditions:

- $V_{CC} = 5\text{ V}$
- Input timing voltage: $V_{IL} = 0.8\text{ V}$, $V_{IH} = 2.5\text{ V}$
- Output timing voltage: $V_{OL} = 0.8\text{ V}$, $V_{OH} = 2.0\text{ V}$

Figure 5.2 Memory expansion mode and microprocessor mode (with wait)

(3) Multiplex Bus, With Wait, Accessing External Memory Area

Table 5.4 and Figure 5.3 show the bus timing in memory expansion mode and microprocessor mode (with wait, accessing external memory area and using multiplex bus).


Table 5.4 Memory expansion mode and microprocessor mode (with wait, multiplex bus)

Symbol	Item	Actual MCU (ns)		This product (ns)	
		Min.	Max.	Min.	Max.
Td (BCLK-AD)	Address output delay time		25		See left
Th (BCLK-AD)	Address output hold time (BCLK standard)	4		See left	
Th (RD-AD)	Address output hold time (RD standard)	(*1)		(*2)	
Th (WR-AD)	Address output hold time (WR standard)	(*1)		(*2)	
Td (BCLK-CS)	Chip-select output delay time		25		See left
Th (BCLK-CS)	Chip-select output hold time (BCLK standard)	4		See left	
Th (RD-CS)	Chip-select output hold time (RD standard)	(*1)		(*2)	
Th (WR-CS)	Chip-select output hold time (WR standard)	(*1)		(*2)	
Td (BCLK-RD)	RD signal output delay time		25		See left
Th (BCLK-RD)	RD signal output hold time	0		See left	
Td (BCLK-WR)	WR signal output delay time		25		See left
Th (BCLK-WR)	WR signal output hold time	0		See left	
Td (BCLK-DB)	Data output delay time (BCLK standard)		40		See left
Th (BCLK-DB)	Data output hold time (BCLK standard)	4		See left	
Td (DB-WR)	Data output delay time (WR standard)	(*1)		See left	
Th (WR-DB)	Data output hold time (WR standard)	(*1)		(*2)	
Td (BCLK-ALE)	ALE output delay time (BCLK standard)		25		See left
Th (BCLK-ALE)	ALE output hold time (BCLK standard)	-4		See left	
Td (AD-ALE)	ALE output delay time (Address standard)	(*1)		See left	
Th (ALE-AD)	ALE output hold time (Address standard)	50		See left	
Td (AD-RD)	After address RD signal output delay time	0		See left	
Td (AD-WR)	After address WR signal output delay time	0		See left	
Tdz (RD-AD)	Address output floating start time		8		See left


*1 Calculated by the following formulas according to the frequency of BCLK.	*2 Calculated by the following formulas according to the frequency of BCLK.
$Th (RD-AD) = \frac{10^9}{f(BCLK) \times 2} \text{ (ns)}$	$Th (RD-AD) = \frac{10^9}{f(BCLK) \times 2} - 6 \text{ (ns)}$
$Th (WR-AD) = \frac{10^9}{f(BCLK) \times 2} \text{ (ns)}$	$Th (WR-AD) = \frac{10^9}{f(BCLK) \times 2} - 6 \text{ (ns)}$
$Th (RD-CS) = \frac{10^9}{f(BCLK) \times 2} \text{ (ns)}$	$Th (RD-CS) = \frac{10^9}{f(BCLK) \times 2} - 3 \text{ (ns)}$
$Th (WR-CS) = \frac{10^9}{f(BCLK) \times 2} \text{ (ns)}$	$Th (WR-CS) = \frac{10^9}{f(BCLK) \times 2} - 3 \text{ (ns)}$
$Td (DB-WR) = \frac{10^9 \times 3}{f(BCLK) \times 2} - 40 \text{ (ns)}$	
$Th (WR-DB) = \frac{10^9}{f(BCLK) \times 2} \text{ (ns)}$	$Th (RD-AD) = \frac{10^9}{f(BCLK) \times 2} - 6 \text{ (ns)}$
$Td (AD-ALE) = \frac{10^9}{f(BCLK) \times 2} - 25 \text{ (ns)}$	

Memory expansion mode and microprocessor mode
(with wait, accessing external memory area and using multiplex bus)

Read timing



Write timing



Conditions:

- $V_{\text{CC}} = 5 \text{ V}$
- Input timing voltage: $V_{\text{IL}} = 0.8 \text{ V}$, $V_{\text{IH}} = 2.5 \text{ V}$
- Output timing voltage: $V_{\text{OL}} = 0.8 \text{ V}$, $V_{\text{OH}} = 2.0 \text{ V}$

Figure 5.3 Memory expansion mode and microprocessor mode (with wait, multiplex bus)

(4) Timing Requirements

Table 5.5, Figures 5.4 and 5.5 show timing requirements in memory expansion mode and the microprocessor mode.

Table 5.5 Timing requirements

Symbol	Item	Actual MCU (ns)		This product (ns)	
		Min.	Max.	Min.	Max.
Tsu (DB-RD)	Data input setup time	40		See left	
Tsu (RDY-BCLK)	RDY* input setup time	30		See left	
Tsu (HOLD-BCLK)	HOLD* input setup time	40		(*1)	
Th (RD-DB)	Data input hold time	0		See left	
Th (BCLK-RDY)	RDY* input hold time	0		See left	
Th (BCLK-HOLD)	HOLD* input hold time	0		See left	
Td (BCLK-HLDA)	HLDA* output delay time		40		See left

*1 Minimum 7 ns (The definition is different from that of actual MCUs. For details, see Figure 5.5.)






Figure 5.4 Timing requirements

Common to "with wait" and "no-wait" (actual MCU)



Common to "with wait" and "no-wait" (This product)



Note 1. P00 through P52 will be high-impedance status regardless of the input level of pin BYTE and ports P40 through P43 function selection bit (PM06) of the processor mode register 0.

Note 2. This product will be high-impedance delaying by 2.5 cycles than an actual MCU.

Note 3. The setup time of HOLD is defined by the startup of BCLK, differently from that of actual MCUs.

Conditions:

- $V_{CC} = 5\text{ V}$
- Input timing voltage: $V_{IL} = 1.0\text{ V}$, $V_{IH} = 4.0\text{ V}$
- Output timing voltage: $V_{OL} = 2.5\text{ V}$, $V_{OH} = 2.5\text{ V}$

Figure 5.5 Timing requirements

5.3 Electrical Characteristics

Tables 5.6 and 5.7 list IC electrical characteristics of the user interface.

Table 5.6 Electrical characteristics of the 74HC4066AFT
(P100--P107, AN0--AN7, AN00--AN07, AN20--AN27)

Symbol	Parameter	V _{CC}	Standard values			Unit
			Min.	Standard	Max.	
V _{IHC}	High level control input voltage	4.5	3.15			V
V _{ILC}	Low level control input voltage	4.5			1.35	V
R _{ON}	ON resistance	4.5		96	200	Ω
R _{ON}	Difference of ON resistances	4.5		10		Ω

Table 5.7 Electrical characteristics of the M60081L-0142FP (P00--P57)

Symbol	Parameter	Condition	Standard values			Unit
			Min.	Standard	Max.	
V _{IL}	Input voltage	V _{CC} = 4.5 V	0		1.35	V
V _{IH}		V _{CC} = 5.5 V	3.85		5.5	
V _{OH}	Output voltage	V _{CC} = 5.0 V			0.05	V
V _{OL}		I _O < 1 μA	4.95			V
I _{OL}	Output current	V _{CC} = 4.5 V V _{OL} = 0.4 V	8			mA
I _{OH}		V _{CC} = 4.5 V V _{OH} = 4.1 V			-8	mA
I _{IL}	Input leak current	V _{CC} = 5.5 V V _I = 0 V	-1		+1	μA
I _{IH}		V _{CC} = 5.5 V V _I = 5.5 V	-1		+1	μA
I _{OZL}	OFF state output leak current	V _{CC} = 5.5 V V _O = 0 V	-1		+1	μA
I _{OZH}		V _{CC} = 5.5 V V _O = 5.5 V	-1		+1	μA
C _{IO}	I/O pin capacity	f = 1 MHz V _{CC} = 0 V		7	15	pF

5.4 Connection Diagram

Figure 5.6 shows the connection diagram of the M306NAT2-RPD-E. This connection diagram mainly shows the interface section, and the circuits which are not connected to the target system such as the emulator's control system are omitted.




Figure 5.6 Connection diagram

5.5 External Dimensions

(1) External Dimensions of the Emulation Pod




Figure 5.7 External dimensions of the emulation pod

(2) External Dimensions of the Converter Board M3T-FLX-100LCC

Figure 5.8 shows external dimensions of the converter board M3T-FLX-100LCC for 100-pin LQFP (100D0).




Figure 5.8 External Dimensions of the Converter Board M3T-FLX-100LCC

(3) Reference Dimensional Drawing for 100-pin 0.65-mm-pitch QFP Foot Pattern

Figure 5.9 shows an sample foot pattern for Renesas 100P6S-A, the socket IC61-1004-051 (made by Yamaichi Electronics Co., Ltd.) for LCC, the IC socket AXS4003M291 (made by Matsushita Electric Works, Ltd.) for dummy IC and pitch converter board M3T-FLX-100NRB (NQPAC100RB).




Figure 5.9 Reference dimensional drawing for a 100-pin 0.65-mm-pitch QFP foot pattern

Chapter 6. Troubleshooting

This chapter describes how to troubleshoot when this product does not work properly.

6.1 Flowchart to Remedy the Troubles	66
6.2 When the Emulator Debugger Does Not Start Up Properly	67
(1) When LED Display of the PC4701 is Abnormal	67
(2) Program Window Does Not Appear at Debugger Startup (target connected)	68
(3) Program Window Does Not Appear at Debugger Startup (target not connected)	69
(4) Errors Occur at Debugger Startup (target connected)	69
6.3 Operation Differs from That of Actual MCUs	70
(1) Cannot Reset from the Target System	70
(2) Data Values of ROM Area at Power-on Are Different	70
(3) HOLD* Control	70
(4) A-D Conversion Values are Different from Expected Values	70
(5) Outputs of ALE, Address and Others are Different from Those of Actual MCUs	70

Chapter 6. Troubleshooting

6.1 Flowchart to Remedy the Troubles

Figure 6.1 shows the flowchart to remedy the troubles from when power to the emulator is activated until the emulator debugger starts up. Check this while the target system is disconnected. FAQs visit the following URL.

<http://www.renesas.com/en/tools>




Figure 6.1 Flowchart to remedy the troubles

6.2 When the Emulator Debugger Does Not Start Up Properly

(1) When LED Display of the PC4701 is Abnormal

Table 6.1 LED's abnormal display and its checkpoints

Error	Connection to the target system	Checkpoint
LEDs do not light up.	-	Recheck that the power cable is connected to the PC4701. <i>See the instruction manual of the PC4701.</i>
All LEDs remain lit.	-	Recheck that the connection between the PC4701 and this product. <i>See "3.5 Connecting the PC4701" (page 38).</i>
POWER LED of STATUS OF TARGET does not light up.	Connected	Check that power is properly supplied to the target system and that the target system is properly grounded.
CLOCK LED of STATUS OF TARGET does not light up.	Disconnected	(1) Check that both the main and sub clocks of the emulator debugger are not set to "EXT". <i>See the CLK command of the emulator debugger.</i> (2) Check that the oscillation circuit in the emulation pod is oscillating. <i>See "3.3 Selecting Clock Supply" (page 33).</i>
	Connected	(1) Check that the oscillation circuit in the target system is oscillating. (2) Check that the switches in the emulation pod are correctly set. <i>See "3.2 Setting Switches and Pullup Resistors" (page 29).</i>
RESET LED of STATUS OF TARGET does not turn off.	Connected	Check that the reset pin of the target system is pulled "High".

(2) Program Window Does Not Appear at Debugger Startup (target connected)

Table 6.2 Checkpoints of errors when starting up the emulator debugger (target connected)

Error	Checkpoint
Communication error occurred Data was not sent to the target	Check that all emulator debugger settings, interface cable connection and switches on the rear of the PC4701 match. <i>See the user's manuals of the PC4701 and the emulator debugger.</i>
Target system cannot be properly built	(1) Download the proper firmware. <i>See "4.3 Downloading Firmware" (page 48).</i> (2) Recheck that the connection between the PC4701 and this product. <i>See "3.5 Connecting the PC4701" (page 38).</i>
M3T-PD30 version is not the same version as the firmware in the target	Download the proper firmware. <i>See "4.3 Downloading Firmware" (page 48).</i>
Target MCU is in the reset state	Check the reset pin of the target system has changed from "Low" to "High" level.
Target MCU cannot be reset	(1) Check that pins RESET* and NMI* are held "High". (2) If in memory expansion mode or microprocessor mode, check that pins RDY* and HOLD* are held "High". (3) If the reset circuit of the target system has a watchdog timer, disable the timer. (4) Check that power is properly supplied to the target system and that the target system is properly grounded. (5) The program may be uncontrollable in areas where memory is not allocated. Recheck the map setting. <i>See the user's manual of the emulator debugger.</i>
Target is in HOLD state	(1) The MCU is either in stop mode or wait mode. Either reset the MCU or cancel the mode with an interrupt. <i>See the MCU specifications.</i> (2) The program may be uncontrollable in areas where memory is not allocated. Recheck the map setting. <i>See the user's manual of the emulator debugger.</i>
Target clock is stopped	(1) Check that the oscillation circuit of the target system is oscillating properly. (2) Check that the switches in the emulation pod are correctly set. <i>See "3.2 Setting Switches and Pullup Resistors" (page 29).</i>
Target MCU is not receiving power	Check that power is properly supplied to the target system and the target system is properly grounded.

(3) Program Window Does Not Appear at Debugger Startup (target not connected)

Table 6.3 Checkpoints of errors when starting up the emulator debugger (target not connected)

Error	Checkpoint
Communication error occurred Data was not sent to the target	Check that all emulator debugger settings, interface cable connection and switches on the rear of the PC4701 match. <i>See the user's manuals of the PC4701 and the emulator debugger.</i>
Target system cannot be properly built	(1) Download the proper firmware. <i>See "4.3 Downloading Firmware" (page 48).</i> (2) Recheck the connection between the PC4701 and this product. <i>See "3.5 Connecting the PC4701" (page 38).</i>
M3T-PD30 version is not the same version as the firmware in the target	Download the proper firmware. <i>See "4.3 Downloading Firmware" (page 48).</i>
Target MCU cannot be reset	The program may be uncontrollable in areas where memory is not allocated. Recheck the map setting. <i>See the user's manual of the emulator debugger.</i>
Target is in HOLD state	(1) The MCU is either in stop mode or wait mode. Either reset the MCU or cancel the mode with an interrupt. <i>See the MCU specifications.</i> (2) The program may be uncontrollable in areas where memory not allocated. Recheck the map setting. <i>See the user's manual of the emulator debugger.</i>
Target clock is stopped	Check that the switches in the emulation pod are correctly set. <i>See "3.2 Setting Switches and Pullup Resistors" (page 29).</i>

(4) Errors Occur at Debugger Startup (target connected)

Table 6.4 Checkpoints of errors when starting up the emulator debugger (target connected)

Error	Checkpoint
Target MCU is uncontrollable.	(1) If in memory expansion mode or microprocessor mode, check pins RDY* and HOLD* are held "High". (2) The program may be uncontrollable in areas where memory is not allocated. Recheck the map setting. <i>See the user's manual of the emulator debugger.</i>

6.3 Operation Differs from That of Actual MCUs

(1) Cannot Reset from the Target System

Set the rise time (0.2 V_{cc} to 0.8 V_{cc}) 1 μs or less.

(2) Data Values of ROM Area at Power-on Are Different

For this product, 04h is written into the ROM area at power-on. Therefore, the data values are different from those of an actual MCU.

(3) HOLD* Control

When inputting "Low" to pin HOLD* to run into the HOLD state, P00 to P52 will be in the HOLD state delaying by 2.5 cycles than an actual MCU (see Figure 5.5 and Table 5.5).

(4) A-D Conversion Values are Different from Expected Values

As a flexible cable, a pitch converter board and other devices are used between the evaluation MCU and the target system, some characteristics are slightly different from those of the actual MCU. Therefore, be sure to evaluate your system with an actual MCU.

(5) Outputs of ALE, Address and Others are Different from Those of Actual MCUs

This product has some output signals which are different from those of actual MCU as following.

- ALE signal output in accessing the SFR area
- Address, BHE* and ALE signal outputs in accessing the internal RAM and ROM
- State of the data bus in stop mode and wait mode

For details, see Chapter 1 "Note on Differences between Actual MCU and Emulator" (pages 17 to 19).

Chapter 7. Maintenance and Guarantee

This chapter describes how to maintenance, repair provisions and how to request for repair.

7.1 Maintenance	72
7.2 Guarantee	72
7.3 Repair Provisions	72
7.4 How to Request for Repair	73

Chapter 7. Maintenance and Guarantee

7.1 Maintenance

If dust or dirt collects on any equipment of your emulation system, wipe it off with a dry soft cloth. Do not use thinner or other solvents because these chemicals can cause the equipment's surface coating to separate.

7.2 Guarantee

If your product becomes faulty within one year after its purchase while being used under good conditions by observing "Precautions for Safety" described in Chapter 1 of this user's manual, we will repair or replace your faulty product free of charge. Note, however, that if your product's fault is raised by any one of the following causes, we will repair it or replace it with new one with extra-charge:

- Misuse, abuse, or use under extraordinary conditions
- Unauthorized repair, remodeling, maintenance, and so on
- Inadequate user's system or misuse of it
- Fires, earthquakes, and other unexpected disasters

In the above cases, contact your local distributor. If your product is being leased, consult the leasing company or the owner.

7.3 Repair Provisions

(1) Repair with extra-charge

The products elapsed more than one year after purchase can be repaired with extra-charge.

(2) Replacement with extra-charge

If your product's fault falls in any of the following categories, the fault will be corrected by replacing the entire product instead of repair, or you will be advised to purchase new one, depending on the severity of the fault.

- Faulty or broken mechanical portions
- Flaw, separation, or rust in coated or plated portions
- Flaw or cracks in plastic portions
- Faults or breakage caused by improper use or unauthorized repair or modification
- Heavily damaged electric circuits due to overvoltage, overcurrent or shorting of power supply
- Cracks in the printed circuit board or burnt-down patterns
- Wide range of faults that makes replacement less expensive than repair
- Unlocatable or unidentified faults

(3) Expiration of the repair period


When a period of one year elapses after the model was dropped from production, repairing products of the model may become impossible.

(4) Transportation fees at sending your product for repair

Please send your product to us for repair at your expense.

7.4 How to Request for Repair

If your product is found faulty, follow the procedure below to send your product for repair.



CAUTION

Note on Transporting the Product:



- When sending your product for repair, use the packing box and cushion material supplied with this product when delivered to you and specify handling caution for it to be handled as precision equipment. If packing of your product is not complete, it may be damaged during transportation. When you pack your product in a bag, make sure to use conductive polyvinyl supplied with this product (usually a blue bag). When you use other bags, they may cause a trouble on your product because of static electricity.

MEMO

M306NAT2-RPD-E User's Manual

Rev.2.00
July 1, 2004
REJ10J0202-0200Z

COPYRIGHT ©2003-2004 RENESAS TECHNOLOGY CORPORATION
AND RENESAS SOLUTIONS CORPORATION ALL RIGHTS RESERVED

M306NAT2-RPD-E User's Manual



Renesas Electronics Corporation

1753, Shimonumabe, Nakahara-ku, Kawasaki-shi, Kanagawa 211-8668 Japan

REJ10J0202-0200Z