

---

## DA9292 Unused Pin Configuration

---

This application note describes the recommended configuration for unused pins in applications that use either the DA9292 power management IC.

### Contents

Contents .....	1
Tables.....	1
1. Terms and Definitions .....	2
2. References.....	2
3. Introduction .....	2
4. DA9292 Functional Blocks.....	2
5. Conclusion .....	4
Revision History .....	5

### Tables

Table 1: Pin Type Definition.....	2
Table 2: Pin Description.....	2

## 1. Terms and Definitions

CH<x>	Channel <x>, where x = 1 to 2
CPU	Central processing unit
GPU	Graphics processing unit
IC	Integrated circuit
SoC	System on chip

## 2. References

[1] DA9292\_Datasheet, Renesas Electronics.

**Note 1** References are for the latest published version, unless otherwise indicated.

## 3. Introduction

DA9292 is a high-performance Power Management IC suitable for supplying high-current rails in CPUs, GPUs, SoCs in multiple end-applications. The device is capable of supporting up to 52 A of peak current in a compact offering, with fully integrated power devices. DA9292 can be configured as either a 20 A quad-phase buck converter or two 10 A dual-phase buck converters.

In some applications, certain functions or features may not be required and, to minimize any potential issues with these unused functions, the pins related to them need to be configured correctly. This document provides guidance on how to configure unused connections on the DA9292.

## 4. DA9292 Functional Blocks

The following tables describe the recommended configurations for unused pins. Mandatory means that the pin is used in all applications.

**Table 1: Pin Type Definition**

Pin Type	Description	Pin Type	Description
DI	Digital input	AI	Analog input
DOD	Digital output open drain	AO	Analog output
DIOD	Digital input/output open drain	AIO	Analog input/output
PWR	Power	GND	Ground

**Table 2: Pin Description**

Pin #	Pin Name	Type (Table 1)	Drive (mA)	Description	If Unused	
					1CH4PH Operation	2CH2PH Operation
A1, B1, C1	VDD1	PWR	5000	Power supply for phase1	Mandatory	Connect to GND (no cap required)
A2, B2, C2	LX1	AIO	5000	LX node of phase1	Mandatory	Leave floating (L and Cout not required)
A3, B3, C3	GND1	GND	5000	Power ground of phase1	Mandatory	Mandatory
A4, B4, C4	GND2	GND	5000	Power ground of phase2	Mandatory	Mandatory

## DA9292 Unused Pin Configuration

Pin #	Pin Name	Type (Table 1)	Drive (mA)	Description	If Unused	
					1CH4PH Operation	2CH2PH Operation
A5, B5, C5	LX2	AIO	5000	LX node of phase2	Mandatory	Leave floating (L and Cout not required)
A6, B6, C6	VDD2	PWR	5000	Power supply for phase2	Mandatory	Connect to GND (no cap required)
D1	FBN1	AI	10	Negative remote sense input for CH1	Mandatory	Connect to GND
D2	EN1	DI	10	Enable/disable input of CH1	Connect to GND	Connect to GND
D3	VSEL1	DI	10	External voltage control pin of CH1	Connect to GND	Connect to GND
D4	INT_N	DOD	10	Interrupt output, active low	Leave floating	Leave floating
D5	TW_N	DOD	10	Thermal warning output, active low	Leave floating	Leave floating
D6	VDDIO	PWR	15	Power supply for IO	Mandatory	Mandatory
E1	FBP1	AI	10	Positive remote sense input of CH1	Mandatory	Connect to GND
E2	AGND	GND	15	Ground of internal analog circuitry	Mandatory	Mandatory
E3	SCL	DI	15	I <sup>2</sup> C clock	Mandatory - though can be connected to GND if I <sup>2</sup> C control/monitoring is not required	Mandatory - though can be connected to GND if I <sup>2</sup> C control/monitoring is not required
E4	SDA	DIOD	15	I <sup>2</sup> C data	Mandatory - though can be connected to GND if I <sup>2</sup> C control/monitoring is not required	Mandatory - though can be connected to GND if I <sup>2</sup> C control/monitoring is not required
E5	CE	DI	10	Chip enable	Mandatory	Mandatory
E6	FBP2	AI	10	Positive remote sense input of CH2	Leave floating	Connect to GND
F1	AVDD	PWR	10	Power supply for internal analog circuitry	Mandatory	Mandatory
F2	PB_N	DOD	10	Power-bad output, active low	Leave floating	Leave floating
F3	CONF	DI	10	Configuration mode select (1Ch-4Ph or 2Ch-2Ph+2Ph)	Mandatory	Mandatory
F4	VSEL2	DI	10	External voltage control pin of CH2	In 1Ch-4Ph configuration, connect to AGND In 2Ch-2Ph+2Ph configuration, connect to GND	Connect to GND
F5	EN2	DI	10	Enable/disable input of CH2	In 1Ch-4Ph configuration, connect to AGND In 2Ch-2Ph+2Ph configuration, connect to GND	Connect to GND
F6	FBN2	AI	10	Negative remote sense input of CH2	Leave floating	Connect to GND
G1, H1, J1	VDD3	PWR	5000	Power supply for phase3	Mandatory	Connect to GND (no cap required)

Pin #	Pin Name	Type (Table 1)	Drive (mA)	Description	If Unused	
					1CH4PH Operation	2CH2PH Operation
G2, H2, J2	LX3	AIO	5000	LX node of phase3	Mandatory	Leave floating (L and Cout not required)
G3, H3, J3	GND3	GND	5000	Power ground of phase3	Mandatory	Mandatory
G4, H4, J4	GND4	GND	5000	Power ground of phase4	Mandatory	Mandatory
G5, H5, J5	LX4	AIO	5000	LX node of phase4	Mandatory	Leave floating (L and Cout not required)
G6, H6, J6	VDD4	PWR	5000	Power supply for phase4	Mandatory	Connect to GND (no cap required)

## 5. Conclusion

Adherence to the recommendations of this document helps minimize spurious application issues such as noise and increased current consumption and may avoid device damage due to incorrectly biased pins. For further information please consult your Renesas Electronics [local sales representative](#).

## Revision History

Revision	Date	Description
1.0	Nov 26, 2024	First version.
2.0	Mar 31, 2025	Section 4: Updated Pin Description

### Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

### RoHS Compliance

Renesas Electronics' suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

### Important Notice and Disclaimer

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

© 2025 Renesas Electronics Corporation. All rights reserved.

(Rev.1.0 Mar 2020)

### Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu  
Koto-ku, Tokyo 135-0061, Japan  
[www.renesas.com](http://www.renesas.com)

### Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:  
<https://www.renesas.com/contact/>

### Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.