

Thank you for purchasing Parameter Files for PG-FP5.

This document describes cautions on using Parameter Files for PG-FP5. Also see the user's manual of the PG-FP5 for cautions on using the PG-FP5.

See a following WEB site about PG-FP5.

<https://www.renesas.com/pg-fp5>

Chapter 1. Package List.....	3
Chapter 2. Correspondence version and notes of PG-FP5.....	6
2.1 PR5-R5F10D (RL78/D1A), PR5-R5F10B (RL78/F13), PR5-R5F10P (RL78/F14), PR5-R5F113 (RL78/F15), PR5-R5F114 (RL78/F1A), PR5-R5F105 (RL78/G11), PR5-R5F104 (RL78/G14), PR5-R5F11A (RL78/G1D), PR5-R5F10F (RL78/G1E), PR5-R5F11B (RL78/G1F, ICs for Motor Driver/Actuator Driver ICs for Motor Control), PR5-R5F11E (RL78/G1G), PR5-R5F11F (RL78/G1H), PR5-R5F11N (RL78/H1D), PR5-R5F10M (RL78/I1B), PR5-R5F10N (RL78/I1C), PR5-R5F117 (RL78/I1D), PR5-R5F11C (RL78/I1E), PR5-R5F11M (RL78/L1A), PR5-R5F110 (RL78/L1C), PR5-USBPDC30 (Renesas USB Power Delivery C30).....	6
2.2 PR5-R5F10Y (RL78/G10)	7
2.3 PR5-R5F5110 (RX110), PR5-R5F5111 (RX111), PR5-R5F5113 (RX113), PR5-R5F5130 (RX130).....	8
2.4 PR5-R5F5210 (RX210), PR5-R5F5210A (RX21A)	9
2.5 PR5-R5F5220 (RX220).....	10
2.6 PR5-R5F5230 (RX230), PR5-R5F5231 (RX231).....	11
2.7 PR5-R5F523T (RX23T), PR5-R5F524T (RX24T), PR5-R5F524U (RX24U).....	12
2.8 PR5-R5F5610 (RX610).....	13
2.9 PR5-R5F5621 (RX621), PR5-R5F562N (RX62N).....	14
2.10 PR5-R5F562G (RX62G), PR5-R5F562T (RX62T)	15
2.11 PR5-R5F5630 (RX630), PR5-R5F5631 (RX631), PR5-R5F563N (RX63N).....	16
2.12 PR5-R5F5634 (RX634).....	17
2.13 PR5-R5F563T (RX63T).....	18
2.14 PR5-RH850F1X (RH850/F1L), PR5-RH850 (RH850)	19
2.15 PR5-R5F564M (RX64M), PR5-R5F566T (RX66T), PR5-R5F571M (RX71M), PR5-RH850C1X (RH850/C1x), PR5-RH850D1X (RH850/D1x), PR5-RH850E1X (RH850/E1x), PR5-RH850F1X (RH850/F1M, RH850/F1H), PR5-RH850P1X (RH850/P1M, RH850/P1M-E).....	20
2.16 PR5-R5F5651 (RX651), PR5-R5F565N (RX65N)	21
2.17 PR5-RH850F1X (RH850/F1K, RH850/F1KM), PR5-RH850P1X (RH850/P1x-C).....	22
2.18 PR5-78F8039 (UPD78F8032)	23
2.19 PR5-70F3482 (V850E/Sx3-H)	24

2.20	PR5-70F3537 (V850E2/Dx4, V850E2/Dx4-H)	25
2.21	PR5-70F4012 (V850E2/Fx4), PR5-70F3545 (V850E2/Fx4-M)	26
2.22	PR5-70F3592 (V850E2/Fx4-G)	27
2.23	PR5-70F3585 (V850E2/Fx4-L)	28
2.24	PR5-70F4155 (V850E2/Px4-L), PR5-70F4159 (V850E2/PG4-S)	29
2.25	PR5-70F4018 (V850E2/Sx4-H)	30
2.26	PR5-R8C3X (R8C/3x), PR5-R8C5X (R8C/5x), PR5-R8CLX (R8C/Lx)	31
2.27	PR5-SH7250 (SH7253)	32
2.28	PR5-SH72AX (SH72Ax)	33

Chapter 1. Package List

Information on the packages listed below is given. For other packages, refer to the release notes that accompany the packages.

RL78 Family

Group	Package name	Package version	Refer to:
RL78/D1A	PR5-R5F10D	V1.01	2.1
RL78/F13	PR5-R5F10B	V1.01	2.1
RL78/F14	PR5-R5F10P	V1.01	2.1
RL78/F15	PR5-R5F113	V1.01	2.1
RL78/F1A	PR5-R5F114	V1.00	2.1
RL78/G10	PR5-R5F10Y	V1.01	2.2
RL78/G11	PR5-R5F105	V1.01	2.1
RL78/G14	PR5-R5F104	V1.07	2.1
RL78/G1D	PR5-R5F11A	V1.00	2.1
RL78/G1E	PR5-R5F10F	V1.02	2.1
RL78/G1F	PR5-R5F11B	V1.00	2.1
RL78/G1G	PR5-R5F11E	V1.00	2.1
RL78/G1H	PR5-R5F11F	V1.00	2.1
RL78/H1D	PR5-R5F11N	V1.01	2.1
RL78/I1B	PR5-R5F10M	V1.00	2.1
RL78/I1C	PR5-R5F10N	V1.01	2.1
RL78/I1D	PR5-R5F117	V1.00	2.1
RL78/I1E	PR5-R5F11C	V1.00	2.1
RL78/L1A	PR5-R5F11M	V1.00	2.1
RL78/L1C	PR5-R5F110	V1.01	2.1

RX Family

Group	Package name	Package version	Refer to:
RX110	PR5-R5F5110	V1.00	2.3
RX111	PR5-R5F5111	V1.01	2.3
RX113	PR5-R5F5113	V1.00	2.3
RX130	PR5-R5F5130	V1.02	2.3
RX210	PR5-R5F5210	V1.03	2.4
RX21A	PR5-R5F521A	V1.01	2.4
RX220	PR5-R5F5220	V1.01	2.5
RX230	PR5-R5F5230	V1.02	2.6
RX231	PR5-R5F5231	V1.02	2.6
RX23T	PR5-R5F523T	V1.01	2.7
RX24T	PR5-R5F524T	V1.02	2.7
RX24U	PR5-R5F524U	V1.00	2.7
RX610	PR5-R5F5610	V1.01	2.8
RX621	PR5-R5F5621	V1.01	2.9
RX62G	PR5-R5F562G	V1.01	2.10
RX62N	PR5-R5F562N	V1.01	2.9
RX62T	PR5-R5F562T	V1.01	2.10
RX630	PR5-R5F5630	V1.01	2.11
RX631	PR5-R5F5631	V1.04	2.11
RX634	PR5-R5F5634	V1.00	2.12
RX63N	PR5-R5F563N	V1.04	2.11
RX63T	PR5-R5F563T	V1.01	2.13
RX64M	PR5-R5F564M	V1.02	2.15
RX651	PR5-R5F5651	V1.02	2.16
RX65N	PR5-R5F565N	V1.02	2.16
RX66T	PR5-R5F566T	V1.00	2.15
RX71M	PR5-R5F571M	V1.01	2.15

RH850 Family

Group	Package name	Package version	Refer to:
RH850/C1x	PR5-RH850C1X	V1.03	2.15
RH850/D1x	PR5-RH850D1X	V1.03	2.15
RH850/E1x	PR5-RH850E1X	V1.02	2.15
RH850/F1H	PR5-RH850F1X	V1.10	2.15
RH850/F1K	PR5-RH850F1X	V1.10	2.17
RH850/F1L	PR5-RH850F1X	V1.10	2.14
RH850/F1M	PR5-RH850F1X	V1.10	2.15
RH850/P1M	PR5-RH850P1X	V1.06	2.15
RH850/P1M-E	PR5-RH850P1X	V1.06	2.15
RH850/P1x-C	PR5-RH850P1X	V1.06	2.17
RH850	PR5-RH850	V1.01	2.14

Renesas USB Power Delivery Family

Group	Package name	Package version	Refer to:
C30	PR5-USBPDC30	V1.00	2.1

ICs for Motor Driver/Actuator Driver

Group	Package name	Package version	Refer to:
ICs for Motor Control	PR5-R5F11B	V1.00	2.1

78K Family

Group	Package name	Package version	Refer to:
UPD78F8032	PR5-78F8039	V1.01	2.18

V850 Family

Group	Package name	Package version	Refer to:
V850E/Sx3-H	PR5-70F3482	V1.04	2.19
V850E2/Dx4, V850E2/Dx4-H	PR5-70F3537	V1.01	2.20
V850E2/Fx4	PR5-70F4012	V1.06	2.21
V850E2/Fx4-G	PR5-70F3592	V1.01	2.22
V850E2/Fx4-L	PR5-70F3585	V1.01	2.23
V850E2/Fx4-M	PR5-70F3545	V1.02	2.21
V850E2/Px4-L	PR5-70F4155	V1.01	2.24
V850E2/PG4-S	PR5-70F4159	V1.00	2.24
V850E2/Sx4-H	PR5-70F4018	V1.02	2.25

R8C Family

Group	Package name	Package version	Refer to:
R8C/3x	PR5-R8C3X	V1.06	2.26
R8C/5x	PR5-R8C5X	V1.02	2.26
R8C/Lx	PR5-R8CLX	V1.03	2.26

SuperH Family

Group	Package name	Package version	Refer to:
SH7253	PR5-SH7250	V1.00	2.27
SH72Ax	PR5-SH72AX	V1.01	2.28

Chapter 2. Correspondence version and notes of PG-FP5

2.1 PR5-R5F10D (RL78/D1A), PR5-R5F10B (RL78/F13), PR5-R5F10P (RL78/F14), PR5-R5F113 (RL78/F15), PR5-R5F114 (RL78/F1A), PR5-R5F105 (RL78/G11), PR5-R5F104 (RL78/G14), PR5-R5F11A (RL78/G1D), PR5-R5F10F (RL78/G1E), PR5-R5F11B (RL78/G1F, ICs for Motor Driver/Actuator Driver ICs for Motor Control), PR5-R5F11E (RL78/G1G), PR5-R5F11F (RL78/G1H), PR5-R5F11N (RL78/H1D), PR5-R5F10M (RL78/I1B), PR5-R5F10N (RL78/I1C), PR5-R5F117 (RL78/I1D), PR5-R5F11C (RL78/I1E), PR5-R5F11M (RL78/L1A), PR5-R5F110 (RL78/L1C), PR5-USBPDC30 (Renesas USB Power Delivery C30)

2.1.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.06 or later
Firmware for PG-FP5	V2.06 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
Single-line UART	1 wire UART	115200,250000,500000,1MBaud

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	Internal oscillation circuit	Can't be changed	Can't be changed

2.2 PR5-R5F10Y (RL78/G10)

2.2.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.10 or later
Firmware for PG-FP5	V2.10 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
Single-line UART	1 wire UART	115200Baud

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	Internal oscillation circuit	Can't be changed	Can't be changed

2.3 PR5-R5F5110 (RX110), PR5-R5F5111 (RX111), PR5-R5F5113 (RX113), PR5-R5F5130 (RX130)

2.3.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	High-speed on-chip oscillator	When using SCI1: fx=16.0MHz When using FINE: fx=8.0MHz (VCC<3.0V), 32MHz (VCC≥3.0V)	PLL mode (CKM) 1.00 (CKP) 1.00

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.
FINE	Fine-D	

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

c. Use R5F5xxxxx_x_2.pr5 when writing to R5F51305 products having 100 pins. Use R5F5xxxxx_x.pr5 to write to microcontrollers having 80 or less pins.

2.4 PR5-R5F5210 (RX210), PR5-R5F5210A (RX21A)

2.4.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	High-speed on-chip oscillator	fx=32.0MHz	PLL mode (CKM) 1.00 (CKP) 1.00

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.
FINE	Fine-D	

- b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.
- c. Use R5F5xxxxx_x_2.pr5 when writing to R5F52105B or R5F52106B products having 144 or more pins. Use R5F5xxxxx_x.pr5 to write to microcontrollers having 100 or less pins.
- d. For the Chip Version A of the RX210, FINE is not supported.

2.5 PR5-R5F5220 (RX220)

2.5.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	High-speed on-chip oscillator	$f_x=32.0\text{MHz}$	PLL mode (CKM) 0.50 (VCC<3.0V), 1.00 (VCC \geq 3.0V) (CKP) 0.50 (VCC<3.0V), 1.00 (VCC \geq 3.0V)

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.
FINE	Fine-D	

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.6 PR5-R5F5230 (RX230), PR5-R5F5231 (RX231)

2.6.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	High-speed on-chip oscillator	fx=8.0MHz (VCC < 3.0V), 32.0MHz (VCC ≥ 3.0V)	When using SCI1: PLL mode (CKM) 2.00 (CKP) 2.00
			When using FINE: PLL mode (CKM) 1.00 (CKP) 1.00

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected. When using SCI1 and fx=32.0MHz, 4.000Mbd not selected. When using fx=8.0MHz, 1.000Mbd or more is not selected.
FINE	Fine-D	

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.7 PR5-R5F523T (RX23T), PR5-R5F524T (RX24T), PR5-R5F524U (RX24U)

2.7.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	High-speed on-chip oscillator	fx=32.0MHz	When using SC11: PLL mode (CKM) 2.00 (CKP) 2.00
			When using FINE: PLL mode (CKM) 1.00 (CKP) 1.00

Communication system setup

Communication port of Device	Port	Speed
SC11	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected. When using SC11, 4.000Mbd not selected.
FINE	Fine-D	

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.8 PR5-R5F5610 (RX610)

2.8.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.06 or later
Firmware for PG-FP5	V2.06 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$8.0\text{MHz} \leq f_x \leq 14.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=8MHz~100MHz(ICLK)" and "Frequency * CKP=8MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI4	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

2.9 PR5-R5F5621 (RX621), PR5-R5F562N (RX62N)

2.9.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.06 or later
Firmware for PG-FP5	V2.06 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$8.0\text{MHz} \leq f_x \leq 14.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=8MHz~100MHz(ICLK)" and "Frequency * CKP=8MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

2.10 PR5-R5F562G (RX62G), PR5-R5F562T (RX62T)

2.10.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.06 or later
Firmware for PG-FP5	V2.06 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$8.0\text{MHz} \leq f_x \leq 12.5\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=8MHz~100MHz(ICLK)" and "Frequency * CKP=8MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

2.11 PR5-R5F5630 (RX630), PR5-R5F5631 (RX631), PR5-R5F563N (RX63N)

2.11.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.09 or later
Firmware for PG-FP5	V2.09 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup (R5F56316, R5F56317, R5F56318, R5F5631F, R5F5631G, R5F5631J, R5F5631W, R5F5631Y, R5F563NF, R5F563NG, R5F563NJ, R5F563NW, R5F563NY)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$4.0\text{MHz} \leq f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00, 16.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=4MHz~100MHz(ICLK)" and "Frequency * CKP=4MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Supply oscillator setup (Except R5F56316, R5F56317, R5F56318, R5F5631F, R5F5631G, R5F5631J, R5F5631W, R5F5631Y, R5F563NF, R5F563NG, R5F563NJ, R5F563NW, R5F563NY)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$4.0\text{MHz} \leq f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00, 16.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=8MHz~100MHz(ICLK)" and "Frequency * CKP=8MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.12 PR5-R5F5634 (RX634)

2.12.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.09 or later
Firmware for PG-FP5	V2.09 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$4.0\text{MHz} \leq f_x \leq 20.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00, 16.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=4MHz~54MHz(ICLK)" and "Frequency * CKP=4MHz~32MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.13 PR5-R5F563T (RX63T)

2.13.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.09 or later
Firmware for PG-FP5	V2.09 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup (R5F563TB, R5F563TC, R5F563TE)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$8.0\text{MHz} \leq f_x \leq 12.5\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00, 16.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=8MHz~100MHz(ICLK)" and "Frequency * CKP=8MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Supply oscillator setup (Except R5F563TB, R5F563TC, R5F563TE)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	$4.0\text{MHz} \leq f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode ^{Note} (CKM) 1.00,2.00,4.00,8.00, 16.00 (CKP) 1.00,2.00,4.00,8.00

Note) Please set so that "Frequency * CKM=4MHz~100MHz(ICLK)" and "Frequency * CKP=4MHz~50MHz(PCLK)".

Please refer to the user's manual of a device for Operation Conditions.

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

b. If microcontroller is programmed by little endian, you must use the parameter file of R5F5xxxxx_L.pr5. The other parameter file of R5F5xxxxx_B.pr5 is used by big endian.

2.14 PR5-RH850F1X (RH850/F1L), PR5-RH850 (RH850)

2.14.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.12 or later
Firmware for PG-FP5	V2.12 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2.15 PR5-R5F564M (RX64M), PR5-R5F566T (RX66T), PR5-R5F571M (RX71M), PR5-RH850C1X (RH850/C1x), PR5-RH850D1X (RH850/D1x), PR5-RH850E1X (RH850/E1x), PR5-RH850F1X (RH850/F1M, RH850/F1H), PR5-RH850P1X (RH850/P1M, RH850/P1M-E)

2.15.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list (Except RH850/D1M: R7F701441, R7F701442, R7F701461, R7F701462)

PG-FP5	Version
Programming GUI for PG-FP5	V2.13 or later
Firmware for PG-FP5	V2.13 or later
FPGA for PG-FP5	V4 or later

Correspondence PG-FP5 version list (RH850/D1M: R7F701441, R7F701442, R7F701461, R7F701462)

PG-FP5	Version
Programming GUI for PG-FP5	V2.14 or later
Firmware for PG-FP5	V2.14 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

- a. In the case of RH850/C1x, RH850/E1x, RH850/P1M, it is not possible to write it by supplying power from the flash programmer to VDD terminal. Please supply power from the outside.
- b. In the case of RH850/C1H, it uses the 16MB (1 division) or 10MB (2 division) of the programming area.
- c. In the case of RX66T, it is not possible to erase all by ID authentication failure. FINE connection is not possible.

2.16 PR5-R5F5651 (RX651), PR5-R5F565N (RX65N)

2.16.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.
Correspondence PG-FP5 version list (R5F56514, R5F56517, R5F56519, R5F565N4, R5F565N7, R5F565N9)

PG-FP5	Version
Programming GUI for PG-FP5	V2.15 or later
Firmware for PG-FP5	V2.15 or later
FPGA for PG-FP5	V4 or later

Correspondence PG-FP5 version list (R5F5651C, R5F5651E, R5F565NC, R5F565NE)

PG-FP5	Version
Programming GUI for PG-FP5	V2.15 or later
Firmware for PG-FP5	V2.16 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

- a. In the case of R5F5651C, R5F5651E, R5F565NC, R5F565NE, if microcontroller is programmed by Dual Mode, you must use the parameter file of R5F565x_D_2.pr5. The other parameter file of R5F565x_L_2.pr5 is used by Linear Mode.

2. Notes

RX651: R5F5651C, R5F5651E
RX65N: R5F565NC, R5F565NE

Select the parameter file according to the setting of the Option-Setting Memory "Bank Mode Select" to create a setting file (ESF file).

Bank Mode Select	Target Device	Parameter File
Linear Mode	R5F5651C	R5F5651_L_2.pr5
	R5F5651E	R5F5651_L_2.pr5
	R5F565NC	R5F565N_L_2.pr5
	R5F565NE	R5F565N_L_2.pr5
Dual Mode	R5F5651C	R5F5651_D_2.pr5
	R5F5651E	R5F5651_D_2.pr5
	R5F565NC	R5F565N_D_2.pr5
	R5F565NE	R5F565N_D_2.pr5

When connecting to the MCU of "Bank Mode Select" different from the setting file, the following error is displayed.

Message display on the main unit: ERROR:023 Inv. Sig. addr.
FP6 Terminal: ERROR(E023): Connection or synchronisation failed.

The Bank Mode of the MCU is changed at the following timing.

- When MCU is reset after programming Bank Mode setting different from present condition to "Bank Mode Select".
- When MCU in the Dual Mode is reset after erasing with the Erase Options "Erase Chip".

How to change to the Dual Mode

1. Make the setting file for Linear Mode.
2. Erase with selecting "Configuration Clear after Erase".
3. Program the program file of only Option-Setting Memory area set to Dual Mode.
4. Reset MCU.

2.17 PR5-RH850F1X (RH850/F1K, RH850/F1KM), PR5-RH850P1X (RH850/P1x-C)

2.17.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.14 or later
Firmware for PG-FP5	V2.14 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

- In the case of RH850/P1x-C, it is not possible to write it by supplying power from the flash programmer to VDD terminal. Please supply power from the outside.
- In the case of RH850/P1x-C, it uses the 16MB (1 division) of the programming area.

2.18 PR5-78F8039 (UPD78F8032)

2.18.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V1.00 or later
Firmware for PG-FP5	V1.00 or later
FPGA for PG-FP5	V1 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
CSI10 (Internal oscillation circuit)	CSI-Internal-OSC	9.8kHz~2500kHz
UART6 (External clock/Programmer clock)	UART-EXCLK	115200Baud
UART6 (External oscillation circuit)	UART-X1-OSC	115200Baud

Supply oscillator setup

On Target check box	Supply origin ^{Note1}	Frequency	Multiply rate
Check box is selected	Internal oscillation circuit	Can't be changed	Can't be changed
	External clock/External oscillation circuit	2.0MHz ≤ f _x ≤ 20.0MHz ^{Note2}	
Check box isn't selected	Programmer clock		

Note1) Supply origin is changed by communication port of Device.

Note2) Please refer to the user's manual of a device for Operation Conditions.

2.19 PR5-70F3482 (V850E/Sx3-H)

2.19.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.01 or later
Firmware for PG-FP5	V2.01 or later
FPGA for PG-FP5	V2 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
UARTA0	UART-ch0	9600,19200,31250,38400,57600,76800,115200, 128000,153600,500000Baud
CSIB0	SIO-ch0 (70F3xxx_CSI0.pr5)	9.8kHz~5000kHz
CSIB0+HS	SIO-H/S (70F3xxx_CSI0.pr5)	9.8kHz~5000kHz
CSIB3	SIO-ch0 (70F3xxx_CSI3.pr5)	9.8kHz~5000kHz
CSIB3+HS	SIO-H/S (70F3xxx_CSI3.pr5)	9.8kHz~5000kHz

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected ^{Note1}	External oscillation circuit	$3.0\text{MHz} \leq f_x \leq 6.0\text{MHz}$ ^{Note2}	PLL mode 8.00
		$6.0\text{MHz} < f_x \leq 10.0\text{MHz}$ ^{Note2}	PLL mode 4.00

Note1) Please don't use programmer clock.

Note2) Please refer to the user's manual of a device for Operation Conditions.

2.20 PR5-70F3537 (V850E2/Dx4, V850E2/Dx4-H)

2.20.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.05 or later
Firmware for PG-FP5	V2.05 or later
FPGA for PG-FP5	V2 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR0	UART-ch0	115200,250000,500000,1MBaud
FLCS0	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	Note	Note

Note) Please refer to the user's manual of a device for Operation Conditions.

b. It is not possible to write it by supplying power from the flash programmer. Please supply power from the outside.

2.21 PR5-70F4012 (V850E2/Fx4), PR5-70F3545 (V850E2/Fx4-M)

2.21.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.05 or later
Firmware for PG-FP5	V2.05 or later
FPGA for PG-FP5	V2 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR0	UART-ch0	115200,250000,500000,1MBaud
FLCS0	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x = 4.0\text{MHz}$ <small>Note</small>	PLL mode 20.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ <small>Note</small>	PLL mode 16.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ <small>Note</small>	PLL mode 10.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ <small>Note</small>	PLL mode 5.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ <small>Note</small>	PLL mode 4.00

Note) Please refer to the user's manual of a device for Operation Conditions.

2.22 PR5-70F3592 (V850E2/Fx4-G)

2.22.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.07 or later
Firmware for PG-FP5	V2.07 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR0	UART-ch0	115200,250000,500000,1MBaud
FLCS0	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup (UPD70F3592)

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x=4.0\text{MHz}$ ^{Note}	PLL mode 20.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ ^{Note}	PLL mode 16.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ ^{Note}	PLL mode 10.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode 5.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ ^{Note}	PLL mode 4.00

Supply oscillator setup (Except UPD70F3592)

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x=4.0\text{MHz}$ ^{Note}	PLL mode 16.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ ^{Note}	PLL mode 9.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ ^{Note}	PLL mode 8.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode 4.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ ^{Note}	PLL mode 1.00

Note) Please refer to the user's manual of a device for Operation Conditions.

2.23 PR5-70F3585 (V850E2/Fx4-L)

2.23.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.07 or later
Firmware for PG-FP5	V2.07 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR0	UART-ch0	115200,250000,500000,1MBaud
FLCS0	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup (UPD70F3579, UPD70F3580, UPD70F3584, UPD70F3585)

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x=4.0\text{MHz}$ ^{Note}	PLL mode 16.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ ^{Note}	PLL mode 9.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ ^{Note}	PLL mode 8.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode 4.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ ^{Note}	PLL mode 1.00

Supply oscillator setup (Except UPD70F3579, UPD70F3580, UPD70F3584, UPD70F3585)

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x=4.0\text{MHz}$ ^{Note}	PLL mode 12.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ ^{Note}	PLL mode 9.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ ^{Note}	PLL mode 5.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ ^{Note}	PLL mode 2.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ ^{Note}	PLL mode 1.00

Note) Please refer to the user's manual of a device for Operation Conditions.

2.24 PR5-70F4155 (V850E2/Px4-L), PR5-70F4159 (V850E2/PG4-S)

2.24.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.07 or later
Firmware for PG-FP5	V2.07 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR	UART-ch0	115200,250000,500000,1MBaud
FLCS	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	Note	Note

Note) Depends on the operating conditions of the option byte settings. Please refer to the user's manual for the device.

2.25 PR5-70F4018 (V850E2/Sx4-H)

2.25.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.05 or later
Firmware for PG-FP5	V2.05 or later
FPGA for PG-FP5	V2 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
FLUR0	UART-ch0	115200,250000,500000,1MBaud
FLCS0	SIO-ch0	9.8kHz~5000kHz

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Check box is selected	External oscillation circuit	$f_x = 4.0\text{MHz}$ <small>Note</small>	PLL mode 40.00
		$4.0\text{MHz} < f_x \leq 5.0\text{MHz}$ <small>Note</small>	PLL mode 32.00
		$5.0\text{MHz} < f_x \leq 8.0\text{MHz}$ <small>Note</small>	PLL mode 20.00
		$8.0\text{MHz} < f_x \leq 16.0\text{MHz}$ <small>Note</small>	PLL mode 10.00
		$16.0\text{MHz} < f_x \leq 20.0\text{MHz}$ <small>Note</small>	PLL mode 8.00

Note) Please refer to the user's manual of a device for Operation Conditions.

2.26 PR5-R8C3X (R8C/3x), PR5-R8C5X (R8C/5x), PR5-R8CLX (R8C/Lx)

2.26.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.09 or later
Firmware for PG-FP5	V2.09 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Communication system setup

Communication port of Device	Port	Speed
Standard serial I/O mode 3	UART I/O mode3	9600,19200,38400,57600,115200,250000,500000Baud

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	Internal oscillation circuit	Can't be changed	Can't be changed

b. For the R8C/Lx, if microcontroller is programmed by $2.7V \leq VCC \leq 5.5V$, you must use the parameter file of R5F2LAXxx.pr5. The other parameter file of R5F2LAXxx_LV.pr5 is used by $1.8V \leq VCC < 2.7V$.

2.27 PR5-SH7250 (SH7253)

2.27.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup

On Target check box	Supply origin	Frequency	Multiply rate	Pin Setting
Can't be changed	External oscillation circuit	$16.0\text{MHz} \leq f_x \leq 20.0\text{MHz}$	PLL mode (CKM) 6.00 (CKP) 1.00	MD_CLK0: 0 MD_CLKP: 0
			PLL mode (CKM) 6.00 (CKP) 2.00	MD_CLK0: 0 MD_CLKP: 1
			PLL mode (CKM) 8.00 (CKP) 1.00	MD_CLK0: 1 MD_CLKP: 0
			PLL mode (CKM) 8.00 (CKP) 2.00	MD_CLK0: 1 MD_CLKP: 1

Communication system setup

Communication port of Device	Port	Speed
SCI_A	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

2.28 PR5-SH72AX (SH72Ax)

2.28.1 Correspondence version and notes of PG-FP5

1. Correspondence version

The correspondence of the version of this parameter file and PG-FP5 is as follows. Please use it in this combination.

Correspondence PG-FP5 version list

PG-FP5	Version
Programming GUI for PG-FP5	V2.11 or later
Firmware for PG-FP5	V2.11 or later
FPGA for PG-FP5	V4 or later

<Version confirmation>

- Programming GUI: Displayed by selecting [About FP5...] from the [Help] menu
- Firmware: Displayed by selecting [Reset] from the [Programmer] menu
- FPGA: Displayed by selecting [Reset] from the [Programmer] menu

2. Notes

a. Please set up programming GUI for PG-FP5 as follows.

Supply oscillator setup (SH72AW, SH72AY)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	fx=20.0MHz	PLL mode (CKM) 4.00 (CKP) 2.00

Supply oscillator setup (SH72A0)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	fx=8.0MHz, 10.0MHz	PLL mode (CKM) 8.00 (CKP) 4.00

Supply oscillator setup (SH72A2)

On Target check box	Supply origin	Frequency	Multiply rate
Can't be changed	External oscillation circuit	fx=8.0MHz, 10.0MHz	PLL mode (CKM) 10.00 (CKP) 5.00

Communication system setup

Communication port of Device	Port	Speed
SCI1	UART	By setting the frequency and Multiply rate, you can select the communication speed can be selected.

All trademarks and registered trademarks are the property of their respective owners.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
 6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics Corporation

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

Renesas Electronics America Inc.

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.
Tel: +1-408-432-8888, Fax: +1-408-434-5351

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3
Tel: +1-905-237-2004

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-651-700

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India
Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5338