

# Renesas e<sup>2</sup> studio

R20AN0495ES0100

Rev.1.00

## Smart Configurator Application Examples: Ethernet

Mar.27 ,2018

### Introduction

Smart Configurator (SC) is a GUI-based tool that has the functionalities of code generation and configuration for drivers, middleware and pins. SC generates suitable code for each Renesas MCU family and has the functionality to import code generated by FIT modules.

This application note guides user to use SC in the e<sup>2</sup> studio to configure ether component and generate codes. The following operating systems on the host computer are supported:

- Windows 7 32-bit / 64-bit
- Windows 8.1 32-bit / 64-bit
- Windows 10 32-bit / 64-bit

### Target Device

- RX64M Group
- RX65N Group

### Software Components

The Smart Configurator supports 2 types of software components: Code Generator (CG) and Firmware Integration Technology (FIT). Drivers and middleware supported by each software type are:

- Basic drivers: CG drivers (CMT, A/D Converter, SCI, etc.)  
FIT modules (CMT, DTC, DMAC, RSPI, SCIFA, etc.)
- Middleware: FIT modules (USB, Ethernet, Flash Memory (programming the on-chip flash memory), etc.)

The basic driver is a control program for peripheral functions of microcomputer such as CMT, A/D converter, SCI, etc. It is convenient to embed software component (CG driver) using code generation (CG) function.

In addition, FIT modules can be embedded for using middleware such as USB, Ethernet, and Flash memory (programming the on-chip flash memory) as software components.

List of abbreviations:

- CMT: Compare Match Timer
- DTC: Data Transfer Controller
- DMAC: Direct Memory Access Controller
- RSPI: Serial Peripheral Interface
- SCIFA: FIFO Embedded Serial Communications Interface

## Contents

<b>1. Overview .....</b>	<b>3</b>
1.1 Purpose.....	3
1.2 Operating Environment .....	3
1.3 Basic Operation Steps of Smart Configurator Project.....	4
1.4 Module Structure.....	5
1.5 Pin Setting for Ethernet Driver .....	6
1.6 Main Clock Source .....	7
<b>2. Application Example (Create an Ethernet Program Using Smart Configurator) .....</b>	<b>8</b>
2.1 Program Work Flowchart.....	8
2.2 Creating a Workspace.....	10
2.3 Creating a Project.....	10
2.4 Clock Settings .....	14
2.5 Adding Software Components .....	16
2.6 MCU Package .....	23
2.7 Generating Codes .....	24
2.8 Adding Source File Under src Folder .....	25
2.9 Adding Application Codes in main().....	28
<b>3. Verify Operation .....</b>	<b>30</b>
3.1 Marco Definition .....	30
3.2 Setting on Board and PC .....	32
3.3 Build and Debug Project.....	37
3.4 Echo Server Operation .....	41
3.5 Additional Debugging Assistance Tool (QE).....	42
<b>Website and Support .....</b>	<b>43</b>

## 1. Overview


### 1.1 Purpose

This document guides user to create an echo server program using ethernet FIT modules in Smart Configurator.

### 1.2 Operating Environment

<b>Target devices</b>	RX64M Group RX65N, RX651 Group
<b>Evaluation board</b>	Renesas Starter Kit+ for RX65N-2MB (RX65N R5F565NEDxFC)
<b>Debugger</b>	E1 /E2 Lite
<b>IDE</b>	e <sup>2</sup> studio v.6.2.0 or above
<b>Toolchains</b>	Renesas C/C++ compiler package for RX family

### 1.3 Basic Operation Steps of Smart Configurator Project




**Figure 1-1 Basic operation**

Refer to “Smart Configurator User Guide” document for detailed operations of Smart Configurator.

### 1.4 Module Structure

This section shows the structure of the FIT modules used by Echo Server sample. Application note that explains the usage of FIT module is available in the project tree under “doc” folder of each module. For example, Application Note for Ethernet Driver, R01AN2009, is located in \src\smc\_gen\r\_ether\_rx\doc folder.



**Figure 1-2 Module Structure**

Table 1-1 below shows FIT Module to be configured.

**Table 1-1 FIT Modules**

Type	Module	SC Software Component Name	Version
Middleware	T4 Library (TCP/IP for Embedded System M3S-T4-Tiny)	r_t4_rx	2.07
Interface	Interface Conversion Module for Ether Driver and Embedded System T4	r_t4_driver_rx	1.06
Device Driver	Ether Driver	r_ether_rx	1.14
Middleware	System Timer	r_sys_time_rx	1.00
Device Driver	CMT Driver (Compare Match Timer)	r_cmt_rx	3.10
BSP	BSP (Board Support Package)	r_bsp	3.60

### 1.5 Pin Setting for Ethernet Driver

The MII Ethernet control mode is used in this Ethernet application example. An extract from Application Note for Ethernet module using FIT (R01AN2009EJ0114 - located in \src\smc\_gen\r\_ether\_rx(doc) is shown below.

Case of Using MII Mode	Case of Using RMII Mode
ET0_TX_CLK	
ET0_RX_CLK	REF50CK0
ET0_TX_EN	RMII0_TXD_EN
ET0_ETXD3	
ET0_ETXD2	
ET0_ETXD1	RMII0_TXD1
ET0_ETXD0	RMII0_TXD0
ET0_TX_ER	
ET0_RX_DV	
ET0_ERXD3	
ET0_ERXD2	
ET0_ERXD1	RMII0_RXD1
ET0_ERXD0	RMII0_RXD0
ET0_RX_ER	RMII0_RX_ER
ET0_CRS	RMII0_CRS_DV
ET0_COL	
ET0_MDC	
ET0_MDIO	
ET0_LINKSTA *1	
ET0_EXOUT *2	
ET0_WOL *2	

Notes: 1. Setting is not required if the setting of #define ETHER\_CFG\_USE\_LINKSTA is 0.  
 Notes: 2. Setting is not required because these pin are not used in Ethernet FIT module.

Figure 1-3 Pin Usage in MII Ethernet Control Mode

The schematic taken from Renesas Starter Kit+ for RX65N-2MB below shows the corresponding pins.




Figure 1-4 MII Ethernet physical pin assignment in Renesas Starter Kit+ for RX65N-2MB


In summary, configure the pins for Renesas Starter Kit+ for RX65N-2MB to operate in MII Ethernet control mode as shown in Table 1-2. This pin assignment will be configured in [Chapter 2.5](#) on component pin setting.

**Table 1-2 Pin Assignment**

Function	Port Assignment	Pin Number
ET0_COL	PC7	76
ET0_CRS	P83	74
ET0_ERXD0	P75	87
ET0_ERXD1	P74	88
ET0_ERXD2	PC1	89
ET0_ERXD3	PC0	91
ET0_ETXD0	P81	80
ET0_ETXD1	P82	79
ET0_ETXD2	PC5	78
ET0_ETXD3	PC6	77
ET0_LINKSTA	P34	27
ET0_MDC	P72	101
ET0_MDIO	P71	102
ET0_RX_CLK	P76	85
ET0_RX_DV	PC2	86
ET0_RX_ER	P77	84
ET0_TX_CLK	PC4	82
ET0_TX_EN	P80	81
ET0_TX_ER	PC3	83

**1.6 Main Clock Source**

Based on the schematic below, RX65N main clock is connected to a 24MHz crystal resonator. This clock will be configured as main clock source in [Chapter 3.3](#) on debug configuration setting.



**Figure 1-5 Schematic Diagram of Renesas Starter Kit+ for RX65N-2MB**

## 2. Application Example (Create an Ethernet Program Using Smart Configurator)

### 2.1 Program Work Flowchart

The program flowchart is shown as below:

a) Main function:




Figure 2-1 Main Flowchart



b) Echo function:




Figure 2-2 Echo Function Flowchart

## 2.2 Creating a Workspace

- 1) Start e<sup>2</sup> studio from Windows® Start Menu. Use default workspace folder and click [OK].




Figure 2-3 Workspace Launcher

## 2.3 Creating a Project

- 1) Create a new C project in e<sup>2</sup> studio.  
Go to [File] → [New] → [C/C++ Project] to start new project generation




Figure 2-4 Creating Project from File Menu

- 2) Select [Renesas RX] → [Renesas CC-RX C/C++ Executable Project] → [Next]




Figure 2-5 Creating Project from File Menu

- 3) Give an appropriate name to the project, for example “Smart\_Configurator\_Example” → [Next]




Figure 2-6 Creating Project from File Menu

- 4) Select "C" as Language
- 5) Select "Renesas CCRX" as Toolchain
- 6) Select Toolchain Version, e.g. "v2.08.00"
- 7) Select Target Device accordingly:  
 For RX65N-2MB, select "RX600 > RX65N > RX65N - 176pin > R5F565NEDxFC"  
 For RX64M, select "RX600 > RX64M > RX64M - 176pin > R5F564MLCxFC"
- 8) Ensure [Create Hardware Debug Configuration] is ticked. Select emulator, e.g. "E1 (RX)".
- 9) Click [Next]




Figure 2-7 C Project - Target Specific Settings Example with E1 Emulator

- 10) In the “Select Coding Assistant settings” dialog, select the checkbox of “Smart Configurator”
- 11) Click [Finish]




Figure 2-8 Select Coding Assistant Tool

## 2.4 Clock Settings

Smart Configurator perspective will be launched as shown below.

- 1) In Smart\_Configurator\_Example.scfg pane, click the [Clocks] page




Figure 2-9 Smart Configurator Perspective

- 2) Since a 24MHz crystal resonator is connected to main clock of RX65N (refer to chapter 1.6), check to confirm that the main clock frequency is set to 24 MHz. Keep the other clock settings as default.




Figure 2-10 Clock Configuration in Smart Configurator

## 2.5 Adding Software Components

- 1) In Smart\_Configurator\_Example.scfg pane, click the [Components] page




Figure 2-11 Smart Configurator Perspective


- 2) Click  to add new component.



Figure 2-12 Software Component Configuration in Smart Configurator



- 3) Add FIT modules into the project
  - a. Navigate the component list and select *r\_cmt\_rx* module
  - b. Press and hold Ctrl key, click on *following* modules:
    - r\_ether\_rx*
    - r\_sys\_time\_rx*
    - r\_t4\_driver\_rx*
    - r\_t4\_rx*
 Note: If above drivers are not available in the list, click [Download more software components] to download the FIT modules.
  - c. Click [Finish]




Figure 2-13 Select Software Component

4) New software components are shown in the [Components] page.




Figure 2-14 Software Component Configuration in Smart Configurator

- 5) In the [Components] page,
  - a. select `r_t4_rx`
  - b. set the following settings under ‘Configurations’
 

Channel number your system has.	1
Enable/Disable DHCP Function.	0
SYSTEM callback function use	0

Note: These settings can be found in “config\_tcpudp.c” file in `\src\smc_gen\r_t4_rx\src` folder after generating codes.




Figure 2-15 Components Setting

- 6) In the [Components] page,
  - a. select `r_ether_rx`
  - b. set the following settings under ‘Configurations’
 

Ethernet interface	MII
PHY-LSI address setting for ETHER 0	30 (For RSK+ 65N-2MB) 0 (For RSK+ 64M)
PHY-LSI address setting for ETHER 1	1
The register bus of PHY0 for ETHER0/1	Use ETHER0
The register bus of PHY1 for ETHER0/1	Use ETHER1

Note: These settings can be found in “`r_ether_rx_config.h`” file in `\src\smc_gen\r_config` folder after generating codes.




Figure 2-16 Ethernet Pin Setting

- 7) In the [Components] page,
  - a. select *r\_ether\_rx*
  - b. Under “Resources”, click the checkboxes for the resources as shown in the picture below. These selected resources are used in this example code





Figure 2-17 Ethernet Pin Setting

8) At [Pins] page, click  button to switch tree to Software Components view




Figure 2-18 Pins page

- 9) At the tree, click *r\_ether\_rx* to view pin configurations
- 10) Ensure following functions were assigned to corresponding pins (as explained in chapter 1.5):  
e.g. Check enable flag and change assignment of Function “ET0\_CRS” from PB7(default) to P83




Figure 2-19 Pin configuration of r\_ether\_rx

## 2.6 MCU Package

After completing all pin configurations, the MCU package view also updated the pin assignment automatically as shown in picture below.




Figure 2-20 Pin Assignment in MCU Package

## 2.7 Generating Codes

- 1) Click  to generate codes



Figure 2-21 Generate codes

- 2) Message 'Code generation is successful' will be shown at Console
- 3) Files generated into \src\smc\_gen folder of the project




Figure 2-22 Successful Code Generation



## 2.8 Adding Source File Under src Folder

- 1) At Project Explore tree, right click [src] folder, select [New] → [Source file]




Figure 2-23 Adding Source File

- 2) Input header file name (e.g. *echo\_srv.c*), click [Finish]




Figure 2-24 Adding Source File

- 3) Open “*echo\_srv.c*” file in \src folder  
Add below codes in “*echo\_srv.c*” for this application example:

```
#include "r_t4_itcpip.h"
/*****
Macro definitions
*****/
/* Size of Ethernet receive buffer, refer to tcp_ccep[].rbufsz */
#define BUFFER_SIZE          (1460)

/*****echo server main function*****/
void echo_srv(void)
{
    ID          cepid=1; /*ID of a TCP communication end point ("1"~ "30") */
    ID          repid=1; /*ID of a TCP reception point ("1"~ "30") */
    T_IPV4EP    dst_addr; /*destination IP address (PC)*/
    UB          rcv_buf[BUFFER_SIZE ];/*receive buffer*/
    ER          ercd;/*error code*/

    /* Make one TCP connection on Ethernet channel.
    Ethernet 0: 192.168.0.3 - Port: 1024 (refer to config_tcpudp.c)*/

    while (1)
    {
        /* TCP connection open */
        ercd = tcp_acp_cep(cepid, repid, &dst_addr, TMO_FEVR);

        if(E_OK == ercd)
        {
            /* process of echo server */
            while(1)
            {
                /* TCP receive data */
                ercd = tcp_rcv_dat(cepid, rcv_buf, sizeof(rcv_buf), TMO_FEVR);
                if(ercd <= 0)
                {
                    break;
                }

                /* TCP transmit echo data back */
                ercd = tcp_snd_dat(cepid, rcv_buf, ercd, TMO_FEVR);
                if(ercd < 0)
                {
                    break;
                }
            }

            /* Close TCP connection */
            tcp_sht_cep(cepid); /*TCP transmission shutdown */
            tcp_cls_cep(cepid, TMO_FEVR);/*TCP connection disconnect */
        }
    }
} /* End of function echo_srv */
```

Your source file should look like this:

```

* echo_srv.c
#include "r_t4_itcpip.h"
/*****
Macro definitions
*****/
/* Size of Ethernet receive buffer, refer to tcp_ccep[].rbufsz */
#define BUFFER_SIZE (1460)
/*****echo server main function*****/
void echo_srv(void)
{
    ID      cepid=1; /*ID of a TCP communication end point ("1"~ "30") */
    ID      repid=1; /*ID of a TCP reception point ("1"~ "30") */
    T_IPV4EP dst_addr; /*destination IP address (PC)*/
    UB      rcv_buf[BUFFER_SIZE ];/*receive buffer*/
    ER      ercd;/*error code*/
    /* Make one TCP connection on Ethernet channel.
    Ethernet 0: 192.168.0.3 - Port: 1024 (refer to config_tcpudp.c)*/
    while (1)
    {
        /* TCP connection open */
        ercd = tcp_acp_cep(cepid, repid, &dst_addr, TMO_FEVR);
        if(E_OK == ercd)
        {
            /* process of echo server */
            while(1)
            {
                /* TCP receive data */
                ercd = tcp_rcv_dat(cepid, rcv_buf, sizeof(rcv_buf), TMO_FEVR);
                if(ercd <= 0)
                {
                    break;
                }

                /* TCP transmit echo data back */
                ercd = tcp_snd_dat(cepid, rcv_buf, ercd, TMO_FEVR);
                if(ercd < 0)
                {
                    break;
                }
            }

            /* Close TCP connection */
            tcp_sht_cep(cepid); /*TCP transmission shutdown */
            tcp_cls_cep(cepid, TMO_FEVR);/*TCP connection disconnect */
        }
    }
} /* End of function echo_srv */

```

Figure 2-25 echo\_srv.c

## 2.9 Adding Application Codes in main()

- 1) In Smart\_Configurator\_Example.c, add/overwrite below codes after code line [#include "r\_smc\_entry.h"]

```

#include <string.h>
#include "r_t4_itcpip.h"
#include "r_sys_time_rx_if.h"

/*****
Macro definitions
*****/
/* T4 work memory area size is 4.5 KB, refer to application note R20AN0051EJ0206 */
#define T4_WORK_SIZE (4608)
/*****
Private global variables and functions
*****/
static UW tcpudp_work[T4_WORK_SIZE / sizeof(UW) + 1];

/*****
Imported global variables and functions (from other files)
*****/
extern void echo_srv(void);
extern void R_ETHER_PinSet_ETHERC0_MII();
void main(void)
{
    ER ercd; /*error code*/

    sys_time_err_t systime_ercd; /*system time error code*/
    char ver[128];

    /* Initializes pins for r_ether_rx module */
    R_ETHER_PinSet_ETHERC0_MII();

    /* Get the version of T4 */
    strcpy(ver, (char*)R_t4_version.library);

    /* start system time */
    systime_ercd = R_SYS_TIME_Open();
    if (systime_ercd != SYS_TIME_SUCCESS)
    {
        while (1);
    }

    /* start LAN controller */
    ercd = lan_open();
    if (ercd != E_OK)
    {
        while (1)
        {
            /* Cannot open LAN controller */
        };
    }

    /* Initialize the TCP/IP */
    ercd = tcpudp_open(tcpudp_work);
    if (ercd != E_OK)
    {
        while (1)
        {
            /* Cannot open TCP/IP */
        };
    }

    /* start echo server */
    echo_srv();

    /* end TCP/IP */
    tcpudp_close();
    lan_close();
    R_SYS_TIME_Close();
}/* End of function main() */

```

Your source file should look like this:

```

#include "r_smc_entry.h"

#include <string.h>
#include "r_t4_itcpip.h"
#include "r_sys_time_rx_if.h"

/*****
Macro definitions
*****/
/* T4 work memory area size is 4.5 KB, refer to application note R20AN0051EJ0206 */
#define T4_WORK_SIZE (4606)
/*****
Private global variables and functions
*****/
static UW tcpudp_work[T4_WORK_SIZE / sizeof(UW) + 1];

/*****
Imported global variables and functions (from other files)
*****/
extern void echo_srv(void);
extern void R_ETHER_PinSet_ETHERC0_MII();
void main(void)
{
    ER ercd; /*error code*/
    sys_time_err_t systime_ercd; /*system time error code*/
    char ver[128];

    /* Initializes pins for r_ether_rx module */
    R_ETHER_PinSet_ETHERC0_MII();

    /* Get the version of T4 */
    strcpy(ver, (char*)R_t4_version.library);

    /* start system time */
    systime_ercd = R_SYS_TIME_Open();
    if (systime_ercd != SYS_TIME_SUCCESS)
    {
        while (1);
    }

    /* start LAN controller */
    ercd = lan_open();
    if (ercd != E_OK)
    {
        while (1)
        {
            /* Cannot open LAN controller */
        };
    }

    /* Initialize the TCP/IP */
    ercd = tcpudp_open(tcpudp_work);
    if (ercd != E_OK)
    {
        while (1)
        {
            /* Cannot open TCP/IP */
        };
    }

    /* start echo server */
    echo_srv();

    /* end TCP/IP */
    tcpudp_close();
    lan_close();
    R_SYS_TIME_Close();
}/* End of function main() */

```

Figure 2-26 main.c

### 3. Verify Operation

#### 3.1 Marco Definition

- 1) Right click [Smart\_Configurator\_Example] in Project Explorer, click [Properties]





Figure 3-1 Open Properties

- 2) Under properties window:
  - a. Click [C/C++ Build] → [Settings]
  - b. Under [Tool Settings] tab, select [Compiler] → [Source]
  - c. Click  button at [Macro definition] window
  - d. At the pop up window, enter ‘\_\_RX’
  - e. Click [OK] to close [Enter Value] window
  - f. Click [OK] to confirm all settings




Figure 3-2 Modify Properties

### 3.2 Setting on Board and PC

- 1) Ensure hardware of target board is setup according to Table 3-1 below.

**Table 3-1 Setting on Board**

Function	Configuration	
	RSK+ RX65N-2MB	RSK+ RX64M
LAN cable	ETHERNET socket	ETHERNET0 socket
MII Mode	J8: Open (do not connect)	-
ET0LINKSTA	-	SW6.5: ON; SW6.6: OFF
ET0MDIO	-	J3: Pin1-2
ET0MDC	-	J4: Pin1-2
ET0ERXD1	-	SW6.7: ON; SW6.8: OFF
ET0RXCLK	-	J10: Pin1-2; R48 soldered; R57 not soldered
ET0RXER	-	SW6.9: ON; SW6.10: OFF
ET0TXEN	-	SW7.1: ON; SW7.2: OFF; SW7.3: OFF
ET0ETXD0	-	SW7.4: ON; SW7.5: OFF; SW7.6: OFF
ET0ETXD1	-	SW7.7: ON; SW7.8: OFF
ET0CRS	-	SW7.9: ON; SW7.10: OFF
ET0ERXD3	-	J11: Pin2-3; SW5.1: ON
ET0ERXD2	-	SW5.2: ON; SW5.3: OFF
ET0RXDV	-	SW5.4: ON; SW5.5: OFF
ET0TXER	-	SW5.6: ON; SW5.7: OFF; SW5.8: OFF
ET0TXCLK	-	SW5.9: ON; SW5.10: OFF
ET0ETXD2	-	J13: Pin2-3; SW6.1: ON
ET0ETXD3	-	J14: Pin2-3; SW6.2: ON
ET0COL	-	J12: Pin2-3; SW6.3: ON; SW6.4: OFF



- 2) Connect the target board to PC
  - a. Connect RSK+ RX65N-2MB board to E1/ E2 Lite emulator and connect the E1/ E2 Lite emulator to PC
  - b. Use 1 LAN cable (cross or straight) to connect RSK+ RX65N 2MB board to PC




Figure 3-3 Connection between PC and RSK+ RX65N 2MB

- 3) Set IP address on PC
  - a. In Windows 10 OS environment, under [Network & Internet] setting,
    - (a.1) Click [Proxy] to open setup page
    - (a.2) Ensure that [Manual proxy setup] is set to off.




Figure 3-4 Setting IP address on PC

- b. Under [Network & Internet] setting:
  - (b.1) Click [Ethernet] to open setup page
  - (b.2) Click [Change adapter options]
  - (b.3) In the pop up window, right click the 'Ethernet' and select [Properties]




Figure 3-5 Setting IP address on PC

- c. In the pop up window:
  - (c.1) Select [Internet Protocol Version 4 (TCP/IPv4)]
  - (c.2) Click [Properties]




Figure 3-6 Setting IP address on PC

- d. In the pop up window:
- (d.1) Select button for [Use the following IP address] and set the following:  
IP address: 192.168.0.100  
(192.168.0.x in which x = 1~254 except 3, to avoid conflict with IP address of the target board)  
Subnet mask: 255.255.255.0
  - (d.2) Select button for [Use the following DNS server address]
  - (d.3) Click [OK] for confirm the settings for the TCP/IPv4 properties.




Figure 3-7 Setting IP address on PC

- 4) Enable “Telnet Client” on PC
  - In Windows 10 OS environment, under [Programs & Features] setting,
    - a. Click [Turn Windows features on or off] to open setup page
    - b. Tick the checkbox for [Telnet Client] in the pop up window
    - c. Click [OK] to confirm the settings.




Figure 3-8 Enable “Telnet Client” on PC

### 3.3 Build and Debug Project

- 1) Build the project, click [Project] → [Build Project]





Figure 3-9 Build Project

- 2) Debug the code

[Run] → [Debug Configurations...] or the downward arrow by the side of  icon → [Debug Configurations...]




Figure 3-10 Open Debug Configurations Window

- 3) Expand [Renesas GDB Hardware Debugging] and click on [Smart\_Configurator\_Example\_HardwareDebug]. Click on the [Debugger] tab, click on [Connection Settings] tab and set the following settings:
  - a. Debug Hardware: Select E1 (RX) or E2 Lite (RX)  
Target Device: R5F565NE (For RSK+65N-2MB)  
R5F564ML (For RSK+64M)
  - b. Main Clock Source: EXTAL
  - c. Extal Frequency[MHz]: 24MHz
  - d. Permit Clock Source Change On Writing Internal Flash: Yes
  - e. Power Target From The Emulator (MAX 200mA): Yes




Figure 3-11 Debug Configurations Example When Connecting to E1 Emulator

- 4) Click on the Startup tab, uncheck “Set breakpoint at: main”
- 5) Click [Debug] to start debugging.







Figure 3-12 Remove Breakpoint at Main


- 6) 'Confirm Perspective Switch' dialog may pop up, click [Yes] to continue.
- 7) Click  to start project execution




**Figure 3-13 Start Execution**


The following are information on how to suspend and stop the program in debug window. Do not execute it now.

- 1) To suspend the program execution, click suspend button 



**Figure 3-14 Suspend Execution**

- 2) To stop the program execution, click disconnect button  to end debug session.




**Figure 3-15 Stop Debug**



### 3.4 Echo Server Operation

- 1) Open [Command Prompt] terminal in Windows OS environment
  - a. Enter command: 'Ping 192.168.0.3'
  - b. Reply from target board (192.168.0.3) can be observed. This indicates that the Ethernet connection between the board and PC is successful.



```
Microsoft Windows [Version 10.0.14393]
(c) 2016 Microsoft Corporation. All rights reserved.

C:\WINDOWS\System32>ping 192.168.0.3


Pinging 192.168.0.3 with 32 bytes of data:
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80

Ping statistics for 192.168.0.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\WINDOWS\System32>
```

Figure 3-16 Command Prompt

- 2) Next, enter command: 'telnet 192.168.0.3 1024'



```
Microsoft Windows [Version 10.0.14393]
(c) 2016 Microsoft Corporation. All rights reserved.

C:\WINDOWS\System32>ping 192.168.0.3

Pinging 192.168.0.3 with 32 bytes of data:
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80
Reply from 192.168.0.3: bytes=32 time<lms TTL=80

Ping statistics for 192.168.0.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\WINDOWS\System32>telnet 192.168.0.3 1024
```

Figure 3-17 Command Prompt

- 3) In the pop up window [Telnet 192.168.0.3] :
  - a. Enter any characters and observed the echo back messages




Figure 3-18 Telnet 192.168.0.3

### 3.5 Additional Debugging Assistance Tool (QE)

Renesas has a range of Quick and Effective Tool Solutions (QEs) as development tools for particular applications to assist and improve efficiency during development. Specific to this example of integrating TCP/IP function, QE for TCP/IP is recommended as it has several features to assist in debugging application based on TCP/IP function. Please refer to the following link for more information on QE and the type of supported applications for Renesas IDE:

QE:

<https://www.renesas.com/qe>

QE for TCP/IP:

<https://www.renesas.com/qe-tcpip>

## Website and Support

- Renesas Electronics Website  
<http://www.renesas.com/>
- Inquiries  
<http://www.renesas.com/contact/>

All trademarks and registered trademarks are the property of their respective owners.

**Revision History**

<b>Rev.</b>	<b>Date</b>	<b>Description</b>	
		<b>Page</b>	<b>Summary</b>
1.00	Mar. 27, 2018	-	First edition issued

## General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

### 1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

### 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

### 3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

### 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

### 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

- The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.  
Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment, etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.  
(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.  
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)



### SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

#### Renesas Electronics America Inc.

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.  
Tel: +1-408-432-8888, Fax: +1-408-434-5351

#### Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3  
Tel: +1-905-237-2004

#### Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.  
Tel: +44-1628-651-700, Fax: +44-1628-651-804

#### Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

#### Renesas Electronics (China) Co., Ltd.

Room 1709 Quantum Plaza, No.27 ZhichunLu, Haidian District, Beijing, 100191 P. R. China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

#### Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, 200333 P. R. China  
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

#### Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2265-6688, Fax: +852 2886-9022

#### Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan  
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

#### Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

#### Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

#### Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India  
Tel: +91-80-67208700, Fax: +91-80-67208777

#### Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5338