

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.

8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

To all our customers

Regarding the change of names mentioned in the document, such as Hitachi Electric and Hitachi XX, to Renesas Technology Corp.

The semiconductor operations of Mitsubishi Electric and Hitachi were transferred to Renesas Technology Corporation on April 1st 2003. These operations include microcomputer, logic, analog and discrete devices, and memory chips other than DRAMs (flash memory, SRAMs etc.) Accordingly, although Hitachi, Hitachi, Ltd., Hitachi Semiconductors, and other Hitachi brand names are mentioned in the document, these names have in fact all been changed to Renesas Technology Corp. Thank you for your understanding. Except for our corporate trademark, logo and corporate statement, no changes whatsoever have been made to the contents of the document, and these changes do not constitute any alteration to the contents of the document itself.

Renesas Technology Home Page: <http://www.renesas.com>

Renesas Technology Corp.
Customer Support Dept.
April 1, 2003

SH7410 E8000
Debugging Interface
HS7410D8IW2S
User's Manual

Renesas Microcomputer
Development Environment
System

Cautions

1. Hitachi neither warrants nor grants licenses of any rights of Hitachi's or any third party's patent, copyright, trademark, or other intellectual property rights for information contained in this document. Hitachi bears no responsibility for problems that may arise with third party's rights, including intellectual property rights, in connection with use of the information contained in this document.
2. Products and product specifications may be subject to change without notice. Confirm that you have received the latest product standards or specifications before final design, purchase or use.
3. Hitachi makes every attempt to ensure that its products are of high quality and reliability. However, contact Hitachi's sales office before using the product in an application that demands especially high quality and reliability or where its failure or malfunction may directly threaten human life or cause risk of bodily injury, such as aerospace, aeronautics, nuclear power, combustion control, transportation, traffic, safety equipment or medical equipment for life support.
4. Design your application so that the product is used within the ranges guaranteed by Hitachi particularly for maximum rating, operating supply voltage range, heat radiation characteristics, installation conditions and other characteristics. Hitachi bears no responsibility for failure or damage when used beyond the guaranteed ranges. Even within the guaranteed ranges, consider normally foreseeable failure rates or failure modes in semiconductor devices and employ systemic measures such as fail-safes, so that the equipment incorporating Hitachi product does not cause bodily injury, fire or other consequential damage due to operation of the Hitachi product.
5. This product is not designed to be radiation resistant.
6. No one is permitted to reproduce or duplicate, in any form, the whole or part of this document without written approval from Hitachi.
7. Contact Hitachi's sales office for any questions regarding this document or Hitachi semiconductor products.

IMPORTANT INFORMATION

READ FIRST

- **READ** this user's manual before using this emulator product.
- **KEEP** the user's manual handy for future reference.

Do not attempt to use the emulator product until you fully understand its mechanism.

DEFINITION OF SIGNAL WORDS

CAUTION indicates a hazardous situation which, **if not avoided**, may result in **minor or moderate injury** to you or other people, or may result in **damage to the machine** or **loss of the user program**. It may also be used to alert against unsafe usage.

NOTE emphasizes essential information.

Preface

The SH7410 E8000 Hitachi Debugging Interface (referred to as the HDI) is a software tool that supports program development and debugging on a host computer by using an emulator for the Hitachi microprocessor SH7410 (referred to as the E8000 emulator).

This user's manual is a separate volume to the Hitachi Debugging Interface User's Manual, and describes the HDI functions and its usage. Read this manual and the following manuals before using the HDI.

For details on the E8000 emulator,

- E8000 SH7410 Emulator User's Manual
- Description Notes on Using the IBM PC Interface Board
- SH7410 E8000 Emulator Diagnostic Program Manual

For details on the related software manuals,

- Hitachi Debugging Interface User's Manual
- SH Series C Compiler User's Manual
- SH Series Cross Assembler User's Manual
- H Series Linkage Editor Librarian, Object Converter User's Manual

For details on the SH7410-series microprocessor,

- SH7410 Hardware Manual
- SH7410 Programming Manual

The HDI installation disks are 1.44-MB-formatted by the IBM PC. Refer to manuals for the host computer to be connected and the operating system being used, and prepare backups to other floppy disks. Install or copy the HDI disks after the backup has been completed. Administer the master floppy disks.

Refer to section 2, Installation, for details on HDI installation.

- Notes:
1. Windows is a registered trademark of Microsoft Corporation.
 2. IBM PC is a registered trademark of International Business Machines Corporation.
 3. Pentium is a registered trademark of Intel Corporation.

Contents

Section 1	Overview	1
1.1	Overview	1
1.1.1	Features	1
1.2	Operating Environment	2
Section 2	Installation	3
2.1	Installation Procedures	3
2.1.1	Setting up the E8000 Emulator	3
2.1.2	Installing the PC Interface Board	3
2.1.3	Installing the HDI Software	5
2.2	Checking the System	13
2.3	Troubleshooting	15
Section 3	Tutorial	17
3.1	Introduction	17
3.2	Running HDI	18
3.3	Selecting the Target Platform	19
3.4	Setting up the E8000 Emulator	21
3.4.1	Setting the [Configuration] Dialog Box	22
3.4.2	Setting the Memory Map	24
3.5	Downloading the Tutorial Program	26
3.5.1	Downloading the Tutorial Program	26
3.5.2	Displaying the Source Program	28
3.6	Setting the Software Breakpoint	30
3.7	Setting Registers	31
3.7.1	Setting the Program Counter	32
3.7.2	Setting the Stack Pointer	34
3.8	Executing the Program	35
3.9	Reviewing Breakpoints	37
3.10	Viewing Memory	38
3.11	Watching Variables	40
3.12	Stepping Through a Program	45
3.12.1	Executing [Step In] Command	46
3.12.2	Executing [Step Out] Command	48
3.12.3	Executing [Step Over] Command	50
3.13	Displaying Local Variables	52
3.14	Setting the Hardware Break Condition	53
3.15	Setting the Sequential Break Condition	61
3.16	Using the Trace Buffer	69

3.16.1	Displaying the Trace Buffer.....	69
3.16.2	Setting the Trace Filter.....	70
3.17	Trace Acquisition Condition Setting.....	75
3.18	Saving the Session	83
3.19	What Next?	84

Section 4 Descriptions of Windows 85

4.1	SH7410 E8000 HDI Windows.....	85
4.2	Descriptions of Each Window	89
4.2.1	[Configuration] Dialog Box.....	90
4.2.2	[Breakpoints] Window.....	98
4.2.3	[Break] Dialog Box.....	100
4.2.4	[Break Point] Dialog Box	114
4.2.5	[Break Point Sequence] Dialog Box	116
4.2.6	[Break Condition A] Dialog Box	118
4.2.7	[Break Condition B] Dialog Box	120
4.2.8	[Break Condition C] Dialog Box	122
4.2.9	[Break Condition Sequence] Dialog Box.....	124
4.2.10	[Break Condition] Dialog Box Pages.....	126
4.2.11	[Break Condition UBC] Dialog Box.....	143
4.2.12	[Break Condition UBC] Dialog Box Pages	145
4.2.13	[Memory Mapping] Window	154
4.2.14	[Edit Memory Mapping] Dialog Box.....	156
4.2.15	[Trace] Window.....	158
4.2.16	[Trace Acquisition] Dialog Box.....	161
4.2.17	[Trace Condition A] Dialog Box	171
4.2.18	[Trace Condition B] Dialog Box.....	173
4.2.19	[Trace Condition C] Dialog Box.....	175
4.2.20	[Trace Condition Sequence] Dialog Box	177
4.2.21	[Trace Condition] Dialog Box Pages	179
4.2.22	[Trace Filter] Dialog Box.....	199
4.2.23	[Trace Find] Dialog Box.....	201
4.2.24	[Trace Filter] and [Trace Find] Dialog Box Pages.....	203

Section 5 Command-line Function 219

5.1	Table and Symbol Description.....	219
5.1.1	Format.....	220
5.1.2	Parameter Input.....	221
5.1.3	Example	222
5.2	Command Descriptions.....	223
5.2.1	BKGRND_INT: BI.....	226
5.2.2	BREAKCONDITION_CLEAR: BCC.....	227
5.2.3	BREAKCONDITION_DISPLAY: BCD.....	228

5.2.4	BREAKCONDITION_ENABLE: BCE	230
5.2.5	BREAKCONDITION_SET: BCS	231
5.2.6	BREAKSEQUENCE_CLEAR: BSC	236
5.2.7	BREAKSEQUENCE_DISPLAY: BSD	237
5.2.8	BREAKSEQUENCE_ENABLE: BSE	238
5.2.9	BREAKSEQUENCE_SET: BSS	239
5.2.10	BREAKPOINT: BP	240
5.2.11	BREAKPOINT_CLEAR: BC	241
5.2.12	BREAKPOINT_DISPLAY: BD	242
5.2.13	BREAKPOINT_ENABLE: BE	243
5.2.14	CLOCK: CK	244
5.2.15	DEVICE_TYPE: DE	245
5.2.16	END: END	246
5.2.17	EXECUTION_MODE: EM	247
5.2.18	GO_OPTION: GP	251
5.2.19	ID: ID	254
5.2.20	MAP_SET: MS	255
5.2.21	MODE: MO	256
5.2.22	MOVE_TO_RAM: MR	257
5.2.23	PERFORMANCE_ANALYSIS: PA	258
5.2.24	PERFORMANCE_CLEAR: PC	261
5.2.25	PERFORMANCE_SET: PS	262
5.2.26	STATUS: STS	265
5.2.27	TRACEACQUISITION_CLEAR: TAC	267
5.2.28	TRACEACQUISITION_DISPLAY: TAD	268
5.2.29	TRACEACQUISITION_SET: TAS	270
5.2.30	TRACE_DISPLAY: TD	275
5.2.31	TRACE_MODE: TM	276
5.2.32	TRACE_SEARCH: TS	278
5.2.33	UBC_CLEAR: UBC	282
5.2.34	UBC_DISPLAY: UBD	283
5.2.35	UBC_ENABLE: UBE	284
5.2.36	UBC_SET: UBS	285
Section 6 Use of Diagnostic Program		289
6.1	Diagnostic Program Operation	289
6.1.1	Diagnostic Program Installation on the HDI	290
6.1.2	TARGET.INI File Setting	291
6.1.3	Diagnostic Program Start-Up	292
6.1.4	Diagnostic Program Termination	295
Section 7 Error Messages		297
7.1	Error Messages	297

Section 1 Overview

1.1 Overview

The SH7410 E8000 Hitachi Debugging Interface (referred to as the HDI) promotes efficient debugging of programs written in C or assembly language in the environment using the E8000 emulator for the SH7410 microprocessor.

1.1.1 Features

- High-speed downloading of load module files.
- A comprehensive set of break functions, trace conditions, and functions to set or edit memory maps are enabled by the HDI windows.
- Large-capacity trace information can be displayed (a maximum of 64-k bus cycles are displayed on the window).
- Command line functions (command system for the SH7410 E8000 HDI).

1.2 Operating Environment

The HDI is provided on two 3.5-inch floppy disks. The following shows the acceptable operating environments:

Table 1.1 Operating Environments

Item	Operating Environment
Host computer	Built-in Pentium or higher-performance CPU (166 MHz or higher recommended); IBM PC or compatible with an ISA bus.
OS	Windows95 or MS-DOS that runs Windows3.1.
Windows	Windows3.1 or Windows95.
Minimum memory capacity	32 Mbytes or more (twice the load module size recommended).
Display	Connectable to the host computer; color or monochrome display compatible with Windows (above VGA resolution recommended).
Hard-disk capacity	Installation disk capacity: 5 Mbytes or more. Prepare an area at least double the memory capacity (four-times or more recommended) as the swap area.
Mouse	Connectable to the host computer; compatible with Windows3.1 or Windows95.

Section 2 Installation

2.1 Installation Procedures

The installation procedures for the HDI are described below.

2.1.1 Setting up the E8000 Emulator

Set up the E8000 emulator. For details, refer to the SH7410 E8000 Emulator User's Manual.

2.1.2 Installing the PC Interface Board

The HDI communicates with the E8000 emulator using the dedicated PC interface board. The PC interface board should be inserted into an unused expansion slot of the IBM PC.

A memory address block must be allocated to the PC interface board before it is inserted as a memory-mapped board. This prevents other programs from using the PC interface hardware.

CAUTION

Allocate the memory area to the PC interface board so that it does not overlap another area allocated to the other board. If the memory areas overlap, the PC interface board and the E8000 emulator will not operate correctly.

At shipment, the switch is set to allocate address range from H'D0000 to H'D3FFF to the PC interface board.

Table 2.1 Memory Map of PC Interface Board

Switch	Address Range
0	H'C0000-H'C3FFF
1	H'C4000-H'C7FFF
2	H'C8000-H'CBFFF
3	H'CC000-H'CEFFF
4	H'D0000-H'D3FFF (at shipment)
5	H'D4000-H'D7FFF
6	H'D8000-H'DBFFF
7	H'DC000-H'DFFFF
8	H'E0000-H'E3FFF
9	H'E4000-H'E7FFF
A	H'E8000-H'EBFFF
B	H'EC000-H'FFFFFF

Refer to the E8000 SH7410 Emulator User's Manual and the Description Notes on Using the IBM PC Interface Board, for details on how to insert the board.

1. Select one of the available address ranges and determine the corresponding switch number.
2. Using a small flat-head screwdriver, turn the switch attached to the rear panel of the PC interface board so that the arrow indicates the number for the selected address range.
3. Remove the PC cover and insert the PC interface board into an unused ISA-bus slot.
4. Set the PC cover.
5. Connect the PC interface cable between the PC interface board and the PC interface connector of the E8000 emulator. Insert connectors or plugs completely.
6. Supply power to the PC.
7. Using the EDIT program attached to the MS-DOS, edit the CONFIG.SYS file as follows:

EDIT CONFIG.SYS

8. Put a line cursor in the following line:

DEVICE=C:\DOS\EMM386.EXE

9. Change the above line as follows:

DEVICE=C:\DOS\EMM386.EXE X=aaaa-bbbb

10. The 'aaaa' means the lower limit and the 'bbbb' the upper limit. For example, when the switch is set to 4, the line must be set as follows:

DEVICE=C:\DOS\EMM386.EXE X=D000-D3FF

11. When the PC is restarted without problems, the following line must be added to the [386enh] section in the Windows SYSTEM.INI file:

EMMExclude=aaaa-bbbb

12. The 'aaaa' and the 'bbbb' are the same addresses as the ones specified in the CONFIG.SYS file. Because of this, Windows does not use this memory block. Now the user is ready to execute the HDI software and check the communication state of the E8000 emulator.

2.1.3 Installing the HDI Software

This section describes an example of installing the HDI on Windows95. Use a backup floppy disk for installing. Install the HDI software on the IBM PC by using the installation disk as follows:

1. Insert the HDI installation disk into the floppy disk driver (assumed to be the **A** drive).
2. Start Windows.
3. Click [Run] from the start menu to display the following dialog box.
4. Type `A:\SETUP.EXE` and click the [OK] button.




Figure 2.1 [Run] Dialog Box

5. This runs the HDI installer, and the following [Welcome!] dialog box will be displayed.




Figure 2.2 [Welcome!] Dialog Box

6. Click the [OK] button to proceed with the installation.

7. The following dialog box then displays version information as a [Read Me] dialog box on the HDI the user is installing. Click the [OK] button to proceed.




Figure 2.3 [Read Me] Dialog Box

8. The [Select Destination Directory] dialog box then allows the user to select a directory for installing the HDI and to click the [OK] button. When installing into the default directory C:\HDI, just click the [OK] button.



Figure 2.4 [Select Destination Directory] Dialog Box

9. When the specified directory already exists, the [Install] dialog box is displayed. When installing the HDI to the same directory as C : \HDI, click the [Yes] button. If the user wants to change the directory, click the [No] button. The [Select Destination Directory] dialog box then allows the user to select another directory.



Figure 2.5 [Install] Dialog Box

10. Clicking the [Yes] button in the [Install] dialog box displays the [Make Backups?] dialog box to ask the user whether a backup should be made of the files replaced by the installation. Click the [Yes] button to save any files or the [No] button if the user does not want to make a backup.




Figure 2.6 [Make Backups?] Dialog Box

11. When the user selects the [Yes] button in the [Make Backups?] dialog box, the [Select Backup Directory] dialog box is displayed. Specify the backup file name then click the [OK] button to proceed. If saving into the default directory C:\HDI\BACKUP, just click the [OK] button.



Figure 2.7 [Select Backup Directory] Dialog Box

12. The installer then installs the HDI files to the specified directory. (The user must change the floppy disk during installation. According to the message in the dialog box, change the disk to the other one.)




Figure 2.8 [Installing] Dialog Box

13. Clicking the [Yes] button in the [Diagnostic Program Install] dialog box installs a program that uses the diagnostic program for the E8000 emulator on the HDI. Click the [No] button if the user does not want to install the program.




Figure 2.9 [Diagnostic Program Install] Dialog Box

14. Finally the [Select Program Manager Group] dialog box allows the user to specify the program group name for the HDI icons. If specifying the default group name HDI, just click the [OK] button. This is the end of installation.




Figure 2.10 [Select Program Manager Group] Dialog Box

15. Specifying the program group name enables the installer to create the following icons in the program group the user specified.



Figure 2.11 HDI Program Group

16. These icons represent the following functions:

[HDI for E8000 SH7410]: The HDI program is executed.

[Uninstall HDI for E8000 SH7410]: The HDI software and the associated files are deleted when the HDI is uninstalled.

2.2 Checking the System

The next step is to activate the HDI software to check that the E8000 emulator is working correctly.

1. Turn on the E8000 emulator after confirming that the S7 and S8 DIP switches of SW1 on the E8000 emulator are set to 'on' (pushed to the left).
2. Select the [HDI for E8000 SH7410] icon.



Figure 2.12 [HDI for E8000 SH7410] Icon

3. The HDI window will be displayed. If "Link up" is shown on the status bar, the HDI startup is completed (figure 2.13).



Figure 2.13 HDI Status Bar

Figure 2.14 shows the HDI window.




Figure 2.14 HDI Window

2.3 Troubleshooting

If the following dialog box is displayed when the HDI software is activated, the HDI and the E8000 emulator are not communicating correctly.




Figure 2.15 Illegal Communication Message Dialog Box

In this case, exit the HDI and turn off the power of the E8000 emulator. Then, turn on the E8000 emulator again and restart the HDI. If the illegal communication is not corrected, inform a Hitachi sales representative or agency of the situation.

Section 3 Tutorial

3.1 Introduction

The following describes a sample program debugging session, designed to introduce the main functions of the HDL.

This sample C program sorts ten random data items first in ascending order, then in descending order.

The sample C program performs the following actions:

- The `main` function generates random data to be sorted.
- The `sort` function sorts the random data in ascending order.
- The `change` function changes the data in descending order.

The sample program `sort.c` and the SYSROF load module `sort.abs` are provided on the installation disk.

Note: The sample program is compiled with `C:\hdi\tutorial`. When using a directory other than `C:\hdi\tutorial`, recompile the sample program.

3.2 Running HDI

To run the HDI, select the [HDI for E8000 SH7410] icon.



HDI for
E8000
SH7410

Figure 3.1 [HDI for E8000 SH7410] Icon

3.3 Selecting the Target Platform

The HDI supports multiple target platforms. If the user sets up the system for more than one platform, the HDI will prompt to select a platform for the current session.




Figure 3.2 [Select Platform] Dialog Box

Note that the user can change the target platform at any time by selecting [Select Platform...] from the [Setup] menu. However, since only one platform SH7410 E8000 is installed in the HDI, this menu option will not be available.

When the E8000 emulator has been successfully set up, the HDI window will be displayed, with the message “Link up” in the status bar. Figure 3.3 shows the key functions of the window:




Figure 3.3 HDI Window

The key functions of the HDI are described in section 4, Descriptions of Windows. Numbers in figure 3.3 indicate the following:

1. Menu bar: Give the user access to the HDI commands for using the HDI debugger.
2. Toolbar: Provides convenient buttons as shortcuts for the most frequently used menu commands.
3. Program window: Displays the source program being debugged.
4. Status bar: Displays the status of the E8000 emulator, and progress information about downloading.
5. [Help] button: Activates context sensitive help about any features of the HDI user interface.

3.4 Setting up the E8000 Emulator

The following MCU conditions must be set up before downloading the program:

- Device type
- Operating mode
- Operating clock
- Execution operating mode
- Memory map

The following describes how to set up the E8000 emulator correctly for the tutorial programs.

3.4.1 Setting the [Configuration] Dialog Box

- Select [Configure Platform...] from the [Setup] menu to set configuration. The following dialog box is displayed:




Figure 3.4 [Configuration] Dialog Box

Set options as follows:

Table 3.1 Setting the [Configuration] Dialog Box

Option	Value
Mode [Mode]	H'1C (CS0 external memory mode and internal clock)
Emulation clock [Clock]	System clock (using the E8000 emulator clock)
Emulation mode [Emulation mode]	Normal (normal execution)
UBC sequential break mode [UBC Sequential break mode]	Invalid (setting default)
Display of TCS and BCS sequential condition satisfaction levels [Display sequential break level both Break condition sequence and Trace condition sequence]	Invalid (setting default)
Program counter display interval [Execution status display interval]	About 200 ms (setting default)
Timer resolution [The minimum time to be measured by Go command execution]	1.6 us (setting default)
Emulation memory bus width [Emulation memory bus width]	32-bit bus width
BREQ signal control [Enable the BREQ signal input]	Valid (setting default)
User-wait control [Enable user wait]	Invalid (setting default)
Performance execution count measurement mode [ECNT Option]	Upper (setting default)
Trigger output control 1 at break [TRGU Option]	Upper (setting default)
Trigger output control 2 at break [TRGB Option]	Upper (setting default)

- Click the [OK] button to set any changes in the configuration.

3.4.2 Setting the Memory Map

In the next step, allocate the emulation memory for the developing application.

- Select [Memory Mapping Window] from the [View] menu to display the current memory map. The [Memory Mapping] window is displayed.




Figure 3.5 [Memory Mapping] Window

The E8000 emulator can allocate the optional memory area as one of the following three types:

Table 3.2 Memory Type

Memory Type	Description
EMULATION AREA	Sets the address range of the emulation memory area.
USER AREA	Sets the address range of the user memory area.
EMULATION Read-Only	Sets the emulation memory to be write-protected.

Note: When the user memory is allocated, the memory allocation information of the user system is not displayed.

When the [Add] button is clicked, the [Edit Memory Mapping] dialog box is displayed.




Figure 3.6 [Edit Memory Mapping] Dialog Box

For this tutorial, allocate the memory area of addresses ranging from H'00000000 to H'000FFFFF as an emulation memory area.

- Edit the [From] and [To] fields to H'00000000 and H'000FFFFF, respectively, set the [Setting] to EMULATION AREA, and click the [OK] button.

The [Memory Mapping] window will now show the modified ranges.

- Click the close box [X] in the upper-right corner of the [Memory Mapping] window to close the window.

3.5 Downloading the Tutorial Program

3.5.1 Downloading the Tutorial Program

Download the object program to be debugged.

- Select [Load Program...] from the [File] menu.
- Select the file `sort.abs` in the `hdi\tutorial` directory, and click the [OK] button.




Figure 3.7 [Load Object File] Dialog Box

When the file has been loaded, the following dialog box displays information about the memory areas that have been filled with the program code.




Figure 3.8 HDI Dialog Box

- Click the [OK] button to continue.

3.5.2 Displaying the Source Program

The HDI allows the user to debug a program at the source level, so that the user can see a list of the C program alongside the machine code as the user debugs. To do this, the C source file that corresponds to the object file needs to be read.

- Select [Program Window...] from the [View] menu.
- Select the C source file that corresponds to the object file the user have loaded.




Figure 3.9 [Open Program Window] Dialog Box

- Select [sort.c] and click the [OK] button. The [Program] window is displayed.

```

SORT.C
Address | Break | Code
00000000 void main(void)
        {
            long a[10];
            long j;
            int i, min, max;

00000004     for( i=0; i<10; i++ ){
0000000c         j = rand();
00000014         if(j < 0){
00000018             j = -j;
        }
0000001c         a[i] = j;
    }

00000038     sort(a);
00000040     min = a[0];
00000044     max = a[9];
00000048     min = 0;
0000004c     max = 0;
00000050     change(a);
00000058     min = a[9];
0000005c     max = a[0];
00000060 }

```

Figure 3.10 [Program] Window (Displaying the Source Program)

- If necessary, select the [Font] option from the [Customise] submenu on the [Setup] menu to select a font and size suitable for the host computer.

Initially the [Program] window shows the start of the main program, but the user can use the scroll bar to scroll through the program to see the other statements.

3.6 Setting the Software Breakpoint

A breakpoint is one of the easy debugging functions.

The [Program] window provides a very simple way of setting a breakpoint at any point in a program. For example, to set a breakpoint at the `sort` function call:

- Select the [Break] column on the line containing the `sort` function call.




Figure 3.11 [Program] Window (Setting a Software Breakpoint)

The word *Break* will be displayed on the line containing the `sort` function to show that a software breakpoint is set at that address.

Note: The software breakpoint cannot be set in the ROM area.

3.7 Setting Registers

Set values of the program counter and the stack pointer before executing the program.

3.7.1 Setting the Program Counter

Set the value of the program counter.

- Select [Register Window] from the [View] menu. The [Registers] window is displayed.




Figure 3.12 [Registers] Window

- Select [PC] in the [Registers] window to change the value of the program counter (PC).

The following dialog box enables the value to be changed.




Figure 3.13 [Register] Dialog Box (PC)

- Set the program counter to H'0 in this sample program, and click the [OK] button.

3.7.2 Setting the Stack Pointer

- Select [R15] in the [Registers] window to change the value of the stack pointer (R15). In the same way of setting the program counter, the stack pointer can be changed by the [Register] dialog box.




Figure 3.14 [Register] Dialog Box (R15)

- Set H'4000 for the value of the stack pointer in this sample program, and click the [OK] button.

3.8 Executing the Program

- To execute the program, select [Go] from the [Run] menu, or click the [Go] button on the toolbar.



Figure 3.15 [Go] Button

The program will be executed up to the breakpoint that has been inserted, and a statement will be highlighted in the [Program] window to show the position that the program has halted, with the message [Break=BREAKPOINT] in the status bar.




Figure 3.16 [Program] Window (Break Status)

The user can see the cause of the last break in the [System Status] window.

- Select [Status Window] from the [View] menu.




Figure 3.17 [System Status] Window

The [Cause of last break] line shows that the cause of the break is the breakpoint.

3.9 Reviewing Breakpoints

The user can see all the breakpoints set in the program in the [Breakpoints] window.

- Select [Breakpoint Window] from the [View] menu.




Figure 3.18 [Breakpoints] Window

The [Breakpoints] window also allows the user to set breakpoints, define new breakpoints, and delete breakpoints.

- Highlight the breakpoint in the [Breakpoints] window and click the [Delete] button.

3.10 Viewing Memory

The user can view the contents of a memory block in the [Memory] window. For example, to view the memory corresponding to the main function in word size:

- Select [Memory Window...] from the [View] menu, enter main in the [Address] field, and set [Format] as Word.





Figure 3.19 [Open Memory Window] Dialog Box

- Click the [OK] button. The [Word Memory] window showing the specified area of memory is displayed.



The image shows a window titled "Word Memory - _main" with a table of memory addresses and data. The table has two columns: "Address" and "Data". The data is displayed in hexadecimal format, with each row representing a 32-bit word of memory. The addresses range from 00000000 to 00000030 in increments of 4 bytes. The data for each address is shown as four bytes separated by spaces.

Address	Data
00000000	4F22 7FC8 E300 1F32
00000008	A012 0009 D11E 410B
00000010	0009 1F03 4011 8901
00000018	600B 1F03 53F2 4308
00000020	62F3 7210 332C 51F3
00000028	2312 53F2 7301 1F32
00000030	E20A 51F2 3123 8BE9
00000038	64F2 7410 8014 0000

Figure 3.20 [Word Memory] Window

3.11 Watching Variables

As the user steps through a program, it is possible to watch the values of variables used in the program. For example, set a watch on the long-type array `a` declared at the beginning of the program, by using the following procedure:

- Click the left of displayed array `a` in the [Program] window to position the cursor.
- Click the [Program] window with the right mouse button, and select [Instant Watch...] from a pop-up menu.

The following dialog box will be displayed.




Figure 3.21 [Instant Watch] Dialog Box

- Click the [Add Watch] button to add a variable to the [Watch] window.



Figure 3.22 [Watch] Window (Displaying the Array)

The user can also add a variable to the [Watch] window by specifying its name.

- Click the [Watch] window with the right mouse button and select [Add Watch] from the pop-up menu.

The following dialog box will be displayed.




Figure 3.23 [Add Watch] Dialog Box

- Input variable max and click the [OK] button.

The [Watch] window will now also show the long-type variable max.




Figure 3.24 [Watch] Window (Displaying the Variable)

The user can select the + symbol to the left of any variable in the [Watch] window to expand the variable and watch all the elements in the array.




Figure 3.25 [Watch] Window (Displaying Array Elements)

3.12 Stepping Through a Program

The HDI provides a range of step menu commands that allow efficient program debugging.

Table 3.3 Step Option

Menu Command	Description
Step In	Executes each statement, including statements within functions.
Step Over	Executes a function call in a single step.
Step Out	Steps out of a function, and stops at the next statement that called the function in the program.
Step...	Steps the specified counts repeatedly at a specified rate.

To demonstrate program stepping, confirm that the `sort` function statement at address H'00000038 has been executed.




Figure 3.26 [Program] Window (Step Execution)

3.12.1 Executing [Step In] Command

The [Step In] steps into the called function and stops at the first statement of the called function.

- To step through the `sort` function, select [Step In] from the [Run] menu, or click the [Step In] button in the toolbar.



Figure 3.27 [Step In] Button

```
SORT.C
Address | Break | Code
00000000      void main(void)
          {
            long a[10];
            long j;
            int i, min, max;

00000004      for( i=0; i<10; i++ ){
0000000c          j = rand();
00000014          if(j < 0){
00000018              j = -j;
          }
0000001c          a[i] = j;
        }

00000038      sort(a);
00000040      min = a[0];
00000044      max = a[9];
00000048      min = 0;
0000004c      max = 0;
00000050      change(a);
00000058      min = a[9];
0000005c      max = a[0];
00000060      }

00000068      void sort(long *a)
          {
            long t;
            int i, j, k, gap;
```

Figure 3.28 [Program] Window (Step In)

- The highlighted line moves to the first statement of the sort function in the [Program] window.

3.12.2 Executing [Step Out] Command

The [Step Out] command steps out of the called function and stops at the next statement of the `sort` calling statement in the main function.

- To step out of the `sort` function, select [Step Out] from the [Run] menu, or click the [Step Out] button in the toolbar.



Figure 3.29 [Step Out] Button




Figure 3.30 [Program] Window (Step Out)

- The data of variable `a` displayed in the [Watch] window is sorted in ascending order.

- To execute two steps, use [Step In] twice.




Figure 3.31 [Program] Window (Step In → Step In)

- The value of `max` displayed in the [Watch] window is changed to the maximum data value.

3.12.3 Executing [Step Over] Command

The [Step Over] executes a function call as a single step and stops at the next statement of the main program.

- To demonstrate [Step Over], execute two steps to reach the change function statement.




Figure 3.32 [Program] Window (Before Step Over Execution)

- To step through all statements in the change function at a single step, select [Step Over] from the [Run] menu, or click the [Step Over] button in the toolbar.



Figure 3.33 [Step Over] Button




Figure 3.34 [Program] Window (Step Over)

When the last statement of the change function is executed, the data of variable a, which is displayed in the [Watch] window, is sorted in descending order.

3.13 Displaying Local Variables

The user can display local variables in a function using the [Locals] window. For example, the local variables in the `main` function will be examined, which declares five local variables: `a`, `j`, `i`, `min`, and `max`.

- Select [Local Variable Window] from the [View] menu. The [Locals] window is displayed. Initially, the [Locals] window is empty because local variables have not yet been declared.
- Select [Step In] from the [Run] menu to execute a single step. The [Locals] window will now show the local variables and their values.




Figure 3.35 [Locals] Window

- Select the + symbol to the left of array `a` in the [Locals] window to display the elements of array `a`.
- Refer to the elements of array `a` before and after the execution of the `sort` function, and confirm that random data is sorted in ascending or descending order.

3.14 Setting the Hardware Break Condition

The E8000 emulator has powerful hardware break functions. In the HDI, these hardware break conditions can be set by using dialog boxes. The dialog boxes for setting hardware break conditions, and the corresponding break conditions, are described below.

Table 3.4 Dialog Boxes for Setting Hardware Break Conditions

Dialog Box \ Function	Address Bus Condition (Address)	Data Bus Condition (Data)	Bus State Condition (State)	External Probe Condition (Probe)	Interrupt Condition (Interrupt)	Satisfaction Count (Count)	DELAY Condition (Delay)*3
[Break Condition UBC1] dialog box	O	O	O	O	X	O	X
[Break Condition UBC2] dialog box	O	X	O	X	X	X	X
[Break Condition A] dialog box*2	O	O	O	O	O	X	X
[Break Condition B] dialog box*2	O	O	O	O	O	O	O
[Break Condition C] dialog box*2	O	X	O	X	X	X	X

Notes: 1. O: Can be set in the dialog box.

X: Cannot be set in the dialog box.

2. Eight break condition points can be set independently in each of the [Break Condition A/B/C] dialog boxes.
3. Only Break Condition B7 can be set for the DELAY condition in the [Break Condition B] dialog box.

Table 3.5 Main Break Conditions

Break Condition	Description
Address bus condition (Address)	Breaks on a match of the SH7410 address bus value.
Data bus condition (Data)	Breaks on a match of the SH7410 data bus value. Byte, word, or longword can be specified as the access data size.
Bus state condition (Bus State)	There are two bus state condition settings: Read/write condition: Breaks when the SH7410 RD or RDRW signal level matches the specified condition. Bus state condition: Breaks when the operating state in an SH7410 bus cycle matches the specified condition.
External probe signal condition (Probe)	Breaks when an external probe signal (PRB1–PRB4) level matches the specified condition.
Interrupt signal condition (Interrupt)	Breaks when the NMI signal or an external interrupt signal (IRQ0–IRQ3) level matches the specified condition.
Satisfaction Count (Count)	Breaks when all the above conditions have been satisfied the number of times specified in this condition. (A maximum count of 65,536 can be specified.)
DELAY condition (Delay)	Breaks when all the above conditions have been satisfied and the bus cycles specified in this condition have been executed. (A maximum of 32,767 bus cycles can be specified.)

An example is given below in which address bus condition and read cycles for state condition are set in Break Condition A as hardware break conditions.

- Select [Breakpoint Window] from the [View] menu. The [Breakpoints] window is displayed.
- Click the [Del All] button to clear all the set break conditions.
- Click the [Add] button.




Figure 3.36 [Breakpoints] Window (Before Hardware Break Condition Setting)

The [Break] dialog box is displayed. For hardware break conditions, the [Break] dialog box pages required for the setting must be selected.

- Select [Condition A] to display the [Condition A] page.




Figure 3.37 [Condition A] Page ([Break] Dialog Box)

Up to eight breakpoints can be set independently for the Break Condition A (B, C) hardware break condition. In the example, one point is set for the Break Condition A hardware break condition.

- Highlight the first point in the [Condition] display field.
- Click the [Edit...] button. The [Break Condition A1] dialog box is displayed.
- Clear the [Don't Care] check box in the [Address] page.

- Select [Address] and input address **H'5A** as the value in the [Start] field.



Figure 3.38 [Address] Page ([Break Condition A1] Dialog Box)

- Select [Bus State] to display the [Bus State] page.
- Select [Read] in [Read/Write].




Figure 3.39 [Bus State] Page ([Break Condition A1] Dialog Box)

- Click the [OK] button.
- The [Break] dialog box is displayed, and the first point display in the [Condition] display field changes from Empty to Enable.




Figure 3.40 [Break] Dialog Box (After Hardware Break Condition Setting)

- Click the [Close] button.

The newly set hardware breakpoint is displayed in the [Breakpoints] window. With this setting, Break Condition A1 is displayed in [Type] in the [Breakpoints] window.

This completes the setting of the Break Condition A1 hardware break condition. When the program is executed, a break will occur when address H'5A is accessed in a read cycle.




Figure 3.41 [Breakpoints] Window ([Break Condition A] Setting)

3.15 Setting the Sequential Break Condition

The E8000 emulator has powerful sequential break functions. In the HDI, these sequential break conditions can be set by using dialog boxes. The dialog boxes for setting sequential break conditions, and the corresponding sequential break functions, are described below.

Table 3.6 Dialog Boxes for Setting Sequential Break Conditions

Function Dialog Box	Address Bus Condition (Address)	Data Bus Condition (Data)	Bus State Condition (State)	External Probe Condition (Probe)	Interrupt Condition (Interrupt)	Satis- faction Count (Count)	DELAY Condition (Delay)
[Break Condition UBC1] dialog box	O	O	O	O	X	O	X
[Break Condition UBC2] dialog box	O	X	O	X	X	X	X
[Break Sequence] dialog box	O	X	X	X	X	X	X
[Break Condition Sequence] dialog box	O	O	O	O	O	X	O

Note: O: Can be set in the dialog box.

X: Cannot be set in the dialog box.

Table 3.7 Main Sequential Break Conditions

Sequential Break Function	Description
Break Sequence	<p>A sequential break function using software breaks.</p> <p>Up to 7 address points can be set. Program execution is halted when all the set addresses have been passed in sequence.</p> <p>One point can be set as a reset point address. When the reset point is passed, the sequential break conditions that have been passed thus far are cleared, and checking begins again from the first break condition.</p>
Break Condition Sequence	<p>A sequential break function using hardware breaks.</p> <p>Up to 7 address points can be set. Program execution is halted when all the set break conditions have been satisfied in sequence.</p> <p>One point can be set as a reset point. When the condition is satisfied at the reset point, the sequential break conditions that have been satisfied thus far are cleared, and checking begins again from the first break condition.</p>
Break Condition UBC1, 2	<p>A sequential break function using a combination of Break Condition UBC1 and UBC2. Program execution is halted when Break Condition UBC2 and Break Condition UBC1 are satisfied in that order.</p>

An example is given below in which Break Condition Sequence is used as the sequential break function. Set break conditions as follows:

Break condition 1: A break is executed when address H'5A is accessed in a read cycle.

Break condition 2: A break is executed when address H'5E is accessed in a read cycle.

In Break Condition Sequence, program execution is halted when break conditions 1 and 2 are satisfied in that order.

- Select [Breakpoint Window] from the [View] menu. The [Breakpoints] window is displayed.
- Click the [Del All] button to clear all the set break conditions.
- Click the [Add] button.




Figure 3.42 [Breakpoints] Window (Before Sequential Break Condition Setting)

The [Break] dialog box is displayed. To set sequential break conditions, the [Break] dialog box pages required for the setting must be selected.

- Select [Condition Sequence] to display the [Condition Sequence] page.




Figure 3.43 [Break Condition Sequence] Page ([Break] Dialog Box)

Up to seven independent condition points and a reset point condition can be set for the Break Condition Sequence sequential break condition. In the example, break condition 1 is set for Break Condition Sequence1, and break condition 2 for Break Condition Sequence2.

- Highlight the first point in the [Sequence condition] display field.
- Click the [Edit...] button. The [Break Condition Sequence1] dialog box is displayed.
- Clear the [Don't Care] check box in the [Address] page.
- Select [Address] and input address **H'5A** as the value in the [Start] field.




Figure 3.44 Condition 1 [Address] Page ([Break Condition Sequence1] Dialog Box)

- Select [Bus State] to display the [Bus State] page.
- Select [Read] in [Read/Write].




Figure 3.45 Condition 1 [Bus State] Page ([Break Condition Sequence1] Dialog Box)

- Click the [OK] button.
- The [Break] dialog box is displayed, and the first point display in the [Sequence condition] display field changes from Empty to Enable.




Figure 3.46 [Break] Dialog Box (After [Break Condition Sequence1] Condition Setting)

This completes the setting of break condition 1. Next, Set break condition 2 as follows:

- Highlight the second point in the [Sequence condition] display field.
- Click the [Edit...] button. The [Break Condition Sequence2] dialog box is displayed.

The setting can then be made in the same way as for break condition 1.

- After setting break conditions 1 and 2, click the [Close] button.

Break Condition Sequence is displayed in [Type] in the [Breakpoints] window.




Figure 3.47 [Breakpoints] Window (After Sequential Break Condition Setting)

3.16 Using the Trace Buffer

3.16.1 Displaying the Trace Buffer

Using the trace buffer, it is possible to verify execution results upstream of the MCU cycles.

- Select [Trace Window] from the [View] menu to open the [Trace] window.
- If necessary, adjust the column width by dragging the column divider beside the label immediately below the title bar.




Figure 3.48 [Trace] Window (Free Trace Results)

3.16.2 Setting the Trace Filter

In a free trace, the [Trace] window displays all the MCU cycles. By setting the specific search condition, it is possible to display only the trace contents that match the search condition in the [Trace] window.

Table 3.8 Main Trace Search Conditions

Break Condition	Description
Address bus condition (Address)	Searches for an item that matches the SH7410 address bus value.
Data bus condition (Data)	Searches for an item that matches the SH7410 data bus value. Byte, word, or long word can be specified as the access data size.
Bus state condition (Bus & Area)	There are three bus state condition settings: Read/write condition: Searches for an item for which the SH7410 RD or RDRW signal level matches the specified condition. Bus state condition: Searches for an item for which the operating state in an SH7410 bus cycle matches the specified condition. Area condition: Searches for an item for which the memory space accessed in an SH7410 bus cycle matches the specified condition.
External probe signal condition (Probe)	Searches for an item for which an external probe signal (PRB1–PRB4) level matches the specified condition.
Interrupt signal condition (Interrupt)	Searches for an item for which the levels of the NMI signal, external interrupt signals (IRQ0–IRQ3), and the RESET signal matches the specified condition.
Time condition (Time)	Searches for an item for which the time stamp value or range matches the specified condition.

For the trace search conditions:

- First, click the [Clear] button in the [Trace] window to clear the current trace buffer.
- Next, click the [Filter] button to display the [Trace Filter] dialog box.

The filter conditions that limit the cycles to be displayed in the trace buffer can then be set.

- Select [Pattern] in [Type].




Figure 3.49 [General] Page ([Trace Filter] Dialog Box)

- Select [Address] to display the [Address] page.
- Clear the [Don't Care] check box in the [Address] page.
- Select [Address] and input address **H' 5A** as the value in the [Start] field.




Figure 3.50 [Address] Page ([Trace Filter] Dialog Box)

- Select [Bus & Area] to display the [Bus & Area] page.
- Select [Read] in [Read/Write].




Figure 3.51 [Bus & Area] Page ([Trace Filter] Dialog Box)

- Click the [OK] button to save the trace filter.
- Select [Go] from the [Run] menu to execute the program.
- Open the [Trace] window.




Figure 3.52 [Trace] Window (Trace Filter Results)

3.17 Trace Acquisition Condition Setting

The E8000 emulator has powerful realtime trace functions. Trace information for up to 131,070 bus cycles can be acquired. In the HDI, trace acquisition conditions can be set by using dialog boxes. The dialog boxes for setting trace acquisition conditions, and the corresponding trace acquisition conditions, are described below.

Table 3.9 Dialog Boxes for Setting Trace Acquisition Conditions

Dialog Box	Function	Subroutine Trace	Range Trace	Trace Stop	Subroutine Range Trace
[Trace Condition A] dialog box		O	X	O	X
[Trace Condition B] dialog box		O	O	O	O
[Trace Condition C] dialog box		O	O	O	X

Note: O: Can be set in the dialog box.

X: Cannot be set in the dialog box.

Table 3.10 Main Trace Acquisition Conditions

Trace Acquisition Condition	Description
Free trace	Acquires trace information continuously from the start of execution of the user program until the program breaks. If Trace Conditions A/B/C is not set, this mode is entered.
Subroutine trace	Performs trace acquisition of instructions or operand accesses between the start address and end address of the specific subroutine with Trace Condition A/B/C.
Range trace	Performs trace acquisition only for places where the condition specified by Trace Condition A/B/C is satisfied. Specifiable conditions are: Address bus condition (range specification or negative condition specification possible) Read/write condition Bus state condition (prefetch cycle, execution cycle)
Trace stop	Stops trace acquisition when the condition specified by Trace Condition A/B/C is satisfied. Specifiable conditions are: Address bus condition Data bus condition Read/write condition Bus state condition (DMA cycle, execution cycle, vector fetch cycle) System control signal (BREQ) External probe condition DELAY condition
Subroutine range trace	Performs trace acquisition only for places where a subroutine instruction and an operand that have been specified by Trace Condition A/B/C are accessed, and the condition is satisfied.

An example is given below in which trace stop mode (in which address bus condition and read cycles for state condition are set) is selected for Trace Condition A as the trace acquisition condition.

- Select [Trace Window] from the [View] menu to display the [Trace] window.
- Click the [Acquisition] button to display the [Trace Acquisition] dialog box.




Figure 3.53 [Trace Acquisition] Dialog Box

For trace acquisition conditions, the [Trace Acquisition] dialog box pages required for the setting must be selected.

- Select [Condition A] to display the [Condition A] page.




Figure 3.54 [Condition A] Page ([Trace Acquisition] Dialog Box)

- Highlight the first point in the [Condition] display field.
- Click the [Edit...] button.

- The [Trace Condition A1] dialog box is displayed.




Figure 3.55 [General] Page ([Trace Condition A1] Dialog Box)

- Select [Trace Stop] as [Mode] in the [General] page.
- Select [Address] to display the [Address] page.
- Clear the [Don't Care] check box in the [Address] page.
- Select [Address] and input **H'5A** as the value in the [Start] field.




Figure 3.56 [Address] Page ([Trace Condition A1] Dialog Box)

- Select [Bus State] to display the [Bus State] page.
- Select [Read] in [Read/Write].




Figure 3.57 [Bus State] Page ([Trace Condition A1] Dialog Box)

- Click the [OK] button.
- The [Trace Acquisition] dialog box is displayed, and the first point display in the [Condition] display field changes from Empty to Enable.




Figure 3.58 [Condition A] Page ([Trace Acquisition] Dialog Box)

This completes the setting of the Trace Condition A1 trace acquisition condition. When the program is executed, trace acquisition will stop when address H'5A is accessed in a read cycle.

3.18 Saving the Session

Saving the present debugging session before quitting will allow debugging to be resumed from the same state in the next session.

Select [Exit] from the [File] menu to exit the HDI. At this time, a window for specifying the file name is displayed. Input the session file name in the window and click the [OK] button.

3.19 What Next?

This tutorial has described the major features of the E8000 emulator and the use of the HDI.

Sophisticated debugging can be carried out by using the E8000 emulator in combination with the emulation tools it offers. This provides for effective investigation of hardware and software problems by accurately isolating and identifying the conditions under which such problems arise.

Further details on the use of the HDI can be found in the separately issued Hitachi Debugging Interface User's Manual.

Section 4 Descriptions of Windows

4.1 SH7410 E8000 HDI Windows

HDI window menu bars and the corresponding pull-down menus are listed in table 4.1. Where a description of a menu is included in the Hitachi Debugging Interface User's Manual or in this manual, an O mark or the relevant section number is shown. Related commands in the E8000 Emulator User's Manual are also shown. (E8000-related commands are given in abbreviated forms.)

Table 4.1 HDI Window Menus and Related Manual Entries

Menu Bar	Pull-Down Menu	Hitachi Debugging Interface User's Manual	This Manual	E8000-Related Commands
File menu	Load Program...	O	3.5.1	—
	Save Memory...	O	—	—
	Verify Memory...	O	—	—
	Save Session	O	3.18	—
	Load Session...	O	—	—
	Save Session As...	O	—	—
	Initialise	O	—	—
	Exit	O	3.18	—
Edit Menu	Cut	O	—	—
	Copy	O	—	—
	Paste	O	—	—
	Find...	O	—	—
	Set Line...	O	—	—
	Fill Memory...	O	—	F
	Move Memory...	O	—	MV
	Test Memory...	O	—	—
	Update Memory	O	—	—

Table 4.1 HDI Window Menus and Related Manual Entries (cont)

Menu Bar	Pull-Down Menu	Hitachi Debugging Interface User's Manual		E8000-Related Commands
		This Manual		
View Menu	Toolbar	O	—	—
	Status Bar	O	—	—
	Breakpoint Window	O	3.9, 3.14, 3.15, 4.2.2	B,BS,BCA,BCB, BCC,BCS,BCU
	Command Line Window	O	—	—
	I/O Register Window	O	—	—
	Local Variable Window	O	3.13	—
	Memory Mapping Window	O	3.4.2, 4.2.13	MP
	Memory Window...	O	3.10	M, D
	Performance Analysis Window	O	—	PA
	Program Window...	O	3.5.2, 3.6, 3.8, 3.11	—
	Register Window	O	3.7	—
	Status Window	O	3.8	CL, EM, G.MD
	Text Window	O	—	—
	Trace Window	O	3.16, 3.17, 4.2.15	T,TCA,TCB,TCC, TCS,TS,TMO
	Watch Window	O	3.11	—
Run Menu	Go	O	3.8	G
	Go Reset	O	—	G
	Go to Cursor	O	—	—
	Run...	O	—	G
	Step In	O	3.12.1, 3.13	S
	Step Over	O	3.12.3	SO
	Step Out	O	3.12.2	—
	Step...	O	—	S
	Halt Program	O	—	—
	Set PC To Cursor	O	—	—
Reset CPU	O	—	RS	

Table 4.1 HDI Window Menus and Related Manual Entries (cont)

Menu Bar	Pull-Down Menu	Hitachi Debugging Interface User's Manual	This Manual	E8000-Related Commands
Setup Menu	Options	O	—	—
	Radix	O	—	RX
	Customise	O	3.5.2	—
	Select Platform...	O	3.3	—
	Configure Platform...	O	3.4.1, 4.2.1	CL, EM, G.MD
Tools Menu	Symbols...	O	—	—
	Evaluate...	O	—	—
Window Menu	Cascade	O	—	—
	Tile	O	—	—
	Arrange Icons	O	—	—
	Close All	O	—	—
Help Menu	Index	O	—	—
	Using Help	O	—	—
	Search for Help on	O	—	—
	About HDI	O	—	—

The following windows and dialog boxes are provided in the HDI.

- [Configuration] dialog box
- [Break] dialog box
- [Break Point] dialog box
- [Break Point Sequence] dialog box
- [Break Condition A] dialog box
- [Break Condition B] dialog box
- [Break Condition C] dialog box
- [Break Condition Sequence] dialog box
- [Break Condition UBC] dialog box
- [Memory Mapping] window
- [Edit Memory Mapping] dialog box
- [Trace Acquisition] dialog box
- [Trace Condition A] dialog box
- [Trace Condition B] dialog box
- [Trace Condition C] dialog box
- [Trace Condition Sequence] dialog box
- [Trace Filter] dialog box
- [Trace Find] dialog box

This window and dialog boxes can be used to access the E8000 emulator's sophisticated debugging functions.

4.2 Descriptions of Each Window

This section describes each window.

4.2.1 [Configuration] Dialog Box

Function:

This dialog box sets the emulation conditions of the emulator. To display the [Configuration] dialog box, select [Configure Platform...] from the [View] menu.

Window:




Figure 4.1 [Configuration] Dialog Box

Description:

The [Configuration] dialog box consists of the pages listed in table 4.2.

Table 4.2 [Configuration] Dialog Box Pages

Page Name	Description
[General]	Sets and displays the operation mode, emulation clock, and emulation mode conditions for the SH7410.
[Execution Mode1]	Sets and displays the program counter display interval, timer resolution, emulation memory bus width, BREQ signal control, user wait control, and performance count measurement mode conditions.
[Execution Mode2]	Sets and displays the conditions of the trigger output control when a break occurs.

Clicking the [OK] button sets emulation conditions. If the [Cancel] button is clicked, this dialog box is closed without setting emulation conditions. The [Apply] button cannot be used.

(1) [General] Page ([Configuration] Dialog Box)

Function:

This page sets and displays the conditions of the operation mode, emulation clock, and emulation mode for the SH7410.

Window:




Figure 4.2 [General] Page ([Configuration] Dialog Box)

Description:

Table 4.3 [General] Page Options

Option	Description
[Mode] combo box	Sets the operation mode (CS0-space bus width setting and clock mode). Select one of SH7410 MD4-0 Pins 0-1D.
[Clock] combo box	Sets the emulation clock. Select System clock, User clock, or X'TAL.
[Emulation mode] combo box	Selects the execution time measurement format. Select Normal to perform normal emulation. Select 6.5-us, 9.8-us, 50-us, 100-us, 500-us, 1-ms, 5-ms, 10-ms, 50-ms, 100-ms, 500-ms, or 1-s Cycle Reset for cycle reset mode execution. Select Time interval measurement mode 1 or Time interval measurement mode 2 for execution. Select Timeout break of PA1 to enable a time out that has been set by the [Performance_Analysis 1] command. Select No Break to disable breakpoint settings.
[UBC Sequential break mode] check box	Sets whether to break when the conditions set with [Break Condition UBC2] and [Break Condition UBC1] dialog boxes are satisfied in that order. When this setting is made, the condition set in the [Emulation mode] combo box is disabled.
[Display sequential break level both Break condition sequence and Trace condition sequence] check box	Sets whether to display, on the status bar during the execution, the level at which the sequential break condition set with the [Break Condition Sequence] and [Trace Condition Sequence] dialog boxes is satisfied.

Note:

If the settings of the operating mode (CS0-space bus width setting and clock mode) are changed, the emulator is initialized and all setting information is cleared.

Related Commands:

MODE command
CLOCK command
GO_OPTION command

(2) [Execution Mode1] Page ([Configuration] Dialog Box)

Function:

This page sets the conditions of the emulation execution mode.

Window:




Figure 4.3 [Execution Mode1] Page ([Configuration] Dialog Box)

Description:

Table 4.4 [Execution Mode1] Page Options

Option	Description
[Execution status display interval] combo box	Sets the program counter display interval on the status bar. Select Not display, About 200 ms, or About 2 s.
[The minimum time to be measured by Go command execution] combo box	Sets the resolution of the timer to be used for measuring execution time. Select 1.6 us, 406 ns, or 20 ns.
[Emulation memory bus width] combo box	Sets the emulation memory bus width. Select 32-bit bus width, 16-bit bus width, or 8-bit bus width.
[Enable the BREQ signal input] check box	Sets whether to enable the BREQ signal input during execution.
[Enable user wait] check box	Sets whether to enable user wait during execution.
[ECNT Option] group box	Sets the execution count measurement mode of the [Performance Analysis] command. Condition 1: Counts the number of times the subroutine end address is passed after the subroutine start address is passed. Condition 2: Simply counts the number of times the subroutine end address is passed. Select condition 1 or 2.

Related Command:

EXECUTION_MODE command

(3) [Execution Mode2] Page ([Configuration] Dialog Box)

Function:

This page also sets the conditions of the emulation execution mode.

Window:




Figure 4.4 [Execution Mode2] Page ([Configuration] Dialog Box)

Description:

Table 4.5 [Execution Mode2] Page Options

Button Name	Description
[TRGU Option]	<p>Sets the conditions related to control of the pulse output from the trigger output pin of the E8000 emulator when the conditions set with the [Break Condition UBC1] and [Break Condition UBC2] dialog boxes are satisfied.</p> <p>Condition 1: Break without trigger output</p> <p>Condition 2: Break and trigger output</p> <p>Condition 3: Trigger output without break</p> <p>Select condition 1, 2, or 3.</p>
[TRGB Option]	<p>Sets the conditions related to control of the pulse output from the trigger output pin of the E8000 emulator when the break condition set with the [Condition B] dialog box is satisfied.</p> <p>Condition 1: Break without trigger output when one of the conditions of channels 1 to 8 is satisfied</p> <p>Condition 2: Trigger output when one of the conditions of channels 1 to 8 is satisfied</p> <p>Condition 3: Trigger output when the set channel condition is satisfied</p> <p>Select condition 1, 2, or 3. When selecting condition 1, set the channel number.</p>

Related Command:

EXECUTION_MODE command

4.2.2 [Breakpoints] Window

Function:

This window lists all break conditions that have been set. To display the [Breakpoints] window, select [Breakpoint Window] from the [View] menu.

Window:




Figure 4.5 [Breakpoints] Window

Description:

The [Breakpoints] window displays breakpoint setting information. The items listed in the following tables are displayed.

Table 4.6 [Breakpoints] Window Display Items

Item	Description
[Enable]	Displays whether the break condition is enabled or disabled. Symbol X indicates that the break condition is enabled.
[File/Line]	Displays the file name and line number where the breakpoint is set.
[Symbol]	Displays the symbol corresponding to the breakpoint address. If no symbol has been defined for the address, a blank will be displayed.
[Address]	Displays the address where the breakpoint is set.
[Type]	Displays the break condition type as follows: Program: Software breakpoint Break Sequence: Software sequential breakpoint Break Condition Xn: Hardware break condition (X is A, B, or C, and n is a number.) Break Condition Sequence: Hardware break condition Break Condition UBCn: Hardware break condition (n is a number.)

Buttons in the window can be used to set, change, and clear breakpoints, and to enable or disable break conditions. The button functions are described in the following table.

Table 4.7 [Breakpoints] Window Button Operation

Button Name	Description
[Add]	Sets break conditions. Clicking this button will display the [Break] dialog box, enabling break conditions to be set.
[Edit]	Changes break conditions. Select break conditions to be changed and select this button. The break condition setting dialog box will be displayed, enabling the break condition to be changed.
[Delete]	Clears break conditions. Select break conditions to be cleared and select this button.
[Del All]	Clears all break conditions.
[Disable] ([Enable])	Enables or disables break conditions. Select break conditions to be enabled or disabled and select this button.
[Help]	Displays help information.

Similar button operations can also be performed with the pop-up menu displayed by clicking the view area with the right mouse button.

4.2.3 [Break] Dialog Box

Function:

This dialog box displays the break condition settings. To display the [Break] dialog box, click the [Add] button in the [Breakpoints] window.

Window:




Figure 4.6 [Break] Dialog Box

Description:

The [Break] dialog box consists of the pages listed in table 4.8.

Table 4.8 [Break] Dialog Box Pages

Page Name	Description
[Point]	Displays software breakpoint settings.
[Sequence]	Displays software sequential break point settings.
[Condition A]	Displays BREAK CONDITION A settings.
[Condition B]	Displays BREAK CONDITION B settings.
[Condition C]	Displays BREAK CONDITION C settings.
[Condition Sequence]	Displays BREAK CONDITION SEQUENCE settings.
[Condition UBC]	Displays BREAK CONDITION UBC settings.

The dialog box can be opened from the above pages to set or change break conditions.

Clicking the [Close] button will close this dialog box. The [Apply] button cannot be used.

(1) [Point] Page ([Break] Dialog Box)

Function:

This page displays software breakpoint settings. In this page, software breakpoints can be set, changed, and cleared.

Window:




Figure 4.7 [Point] Page ([Break] Dialog Box)

Description:

Table 4.9 [Point] Page Options

Option	Description
[Break point] list box	Lists the contents of the software breakpoint currently being set. The display contents are <breakpoint address> and <specified count>.
[Add...] button	Sets software breakpoints. Clicking this button displays the [Break Point] dialog box.
[Edit...] button	Changes the software breakpoint selected in the [Break Point] list box. Clicking this button displays the [Break Point] dialog box.
[Reset] button	Clears the software breakpoint selected in the [Break Point] list box.
[Reset All] button	Clears all software breakpoints displayed in the [Break Point] list box.

Related Commands:

BREAKPOINT command

BREAKPOINT_CLEAR command

BREAKPOINT_ENABLE command

BREAKPOINT_DISPLAY command

(2) [Sequence] Page ([Break] Dialog Box)

Function:

This page displays the software sequential breakpoint settings. These settings can also be set or cleared in this page.

Window:




Figure 4.8 [Sequence] Page ([Break] Dialog Box)

Description:

Table 4.10 [Sequence] Page Options

Option	Description
[Sequence point] list box	Displays the software sequential breakpoint settings. The default settings are as follows (Empty means no setting): 1 Empty (setting of pass point address 1) 2 Empty (setting of pass point address 2) 3 Empty (setting of pass point address 3) 4 Empty (setting of pass point address 4) 5 Empty (setting of pass point address 5) 6 Empty (setting of pass point address 6) 7 Empty (setting of pass point address 7) R Empty (setting of the reset point address)
[Edit...] button	Changes the software sequential breakpoint settings selected in the [Sequence point] list box. Clicking this button displays the [Break Sequence] dialog box.
[Reset All] button	Clears all software sequential breakpoint settings in the [Sequence point] list box.

Related Commands:

BREAKSEQUENCE_CLEAR command

BREAKSEQUENCE_DISPLAY command

BREAKSEQUENCE_ENABLE command

BREAKSEQUENCE_SET command

(3) [Condition A/B/C] Page ([Break] Dialog Box)

Function:

This page displays the BREAK CONDITION settings. These conditions can also be set or cleared in this page.

Window:




Figure 4.9 [Condition A] Page ([Break] Dialog Box)

The [Condition B] and [Condition C] pages are similar.

Description:

Table 4.11 [Condition A/B/C] Page Options

Option	Description
[Condition] list box	<p>Displays the BREAK CONDITION settings. The default settings are as follows (Empty means no setting):</p> <ol style="list-style-type: none">1 Empty (setting of BREAK CONDITION x1)2 Empty (setting of BREAK CONDITION x2)3 Empty (setting of BREAK CONDITION x3)4 Empty (setting of BREAK CONDITION x4)5 Empty (setting of BREAK CONDITION x5)6 Empty (setting of BREAK CONDITION x6)7 Empty (setting of BREAK CONDITION x7)8 Empty (setting of BREAK CONDITION x8) <p>(x is A, B, or C.)</p> <p>If the BREAK CONDITION settings are set and in the [Enable] state, the following is displayed:</p> <ol style="list-style-type: none">1 Enable <p>If the BREAK CONDITION settings are in the [Disable] state, the following is displayed and a command for sharing hardware can be set (see Notes):</p> <ol style="list-style-type: none">1 Disable Empty <p>If a command for sharing hardware is set in this state, the following is displayed:</p> <ol style="list-style-type: none">1 Disable By X1 (X is a command for sharing hardware.)
[Edit...] button	Changes the BREAK CONDITION setting selected in the [Condition] list box. Clicking this button displays the [Break Condition Xn] dialog box. (X is A, B, or C, and n is a number.)
[Reset] button	Clears the BREAK CONDITION setting selected in the [Condition] list box.
[Reset All] button	Clears all BREAK CONDITION settings in the [Condition] list box.

Notes:

Since BREAK CONDITION A shares hardware with TRACE CONDITION A, BREAK CONDITION A settings cannot be set or changed if TRACE CONDITION A has already been set.

Since BREAK CONDITION B shares hardware with TRACE CONDITION B, BREAK CONDITION SEQUENCE, and TRACE CONDITION SEQUENCE, BREAK CONDITION B settings cannot be set or changed if these settings have already been set. However, if BREAK CONDITION SEQUENCE settings are disabled, the conditions of BREAK CONDITION B can be set or changed. In this case, BREAK CONDITION SEQUENCE settings are cleared.

Since BREAK CONDITION C shares hardware with TRACE CONDITION C and PERFORMANCE ANALYSIS, BREAK CONDITION C settings cannot be set or changed if these settings have already been set.

(Example) If TRACE CONDITION A1, A4 settings have already been set, BREAK CONDITION A1, A4 cannot be set or changed.

(BREAK CONDITION A2, A3, A5, A6, A7, A8 can be set and changed.)

For BREAK CONDITION A, the display contents of the [Condition] list box are as follows:

- 1 By Trace Condition A1
- 2 Empty
- 3 Empty
- 4 By Trace Condition A4
- 5 Empty
- 6 Empty
- 7 Empty
- 8 Empty

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

(4) [Condition Sequence] Page ([Break] Dialog Box)

Function:

This page displays the BREAK CONDITION SEQUENCE settings. These conditions can also be set or cleared in this page.

Window:




Figure 4.10 [Condition Sequence] Page ([Break] Dialog Box)

Description:

Table 4.12 [Condition Sequence] Page Options

Option	Description
[Sequence condition] list box	<p>Displays the BREAK CONDITION SEQUENCE settings. The default settings are as follows (Empty means no setting):</p> <ol style="list-style-type: none">1 Empty (setting of BREAK CONDITION SEQUENCE1)2 Empty (setting of BREAK CONDITION SEQUENCE2)3 Empty (setting of BREAK CONDITION SEQUENCE3)4 Empty (setting of BREAK CONDITION SEQUENCE4)5 Empty (setting of BREAK CONDITION SEQUENCE5)6 Empty (setting of BREAK CONDITION SEQUENCE6)7 Empty (setting of BREAK CONDITION SEQUENCE7) <p>If the BREAK CONDITION SEQUENCE settings are set and in the [Enable] state, the following is displayed:</p> <ol style="list-style-type: none">1 Enable <p>If the BREAK CONDITION SEQUENCE settings are in the [Disable] state, the following is displayed and a command for sharing hardware can be set (see Notes):</p> <ol style="list-style-type: none">1 Disable <p>If a command for sharing hardware is set in this state, the following is displayed:</p> <ol style="list-style-type: none">1 Disable By X1 (X is a command for sharing hardware.)
[Edit...] button	Changes the BREAK CONDITION SEQUENCE setting selected in the [Sequence condition] list box. Clicking this button displays the [Break Condition Sequence n] dialog box. (n is a number.)
[Up] button	Moves up the setting selected in the [Sequence condition] list box.
[Down] button	Moves down the setting selected in the [Sequence condition] list box.
[Reset] button	Clears the BREAK CONDITION SEQUENCE setting selected in the [Sequence condition] list box.
[Reset All] button	Clears all BREAK CONDITION SEQUENCE settings in the [Sequence condition] list box and [Sequence Reset condition] edit box.
[Sequence Reset condition] edit box	Displays the reset conditions of the BREAK CONDITION SEQUENCE settings.
[R-Edit...] button	Changes the reset condition of the BREAK CONDITION SEQUENCE setting. Clicking this button displays the [Break Condition Sequence Reset] dialog box.
[R-Reset] button	Clears the reset condition of the BREAK CONDITION SEQUENCE setting in the [Sequence Reset condition] edit box.

Notes:

Since BREAK CONDITION SEQUENCE shares hardware with TRACE CONDITION B, BREAK CONDITION B, and TRACE CONDITION SEQUENCE, BREAK CONDITION SEQUENCE settings cannot be set or changed if these settings have already been set. The [Edit...] and [R-Edit...] buttons are disabled in this case. However, if BREAK CONDITION B settings are disabled, the conditions of BREAK CONDITION SEQUENCE can be set or changed. In this case, BREAK CONDITION B settings are cleared.

(Example) If TRACE CONDITION B1, B4 settings have already been set, BREAK CONDITION SEQUENCE cannot be set or changed.

For BREAK CONDITION SEQUENCE, the display contents of the [Sequence condition] list box are as follows:

- 1 By Trace Condition B1
- 2 Empty
- 3 Empty
- 4 By Trace Condition B4
- 5 Empty
- 6 Empty
- 7 Empty

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

(5) [Condition UBC] Page ([Break] Dialog Box)

Function:

This page displays the BREAK CONDITION UBC1, 2 settings. These conditions can also be set or cleared in this page.

Window:




Figure 4.11 [Condition UBC] Page ([Break] Dialog Box)

Description:**Table 4.13 [Condition UBC] Page Options**

Option	Description
[Condition] list box	Displays the BREAK CONDITION UBC settings. The default settings are as follows (Empty means no setting): 1 Empty (setting of BREAK CONDITION UBC1) 2 Empty (setting of BREAK CONDITION UBC2)
[Edit...] button	Changes the BREAK CONDITION UBC setting selected in the [Condition] list box. Clicking this button displays the [Break Condition UBC1] or [Break Condition UBC2] dialog box.
[Reset] button	Clears the BREAK CONDITION UBC setting selected in the [Condition] list box.
[Reset All] button	Clears all BREAK CONDITION UBC settings in the [Condition] list box.

Related Commands:

UBC_CLEAR command

UBC_DISPLAY command

UBC_ENABLE command

UBC_SET command

4.2.4 [Break Point] Dialog Box

Function:

This dialog box sets software breakpoints.

Window:




Figure 4.12 [Break Point] Dialog Box

Description:

The [Break Point] dialog box consists of the [Address] page only, and sets address conditions and pass count conditions. The option contents are listed in table 4.14.

Table 4.14 [Address] Page Options

Option	Description
[Value] edit box	Sets a breakpoint address with a number or a symbol.
[Count Number] edit box	Sets the pass count with a number. Breaks when a breakpoint is passed a specified number of times. The default setting is 1. Values from 1 to 65535 can be set.

Clicking the [OK] button enables breakpoints to be set. If the [Cancel] button is clicked, this dialog box is closed without setting breakpoints.

Related Commands:

BREAKPOINT command

BREAKPOINT_CLEAR command

BREAKPOINT_DISPLAY command

BREAKPOINT_SET command

4.2.5 [Break Point Sequence] Dialog Box

Function:

This dialog box sets software sequential breakpoints.

Window:




Figure 4.13 [Break Point Sequence] Dialog Box

Description:

The [Break Point Sequence] dialog box consists of the [Address] page only, and sets breakpoints and reset points by the pass sequence. The option contents are listed in table 4.15.

Table 4.15 [Address] Page Options

Option	Description
[Address1]–[Address7] edit boxes	Sets a breakpoint address by the pass sequence with a number or a symbol. Two to seven pass points can be set. Only 1 point cannot be set.
[Reset Point] edit box	Sets a reset point with a number or a symbol, which can be omitted.

Clicking the [OK] button sets breakpoints and reset points by the pass sequence. If the [Cancel] button is clicked, this dialog box is closed without setting breakpoints and reset points.

Related Commands:

BREAKSEQUENCE_CLEAR command
BREAKSEQUENCE_DISPLAY command
BREAKSEQUENCE_ENABLE command
BREAKSEQUENCE_SET command

4.2.6 [Break Condition A] Dialog Box

Function:

The [Break Condition A] dialog box sets hardware break conditions.

Window:




Figure 4.14 [Break Condition A1] Dialog Box

Description:

The [Break Condition A] dialog box is composed of a number of pages. Conditions for halting the program can be set in each page.

The various options are summarized in the following table.

Table 4.16 [Break Condition A] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition A address conditions.
[Data]	Sets Break Condition A data conditions.
[Bus State]	Sets Break Condition A bus state conditions and read/write cycle conditions.
[Probe]	Sets Break Condition A external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Break Condition A external interrupt signal (IRQ0–IRQ3) and NMI signal conditions.

For the settings in each page, see the description in section 4.2.10, [Break Condition] Dialog Box Pages.

Clicking the [OK] button sets hardware break conditions. If the [Cancel] button is clicked, the dialog box is closed without setting the hardware break conditions.

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

4.2.7 [Break Condition B] Dialog Box

Function:

The [Break Condition B] dialog box sets hardware break conditions.

Window:




Figure 4.15 [Break Condition B1] Dialog Box

Description:

The [Break Condition B] dialog box is composed of a number of pages. Conditions for halting the program can be set in each page.

The various options are summarized in the following table.

Table 4.17 [Break Condition B] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition B address conditions.
[Data]	Sets Break Condition B data conditions.
[Bus State]	Sets Break Condition B bus state conditions and read/write cycle conditions.
[Probe]	Sets Break Condition B external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Break Condition B external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Count]	Sets the satisfaction count conditions of Break Condition B. Displayed when Break Condition B1–B6 and B8 conditions are set.
[Delay & Count]	Sets the delay conditions or satisfaction count conditions of Break Condition B. Displayed when Break Condition B7 conditions are set.

For the settings in each page, see the description in section 4.2.10, [Break Condition] Dialog Box Pages.

Clicking the [OK] button sets hardware break conditions. If the [Cancel] button is clicked, the dialog box is closed without setting the hardware break conditions.

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

4.2.8 [Break Condition C] Dialog Box

Function:

The [Break Condition C] dialog box sets hardware break conditions.

Window:




Figure 4.16 [Break Condition C1] Dialog Box

Description

The [Break Condition C] dialog box is composed of a number of pages. Conditions for halting the program can be set in each page.

The various options are summarized in the following table.

Table 4.18 [Break Condition C] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition C address conditions.
[Bus State]	Sets Break Condition C bus state conditions and read/write cycle conditions.

For the settings in each page, see the description in section 4.2.10, [Break Condition] Dialog Box Pages.

Clicking the [OK] button sets hardware break conditions. If the [Cancel] button is clicked, the dialog box is closed without setting the hardware break conditions.

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

4.2.9 [Break Condition Sequence] Dialog Box

Function:

The [Break Condition Sequence] dialog box sets hardware break conditions.

Window:




Figure 4.17 [Break Condition Sequence1] Dialog Box

Description:

The [Break Condition Sequence] dialog box is composed of a number of pages. Conditions for halting the program can be set in each page.

The various options are summarized in the following table.

Table 4.19 [Break Condition Sequence] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition Sequence address conditions.
[Data]	Sets Break Condition Sequence data conditions.
[Bus State]	Sets Break Condition Sequence bus state conditions and read/write cycle conditions.
[Probe]	Sets Break Condition Sequence external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Break Condition Sequence external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Delay]	Sets Break Condition Sequence delay conditions. Displayed when Break Condition Sequence 7 conditions are set.

For the settings in each page, see the description in section 4.2.10, [Break Condition] Dialog Box Pages.

With the [Break Condition Sequence] dialog box, clicking the [OK] button sets hardware break conditions. If the [Cancel] button is clicked, the dialog box is closed without setting the hardware break conditions.

Related Commands:

BREAKCONDITION_CLEAR command
BREAKCONDITION_DISPLAY command
BREAKCONDITION_ENABLE command
BREAKCONDITION_SET command

4.2.10 [Break Condition] Dialog Box Pages

Function:

The [Break Condition] dialog box pages allow a number of hardware break conditions to be set. The following table shows all the [Break Condition] dialog box pages.

Table 4.20 [Break Condition] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition address conditions.
[Data]	Sets Break Condition data conditions.
[Bus State]	Sets Break Condition bus state conditions and read/write cycle conditions.
[Probe]	Sets Break Condition external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Break Condition external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Count]	Sets the satisfaction count conditions of Break Condition. Displayed when Break Condition B1–B6 and B8 conditions are set.
[Delay & Count]	Sets the delay conditions or satisfaction count conditions of Break Condition. Displayed when Break Condition B7 conditions are set.
[Delay]	Sets Break Condition delay conditions. Displayed when Break Condition Sequence 7 conditions are set.

(1) [Address] page ([Break Condition] dialog box)

Function:

Sets a condition for the address bus.

Window:




Figure 4.18 [Address] Page ([Break Condition] Dialog Box)

Description:**Table 4.21 [Address] Page Options**

Option	Description
[Don't Care] check box	Indicates that an address condition is not to be set.
[Address] radio button	Breaks at the address specified by [Start] or [Mask].
[Range] radio button	Breaks in the address range specified by [Start]–[End].
[Start] edit box	Sets the (start) address bus value with a number or a symbol.
[End] edit box	When [Range] is selected, sets the (end) address bus value with a number or a symbol.
[Outside Range] check box	Selected to break at an address outside the values set with [Start] or [Mask], or outside the range set with [Start]–[End]. Can be specified when Break Condition B or Break Condition Sequence conditions are set.
[Non user mask] radio button	A mask condition is not specified.
[User mask] radio button	A mask condition is specified.
[Mask] edit box	When [Address] and [User mask] are selected, sets the value to be masked. For masked bits, the condition is satisfied regardless of the address values. Invalid when [Range] is selected.

(2) [Data] page ([Break Condition] dialog box)

Function:

Sets a condition for the data bus.

Window:




Figure 4.19 [Data] Page ([Break Condition] Dialog Box)

Table 4.22 [Data] Page Options

Option	Description
[Don't Care] check box	Does not set data conditions.
[Value] edit box	Sets the data bus value with a number.
[Outside Range] check box	Sets under a data condition other than that set by [Value]. Can be specified when the conditions of Break Condition B and Break Condition Sequence are set.
[Byte] radio button	Sets byte data access cycles.
[Word] radio button	Sets word data access cycles.
[Long] radio button	Sets longword data access cycles.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits if [User mask] is selected. For masked bits, the break conditions will be satisfied regardless of the data values.

(3) [Bus State] Page ([Break Condition] Dialog Box)

Function:

This page sets bus state conditions and read/write cycle conditions.

Window:




Figure 4.20 [Bus State] Page ([Break Condition] Dialog Box)

Description:**Table 4.23 [Bus State] Page Options**

Option	Description
[Bus State] group box	Sets the bus state conditions by the following options.
[All] radio button	Does not set bus state conditions as break conditions.
[Data] radio button	Sets memory access cycles as break conditions.
[DMAC] radio button	Sets DMA cycles as break conditions.
[Vector Fetch] radio button	Sets vector fetch cycles as break conditions.
[Read/Write] group box	Sets the read/write cycle conditions by the following options.
[Read/Write] radio button	Does not set read/write cycle conditions as break conditions.
[Read] radio button	Sets read cycles as break conditions.
[Write] radio button	Sets write cycles as break conditions.

(4) [Probe] Page ([Break Condition] Dialog Box)

Function:

This page sets the external probe signal (PRB1–PRB4) conditions.

Window:

Address	Data	Bus State	Probe	Interrupt	Count
Probe 1					
<input checked="" type="radio"/> High					
<input type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 2					
<input type="radio"/> High					
<input checked="" type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 3					
<input checked="" type="radio"/> High					
<input type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 4					
<input type="radio"/> High					
<input type="radio"/> Low					
<input checked="" type="radio"/> Don't Care					

Figure 4.21 [Probe] Page ([Break Condition] Dialog Box)

Description:**Table 4.24 [Probe] Page Options**

Option	Description
[Probe1]–[Probe4] group box	Selects the external probe signal (PRB1–PRB4) conditions by the following options.
[High] radio button	Sets high-level external probe signals as break conditions.
[Low] radio button	Sets low-level external probe signals as break conditions.
[Don't Care] radio button	Does not set external probe signal states as break conditions.

(5) [Interrupt] Page ([Break Condition] Dialog Box)

Function:

This page sets the external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.

Window:




Figure 4.22 [Interrupt] Page ([Break Condition] Dialog Box)

Description:**Table 4.25 [Interrupt] Page Options**

Option	Description
[IRQ0]–[IRQ3] group box	Selects the external interrupt signal (IRQ0–IRQ3) conditions by the following options.
[High] radio button	Sets high-level external interrupt signals as break conditions.
[Low] radio button	Sets low-level external interrupt signals as break conditions.
[Don't Care] radio button	Does not set external interrupt signal states as break conditions.
[NMI] group box	Selects the NMI signal conditions by the following options.
[High] radio button	Sets high-level NMI signals as break conditions.
[Low] radio button	Sets low-level NMI signals as break conditions.
[Don't Care] radio button	Does not set NMI signal states as break conditions.

(6) [Count] Page ([Break Condition] Dialog Box)

Function:

This page sets the satisfaction count condition.

Window:




Figure 4.23 [Count] Page ([Break Condition] Dialog Box)

Description:**Table 4.26 [Count] Page Options**

Option	Description
[Don't Care] check box	Does not set satisfaction count conditions.
Input area	Sets the satisfaction count conditions with a number. Breaks when the conditions set by the [Break Condition] dialog box are satisfied a specified number of times. The default is 1.

This page is displayed when the conditions of BREAK CONDITION B1–B6 and B8 are set.

Note:

The [Count] option cannot be independently used. Use this option together with other options.

(7) [Delay & Count] Page ([Break Condition] Dialog Box)

Function:

This page sets the delay and the satisfaction count condition.

Window:




Figure 4.24 [Delay & Count] Page ([Break Condition] Dialog Box)

Description:**Table 4.27 [Delay & Count] Page Options**

Option	Description
[Don't Care] check box	Does not set delay conditions and no satisfaction count conditions.
[Count] radio button	Sets the satisfaction count conditions.
[Delay] radio button	Sets the delay conditions.
Input area	Sets the delay and satisfaction count conditions with a numerical value. The default is 1.

This page is displayed when the conditions of Break Condition B7 are set.

Note:

The [Delay & Count] option cannot be independently used. Use this option together with other options.

(8) [Delay] Page ([Break Condition] Dialog Box)

Function:

Sets delay conditions.

Window:




Figure 4.25 [Delay] Page ([Break Condition] Dialog Box)

Description:**Table 4.28 [Delay] Page Options**

Option	Description
[Don't Care] check box	Does not set delay conditions.
Input area	Sets the value for the delay conditions with a number. When the conditions set in the [Break Condition] dialog box are satisfied, a break occurs after the delay of the number of bus cycles set here. The default setting is 1.

Displayed when Break Condition Sequence7 condition are set.

Note:

The [Delay] option cannot be independently used. Use this option together with other options.

4.2.11 [Break Condition UBC] Dialog Box

Function:

The [Break Condition UBC] dialog box is used to set hardware break conditions.

Window:




Figure 4.26 [Break Condition UBC1] Dialog Box

Description:

The [Break Condition UBC] dialog box is composed of a number of pages. For the settings in each page, see the description in section 4.2.12, [Break Condition UBC] Dialog Box Pages.

When the [OK] button is clicked, the hardware break conditions are set. If the [Cancel] button is clicked, the dialog box is closed without setting the hardware break conditions.,

Related Commands:

UBC_CLEAR command

UBC_DISPLAY command

UBC_ENABLE command

UBC_SET command

4.2.12 [Break Condition UBC] Dialog Box Pages

Function:

The [Break Condition UBC] dialog box pages allow a number of hardware break conditions to be set. The following table shows all the [Break Condition UBC] dialog box pages.

Table 4.29 [Break Condition UBC] Dialog Box Pages

Page Name	Function
[Address]	Sets Break Condition UBC address conditions.
[Data]	Sets Break Condition UBC data conditions. Displayed when Break Condition UBC1 conditions are set.
[Bus State]	Sets Break Condition UBC bus state conditions and read/write cycle conditions.
[Count]	Sets the satisfaction count conditions of Break Condition UBC. Displayed when Break Condition UBC1 conditions are set.

(1) [Address] Page ([Break Condition UBC] Dialog Box)

Function:

This page sets the address bus conditions.

Window:




Figure 4.27 [Address] Page ([Break Condition UBC] Dialog Box)

Description:

Table 4.30 [Address] Page Options

Option	Description
[Don't Care] check box	Does not set address conditions.
[Address] radio button	Sets use of the normal address bus as break conditions.
[Prefetch address break before executing] radio button	Sets a break before prefetched address execution as break conditions.
[Prefetch address break after executing] radio button	Sets a break after prefetched address execution as break conditions.
[X-Bus address] radio button	Sets use of the X-BUS address bus as break conditions. Can be set only with the BREAK CONDITION UBC 1.
[Y-Bus address] radio button	Sets use of the Y-BUS address bus as break conditions. Can be set only with the BREAK CONDITION UBC 1.
[Address] edit box	Sets the address value with a number or a symbol.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits if [User mask] is selected. For masked bits, the break conditions will be satisfied regardless of the address values.

If the selection of an address type is changed, items displayed in [Break Condition UBC] are changed. The items that can be set are listed in table 4.31.

Table 4.31 Address Type Selection and Items That Can be Set

Address Type Selection	Items that can be set by [Break Condition UBC]
[Address], [X-Bus address], or [Y-Bus Address]	[Address], [Data], [Bus State], and [Count] ([Data] and [Count] cannot be displayed with Break Condition UBC2.)
[Prefetch address break before executing] or [Prefetch address break after executing]	[Address] and [Count] ([Count] cannot be displayed with Break Condition UBC2.)

(2) [Data] Page ([Break Condition UBC] Dialog Box)

Function:

This page sets the data bus conditions.

Window:

The image shows a dialog box window with four tabs: "Address", "Data", "Bus State", and "Count". The "Data" tab is selected. Inside the "Data" tab, there is a "Data" section. At the top of this section is a checkbox labeled "Don't Care". Below it is a text box labeled "Value" containing the text "H' 10ff". Underneath the "Value" box are five radio buttons: "Byte", "Word", "Long", "X-Bus data" (which is selected), and "Y-Bus data". Below these are two more radio buttons: "Non user mask" (selected) and "User mask". At the bottom of the "Data" section is a text box labeled "Mask".

Figure 4.28 [Data] Page ([Break Condition UBC] Dialog Box)

Description:

Table 4.32 [Data] Page Options

Option	Description
[Don't Care] check box	Does not set data conditions.
[Value] edit box	Sets the data bus value with a number.
[Byte] radio button	Sets byte data access cycles.
[Word] radio button	Sets word data access cycles.
[Long] radio button	Sets longword data access cycles.
[X-Bus data] radio button	Sets X-BUS data bus access cycles.
[Y-Bus data] radio button	Sets Y-BUS data bus access cycles.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits if [User mask] is selected. For masked bits, the break conditions will be satisfied regardless of the address values.

This page is displayed when the conditions of Break Condition UBC1 are set.

(3) [Bus State] Page ([Break Condition UBC] Dialog Box)

Function:

This page sets bus state conditions and read/write cycle conditions.

Window:




Figure 4.29 [Bus State] Page ([Break Condition UBC] Dialog Box)

Description:**Table 4.33 [Bus State] Page Options**

Option	Description
[Bus State] group box	Sets the bus state conditions by the following options.
[All] radio button	Does not set bus state conditions as break conditions.
[Data] radio button	Sets memory access as break conditions.
[DMAC] radio button	Sets DMA cycles as break conditions.
[Read/Write] group box	Sets the read/write cycle conditions by the following options.
[Read/Write] radio button	Does not set read/write cycle conditions as break conditions.
[Read] radio button	Sets read cycles as break conditions.
[Write] radio button	Sets write cycles as break conditions.

(4) [Count] Page ([Break Condition UBC] Dialog Box)

Function:

This page sets the satisfaction count conditions.

Window:



Figure 4.30 [Count] Page ([Break Condition UBC] Dialog Box)

Description:**Table 4.34 [Count] Page Options**

Option	Description
[Don't Care] check box	Does not set satisfaction count conditions.
Input area	Sets the satisfaction count as break conditions. Breaks when the conditions set by the [Break Condition UBC] dialog box are satisfied a specified number of times. The default is 1.

This page is displayed when the conditions of BREAK CONDITION UBC1 are set.

4.2.13 [Memory Mapping] Window

Function:

This window can display and modify emulation memory allocation information. To display the [Memory Mapping] window, select [Memory Mapping Window] from the [View] menu.

Window:




Figure 4.31 [Memory Mapping] Window

Description:

This window displays emulation memory allocation information. The items listed in table 4.35 are displayed.

Table 4.35 [Memory Mapping] Window Display Items

Item	Description
[From To Mapping] list box	Displays memory address and memory type settings.
[Target Device Configuration] list box	Displays the memory mapping of the X-ROM space, X-RAM space, Y-ROM space, Y-RAM space, and peripheral module (INTERNAL I/O).
[System memory resources] list box	Displays the total capacity and remaining capacity of the emulation memory.
[Memory type] combo box	Selects the emulation memory type.

Table 4.36 [Memory Mapping] Window Button Functions

Button Name	Description
[Edit]	Changes memory allocation information. Clicking this button displays the Edit Memory Mapping dialog box.
[Add]	Allocates new memory. Clicking this button displays the Edit Memory Mapping dialog box.
[Reset]	Resets the memory allocation information selected by [From To Mapping].
[Help]	Displays help information.

Related Command:

MAP_SET command

4.2.14 [Edit Memory Mapping] Dialog Box

Function:

This dialog box can display and change emulation memory allocation information. To display the [Edit Memory Mapping] dialog box, click the [Edit] button in the [Memory Mapping] window.

Window:




Figure 4.32 [Edit Memory Mapping] Dialog Box

Description:

This dialog box displays emulation memory allocation information.

Table 4.37 [Edit Memory Mapping] Page Options

Option	Description
[From] edit box	Sets the start address of the memory block.
[To] edit box	Sets the end address of the memory block.
[Setting] combo box	Selects the memory type.

Clicking the [OK] button enables each condition to be set. The following shows memory types that can be set by the [Setting] combo box.

Table 4.38 Memory Type

Memory type	Description
EMULATION AREA	Sets the address range in the emulation memory area.
USER AREA	Sets the address range in the user memory area.
EMULATION Read-Only	Sets the address range as a write-protected area in the emulation memory area.

Related Command:

MAP_SET command

4.2.15 [Trace] Window

Function:

This window displays the trace buffer contents. To display the [Trace] window, select [Trace Window] from the [View] menu.

Window:

Cycle	Label	PC	Code	AB	DB	Area	R/W	Stat	IRQ	NMI	RBS	BRBQ	VCC	PROB	Time Stamp
-001961		01000028	ADD #H'01, R2	0107ffff	010003cc	EXT	R	DAT	1111	1	1	1	1	1111	000H00M448
-001960		01000028	ADD #H'01, R2	010003cc	00013415	EXT	R	DAT	1111	1	1	1	1	1111	000H00M448
-001959		0100002a	BRA @H'1000008	01000030	2fe6605f	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001958		0100002c	MOV.L R2, @R14	01000008	e500b010	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001957	sort(section1, NAME);	01000008	MOV #H'00, R5	0100000c	64d3e501	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001956		0100003c		010003cc	00013416	EXT	W	DAT	1111	1	1	1	1	1111	000H00M448
-001955		0100000a	BSR @_sort:12	01000010	62e27201	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001954		0100002e	****e700	0100002e	****e700	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001953		0100000c	MOV R13, R4	01000030	2fe6605f	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001952	switch(key) {	0100002e	MOV #H'00, R7	01000034	2fd68800	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001951	_sort	01000030	MOV.L R14, @-R1	01000038	4e227ff0	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001950		01000032	EXTS.W R5, R0	01000038	4e227ff0	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001950		01000034	MOV.L R13, @-R1	0107ffff	010003cc	EXT	W	DAT	1111	1	1	1	1	1111	000H00M448
-001949		01000036	CMP/EQ #H'00, R	0100003c	66f38907	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001948		01000038	STS.L ER, @-R15	0107ffff	0100036c	EXT	W	DAT	1111	1	1	1	1	1111	000H00M448
-001947		0100003a	ADD #H'F0, R15	01000040	88018945	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448
-001946		0100003c	MOV R15, R6	0107ffff	0100000e	EXT	W	DAT	1111	1	1	1	1	1111	000H00M448
-001945		0100003e	EM @H'1000050	01000044	88028b01	EXT	R	PRG	1111	1	1	1	1	1111	000H00M448

Total Records: 4972

Find Filter Snapshot Halt Clear
Find Next Acquisition Restart Save

Figure 4.33 [Trace] Window

Description:

This window displays the trace buffer contents. The items listed in table 4.39 are displayed.

Table 4.39 [Trace] Window Display Items

Item	Description
[Cycle]	Displays the number of bus cycles (signed decimal). Set the value with a bus cycle as an origin (0) when a delay condition is satisfied. A cycle before that point is a negative value. Delay conditions set by [Condition B] and [Condition Sequence] dialog boxes are displayed.
[Label]	Displays the label name. If there is no label, nothing is displayed.
[PC]	Displays the program counter value.
[Code]	Displays the execution instruction code. If a cycle has no execution instruction, nothing is displayed.
[AB]	Displays the address bus value.
[DB]	Displays the data bus value.
[Area]	Displays the accessed memory area type. IO: Internal I/O area access EXT: CS0-CS3 area access (including reserved-area access) INT: Internal area access
[R/W]	Displays the read cycle (R) and write cycle (W) types.
[Status]	Displays the state. PRG: Instruction fetch cycle (including PC-relative data access) DAT: Data access cycle (excluding PC-relative data access) DMA: Internal DMAC execution cycle VCF: Vector fetch cycle REF: Refresh cycle STY: Standby state BRL: Bus-release state
[IRQ]	Displays the external interrupt signal state (0: Low level; 1: High level). The IRQ numbers are 3, 2, 1, and 0 from left.
[NMI]	Displays the NMI signal state (0: Low level; 1: High level).
[RESET]	Displays the RESET signal state (0: Low level; 1: High level).
[BREQ]	Displays the BREQ signal state (0: Low level; 1: High level).
[VCC]	Displays the VCC signal state (0: 2.65 V or less; 1: 2.65 V or higher).
[PROBES]	Displays the external probe signal state (0: Low level; 1: High level). The external probe numbers are 4, 3, 2, and 1 from left.
[Time Stamp/Clock]	Displays the time stamp value (default). The time stamp display format is as follows: xxxHxxMxxSxxxxxUxxxN (H: hour, M: minute, S: second, U: microsecond, N: nanosecond). With the [Trace Mode] page settings, the clock count from the end of the previous bus cycle to the end of this bus cycle can also be displayed.

Table 4.39 [Trace] Window Display Items (cont)

Item	Description
[Total Records]	Displays the total number of bus cycles of trace information displayed in the [Trace] window.

The trace buffer contents are displayed in C language and assembly language to make debugging easy. However, if the trace filtering function is used, the contents are displayed only in assembly language.

Table 4.40 [Trace] Window Button Functions

Button Name	Description
[Find]	Displays the [Trace Find] dialog box.
[Find Next]	Searches the next trace information that matches the condition set by the [Trace Find] dialog box.
[Filter]	Displays the [Trace Filter] dialog box.
[Acquisition]	Displays the [Trace Acquisition] dialog box.
[Snapshot]	Not supported.
[Halt]	Halts trace information acquisition (in parallel mode).
[Restart]	Restarts trace information acquisition (in parallel mode).
[Clear]	Clears the displayed trace information.
[Save]	Saves the displayed information in a file.

Notes: 1 The following message will be displayed in the last bus cycle when the user program stops. Ignore this cycle because it is an emulator cycle; it is not a user program cycle.

*** E8000 ***

- 2 If the displayed character string of the execution instruction code such as a DSP instruction execution cycle is long, only part of the string may be displayed in [Code].

Related Command:

TRACE command

4.2.16 [Trace Acquisition] Dialog Box

Function:

This dialog box sets the trace acquisition conditions and displays the settings. To display the [Trace Acquisition] dialog box, click the [Acquisition] button in the [Trace] window.

Window:




Figure 4.34 [Trace Acquisition] Dialog Box

Description:

The [Trace Acquisition] dialog box consists of pages listed in table 4.41.

Table 4.41 [Trace Acquisition] Dialog Box

Page Name	Description
[Trace Mode]	Sets TRACE MODE conditions.
[Condition A]	Displays TRACE CONDITION A settings.
[Condition B]	Displays TRACE CONDITION B settings.
[Condition C]	Displays TRACE CONDITION C settings.
[Condition Sequence]	Displays TRACE CONDITION SEQUENCE settings.

The dialog box for setting and changing trace acquisition and display conditions can be displayed by the above pages.

Clicking the [Close] button will close this dialog box. The [Apply] button cannot be used.

(1) [Trace Mode] Page ([Trace Acquisition] Dialog Box)

Function:

This page sets the trace acquisition modes.

Window:




Figure 4.35 [Trace Mode] Page ([Trace Acquisition] Dialog Box)

Description:

Table 4.42 [Trace Mode] Page Options

Option	Description
[DMA cycle trace] check box	Sets whether to acquire DMA-cycle trace information in the trace buffer.
[Refresh cycle trace] check box	Sets whether to acquire refresh-cycle trace information in the trace buffer.
[Program stop in trace overflow] check box	Sets whether to stop user program execution when the trace buffer overflows.
[Clock] combo box	Selects whether to acquire the measurement results of the time stamp into the trace buffer or to acquire the clock count. If acquiring the measurement results of the time stamp, select 20 ns, 1.6 us, or 52 us for the time stamp measurement interval. If acquiring the number of clocks, select Clock.
[Apply] button	Updates [Trace Mode] conditions. If no button is selected, no settings are updated.

Related Command:

TRACE_MODE command

(2) [Condition A/B/C] Page ([Trace Acquisition] Dialog Box)

Function:

This page displays the TRACE CONDITION settings. These conditions can also be set or cleared in this page.

Window:




Figure 4.36 [Condition A] Page ([Trace Acquisition] Dialog Box)

The [Condition B] and [Condition C] pages are similar.

Description:

Table 4.43 [Condition A/B/C] Page Options

Option	Description
[Condition] list box	<p>Displays the TRACE CONDITION settings. The default settings are as follows (Empty means no setting):</p> <ol style="list-style-type: none">1 Empty (Displays TRACE CONDITION x1 setting)2 Empty (Displays TRACE CONDITION x2 setting)3 Empty (Displays TRACE CONDITION x3 setting)4 Empty (Displays TRACE CONDITION x4 setting)5 Empty (Displays TRACE CONDITION x5 setting)6 Empty (Displays TRACE CONDITION x6 setting)7 Empty (Displays TRACE CONDITION x7 setting)8 Empty (Displays TRACE CONDITION x8 setting) <p>(x is A, B, or C.)</p> <p>If the TRACE CONDITION settings are set, the following is displayed:</p> <ol style="list-style-type: none">1 Enable
[Edit...] button	Changes the TRACE CONDITION setting selected in the [Condition] list box. Selecting this button displays the [Trace Condition Xn] dialog box. (X is A, B, or C, and n is a number.)
[Reset] button	Clears the TRACE CONDITION setting selected in the [Condition] list box.
[Reset All] button	Clears all TRACE CONDITION settings in the [Condition] list box.

Notes:

Since TRACE CONDITION A shares hardware with BREAK CONDITION A, TRACE CONDITION A settings cannot be set or changed if BREAK CONDITION A has already been set.

Since TRACE CONDITION B shares hardware with BREAK CONDITION B, BREAK CONDITION SEQUENCE, and TRACE CONDITION SEQUENCE, TRACE CONDITION B settings cannot be set or changed if these settings have already been set. However, if BREAK CONDITION B and BREAK CONDITION SEQUENCE settings are disabled, the conditions of TRACE CONDITION B can be set or changed. In this case, BREAK CONDITION B and BREAK CONDITION SEQUENCE settings are cleared.

Since TRACE CONDITION C shares hardware with BREAK CONDITION C and PERFORMANCE ANALYSIS, TRACE CONDITION C settings cannot be set or changed if these settings have already been set.

(Example)

If BREAK CONDITION A1, A4 settings have already been set, TRACE CONDITION A1, A4 cannot be changed. (TRACE CONDITION A2, A3, A5, A6, A7, A8 can be set.)

For TRACE CONDITION A, the display contents of the [Condition] list box are as follows:

- 1 By Break Condition A1
- 2 Empty
- 3 Empty
- 4 By Break Condition A4
- 5 Empty
- 6 Empty
- 7 Empty
- 8 Empty

Related Commands:

TRACEACQUISITION_CLEAR command
TRACEACQUISITION_DISPLAY command
TRACEACQUISITION_SET command

(3) [Condition Sequence] Page ([Trace Acquisition] Dialog Box)

Function:

This page displays the TRACE CONDITION SEQUENCE settings. These conditions can also be set or cleared in this page.

Window:




Figure 4.37 [Condition Sequence] Page ([Trace Acquisition] Dialog Box)

Description:

Table 4.44 [Condition Sequence] Page Options

Option	Description
[Sequence condition] list box	<p>Displays the TRACE CONDITION SEQUENCE settings. The default settings are as follows (Empty means no setting):</p> <ol style="list-style-type: none">1 Empty (TRACE CONDITION SEQUENCE1 setting)2 Empty (TRACE CONDITION SEQUENCE2 setting)3 Empty (TRACE CONDITION SEQUENCE3 setting)4 Empty (TRACE CONDITION SEQUENCE4 setting)5 Empty (TRACE CONDITION SEQUENCE5 setting)6 Empty (TRACE CONDITION SEQUENCE6 setting)7 Empty (TRACE CONDITION SEQUENCE7 setting) <p>If the TRACE CONDITION SEQUENCE settings are set, the following is displayed:</p> <ol style="list-style-type: none">1 Enable
[Edit...] button	Changes the TRACE CONDITION SEQUENCE setting selected in the [Sequence condition] list box. Selecting this button displays the [Trace Condition Sequence n] dialog box (n is a number).
[Up] button	Moves up the settings selected in the [Sequence condition] list box.
[Down] button	Moves down the settings selected in the [Sequence condition] list box.
[Reset] button	Clears the TRACE CONDITION SEQUENCE setting selected in the [Sequence condition] list box.
[Reset All] button	Clears all TRACE CONDITION SEQUENCE settings in the [Sequence condition] list box and the [Sequence Reset condition] edit box.
[Sequence Reset condition] edit box	Displays the reset conditions of the TRACE CONDITION SEQUENCE settings.
[R-Edit...] button	Changes the reset condition of the TRACE CONDITION SEQUENCE setting. Selecting this button displays the [Trace Condition Sequence Reset] dialog box.
[R-Reset] button	Clears the reset condition of the TRACE CONDITION SEQUENCE setting in the [Sequence Reset condition] edit box.

Notes:

Since TRACE CONDITION SEQUENCE shares hardware with BREAK CONDITION B, TRACE CONDITION B, and BREAK CONDITION SEQUENCE, TRACE CONDITION SEQUENCE settings cannot be set or changed if these settings have already been set. In this case, the [Edit...] and [R-Edit...] buttons are disabled. However, if BREAK CONDITION B and BREAK CONDITION SEQUENCE settings are disabled, the conditions of TRACE CONDITION SEQUENCE can be set or changed. In this case, BREAK CONDITION B and BREAK CONDITION SEQUENCE settings are cleared.

(Example)

If TRACE CONDITION B1, B4 settings have already been set, TRACE CONDITION SEQUENCE cannot be set or changed.

For TRACE CONDITION SEQUENCE, the displayed contents of the [Sequence condition] list box are as follows:

- 1 By Trace Condition B1
- 2 Empty
- 3 Empty
- 4 By Trace Condition B4
- 5 Empty
- 6 Empty
- 7 Empty

Related Commands:

TRACEACQUISITION_CLEAR command

TRACEACQUISITION_DISPLAY command

TRACEACQUISITION_SET command

4.2.17 [Trace Condition A] Dialog Box

Function:

The [Trace Condition A] dialog box sets trace information acquisition conditions.

Window:




Figure 4.38 [Trace Condition A1] Dialog Box

Description:

The [Trace Condition A] dialog box is composed of six pages. Conditions for trace information acquisition can be set in each page.

The various options are summarized in the following table.

Table 4.45 [Trace Condition A] Dialog Box Pages

Page Name	Function
[General]	Sets the trace acquisition method.
[Address]	Sets Trace Condition A address conditions.
[Data]	Sets Trace Condition A data conditions.
[Bus State]	Sets Trace Condition A bus state conditions and read/write cycle conditions.
[Probe]	Sets Trace Condition A external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Trace Condition A external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.

For the settings in each page, see the description in section 4.2.21, [Trace Condition] Dialog Box Pages.

With the [Trace Condition A] dialog box, when the [OK] button is clicked, the dialog box is closed and the trace information acquisition conditions are set. If the [Cancel] button is clicked, the dialog box is closed without setting the trace information acquisition conditions.

Related Commands:

TRACEACQUISITION_CLEAR command
TRACEACQUISITION_DISPLAY command
TRACEACQUISITION_SET command

4.2.18 [Trace Condition B] Dialog Box

Function:

The [Trace Condition B] dialog box sets trace information acquisition conditions.

Window:




Figure 4.39 [Trace Condition B1] Dialog Box

Description:

The [Trace Condition B] dialog box is composed of a number of pages. Conditions for trace information acquisition can be set in each page.

The various options are summarized in the following table.

Table 4.46 [Trace Condition B] Dialog Box Pages

Page Name	Function
[General]	Sets the trace acquisition method.
[Address]	Sets Trace Condition B address conditions.
[Data]	Sets Trace Condition B data conditions.
[Bus State]	Sets Trace Condition B bus state conditions and read/write cycle conditions.
[Probe]	Sets Trace Condition B external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Trace Condition B external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Count]	Sets the satisfaction count conditions of Trace Condition B. Displayed when Trace Condition B1–B6 and B8 conditions are set.
[Delay & Count]	Sets the delay conditions or satisfaction count conditions of Trace Condition B. Displayed when Trace Condition B7 conditions are set.

For the settings in each page, see the description in section 4.2.21, [Trace Condition] Dialog Box Pages.

When the [OK] button is clicked, the trace information acquisition conditions are set. If the [Cancel] button is clicked, the dialog box is closed without setting the trace information acquisition conditions.

Related Commands:

TRACEACQUISITION_CLEAR command
TRACEACQUISITION_DISPLAY command
TRACEACQUISITION_SET command

4.2.19 [Trace Condition C] Dialog Box

Function:

The [Trace Condition C] dialog box sets trace information acquisition conditions.

Window:




Figure 4.40 [Trace Condition C1] Dialog Box

Description:

The [Trace Condition C] dialog box is composed of a number of pages. Conditions for trace information acquisition can be set in each page.

The various options are summarized in the following table.

Table 4.47 [Trace Condition C] Dialog Box Pages

Page Name	Function
[General]	Sets the trace acquisition method.
[Address]	Sets Trace Condition C address conditions.
[Bus State]	Sets Trace Condition C bus state conditions and read/write cycle conditions.

For the settings in each page, see the description in section 4.2.21, [Trace Condition] Dialog Box Pages.

When the [OK] button is clicked, the trace information acquisition conditions are set. If the [Cancel] button is clicked, the dialog box is closed without setting the trace information acquisition conditions.

Related Commands:

TRACEACQUISITION_CLEAR command
TRACEACQUISITION_DISPLAY command
TRACEACQUISITION_SET command

4.2.20 [Trace Condition Sequence] Dialog Box

Function:

The [Trace Condition Sequence] dialog box sets trace information acquisition conditions.

Window:




Figure 4.41 [Trace Condition Sequence1] Dialog Box

Description:

The [Trace Condition Sequence] dialog box is composed of a number of pages. Conditions for trace information acquisition can be set in each page.

The various options are summarized in the following table.

Table 4.48 [Trace Condition Sequence] Dialog Box Pages

Page Name	Function
[Address]	Sets Trace Condition Sequence address conditions.
[Data]	Sets Trace Condition Sequence data conditions.
[Bus State]	Sets Trace Condition Sequence bus state conditions and read/write cycle conditions.
[Probe]	Sets Trace Condition Sequence external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Trace Condition Sequence external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Delay]	Sets Trace Condition Sequence delay conditions. Displayed when Trace Condition Sequence 7 conditions are set.

For the settings in each page, see the description in section 4.2.21, [Trace Condition] Dialog Box Pages.

When the [OK] button is clicked, the trace information acquisition conditions are set. If the [Cancel] button is clicked, the dialog box is closed without setting the trace information acquisition conditions.

Related Commands:

TRACEACQUISITION_CLEAR command

TRACEACQUISITION_DISPLAY command

TRACEACQUISITION_SET command

4.2.21 [Trace Condition] Dialog Box Pages

Function:

The [Trace Condition] dialog box pages allow a number of trace information acquisition conditions to be set. The following table shows all the [Trace Condition] dialog box pages.

Table 4.49 [Trace Condition] Dialog Box Pages

Page Name	Function
[General]	Sets the trace acquisition method.
[Address]	Sets Trace Condition address conditions.
[Data]	Sets Trace Condition data conditions.
[Bus State]	Sets Trace Condition bus state conditions and read/write cycle conditions.
[Probe]	Sets Trace Condition external probe signal (PRB1–PRB4) conditions.
[Interrupt]	Sets Trace Condition external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.
[Count]	Sets the satisfaction count conditions of Trace Condition. Displayed when Trace Condition B1–B6 and B8 conditions are set.
[Delay & Count]	Sets the delay conditions or satisfaction count conditions of Trace Condition. Displayed when Trace Condition B7 conditions are set.
[Delay]	Sets Trace Condition delay conditions. Displayed when Trace Condition Sequence 7 conditions are set.

(1) [General] Page ([Trace Condition] Dialog Box)

Function:

This page sets the trace acquisition.

Window:

The screenshot shows a dialog box with a tabbed interface. The 'General' tab is selected. The 'Mode' section has four radio button options: 'Range', 'Trace Stop' (which is selected and has a dotted border), 'Subroutine', and 'Range in subroutine'. The 'Subroutine Address' section contains two text input fields: 'Start' and 'End', both of which contain the hexadecimal value 'H'0'.

Figure 4.42 [General] Page ([Trace Condition] Dialog Box)

Description:

Table 4.50 [General] Page Options

Option	Description
[Mode] group box	Sets trace acquisition mode.
[Range] radio button	Acquires trace when Trace Condition is satisfied.
[Trace Stop] radio button	Stops trace acquisition when Trace Condition is satisfied.
[Subroutine] radio button	Acquires trace for the address range set by [Subroutine Address].
[Range in subroutine] radio button	Acquires trace when the Trace Condition is satisfied and the address range condition set by [Subroutine Address] is satisfied.
[Subroutine Address] group box	Sets the address range for [Subroutine] and [Range in subroutine].
[Start] edit box	Sets the start address value with a number or a symbol.
[End] edit box	Sets the end address value with a number or a symbol when [Range] is selected.

Selecting [Mode] of [General] causes the displayed items in the [Trace Condition] dialog box to be changed. The items that can be set are listed in table 4.51.

Table 4.51 [Mode] Selection and Items That Can be Set

[Mode] selection	Items that can be set by [Trace Condition]
[Range] radio button	[Address], [Data], [Bus State], [Probe], [Interrupt]
[Trace Stop] radio button	[Address], [Data], [Bus State], [Probe], [Interrupt], [Count], [Delay & Count] ([Count] can be set when Trace Conditions B1–B6 and B8 are set, and [Delay & Count] can be set when TRACE CONDITION B7 is set.)
[Subroutine] radio button	[General]
[Range in subroutine] radio button	[General], [Address], [Data], [Bus State], [Probe], [Interrupt]

Notes:

When [Range in subroutine] is selected, note the following:

1. When TRACE CONDITION B2 is set, TRACE CONDITION B1 cannot select [Range in subroutine].
2. When TRACE CONDITION B4 is set, TRACE CONDITION B3 cannot select [Range in subroutine].
3. When TRACE CONDITION B6 is set, TRACE CONDITION B5 cannot select [Range in subroutine].
4. When TRACE CONDITION B8 is set, TRACE CONDITION B7 cannot select [Range in subroutine].

(2) [Address] Page ([Trace Condition] Dialog Box)

Function:

This page sets the address bus condition.

Window:

The screenshot shows a dialog box titled "[Address] Page ([Trace Condition] Dialog Box)". The window has a tabbed interface with tabs for "Address", "Data", "Bus State", "Probe", "Interrupt", and "Count". The "Address" tab is selected. Inside the dialog, there is a section labeled "Address" containing the following controls:

- Don't Care
- Address Range
- Start:
- End:
- Outside Range
- Non user mask User mask
- Mask:

Figure 4.43 [Address] Page ([Trace Condition] Dialog Box)

Description:**Table 4.52 [Address] Page Options**

Option	Description
[Don't Care] check box	Does not set address conditions.
[Address] radio button	Sets the address set by [Start] or [Mask] as trace acquisition conditions.
[Range] radio button	Sets the address range set by [Start]-[End] as trace acquisition conditions.
[Start] edit box	Sets the start address value with a number or a symbol.
[End] edit box	Sets the end address value if [Range] is selected.
[Outside Range] check box	Selected to set a value that has been set by [Start] or [Mask], or an address other than those in the range set by [Start] to [End] as trace acquisition conditions. Can be selected when Trace Condition B or Trace Condition Sequence is set.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits if [Address] and [User mask] are selected. For masked bits, the trace conditions will be satisfied regardless of the values. Disabled if [Range] is selected.

(3) [Data] Page ([Trace Condition] Dialog Box)

Function:

This page sets the data bus condition.

Window:




Figure 4.44 [Data] Page ([Trace Condition] Dialog Box)

Description:**Table 4.53 [Data] Page Options**

Option	Description
[Don't Care] check box	Does not set data conditions.
[Value] edit box	Sets the data bus with a number.
[Outside Range] check box	Sets a value other than that set by [Value] as data conditions. Can be specified when Trace Condition B or Trace Condition Sequence is set.
[Byte] radio button	Sets byte data access size.
[Word] radio button	Sets word data access size.
[Long] radio button	Sets longword data access size.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits if [User mask] is selected. For masked bits, the trace conditions will be satisfied regardless of the data values.

(4) [Bus State] Page ([Trace Condition] Dialog Box)

Function:

This page sets bus state and read/write cycle conditions.

Window:




Figure 4.45 [Bus State] Page ([Trace Condition] Dialog Box)

Description:**Table 4.54 [Bus State] Page Options**

Option	Description
[Bus State] group box	Sets the bus state conditions by the following options.
[All] radio button	Does not set bus state conditions.
[Data] radio button	Sets memory access cycles as trace conditions.
[DMAC] radio button	Sets DMA cycles as trace conditions.
[Vector Fetch] radio button	Sets vector fetch cycles as trace conditions.
[Read/Write] group box	Sets the read/write cycle conditions by the following options.
[Read/Write] radio button	Does not set read/write cycle conditions.
[Read] radio button	Sets read cycles as trace conditions.
[Write] radio button	Sets write cycles as trace conditions.

(5) [Probe] Page ([Trace Condition] Dialog Box)

Function:

This page sets external probe signal (PRB1–PRB4) conditions.

Window:

Address	Data	Bus State	Probe	Interrupt	Count
Probe 1					
<input checked="" type="radio"/> High					
<input type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 2					
<input type="radio"/> High					
<input checked="" type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 3					
<input checked="" type="radio"/> High					
<input type="radio"/> Low					
<input type="radio"/> Don't Care					
Probe 4					
<input type="radio"/> High					
<input type="radio"/> Low					
<input checked="" type="radio"/> Don't Care					

Figure 4.46 [Probe] Page ([Trace Condition] Dialog Box)

Description:**Table 4.55 [Probe] Page Options**

Option	Description
[Probe1]–[Probe4] group box	Selects the external probe signal (PRB1–PRB4) conditions by the following options.
[High] radio button	Sets high-level external probe signals as trace conditions.
[Low] radio button	Sets low-level external probe signals as trace conditions.
[Don't Care] radio button	Does not set external probe signal states as trace conditions.

(6) [Interrupt] Page ([Trace Condition] Dialog Box)

Function:

This page sets external interrupt signal (IRQ0–IRQ3) conditions and NMI signal conditions.

Window:

Address	Data	Bus State	Probe	Interrupt	Count						
<table><tr><td>IRQ₀ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care</td><td>IRQ₁ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care</td><td>IRQ₂ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care</td></tr><tr><td>IRQ₃ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care</td><td>NMI <input type="radio"/> High <input checked="" type="radio"/> Low <input type="radio"/> Don't Care</td><td></td></tr></table>						IRQ₀ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	IRQ₁ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	IRQ₂ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	IRQ₃ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	NMI <input type="radio"/> High <input checked="" type="radio"/> Low <input type="radio"/> Don't Care	
IRQ₀ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	IRQ₁ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	IRQ₂ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care									
IRQ₃ <input checked="" type="radio"/> High <input type="radio"/> Low <input type="radio"/> Don't Care	NMI <input type="radio"/> High <input checked="" type="radio"/> Low <input type="radio"/> Don't Care										

Figure 4.47 [Interrupt] Page ([Trace Condition] Dialog Box)

Description:**Table 4.56 [Interrupt] Page Options**

Option	Description
[IRQ0]–[IRQ3] group box	Sets the external interrupt signal (IRQ0–IRQ3) conditions by the following options.
[High] radio button	Sets high-level external interrupt signals as trace conditions.
[Low] radio button	Sets low-level external interrupt signals as trace conditions.
[Don't Care] radio button	Does not set external interrupt signal states as trace conditions.
[NMI] group box	Sets the NMI signal conditions by the following options.
[High] radio button	Sets high-level NMI signals as trace conditions.
[Low] radio button	Sets low-level NMI signals as trace conditions.
[Don't Care] radio button	Does not set NMI signal states as trace conditions.

(7) [Count] Page ([Trace Condition] Dialog Box)

Function:

This page sets satisfaction count conditions.

Window:




Figure 4.48 [Count] Page ([Trace Condition] Dialog Box)

Description:**Table 4.57 [Count] Page Options**

Option	Description
[Don't Care] check box	Does not set satisfaction count conditions.
Input area	Sets a value determined as a satisfaction count condition with a number. When the conditions set by the [Trace Condition] dialog box are satisfied a specified number of times, trace information acquisition is stopped. The default is 1.

This page is displayed when the conditions of Trace Condition B1–B6 and B8 are set.

Note:

The [Count] option cannot be independently set. Use this option together with other options.

(8) [Delay & Count] Page ([Trace Condition] Dialog Box)

Function:

This page sets the delay and satisfaction count conditions.

Window:




Figure 4.49 [Delay & Count] Page ([Trace Condition] Dialog Box)

Description:**Table 4.58 [Delay & Count] Page Options**

Option	Description
[Don't Care] check box	Does not set delay or satisfaction count conditions.
[Count] radio button	Sets satisfaction count conditions.
[Delay] radio button	Sets delay conditions.
Input area	Sets a delay or a value determined as satisfaction count conditions with a number. The default is 1.

This page is displayed when the conditions of Trace Condition B7 are set.

Note:

The [Delay & Count] option cannot be independently set. Use this option together with other options.

(9) [Delay] Page ([Trace Condition] Dialog Box)

Function:

This page sets delay conditions.

Window:



Figure 4.50 [Delay] Page ([Trace Condition] Dialog Box)

Description:**Table 4.59 [Delay] Page Options**

Option	Description
[Don't Care] check box	Does not set delay conditions.
Input area	Sets a value determined as delay conditions with a number. When the conditions set by the [Trace Condition] dialog box are satisfied, trace information acquisition is stopped after the specified bus cycles are executed. The default is 1.

This page is displayed when the conditions of Trace Condition Sequence7 are set.

Note:

The [Delay] option cannot be independently set. Use this option together with other options.

4.2.22 [Trace Filter] Dialog Box

Function:

This dialog box displays the trace results that agree with the conditions that have been set from among the trace results displayed in the [Trace] window. To display the [Trace Filter] dialog box, click the [Filter] button in the [Trace] window. This dialog box can set the following seven search conditions:

Window:




Figure 4.51 [Trace Filter] Dialog Box

Description:

The [Trace Filter] dialog box consists of the pages listed in table 4.60.

Table 4.60 [Trace Filter] Dialog Box Pages

Page Name	Description
[General]	Sets trace display conditions.
[Address]	Sets address conditions.
[Data]	Sets data conditions.
[Bus & Area]	Sets bus state conditions, read-write cycle conditions, and memory access area conditions.
[Probe]	Sets external probe conditions.
[Interrupt]	Sets external interrupt conditions.
[Time]	Sets time stamp conditions.

The setting contents of each page are described in section 4.2.24, [Trace Filter] and [Trace Find] Dialog Box Pages.

Clicking the [OK] button sets each condition then updates the data to be displayed. Clicking the [cancel] button closes this dialog box without setting the conditions. The [Apply] button cannot be used.

4.2.23 [Trace Find] Dialog Box

Function:

This dialog box searches for trace results that agree with the conditions that have been set from among the trace results displayed in the [Trace] window. To display the [Trace Find] dialog box, click the [Find] button in the [Trace] window. This dialog box can set the following seven search conditions:

Window:




Figure 4.52 [Trace Find] Dialog Box

Description:

The [Trace Find] dialog box consists of the pages listed in table 4.61.

Table 4.61 [Trace Find] Dialog Box Pages

Page Name	Description
[General]	Sets a search start point.
[Address]	Sets address conditions.
[Data]	Sets data conditions.
[Bus & Area]	Sets bus state conditions, read/write cycle conditions, and memory access area conditions.
[Probe]	Sets external probe conditions.
[Interrupt]	Sets external interrupt conditions.
[Time]	Sets time stamp conditions.

The setting contents of each page are described in section 4.2.24, [Trace Filter] and [Trace Find] Dialog Box Pages.

Clicking the [OK] button sets each condition then starts searching. Clicking the [cancel] button closes this dialog box without setting the conditions. The [Apply] button cannot be used.

4.2.24 [Trace Filter] and [Trace Find] Dialog Box Pages

Function:

The [Trace Filter] and [Trace Find] dialog box pages allow trace information search conditions to be set. The following table shows all the [Trace Filter] and [Trace Find] dialog box pages.

Table 4.62 [Trace Filter] and [Trace Find] Dialog Box Pages

Page Name	Function
[General]	Sets trace display conditions and the search start point.
[Address]	Sets address conditions.
[Data]	Sets data conditions.
[Bus & Area]	Sets bus state conditions, read/write cycle conditions, and memory access area conditions.
[Probe]	Sets external probe conditions.
[Interrupt]	Sets external interrupt conditions.
[Time]	Sets time stamp conditions.

(1) [General] Page ([Trace Filter] Dialog Box)

Function:

This page sets conditions for trace information to be displayed in the [Trace] window.

Window:

The image shows a dialog box with the following elements:

- Tabbed interface with tabs: **General**, Address, Data, Bus & Area, Probe, Interrupt, Time.
- Type** section:
 - Cycle
 - Pattern
- Cycle** section:
 - Start:
 - End:

Figure 4.53 [General] Page ([Trace Filter] Dialog Box)

Description:**Table 4.63 [General] Page Options ([Trace Filter] Dialog Box)**

Option	Description
[Type] group box	Selects a trace display format. [Cycle]: Disables the search conditions set in the [Trace Filter] dialog box. Displays all the contents of the trace buffer in the [Trace] window. [Pattern]: Searches under the conditions set in the [Trace Filter] dialog box, and displays the results in the [Trace] window.
[Cycle] group box	Sets a trace information displayed in the [Trace] window and the range for a search. Set with a bus-cycle pointer value. Set the cycles prior to satisfying the delay condition to a negative value, with the bus cycle at delay condition satisfaction set to 0.
[Start] [End] edit box	[Start] represents a start bus pointer and [End] represents an end bus pointer. Always set a value in the input area. The default values are -4095 and 4095 for [Start] and [End], respectively.

(2) [General] Page ([Trace Find] Dialog Box)

Function:

Sets the condition for the position at which the search is to start.

Window:



Figure 4.54 [General] Page ([Trace Find] Dialog Box)

Description:

Table 4.64 [General] Page ([Trace Find] Dialog Box) Options


Option	Description
[Search from Top] check box	Selected when searching from the start of the trace results. If not selected, the search is performed from the current cursor position.

(3) [Address] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Function:

This page sets address bus conditions.

Window:



The image shows a software dialog box with a tabbed interface. The 'Address' tab is selected. The dialog contains the following elements:

- Tabbed interface with tabs: General, **Address**, Data, Bus & Area, Probe, Interrupt, Time.
- Section header: Address
- Checkbox: Don't Care
- Radio buttons: Address, Range
- Text field: Start, containing the value H'1000200
- Text field: End, containing the value H'1000300
- Radio buttons: Non user mask, User mask
- Text field: Mask, currently empty

Figure 4.55 [Address] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Description:**Table 4.65 [Address] Page Options**

Option	Description
[Don't Care] check box	Does not set address conditions when checked.
[Address] radio button	Sets the address set by [Start] or [Mask] as trace acquisition conditions.
[Range] radio button	Sets the address range set by [Start] to [End] as trace acquisition conditions.
[Start] edit box	Sets a start address bus value with a number or a symbol.
[End] edit box	Sets an end address bus value with a number or a symbol when [Range] is selected.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask] edit box	Sets the mask bits when [Address] or [User mask] is selected. For masked bits, the conditions will be satisfied regardless of the masked bit values. When [Range] is selected, the setting is disabled.

(4) [Data] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Function:

This page sets data bus conditions.

Window:




Figure 4.56 [Data] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Description:**Table 4.66 [Data] Page Options**

Option	Description
[Don't Care] check box	Does not set data conditions when checked.
[Value] edit box	Sets the data bus with a number.
[Byte] radio button	Sets byte access cycles.
[Word] radio button	Sets word access cycles.
[Long] radio button	Sets longword access cycles.
[Non user mask] radio button	Does not set mask conditions.
[User mask] radio button	Sets mask conditions.
[Mask]] edit box	Sets the mask bits when [User mask] is selected. For masked bits, the conditions will be satisfied regardless of the masked bit values.

(5) [Bus & Area] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Function:

This page sets bus state conditions, read/write cycle conditions, and the conditions related to the memory access area.

Window:




Figure 4.57 [Bus & Area] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Description:**Table 4.67 [Bus & Area] Page Options**

Option	Description
[Bus State] group box	Sets the bus state conditions by the following options.
[All] radio button	Does not set all bus state conditions as trace search conditions.
[Data] radio button	Specifies only memory access cycles as a trace search condition.
[DMAC] radio button	Sets only DMA cycles as trace search conditions.
[Vector Fetch] radio button	Sets only vector fetch cycles as trace search conditions.
[Read/Write] group box	Sets the read/write cycle conditions by the following options.
[Read/Write] radio button	Does not set read/write cycle conditions as trace search conditions.
[Read] radio button	Sets only read cycles as trace search conditions.
[Write] radio button	Sets only write cycles as trace search conditions.
[Area] group box	Sets the memory access area conditions by the following options.
[All] radio button	Does not set all memory access area conditions as trace search conditions.
[Internal Space] radio button	Sets only internal memory area as trace search conditions.
[I/O Space] radio button	Sets only internal I/O area as trace search conditions.
[External Space] radio button	Sets only external memory area as trace search conditions.

(6) [Probe] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Function:

This page sets external probe signal (PRB1–PRB4) conditions.

Window:

The image shows a dialog box window with the following structure:

- Tabbed interface with tabs: General, Address, Data, Bus & Area, **Probe**, Interrupt, Time.
- Four probe configuration sections:
 - Probe 1**:
 - High
 - Low
 - Don't Care
 - Probe 2**:
 - High
 - Low
 - Don't Care
 - Probe 3**:
 - High
 - Low
 - Don't Care
 - Probe 4**:
 - High
 - Low
 - Don't Care

Figure 4.58 [Probe] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Description:**Table 4.68 [Probe] Page Options**

Option	Description
[Probe1]–[Probe4] group box	Selects the external probe signal (PRB1–PRB4) conditions by the following options.
[High] radio button	Sets the high level of the external probe signal as trace search conditions.
[Low] radio button	Sets the low level of the external probe signal as trace search conditions.
[Don't Care] radio button	Does not set external probe signal levels as trace search conditions.

(7) [Interrupt] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Function:

This page sets the conditions of the external interrupt signals (IRQ0–IRQ3), the NMI signal, and the RESET signal.

Window:

General	Address	Data	Bus & Area	Probe	Interrupt	Time
IRQ0						
<input checked="" type="radio"/> High						
<input type="radio"/> Low						
<input type="radio"/> Don't Care						
IRQ1						
<input checked="" type="radio"/> High						
<input type="radio"/> Low						
<input type="radio"/> Don't Care						
IRQ2						
<input checked="" type="radio"/> High						
<input type="radio"/> Low						
<input type="radio"/> Don't Care						
IRQ3						
<input checked="" type="radio"/> High						
<input type="radio"/> Low						
<input type="radio"/> Don't Care						
NMI						
<input type="radio"/> High						
<input checked="" type="radio"/> Low						
<input type="radio"/> Don't Care						
RESET						
<input checked="" type="radio"/> Low						
<input type="radio"/> Don't Care						

Figure 4.59 [Interrupt] Page ([Trace Filter] and [Trace Find] Dialog Boxes)

Description:**Table 4.69 [Interrupt] Page Options**

Option	Description
[IRQ0]–[IRQ3] group box	Selects the external interrupt (IRQ0–IRQ3) signal conditions by the following options.
[High] radio button	Sets the high level of the external interrupt signal as trace search conditions.
[Low] radio button	Sets the low level of the external interrupt signal as trace search conditions.
[Don't Care] radio button	Does not set the external interrupt signal state as trace search conditions.
[NMI] group box	Selects the NMI signal conditions by the following options.
[High] radio button	Sets the high level of the NMI signal as trace search conditions.
[Low] radio button	Sets the low level of the NMI signal as trace search conditions.
[Don't Care] radio button	Does not set the NMI signal state as trace search conditions.
[RESET] group box	Selects the RESET signal conditions by the following options.
[Low] radio button	Sets the low level of the RESET signal as trace search conditions.
[Don't Care] radio button	Does not set the RESET signal state as search conditions.

Description:**Table 4.70 [Time] Page Options**

Option	Description
[Don't Care] check box	Does not set time stamp conditions.
[Point] radio button	Sets the value set with [From] as trace search conditions.
[Range] radio button	Sets the value from [From] to [To] as trace search conditions.
[From] group	Sets the (start) time stamp value in decimal. Default is 0.
[H] edit box	Sets the (start) hour. 0 to 999 are valid.
[M] edit box	Sets the (start) minute. 0 to 59 are valid.
[S] edit box	Sets the (start) second. 0 to 59 are valid.
[US] edit box	Sets the (start) microsecond. 0 to 999999 are valid.
[To] group	Sets the (end) time stamp value in decimal when [Range] is selected. Default is 0.
[H] edit box	Sets the (end) hour. 0 to 999 are valid.
[M] edit box	Sets the (end) minute. 0 to 59 are valid.
[S] edit box	Sets the (end) second. 0 to 59 are valid.
[US] edit box	Sets the (end) microsecond. 0 to 999999 are valid.

Section 5 Command-line Function

5.1 Table and Symbol Description

This section describes the format used in section 5.2, Command Descriptions. The descriptions of some commands are given over two or more pages.

5.1.1 Format

The input format for each command is as follows. Characters shown in bold are to be input.

[]: Parameters enclosed by [] can be omitted.

< >: Contents shown in < > are specified.

< >=: The parameter to the left of the “=” sign is input in the format shown to the right.

|: This represents a non-exclusive selection.

||: This represents an exclusive selection.

The command parameters are described in the format table.

5.1.2 Parameter Input

Numerical Parameters:

A binary, octal, decimal, or hexadecimal value, a symbol, or an equation can be input. A symbol can contain up to 32 characters. Terms in a formula are separated with operator (such as + or -).

Keyword Parameters:

One of the character strings given in the description column of the table is input. If a character string not shown in the description is input, an error occurs.

Character-string Parameters:

Character-string parameters are used to input a file name.

5.1.3 Example

These are actual input examples. For commands whose execution results in a specific display output, an example of display is given.

5.2 Command Descriptions

The command list of the SH7410 E8000 HDI is shown below.

Table 5.1 SH7410 E8000 HDI Commands

No	Command	Abb.	Function	Related E8000 Commands
1	BKGRND_INT	BI	Sets and displays the user interrupt receive function during a command-wait state.	BACKGROUND_INTERRUPT
2	BREAKCONDITION_CLEAR	BCC	Clears hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C BREAK_CONDITION_SEQUENCE
3	BREAKCONDITION_DISPLAY	BCD	Displays hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C BREAK_CONDITION_SEQUENCE
4	BREAKCONDITION_ENABLE	BCE	Enables or disables hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C BREAK_CONDITION_SEQUENCE
5	BREAKCONDITION_SET	BCS	Sets hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C BREAK_CONDITION_SEQUENCE
6	BREAKSEQUENCE_CLEAR	BSC	Clears software sequential breakpoints that have been set.	BREAK_SEQUENCE
7	BREAKSEQUENCE_DISPLAY	BSD	Displays software sequential breakpoints that have been set.	BREAK_SEQUENCE
8	BREAKSEQUENCE_ENABLE	BSE	Enables or disables software sequential breakpoints that have been set.	BREAK_SEQUENCE
9	BREAKSEQUENCE_SET	BSS	Sets software sequential breakpoints.	BREAK_SEQUENCE
10	BREAKPOINT	BP	Sets software breakpoints.	BREAK

Table 5.1 SH7410 E8000 HDI Commands (cont)

No	Command	Abb.	Function	Related E8000 Commands
11	BREAKPOINT_CLEAR	BC	Clears software breakpoints that have been set.	BREAK
12	BREAKPOINT_DISPLAY	BD	Displays software breakpoints that have been set.	BREAK
13	BREAKPOINT_ENABLE	BE	Enables or disables software breakpoints that have been set.	BREAK
14	CLOCK	CK	Selects a CLOCK signal used by the SH7410.	CLOCK
15	DEVICE_TYPE	DE	Displays the MCU type currently selected.	None
16	END	END	Returns to a user program execution state when the E8000 emulator enters the parallel mode due to trace condition satisfaction.	END
17	EXECUTION_MODE	EM	Sets debugging conditions during user program execution.	EXECUTE_MODE
18	GO_OPTION	GP	Sets the emulation mode during user program execution.	GO
19	ID	ID	Displays an E8000 emulator type and a version number.	ID
20	MAP_SET	MS	Sets E8000 emulator memory-map.	MAP
21	MODE	MO	Selects E8000 emulator mode.	MODE
22	MOVE_TO_RAM	MR	Stores a user program on ROM into RAM.	MOVE_TO_RAM
23	PERFORMANCE_ANALYSIS	PA	Displays program execution state.	PERFORMANCE_ANALYSIS1 to 8
24	PERFORMANCE_CLEAR	PC	Clears performance conditions that have been set.	PERFORMANCE_ANALYSIS1 to 8
25	PERFORMANCE_SET	PS	Sets performance conditions.	PERFORMANCE_ANALYSIS1 to 8

Table 5.1 SH7410 E8000 HDI Commands (cont)

No	Command	Abb.	Function	Related E8000 Commands
26	STATUS	STS	Displays E8000 emulator state information.	None
27	TRACEACQUISITION_CLEAR	TAC	Clears trace conditions that have been set.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
28	TRACEACQUISITION_DISPLAY	TAD	Displays trace conditions that have been set.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
29	TRACEACQUISITION_SET	TAS	Sets trace conditions that acquire trace information.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
30	TRACE_MODE	TM	Sets the trace information acquisition mode.	TRACE_MODE
31	TRACE_SEARCH	TS	Searches for information corresponding to acquired trace information.	TRACE_SEARCH
32	UBC_CLEAR	UBC	Clears UBC breakpoints that have been set.	BREAK_CONDITION_UBC
33	UBC_DISPLAY	UBD	Displays UBC breakpoints that have been set.	BREAK_CONDITION_UBC
34	UBC_ENABLE	UBE	Enables or disables UBC breakpoints that have been set.	BREAK_CONDITION_UBC
35	UBC_SET	UBS	Sets UBC breakpoints.	BREAK_CONDITION_UBC

5.2.1 BKGRND_INT: BI

Description:

Sets and displays the user interrupt receive function during a command-wait state.

Format:

Sets or clears the user interrupt receive function during a command-wait state.

```
bi <mode> <address>
```

Displays the user interrupt receive function during a command-wait state.

```
bi
```

Table 5.2 BKGRND_INT Command Parameters

Parameter	Type	Description
<mode>	Keyword	Enables or disables user interrupt. enable: Enables a user interrupt. disable: Disables a user interrupt.
<address>	Numerical value	Loop program address for receiving a user interrupt.

Example:

To enable the user interrupt receive function during a command-wait state:

```
bi enable FFFC (RET)
```

To disable the user interrupt receive function during a command-wait state:

```
bi disable (RET)
```

To display information on the user interrupt receive function during a command-wait state:

```
bi (RET)
```

5.2.2 BREAKCONDITION_CLEAR: BCC

Description:

Clears hardware breakpoints (break conditions) that have been set.

Format:

```
bcc <type> [ <channel> ]  
<channel> = channel <channel_number> || reset
```

Table 5.3 BREAKCONDITION_CLEAR Command Parameters

Parameter	Type	Description
<type>	Keyword	Break condition type Set either of the following. a: BREAK_CONDITION_A b: BREAK_CONDITION_B c: BREAK_CONDITION_C sequence: BREAK_CONDITION_SEQUENCE
<channel_number>	Numerical value	Break condition channel number from 1 to 8.

Example:

All conditions for break condition A are cleared.

```
bcc a (RET)
```

The conditions set at channel 2 of break condition B are cleared.

```
bcc b channel 2 (RET)
```

- Notes:
1. When <channel> is omitted, all break conditions that have been set are cleared.
 2. When [reset] is specified, all reset conditions for BREAK_CONDITION_SEQUENCE are cleared.

5.2.3 BREAKCONDITION_DISPLAY: BCD

Description:

Displays hardware breakpoints (break conditions) that have been set.

Format:

```
bcd <type> [<channel>]  
<channel> = channel <channel_number> || reset
```

Table 5.4 BREAKCONDITION_DISPLAY Command Parameters

Parameter	Type	Description
<type>	Keyword	Break condition type Set either of the following. a: BREAK_CONDITION_A b: BREAK_CONDITION_B c: BREAK_CONDITION_C sequence: BREAK_CONDITION_SEQUENCE
<channel_number>	Numerical value	Break condition channel number from 1 to 8.

Example:

All conditions for break condition A are displayed.

```
bcd a (RET)
```

The display format is as follows:

```
>bcd a
```

```
Break Condition A1:Enable  address 1000000  
Break Condition A2:Enable  address 100027c to 1000304 direction  
write  
Break Condition A3:Enable  data 4750 word access dat direction  
read  
Break Condition A4:Disable  
Break Condition A5:Disable  
Break Condition A6:Disable  
Break Condition A7:Disable  
Break Condition A8:Enable  irq 1001
```

The conditions set at channel 2 of break condition B are displayed.

```
bcd b channel 2 (RET)
```

The display format is as follows:

```
> bcd b channel 2
```

```
Break Condition B2:Enable  address 10002ec data ffff word access  
dma direction write nmi hi  count a
```

- Notes:
1. When <channel> is omitted, all break conditions that have been set are displayed.
 2. When [reset] is specified, the reset conditions for BREAK_CONDITION_SEQUENCE are displayed.

5.2.4 BREAKCONDITION_ENABLE: BCE

Description:

Enables or disables hardware breakpoints (break conditions) that have been set.

Format:

```
bce <type> [<channel>] <mode>  
<channel> = channel <channel_number>
```

Table 5.5 BREAKCONDITION_ENABLE Command Parameters

Parameter	Type	Description
<type>	Keyword	Break condition type Set either of the following. A: BREAK_CONDITION_A B: BREAK_CONDITION_B C: BREAK_CONDITION_C Sequence: BREAK_CONDITION_SEQUENCE
<channel_number>	Numerical value	Break condition channel number from 1 to 8.
<mode>	Keyword	Enables or disables break conditions. Set either of the following. enable: Enables break conditions. disable: Disables break conditions.

Example:

All conditions for break condition A are enabled.

```
bce a enable (RET)
```

The conditions set at channel 2 of break condition B are disabled.

```
bce b channel 2 disable (RET)
```

Note: When <channel> is omitted, all break conditions that have been set are enabled or disabled.

5.2.5 BREAKCONDITION_SET: BCS

Description:

Sets hardware breakpoints (break conditions).

Format:

```
bcs <type> <channel> <option> [<option>...][<delayopt> | <countopt>
<channel>      = channel <channel_number> || reset
<option>       = <addropt> | <dataopt> | <r/wopt> | <accessopt> |
<prbopt> | <nmiopt> | <irqopt>
<addropt>     = address <address>[to <address>] [not]
                || address mask <maskdata>
<dataopt>     = data <data> <datawidth> [not] || data mask <maskdata>
<r/wopt>      = direction <r/w>
<accessopt>   = access <access>
<prbopt>     = prb <probe>
<nmiopt>     = nmi <nmi>
<irqopt>     = irq <irq>
<delayopt>   = delay <delay>
<countopt>   = count <count>
```

Table 5.6 BREAKCONDITION_SET Command Parameters

Parameter	Type	Description
<type>	Keyword	Break condition type Set either of the following. a: BREAK_CONDITION_A b: BREAK_CONDITION_B c: BREAK_CONDITION_C sequence: BREAK_CONDITION_SEQUENCE
<channel_number>	Numerical value	Break condition channel number from 1 to 8.
<address>	Numerical value	Address bus value
<maskdata>	Character string	Value to be masked
<data>	Numerical value	Data bus value
<datawidth>	Keyword	Data bus access conditions Set either of the following. byte: Byte access word: Word access long: Longword access
<r/w>	Keyword	Read/write conditions Set either of the following. read: Read cycle write: Write cycle
<access>	Keyword	Bus state conditions Set either of the following. dat: Data access cycle dma: DMA cycle vcf: Vector fetch cycle
<probe>	Numerical value	External probe signal conditions

Table 5.6 BREAKCONDITION_SET Command Parameters (cont)

Parameter	Type	Description
<nmi>	Keyword	NMI signal conditions Set either of the following. low : Conditions are satisfied when the NMI signal is low. hi : Conditions are satisfied when the NMI signal is high.
<irq>	Numerical value	IRQ signal conditions
<delay>	Numerical value	Bus-cycle count to be executed after condition satisfaction within the range of H'1 to H'7FFF.
<count>	Numerical value	Pass count until conditions are satisfied within the range of H'1 to H'FFFF.

Examples:

To set the following conditions for channel 2 of break condition A:

Address condition: An address bus value of H'100027c to H'1000304,
Read/write cycle condition: Write cycle only.

```
bcs a channel 2 address 100027c to 1000304 direction write(RET)
```

To set the following conditions for channel 3 of break condition B:

Data condition: Data bus value of H'4750 and word access,
Bus state condition: DAT cycle only,
Read/write cycle condition: Read cycle only.

```
bcs b channel 3 data 4750 word access dat direction read(RET)
```

To set the following conditions for channel 5 of break condition A:

External probe condition: PROBE4=LOW, PROBE3=HIGH, PROBE2=LOW,
PROBE1=HIGH.

```
bcs a channel 5 prb 0101(RET)
```

To set the following conditions for channel 7 of break condition B:

IRQ signal condition: IRQ3=HIGH, IRQ2=HIGH, IRQ1=HIGH, IRQ0=HIGH,
NMI signal condition: NMI=LOW.

```
bcs b channel 7 irq 1111 nmi low(RET)
```

To set the following conditions for channel 1 of break condition B:

Address condition: Mask specification at address bus value = H'1000***.

```
bcs b channel 1 address mask H'1000***(RET)
```

To set the following conditions for channel 3 of break condition B:

Address bus value: Except the range from H'1000000 to H'10001c0.

bcs b channel 3 address 1000000 to 10001c0 not(RET)

To set program stop after executing the program for 10 cycles when the following conditions are satisfied:

Address bus value: In the order of H'10002ac, H'1000304, and H'1000402,

and to reset the pass sequence analysis when the following conditions are satisfied:

Address bus range: From H'10002cc to 10002fc.

bcs sequence channel 1 address 10002ac(RET)

bcs sequence channel 2 address 1000304(RET)

bcs sequence channel 7 address 1000402 delay a(RET)

bcs sequence reset address 10002cc to 10002fc(RET)

Notes: 1. When [not] is set, the values or ranges other than set address bus values, address bus ranges, or data bus values are set.

2. Each bit for external probe conditions and IRQ signal conditions is set as follows:

(1) Bit specification for PRB1-PRB4 signals

3	2	1	0: Bit position
x	x	x	x: 0 (Low level) or 1 (High level) is set for x.
4	3	2	1: PRB number

(2) Bit specification for IRQ0-IRQ3

3	2	1	0: Bit position
x	x	x	x: 0 (Low level) or 1 (High level) is set for x.
3	2	1	0: IRQ number

Setting a mask character* excludes the external probe conditions and IRQ signal conditions at the corresponding bit position.

3. When [reset] is set, the reset conditions for BREAK_CONDITION_SEQUENCE are set.
4. When b or sequence is set to the <type> parameter, and when the <channel_number> parameter is 7, the <delayopt> parameter can be set.
5. Set one or more <option> parameters to the <delayopt> parameter.
6. The <countopt> parameter can be set when the <type> parameter is b.
7. Set one or more <option> parameters to the <countopt> parameter.
8. When b is set to the <type> parameter, [not] is enabled.

9. When *c* is set to the <type> parameter, only the <addropt> and <accessopt> can be set to the <option> parameter.

5.2.6 BREAKSEQUENCE_CLEAR: BSC

Description:

Clears software sequential breakpoints that have been set.

Format:

bsc

Table 5.7 BREAKSEQUENCE_CLEAR Command Parameter

Parameter	Type	Description
None		

Example:

To clear software sequential breakpoints that have been set:

bsc (RET)

5.2.7 BREAKSEQUENCE_DISPLAY: BSD

Description:

Displays software sequential breakpoints that have been set.

Format:

`bsd`

Table 5.8 BREAKSEQUENCE_DISPLAY Command Parameter

Parameter	Type	Description
None		

Example:

To display software sequential breakpoints that have been set:

```
bsd (RET)
```

The display format is as follows:

```
>bsd
```

```
Enable : 010000ec 01000124 010003fc reset 010004a0
```

5.2.8 BREAKSEQUENCE_ENABLE: BSE

Description:

Enables or disables software sequential breakpoints that have been set.

Format:

```
bse <mode>
```

Table 5.9 BREAKSEQUENCE_ENABLE Command Parameter

Parameter	Type	Description
<mode>	Keyword	Enables or disables software sequential breakpoints. Set either of the following. enable: Enables software sequential breakpoints. disable: Disables software sequential breakpoints.

Example:

To enable software sequential breakpoints that have been set:

```
bse enable(RET)
```

To disable software sequential breakpoints that have been set:

```
bse disable(RET)
```

5.2.9 BREAKSEQUENCE_SET: BSS

Description:

Sets software sequential breakpoints.

Format:

```
bss <address1> <address2> [<address3...7>...] [reset <address8>]
```

Table 5.10 BREAKSEQUENCE_SET Command Parameters

Parameter	Type	Description
<address1>	Numerical value	Address of a pass point (Address for the first pass point.)
<address2>	Numerical value	Address of a pass point (Address for the second pass point.)
<address3...7>	Numerical value	Addresses of pass points (Addresses for the third pass and subsequent points.)
<address8>	Numerical value	Address of the reset point When the reset point is passed, pass sequence analysis is reset. Analysis starts again from the first pass point.

Examples:

To set a software sequential breakpoint by which program execution stops when the program has passed the pass points in the order of H'10000ec, H'1000124, and H'10003fc, and the analysis for the pass sequence is reset when the program has passed H'10004a0:

```
bss 010000ec 01000124 010003fc reset 010004a0 (RET)
```

To set a software sequential breakpoint by which program execution stops when the program has passed the pass points in the order of H'1000, H'2000, and H'3000:

```
bss 1000 2000 3000 (RET)
```

Note: When the software sequential breakpoint is set in the order from address 1 to 7, program execution stops at the last pass point.

5.2.10 BREAKPOINT: BP

Description:

Sets software breakpoints.

Format:

```
bp <address> <count>
```

Table 5.11 BREAKPOINT Command Parameters

Parameter	Type	Description
<address>	Numerical value	Breakpoint address
<count>	Numerical value	Breakpoint pass count within the range from H'1 to H'FFFF.

Examples:

To set a software breakpoint at address H'10002c8:

```
bp 10002c8 (RET)
```

To set a software breakpoint that causes a break when a program executes address H'1000 12 times:

```
bp 1000 12 (RET)
```

5.2.11 BREAKPOINT_CLEAR: BC

Description:

Clears software breakpoints that have been set.

Format:

```
bc <address>
```

Table 5.12 BREAKPOINT_CLEAR Command Parameter

Parameter	Type	Description
<address>	Numerical value	Breakpoint address

Example:

To clear a software breakpoint set at address H'1000:

```
bc 1000 (RET)
```

5.2.12 BREAKPOINT_DISPLAY: BD

Description:

Displays software breakpoints that have been set.

Format:

bd

Table 5.13 BREAKPOINT_DISPLAY Command Parameter

Parameter	Type	Description
None		

Example:

To display the software breakpoints that have been set:

```
bd (RET)
```

The display format is as follows:

```
Address  Count  Enable/Disable
```

```
>bd
```

```
00000110 00000011 Enable
```

```
0000011c 00000012 Disable
```

```
00000250 00000001 Enable
```

5.2.13 BREAKPOINT_ENABLE: BE

Description:

Enables or disables software breakpoints that have been set.

Format:

```
be <address> <mode>
```

Table 5.14 BREAKPOINT_ENABLE Command Parameters

Parameter	Type	Description
<address>	Numerical value	Breakpoint address
<mode>	Keyword	Enables or disables breakpoints. Set either of the following. enable: Enables breakpoint setting. disable: Disables breakpoint setting.

Examples:

To enable a software breakpoint that has been set:

```
be 1002 enable(RET)
```

To disable a software breakpoint that has been set:

```
be 1002 disable(RET)
```

5.2.14 CLOCK: CK

Description:

Displays and sets clock mode.

Format:

Displays clock mode.

```
ck
```

Sets clock mode.

```
ck <mode>
```

Table 5.15 CLOCK Command Parameter

Parameter	Type	Description
<mode>	Keyword	Clock mode
		Set either of the following. user: User system eml: Clock signal of E8000 xtal: Quartz oscillator of E8000

Examples:

To display the currently selected clock mode:

```
ck (RET)
```

The display format is as follows:

```
>ck  
Clock = Emulator
```

To change clock mode:

```
ck user (RET)
```

5.2.15 DEVICE_TYPE: DE

Description:

Displays the currently selected MCU.

Format:

de

Table 5.16 DEVICE_TYPE Command Parameter

Parameter	Type	Description
None		

Example:

To display the currently selected MCU:

```
de (RET)
```

The display format is as follows:

```
>de
```

```
Current device = SH7410
```

5.2.16 END: END

Description:

Returns the E8000 emulator to the user program execution mode when the E8000 emulator enters parallel mode as a result of trace condition satisfaction.

Format:

`end`

Table 5.17 END Command Parameter

Parameter	Type	Description
None		

Example:

To return the E8000 emulator state from parallel mode to user program execution mode:

`end (RET)`

5.2.17 EXECUTION_MODE: EM

Description:

Sets debugging conditions during user program execution.

Format:

Displays debugging conditions during user program execution.

```
em
```

Sets debugging conditions during user program execution.

```
em <busrequest> | <time> | <trigger_abc> | <trigger_bcb> | <mon_time> |  
<pa_count> | <userwait> | <emlmbus>  
<busrequest> = breq <mode>  
<mon_time>   = time <time>  
<trigger_abc>      = trgu <trgu>  
<trigger_bcb>      = trgb <trgb>  
<mon_time>        = mon <mon>  
<pa_count>        = ecnt <ecnt>  
<userwait>        = wait <wait>  
<emlmbus>        = embw <embw>
```

Table 5.18 EXECUTION_MODE Command Parameters

Parameter	Type	Description
<mode>	Keyword	Enables or disables the input of the bus-right request signal. Set either of the following. enable: Enable disable: Disable
<time>	Keyword	Execution time measurement unit. Set either of the following. 1.6us: in units of 1.6 μ s 406ns: in units of 406 ns 20ns: in units of 20 ns
<trgu>	Keyword	Pulse output mode at hardware break condition (UBC) satisfaction. Set either of the following. enable: No break occurs and the trigger signal is output. stop: A break occurs and the trigger signal is output. disable: A break occurs but no trigger signal is output.
<trgb>	Keyword	Pulse output mode when the hardware break condition (BREAK_CONDITION_B) is satisfied. Set either of the following. 1 to 8: When the break condition is satisfied for the channels set by BREAK_CONDITION_B1 to B8, the trigger signal is output. all: The trigger signal is output when either of BREAK_CONDITION_B is satisfied. disable: A break occurs but no trigger signal is output.

Table 5.18 EXECUTION_MODE Command Parameters (cont)

Parameter	Type	Description
<mon>	Keyword	<p>Time intervals of an execution state indication to be displayed on the status bar.</p> <p>Set either of the following.</p> <p>not: A execution state is not displayed.</p> <p>200ms: Displays an execution state with intervals of 200 msec.</p> <p>2s: Displays an execution state with intervals of 2 sec.</p>
<ecnt>	Keyword	<p>Execution count measurement mode for performance analysis.</p> <p>Set either of the following.</p> <p>top_end: Counts number of times in which the last address is passed after the start address of a subroutine is passed.</p> <p>end_only: Counts number of times in which the end address of a subroutine is passed.</p>
<wait>	Keyword	<p>Enables or disables user wait.</p> <p>Set either of the following.</p> <p>enable: Enables user wait.</p> <p>disable: Disables user wait.</p>
<embw>	Keyword	<p>Bus width of the emulation memory.</p> <p>Set either of the following.</p> <p>8: 8-bit bus width</p> <p>16: 16-bit bus width</p> <p>32: 32-bit bus width</p>

Examples:

To display current debugging conditions during user program execution:

```
em(RET)
```

The display format is as follows:

```
>em
```

```
Execution Mode
```

```
Bus Request Enable
```

```
Interval Timer counter 1.6us
```

```
Output trigger(UBC) Disable
```

```
Output trigger(BC-B) Disable
```

```
Display Execution Time 200ms
```

```
User Wait Disable
```

```
Emulator Bus width 32bit
```

```
Performance analysis Passing subroutine end address after start  
address
```

To enable the input of the bus-right request signal, for the debugging conditions during user program execution:

```
em breq enable(RET)
```

To enable the trigger output when either of BREAK_CONDITION_B is satisfied, and to enable user wait acceptance, for the debugging conditions during user program execution:

```
em trgb all wait enable(RET)
```

5.2.18 GO_OPTION: GP

Description:

Sets emulation mode during user program execution.

Format:

Displays emulation mode during user program execution.

```
gp
```

Sets emulation mode during user program execution.

```
gp <eml_opt> | <ubcsq_opt> | <lvldisp_opt>  
<eml_opt>      = eml_mode <eml_mode>  
<ubcsq_opt>   = ubc_sq <ubc_sq>  
<lvldisp_opt> = level_display <lvl_disp>
```

Table 5.19 GO_OPTION Command Parameters

Parameter	Type	Description
<eml_mode>	Keyword	Emulation mode. Refer to the next page for settings (table 5.20).
<ubc_sq>	Keyword	Enables or disables a UBC sequential break. (Program execution stops when the conditions set by BREAK_CONDITION_UBC2 and 1 are satisfied in that order.) Set either of the following. enable: Enables a UBC sequential break. disable: Disables a UBC sequential break.
<lvl_disp>	Keyword	Enables or disables the display of the condition satisfaction level of BREAK_CONDITION_SEQUENCE and TRACE_CONDITION_SEQUENCE displayed in the status bar. Set either of the following. enable: Enables display of the condition satisfaction level. disable: Disables display of the condition satisfaction level.

The following can be set to <eml_mode>.

Table 5.20 Emulation Modes

Mode	Description
normal	Performs normal execution.
6.5 μ s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 6.5 μ s.
9.8 μ s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 9.8 μ s.
50 μ s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 50 μ s.
100 μ s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 100 μ s.
500 μ s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 500 μ s.
1 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 1 ms.
5 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 5 ms.
10 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 10 ms.
50 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 50 ms.
100 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 100 ms.
500 ms	Executes a user program by inputting the RESET signal to SH7410 with intervals of 500 ms.
1 s	Executes a user program by inputting the RESET signal to SH7410 with intervals of 1 s.
measurement1	Measures execution time from the condition satisfaction of BREAK_CONDITION_UBC2 to that of BREAK_CONDITION_UBC1. In this case, user program execution stops after the measurement.
measurement2	Measures the total execution time from the condition satisfaction of BREAK_CONDITION_UBC2 to that of BREAK_CONDITION_UBC1. In this case, the user program execution continues. Next, when the condition of BREAK_CONDITION_UBC is satisfied, this time is added to the execution time measured before.
Pabreak	A break occurs under the timeout conditions set by the [PERFORMANCE_ANALYSIS1] command.
no_break	Temporarily disables the software and hardware break conditions.

Examples:

To display the current emulation mode during user program execution:

```
gp(RET)
```

The display format is as follows:

```
>gp
```

```
Emulator execution mode = Normal
```

```
Display sequence level = Disable
```

```
UBC sequence = Disable
```

To set the emulation mode so that the user program is executed by inputting the RESET signal to SH7410 with intervals of 100 ms.

```
gp em1_mode 100ms(RET)
```

To enable the UBC sequential break during user program execution:

```
gp ubc_sq enable(RET)
```

Note: All trace and break conditions are disabled if the mode of 6.5 μ s to 1 s is selected.

5.2.19 ID: ID

Description:

Displays an E8000 emulator type and a version number.

Format:

`id`

Table 5.21 ID Command Parameter

Parameter	Type	Description
None		

Example:

To display an E8000 emulator type and a version number:

```
id(RET)
```

The display format is as follows:

```
>id  
Emulator ID  
SH7410 E8000 (HS7410EDD82SF) VX.X  
Copyright (C) Hitachi, Ltd. 1996  
Licensed Material of Hitachi, Ltd.
```

5.2.20 MAP_SET: MS

Description:

Sets a memory map of the E8000 emulator.

Format:

```
ms <start> <end> <mode>
```

Table 5.22 MAP_SET Command Parameters

Parameter	Type	Description
<start>	Numerical value	Start address
<end>	Numerical value	End address
<mode>	Keyword	Memory map mode

Set either of the following.

- user** : Sets to a user memory area.
- emulator** : Sets to an emulation memory area.
- read-only** : Sets the emulation memory area to write mode.

Example:

To set the emulation memory to H'1000000-H'10ffff:

```
ms 1000000 10ffff emulator(RET)
```

5.2.21 MODE: MO

Description:

Selects E8000 emulator mode.

Format:

Displays emulator mode.

```
mo
```

Sets emulator mode.

```
mo <mode>
```

Table 5.23 MODE Command Parameter

Parameter	Type	Description
<mode>	Numerical value	Value for emulator mode in the range from H'1 to H'1F.

Example:

To set the E8000 emulator mode setting pins MD4, MD3, MD2, MD1, and MD0 at high, high, low, high, and high, respectively:

```
mo 1b(RET)
```

- Notes:
1. The emulator mode value sets the values to the operating mode setting pins MD4 to MD0.
 2. After this command is executed, the messages Reset by E8000, Firmware System Loading, and ReStart E8000! are displayed on this order in the status bar. Since the emulator settings have been changed, do not touch the HDI until ReStart E8000! is displayed.

5.2.22 MOVE_TO_RAM: MR

Description:

Temporarily stores a user program written in ROM in the RAM.

Format:

```
mr <start address> <end address> [nowrite]
```

Table 5.24 MOVE_TO_RAM Command Parameters

Parameter	Type	Description
<start address>	Numerical value	Start address of the ROM area.
<end address>	Numerical value	End address of the ROM area.

Example:

To temporarily store the user program written in the ROM area from H'0 to H'3ffff in the RAM:

```
mr 0 3ffff(RET)
```

Note: [nowrite] sets a standard emulation memory type. When this setting is not omitted, the standard emulation memory is specified as write-protected.

5.2.23 PERFORMANCE_ANALYSIS: PA

Description:

Displays the program execution state.

Format:

```
pa [<display_mode>]
```

Table 5.25 PERFORMANCE_ANALYSIS Command Parameter

Parameter	Type	Description
<display mode>	Keyword	Display mode for program execution state. Set either of the following. address: Displays subroutine address list. count: Displays execution time and execution count in numerical values. graph: Displays an execution time ratio in graph form. init: Initializes display information.

Examples:

To display an execution time ratio for the program execution state: (The display format is the same as that when graph is specified as a parameter.)

pa (RET)

The display format is as follows:

>***pa***

NO	NAME	MODE	RATE	0--10--20--30--40--50--60--70--80--90--100
1	MAIN	I1	D'1.1%	*
2	SORT1	I1	D'34.6%	*****
3	SORT2	I1	D'16.3%	*****
4				
5				
6				
7				
8				

TOTAL RUN-TIME = D'0000H:00M:08S:029397US

To display an execution time ratio for the program execution state:

pa address (RET)

The display format is as follows:

>***pa address***

NO	NAME	MODE	CONDITION
1	MAIN	I1	01000000:0100002C
2	SORT1	I1	0100002E:01000152
3	SORT2	I1	01000154:010001D6
4			
5			
6			
7			
8			

TOTAL RUN-TIME = D'0000H:00M:08S:029397US

To display an program execution count:

pa count (RET)

The display format is as follows:

>*pa count*

NO	NAME	MODE	RATE	RUN-TIME	E-COUNT
1	MAIN	I1	D'1.1%	D'0000H:00M:00S:091638US	D'00000
2	SORT1	I1	D'34.6%	D'0000H:00M:02S:784208US	D'00597
3	SORT2	I1	D'16.3%	D'0000H:00M:01S:308849US	D'01194
4					
5					
6					
7					
8					

TOTAL RUN-TIME = D'0000H:00M:08S:029397US

To initialize the acquired measurement information:

pa init (RET)

5.2.24 PERFORMANCE_CLEAR: PC

Description:

Clears the performance conditions that have been set.

Format:

```
pc <channel>  
<channel> = channel <channel_number>
```

Table 5.26 PERFORMANCE_CLEAR Command Parameter

Parameter	Type	Description
<channel_number>	Numerical value	Performance channel number from 1 to 8.

Examples:

To clear all performance conditions:

```
pc (RET)
```

To clear the performance condition set to channel 2:

```
pc channel 2 (RET)
```

Note: When <channel> is omitted, all set performance conditions are cleared.

5.2.25 PERFORMANCE_SET: PS

Description:

Sets the condition under which performance information is acquired.

Format:

```
ps <channel> <modeopt> <nameopt> <start> <end> [<option>...]  
<channel>           = channel <channel_number>  
<modeopt>           = mode <mode>  
<nameopt>           = name <name>  
<start>             = start <address> | start <address> to <address>  
<end>               = end <address> | end <address> to <address>  
<option>            = <timeopt> || <accessopt> || <subroutineopt>  
<timeopt>           = time <time> [<count>]  
<accessopt>         = access <address> to <address> [<type>]  
<subroutineopt>    = subroutine <address> to <address>
```

Table 5.27 PERFORMANCE_SET Command Parameters

Parameter	Type	Description
<channel_number>	Numerical value	Channel number from 1 to 8
<mode>	Keyword	Performance information acquisition condition Set either of the following. time1 : Subroutine time measurement mode 1 time2 : Subroutine time measurement mode 2 time3 : Subroutine time measurement mode 3 access : Access area count measurement mode subroutine : Subroutine call count measurement mode
<name>	Character string	Subroutine name
<address>	Numerical value	Address value
<time>	Character string	Timeout time. (This setting is enabled when <channel_number> is specified as 1.) hhh[:mm[:ss[:uuuuu]]]
<count>	Numerical value	Time count conditions in the range from H'1 to H'FFFF. (This setting is enabled when <channel_number> is specified as 1.)
<type>	Keyword	Bus cycle type of the access area. Set either of the following. dat : Execution cycle dma : DMA cycle

Examples:

To set the following conditions for the channel 2 acquisition conditions:

Subroutine time measurement mode: 1,
Subroutine name: sort1,
Start address: H'100002e,
End address: H'100015c.

```
ps channel 2 mode time1 name sort1 start 100002e end  
100015c(RET)
```

To set the following conditions for the channel 5 acquisition conditions:

Subroutine time measurement mode: 3,
Subroutine name: test1,
Start address range: H'1000000 to H'100002e,
End address range: H'1000030 to H'100015c.

```
ps channel 5 mode time3 name test1 start 1000000 to 100002e  
end 1000030 to 100015c(RET)
```

To set the following conditions for the channel 7 acquisition conditions:

Subroutine call count measurement mode,
Subroutine name: sub,
Start address: H'100002e,
End address: H'100015c,
Call subroutine address range: H'100020a to H'10002ce.

```
ps channel 7 mode subroutine name sub start 100002e end  
100015c subroutine 100020a to 10002ce(RET)
```

- Notes:
1. The <timeopt> parameter can be set in subroutine time measurement mode 1, 2, 3.
 2. The <accessopt> parameter can be set in access area count measurement mode.
 3. The <subroutineopt> parameter can be set in subroutine-call count measurement mode.
 4. The range of the <start> and <end> parameters can be set in subroutine time measurement mode 3.

5.2.26 STATUS: STS

Description:

Displays the state information of the E8000 emulator.

Format:

```
sts
```

Table 5.28 STATUS Command Parameter

Parameter	Type	Description
None		

Example:

To display the state information of the E8000 emulator:

```
sts(RET)
```

The display format is as follows:

```
>sts
```

```
Emulator Status
```

```
Connected To:           SH7410 E8000
```

```
CPU                     SH7410
```

```
Mode                   1B
```

```
Clock source           Emulator
```

```
Run status             Break
```

```
Cause of last break    ILLEGAL INSTRUCTION
```

```
Interval Time Count
```

```
(MAX)
```

```
(MIN)
```

```
(AVE)
```

```
Run Time Count
```

```
PIN FAILED AT
```

```
Bus Request            Enable
```

```
Interval Timer counter 1.6us
```

```
Output trigger(UBC)    Disable
```

```
Output trigger(BC-B)   Disable
```

```
Display Execution Time 200ms
```

```
User Wait              Disable
```

```
Emulator Bus width     32bit
```

```
Performance analysis    Passing subroutine end address after start  
                        address
```

```
Emulator mode          Normal
```

```
Display sequence level Inactive
```

5.2.27 TRACEACQUISITION_CLEAR: TAC

Description:

Clears the trace conditions that have been set.

Format:

```
tac <type> [ <channel>]  
<channel> = channel <channel_number> || reset
```

Table 5.29 TRACEACQUISITION_CLEAR Command Parameters

Parameter	Type	Description
<type>	Keyword	Trace condition type Set either of the following. a: TRACE_CONDITION_A b: TRACE_CONDITION_B c: TRACE_CONDITION_C sequence: TRACE_CONDITION_SEQUENCE
<channel_number>	Numerical value	Trace-condition channel number from 1 to 8.

Examples:

To clear all conditions of trace condition A:

```
tac a (RET)
```

To clear the condition that has been set to channel 2 of trace condition B:

```
tac b channel 2 (RET)
```

- Notes:
1. When <channel> is omitted, all trace conditions that have been set are cleared.
 2. When [reset] is omitted, the reset conditions of TRACE_CONDITION_SEQUENCE are cleared.

5.2.28 TRACEACQUISITION_DISPLAY: TAD

Description:

Displays the trace conditions that have been set.

Format:

```
tad <type> [<channel>]  
<channel> = channel <channel_number> || reset
```

Table 5.30 TRACEACQUISITION_DISPLAY Command Parameters

Parameter	Type	Description
<type>	Keyword	Trace condition type Set either of the following. a: TRACE_CONDITION_A b: TRACE_CONDITION_B c: TRACE_CONDITION_C sequence: TRACE_CONDITION_SEQUENCE
<channel_number>	Numerical value	Trace-condition channel number from 1 to 8.

Examples:

To display all conditions of trace condition A:

```
tad a (RET)
```

The display format is as follows:

```
>tad a
```

```
Trace Condition A1:Enable  type range address 100036c direction  
                           write  
Trace Condition A2:Enable  type stop address 10001ac  
Trace Condition A3:Enable  type range address 1000000 to 100002c  
Trace Condition A4:Disable  
Trace Condition A5:Disable  
Trace Condition A6:Disable  
Trace Condition A7:Enable  type range prb 0101  
Trace Condition A8:Enable  type range irq 0000 nmi hi
```

To display the condition that has been set to channel 2 of trace condition B:

```
tad b channel 2(RET)
```

The display format is as follows:

```
>tad b channel 2
```

```
Trace Condition B2:Enable  type subroutine 10002a0 10002c0
```

- Notes:
1. When <channel> is omitted, all trace conditions that have been set are displayed.
 2. When [reset] is set, the reset conditions of TRACE_CONDITION_SEQUENCE are displayed.

5.2.29 TRACEACQUISITION_SET: TAS

Description:

Sets trace conditions for acquiring trace information.

Format:

```
tas <type> <channel> <tracetype> <option> [<option>...][<delayopt> |
<countopt>]
<channel>      = channel <channel_number> || reset
<option>       = <addropt> | <dataopt> | <r/wopt> | <accessopt> |
<prbopt> |    <nmiopt> | <irqopt>
<tracetype>    = type <tracetype> || type <tracetype> <startrange> to
               <endrange>
<addropt>      = address <address>[to <address>] [not] || address mask
               <maskdata>
<dataopt>      = data <data> <datawidth> [not] || data mask <maskdata>
<r/wopt>       = direction <r/w>
<accessopt>    = access <access>
<prbopt>       = prb <probe>
<nmiopt>       = nmi <nmi>
<irqopt>       = irq <irq>
<delayopt>     = delay <delay>
<countopt>     = count <count>
```

Table 5.31 TRACEACQUISITION_SET Command Parameters

Parameter	Type	Description
<type>	Keyword	Trace condition type Set either of the following. a: TRACE_CONDITION_A b: TRACE_CONDITION_B c: TRACE_CONDITION_C sequence: TRACE_CONDITION_SEQUENCE
<channel_number>	Numerical value	Trace-condition channel number from 1 to 8
<tracetype>	Keyword	Trace information acquisition condition Set either of the following. subroutine: Subroutine trace range: Range trace subrange: Range trace within a subroutine stop: Trace stop
<startrange>	Numerical value	Subroutine start address when the subroutine trace or the range trace within a subroutine is set.
<endrange>	Numerical value	Subroutine end address when the subroutine trace or the range trace within a subroutine is set.
<address>	Numerical value	Address bus value
<maskdata>	Character string	Value to be masked
<data>	Numerical value	Data bus value
<datawidth>	Keyword	Data bus access conditions Set either of the following. byte: Byte access word: Word access long: Longword access
<r/w>	Keyword	Read/write condition Set either of the following. read: Read cycle write: Write cycle

Table 5.31 TRACEACQUISITION_SET Command Parameters (cont)

Parameter	Type	Description
<access>	Keyword	Bus state conditions Set either of the following. dat : Data access cycle dma : DMA cycle vcf : Vector fetch cycle
<probe>	Numerical value	External probe conditions
<nmi>	Keyword	NMI signal conditions Set either of the following. low : Conditions are satisfied when the NMI signal is low. hi : Conditions are satisfied when the NMI signal is high.
<irq>	Numerical value	IRQ signal conditions
<delay>	Numerical value	Bus cycle count executed after condition satisfaction within the range from H'1 to H'7FFF
<count>	Numerical value	Pass count until condition satisfaction within the range from H'1 to H'FFFF

Examples:

To set trace stop when the following conditions are satisfied for channel 2 of trace condition A:

Address condition: Address bus value of H'100027c to H'1000304,
Read/write cycle condition: Write cycle only.

```
tas a channel 2 type stop address 100027c to 1000304
direction write(RET)
```

To set trace information acquisition when the following conditions are satisfied for channel 3 of trace condition B:

Data condition: Data bus value of H'4750 and word access,
Bus state condition: DAT cycle only,
Read/write cycle condition: Read cycle only.

```
tas b channel 3 type range data 4750 word access dat
direction read(RET)
```

To set trace information acquisition when the following conditions are satisfied for channel 5 of trace condition A:

External probe condition: PROBE4=LOW, PROBE3=HIGH, PROBE2=LOW, PROBE1=HIGH.

```
tas a channel 5 type range prb 0101(RET)
```

To set trace information acquisition when the following conditions are satisfied for channel 7 of trace condition B:

IRQ signal condition: IRQ3=HIGH, IRQ2=HIGH, IRQ1=HIGH, IRQ0=HIGH,
NMI signal condition: NMI=LOW.

```
tas b channel 7 type range irq 1111 nmi low(RET)
```

To set trace information acquisition when the following conditions are satisfied for channel 1 of trace condition B:

Address condition: Mask specification at address bus value = H'1000***.

```
tas b channel 1 type range address mask H'1000***(RET)
```

To set trace information acquisition when the following conditions are satisfied for channel 3 of trace condition B:

Address bus value: Except the range from H'1000000 to H'10001c0.

```
tas b channel 3 type range address 1000000 to 10001c0 not(RET)
```

To set trace information acquisition stop after executing the program for 10 cycles when the following conditions are satisfied:

Address bus value: In the order of H'10002ac, H'1000304, and H'1000402,

and to reset the pass sequence analysis when the following conditions are satisfied:

Address bus range: From H'10002cc to H'10002fc.

```
tas sequence channel 1 address 10002ac(RET)
```

```
tas sequence channel 2 address 1000304(RET)
```

```
tas sequence channel 7 address 1000402 delay a(RET)
```

```
tas sequence reset address 10002cc to 10002fc(RET)
```

Notes: 1. When [not] is set, the values or ranges other than set address bus values, address bus ranges, or set data bus values are set.

2. Each bit for external probe conditions and IRQ signal conditions is set as follows:

(1) Bit specification for the PRB1-PRB4 signals

3	2	1	0: Bit position
x	x	x	x: 0 (low level) or 1 (high level) is set for x.
4	3	2	1: PRB number

(2) Bit specification for IRQ0-IRQ3 signals

3	2	1	0: Bit position
x	x	x	x: 0 (low level) or 1 (high level) is set for x.
3	2	1	0: IRQ number

Setting a mask character* excludes the external probe conditions or IRQ signal conditions at the corresponding bit position.

3. When [reset] is set, the reset conditions for TRACE_CONDITION_SEQUENCE are set.

4. When b or sequence is set to the <type> parameter, and when the <channel_number> parameter is 7, the <delayopt> parameter can be set.

5. Set one or more <option> parameters to the <delayopt> parameter.

6. The <countopt> parameter can be set when the <type> parameter is b.

7. Set one or more <option> parameters to the <countopt> parameter.

8. When b is set to the <type> parameter, [not] is enabled.

9. When c is set to the <type> parameter, only the <addropt> and <accessopt> can be set to the <option> parameter.

5.2.30 TRACE_DISPLAY: TD

Description:

Displays acquired trace information.

Format:

```
td <rangeopt>  
<rangeopt> = range <startcycle> to <endcycle>
```

Table 5.32 TRACE_DISPLAY Command Parameters

Parameter	Type	Description
<startcycle>	Numerical value	Start cycle value to be displayed
<endcycle>	Numerical value	End cycle value to be displayed

Example:

To display the acquired trace information:

```
td range -100 to 0 (RET)
```

5.2.31 TRACE_MODE: TM

Description:

Sets the trace information acquisition mode.

Format:

Displays trace information acquisition mode.

```
tm
```

Sets trace information acquisition mode.

```
tm [<tracemode>] [time <time>]  
<tracemode> = [dma] || [ref] || [ofbreak]
```

Table 5.33 TRACE_MODE Command Parameters

Parameter	Type	Description
<tracemode>	Keyword	Trace information acquisition mode Set either of the following. dma: Set when trace information is acquired during DMA cycles. When omitted, no trace information is acquired during DMA cycles. ref: Set when trace information is acquired during refresh cycles. When omitted, no trace information is acquired during refresh cycles. ofbreak: Set when a break occurs when the trace buffer overflows. When omitted, no break occurs and execution is continued.
<time>	Keyword	Minimum time for time stamp when the trace information is acquired. Set either of the following. 20ns: Displays in units of 20 ns. 1.6us: Displays in units of 1.6 μ s. 52us: Displays in units of 52 μ s. CLK: Acquires the number of clocks.

Examples:

To display the trace information acquisition mode that has been set:

```
tm (RET)
```

The display format is as follows:

```
>tm  
trace_mode time 20ns
```

To set the trace information acquisition mode so that trace information is acquired during DMA cycles and refresh cycles:

```
tm dma ref(RET)
```

5.2.32 TRACE_SEARCH: TS

Description:

Searches the information that agrees with the condition from among the acquired trace information.

Format:

```
ts <rangeopt> <option> [<option>...]  
<rangeopt>    = range <startcycle> to <endcycle>  
<option>      = <addropt> | <dataopt> | <r/wopt> | <accessopt> |  
<prbopt> |    <memopt> | <nmiopt> | <irqopt> | <resetopt>  
| <timeopt>  
<addropt>    = address <address>[to <address>] || address mask  
<maskdata>  
<dataopt>    = data <data> <datawidth> || data mask <maskdata>  
<r/wopt>     = direction <r/w>  
<accessopt>  = access <access>  
<prbopt>    = prb <probe>  
<memopt>    = memory <memory>  
<nmiopt>    = nmi <nmi>  
<irqopt>    = irq <irq>  
<resetopt>  = reset  
<timeopt>   = time <time> [to <time>]
```

Table 5.34 TRACE_SEARCH Command Parameters

Parameter	Type	Description
<startcycle>	Numerical value	Start cycle value of the search range
<endcycle>	Numerical value	End cycle value of the search range
<address>	Numerical value	Address bus value
<maskdata>	Character string	Value to be masked
<data>	Numerical value	Data bus value
<datawidth>	Keyword	Data bus access conditions Set either of the following. byte : Byte access word : Word access long : Longword access
<r/w>	Keyword	Read/write conditions Set either of the following. read : Read cycle write : Write cycle
<access>	Keyword	State conditions Set either of the following. dat : Execution cycle dma : DMA cycle vcf : Vector fetch cycle
<probe>	Numerical value	External probe signal conditions
<memory>	Keyword	Accessed memory area type Set either of the following. int : Internal memory area io : Internal I/O area ext : External memory area
<nmi>	Keyword	NMI signal conditions Set either of the following. low : Condition is satisfied when the NMI signal is low. hi : Condition is satisfied when the NMI signal is high.

Table 5.34 TRACE_SEARCH Command Parameters (cont)

Parameter	Type	Description
<reset>	Keyword	Set when the RES signal searches for low level of the bus cycle.
<irq>	Numerical value	IRQ signal conditions
<time>	Character string	Searching range of time

Examples:

To display trace information that agrees with the following conditions:

Address condition: Address bus value from H'100027c to H'1000304,
Read/write cycle condition: Write cycle only.

```
ts address 100027c to 1000304 direction write(RET)
```

To display trace information that agrees with the following conditions:

Data condition: Data bus value of H'4750 and word access,
Bus state condition: DAT cycle only,
Read/write cycle condition: Read cycle only.

```
ts b channel 3 data 4750 word access dat direction read(RET)
```

Note: Each bit for the external probe conditions and IRQ signal conditions is set as follows:

(1) Bit specification for the PRB1-PRB4 signals

3	2	1	0 : Bit position
x	x	x	x : 0 (low level) or 1 (high level) is set for x.
4	3	2	1 : PRB number

(2) Bit specification for IRQ0-IRQ3 signals

3	2	1	0 : Bit position
x	x	x	x : 0 (low level) or 1 (high level) is set for x.
3	2	1	0 : IRQ number

Setting a mask character* excludes the external probe conditions or IRQ signal conditions at the corresponding bit position.

5.2.33 UBC_CLEAR: UBC

Description:

Clears the UBC breakpoints that have been set.

Format:

```
ubc [<channel>]  
<channel> = channel <channel_number>
```

Table 5.35 UBC_CLEAR Command Parameter

Parameter	Type	Description
<channel_number>	Numerical value	UBC break channel number 1 or 2

Example:

To clear all UBC breakpoints:

```
ubc (RET)
```

To clear the UBC2 breakpoints:

```
ubc channel 2 (RET)
```

Note: When <channel> is omitted, all UBC breakpoints are cleared.

5.2.34 UBC_DISPLAY: UBD

Description:

Displays the UBC breakpoints that have been set.

Format:

```
ubd [<channel>]  
<channel> = channel <channel_number>
```

Table 5.36 UBC_DISPLAY Command Parameter

Parameter	Type	Description
<channel_number>	Numerical value	UBC break channel number 1 or 2

Example:

To display all UBC breakpoints:

```
ubd (RET)
```

The display format is as follows:

```
>ubd
```

```
Break Condition UBC1:Enable data 20 long access dma direction read  
count 10
```

```
Break Condition UBC2:Disable address 126 access dma direction write
```

To display the UBC1 breakpoint:

```
ubd channel 1 (RET)
```

The display format is as follows:

```
>ubd channel 1
```

```
Break Condition UBC1:Enable data 20 long access dma direction read  
count 10
```

Note: When <channel> is omitted, all UBC breakpoints are displayed.

5.2.35 UBC_ENABLE: UBE

Description:

Enables or disables the UBC breakpoints that have been set.

Format:

```
ube [<channel>] <mode>  
<channel> = channel <channel_number>
```

Table 5.37 UBC_ENABLE Command Parameters

Parameter	Type	Description
<channel_number>	Numerical value	UBC break channel number 1 or 2
<mode>	Keyword	Enables or disables UBC break. Set either of the following. enable: Enables UBC break condition setting. disable: Disables UBC break condition setting.

Example:

To enable the UBC2 breakpoint:

```
ube channel 2 enable(RET)
```

To disable the UBC1 breakpoint:

```
ube channel 1 disable(RET)
```

Note: When <channel> is omitted, all UBC breakpoints are enabled or disabled.

5.2.36 UBC_SET: UBS

Description:

Sets the UBC breakpoints.

Format:

```
ubs <channel> <option> [<option>...][<countopt>]
<channel>      = channel <channel_number>
<option>       = <addropt> | <dataopt> | <r/wopt> | <accessopt>
<addropt>     = address <address> [<addrcycle>] || address mask
<maskdata>
<dataopt>     = data <data> <datawidth> || data mask <maskdata>
<r/wopt>      = direction <r/w>
<accessopt>   = access <access>
<countopt>    = count <count>
```

Table 5.38 UBC_SET Command Parameters

Parameter	Type	Description
<channel_number>	Numerical value	UBC break channel number 1 or 2
<address>	Numerical value	Address bus value
<addrcycle>	Keyword	Address bus access conditions
		Set either of the following. pc : Address bus of the program fetch cycle. The execution breaks before the address set by <address>. pcafter : Address bus of the program fetch cycle. The execution breaks after the address set by <address>. x : X-bus address bus. Set <address> in word size. y : Y-bus address bus. Set <address> in word size. When <addrtype> is omitted, the address bus for data access or program fetch cycle is set.
<maskdata>		Value to be masked
<data>	Numerical value	Data bus value

Table 5.38 UBC_SET Command Parameters (cont)

Parameter	Type	Description
<datawidth>	Keyword	Data bus access conditions Set either of the following. byte : Byte access word : Word access long : Long word access x : X-bus data access Set <data> in word size. y : Y-bus data access Set <data> in word size.
<r/w>	Keyword	Read/write conditions Set either of the following. read : Read cycle write : Write cycle
<access>	Keyword	Bus state conditions Set either of the following. dat : Execution cycle dma : DMA cycle
<count>	Numerical value	Breakpoint pass count Set a value within the range from H'1 to H'FFF.

Examples:

To set the following conditions for the UBC1 breakpoint:

Data condition: Data bus value of H'108 and word access,
Bus state condition: DMA cycle only,
Read/write cycle condition: Read cycle only,
Condition satisfaction count: Twice.

ubs channel 1 data 108 word access dma direction read count 2(RET)

To set the following conditions for the UBC2 breakpoint:

Address condition: Address bus value of H'200,
Read/write cycle condition: Read cycle only.

ubs channel 2 address 200 direction write(RET)

- Notes:
1. The <countopt> parameter can be set when the <channel_number> parameter is 1.
 2. Set one or more <option> parameters for the <countopt> parameter.
 3. When 2 is set to the <channel_number> parameter, only the <addropt>, <r/wopt>, and <accessopt> parameters can be set to the <option> parameter. In addition, only x and y can be set to the <addrcycle> parameter.

Section 6 Use of Diagnostic Program

6.1 Diagnostic Program Operation

An E8000 emulator diagnostic program can be used on the HDI. The installation procedure and operating details of diagnostic program are given in the SH7410 E8000 Emulator Diagnostic Program Operation Manual. This section describes how to run the diagnostic program on the HDI.

6.1.1 Diagnostic Program Installation on the HDI

To use the diagnostic program, the [Yes] button must be clicked in the dialog box displayed when installing the HDI in order to install the diagnostic program.




Figure 6.1 HDI Installation Dialog Box

6.1.2 TARGET.INI File Setting

In HDI installation, a file named TARGET.INI is created. This file contains resource information indicating whether or not the diagnostic program is to be started when the HDI is activated.

```
[E8000 HDI TARGET]
Diagnostic Program=Y
```

Figure 6.2 Example of TARGET.INI File Display

If the diagnostic program is to be run when the HDI is activated, set the following “Diagnostic Program” resource information in the TARGET.INI file.

```
Diagnostic Program=Y
```

Diagnostic Program=Y is set in the default TARGET.INI file.

If the diagnostic program is not to be run, change the setting as follows:

```
Diagnostic Program=N
```

6.1.3 Diagnostic Program Start-Up

When the HDI is activated, the following dialog box is displayed.




Figure 6.3 Diagnostic Program Start-Up Confirmation Dialog Box

When the [Yes] button is clicked, the diagnostic program is started and the following window is displayed.




Figure 6.4 Diagnostic Program Start-Up Window

- **Display area**
Displays the diagnostic program test results.
- **COMMAND text box**
For input of a diagnostic program operation command.
- **STOP button**
Stops the diagnostic program test and switches to the diagnostic program operation command input mode.
- **END button**
Terminates the diagnostic program and activates the HDI.

6.1.4 Diagnostic Program Termination

To terminate the diagnostic program, either click the [END] button or else click the [STOP] button to stop the test and then enter Q in the COMMAND area. This terminates the diagnostic program and activates the HDI.




Figure 6.5 Diagnostic Program Termination

Note: The diagnostic program can only be terminated when waiting for user input during testing.

Section 7 Error Messages

7.1 Error Messages

The HDI outputs error messages to notify the user of operating errors. The error messages output by the HDI are shown in table 7.1.

Table 7.1 Error Messages

Message	Cause and Countermeasure
Can not set target configuration (Clock mode option)	A mode in which the E8000 emulator is not supported has been selected in [Clock] in the Configuration window.
Can not set target configuration (CPU mode option)	A mode in which the E8000 emulator is not supported has been selected in [CPU mode] in the Configuration window.
Can not set target configuration (Execution mode option)	A mode in which the E8000 emulator is not supported has been selected in [Execution mode] in the Configuration window.
Cannot use command when user program executing	Command line input has been performed when a command cannot be issued to the E8000 emulator. Wait for processing to finish.
Command timeout	The HDI has timed out because no response has been received from the E8000 emulator after the HDI issued a command. Terminate the HDI, power on the E8000 emulator, and restart the HDI.
Emulator command send/receive check error	Communication with the E8000 emulator was not performed correctly on HDI activation. Terminate the HDI, power on the E8000 emulator, and restart the HDI. If the illegal communication is not corrected, inform a Hitachi sales representative or agency of the situation.
Emulator firmware not ready	"EMULATOR FIRMWARE NOT READY" is output from the E8000 emulator. Terminate the HDI and check whether the E8000 emulator is functioning normally.
Emulator timeout	A timeout message has been received from the E8000 emulator. Terminate the HDI and check whether the E8000 emulator is functioning normally.
Failed to find matching trace record	This message is output when there is no trace information.

Table 7.1 Error Messages (cont)

Message	Cause and Countermeasure
Hardware register read/write check error	An error was detected when the E8000 emulator hardware and firmware were tested. Terminate the HDI and check whether the E8000 emulator is functioning normally.
Invalid version number in target configuration	The current e8ksh741.dll version is different from the version when the session file was created. Do not use an old session file.
System ID error	An emulator different from the SH7410 E8000 emulator is connected. Connect the SH7410 E8000 emulator to the host computer.
Target internal error	Commands cannot be issued to the E8000 emulator. Wait for processing to finish.
User system not ready	"No clock" has been detected. The HDI is terminated.

SH7410 E8000 Hitachi Debugging Interface User's Manual

Publication Date: 1st Edition, September 1999
2nd Edition, September 2000

Published by: Electronic Devices Sales & Marketing Group
Semiconductor & Integrated Circuits
Hitachi, Ltd.

Edited by: Technical Documentation Group
Hitachi Kodaira Semiconductor Co., Ltd.

Copyright © Hitachi, Ltd., 1999. All rights reserved. Printed in Japan.