

# 120-degree conducting control of permanent magnetic synchronous motor using hall sensors

For Renesas Flexible Motor Control Series

## Introduction

This application note describes the sample program to drive a permanent magnetic synchronous motor with 120-degree conducting method using hall sensors based on Renesas microcontroller.

The targeted software for this note is only to be used for reference purposes and Renesas Electronics Corporation does not guarantee the operations. Please use this after carrying out a thorough evaluation in a suitable environment.

## Contents

|   |    |
|---|----|
| 1. Introduction .....   | 4  |
| 2. Glossary .....   | 6  |
| 3. Used hardware and software .....   | 7  |
| 3.1 List of used hardware .....   | 7  |
| 3.2 List of used software .....   | 7  |
| 4. Building a hardware environment .....                                    | 8  |
| 4.1 Overview : Hardware environments .....                                  | 8  |
| 4.2 Preparing the power supply .....  | 8  |
| 4.3 Preparing the inverter .....  | 9  |
| 4.4 Setting up the RA series CPU board .....                                | 9  |
| 4.5 Connection example of kit .....   | 12 |
| 4.6 Connection of Hall sensor .....   | 13 |
| 4.7 On board debugger .....   | 13 |
| 4.8 Wiring .....  | 14 |
| 5. Environment to build the sample software .....                           | 15 |
| 6. Driving the motor .....  | 16 |
| 6.1 Precautions before driving the motor .....                              | 16 |
| 6.2 Connecting .....  | 16 |
| 6.3 Writing the sample program .....  | 20 |
| 6.3.1 Install e <sup>2</sup> studio .....                                   | 20 |
| 6.3.2 Import a project .....  | 20 |
| 6.3.3 Build the target project .....  | 24 |
| 6.3.4 Connection between PC and the target CPU board via an USB cable ..... | 26 |
| 6.3.5 Writing to the target board (with built program) .....                | 27 |

|       |  |    |
|-------|--|----|
| 6.4   | Introducing RMW.....                             | 29 |
| 6.5   | Registering and updating the Map file.....       | 30 |
| 6.6   | Variables used for working with RMW .....        | 31 |
| 6.7   | Controlling the motor .....                      | 33 |
| 6.8   | Stopping and shutting down the motor.....        | 35 |
| 7.    | Motor control algorithm.....                     | 36 |
| 7.1   | Overview.....                                    | 36 |
| 7.2   | Detection of rotor angle with hall sensors ..... | 37 |
| 7.3   | Speed control function.....                      | 38 |
| 7.4   | Voltage control by PWM .....                     | 39 |
| 7.5   | Start-up method.....                             | 41 |
| 8.    | Hardware specifications .....                    | 42 |
| 8.1   | User interface .....                             | 42 |
| 8.2   | Peripheral functions.....                        | 44 |
| 9.    | Software specifications and configuration .....  | 46 |
| 9.1   | Software specifications.....                     | 46 |
| 9.2   | Overall configuration of the software.....       | 47 |
| 9.3   | Explanation about interrupt .....                | 48 |
| 9.4   | File and folder configuration .....              | 49 |
| 9.5   | Application layer .....                          | 52 |
| 9.5.1 | Functions .....                                  | 52 |
| 9.5.2 | Configurations .....                             | 52 |
| 9.5.3 | Structure and variable information .....         | 53 |
| 9.5.4 | Macro definition .....                           | 55 |
| 9.6   | Interface Module.....                            | 58 |
| 9.6.1 | Functions .....                                  | 58 |
| 9.6.2 | Module configuration diagram.....                | 59 |
| 9.6.3 | State transition .....                           | 60 |
| 9.6.4 | Protection function.....                         | 61 |
| 9.6.5 | API .....  | 62 |
| 9.6.6 | Structure and variable information .....         | 63 |
| 9.6.7 | Macro and enumeration definition .....           | 65 |
| 9.7   | 120-degree hall Control Module .....             | 68 |
| 9.7.1 | Functions .....                                  | 68 |
| 9.7.2 | Module configuration diagram.....                | 68 |
| 9.7.3 | API .....  | 69 |
| 9.7.4 | Structure and variable information .....         | 70 |
| 9.7.5 | Macro and enumeration definition .....           | 74 |

|        |  |     |
|--------|--|-----|
| 9.8    | 120-degree driver Module .....                             | 77  |
| 9.8.1  | Functions .....  | 77  |
| 9.8.2  | Module configuration diagram .....                         | 77  |
| 9.8.3  | API .....  | 78  |
| 9.8.4  | Structure and variable information .....                   | 79  |
| 9.8.5  | Macro and enumeration definition .....                     | 83  |
| 10.    | Setting the parameters .....                               | 87  |
| 10.1   | Overview .....   | 87  |
| 10.2   | List of Interface module parameters .....                  | 87  |
| 10.3   | List of 120-degree control module parameters .....         | 88  |
| 10.4   | List of 120-degree driver module parameters .....          | 91  |
| 10.5   | Parameters about protection function .....                 | 95  |
| 10.6   | Changing the PWM carrier frequency .....                   | 95  |
| 10.7   | modulation method (chopping pattern) .....                 | 95  |
| 10.8   | Parameters for inverter .....                              | 96  |
| 10.8.1 | Deadtime .....   | 96  |
| 10.8.2 | Current detection gain .....                               | 96  |
| 10.8.3 | Voltage detection gain .....                               | 96  |
| 10.9   | Motor parameters .....                                     | 97  |
| 11.    | Control flowcharts .....                                   | 99  |
| 11.1   | Main process .....   | 99  |
| 11.2   | Carrier periodic interrupt process .....                   | 100 |
| 11.3   | Speed control Periodic Interrupt Process .....             | 101 |
| 11.4   | Hall signal interrupt process .....                        | 102 |
| 11.5   | Over Current Detection Interrupt Process .....             | 103 |
| 12.    | FAQ .....  | 104 |
| 12.1   | Troubleshooting .....                                      | 104 |
| 12.2   | Frequently asked questions .....                           | 105 |
| 12.2.1 | The value of a variable displayed in RMW is abnormal ..... | 105 |
|        | Revision History .....                                     | 106 |

## 1. Introduction

This application note explains how to implement the 120-degree conducting control software that drives permanent magnetic synchronous motor using the microcontroller (MCU) Renesas RA series. This sample program can drive a motor with the electrical kit 'Renesas Flexible Motor Control Series'. And, this program supports the motor control development support tool, 'Renesas Motor Workbench'. User can confirm the parameters of program with this tool and can use as User Interface to control motor driven. Please consider selecting which MCU or develop your program with refer to the period of interrupt process.

This sample program supports 'QE for Motor'. Please use the workflow to develop motor software simply by following the steps.

### Target software

The following shows the target software for this application note:

- RA6T2\_MCILV1\_SPM\_HALL\_120\_E2S\_V120
- RA6T2\_MCB2\_MCILV1\_SPM\_HALL\_120\_E2S\_V100
- RA6T2\_MCILV1\_SPM\_HALL\_120\_E2S\_V120
- RA6T3\_MCILV1\_SPM\_HALL\_120\_E2S\_V110
- RA4T1\_MCILV1\_SPM\_HALL\_120\_E2S\_V110
- RA8T1\_MCILV1\_SPM\_HALL\_120\_E2S\_V110
- RA8T2\_MCILV1\_SPM\_HALL\_120\_E2S\_V100

### Reference materials

RA6T2 Group User's Manual: Hardware (R01UH0951)

RA6T3 Group User's Manual: Hardware (R01UH0998)

RA4T1 Group User's Manual: Hardware (R01UH0999)

RA8T1 Group User's Manual: Hardware (R01UH1016)

RA8T2 Group User's Manual: Hardware (R01UH1067)

RA Flexible Software Package Documentation (Release v6.1.0)

120-degree conducting control of permanent magnetic synchronous motor (Algorithm) (R01AN2657)

Renesas Motor Workbench User's Manual (R21UZ0004)

Renesas Motor Workbench Quick start guide (R21QS0011)

MCK-RA6T2 User's Manual (R12UZ0091)

MCK-RA6T3 User's Manual (R12UZ0114)

MCK-RA4T1 User's Manual (R12UZ0115)

MCK-RA8T1 User's Manual (R12UZ0133)

MCK-RA8T2 User's Manual (R12UZ0172)

The following shows a summary of the items that you should check carefully when using this application note and the corresponding chapter for each.

**Table 1-1 List of items to be checked and the corresponding chapters**

| Items to be checked  | Corresponding chapter |
|--|-----------------------|
| Identify and select necessary environments                     | 3                     |
| Confirm the wiring   | 4.8                   |
| Prepare a software development environment                     | 5                     |
| Write the sample program to MCU                                | 6.3                   |
| Install software for operating the motor on the PC.            | 6.4                   |
| Modify the sample program, and then reflect the changes in RMW | 6.5                   |
| Drive the motor  | 6.7                   |
| Stop the motor   | 6.8                   |
| Examine the motor control algorithms                           | 7                     |
| Examine the structure of the sample program                    | 8                     |
| Verify and change the motor parameters                         | 10.9                  |
| Changing the PWM carrier frequency                             | 10.6                  |
| Check the frequently asked questions                           | 12                    |
| Check the troubleshooting tips                                 |                       |

## 2. Glossary

The following lists the main terms used in this document and their descriptions.

**Table 2-1 Glossary**

| Term                 | Description  |
|----------------------|--|
| MC-COM               | Refers to a set of communication jigs and tools for displaying waveforms. For details, refer to the following URL.<br><a href="https://www.renesas.com/design-resources/boards-kits/mc-com">https://www.renesas.com/design-resources/boards-kits/mc-com</a>  |
| RMW                  | Refers to Renesas Motor Workbench, which is the GUI operation software on PC specifically designed for motor control.  |
| QE for Motor         | QE for Motor is a software development support tool for motors that allows you to develop motor software by simply following the workflow. For details, refer to the following URL.<br><a href="https://www.renesas.com/software-tool/qe-motor-development-assistance-tool-motor-applications">https://www.renesas.com/software-tool/qe-motor-development-assistance-tool-motor-applications</a> |
| Inverter bus voltage | Refers to the DC voltage fed to the inverter circuit. Also called DC intermediate voltage.   |
| Open loop            | Refers to a motor control technique that does not need current or position feedback signals to control the voltage.  |
| Sensorless           | In this document, this is used to indicate that there is no magnetic pole position sensor or speed sensor. Omitting the sensors is considered as an advantage because the position sensors and speed sensors present disadvantages in terms of cost and environmental robustness.  |
| Electrical angle     | Phase angle of the output current flowing in the motor. It can be converted to a mechanical angle by dividing it by the number of pole pairs of the motor.   |
| Mechanical angle     | Refers to the physical rotation angle of the motor axis. One rotation of the axis per minute is 1rpm.  |

### 3. Used hardware and software

#### 3.1 List of used hardware

The following lists the hardware devices used for evaluating this sample program.

**Table 3-1 Development Environment : Hardware**

| Category                                 | Product used   |
|--|--|
| Microcontroller / CPU board product type | RA6T2 (R7FA6T2BD3CFP) / MCB Ver.1 RTK0EMA270C00000BJ<br>RA6T2 (R7FA6T2BD3CFP) / MCB Ver.2 RTK0EMA270C00002BJ<br>RA6T3 (R7FA6T3BB3CFM) / RTK0EMA330C00000BJ<br>RA4T1 (R7FA4T1BB3CFM) / RTK0EMA430C00000BJ<br>RA8T1 (R7FA8T1AHECBD) / RTK0EMA5K0C00000BJ<br>RA8T2 (R7KA8T2LFLCAC) / RTK0EMA6L0C00000BJ |
| Inverter board                           | MCI-LV-1 Inverter board / RTK0EM0000B12020BJ   |
| Motor                                    | R42BLD30L3 (Product of 'MOONS')  |

#### 3.2 List of used software

The following lists the software and its version used for evaluating this sample program. This sample program can be used within limitations of our development environment e<sup>2</sup> studio evaluation edition.

**Table 3-2 Software Development Environment**

| e <sup>2</sup> studio version   | FSP version | Toolchain version                 |
|---------------------------------|-------------|-----------------------------------|
| e <sup>2</sup> studio : 2025-07 | V6.1.0      | GCC ARM Embedded :13.2.1.arm-13-7 |

## 4. Building a hardware environment

### 4.1 Overview : Hardware environments

This section describes hardware environments in which an SPM motor is operated using this sample program. Figure 4-1 shows an example of hardware configuration.

In the sections that follow, the power supply (4.2), the inverter (4.3), the CPU boards(4.4) and the on board debugger (4.7) are described in detail.




Figure 4-1 Example of hardware configuration

### 4.2 Preparing the power supply

In this sample program, DC stabilized power supply/AC adapter/a control power supply (capable of output of 24V, 2.5A or more) is used to supply a voltage of 24 VDC to the 3-phase inverter MCI-LV-1.

The voltage supplied to the inverter varies depending on the inductive voltage, rating conditions, maximum load conditions of the motor to be used. Please select an appropriate type of power supply based on your experimental environment and restrictions and conditions of AC power supply to be used.

The inverter introduced here has an output current of 10 A max.

### 4.3 Preparing the inverter

When preparing your inverter, note the following information: This sample program is configured for MCI-LV-1 and must be changed if you use another inverter.

- Rated capacity (VA)
- Dead time value [ $\mu$ s]
- Type, characteristics, and signal specifications of the current sensor
- Characteristic data of the current sensor, including gain and offset values, the relationship between the current and voltage, and linearity of the signals
- Characteristic data of the voltage sensor, including the relationship between the current and voltage and linearity of the signals

### 4.4 Setting up the RA series CPU board

This section describes how to install the RA series CPU board, which can be plugged in MCI-LV-1 directly.




Figure 4-2 RA6T2 CPU board and its interface




Figure 4-3 RA6T3 CPU board and its interface




Figure 4-4 RA4T1 CPU board and its interface




Figure 4-5 RA8T1 CPU board and its interface




Figure 4-6 RA8T2 CPU board and its interface

#### 4.5 Connection example of kit

Figure 4-7 shows an example of the connection of a CPU board in combination with an inverter board kit (MCI-LV-1) and a communication board kit (MC-COM, model name: RTK0EMXC90Z00000BJ).




Figure 4-7 Connection example of kit

#### 4.6 Connection of Hall sensor

Please connect the cables of hall sensor signals and connector for hall sensor signal according to Table 4-1. (Please refer Figure 4-8.)

Table 4-1 Connection of signals

| Function               | Connector port number (in MCI-LV-1) |
|------------------------|-------------------------------------|
| GND                    | CN6 1pin                            |
| +5V                    | CN6 2pin                            |
| Hall sensor input (HW) | CN6 3pin                            |
| Hall sensor input (HV) | CN6 4pin                            |
| Hall sensor input (HU) | CN6 5pin                            |




Figure 4-8 Invertor board (MCI-LV-1)

#### 4.7 On board debugger

The RA series CPU boards include the circuit of "On board debugger J-Link OB (after here, JLOB). The update of program is performed through JLOB. When update, please connect CPU board and your PC via an USB cable.

## 4.8 Wiring

This section describes how to wire between the power supply, inverter, and motor. Terminal names vary depending on the devices used, so be sure to refer to the instruction manuals of the devices to verify the contents and specifications before wiring.

Figure 4-9 shows an example of wiring between the power supply and the inverter. Here, the output terminals of the regulated DC power supply are connected to the P and GND terminals of the inverter. Be careful not to connect with the wrong polarity. Figure 4-10 shows an example of wiring between the inverter and the motor.




Figure 4-9 Wiring between the power supply and the inverter




Figure 4-10 Wiring between the inverter and the motor

## 5. Environment to build the sample software

To develop the sample program in this application note, we will use e<sup>2</sup> studio with RA FSP as the development environment. Please download the installation environment from the following.

Download e<sup>2</sup> studio from the following URL:

<https://www.renesas.com/en/software-tool/flexible-software-package-fsp>

For installation instructions, refer to the PDF manual included with e<sup>2</sup> studio.

For more information on how to use it, refer to the PDF manual that you can download on the above URL or the videos.

How to upload the program to MCU is described in detail on “6.3 Writing the sample program”.

## 6. Driving the motor

This chapter describes how to drive a motor. Please confirm "6.1 Precautions before driving the motor" and operate according to "6.2 Connecting".

### 6.1 Precautions before driving the motor

When driving the motor, note the following points: Improper use may cause electric shock or failure of the devices.

- Do not control the motor under the conditions where the tracing and breakpoints are set while using E2OB. A sudden stop may cause the inverter to operate abnormally. Use RMW and debug under the conditions where the safety functions work properly.
- MC-COM can be safely used during operation because the signals are isolated. When a similar device is used, the GND of the PC and the inverter may be common, which could cause an electric shock hazard via the GND.
- Design the experimental facility so that the motor can be stopped in an emergency.
- When the inverter is stopped but the PM motor is still rotating, the PM motor generates an inductive voltage, thus applying voltage to the U/V/W three-phase wiring. Touching exposed conductive parts may cause electric shock.

### 6.2 Connecting

Note that the device to be used between the CPU board and the PC differs between writing and operating. Wiring methods for (1) writing and (2) motor operation are described below.

#### (1) For writing

CPU board includes the circuit of JLOB, therefore USB cable can be connected directly, and the program can download without another environment. After download, please connect out the cable.




Figure 6-1 RA6T2 CPU board USB connector for writing




Figure 6-2 RA6T3 CPU board USB connector for writing




Figure 6-3 RA4T1 CPU board USB connector for writing



Figure 6-4 RA8T1 CPU board USB connector for writing



Figure 6-5 RA8T2 CPU board USB connector for writing

(2) For motor operation

Connect to the PC using MC-COM(RTK0EMXC90Z00000BJ) as shown in Figure 6-6. The CPU board is connected to the PC via UART and can be operated from the PC using a COM port. RMW can be used to operate the motor. MC-COM provides electrical isolation between the inverter and the PC and can be used safely even in high-voltage environments.




Figure 6-6 Example of connection at investigation

(3) Confirmation of jumper

Please confirm the jumper settings as shown below. After you used the environment for other type control, jumper position is different from below condition.

- Inverter board

| Number of jumper | Connection  |
|------------------|-------------|
| JP8              | Connect 1-2 |
| JP11             | Connect 1-2 |

- RA6T2 board

| Number of jumper | Connection  |
|------------------|-------------|
| JP4              | Connect 1-2 |
| JP5              | Connect 1-2 |

- RA6T3/RA4T1 board

| Number of jumper | Connection  |
|------------------|-------------|
| JP2              | Connect 1-2 |
| JP3              | Connect 1-2 |
| JP4              | Connect 1-2 |

- RA8T1/RA8T2 board

There is no change of jumper settings with other sample programs. Therefore, please use as default.

### 6.3 Writing the sample program

After you have downloaded the sample program from our website, with e<sup>2</sup> studio you can write it to the MCU on the CPU board.

#### 6.3.1 Install e<sup>2</sup> studio

Please download e<sup>2</sup> studio which supports FSP configurator from our below WEB site, and install to your PC.

<https://www.renesas.com/en/software-tool/flexible-software-package-fsp>

#### 6.3.2 Import a project

1. Left click "File" TAB.




Figure 6-7 Selection of the target project (1)

2. Pull down menu is displayed. Then, select “Import” and left click.




Figure 6-8 Selection of the target project (2)

3. Import window opens. Then, select “Existing project into Workspace” and left click.




Figure 6-9 Selection of the target project (3)

4. “Import” window opens. Then, left click “Browse”.




Figure 6-10 Selection of the target project (4)

5. Folder selection window opens. Then select the target folder and left click “Select Folder”.




Figure 6-11 Selection of the target project (5)

6. When the target project is imported correctly, the display became like below. After confirmation, left click "Finish".




Figure 6-12 Selection of the target project (6)

7. Confirm the target project is imported correctly into e<sup>2</sup> studio.




Figure 6-13 Confirmation of import the target project

### 6.3.3 Build the target project

1. Right click the imported target project in e<sup>2</sup> studio window.




Figure 6-14 Selection of the target project

2. Pulldown menu appears. Then, left click "Build Project".




Figure 6-15 Pulldown menu

3. Target build is performed, and build process are displayed in console window. Confirm the finish of build with no error.




Figure 6-16 Confirmation of finish of build

#### 6.3.4 Connection between PC and the target CPU board via an USB cable

Please connect PC and CPU board via an USB cable like below.

(In below figure, target board is RA6T2.)




Figure 6-17 Confirmation between PC and CPU board (RA6T2)

### 6.3.5 Writing to the target board (with built program)

1. Select target project and right click.




Figure 6-18 Selection of target project

2. Pull down menu display. Put mouse cursor on “Debug As”, after that new list window appears. Select “Renesas GDB Hardware Debugging” and left click.




Figure 6-19 Selection of debug method

3. If the connection is correct and program is downloaded successfully, the display changes to “Debug” mode like below.




Figure 6-20 “Debug” mode

4. Left click “■” in debug mode to disconnect from target board. After that disconnect USB cable. All process is finished.




Figure 6-21 Disconnect from target board

## 6.4 Introducing RMW

Renesas Motor Workbench, a motor control development support tool, is used as an user interface (for issuing the rotation start/stop command, rotation speed command, and other commands). Renesas Motor Workbench (RMW) can be downloaded from our website.

<https://www.renesas.com/en/software-tool/renesas-motor-workbench>




Figure 6-22 Window of Renesas Motor Workbench

## 6.5 Registering and updating the Map file

When a part of the sample program is changed by the user, the Map file including variables and other information needs to be registered and updated. If the software has not been changed, the Map file does not need to be registered or updated.




Figure 6-23 Map file registration setup window (upper) and confirmation window (lower) in RMW

## 6.6 Variables used for working with RMW

In this sample program, the motor can be controlled using RMW. Table 6-1 lists the data input variables that are used when the RMW UI is used. The values input to these variables are applied to the corresponding variables in the motor module and then used for controlling the motor if the value written to the com\_u1\_enable\_write variable is the same as the value of the g\_u1\_enable\_write variable. Note, however, that the variables indicated by an asterisk (\*) do not depend on the value of the com\_u1\_enable\_write variable.

Some parameters used for motor control can be changed while the motor is stopped. For details, see Table 9-8.

Note that the variable name prefix (for example, u1 and f4) is an abbreviation of the variable type. RMW recognizes the variable name prefix, automatically selects the type, and displays the numeric value inside the variable in the Control Window.

**Table 6-1 List of main input variables for Analyzer functions**

| Analyzer function input variable name | Type    | Description   |
|---------------------------------------|---------|---|
| com_u1_mode_system (*)                | uint8_t | Managing the state<br>0: Stop mode<br>1: Run mode<br>3: Reset   |
| com_f4_ref_speed_rpm (*)              | float   | Speed command value (mechanical) [rpm]  |
| com_u1_enable_write                   | uint8_t | Whether to enable rewrite of variables for user entry.<br>The input data is applied if the values of this and g_u1_enable_write variables are the same. |

Table 6-2 lists main variables that are often observed when driving under speed control is evaluated. Use this table for reference when the waveform is to be displayed, or the values of variables are to be loaded with an Analyzer function.

**Table 6-2 List of main variables for hall 120-degree conducting control**

| Hall 120-degree conducting control variable name | Type    | Substance                           |
|--|---------|-------------------------------------|
| g_f4_iu_offset_monitor                           | float   | U phase offset [A]                  |
| g_f4_iw_offset_monitor                           | float   | W phase offset [A]                  |
| g_f4_iu_ad_monitor                               | float   | U phase measured current[A]         |
| g_f4_iw_ad_monitor                               | float   | W phase measured current[A]         |
| g_f4_vdc_ad_monitor                              | float   | Measured inverter bus voltage [V]   |
| g_f4_speed_rad_monitor                           | float   | Rotation speed (electrical) [rad/s] |
| g_f4_speed_rpm_monitor                           | float   | Rotation speed (mechanical) [rpm]   |
| g_f4_speed_ref_monitor                           | float   | Speed reference (electrical)[rad/s] |
| g_f4_v_ref_monitor                               | float   | Voltage reference [V]               |
| g_u1_direction_monitor                           | uint8_t | Rotation direction                  |

## 6.7 Controlling the motor

The following shows an example of using the Analyzer function of RMW to perform operations on the motor. The operations are performed from the Control Window on RMW. For details about the Control Window, see the "Renesas Motor Workbench User's Manual".

### a) Start driving of the motor

The motor can be rotated by performing the following steps:

- (1) Confirm that the check boxes in the [W?] column are selected on the "com\_u1\_mode\_system" and "com\_f4\_ref\_speed\_rpm" rows.
- (2) On the "com\_f4\_ref\_speed\_rpm" row, in the [Write] column, enter the command rotation speed.
- (3) Click the [Write] button (At this time, the com\_u1\_mode\_system field remains at "0").
- (4) Click the [Read] button. Confirm that the boxes in the [Read] column on the "com\_f4\_ref\_speed\_rpm" rows.
- (5) On the "com\_u1\_mode\_system" row, in the [Write] column, enter "1".
- (6) Click the [Write] button.




Figure 6-24 Procedure for driving of the motor

b) Stop the motor

- (1) On the "com\_u1\_mode\_system" row, in the [Write] column, enter "0".
- (2) Click the [Write] button.
- (3) Confirm that the motor has stopped.




Figure 6-25 Procedure for stopping the motor

c) What to do in case of motor stop (due to an error)

- (1) On the "com\_u1\_mode\_system" row, in the [Write] column, enter "3".
- (2) Click the [Write] button.




Figure 6-26 Procedure for handling an error

**Table 6-3 Error status description**

| Value  | Error Description  | Assigned macro name           |
|--------|--|-------------------------------|
| 0x0000 | No error   | MOTOR_ERROR_NONE              |
| 0x0001 | Hardware overcurrent error   | MOTOR_ERROR_OVER_CURRENT_HW   |
| 0x0002 | Overvoltage error  | MOTOR_ERROR_OVER_VOLTAGE      |
| 0x0004 | Overspeed error  | MOTOR_ERROR_OVER_SPEED        |
| 0x0008 | Hall signal timeout error  | MOTOR_ERROR_HALL_TIMEOUT      |
| 0x0010 | BEMF signal timeout error<br>(Not happen in 120-degree hall)             | MOTOR_ERROR_BEMF_TIMEOUT      |
| 0x0020 | Unused   | MOTOR_ERROR_HALL_PATTERN      |
| 0x0040 | Hall signal pattern error  | MOTOR_ERROR_BEMF_PATTERN      |
| 0x0080 | Low-voltage error  | MOTOR_ERROR_LOW_VOLTAGE       |
| 0x0100 | Software overcurrent error   | MOTOR_ERROR_OVER_CURRENT_SW   |
| 0x0200 | Induction sensor error in calibration<br>(Not happen in 120-degree hall) | MOTOR_ERROR_INDUCTION_CORRECT |
| 0xFFFF | Undefined error  | MOTOR_ERROR_UNKNOWN           |

## 6.8 Stopping and shutting down the motor

To stop the operating motor, follow the procedure below. In an emergency, prioritize the step (2) and stop supplying 24 VDC.

- (1) Perform the procedure for stopping the motor described in 6.7b).
- (2) After confirming that the motor stops, operate the regulated DC power supply to stop supplying 24 VDC.

## 7. Motor control algorithm

### 7.1 Overview

This section describes the motor control algorithm of this sample program. Table 7-1 shows the motor control functions.

**Table 7-1 Motor control functions of this sample program**

| Function item                       | Function description                             |
|-------------------------------------|--|
| Control method                      | 120-degree conducting control using hall sensors |
| Pulse Width Modulation (PWM) method | First 60 degree chopping                         |
| Position and speed detection method | Detected with hall sensors                       |
| Control mode                        | Only speed control                               |

## 7.2 Detection of rotor angle with hall sensors

The Hall effect sensors are used to detect the position of the permanent magnet, and the signals from the Hall effect sensors are inputted to the microcontroller as position information.




Figure 7-1 Example of Hall effect sensors (HU, HV, HW) position and signals

As shown in Figure 7-1, the Hall effect sensors are allocated every 120 degrees and the respective Hall effect sensor signals are switched depending on change in magnetic poles of the permanent magnet. Combining these signals of three Hall effect sensors enables to obtain position information every 60 degrees (six patterns for one cycle).

At the switching timing of Hall effect sensor signals, the conduction patterns of each phase are changed as shown in Figure 7-2.





Figure 7-2 Relation between Hall effect sensor signals and conduction patterns

(Rotation direction: CW)

### 7.3 Speed control function

In this system, the motor rotation speed is calculated from a difference between the current timer value and the timer value  $2\pi$  [rad] before. The timer values are obtained from free run timer at every hall sensor interrupt. And values which are obtained last 6 times are used as period of  $2\pi$ .



**Figure 7-3 Method to calculate rotation speed**

Speed control in the software targeted by this application note is performed by PI control. Obtain the voltage command value by the following speed control PI control.

$$v^* = (K_{P\omega} + \frac{K_{I\omega}}{s})(\omega^* - \omega)$$

$v^*$ : Voltage command value,  $\omega^*$ : Speed command value,  $\omega$ : Rotation speed

$K_{P\omega}$ : Speed PI proportional gain,  $K_{I\omega}$ : Speed PI integral gain,  $s$ : Laplace operator

Please refer specialized books about detail of PI control.

## 7.4 Voltage control by PWM

PWM control is used for controlling output voltage. The PWM control is a control method that continuously adjusts the average voltage by varying the duty of pulse, as shown in.




Figure 7-4 PWM control

Here, modulation factor  $m$  is defined as follows.

$$m = \frac{V}{E}$$

$m$ : Modulation factor    $V$ : Command value voltage    $E$ : Inverter bus voltage

This modulation factor is reflected in the setting value of the register that determines the PWM duty.

In the target software of this application note, first-60-degree chopping is used to control the output voltage and speed. Figure 7-5 shows an example of motor control signal output waveforms at non-complimentary first 60-degree Chopping. Figure 7-6 shows an example of motor control signal output waveforms at Complimentary first 60-degree Chopping.




Figure 7-5 non-complimentary first 60-degree Chopping




Figure 7-6 Complimentary first 60-degree Chopping

## 7.5 Start-up method

In the case of 120-degree conducting control using hall sensors, the rotor position can be determined by hall sensors' signals. Therefore, the conduction pattern at start-up is also determined.

When the control is changed to PI control, at least the motor needs to rotate one time (refer to 7.3). At start-up the motor is controlled in open loop with a constant voltage until the motor rotate one time.

Figure 7-7 shows the start-up method in this sample software. In "MOTOR\_120\_CONTROL\_RUN\_MODE\_BOOT", open loop with a constant voltage.




Figure 7-7 Start-up method (example)

## 8. Hardware specifications

### 8.1 User interface

User interface in board circuit is listed below Table 8-1.

**Table 8-1 User interface in board circuit**

| Item           | Interface               | Function  |
|----------------|-------------------------|---|
| Rotation speed | Variable resister (VR1) | Input speed reference   |
| START/STOP     | Toggle switch (SW1)     | Start/Stop motor rotation   |
| ERROR RESET    | Push switch (SW2)       | Reset from error state.   |
| LED1           | Orange LED (LED1)       | <ul style="list-style-type: none"> <li>• Motor driven : lighten</li> <li>• Motor stop : lights out</li> </ul> |
| LED2           | Orange LED (LED2)       | <ul style="list-style-type: none"> <li>• Error happen : lighten</li> <li>• No error : lights out</li> </ul>   |
| LED3           | Orange LED (LED3)       | No use  |
| RESET          | Push switch (RESET1)    | System reset  |

Pin interface of this sample software is listed below Table 8-2 and Table 8-3.

**Table 8-2 Pin interface [1/2]**

| Function                                | RA6T2   | RA6T3           | RA4T1           |
|---|---|-----------------|-----------------|
| Measure inverter bus voltage            | Ver.1: PA06 / AN006<br>Ver.2: PA07 / AN007    | P004 / AN004    | P004 / AN004    |
| Input speed reference (VR1)             | Ver.1: PB00 / AN008<br>Ver.2: P000 / AN016    | P005 / AN005    | P005 / AN005    |
| START/STOP Toggle switch (SW1)          | PD04  | P304            | P304            |
| Error reset push switch (SW2)           | PD07  | P200            | P200            |
| LED1 Light control                      | PD01  | P113            | P113            |
| LED2 Light control                      | PD02  | P106            | P106            |
| Measure current of U-phase              | PA04 / AN004                                  | P000 / AN000    | P000 / AN000    |
| Measure current of V-phase              | PA02 / AN002                                  | P001 / AN001    | P001 / AN001    |
| Measure current of W-phase              | PA00 / AN000                                  | P002 / AN002    | P002 / AN002    |
| PWM Output (Up)                         | PB04 / GTIOC4A                                | P409 / GTIOC1A  | P409 / GTIOC1A  |
| PWM Output (Vp)                         | PB06 / GTIOC5A                                | P103 / GTIOC2A  | P103 / GTIOC2A  |
| PWM Output (Wp)                         | PB08 / GTIOC6A                                | P111 / GTIOC3A  | P111 / GTIOC3A  |
| PWM Output (Un)                         | PB05 / GTIOC4B                                | P408 / GTIOC1B  | P408 / GTIOC1B  |
| PWM Output (Vn)                         | PB07 / GTIOC5B                                | P102 / GTIOC2B  | P102 / GTIOC2B  |
| PWM Output (Wn)                         | PB09 / GTIOC6B                                | P112 / GTIOC3B  | P112 / GTIOC3B  |
| Hall sensor input (HU)                  | Ver.1: PC04 / IRQ10<br>Ver.2: PB02 / IRQ15-DS | P008 / IRQ12-DS | P008 / IRQ12-DS |
| Hall sensor input (HV)                  | Ver.1: PC05 / IRQ11<br>Ver.2: PC00 / IRQ11-DS | P006 / IRQ11-DS | P006 / IRQ11-DS |
| Hall sensor input (HW)                  | Ver.1: PB01 / IRQ1<br>Ver.2: PB10 / IRQ10-DS  | P015 / IRQ13    | P015 / IRQ13    |
| Emergency PWM stop input at overcurrent | PC13 / GTETRGD                                | P104 / GTETRGB  | P104 / GTETRGB  |

**Table 8-3 Pin interface [2/2]**

| Function                                | RA8T1          | RA8T2          |
|---|----------------|----------------|
| Measure inverter bus voltage            | P008 / AN008   | P007 / AN007   |
| Input speed reference (VR1)             | P014 / AN007   | P015 / AN015   |
| START/STOP Toggle switch (SW1)          | PA15           | PA00           |
| Error reset push switch (SW2)           | PA13           | PA07           |
| LED1 Light control                      | PA12           | P614           |
| LED2 Light control                      | PA14           | PA15           |
| Measure current of U-phase              | P004 / AN000   | P006 / AN006   |
| Measure current of V-phase              | P005 / AN001   | P008 / AN008   |
| Measure current of W-phase              | P006 / AN002   | P010 / AN010   |
| PWM Output (Up)                         | P115 / GTIOC5A | P605 / GTIOC8A |
| PWM Output (Vp)                         | P113 / GTIOC2A | P603 / GTIOC7A |
| PWM Output (Wp)                         | P300 / GTIOC3A | P612 / GTIOC9A |
| PWM Output (Un)                         | P609 / GTIOC5B | P604 / GTIOC8B |
| PWM Output (Vn)                         | P114 / GTIOC2B | P602 / GTIOC7B |
| PWM Output (Wn)                         | P112 / GTIOC3B | P613 / GTIOC9B |
| Hall sensor input (HU)                  | P907 / IRQ10   | P907 / IRQ10   |
| Hall sensor input (HV)                  | P905 / IRQ8    | P905 / IRQ8    |
| Hall sensor input (HW)                  | P906 / IRQ9    | P906 / IRQ9    |
| Emergency PWM stop input at overcurrent | P613 / GTETRGA | P112 / GTETRGA |

## 8.2 Peripheral functions

Peripheral functions which are used in sample program are listed below Table 8-4 and Table 8-5.

**Table 8-4 Peripheral functions [1/2]**

| Peripheral    | Purpose                                   | RA6T2                         | RA6T3   | RA4T1   |
|---------------|---|-------------------------------|---------|---------|
| A/D converter | Measure current of U-phase                | AN004                         | AN000   | AN000   |
|               | Measure current of V-phase                | AN002                         | AN001   | AN001   |
|               | Measure current of W-phase                | AN000                         | AN002   | AN002   |
|               | Measure inverter bus voltage              | Ver.1: AN006<br>Ver.2: AN007  | AN004   | AN004   |
|               | Measure VR input                          | Ver.1: AN008<br>Ver.2: AN016  | AN005   | AN005   |
| AGTW          | Interval timer for speed control          | AGT0                          | AGT0    | AGT0    |
|               | Free run timer for measuring speed        | -                             | AGT1    | AGT1    |
| GPT           | PWM output of U-phase                     | CH4                           | CH1     | CH1     |
|               | PWM output of V-phase                     | CH5                           | CH2     | CH2     |
|               | PWM output of W-phase                     | CH6                           | CH3     | CH3     |
|               | Free run timer for measuring speed        | CH0                           | -       | -       |
| IRQ           | U-phase Hall sensor signal edge detection | Ver.1: CH10<br>Ver.2: CH15-DS | CH12-DS | CH12-DS |
|               | V-phase Hall sensor signal edge detection | Ver.1: CH11<br>Ver.2: CH11-DS | CH11-DS | CH11-DS |
|               | W-phase Hall sensor signal edge detection | Ver.1: CH1<br>Ver.2: CH10-DS  | CH13    | CH13    |
| POEG          | Emergency stop input of overcurrent       | Group D                       | Group B | Group B |

**Table 8-5 Peripheral functions [2/2]**

| Peripheral    | Purpose                                   | RA8T1   | RA8T2   |
|---------------|---|---------|---------|
| A/D converter | Measure current of U-phase                | AN000   | AN006   |
|               | Measure current of V-phase                | AN001   | AN008   |
|               | Measure current of W-phase                | AN002   | AN010   |
|               | Measure inverter bus voltage              | AN008   | AN007   |
|               | Measure VR input                          | AN007   | AN015   |
| AGTW          | Interval timer for speed control          | AGT0    | AGT0    |
|               | Free run timer for measuring speed        | -       | AGT1    |
| GPT           | PWM output of U-phase                     | CH5     | CH8     |
|               | PWM output of V-phase                     | CH2     | CH7     |
|               | PWM output of W-phase                     | CH3     | CH9     |
|               | Free run timer for measuring speed        | CH0     | -       |
| IRQ           | U-phase Hall sensor signal edge detection | CH10    | CH6     |
|               | V-phase Hall sensor signal edge detection | CH8     | CH4     |
|               | W-phase Hall sensor signal edge detection | CH9     | CH5     |
| POEG          | Emergency stop input of overcurrent       | Group A | Group A |

(1) A/D converter

A/D converter measure current of U-phase( $I_u$ ), current of V-phase( $I_v$ ), current of W-phase( $I_w$ ), inverter bus voltage( $V_{dc}$ ), and Speed reference input (VR) with "Single scan mode" (use hardware trigger).

A/D conversion is synchronized with underflow of GPT (trough of PWM). A/D conversion end interrupt is used as carrier period interrupt.

(2) General asynchronous timer (AGTW)

AGTW is used as cyclic interval timer to generate speed control period interrupt.

With RA6T3/RA4T1/RA8T2, AGTW is also used as a free run timer to calculate rotation speed.

(3) General purpose timer (GPT)

GPT outputs complementally PWM by its original mode with dead time.

With RA6T2/RA8T1, GPT is also used as a free run timer to calculate rotation speed.

(4) External interrupt (IRQ)

The hall sensors' signals are inputted for detection of rotor position.

Both edge mode is used.

When the interrupt occurs, following operations are performed.

- detection of rotor position
- rotation speed measurement
- conduction pattern change

(5) Port output enable for GPT (POEG)

When overcurrent is detected (low level input at GTETRGx pin), set PWM output ports are all high-impedance state.

## 9. Software specifications and configuration

### 9.1 Software specifications

The following shows the basic software specifications of this system.

**Table 9-1 Basic Specifications of 120-degree Hall Control Software**

| Item                             | Content   |                                      |
|----------------------------------|---|--------------------------------------|
| Control method                   | 120-degree conducting control   |                                      |
| Motor rotation start/stop        | SW1 input or input from 'Renesas Motor Workbench'   |                                      |
| Position detection method        | Position detection using hall sensors   |                                      |
| Input voltage                    | 24 [VDC]  |                                      |
| Main clock frequency             | RA6T2: 240 [MHz]<br>RA6T3: 200 [MHz]<br>RA4T1: 100 [MHz]<br>RA8T1: 480 [MHz]<br>RA8T2: 1 [GHz]  |                                      |
| Carrier frequency (PWM)          | 20 [kHz] (Carrier period: 50 [μs])  |                                      |
| Dead time                        | 2 [μs]  |                                      |
| Control period (speed)           | 1 [ms]  |                                      |
| Rotation speed control range     | CW: 550 [rpm] to 2400 [rpm]<br>CCW: 550 [rpm] to 2400 [rpm]   |                                      |
| Optimization setting of compiler | Optimization level  | Optimize more(-O2) (default setting) |
| Processing stop for protection   | <p>Disables the motor control signal output (six outputs), under any of the following conditions.</p> <ol style="list-style-type: none"> <li>1. Instantaneous value of current of any phase exceeds <math>3.54 (=1.67 \times \sqrt{2} \times 1.5)</math> [A] (monitored in current control period)</li> <li>2. Inverter bus voltage exceeds 60 [V] (monitored in current control period)</li> <li>3. Inverter bus voltage is less than 8 [V] (monitored in current control period)</li> <li>4. Rotation speed exceeds 4500 [rpm] (monitored in current control period)</li> </ol> <p>When an external over current signal is detected (when a low level is detected), the PWM output ports are set to high impedance state.</p> |                                      |

## 9.2 Overall configuration of the software

The overall configuration of the software is shown below.





Figure 9-1 Module Configuration

### 9.3 Explanation about interrupt

In the sample program of this document, main processes are performed at speed control period interrupt and carrier period interrupt. UI functions as interface layer are performed in main routine. POEG hardware interrupt is used as emergency stop at detection of overcurrent by hardware.

**Table 9-2 Interrupt priority**

| Interrupt level | Priority  | function  |
|-----------------|---|---|
| 15              | Min<br> |   |
| 14              |   |   |
| 13              |   |   |
| 12              |   |   |
| 11              |   |   |
| 10              |   | AGT0 INT<br>Speed control period interrupt  |
| 9               |   |   |
| 8               |   |   |
| 7               |   |   |
| 6               |   |   |
| 5               |   | ADC0 ADI0(RA6T2, RA8T2)<br>ADC0 SCAN END(RA6T3, RA4T1, RA8T1)<br>Carrier period interrupt (A/D conversion end interrupt)  |
| 4               |   |   |
| 3               |   | ICU IRQ11, ICU IRQ10, ICU IRQ1 (RA6T2)<br>ICU IRQ12, ICU IRQ11, ICU IRQ13 (RA6T3, RA4T1)<br>ICU IRQ10, ICU IRQ8, ICU IRQ9 (RA8T1, RA8T2)<br>Hall signal interrupt |
| 2               |   |   |
| 1               |   |   |
| 0               |   | POEG3 EVENT(RA6T2) POEG1 EVENT(RA6T3, RA4T1)<br>POEG0 EVENT(RA8T1, RA8T2)<br>Over current detection interrupt   |

## 9.4 File and folder configuration

The lists of folder and file configuration of the sample program are shown below.

**Table 9-3 File and folder configuration [1/2]**

| Folder            | Subfolder | File                                 | Remarks   |
|-------------------|-----------|--------------------------------------|---|
| ra_cfg            |           |                                      | Generated config header                             |
| ra_gen            |           |                                      | Generated register setting, main function etc.      |
| ra                | arm       |                                      | CMSIS source code                                   |
|                   | board     |                                      | Function definition for board (bsp)                 |
| fsp/inc/api       |           | bsp_api.h                            | BSP API definition                                  |
|                   |           | fsp_common_api.h                     | Common API definition                               |
|                   |           | r_adc_api.h                          | AD API definition                                   |
|                   |           | r_elc_api.h (RA6T3, RA4T1, RA8T1)    | ELC API definition                                  |
|                   |           | r_external_irq_api.h                 | External IRQ API definition                         |
|                   |           | r_ioport_api.h                       | I/O API definition                                  |
|                   |           | r_poeg_api.h                         | POEG API definition                                 |
|                   |           | r_three_phase_api.h                  | 3phase PWM API definition                           |
|                   |           | r_timer_api.h                        | Timer API definition                                |
|                   |           | r_transfer_api.h                     | Transfer API definition                             |
|                   |           | rm_motor_120_control_api.h           | 120-degree conducting control API definition        |
|                   |           | rm_motor_120_driver_api.h            | 120-degree conducting control driver API definition |
|                   |           | rm_motor_angle_api.h                 | Angle detection API definition                      |
|                   |           | rm_motor_api.h                       | Motor control API definition                        |
|                   |           | rm_motor_current_api.h               | Current control API definition                      |
|                   |           | rm_motor_120_driver_api.h            | Motor driver API definition                         |
|                   |           | rm_motor_position_api.h              | Position control API definition                     |
|                   |           | rm_motor_speed_api.h                 | Speed control API definition                        |
| fsp/inc/instances |           | r_adc_b.h(RA6T2, RA8T2)              | Function definition for ADC                         |
|                   |           | r_adc.h(RA6T3, RA4T1 and RA8T1)      |   |
|                   |           | r_agt.h                              | Function definition for AGT                         |
|                   |           | r_elc.h(Only RA6T3, RA4T1 and RA8T1) | Function definition for ELC                         |
|                   |           | r_gpt.h                              | Function definition for GPT                         |
|                   |           | r_gpt_three_phase.h                  | Function definition for 3 Phase PWM                 |
|                   |           | r_icu.h                              | Function definition for external IRQ                |
|                   |           | r_ioport.h                           | Function definition for I/O                         |
|                   |           | r_poeg.h                             | Function definition for POEG                        |
|                   |           | rm_motor_120_control_hall.h          | Function definition for 120-degree hall control     |
|                   |           | rm_motor_120_degree.h                | Function definition for 120-degree motor            |
|                   |           | rm_motor_120_driver.h                | Function definition for 120-degree motor driver     |

**Table 9-4 File and folder configuration [2/2]**

| Folder  | Subfolder        | File  | Remarks                                      |
|---------|------------------|---|--|
| fsp/src | fsp/src          | bsp   | BSP driver folder                            |
|         |                  | r_adc_b/r_adc_b.c(RA6T2, RA8T2)<br>r_adc/r_adc.c(RA6T3, RA4T1 and RA8T1)  | ADC driver                                   |
|         |                  | r_agt/r_agt.c   | AGT driver                                   |
|         |                  | r_elc/r_elc.c(Only RA6T3, RA4T1 and RA8T1)                                | ELC driver                                   |
|         |                  | r_gpt/r_gpt.c   | GPT driver                                   |
|         |                  | r_gpt_three_phase/ r_gpt_three_phase.c                                    | 3 phase PWM driver                           |
|         |                  | r_icu/r_icu.c   | External IRQ driver                          |
|         |                  | r_ioport/r_ioport.c   | I/O driver                                   |
|         |                  | r_poeg/r_poeg.c   | POEG driver                                  |
|         |                  | rm_motor_120_control_hall/rm_motor_120_contr<br>ol_hall.c                 | 120-degree hall control driver               |
|         |                  | rm_motor_120_degree/rm_motor_120_degree.c                                 | 120-degree driver                            |
|         |                  | rm_motor_120_driver/rm_motor_120_driver.c                                 | 120-degree motor driver                      |
| src     | application/main | mtr_main.h , mtr_main.c   | User main function                           |
|         |                  | r_mtr_control_parameter.h   | Control parameters definition                |
|         |                  | r_mtr_motor_parameter.h   | Motor parameters definition                  |
|         |                  | r_mtr_rmw_display_cfg.h   | Display configuration for RMW                |
|         | application/rmw  | r_mtr_rmw.h , r_mtr_rmw.c   | Function definition for Analyzer<br>UI       |
|         |                  | ICS2_RA6T2.h , ICS2_RA6T3.h , ICS2_RA4T1.h<br>ICS2_RA8T1.h , ICS2_RA8T2.h | Function definition for RMW<br>communication |
|         |                  | ICS2_RA6T2.o , ICS2_RA6T3.o , ICS2_RA4T1.o<br>ICS2_RA8T1.o , ICS2_RA8T2.o | Communication library for GUI<br>tool        |

FSP can be used to generate peripheral drivers easily.

FSP saves the settings information about the microcontrollers, peripheral functions, pin functions, and other items that are used for the project in a Configuration Settings File (configuration.xml), and references the information saved in the file. Settings of configuration can be changed with an operation in e<sup>2</sup> studio.

Below folders are also generated automatically by FSP at structured a program project.

- **ra**

Information about selected target board, header and code files of selected FSP modules are installed below this folder.

If you want to change code for adding functions, maintain the header files of modules and C code files under ra/fsp/inc and ra/fsp/src.

- **ra\_cfg**

Settings (as like "compile option") about selected functions of FSP modules are registered below this folder. Do not edit. These settings are able to be changed only by FSP operation.

- **ra\_gen**

Files which include variables, and these initial values which are generated with configuration settings(Pins, interrupts, property of each module and so on), set by FSP operation, are registered below this folder. These files are always generated at program build. Therefore, it is no need to modify directly.

## 9.5 Application layer

The application layer is used for selecting the user interface (UI), setting command values for controlling motor modules that use RMW, and updating parameters for control modules.

### 9.5.1 Functions

Table 9-5 lists the functions that are configured in the application layer.

**Table 9-5 Functions available in the application layer**

| Functions          | Description   |
|--------------------|---|
| Main processing    | Enables or disables each user command in the system.          |
| UI processing      | Selects of Board UI or RMW UI, and manages these.             |
| Manager processing | Manages motor start/stop. Reads speed reference and reflects. |
| RMW UI processing  | Acquires and sets parameters (including command values).      |

### 9.5.2 Configurations

Application layer is a user interface layer of motor control, which uses generated FSP modules (Speed, Current and so on). Therefore, Application layer program of this sample program is implemented only as a sample. Configurations of this application layer are implemented in "mtr\_main.h" file as MACRO definitions.

Table 9-6 shows the configurations used in the application layer.

**Table 9-6 List of configurations**

| File name  | Macro name        | Description   |
|------------|-------------------|---|
| mtr_main.h | CHATTERING_CNT    | Chattering counts for switch read.  |
|            | MTR_MAX_SPEED_RPM | Maximum limit of speed reference<br>If you set large value of this, speed reference is limited with this value. |
|            | CONFIG_DEFAULT_UI | Selection of Board UI/RMW UI at reset start.  |
|            | MTR_ADCH_VR1      | AD conversion channel of VR for speed reference.  |

**Table 9-7 List of initial values for configurations**

| Macro name        | Set value  |
|-------------------|--|
| CHATTERING_CNT    | 10   |
| MTR_MAX_SPEED_RPM | 2400   |
| CONFIG_DEFAULT_UI | BOARD_UI   |
| MTR_ADCH_VR1      | RA6T2 Ver.1 : 8<br>RA6T2 Ver.2 : 16<br>RA6T3, RA4T1 : 5<br>RA8T1 : 7<br>RA8T2 : 15 |

### 9.5.3 Structure and variable information

Table 9-8 lists the variables that can be used by users in the application layer.

The variables which are listed in Table 9-8 can be changed by users.

When you change these values by RMW, these are reflected to variables listed in Table 9-9. The application layer reflects these settings with each module parameter update process.

**Table 9-8 List of variables**

| Variable                   | Description  |
|----------------------------|--|
| g_u1_trig_enable_write     | An internal flag displays enable of value update   |
| com_u1_mode_system         | Change system mode<br>0: Stop motor rotation<br>1: Start motor rotation<br>3: Reset errors   |
| g_u1_mode_system           | System mode<br>0: Stop motor rotation<br>1: Start motor rotation<br>2: Error   |
| com_u1_enable_write        | A flag displays user command for value update<br>(When this variable is set same value with<br>“g_u1_enable_write”, set values are reflected to each<br>variable.) |
| g_u1_enable_write          | A flag displays enable of value update   |
| com_f4_ref_speed_rpm       | Speed command value (mechanical) [rpm]   |
| com_f4_overcurrent_limit   | High current limit value [A]   |
| com_f4_overvoltage_limit   | High voltage limit value [V]   |
| com_f4_overspeed_limit_rpm | Speed limit value (mechanical) [rpm]   |
| com_f4_lowvoltage_limit    | Low voltage limit value [V]  |
| com_u4_timeout_cnt         | Timeout count limit  |
| com_f4_max_drive_v         | Maximum command voltage [V]  |
| com_f4_min_drive_v         | Minimum command voltage [V]  |
| com_f4_speed_lpf_k         | Speed LPF parameter  |
| com_f4_limit_speed_change  | Command speed changing limit (mechanical) [rpm]  |
| com_f4_start_refv          | Command voltage at startup   |
| com_f4_pi_ctrl_kp          | Speed PI proportional gain   |
| com_f4_pi_ctrl_ki          | Speed PI Integral gain   |
| com_f4_pi_ctrl_ilimit      | Voltage PI control output limit value [V]  |

**Table 9-9 List of variables of the structure for RMW to update parameters**

| Structure                             | Description   |
|---------------------------------------|---|
| g_user_motor_120_degree_extended_cfg  | Structure of configuration for parameters about interface module which can be changed by user               |
| g_user_motor_120_control_extended_cfg | Structure of configuration for parameters about 120-degree hall control module which can be changed by user |
| g_user_motor_120_driver_extended_cfg  | Structure of configuration for parameters about 120-degree motor driver module which can be changed by user |

#### 9.5.4 Macro definition

Macro definitions are listed below.

**Table 9-10 List of macros [1/2] (mtr\_main.h)**

| Macro Name        | RA6T2   | RA6T3   | RA4T1   |
|-------------------|---|---|---|
| SW_ON             | 0   | 0   | 0   |
| SW_OFF            | 1   | 1   | 1   |
| SW1_ON            | 1   | 1   | 1   |
| SW1_OFF           | 0   | 0   | 0   |
| SW2_ON            | 0   | 0   | 0   |
| SW2_OFF           | 1   | 1   | 1   |
| CHATTERING_CNT    | 10  | 10  | 10  |
| SPIKE_CNT         | 128   | 128   | 128   |
| SPIKE_OC_RATE     | 0.9F  | 0.9F  | 0.9F  |
| MTR_CW            | 0   | 0   | 0   |
| MTR_CCW           | 1   | 1   | 1   |
| MTR_LED_ON        | BSP_IO_LEVEL_LOW  | BSP_IO_LEVEL_LOW  | BSP_IO_LEVEL_LOW  |
| MTR_LED_OFF       | BSP_IO_LEVEL_HIGH   | BSP_IO_LEVEL_HIGH   | BSP_IO_LEVEL_HIGH   |
| ICS_UI            | 0   | 0   | 0   |
| BOARD_UI          | 1   | 1   | 1   |
| LOOP_SPEED        | 0   | 0   | 0   |
| LOOP_POSITION     | 1   | 1   | 1   |
| MTR_MAX_SPEED_RPM | 2400  | 2400  | 2400  |
| STOP_RPM          | 400   | 400   | 400   |
| MTR_AD12BIT_DATA  | 4095.0f   | 4095.0f   | 4095.0f   |
| VR1_SCALING       | (MTR_MAX_SPEED_R<br>PM + 100) /<br>(MTR_AD12BIT_DATA<br>* 0.5f) | (MTR_MAX_SPEED_R<br>PM + 100) /<br>(MTR_AD12BIT_DATA<br>* 0.5f) | (MTR_MAX_SPEED_R<br>PM + 100) /<br>(MTR_AD12BIT_DATA<br>* 0.5f) |
| ADJUST_OFFSET     | 0x7FF   | 0x7FF   | 0x7FF   |
| MTR_FLG_CLR       | 0   | 0   | 0   |
| MTR_FLG_SET       | 1   | 1   | 1   |
| CONFIG_DEFAULT_UI | BOARD_UI  | BOARD_UI  | BOARD_UI  |
| CONFIG_LOOP_MODE  | -   | -   | -   |
| MTR_ADCH_VR1      | 8   | 5   | 5   |
| MTR_PORT_SW1      | BSP_IO_PORT_13_PI<br>N_04                                       | BSP_IO_PORT_03_PI<br>N_04                                       | BSP_IO_PORT_03_PI<br>N_04                                       |
| MTR_PORT_SW2      | BSP_IO_PORT_13_PI<br>N_07                                       | BSP_IO_PORT_02_PI<br>N_00                                       | BSP_IO_PORT_02_PI<br>N_00                                       |
| MTR_PORT_LED1     | BSP_IO_PORT_13_PI<br>N_01                                       | BSP_IO_PORT_01_PI<br>N_13                                       | BSP_IO_PORT_01_PI<br>N_13                                       |
| MTR_PORT_LED2     | BSP_IO_PORT_13_PI<br>N_02                                       | BSP_IO_PORT_01_PI<br>N_06                                       | BSP_IO_PORT_01_PI<br>N_06                                       |
| MTR_PORT_LED3     | BSP_IO_PORT_13_PI<br>N_03                                       | -   | -   |

**Table 9-11 List of macros [2/2] (mtr\_main.h)**

| Macro Name        | RA8T1   | R8T2  |
|-------------------|---|---|
| SW_ON             | 0   | 0   |
| SW_OFF            | 1   | 1   |
| SW1_ON            | 1   | 1   |
| SW1_OFF           | 0   | 0   |
| SW2_ON            | 0   | 0   |
| SW2_OFF           | 1   | 1   |
| CHATTERING_CNT    | 10  | 10  |
| SPIKE_CNT         | 128   | 128   |
| SPIKE_OC_RATE     | 0.9F  | 0.9F  |
| MTR_CW            | 0   | 0   |
| MTR_CCW           | 1   | 1   |
| MTR_LED_ON        | BSP_IO_LEVEL_LOW                                      | BSP_IO_LEVEL_LOW                                      |
| MTR_LED_OFF       | BSP_IO_LEVEL_HIGH                                     | BSP_IO_LEVEL_HIGH                                     |
| ICS_UI            | 0   | 0   |
| BOARD_UI          | 1   | 1   |
| LOOP_SPEED        | 0   | 0   |
| LOOP_POSITION     | 1   | 1   |
| MTR_MAX_SPEED_RPM | 2400  | 2400  |
| STOP_RPM          | 400   | 400   |
| MTR_AD12BIT_DATA  | 4095.0f   | 4095.0f   |
| VR1_SCALING       | (MTR_MAX_SPEED_RPM + 100) / (MTR_AD12BIT_DATA * 0.5f) | (MTR_MAX_SPEED_RPM + 100) / (MTR_AD12BIT_DATA * 0.5f) |
| ADJUST_OFFSET     | 0x7FF   | 0x7FF   |
| MTR_FLG_CLR       | 0   | 0   |
| MTR_FLG_SET       | 1   | 1   |
| CONFIG_DEFAULT_UI | BOARD_UI  | BOARD_UI  |
| CONFIG_LOOP_MODE  | -   | -   |
| MTR_ADCH_VR1      | 7   | 15  |
| MTR_PORT_SW1      | BSP_IO_PORT_10_PIN_15                                 | BSP_IO_PORT_10_PIN_00                                 |
| MTR_PORT_SW2      | BSP_IO_PORT_10_PIN_13                                 | BSP_IO_PORT_10_PIN_07                                 |
| MTR_PORT_LED1     | BSP_IO_PORT_10_PIN_12                                 | BSP_IO_PORT_06_PIN_14                                 |
| MTR_PORT_LED2     | BSP_IO_PORT_10_PIN_14                                 | BSP_IO_PORT_10_PIN_15                                 |
| MTR_PORT_LED3     | -   | BSP_IO_PORT_10_PIN_04                                 |

**Table 9-12 List of macros [1/2] (r\_mtr\_rmw.h)**

| Macro Name                  | RA6T2          | RA6T3          | RA4T1          |
|-----------------------------|----------------|----------------|----------------|
| USE_BUILT_IN                | 0              | 0              | 0              |
| MTR_ICS_DECIMATION          | 5              | 5              | 3              |
| ICS_BRR                     | 19             | 250            | 250            |
| ICS_INT_MODE                | 1              | 1              | 1              |
| MTR_SQRT_2                  | 1.41421356f    | 1.41421356f    | 1.41421356f    |
| MTR_TWO_PI                  | 6.28318531f    | 6.28318531f    | 6.28318531f    |
| MTR_RAD_RPM                 | 60/MTR_TWO_PI  | 60/MTR_TWO_PI  | 60/MTR_TWO_PI  |
| MTR_RAD_DEGREE              | 360/MTR_TWO_PI | 360/MTR_TWO_PI | 360/MTR_TWO_PI |
| MTR_OVERCURRENT_MARGIN_MULT | 1.5f           | 1.5f           | 1.5f           |

**Table 9-13 List of macros [2/2] (r\_mtr\_rmw.h)**

| Macro Name                  | RA8T1          | RA8T2          |
|-----------------------------|----------------|----------------|
| USE_BUILT_IN                | 0              | 0              |
| MTR_ICS_DECIMATION          | 5              | 5              |
| ICS_BRR                     | 19             | 19             |
| ICS_INT_MODE                | 1              | 1              |
| MTR_SQRT_2                  | 1.41421356f    | 1.41421356f    |
| MTR_TWO_PI                  | 6.28318531f    | 6.28318531f    |
| MTR_RAD_RPM                 | 60/MTR_TWO_PI  | 60/MTR_TWO_PI  |
| MTR_RAD_DEGREE              | 360/MTR_TWO_PI | 360/MTR_TWO_PI |
| MTR_OVERCURRENT_MARGIN_MULT | 1.5f           | 1.5f           |

## 9.6 Interface Module

The interface module manages motor rotation with specific control modules. This module controls data transfer between modules, total system mode of this project, and protection functions.

### 9.6.1 Functions

Table 9-14 lists the functions of interface module.

**Table 9-14 List of interface module functions**

| Functions                            | Description   |
|--------------------------------------|---|
| Mode management                      | Switches the operation mode of the system in response to the user command to control the motor.   |
| Protection function                  | Handles errors by using the system protection function.   |
| Speed information acquisition        | Acquires the speed information from 120-degree hall control module.                               |
| Control module command value setting | Set speed reference to 120-degree hall control module via API                                     |
| Interrupt processing                 | Perform user functions which are registered as a callback at each interrupts (speed and carrier). |

### 9.6.2 Module configuration diagram

Figure 9-2 shows the module configuration.




Figure 9-2 Module configuration diagram of interface module

### 9.6.3 State transition

Figure 9-3 is a state transition diagram of sample software. In the target software of this application note, the software state is managed by "SYSTEM MODE".




Figure 9-3 State Transition Diagram of Sample Software

#### (1). SYSTEM MODE

"SYSTEM MODE" indicates the operating states of the system. The state transits on occurrence of each event (EVENT). "SYSTEM MODE" has 3 states that are motor drive stop (STOP), motor drive (RUN), and abnormal condition (ERROR).

#### (2). EVENT

When "EVENT" occurs in each "SYSTEM MODE", "SYSTEM MODE" changes as shown the table in Figure 9-3, according to that "EVENT". The occurrence factors of each event are shown below.

Table 9-15 List of EVENT

| EVENT name | occurrence factor                |
|------------|----------------------------------|
| STOP       | by user operation                |
| RUN        | by user operation                |
| ERROR      | when the system detects an error |
| RESET      | by user operation                |

#### 9.6.4 Protection function

This control program provides the following error states and implements an emergency stop function in each error state. For details about the values that can be specified for the settings of the system protection function, see Table 9-16.

- Overcurrent error

Overcurrent errors can be detected on the hardware and in the software.

A high-impedance output is provided to the PWM output pin in response to an emergency stop signal (overcurrent detection) from the hardware. This function monitors U-, V-, and W-phases at the overcurrent monitoring interval. When this function detects an overcurrent (the status in which the current is above the overcurrent limit value), it brings the program to an emergency stop (software detection).

- Overvoltage error

This function monitors the inverter bus voltage at the overvoltage monitoring interval. When the function detects an overvoltage (that is, a voltage above the overvoltage limit value), it brings the program to an emergency stop. The overvoltage limit value is preset in consideration of conditions such as an error in the resistor value of the detection circuit.

- Low-voltage error

This function monitors the inverter bus voltage at the low-voltage monitoring interval. When the function detects a low voltage (that is, a voltage below the low-voltage limit value), it brings the program to an emergency stop. The low-voltage limit value is preset in consideration of conditions such as an error in the resistor value of the detection circuit.

- Rotation speed error

This function monitors the speed at the rotation speed monitoring interval. When the rotation speed exceeds the speed limit value, it brings the program to an emergency stop.

**Table 9-16 Operating conditions and setting values for the system protection functions**

| Category             | Item                                    | Value                        |
|----------------------|---|------------------------------|
| Overcurrent error    | Overcurrent limit value [A]             | 1.67                         |
|                      | Monitoring interval [ $\mu$ s]          | Carrier interrupt interval*1 |
| Overvoltage error    | Overvoltage limit value [V]             | 60                           |
|                      | Monitoring interval [ $\mu$ s]          | Carrier interrupt interval*1 |
| Low-voltage error    | Low-voltage limit value [V]             | 8                            |
|                      | Monitoring interval [ $\mu$ s]          | Carrier interrupt interval*1 |
| Rotation speed error | Speed limit value<br>(mechanical) [rpm] | 4500                         |
|                      | Monitoring interval [ $\mu$ s]          | Carrier interrupt interval*1 |

\*1 Refer to Table 9-1 Basic Specifications of 120-degree Hall Control Software.

### 9.6.5 API

Table 9-17 lists API functions of interface module.

**Table 9-17 List of API functions**

| API                                 | Description   |
|-------------------------------------|---|
| RM_MOTOR_120_DEGREE_Open            | Generates instances of this module and the modules to be used.      |
| RM_MOTOR_120_DEGREE_Close           | Close instances of this module and the modules to be used.          |
| RM_MOTOR_120_DEGREE_Run             | Run the motor.  |
| RM_MOTOR_120_DEGREE_Stop            | Stop the motor.   |
| RM_MOTOR_120_DEGREE_Reset           | Reset this module and the modules to be used.                       |
| RM_MOTOR_120_DEGREE_ErrorSet        | Set error state.  |
| RM_MOTOR_120_DEGREE_SpeedSet        | Set speed reference (mechanical) [rpm]                              |
| RM_MOTOR_120_DEGREE_StatusGet       | Get current state of the project.                                   |
| RM_MOTOR_120_DEGREE_AngleGet        | Get rotor angle [rad]<br>(Unsupported in 120-degree hall)           |
| RM_MOTOR_120_DEGREE_SpeedGet        | Get rotation speed (mechanical) [rpm]                               |
| RM_MOTOR_120_DEGREE_ErrorCheck      | Check error occurrence  |
| RM_MOTOR_120_DEGREE_PositionSet     | Set position reference [degree]<br>(Unsupported in 120-degree hall) |
| RM_MOTOR_120_DEGREE_WaitStopFlagGet | Get a flag of waiting motor stop                                    |
| RM_MOTOR_120_DEGREE_FunctionSelect  | Select to use servo function<br>(Unsupported in 120-degree hall)    |

### 9.6.6 Structure and variable information

The structures and variables for interface module are listed below.

**Table 9-18 List of structures and variable for interface module (rm\_motor\_api.h)**

| Structure             | Members                   | Description   |
|-----------------------|---------------------------|---|
| motor_callback_args_t | *p_context                | Address of context data for callback function                               |
|                       | event                     | Event data of callback  |
| motor_cfg_t           | *p_motor_speed_instance   | Address of speed control module instance (No use in 120-degree hall)        |
|                       | *p_motor_current_instance | Address of current control module instance (No use in 120-degree hall)      |
|                       | *p_callback               | Address of registered callback function                                     |
|                       | *p_context                | Address of context data for registered callback function                    |
|                       | *p_extend                 | Address of structure of extended configuration data to refer                |
| motor_api_t           | *open                     | Function address to open module   |
|                       | *close                    | Function address to close module  |
|                       | *run                      | Function address to activate module (start motor rotation)                  |
|                       | *stop                     | Function address to inactivate module (stop motor rotation)                 |
|                       | *reset                    | Function address to reset module  |
|                       | *errorSet                 | Function address to set error data  |
|                       | *speedSet                 | Function address to set speed (mechanical) [rpm] reference                  |
|                       | *positionSet              | Function address to set position reference (Unsupported in 120-degree hall) |
|                       | *statusGet                | Function address to get moving status                                       |
|                       | *angleGet                 | Function address to get rotor angle (Unsupported in 120-degree hall)        |
|                       | *speedGet                 | Function address to get rotation speed (mechanical) [rpm]                   |
|                       | *waitStopFlagGet          | Function address to get a flag for waiting "STOP"                           |
|                       | *errorCheck               | Function address to check error occurrence                                  |
|                       | *functionSelect           | Function address to select servo function (Unsupported in 120-degree hall)  |
| motor_instance_t      | *p_ctrl                   | Address of structure of variables to be used in the module                  |
|                       | *p_cfg                    | Address of structure of configuration data                                  |
|                       | *p_api                    | Address of structure of API functions                                       |

**Table 9-19 List of structures and variable for interface module (rm\_motor\_120-degree.h)**

| <b>Structure</b>                     | <b>Members</b>      | <b>Description</b>   |
|--------------------------------------|---------------------|--|
| motor_120_degree_statemachin<br>e_t  | status              | Moving status  |
|                                      | status_next         | Next moving status   |
|                                      | current_event       | Current happened event                                       |
|                                      | u2_error_status     | Error status   |
| motor_120_degree_extended_cf<br>g_t  | f_overcurrent_limit | Limit (threshold) of over current detection [A]              |
|                                      | f_overvoltage_limit | Limit (threshold) of over voltage detection [V]              |
|                                      | f_overspeed_limit   | Limit (threshold) of over speed detection (mechanical) [rpm] |
|                                      | f_lowvoltage_limit  | Limit (threshold) of low voltage detection [V]               |
| motor_120_degree_instance_ctr<br>l_t | open                | Module opened information                                    |
|                                      | u2_error_info       | Error status   |
|                                      | f_speed_rpm         | Rotation speed (mechanical) [rpm]                            |
|                                      | st_statem           | Structure of state machine                                   |
|                                      | *p_cfg              | Address of structure of configuration to refer               |

### 9.6.7 Macro and enumeration definition

The macros and enumerations for interface module are listed below.

**Table 9-20 List of macros for interface module**

| File name             | Name of MACRO   | Defined value | Description                     |
|-----------------------|---|---------------|---------------------------------|
| rm_motor_120_degree.c | MOTOR_120_DEGREE_OPEN                                 | 0x4D314C53L   | Module opened information       |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_SIZE_STATE             | 3             | Size of status of state machine |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_SIZE_EVENT             | 4             | Size of event of state machine  |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_ERROR_NONE             | 0x00          | No error happened               |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_ERROR_EVENT_OUTBOUND   | 0x01          | Error of outbound of event      |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_ERROR_STATE_OUTBOUND   | 0x02          | Error of outbound of status     |
|                       | MOTOR_120_DEGREE_STAT_EMACHINE_ERROR_ACTION_EXCEPTION | 0x04          | Error of exception about action |

Table 9-21 List of Enumeration type for interface module [1/2] (rm\_motor\_api.h)

| Enumeration type name  | Members                               | Defined value | Description  |
|------------------------|---------------------------------------|---------------|--|
| motor_error_t          | MOTOR_ERROR_NONE                      | 0x0000        | No error happened  |
|                        | MOTOR_ERROR_OVER_CURRENT_HW           | 0x0001        | Over current error detected by hardware  |
|                        | MOTOR_ERROR_OVER_VOLTAGE              | 0x0002        | Over voltage error   |
|                        | MOTOR_ERROR_OVER_SPEED                | 0x0004        | Over speed error   |
|                        | MOTOR_ERROR_HALL_TIM_EOUT             | 0x0008        | Timeout error of hall signal detection   |
|                        | MOTOR_ERROR_BEMF_TIM_EOUT             | 0x0010        | Timeout error of BEMF signal detection<br>(Not happen in 120-degree hall)            |
|                        | MOTOR_ERROR_HALL_PATERN               | 0x0020        | Unused   |
|                        | MOTOR_ERROR_BEMF_PATERN               | 0x0040        | Hall signal pattern error  |
|                        | MOTOR_ERROR_LOW_VOLTAGE               | 0x0080        | Low voltage error  |
|                        | MOTOR_ERROR_OVER_CURRENT_SW           | 0x0100        | Over current error detected by software  |
|                        | MOTOR_ERROR_INDUCTION_CORRECT         | 0x0200        | Induction calibration error<br>(Not happen in 120-degree hall)                       |
|                        | MOTOR_ERROR_UNKNOWN                   | 0xFFFF        | Unknown error  |
| motor_callback_event_t | MOTOR_CALLBACK_EVENT_SPEED_FORWARD    | 1             | Callback event before cyclic speed control process (Not happen in 120-degree hall)   |
|                        | MOTOR_CALLBACK_EVENT_SPEED_BACKWARD   | 2             | Callback event after cyclic speed control process (Not happen in 120-degree hall)    |
|                        | MOTOR_CALLBACK_EVENT_CURRENT_FORWARD  | 3             | Callback event before cyclic current control process (Not happen in 120-degree hall) |
|                        | MOTOR_CALLBACK_EVENT_CURRENT_BACKWARD | 4             | Callback event after cyclic current control process (Not happen in 120-degree hall)  |
|                        | MOTOR_CALLBACK_EVENT_ADC_FORWARD      | 5             | Callback event before A/D conversion end interrupt process                           |
|                        | MOTOR_CALLBACK_EVENT_ADC_BACKWARD     | 6             | Callback event after A/D conversion end interrupt process                            |
|                        | MOTOR_CALLBACK_EVENT_CYCLE_FORWARD    | 7             | Callback event before cyclic speed control process                                   |
|                        | MOTOR_CALLBACK_EVENT_CYCLE_BACKWARD   | 8             | Callback event after cyclic speed control process                                    |
| motor_wait_stop_flag_t | MOTOR_WAIT_STOP_FLAG_CLEAR            | 0             | Clear a flag for waiting stop  |
|                        | MOTOR_WAIT_STOP_FLAG_SET              | 1             | Set a flag for waiting stop  |

**Table 9-22 List of Enumeration type for interface module [2/2] (rm\_motor\_api.h)**

| Enumeration type name                               | Members                                 | Defined value | Description                                 |
|---|---|---------------|---|
| motor_function_select_t (No use in 120-degree hall) | MOTOR_FUNCTION_SELEC_T_NONE             | 0             | No servo function is selected               |
|   | MOTOR_FUNCTION_SELEC_T_INERTIA_ESTIMATE | 1             | Inertia estimation function is selected     |
|   | MOTOR_FUNCTION_SELEC_T_RETURN_ORIGIN    | 2             | Return origin position function is selected |

**Table 9-23 List of Enumeration type for interface module (rm\_motor\_120\_degree.h)**

| Enumeration type name          | Members                            | Defined value | Description              |
|--------------------------------|------------------------------------|---------------|--------------------------|
| motor_120_degree_ctrl_status_t | MOTOR_120_DEGREE_CTRL_STATUS_STOP  | 0             | Stop state               |
|                                | MOTOR_120_DEGREE_CTRL_STATUS_RUN   | 1             | Run (active) state       |
|                                | MOTOR_120_DEGREE_CTRL_STATUS_ERROR | 2             | Error state              |
| motor_120_degree_ctrl_event_t  | MOTOR_120_DEGREE_CTRL_EVENT_STOP   | 0             | Event to stop (inactive) |
|                                | MOTOR_120_DEGREE_CTRL_EVENT_RUN    | 1             | Event to run (active)    |
|                                | MOTOR_120_DEGREE_CTRL_EVENT_ERROR  | 2             | Event of error           |
|                                | MOTOR_120_DEGREE_CTRL_EVENT_RESET  | 3             | Event to reset           |

## 9.7 120-degree hall Control Module

120-degree hall control module calculates speed PI with speed reference which is set by user and rotation speed. And it outputs drive voltage reference to 120-degree motor driver module.

### 9.7.1 Functions


Functions of 120-degree hall control module are listed below.

**Table 9-24 Functions of 120-degree hall control module**

| Function                      | Description  |
|-------------------------------|--|
| 120-degree conducting control | Set 120-degree chipping pattern according to the Hall sensor signal. Chopping pattern is selected from non-complimentary 60 degree chopping or complimentary 60 degree chopping. |
| Detection of rotation speed   | Detect rotation speed with Hall sensor signal and free run timer counter.  |
| Speed PI control              | Calculate PWM duty with speed reference and estimated speed by PI control. Set the PWM duty to 120-degree motor driver module.   |

### 9.7.2 Module configuration diagram

Figure 9-4 shows the module configuration diagram.



**Figure 9-4 Module configuration diagram of 120-degree hall control module**

### 9.7.3 API

Table 9-25 lists API functions of 120-degree hall control module.

**Table 9-25 List of API functions of the 120-degree hall control module**

| API   | Description   |
|---|---|
| RM_MOTOR_120_CONTROL_HALL_Open                | Generates instances of 120-degree hall control module and the modules to be used. |
| RM_MOTOR_120_CONTROL_HALL_Close               | Close instances of 120-degree hall control module and the modules to be used.     |
| RM_MOTOR_120_CONTROL_HALL_Run                 | Start motor rotation.   |
| RM_MOTOR_120_CONTROL_HALL_Stop                | Stop motor rotation.  |
| RM_MOTOR_120_CONTROL_HALL_Reset               | Reset this module and the modules to be used.                                     |
| RM_MOTOR_120_CONTROL_HALL_SpeedSet            | Set speed (mechanical) [rpm] reference.   |
| RM_MOTOR_120_CONTROL_HALL_SpeedGet            | Get estimated rotation speed (mechanical) [rpm].                                  |
| RM_MOTOR_120_CONTROL_HALL_CurrentGet          | Get detected phase current, inverter bus voltage.                                 |
| RM_MOTOR_120_CONTROL_HALL_WaitStopFlagGet     | Get the flag to wait motor stop.  |
| RM_MOTOR_120_CONTROL_HALL_TimeoutErrorFlagGet | Get the flag of error occurrence about Hall time out.                             |
| RM_MOTOR_120_CONTROL_HALL_PatternErrorFlagGet | Get the flag of error occurrence about hall pattern                               |
| RM_MOTOR_120_CONTROL_HALL_VoltageRefGet       | Get voltage reference.  |
| RM_MOTOR_120_CONTROL_HALL_ParameterUpdate     | Update the configuration parameters of this module.                               |

#### 9.7.4 Structure and variable information

Structures and variables of 120-degree hall control module are listed below.

**Table 9-26 List of structures and variables of 120-degree control module [1/2]**  
(rm\_motor\_120\_control\_api.h)

| Structure                           | Members                | Description  |
|-------------------------------------|------------------------|--|
| motor_120_control_callback_args_t   | *p_context             | Address of context data for callback function      |
|                                     | event                  | Event data of callback                             |
| motor_120_control_motor_parameter_t | u4_motor_pp            | Pole pairs   |
|                                     | f4_motor_r             | Resistance [ohm]                                   |
|                                     | f4_motor_Id            | d-axis inductance [H]                              |
|                                     | f4_motor_Iq            | q-axis inductance [H]                              |
|                                     | f4_motor_m             | Magnetic flux [Wb]                                 |
|                                     | f4_motor_j             | Inertia [kgm^2]                                    |
| motor_120_control_cfg_t             | conduction_type        | Selection of chopping pattern                      |
|                                     | u4_timeout_cnt         | Time out counts to detect BEMF pattern             |
|                                     | f4_max_drive_v         | Maximum drive voltage [V]                          |
|                                     | f4_min_drive_v         | Minimum drive voltage [V]                          |
|                                     | u4_speed_pi_decimation | Decimation number of speed control                 |
|                                     | u4_free_run_timer_freq | Free run timer frequency for speed detection [MHz] |
|                                     | f4_speed_lpf_k         | Coefficient of speed LPF                           |
|                                     | f4_limit_speed_change  | Additional step of speed change (mechanical) [rpm] |
|                                     | f4_pi_ctrl_kp          | Proportional parameter of speed PI                 |
|                                     | f4_pi_ctrl_ki          | Integrated parameter of speed PI                   |
|                                     | f4_pi_ctrl_ilimit      | Limit of speed PI                                  |
|                                     | *p_callback            | Address of callback function                       |
|                                     | *p_context             | Address of context data for callback function      |
|                                     | *p_extend              | Address to refer extended configuration structure  |

**Table 9-27 List of structures and variables of 120-degree control module [2/2]**  
(rm\_motor\_120\_control\_api.h)

| Structure                    | Members              | Description  |
|------------------------------|----------------------|--|
| motor_120_control_api_t      | *open                | Function address to open module                                      |
|                              | *close               | Function address to close module                                     |
|                              | *run                 | Function address to start motor rotation                             |
|                              | *stop                | Function address to stop motor rotation                              |
|                              | *reset               | Function address to reset module                                     |
|                              | *speedSet            | Function address to set speed (mechanical) [rpm] reference           |
|                              | *speedGet            | Function address to get estimated speed (mechanical) [rpm]           |
|                              | *currentGet          | Function address to get phase current and inverter bus voltage       |
|                              | *waitStopFlagGet     | Function address to get the flag to wait motor stop                  |
|                              | *timeoutErrorFlagGet | Function address to get the flag of occurrence of time out error     |
|                              | *patternErrorFlagGet | Function address to get the flag of occurrence of BEMF pattern error |
|                              | *voltageRefGet       | Function address to get voltage reference                            |
| motor_120_control_instance_t | *p_ctrl              | Address of module variable structure                                 |
|                              | *p_cfg               | Address of module configuration structure                            |
|                              | *p_api               | Address of API function structure                                    |

**Table 9-28 List of structures and variables of 120-degree hall control module [1/2]**  
(rm\_motor\_120\_control\_hall.h)

| Structure                              | Members                        | Description   |
|--|--------------------------------|---|
| motor_120_control_hall_extended_cfg_t  | port_hall_sensor_u             | Port number of U phase hall signal                        |
|  | port_hall_sensor_v             | Port number of V phase hall signal                        |
|  | port_hall_sensor_w             | Port number of W phase hall signal                        |
|  | f4_start_refv                  | Voltage reference at start up [V]                         |
|  | u4_hall_wait_cnt               | Counts to judge motor rotate at start up                  |
|  | u4_stop_judge_time             | Time to judge motor stop (counts)                         |
|  | u4_min_speed_rpm               | Minimum rotation speed (mechanical) [rpm]                 |
|  | u4_hall_interrupt_mask_value   | Mask value to avoid error signal in hall signal (counts)  |
|  | *p_motor_120_driver_instance   | Address of 120-degree driver module instance              |
|  | *p_speed_cyclic_timer_instance | Address of timer instance for cyclic speed control        |
|  | *p_speed_calc_timer_instance   | Address of timer instance for free run                    |
|  | *p_u_hall_irq_instance         | Address of external interrupt module instance for U phase |
|  | *p_v_hall_irq_instance         | Address of external interrupt module instance for V phase |
|  | *p_w_hall_irq_instance         | Address of external interrupt module instance for W phase |
| motor_120_control_hall_instance_ctrl_t | open                           | Module opened information                                 |
|  | active                         | System state (active/inactive)                            |
|  | run_mode                       | Management of rotation mode                               |
|  | timeout_error_flag             | The flag for timeout error                                |
|  | pattern_error_flag             | The flag for pattern error                                |

**Table 9-29 List of structures and variables of 120-degree hall control module [2/2]**  
(rm\_motor\_120\_control\_hall.h)

| Structure                                  | Members               | Description   |
|--|-----------------------|---|
| motor_120_control_hall<br>_instance_ctrl_t | direction             | Rotation direction  |
|  | f4_speed_calc_base    | Base counts to calculate rotation speed                   |
|  | f_rpm2rad             | Translate for rpm=>rad/s                                  |
|  | f4_v_ref              | Voltage reference [V]                                     |
|  | f4_ref_speed_rad      | Speed reference (electrical) [rad/s]                      |
|  | f4_ref_speed_rad_ctrl | Internal speed reference (electrical) [rad/s]             |
|  | f4_speed_rad          | Rotation speed (electrical) [rad/s]                       |
|  | u4_cnt_speed_pi       | Counter for speed PI control                              |
|  | flag_wait_stop        | The flag to wait motor stop                               |
|  | u4_cnt_wait_stop      | Counter to wait motor stop                                |
|  | v_pattern             | Chopping pattern  |
|  | flag_speed_ref        | State of speed reference                                  |
|  | flag_voltage_ref      | State of voltage reference                                |
|  | u4_cnt_timeout        | Counter to judge timeout                                  |
|  | u4_hall_timer_cnt     | Free run counts at hall interrupt                         |
|  | u4_pre_hall_timer_cnt | Previous free run counts                                  |
|  | s4_timer_cnt_ave      | Free run counts for $2\pi$                                |
|  | u4_timer_cnt_buf      | Buffer of free run counts to calculate $2\pi$             |
|  | u4_timer_cnt_num      | Number to manage above buffer array                       |
|  | f4_pi_ctrl_err        | Error of speed PI control                                 |
|  | f4_pi_ctrl_refi       | Integral value of speed PI control                        |
|  | u4_hall_intr_cnt      | Counter of hall interrupt at startup                      |
|  | u4_adc_interrupt_cnt  | Counter of AD end interrupt to avoid error of hall signal |
|  | *p_cfg                | Address of structure of module configuration to refer     |
|  | timer_direction       | Timer direction of free run timer                         |
|  | hall_interrupt_args   | Arguments for hall interrupt callback                     |
|  | timer_args            | Arguments for timer interrupt callback                    |

### 9.7.5 Macro and enumeration definition

The macros and enumerations for 120-degree hall control module are listed below.

**Table 9-30 List of macros of 120-degree hall control module (rm\_motor\_120\_control.hall.c)**

| File name                   | Name of MACRO                           | Defined value   | Description                                      |
|-----------------------------|---|---|--|
| rm_motor_120_control.hall.c | MOTOR_120_CONTROL_H_ALL_OPEN            | ('1' << 24U)   ('2' << 16U)   ('H' << 8U)   ('L' << 0U) | Module opened information                        |
|                             | MOTOR_120_CONTROL_H_ALL_TWOPI           | 2.0F * 3.1415926535 F                                   | $2\pi$   |
|                             | MOTOR_120_CONTROL_H_ALL_TWOPI_DIV_60    | MOTOR_120_CONTROL_H_ALL_TWOPI / 60.0F                   | $2\pi/60$ (To use translation from rpm to rad/s) |
|                             | MOTOR_120_CONTROL_H_ALL_HZ_TRANS        | 1000U   | To use translation from kHz to Hz                |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_V_U  | 2   | Hall pattern V->U at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_W_U  | 3   | Hall pattern W->U at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_W_V  | 1   | Hall pattern W->V at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_U_V  | 5   | Hall pattern U->V at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_U_W  | 4   | Hall pattern U->W at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CW_V_W  | 6   | Hall pattern V->W at clockwise                   |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_V_U | 5   | Hall pattern V->U at counterclockwise            |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_V_W | 1   | Hall pattern W->U at counterclockwise            |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_U_W | 3   | Hall pattern W->V at counterclockwise            |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_U_V | 2   | Hall pattern U->V at counterclockwise            |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_W_V | 6   | Hall pattern U->W at counterclockwise            |
|                             | MOTOR_120_CONTROL_H_ALL_PATTERN_CCW_W_U | 4   | Hall pattern V->W at counterclockwise            |

**Table 9-31 List of Enumeration type for 120-degree control module (rm\_motor\_120\_control\_api.h)  
[1/2]**

| Enumeration type name                  | Members                                     | Defined value | Description   |
|--|---|---------------|---|
| motor_120_control_event_t              | MOTOR_120_CONTROL_EVENT_ADC_FORWARD         | 1             | Event before carrier interrupt process                |
|  | MOTOR_120_CONTROL_EVENT_ADC_BACKWARD        | 2             | Event after carrier interrupt process                 |
|  | MOTOR_120_CONTROL_EVENT_CYCLE_FORWARD       | 3             | Event before speed control process                    |
|  | MOTOR_120_CONTROL_EVENT_CYCLE_BACKWARD      | 4             | Event after speed control process                     |
| motor_120_conduction_type_t            | MOTOR_120_CONDUCTION_TYPE_FIRST60           | 0             | None-complementary 1 <sup>st</sup> 60 degree chopping |
|  | MOTOR_120_CONDUCTION_TYPE_COMPLEMENTARY     | 1             | Complementary 1 <sup>st</sup> 60 degree chopping      |
| motor_120_control_status_t             | MOTOR_120_CONTROL_STATUS_INACTIVE           | 0             | Inactive  |
|  | MOTOR_120_CONTROL_STATUS_ACTIVE             | 1             | Active  |
| motor_120_control_run_mode_t           | MOTOR_120_CONTROL_RUN_MODE_INIT             | 0             | Initialize state                                      |
|  | MOTOR_120_CONTROL_RUN_MODE_BOOT             | 1             | Boot state  |
|  | MOTOR_120_CONTROL_RUN_MODE_DRIVE            | 2             | Drive state   |
| motor_120_control_rotation_direction_t | MOTOR_120_CONTROL_ROTATION_DIRECTION_CW     | 0             | Direction clockwise                                   |
|  | MOTOR_120_CONTROL_ROTATION_DIRECTION_CCW    | 1             | Direction counterclockwise                            |
|  | MOTOR_120_CONTROL_ROTATION_DIRECTION_MAX    | 2             | Maximum of direction                                  |
| motor_120_control_wait_stop_flag_t     | MOTOR_120_CONTROL_WAIT_STOP_FLAG_CLEAR      | 0             | Clear the flag to wait motor stop                     |
|  | MOTOR_120_CONTROL_WAIT_STOP_FLAG_SET        | 1             | Set the flag to wait motor stop                       |
| motor_120_control_timeout_error_flag_t | MOTOR_120_CONTROL_TIME_OUT_ERROR_FLAG_CLEAR | 0             | Clear the flag of time out error                      |
|  | MOTOR_120_CONTROL_TIME_OUT_ERROR_FLAG_SET   | 1             | Set the flag of time out error                        |
| motor_120_control_pattern_error_flag_t | MOTOR_120_CONTROL_PATT_ERROR_FLAG_CLEAR     | 0             | Clear the flag of BEMF pattern error                  |
|  | MOTOR_120_CONTROL_PATT_ERROR_FLAG_SET       | 1             | Set the flag of BEMF pattern error                    |

**Table 9-32 List of Enumeration type for 120-degree control module (rm\_motor\_120\_control\_api.h)  
[2/2]**

| Enumeration type name           | Members                                   | Defined value | Description                              |
|---------------------------------|---|---------------|--|
| motor_120_control_speed_ref_t   | MOTOR_120_CONTROL_SP_EED_REF_ZERO_CONST   | 0             | State to set speed reference to zero     |
|                                 | MOTOR_120_CONTROL_SP_EED_REF_OPENLOOP_1   | 1             | State of speed reference at open loop #1 |
|                                 | MOTOR_120_CONTROL_SP_EED_REF_OPENLOOP_2   | 2             | State of speed reference at open loop #2 |
|                                 | MOTOR_120_CONTROL_SP_EED_REF_OPENLOOP_3   | 3             | State of speed reference at open loop #3 |
|                                 | MOTOR_120_CONTROL_SP_EED_REF_CHANGE       | 4             | State of speed reference at PI control   |
| motor_120_control_voltage_ref_t | MOTOR_120_CONTROL_VO_LTAGE_REF_ZERO_CONST | 0             | State to set voltage reference to zero   |
|                                 | MOTOR_120_CONTROL_VO_LTAGE_REF_UP         | 1             | State to increase voltage reference      |
|                                 | MOTOR_120_CONTROL_VO_LTAGE_REF_CONST      | 2             | State to set voltage reference constant  |
|                                 | MOTOR_120_CONTROL_VO_LTAGE_REF_OPENLOOP   | 3             | State of voltage reference at open loop  |
|                                 | MOTOR_120_CONTROL_VO_LTAGE_REF_PI_OUTPUT  | 4             | State of voltage reference at PI control |

## 9.8 120-degree driver Module

The 120-degree driver module works as an interface between each motor modules and MCU peripherals. Appropriately configuring the 120-degree driver module allows you to use microcontroller function allocation and the differences of the board to be used without modifying the motor module.

### 9.8.1 Functions


Table 9-33 lists the functions of the 120-degree driver module.

**Table 9-33 List of functions of the 120-degree driver module**

| Functions                                | Description   |
|--|---|
| Acquisition of the A/D conversion value  | Acquires A/D converted values such as the phase current and inverter bus voltage. |
| Offset adjustment of current and voltage | Calculate A/D offset at each phase current and voltage detection                  |
| PWM duty setting                         | Sets the PWM duty value that is to be output to U, V, and W-phases.               |
| PWM start/stop                           | Controls whether to start or stop (active or inactive) of PWM output.             |

### 9.8.2 Module configuration diagram

The module configuration of 120-degree driver module is shown below.



**Figure 9-5 Module configuration diagram of 120-degree driver module**

### 9.8.3 API

Table 9-34 lists and describes the API functions for 120-degree driver module.

**Table 9-34 List of API functions for the 120-degree driver module**

| <b>API</b>                               | <b>Description</b>   |
|--|--|
| RM_MOTOR_120_DRIVER_Open                 | Generate instances of 120-degree driver module and the modules to be used. |
| RM_MOTOR_120_DRIVER_Close                | Close instances of 120-degree driver module and the modules to be used.    |
| RM_MOTOR_120_DRIVER_Run                  | Active the module (Start motor rotation)                                   |
| RM_MOTOR_120_DRIVER_Stop                 | Inactive the module (Stop motor rotation)                                  |
| RM_MOTOR_120_DRIVER_Reset                | Reset the module and the modules to be used.                               |
| RM_MOTOR_120_DRIVER_PhaseVoltageSet      | Set phase voltage reference  |
| RM_MOTOR_120_DRIVER_PhasePatternSet      | Set phase chopping pattern   |
| RM_MOTOR_120_DRIVER_CurrentGet           | Get A/D converted data of phase current and inverter bus voltage           |
| RM_MOTOR_120_DRIVER_CurrentOffsetCalc    | Calculate A/D offset   |
| RM_MOTOR_120_DRIVER_FlagCurrentOffsetGet | Get the flag of A/D offset state (active/finish)                           |
| RM_MOTOR_120_DRIVER_ParameterUpdate      | Update configuration parameters of the module                              |

#### 9.8.4 Structure and variable information

Structures and variables of 120-degree driver module are listed below.

**Table 9-35 List of structures and variables for 120-degree driver module (rm\_motor\_120\_driver\_api.h)**

| Structure                         | Members               | Description   |
|-----------------------------------|-----------------------|---|
| motor_120_driver_callback_args_t  | event                 | Event data of callback  |
|                                   | *p_context            | Address of context data for callback function                     |
| motor_120_driver_current_status_t | iu                    | U phase electrical current [A]                                    |
|                                   | iv                    | V phase electrical current [A]                                    |
|                                   | iw                    | W phase electrical current [A]                                    |
|                                   | vdc                   | Inverter bus voltage [V]  |
|                                   | vu                    | U phase voltage [V]<br>(No use in 120-degree hall)                |
|                                   | vv                    | V phase voltage [V]<br>(No use in 120-degree hall)                |
|                                   | vw                    | W phase voltage [V]<br>(No use in 120-degree hall)                |
| motor_120_driver_cfg_t            | *p_callback           | Address of set callback function                                  |
|                                   | *p_context            | Address of context data for callback function                     |
|                                   | *p_extend             | Address to refer the extended configuration structure             |
| motor_120_driver_api_t            | *open                 | Address of open function  |
|                                   | *close                | Address of close function   |
|                                   | *run                  | Address of function to active the module (start motor rotation)   |
|                                   | *stop                 | Address of function to inactive the module (stop motor rotation)  |
|                                   | *reset                | Address of reset function   |
|                                   | *phaseVoltageSet      | Address of function to set phase voltage reference                |
|                                   | *phasePatternSet      | Address of function to set chopping pattern                       |
|                                   | *currentGet           | Address of function to get phase current and inverter bus voltage |
|                                   | *currentOffsetCalc    | Address of function to perform calculation of A/D offset          |
|                                   | *flagCurrentOffsetGet | Address of function to get the flag of A/D offset                 |
| motor_120_driver_instance_t       | *p_ctrl               | Address of structure of module variables                          |
|                                   | *p_cfg                | Address of structure of module configuration                      |
|                                   | *p_api                | Address of structure of API function address                      |

**Table 9-36 List of structures and variables for 120-degree driver module [1/3] (rm\_motor\_120\_driver.h)**

| Structure                               | Members                 | Description  |
|---|-------------------------|--|
| motor_120_driver_shared_instance_ctrl_t | open                    | Module opened information  |
|   | registered_motor_count  | Registered motor counts  |
|   | *p_context              | Address of context to be referred                                  |
| motor_120_driver_extended_shared_cfg_t  | *p_adc_instance_1st     | Address of ADC instance #1   |
|   | *p_adc_instance_2nd     | Address of ADC instance #2   |
|   | *p_shared_instance_ctrl | Address of structure of shared module variables                    |
| motor_120_driver_modulation_t           | f4_vdc                  | Inverter bus voltage   |
|   | f4_max_duty             | Maximum of PWM duty  |
|   | f4_min_duty             | Minimum of PWM duty  |
|   | f4_neutral_duty         | Value of PWM to output neutral                                     |
| motor_120_driver_extended_cfg_t         | *p_adc_instance         | Address of ADC instance  |
|   | *p_three_phase_instance | Address of 3phase PWM instance                                     |
|   | motor_120_type          | 120 sensorless/hall type   |
|   | iu_ad_ch                | A/D channel for U phase current                                    |
|   | iw_ad_ch                | A/D channel for W phase current                                    |
|   | vdc_ad_ch               | A/D channel for inverter bus voltage                               |
|   | vu_ad_ch                | A/D channel for U phase voltage<br>(No use in 120-degree hall)     |
|   | vv_ad_ch                | A/D channel for V phase voltage<br>(No use in 120-degree hall)     |
|   | vw_ad_ch                | A/D channel for W phase voltage<br>(No use in 120-degree hall)     |
|   | iu_ad_unit              | A/D unit number for U phase current                                |
|   | iw_ad_unit              | A/D unit number for W phase current                                |
|   | vdc_ad_unit             | A/D unit number for inverter bus voltage                           |
|   | vu_ad_unit              | A/D unit number for U phase voltage<br>(No use in 120-degree hall) |
|   | vv_ad_unit              | A/D unit number for V phase voltage<br>(No use in 120-degree hall) |
|   | vw_ad_unit              | A/D unit number for W phase voltage<br>(No use in 120-degree hall) |
|   | port_up                 | Port number for U phase upper side                                 |
|   | port_un                 | Port number for U phase lower side                                 |
|   | port_vp                 | Port number for V phase upper side                                 |
|   | port_vn                 | Port number for V phase lower side                                 |
|   | port_wp                 | Port number for W phase upper side                                 |
|   | port_wn                 | Port number for W phase lower side                                 |

**Table 9-37 List of structures and variables for 120-degree driver module [2/3] (rm\_motor\_120\_driver.h)**

| Structure                        | Members                 | Description   |
|----------------------------------|-------------------------|---|
| motor_120_driver_extend_cfg_t    | u4_pwm_timer_freq       | PWM timer frequency [MHz]                                   |
|                                  | pwm_carrier_freq        | PWM carrier frequency [kHz]                                 |
|                                  | u4_deadtime             | Value of dead time (counter value)                          |
|                                  | f_current_range         | Maximum to detect electrical current [A]                    |
|                                  | f_vdc_range             | Maximum to detect inverter bus voltage [V]                  |
|                                  | f_ad_resolution         | Resolution of A/D conversion                                |
|                                  | f_ad_current_offset     | Center value of A/D for current detection                   |
|                                  | f_ad_voltage_conversion | Value to convert A/D data                                   |
|                                  | u4_offset_calc_count    | Counts to measure A/D offset                                |
|                                  | mod_param               | Structure for modulation                                    |
|                                  | interrupt_adc           | A/D unit number which occurs A/D end interrupt              |
|                                  | *p_shared_cfg           | Address of A/D shared module configuration                  |
| motor_120_driver_instance_ctrl_t | open                    | Module opened information                                   |
|                                  | u1_active               | Status of active/inactive of the module                     |
|                                  | u4_carrier_base         | Base counts to calculate PWM duty                           |
|                                  | u4_deadtime_count       | Couts to calculate dead time                                |
|                                  | f_iu_ad                 | Detected U phase electrical current [A]                     |
|                                  | f_iw_ad                 | Detected V phase electrical current [A]                     |
|                                  | f_vdc_ad                | Detected inverter bus voltage [V]                           |
|                                  | f_refu                  | U phase voltage reference [V]                               |
|                                  | f_refv                  | V phase voltage reference [V]                               |
|                                  | f_refw                  | W phase voltage reference [V]                               |
|                                  | f_vu_ad                 | Detected U phase voltage [V]<br>(No use in 120-degree hall) |
|                                  | f_vv_ad                 | Detected V phase voltage [V]<br>(No use in 120-degree hall) |
|                                  | f_vw_ad                 | Detected W phase voltage [V]<br>(No use in 120-degree hall) |
|                                  | u1_flag_offset_calc     | The flag of state of calculate A/D offset                   |
|                                  | u4_offset_calc_times    | Counter to measure A/D offset                               |

**Table 9-38 List of structures and variables for 120-degree driver module [3/3] (rm\_motor\_120\_driver.h)**

| Structure                        | Members   | Description   |
|----------------------------------|---|---|
| motor_120_driver_instance_ctrl_t | f_offset_iu   | A/D offset for U phase current  |
|                                  | f_offset_iw   | A/D offset for W phase current  |
|                                  | f_sum_iu_ad   | Summation of A/D offset for U phase current                                 |
|                                  | f_sum_iw_ad   | Summation of A/D offset for V phase current                                 |
|                                  | f_offset_vu   | A/D offset for U phase voltage<br>(No use in 120-degree hall)               |
|                                  | f_offset_vv   | A/D offset for V phase voltage<br>(No use in 120-degree hall)               |
|                                  | f_offset_vw   | A/D offset for W phase voltage<br>(No use in 120-degree hall)               |
|                                  | f_offset_off_vu   | A/D offset for U phase voltage at PWM is off<br>(No use in 120-degree hall) |
|                                  | f_offset_off_vv   | A/D offset for V phase voltage at PWM is off<br>(No use in 120-degree hall) |
|                                  | f_offset_off_vw   | A/D offset for W phase voltage at PWM is off<br>(No use in 120-degree hall) |
|                                  | f_sum_vu_ad   | Summation of A/D offset for U phase voltage<br>(No use in 120-degree hall)  |
|                                  | f_sum_vv_ad   | Summation of A/D offset for V phase voltage<br>(No use in 120-degree hall)  |
|                                  | f_sum_vw_ad   | Summation of A/D offset for W phase voltage<br>(No use in 120-degree hall)  |
|                                  | u4_gtioca_general_low_cfg                                       | Setting data of GTIOCA as general port to output low signal                 |
|                                  | u4_gtioca_general_high_cfg                                      | Setting data of GTIOCA as general port to output high signal                |
|                                  | u4_gtioca_peripheral_low_cfg                                    | Setting data of GTIOCA as peripheral port to output low signal              |
|                                  | u4_gtioca_peripheral_high_cfg                                   | Setting data of GTIOCA as peripheral port to output high signal             |
|                                  | u4_gtiocb_general_low_cfg                                       | Setting data of GTIOCB as general port to output low signal                 |
|                                  | u4_gtiocb_general_high_cfg                                      | Setting data of GTIOCB as general port to output high signal                |
|                                  | u4_gtiocb_peripheral_low_cfg                                    | Setting data of GTIOCB as peripheral port to output low signal              |
| u4_gtiocb_peripheral_high_cfg    | Setting data of GTIOCB as peripheral port to output high signal |   |
| st_modulation                    | Structure of modulation   |   |
| *p_cfg                           | Address to refer module configuration                           |   |
| adc_callback_args                | Callback argument for ADC callback                              |   |
| timer_callback_args              | Callback argument for timer callback                            |   |
| *p_shared_ctrl                   | Address of structure of A/D shared module variables             |   |

### 9.8.5 Macro and enumeration definition

The macros and enumerations for 120-degree driver module are listed below.

**Table 9-39 List of macros of 120-degree driver module**

| File name                 | Name of MACRO                             | Defined value   | Description                                      |
|---------------------------|---|---|--|
| rm_motor_120_dri<br>ver.c | MOTOR_120_DRIVER_OPEN                     | ('M' << 24U)   ('1' << 16U)   ('D' << 8U)   ('R' << 0U) | Module opened information                        |
|                           | MOTOR_120_DRIVER_SHARED<br>_ADC_OPEN      | ('M' << 24U)   ('1' << 16U)   ('S' << 8U)   ('A' << 0U) | Module opened information<br>of shared module    |
|                           | MOTOR_120_DRIVER_DEV_HA<br>LF             | 0.5F  | 0.5  |
|                           | MOTOR_120_DRIVER_KHZ_TR<br>ANS            | 1000U   | To transform kHz => Hz                           |
|                           | MOTOR_120_DRIVER_GENERA<br>L_IO_PORT_L    | 0x3000004   | Value to set a port to<br>general low output     |
|                           | MOTOR_120_DRIVER_GENERA<br>L_IO_PORT_H    | 0x3000005   | Value to set a port to<br>general high output    |
|                           | MOTOR_120_DRIVER_PERIPH<br>ERAL_IO_PORT_L | 0x3010004   | Value to set a port to<br>peripheral low output  |
|                           | MOTOR_120_DRIVER_PERIPH<br>ERAL_IO_PORT_H | 0x3010005   | Value to set a port to<br>peripheral high output |

**Table 9-40 List of Enumeration type for 120-degree driver module [1/2] (rm\_motor\_120\_driver\_api.h)**

| Enumeration                         | Members                                       | Defined value | Description   |
|-------------------------------------|---|---------------|---|
| motor_120_driver_event_t            | MOTOR_120_DRIVER_EVENT_FORWARD                | 0             | Callback event before 120-degree driver module process (A/D conversion end interrupt) |
|                                     | MOTOR_120_DRIVER_EVENT_120_CONTROL            | 1             | Callback event for 120-degree driver module process (A/D conversion end interrupt)    |
|                                     | MOTOR_120_DRIVER_EVENT_BACKWARD               | 2             | Callback event after 120-degree driver module process (A/D conversion end interrupt)  |
| motor_120_driver_flag_offset_calc_t | MOTOR_120_DRIVER_FLAG_O_FFSET_CALC_CLEAR      | 0             | No get A/D offset   |
|                                     | MOTOR_120_DRIVER_FLAG_O_FFSET_CALC_OFF_FINISH | 1             | A/D offset is gotten at port off  |
|                                     | MOTOR_120_DRIVER_FLAG_O_FFSET_CALC_ALL_FINISH | 2             | Finish to get A/D offset  |
| motor_120_driver_phase_pattern_t    | MOTOR_120_DRIVER_PHASE_PATTERN_ERROR          | 0             | Error of 3 phase chopping pattern   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_UP_PWM_VN_ON   | 1             | U phase upper side : PWM<br>V phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_UP_PWM_WN_ON   | 2             | U phase upper side : PWM<br>W phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_VP_PWM_UN_ON   | 3             | V phase upper side : PWM<br>U phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_VP_PWM_WN_ON   | 4             | V phase upper side : PWM<br>W phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_WP_PWM_UN_ON   | 5             | W phase upper side : PWM<br>U phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_WP_PWM_VN_ON   | 6             | W phase upper side : PWM<br>V phase lower side : ON                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_UP_ON_VN_PWM   | 7             | U phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_UP_ON_WN_PWM   | 8             | U phase upper side : ON<br>W phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_VP_ON_UN_PWM   | 9             | U phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_VP_ON_WN_PWM   | 10            | U phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_WP_ON_UN_PWM   | 11            | U phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_WP_ON_VN_PWM   | 12            | W phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_U_PWM_VN_ON    | 13            | U phase upper side : ON<br>V phase lower side : PWM                                   |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_U_PWM_WN_ON    | 14            | U phase : PWM<br>W phase lower side : ON  |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_V_PWM_UN_ON    | 15            | V phase : PWM<br>U phase lower side : ON  |
|                                     | MOTOR_120_DRIVER_PHASE_PATTERN_V_PWM_WN_ON    | 16            | V phase : PWM<br>W phase lower side : ON  |

**Table 9-41 List of Enumeration type for 120-degree driver module [2/2] (rm\_motor\_120\_driver\_api.h)**

| Enumeration                      | Members                                    | Defined value | Description                              |
|----------------------------------|--|---------------|--|
| motor_120_driver_phase_pattern_t | MOTOR_120_DRIVER_PHASE_PATTERN_W_PWM_UN_ON | 17            | W phase : PWM<br>U phase lower side : ON |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_W_PWM_VN_ON | 18            | W phase : PWM<br>V phase lower side : ON |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_UP_ON_V_PWM | 19            | U phase upper side : ON<br>V phase : PWM |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_UP_ON_W_PWM | 20            | U phase upper side : ON<br>W phase : PWM |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_VP_ON_U_PWM | 21            | V phase upper side : ON<br>U phase : PWM |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_VP_ON_W_PWM | 22            | V phase upper side : ON<br>W phase : PWM |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_WP_ON_U_PWM | 23            | W phase upper side : ON<br>U phase : PWM |
|                                  | MOTOR_120_DRIVER_PHASE_PATTERN_WP_ON_V_PWM | 24            | W phase upper side : ON<br>V phase : PWM |

**Table 9-42 List of Enumeration type for 120-degree driver module (rm\_motor\_120\_driver.h)**

| Enumeration                            | Members                                  | Defined value | Description                         |
|--|--|---------------|-------------------------------------|
| motor_120_driver_select_adc_instance_t | MOTOR_120_DRIVER_SELECT_ADC_INSTANCE_1ST | 0             | 1 <sup>st</sup> ADC module instance |
|  | MOTOR_120_DRIVER_SELECT_ADC_INSTANCE_2ND | 1             | 2 <sup>nd</sup> ADC module instance |
| motor_120_driver_status_t              | MOTOR_120_DRIVER_STATUS_INACTIVE         | 0             | Inactive state (Motor stops)        |
|  | MOTOR_120_DRIVER_STATUS_ACTIVE           | 1             | Active state (Motor rotates)        |
| motor_120_driver_type_t                | MOTOR_120_DRIVER_TYPE_SENSORLESS         | 0             | 120-degree sensorless               |
|  | MOTOR_120_DRIVER_TYPE_HALL               | 1             | 120-degree hall                     |

## 10. Setting the parameters

### 10.1 Overview

In this sample program, initial data of each module can be set by FSP configurator. Set values are automatically reflected to common\_data.c/h and hal\_data.c/h at code generation. Set values are also included to need parameters of each module at initial process (open process).

A part of parameter can be changed by RMW. Target parameters are listed in “9.5.3”. How to change values is referred to RMW manual.

### 10.2 List of Interface module parameters

The changeable parameters that are used in Interface module are listed in Table 10-1. And initial value are listed in Table 10-2 and Table 10-3. Setting can be changed in “Property” TAB on e<sup>2</sup> studio FSP. About other modules, same method can be used.

**Table 10-1 Configuration Options (rm\_motor\_120\_degree)**

| Option name               | Description   |
|---------------------------|---|
| Limit of over current (A) | When electric current over this value, PWM ports are set to OFF.              |
| Limit of over voltage (V) | When entered inverter bus voltage over this value, PWM ports are set to OFF.  |
| Limit of over speed (rpm) | When rotation speed over this value, PWM ports are set to OFF.                |
| Limit of low voltage (V)  | When entered inverter bus voltage below this value, PWM ports are set to OFF. |
| Callback                  | Callback function to be called at Speed/Current cyclic process.               |

**Table 10-2 Initial value of configuration options [1/2] (rm\_motor\_120\_degree)**

| Option name               | RA6T2              | RA6T3              | RA4T1              |
|---------------------------|--------------------|--------------------|--------------------|
| Limit of over current (A) | 1.67               | 1.67               | 1.67               |
| Limit of over voltage (V) | 60.0               | 60.0               | 60.0               |
| Limit of over speed (rpm) | 4500.0             | 4500.0             | 4500.0             |
| Limit of low voltage (V)  | 8.0                | 8.0                | 8.0                |
| Callback                  | mtr_callback_event | mtr_callback_event | mtr_callback_event |

**Table 10-3 Initial value of configuration options [2/2] (rm\_motor\_120\_degree)**

| Option name               | RA8T1              | RA8T2              |
|---------------------------|--------------------|--------------------|
| Limit of over current (A) | 1.67               | 1.67               |
| Limit of over voltage (V) | 60.0               | 60.0               |
| Limit of over speed (rpm) | 4500.0             | 4500.0             |
| Limit of low voltage (V)  | 8.0                | 8.0                |
| Callback                  | mtr_callback_event | mtr_callback_event |

### 10.3 List of 120-degree control module parameters

The changeable parameters that are used in 120-degree control module and these initial values are listed below.

**Table 10-4 Configuration Options (rm\_motor\_120\_control\_hall)**

| Options  | Description                                  |
|--|--|
| General   Conduction type                      | Type of chopping pattern                     |
| General   Timeout counts (msec)                | Couts to judge timeout [ms]                  |
| General   Maximum voltage (V)                  | Maximum voltage [V]                          |
| General   Minimum voltage (V)                  | Minimum voltage [V]                          |
| General   Speed PI decimation                  | Decimation value of speed process interrupt  |
| General   Free run timer frequency (MHz)       | Frequency of free run timer [MHz]            |
| General   Speed LPF                            | Coefficient of speed LPF                     |
| General   Step of speed reference change       | Changing step of speed reference             |
| General   Start reference voltage (V)          | Voltage reference at start up [V]            |
| General   Hall wait counts                     | Counts to judge motor rotation at start up   |
| General   Minimum limit speed (rpm)            | Minimum of rotation speed (mechanical) [rpm] |
| General   PI control KP                        | Proportional parameter of speed PI           |
| General   PI control KI                        | Integral parameter of speed PI               |
| General   PI control limit                     | Integral limit of speed PI [V]               |
| General   Hall interrupt mask value            | Counts to mask error of hall signal          |
| Motor Parameter   Pole pairs                   | Pole pairs                                   |
| Motor Parameter   Resistance (ohm)             | Resistance [ohm]                             |
| Motor Parameter   Inductance of d-axis (H)     | d-axis inductance [H]                        |
| Motor Parameter   Inductance of q-axis (H)     | q-axis inductance [H]                        |
| Motor Parameter   Permanent magnetic flux (Wb) | Magnetic flux [Wb]                           |
| Motor Parameter   Rotor inertia (kgm^2)        | Inertia [kgm^2]                              |
| Hall sensor port U                             | Port number of U phase hall sensor           |
| Hall sensor port V                             | Port number of V phase hall sensor           |
| Hall sensor port W                             | Port number of W phase hall sensor           |

**Table 10-5 Configuration Options initial value [1/2] (rm\_motor\_120\_control\_hall)**

| Options  | RA6T2                                   | RA6T3                                   | RA4T1                                   |
|--|---|---|---|
| General   Conduction type                      | Complementary<br>First 60 degree<br>PWM | Complementary<br>First 60 degree<br>PWM | Complementary<br>First 60 degree<br>PWM |
| General   Timeout counts (msec)                | 200                                     | 200                                     | 200                                     |
| General   Maximum voltage (V)                  | 22.0                                    | 22.0                                    | 22.0                                    |
| General   Minimum voltage (V)                  | 3.0                                     | 3.0                                     | 3.0                                     |
| General   Speed PI decimation                  | 0                                       | 0                                       | 0                                       |
| General   Free run timer frequency (MHz)       | 120.0                                   | 50.0                                    | 50.0                                    |
| General   Speed LPF                            | 1.0                                     | 1.0                                     | 1.0                                     |
| General   Step of speed reference change       | 0.2                                     | 0.2                                     | 0.2                                     |
| General   Start reference voltage (V)          | 5.8                                     | 5.8                                     | 5.8                                     |
| General   Hall wait counts                     | 12                                      | 12                                      | 12                                      |
| General   Minimum limit speed (rpm)            | 550                                     | 550                                     | 550                                     |
| General   PI control KP                        | 0.02                                    | 0.02                                    | 0.02                                    |
| General   PI control KI                        | 0.0005                                  | 0.0005                                  | 0.0005                                  |
| General   PI control limit                     | 24.0                                    | 24.0                                    | 24.0                                    |
| General   Hall interrupt mask value            | 15                                      | 15                                      | 15                                      |
| Motor Parameter   Pole pairs                   | 4                                       | 4                                       | 4                                       |
| Motor Parameter   Resistance (ohm)             | 1.3                                     | 1.3                                     | 1.3                                     |
| Motor Parameter   Inductance of d-axis (H)     | 0.0013                                  | 0.0013                                  | 0.0013                                  |
| Motor Parameter   Inductance of q-axis (H)     | 0.0013                                  | 0.0013                                  | 0.0013                                  |
| Motor Parameter   Permanent magnetic flux (Wb) | 0.01119                                 | 0.01119                                 | 0.01119                                 |
| Motor Parameter   Rotor inertia (kgm^2)        | 0.000003666                             | 0.000003666                             | 0.000003666                             |
| Hall sensor port U                             | BSP_IO_PORT<br>_12_PIN_04               | BSP_IO_PORT<br>_00_PIN_08               | BSP_IO_PORT<br>_00_PIN_08               |
| Hall sensor port V                             | BSP_IO_PORT<br>_12_PIN_05               | BSP_IO_PORT<br>_00_PIN_06               | BSP_IO_PORT<br>_00_PIN_06               |
| Hall sensor port W                             | BSP_IO_PORT<br>_11_PIN_01               | BSP_IO_PORT<br>_00_PIN_15               | BSP_IO_PORT<br>_00_PIN_15               |

**Table 10-6 Configuration Options initial value [2/2] (rm\_motor\_120\_control\_hall)**

| Options  | RA8T1                                   | RA8T2                                   |
|--|---|---|
| General   Conduction type                      | Complementary<br>First 60 degree<br>PWM | Complementary<br>First 60 degree<br>PWM |
| General   Timeout counts (msec)                | 200                                     | 200                                     |
| General   Maximum voltage (V)                  | 22.0                                    | 22.0                                    |
| General   Minimum voltage (V)                  | 3.0                                     | 3.0                                     |
| General   Speed PI decimation                  | 0                                       | 0                                       |
| General   Free run timer frequency (MHz)       | 120.0                                   | 250.0                                   |
| General   Speed LPF                            | 1.0                                     | 1.0                                     |
| General   Step of speed reference change       | 0.2                                     | 0.2                                     |
| General   Start reference voltage (V)          | 5.8                                     | 5.8                                     |
| General   Hall wait counts                     | 12                                      | 12                                      |
| General   Minimum limit speed (rpm)            | 550                                     | 550                                     |
| General   PI control KP                        | 0.02                                    | 0.02                                    |
| General   PI control KI                        | 0.0005                                  | 0.0005                                  |
| General   PI control limit                     | 24.0                                    | 24.0                                    |
| General   Hall interrupt mask value            | 15                                      | 15                                      |
| Motor Parameter   Pole pairs                   | 4                                       | 4                                       |
| Motor Parameter   Resistance (ohm)             | 1.3                                     | 1.3                                     |
| Motor Parameter   Inductance of d-axis (H)     | 0.0013                                  | 0.0013                                  |
| Motor Parameter   Inductance of q-axis (H)     | 0.0013                                  | 0.0013                                  |
| Motor Parameter   Permanent magnetic flux (Wb) | 0.01119                                 | 0.01119                                 |
| Motor Parameter   Rotor inertia (kgm^2)        | 0.000003666                             | 0.000003666                             |
| Hall sensor port U                             | BSP_IO_PORT<br>_09_PIN_07               | BSP_IO_PORT<br>_10_PIN_08               |
| Hall sensor port V                             | BSP_IO_PORT<br>_09_PIN_05               | BSP_IO_PORT<br>_10_PIN_10               |
| Hall sensor port W                             | BSP_IO_PORT<br>_09_PIN_06               | BSP_IO_PORT<br>_10_PIN_09               |

## 10.4 List of 120-degree driver module parameters

The changeable parameters that are used in 120-degree driver control module and these initial values are listed below.

**Table 10-7 Configuration options of driver module [1/2] (rm\_motor\_120\_driver)**

| Option name  | Description   |
|--|---|
| Common   ADC_B Support                                   | ADC_B module support                                      |
| Common   Shared ADC Support                              | Selection of using shared ADC module                      |
| General   PWM output port UP                             | PWM output (Up) port                                      |
| General   PWM output port UN                             | PWM output (Un) port                                      |
| General   PWM output port VP                             | PWM output (Vp) port                                      |
| General   PWM output port VN                             | PWM output (Vn) port                                      |
| General   PWM output port WP                             | PWM output (Wp) port                                      |
| General   PWM output port WN                             | PWM output (Wn) port                                      |
| General   PWM timer frequency (MHz)                      | PWM timer frequency [MHz]                                 |
| General   PWM carrier period (Microseconds)              | PWM carrier frequency [Microseconds]                      |
| General   Dead time (Raw counts)                         | Dead time count [Raw counts]                              |
| General   Current range (A)                              | Current detection range [A]                               |
| General   Voltage range (V)                              | Voltage detection range [V]                               |
| General   Resolution of A/D conversion                   | A/D conversion value                                      |
| General   Offset of A/D conversion for current           | A/D conversion offset                                     |
| General   Conversion level of A/D conversion for voltage | Voltage A/D conversion rate                               |
| General   Counts for current offset measurement          | Offset value calculation count                            |
| General   Input voltage                                  | Inverter bus voltage                                      |
| General   A/D conversion channel for U phase current     | U phase current detection channel                         |
| General   A/D conversion channel for W phase current     | W phase current detection channel                         |
| General   A/D conversion channel for main line voltage   | Inverter bus voltage detection channel                    |
| General   A/D conversion channel for U phase voltage     | U phase voltage detection channel                         |
| General   A/D conversion channel for V phase voltage     | V phase voltage detection channel                         |
| General   A/D conversion channel for W phase voltage     | W phase voltage detection channel                         |
| General   A/D conversion unit for U phase current        | Select the A/D conversion module for U phase current      |
| General   A/D conversion unit for W phase current        | Select the A/D conversion module for W phase current      |
| General   A/D conversion unit for main line voltage      | Select the A/D conversion module for inverter bus voltage |

**Table 10-8 Configuration options of driver module [2/2] (rm\_motor\_120\_driver)**

| Option name                                       | Description  |
|---|--|
| General   A/D conversion unit for U phase voltage | Select the A/D conversion module for U phase voltage |
| General   A/D conversion unit for V phase voltage | Select the A/D conversion module for V phase voltage |
| General   A/D conversion unit for W phase voltage | Select the A/D conversion module for W phase voltage |
| General   GTIOCA stop level                       | Level when the upper arm is stopped                  |
| General   GTIOCB stop level                       | Level when lower arm is stopped                      |
| General   ADC interrupt module                    | A/D unit number which occurs interrupt               |
| Modulation   Maximum duty                         | PWM maximum duty                                     |

**Table 10-9 Configuration Options initial value [1/2] (rm\_motor\_120\_driver)**

| Option name  | RA6T2                     | RA6T3                     | RA4T1                     |
|--|---------------------------|---------------------------|---------------------------|
| Common   ADC_B Support                                   | Enabled                   | Disabled                  | Disabled                  |
| Common   Shared ADC Support                              | Disabled                  | Disabled                  | Disabled                  |
| General   PWM output port UP                             | BSP_IO_PORT<br>_11_PIN_04 | BSP_IO_PORT<br>_04_PIN_09 | BSP_IO_PORT<br>_04_PIN_09 |
| General   PWM output port UN                             | BSP_IO_PORT<br>_11_PIN_05 | BSP_IO_PORT<br>_04_PIN_08 | BSP_IO_PORT<br>_04_PIN_08 |
| General   PWM output port VP                             | BSP_IO_PORT<br>_11_PIN_06 | BSP_IO_PORT<br>_01_PIN_03 | BSP_IO_PORT<br>_01_PIN_03 |
| General   PWM output port VN                             | BSP_IO_PORT<br>_11_PIN_07 | BSP_IO_PORT<br>_01_PIN_02 | BSP_IO_PORT<br>_01_PIN_02 |
| General   PWM output port WP                             | BSP_IO_PORT<br>_11_PIN_08 | BSP_IO_PORT<br>_01_PIN_11 | BSP_IO_PORT<br>_01_PIN_11 |
| General   PWM output port WN                             | BSP_IO_PORT<br>_11_PIN_09 | BSP_IO_PORT<br>_01_PIN_12 | BSP_IO_PORT<br>_01_PIN_12 |
| General   PWM timer frequency (MHz)                      | 120                       | 100                       | 100                       |
| General   PWM carrier period (Microseconds)              | 50                        | 50                        | 50                        |
| General   Dead time (Raw counts)                         | 240                       | 200                       | 200                       |
| General   Current range (A)                              | 16.5                      | 16.5                      | 16.5                      |
| General   Voltage range (V)                              | 73.51                     | 73.51                     | 73.51                     |
| General   Resolution of A/D conversion                   | 0xFFFF                    | 0xFFFF                    | 0xFFFF                    |
| General   Offset of A/D conversion for current           | 0x7FF                     | 0x7FF                     | 0x7FF                     |
| General   Conversion level of A/D conversion for voltage | 1.0                       | 1.0                       | 1.0                       |
| General   Counts for current offset measurement          | 500                       | 500                       | 500                       |
| General   Input voltage                                  | 24.0                      | 24.0                      | 24.0                      |
| General   A/D conversion channel for U phase current     | 4                         | 0                         | 0                         |
| General   A/D conversion channel for W phase current     | 0                         | 2                         | 2                         |
| General   A/D conversion channel for main line voltage   | Ver.1: 6<br>Ver.2: 7      | 4                         | 4                         |
| General   A/D conversion channel for U phase voltage     | -                         | -                         | -                         |
| General   A/D conversion channel for V phase voltage     | -                         | -                         | -                         |
| General   A/D conversion channel for W phase voltage     | -                         | -                         | -                         |
| General   A/D conversion unit for U phase current        | -                         | -                         | -                         |
| General   A/D conversion unit for W phase current        | -                         | -                         | -                         |
| General   A/D conversion unit for main line voltage      | -                         | -                         | -                         |
| General   A/D conversion unit for U phase voltage        | -                         | -                         | -                         |
| General   A/D conversion unit for V phase voltage        | -                         | -                         | -                         |
| General   A/D conversion unit for W phase voltage        | -                         | -                         | -                         |
| General   GTIOCA stop level                              | Pin Level Low             | Pin Level Low             | Pin Level Low             |
| General   GTIOCB stop level                              | Pin Level High            | Pin Level High            | Pin Level High            |
| General   ADC interrupt module                           | -                         | -                         | -                         |
| Modulation   Maximum duty                                | 0.9375                    | 0.9375                    | 0.9375                    |

**Table 10-10 Configuration Options initial value [2/2] (rm\_motor\_120\_driver)**

| Option name  | RA8T1                 | RA8T2                 |
|--|-----------------------|-----------------------|
| Common   ADC_B Support                                   | Disabled              | Enabled               |
| Common   Shared ADC Support                              | Enabled               | Disabled              |
| General   PWM output port UP                             | BSP_IO_PORT_01_PIN_15 | BSP_IO_PORT_06_PIN_05 |
| General   PWM output port UN                             | BSP_IO_PORT_06_PIN_09 | BSP_IO_PORT_06_PIN_04 |
| General   PWM output port VP                             | BSP_IO_PORT_01_PIN_13 | BSP_IO_PORT_06_PIN_03 |
| General   PWM output port VN                             | BSP_IO_PORT_01_PIN_14 | BSP_IO_PORT_06_PIN_02 |
| General   PWM output port WP                             | BSP_IO_PORT_03_PIN_00 | BSP_IO_PORT_06_PIN_12 |
| General   PWM output port WN                             | BSP_IO_PORT_01_PIN_12 | BSP_IO_PORT_06_PIN_13 |
| General   PWM timer frequency (MHz)                      | 120                   | 250                   |
| General   PWM carrier period (Microseconds)              | 50                    | 50                    |
| General   Dead time (Raw counts)                         | 240                   | 500                   |
| General   Current range (A)                              | 16.5                  | 16.5                  |
| General   Voltage range (V)                              | 73.51                 | 73.51                 |
| General   Resolution of A/D conversion                   | 0xFFFF                | 0xFFFF                |
| General   Offset of A/D conversion for current           | 0x7FF                 | 0x7FF                 |
| General   Conversion level of A/D conversion for voltage | 1.0                   | 1.0                   |
| General   Counts for current offset measurement          | 500                   | 500                   |
| General   Input voltage                                  | 24.0                  | 24.0                  |
| General   A/D conversion channel for U phase current     | 0                     | 6                     |
| General   A/D conversion channel for W phase current     | 2                     | 10                    |
| General   A/D conversion channel for main line voltage   | 8                     | 7                     |
| General   A/D conversion channel for U phase voltage     | -                     | -                     |
| General   A/D conversion channel for V phase voltage     | -                     | -                     |
| General   A/D conversion channel for W phase voltage     | -                     | -                     |
| General   A/D conversion unit for U phase current        | -                     | -                     |
| General   A/D conversion unit for W phase current        | -                     | -                     |
| General   A/D conversion unit for main line voltage      | -                     | -                     |
| General   A/D conversion unit for U phase voltage        | -                     | -                     |
| General   A/D conversion unit for V phase voltage        | -                     | -                     |
| General   A/D conversion unit for W phase voltage        | -                     | -                     |
| General   GTIOCA stop level                              | Pin Level Low         | Pin Level Low         |
| General   GTIOCB stop level                              | Pin Level High        | Pin Level High        |
| General   ADC interrupt module                           | 1st                   | 1st                   |
| Modulation   Maximum duty                                | 0.9375                | 0.9375                |

## 10.5 Parameters about protection function

rm\_motor\_120\_degree / Limit of over current

Set the threshold to judge overcurrent. Actual value is calculated by “input value \* sqrt(2) \* 1.5”.

rm\_motor\_120\_degree / Limit of over voltage

Set the threshold to judge over voltage error. Please select reasonable value with your environment.

rm\_motor\_120\_degree / Limit of low voltage

Set the threshold to judge low voltage error. Please select reasonable value with your environment.

## 10.6 Changing the PWM carrier frequency

If you want to change PWM carrier frequency, please change below items.

rm\_motor\_120\_driver / PWM Carrier frequency

Set the frequency of PWM carrier.

## 10.7 modulation method (chopping pattern)

rm\_motor\_120\_control\_hall / Conduction type

In this sample program, 2 types chopping pattern can be selected. Default setting is “Complimentary first 60 chopping”.

## 10.8 Parameters for inverter

### 10.8.1 Deadtime

rm\_motor\_120\_driver / Dead Time (Raw Counts)

Set dead time which is written in specification or design document about the inverter as counts of the timer (GPT). For example, if the timer clock is “120[MHz]” and deadtime is “2[μs]”, please set “240”.

### 10.8.2 Current detection gain

rm\_motor\_120\_driver / Current Range (A)

Set the range to detect electrical current. In the specification of MCILV-1, when 0.0 to 3.3[V] input,  $\pm 8.25[A]$  (peak to peak 16.5[A]) is detected. Please set value of “peak to peak”.

Table 10-11 Current signal specifications for MCILV-1

| 3-phase output current value | ADC Input voltage value | ADC conversion value |
|------------------------------|-------------------------|----------------------|
| +8.25A                       | 3.3V                    | 4095                 |
| 0A                           | 1.65V                   | 2047                 |
| -8.25A                       | 0V                      | 0                    |




Figure 10-1 Current detection calculation flow

### 10.8.3 Voltage detection gain

rm\_motor\_120\_driver / Voltage Range (V)

Set the value when maximum digits (12bit conversion : 4095) is detected, how much voltage is inputted. For MCILV-1, when ADC input is 3.3[V], detected voltage is correspond to 73.51[V] (this ratio depends on circuit). Therefore, set “73.51” in this configuration.

Table 10-12 Inverter bus voltage signal specifications for MCILV-1

| Inverter bus voltage value | ADC Input voltage value | ADC conversion value |
|----------------------------|-------------------------|----------------------|
| 0V                         | 0V                      | 0                    |
| 73.51V                     | 3.3V                    | 4095                 |

## 10.9 Motor parameters

If motor parameter information is not available from the motor manufacturer, motor parameters  $R$ ,  $L_d$ , and  $L_q$  can be obtained simply by using an LCR meter. The inductive voltage can also be obtained simply by using an oscilloscope. The methods described here are simplified methods that does not take into account magnetic saturation or other phenomenon and is intended to turn the motor quickly, being subject to individual differences and measurement errors. Therefore, when using the parameters in actual product development, measurement should be performed using measurement equipment whose accuracy is ensured.

The LCR meter should be calibrated periodically, and measurement should be made in a warm-up complete state after at least 30 minutes of power on. In addition, perform open compensation and short compensation in advance to reduce probe errors using the 4-terminal pair method. For details, refer to the LCR meter's instruction manual.

### Pole pairs

Set the number of pole pairs of the motor. The number of pole pairs is 1/2 the number of poles. Refer to the motor specifications.

### Resistance

For wiring when measuring with an LCR meter, select two of the motor's three-phase output wires U, V, and W and connect the probes to them. To measure the resistance, use the DC resistance (DCR) mode. Because the resistance value obtained is the composite resistance of the two phases, the resistance value of the motor for one phase can be obtained by halving it. The unit is ohm.

### Inductance of d-axis, Inductance of q-axis

For wiring when measuring with an LCR meter, select two of the motor's three-phase output wires U, V, and W and connect the probes to them. For the measurement mode, use the series equivalent circuit mode ( $L_s$ ). For detailed measurement methods, refer to the LCR meter's instruction manual.

Turn the axis slowly and note down the maximum and minimum inductance values that are displayed. Here, 1/2 of the maximum value is  $L_q$  and 1/2 of the minimum value is  $L_d$ .

Set the obtained  $L_d$  and  $L_q$ . The unit is H (henry).

### Roter inertia

Specify the inertia (moment of inertia) of the motor's rotor and shaft. The unit is  $\text{kg m}^2$ . Usually, you can find a description in the documentation provided with the motor. If a load is installed, inertia on the load side should also be added to the setting.


### Nominal current

Specify the motor's rated current (RMS). The unit is ampere. It is indicated on the nameplate of the motor or in the accompanying documentation.

### Permanent magnetic flux

Select two of the motor's three-phase output wires U, V, and W and connect them to the oscilloscope. For example, connect the oscilloscope probes to the U and V phases so that the voltages can be measured. The U-V phase line voltage value can be obtained by connecting a motor that can rotate at the rated speed to the end of the motor shaft and rotating it at the rated speed. Dividing the line voltage value by  $\sqrt{3}$  gives the peak value of inductive voltage per phase. You can obtain the magnetic flux linkage  $\Psi$  from the equation of the inductive voltage =  $\omega\Psi$ . Convert the rated speed to the electrical angular speed frequency  $f[\text{Hz}]$ , substitute  $\omega$  with  $2\pi f$  to make the inductive voltage =  $2\pi f\Psi$ , rearrange the equation, substitute a value to obtain the magnetic flux linkage  $\Psi[\text{Wb}]$ .

In cases where a motor cannot be mounted on the end of the shaft, a simple method of obtaining voltage waveforms by quickly rotating the motor by hand can also be used. However, accuracy cannot be guaranteed, and the method can only be used for test run purposes. When turned by hand, the voltage waveform similar to the following image is obtained. In this case, select a cycle close to a constant speed with a sine wave, and find the peak and cycle of the voltage.



In this algorithm, the peak value must be converted to an RMS value. Therefore, divide it by  $\sqrt{2}$  to obtain the RMS value,  $\text{Emf}'_{\text{rms}}$ .

$$\text{Emf}'_{\text{rms}}[\text{V}] = \text{Emf}'_{\text{peak}}[\text{V}] \times \frac{1}{\sqrt{2}}$$

To convert the obtained time  $t[\text{sec}]$  to Hz, apply the formula  $f=1/t$ . Find the ratio of the obtained  $f[\text{Hz}]$  to the electrical angular frequency [Hz] obtained from the rated speed of this IPM motor, and multiply the voltage  $\text{Emf}'_{\text{rms}}[\text{V}]$  obtained simultaneously by the ratio.

$$\text{Emf}[\text{V}] = \text{Emf}'_{\text{rms}}[\text{V}] \times \frac{\text{electrical angular frequency}[\text{Hz}]}{f'[\text{Hz}]}$$

As a result, the inductive voltage [V] that is generated when this IPM motor rotates at its rated speed can be determined simply. To determine the inductive voltage, it must be measured by rotating the motor shaft at the rated speed using a load test device.

Next, the magnetic flux linkage  $\Psi[\text{Wb}]$  is obtained from the inductive voltage. In general, inductive voltage and magnetic flux linkage have the relationship as below.  $f$  is the electric angular frequency [Hz] at rated speed.

$$\text{Emf}[\text{V}] = \omega\Psi = 2\pi f\Psi$$

The magnetic flux linkage  $\Psi[\text{Wb}]$  can be obtained by rearranging the equation and substituting the inductive voltage  $\text{Emf}[\text{V}]$  obtained above and the electric angular frequency [Hz] during rated speed operation.

$$\Psi = \frac{\text{Emf}[\text{V}]}{2\pi f}$$

Specify the obtained magnetic flux linkage  $\Psi$  to Magnetic Flux of each module.

## 11. Control flowcharts

### 11.1 Main process




Figure 11-1 Main Process Flowchart

## 11.2 Carrier periodic interrupt process




Figure 11-2 Carrier Periodic Interrupt Process Flowchart

### 11.3 Speed control Periodic Interrupt Process




Figure 11-3 Speed Control Periodic Interrupt Process Flowchart

## 11.4 Hall signal interrupt process




Figure 11-4 Hall signal interrupt process flowchart

## 11.5 Over Current Detection Interrupt Process

The overcurrent detection interrupt is an interrupt that occurs when an external overcurrent detection signal is input. The PWM output terminal are put in the high impedance state. Therefore, at the start of execution of this interrupt processing, the PWM output terminal is already in the high impedance state and the output to the motor had been stopped.




Figure 11-5 Over Current Detection Interrupt Process Flowchart

## 12. FAQ

### 12.1 Troubleshooting

Table 12-1 shows typical phenomena and their solutions.

**Table 12-1 List of phenomena and their solutions**

| Phenomena  | Solution   |
|--|--|
| When a load is applied, the motor keeps turning at a speed other than the setting. | The motor is stepped out. The motor is out of control and must be stopped immediately.<br>Inappropriate motor parameters or control parameters or hardware performance limitations such as sensors may prevent control. Reconsider the design.   |
| Motor cannot rotate after stopping due to an error.                                | For details, see 6.7 c). It explains how to recover from errors.   |
| The motor stops with an error even after starting.                                 | See 6.7 c) for the cause of the error. After that, please confirm settings about the cause of errors.  |
| The values set from RMW are not reflected.   | Manipulate variables in com_u1_enable_write to rewrite the parameters. When the timing for writing values to com_u1_enable_write is prior to writing parameters, the internal reflection process operates first. Address as the following: <ul style="list-style-type: none"><li>Put com_u1_enable_write on the last line.</li><li>Write com_u1_enable_write twice or toggle write</li></ul> |

## 12.2 Frequently asked questions

### 12.2.1 The value of a variable displayed in RMW is abnormal.

When any change is made to the software, it is necessary to register the Map file “src/application/rmw/\*.map” with RMW to update the variable status of the software. If you omit this step, the variable may not display correctly. For details, see 6.5.

## Revision History

| Rev. | Date of issue | Amendments |   |
|------|---------------|------------|---|
|      |               | Page       | Point   |
| 1.00 | May 23, 2023  | -          | First edition issued  |
| 1.10 | Jan 23, 2024  | -          | Added description related to RA8T1  |
| 1.11 | Dec 23, 2024  | -          | Update target software  |
| 1.20 | Sep 2, 2025   |            | <ul style="list-style-type: none"><li>- Added RA8T2</li><li>- Updated chapter titles</li></ul>        |
| 1.21 | Oct 31, 2025  | -          | <ul style="list-style-type: none"><li>- Added RA6T2 ver.2</li><li>- Fixed incorrect entries</li></ul> |

# General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

## 1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

## 2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

## 3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

## 4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

## 5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

## 6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.).

## 7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

## 8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implants; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. **RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.**
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan  
[www.renesas.com](http://www.renesas.com)

## Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:  
[www.renesas.com/contact/](http://www.renesas.com/contact/).