

RH850 Evaluation Platform

RH850/P1M-144-pin PiggyBack board Y-RH850-P1X-144PIN-PB-T1-V1

32

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Technology Corp. website (<http://www.renesas.com>).

The newest version of this document can be obtained from the following web location
<http://www.renesas.eu/updates?oc=Y-RH850-P1X-144PIN-PB-T1-V1>.

Table of Contents

Chapter 1	Introduction	3
Chapter 2	Overview	4
2.1	Overview	4
2.2	Mounting of the device	5
Chapter 3	Power supply	6
3.1	Board power connection	6
3.2	Voltage distribution.....	7
Chapter 4	Clock sources.....	9
4.1.1	MainOsc	9
Chapter 5	Debug and Programming interface	10
Chapter 6	Connectors for ports of device.....	11
6.1	Push button for RESET	11
6.2	Connectors to MainBoard.....	11
6.2.1	Connector CN1.....	11
6.2.2	Connector CN4.....	13
Chapter 7	Precautions.....	15
7.1	Jumper 5 (JP5) Labelling	15
7.2	Capacitance Value of C21.....	15
Chapter 8	Mechanical dimensions	16
Chapter 9	Schematic	17
Chapter 10	Revision History	21

Chapter 1 Introduction

The RH850/P1x Application Board is part of the RH850 Evaluation Platform and serves as a simple and easy to use platform for evaluating the features and performance of Renesas Electronics 32-bit RH850/P1x microcontrollers. The PiggyBack board (Y-RH850-P1X-144PIN-PB-T1-V1) can be used as a standalone board, or can be mated with a mainboard (e.g. Y-RH850-X1X-MB-T1-V1) for extended functionality.

Main features:

- Socket for mounting of device
- Standalone operation of the board
- Direct supply of device voltage (typ. 3.3V/5.0V and 1.25V) enabling single power supply (eVR – **e**mb**e**dded **V**oltage **R**egulator) and **d**ual **p**ower **s**upply (**D**PS)
- Device programming capability
- Device debugging capability
- Pin headers for direct access to each device pin
- Reset switch
- MainOSC circuitry
- Connectors to MainBoard
- Operating temperature from 0°C to +40°C

This document describes the functionality provided by the PiggyBack board and guides the user through its operation.

For details regarding the operation of the microcontroller, refer to the RH850/P1x User Manual.

Chapter 2 Overview

2.1 Overview

Figures 1 and 2 provide the views of the PiggyBack board.




Figure 1 – PiggyBack Board Top View

The arrow denotes the position of device pin #1




Figure 2 – PiggyBack Board Bottom View

2.2

Mounting of the device

The board is designed for use with the following device:

RH850/P1M-144-pin, 0.4 pin pitch.

The device must be placed inside the socket IC1. To insert the device, press down the lid, align the #1 pin of the device to the #1pin of the socket, insert the device inside the socket and release the lid.

Chapter 3 Power supply

3.1 Board power connection

For operation of the device, a supply voltage must be connected to the board. There are several possibilities to power the device.

Within this document the following voltages are considered as 'typical' connections:

Voltage1 = 5.0V

Voltage2 = 3.3V

Voltage3 = 1.25V

Direct voltage supply

Three different voltages can be supplied to the board.

The following connectors are available to supply those voltages directly:

- Four 4mm 'banana-type' connectors:
 - Three red connectors for voltages *Voltage1* (CN21), *Voltage2* (CN23) and *Voltage3* (CN 24).
 - A black connector for ground (GND) connection (CN22).**Note:** The four connectors are supplied with the board but not assembled.
- Both devices, eVR and DPS, can be supplied by direct voltage supply

For details about voltage distribution, refer to **Chapter 3.2 'Voltage distribution'**.

Supply by MainBoard

In case the PiggyBack board is mounted on a MainBoard, the voltages *Voltage1* and *Voltage2* are supplied by the on-board regulators of the MainBoard.

CAUTION: Do not supply any voltage directly to the PiggyBack board in case it is mounted on the MainBoard.

For each of the voltages, *Voltage1*, *Voltage2* and *Voltage3* a green LED is available to signal that the related voltage is available on the PiggyBack board. The corresponding LEDs are placed directly beneath the connectors of the related voltage.

3.2 Voltage distribution

The table shows the required device power supply pins and their function:

Device supply pin	Function
VCC	Supply for the device internal regulators and digital logic.
VDD	Supply for core power (only DPS).
VCL	Capacitance connection pin for the on-chip regulator (only eVR).
EVCC	Supply for ports.
AnVCC	Supply for ADCn (n = 0, 1).
AnVREFH	Reference voltage for ADCn (n = 0, 1).

Additional one power supply for the MainBoard can be selected:

Supply voltage	Function
VDDIOF	IO supply voltage for components located on a connected mainboard.

The following figure shows the configurable voltage distribution on the PiggyBack board.




Figure 3 – Voltage Distribution on the PiggyBack Board

- All power supply lines can be interrupted by jumpers (JP0, JP4 and JP5). This provides the possibility to measure the current consumption of the device.
Note: The jumpers (JP0, JP4 and JP5) must be connected even if the device is powered by a connected MainBoard. Please refer also to the caution regarding settings for JP5 below.
- The voltage source for VCC, EVCC and AnVCC/AnVREFH can be selected from *Voltage1* (typ. 5.0V) or *Voltage2* (typ. 3.3V) by the jumpers JP1, JP2 and JP3.

-
- The IO supply voltage for the Mainboard (VDDIOF) can be connected via jumper JP7 to the same voltage supply as for EVCC, if the PiggyBack board is mounted on a MainBoard.
 - In case of a DPS device, VDD can be powered either directly from the 'banana-type' connector (*Voltage3*) or by an on-board voltage regulator. Thereby even a DPS device can be operated with one single voltage supply (*Voltage1* or *Voltage2*). The source for VDD is selectable by JP5.
 - The function of device pin #142 depends on the device type. It is either VDD or VCC for DPS and eVR devices, respectively. For more details, refer to the RH850/P1x User Manual. The voltage supply type can be configured by jumper JP6.
 - The LED indicating availability of *Voltage3* is controlled by jumper JP8 (not shown in Figure 3, for details refer to **Chapter 9 'Schematic'**).
Note: The jumper JP8 must be configured same as jumper JP5.

CAUTION: Jumper JP5 must not be connected in case of an eVR device. Therefore the pin header for JP5 is only provided with the board but not assembled.

Chapter 4 Clock sources

One external crystal oscillator for the device clock supply is provided with the board.

4.1.1 MainOsc

A crystal or ceramic resonator with 16MHz operating frequency can be mounted on socket X1.

A 16Mhz oscillator is supplied with the board.

Chapter 5 Debug and Programming interface

For connection of the microcontroller debug and flash programming tools, the connector CN25 with fourteen pins is provided.

The signal connection of the connector CN25 is shown in the table below:

CN25 pin	Device Port	Device signal
1	JP0_2	DCUTCK / LPDCLK / FLSCI3SCKI
2	GND	GND
3	JP0_4	$\overline{\text{DCUTRST}}$
4	FLMD0	FLMD0
5	JP0_1	DCUTDO / LPDO / FLSCI3TXD
6	-	-
7	JP0_0	DCUTDI / LPDIO / LPDI / FLSCI3RXD / FLSCI3TXD
8	'Dbg_Voltage'	EVCC
9	JP0_3	DCUTMS
10	-	-
11	JP0_5	$\overline{\text{DCUTRDY}}$ / LPDCLKOUT
12	GND	-
13	RESET	$\overline{\text{RESET}}$
14	GND	-

Chapter 6 Connectors for ports of device

Connection to each pin of the device is possible via the connectors CN5 to CN8.

CAUTION: The pin headers are directly connected to the pins of the device, therefore special care must be taken to avoid any electrostatic or other damage to the device.

6.1 Push button for RESET

In order to issue a RESET to the device, the push-button SW1 is available.

6.2 Connectors to MainBoard

Up to four connectors (CN1 to CN4) are available to connect the PiggyBack board to a MainBoard.

CN2 is mounted on the PiggyBack board to enable a stable mechanical connection to the currently available MainBoard (Y-RH850-X1X-MB-T1-V1). No connections are available from the device to CN2.

The signal connection of each connector is described in the following tables.

6.2.1 Connector CN1

Pin	Function on MainBoard	Device Port		Pin	Function on MainBoard	Device Port
1	VOLTAGE1	-		2	VOLTAGE1	-
3	VOLTAGE1	-		4	VOLTAGE1	-
5	RESET	$\overline{\text{RESET}}$		6	NMI	P3_14
7	WAKE	-		8	-	-
9	INT0	P3_4		10	INT1	P2_5
11	INT2	P3_7		12	INT3	P3_12
13	-	-		14	-	-
15	UART0TX	-		16	UART1TX	-
17	UART0RX	-		18	UART1RX	-
19	LIN0TX	P3_5		20	LIN1TX	P2_4
21	LIN0RX	P3_4		22	LIN1RX	P2_5
23	IIC0SDL	-		24	IIC1SDL	-
25	IIC0SDA	-		26	IIC1SDA	-
27	CAN0TX	P2_1		28	CAN1TX	P3_13
29	CAN0RX	P2_0		30	CAN1RX	P3_12
31	SENTIN0	P5_14		32	SENTIN1	P0_1
33	SENTOUT0	P0_0		34	SENTOUT1	P3_11
35	PSI50Rx	P5_14		36	PSI51Rx	P5_9
37	PSI50Tx	P0_0		38	PSI51Tx	P5_10
39	PSI50Ssync	-		40	PSI51Sync	-
41	FLX0TX	P4_0		42	FLX0EN	P4_1
43	FLX0RX	P4_2		44	-	-

Pin	Function on MainBoard	Device Port		Pin	Function on MainBoard	Device Port
45	FLX1TX	P4_5		46	FX1EN	P4_6
47	FLX1RX	P4_3		48	-	-
49	-	-		50	-	-
51	ETH0MDIO	-		52	ETH0MDC	-
53	ETH0RXD0	-		54	EH0TXD0	-
55	ETH0RXD1	-		56	EH0TXD1	-
57	ETH0RXD2	-		58	EH0TXD2	-
59	ETH0RXD3	-		60	EH0TXD3	-
61	ETH0RXDCLK	-		62	ETH0TXCLK	-
63	ETH0RXER	-		64	ETH0TXER	-
65	ETH0CRSDV	-		66	ETH0TXEN	-
67	ETH0RXDV	-		68	ETH0COL	-
69	ETH0RESET	-		70	-	-
71	-	-		72	-	-
73	USB0UDMF	-		74	USB0UDMH	-
75	USB0UDPF	-		76	USB0UDPH	-
77	-	-		78	-	-
79	-	-		80	-	-
81	-	-		82	-	-
83	-	-		84	-	-
85	DIGIO_0	P5_8		86	DIGIO_1	P0_2
87	DIGIO_2	P0_13		88	DIGIO_3	P1_1
89	DIGIO_4	P1_2		90	DIGIO_5	P1_3
91	DIGIO_6	P1_4		92	DIGIO_7	P2_3
93	DIGIO_8	P2_6		94	DIGIO_9	P2_7
95	DIGIO_10	P2_8		96	DIGIO_11	P2_9
97	DIGIO_12	P3_3		98	DIGIO_13	P3_6
99	DIGIO_14	P3_9		100	DIGIO_15	P3_10
101	-	-		102	-	-
103	MUX0	-		104	MUX1	-
105	MUX2	-		106	-	-
107	ADC0	ADCA0I7		108	ADC1	ADCA0I6
109	ADC2	ADCA0I5		110	ADC3	ADCA0I4
111	ADC4	ADCA0I3		112	ADC5	ADCA0I2
113	ADC6	ADCA0I1		114	ADC7	ADCA0I0
115	VDDIOF	-		116	VDDIOF	-
117	VOLTAGE2	-		118	VOLTAGE2	-
119	VOLTAGE2	-		120	VOLTAGE2	-

6.2.2

Connector CN4

The here described functions are not available on the currently available Mainboard (Y-RH850-X1X-MB-T1-V1). They are reserved for a future update.

Pin	Function on MainBoard	Device Port	Pin	Function on MainBoard	Device Port
1	VOLTAGE 3	-	2	VOLTAGE 3	-
3	VOLTAGE 3	-	4	VOLTAGE 3	-
5	ERROROUT	$\overline{\text{ERROROUT}}$	6	CVMOUT	$\overline{\text{CVMOUT}}$
7	-	-	8	-	-
9	ENC0 A	P4_0	10	ENC0 B	P4_1
11	ENC0 Z	P4_2	12	ENC1 A	P4_4
13	ENC1 B	P4_5	14	ENC1 Z	P4_6
15	Hi-Z control 0	P3_14	16	Hi-Z control 1	P0_2
17	-	-	18	-	-
19	TAUD0ch0	P3_5	20	TAUD0ch1	P5_0
21	TAUD0ch2/3	P5_1	22	TAUD0ch4/5	P5_4
23	TAUD0ch6/7	P5_5	24	TAUD0ch8/9	P5_6
25	TAUD0ch10/11	P5_7	26	TAUD0ch12/13	P5_8
27	TAUD0ch14/15	P5_9	28	-	-
29	TAUD1ch0/1	P2_11	30	TAUD1ch2/3	P2_12
31	TAUD1ch4/5	P2_13	32	TAUD1ch6/7	P2_14
33	TAUD1ch8/9	P2_15	34	TAUD1ch10/11	P3_0
35	TAUD1ch12/13	P3_1	36	TAUD1ch14/15	P3_2
37	-	-	38	-	-
39	-	-	40	-	-
41	-	-	42	-	-
43	TSG30STOut	P2_2	44	TSG30PWMOut1	P2_3
45	TSG30PWMOut2	P2_5	46	TSG30PWMOut3	P2_6
47	TSG30PWMOut4	P2_7	48	TSG30PWMOut5	P2_8
49	TSG30PWMOut6	P2_9	50	TSG30HSensIn0	P4_0
51	TSG30HsensIn1	P4_1	52	TSG30HsensIn2	P4_2
53	TSG31STOut	P3_6	54	TSG31PWMOut1	P3_7
55	TSG31PWMOut2	P3_8	56	TSG31PWMOut3	P3_9
57	TSG31PWMOut4	P3_10	58	TSG31PWMOut5	P3_12
59	TSG31PWMOut6	P3_13	60	TSG31HSensIn0	P4_4
61	TSG31HsensIn1	P4_5	62	TSG31HsensIn2	P4_6
63	-	-	64	-	-
65	TPBOut	P2_2	66	-	-
67	-	-	68	-	-
69	CSIH0SI	P2_4	70	CSH0CLK	P2_6
71	CSIH0SO	P2_5	72	CSIH0CSS0	P2_7
73	CSIH0CSS1	P2_8	74	-	-
75	CSIH1SI	P2_7	76	CSIH1CLK	P2_9
77	CSIH1SO	P2_8	78	-	-


Pin	Function on MainBoard	Device Port		Pin	Function on MainBoard	Device Port
79	-	-		80	-	-
81	ADC1-0	ADCA1I0		82	ADC1-1	ADCA1I1
83	ADC1-2	ADCA1I2		84	ADC1-3	ADCA1I3
85	ADC1-4	ADCA1I4		86	ADC1-5	ADCA1I5
87	ADC1-6	ADCA1I6		88	ADC1-7	ADCA1I7
89	ADC1-8	ADCA1I8		90	ADC1-9	ADCA1I9
91	ADC1-10	ADCA1I10		92	ADC1-11	ADCA1I11
93	-	-		94	-	-
95	-	-		96	-	-
97	-	-		98	-	-
99	-	-		100	-	-
101	-	-		102	-	-
103	-	-		104	-	-
105	-	-		106	-	-
107	-	-		108	-	-
109	-	-		110	-	-
111	-	-		112	-	-
113	-	-		114	-	-
115	-	-		116	-	-
117	-	-		118	-	-
119	-	-		120	-	-

Chapter 7 Precautions

7.1 Jumper 5 (JP5) Labelling

Description

The labelling of JP5 is wrong on the PiggyBack board (EESS-0402-085-01).



As depicted in the figure above, the two jumper options are inverted. This issue is only valid if JP5 is assembled and used to configure voltage supply for DPS devices.

Workaround

When configuring JP5 for DPS devices, jumper option “REG1V25” has to be chosen to apply the voltage from CN24 and vice versa.

7.2 Capacitance Value of C21


Description

The value of C21 is 10nF on the PiggyBack board (EESS-0402-085-01), which causes RESETZ release after power-up that is not compliant to the specification of P1M.


Workaround

If troubles are detected related to the RESET release timing of the microcontroller, the capacitance value can be exchanged by a bigger value. Please refer to Chapter 9 Schematic, section “Push Button for Reset”.

The below figure shows the position of the capacitor C21 (red circle) on the top side of the PiggyBack board.



Chapter 8 Mechanical dimensions



Chapter 9 Schematic

CAUTION: *The schematic shown in this document is not intended to be used as a reference for mass production. Any usage in an application design is in sole responsibility of the customer.*

The following components described in the schematic are not provided with the board:

- Mainboard connector CN3

The following components described in the schematic are provided with but not mounted on the board:

- Standard 4mm power lab sockets
 - CN21
 - CN22
 - CN23
 - CN24
- Jumper JP5



[illegible]

Chapter 10 Revision History

The table provides information about the major changes of the document versions.

Date	Version	Description
2013-09-03	1.0	Initial release
2015-03-19	1.1	- Added product name of the board as subtitle to cover page - Added link to download page to the cover page - Sec. 6.2.2: Added note that CN4 signals are reserved. - Added precaution sec. 7.2 - Chapter 9: Added caution and note regarding devices not provided or mounted. Updated schematic.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics.

The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.

8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.

-
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



Renesas Electronics Corporation
www.renesas.com