

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

# Application Note

## 78K0S/Kx1+

### Sample Program

### Startup Guide

This document describes how to download and install the development environment required for using sample programs and how to use the sample programs.

#### Target devices

- 78K0S/KA1+ microcontroller
- 78K0S/KB1+ microcontroller
- 78K0S/KU1+ microcontroller
- 78K0S/KY1+ microcontroller

#### CONTENTS

<b>PREFACE</b> .....	<b>3</b>
<b>CHAPTER 1 PREPARING DEVELOPMENT ENVIRONMENT</b> .....	<b>4</b>
1.1 Relation Between the Development Procedure and the Development Tools .....	4
1.2 Configuration of Development Environment .....	5
<b>CHAPTER 2 PREPARING SAMPLE PROGRAMS</b> .....	<b>6</b>
2.1 Downloading Sample Programs .....	6
2.2 File Configuration .....	8
<b>CHAPTER 3 REGISTERING INTEGRATED DEVELOPMENT ENVIRONMENT PM+ PROJECTS AND EXECUTING BUILD</b> .....	<b>9</b>

3.1 Project Registration .....	9
3.1.1 Project registration (only source files) .....	9
3.1.2 Project registration (source files and project file) .....	15
3.2 Executing Build .....	17
<b>CHAPTER 4 OPERATION CHECK USING SYSTEM SIMULATOR SM+</b> .....	<b>19</b>
4.1 Starting SM+ .....	19
4.1.1 SM+ start screen (only source files) .....	20
4.1.2 SM+ start screen (source files and project file) .....	21
4.1.3 Opening a simulation file (only source files) .....	22
4.2 Simulation .....	24
<b>CHAPTER 5 MAIN SM+ FUNCTIONS</b> .....	<b>27</b>
5.1 [Source] Window .....	27
5.2 [Timing Chart] Window .....	31
5.3 [I/O Panel] Window .....	35
5.4 [Assemble] Window .....	37
5.5 [Memory] Window .....	40
5.6 [Watch] Window .....	42
5.7 [Register] Window .....	44
5.8 [SFR] Window .....	47
<b>CHAPTER 6 RELATED DOCUMENTS</b> .....	<b>51</b>
<b>APPENDIX REVISION HISTORY</b> .....	<b>52</b>

Document No. U18787EJ2V0AN00 (2nd edition)  
 Date Published September 2008 N

Windows is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

- **The information in this document is current as of July, 2008. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.**

- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.

- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.

- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.

- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.

- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

## PREFACE

### Target Readers


This manual is intended for customers using sample programs for the first time as well as customers using the 78K0S/Kx1+ microcontroller development tools for the first time. To use the development tools, basic knowledge on how to operate Windows™ is required.

### Purpose

This manual is intended for customers to understand how to use sample programs and the basic operation of the 78K0S/Kx1+ microcontroller development tools. A deeper understanding of how to use sample programs and the basic operation of the development tools can be obtained when the tools are actually operated while reading this manual.

### Organization

This manual consists of the following chapters.




The descriptions in chapter 2 and the following chapters use the sample program (initial setting) for the 78K0S/KB1+ microcontroller as an example.

# CHAPTER 1 PREPARING DEVELOPMENT ENVIRONMENT

This chapter describes the preparation of the development environment.

## 1.1 Relation Between the Development Procedure and the Development Tools

The following figure shows the development procedure and development tools.



To check the operation of a sample program, the development tools in the shaded ovals are used.

## 1.2 Configuration of Development Environment

To check the operation of a sample program, the following development tools must be installed.

**(1) Device file**

This file contains device-specific information. It is used in combination with each tool (CC78K0S, RA78K0S, SM+ for 78K0S/Kx1+).

**(2) CC78K0S (C compiler)**

This is a highly versatile and portable C compiler developed for coding embedded control programs for the 78K0S microcontroller in C language. PM+ is required to operate CC78K0S on Windows.

**(3) RA78K0S (assembler)**

RA78K0S generates an execution code that can be executed from the assembler source program using the 78K0S microcontroller. PM+ is required to operate RA78K0S on Windows.

**(4) PM+ (integrated development environment)**

This is an integrated development environment to be used on Windows. It enables efficient development by operating in combination with development tools, such as editors, compilers, and debuggers.

**(5) SM+ for 78K0S/Kx1+ (system simulator)**

SM+ for 78K0S/Kx1+ simulates the execution code created for the 78K0S/Kx1+ microcontroller, on the host PC.

To obtain the above tools, contact your sales representative.

## CHAPTER 2 PREPARING SAMPLE PROGRAMS

This chapter describes the preparation of the sample programs.

### 2.1 Downloading Sample Programs

The sample programs for the 78K0S/Kx1+ microcontroller can be obtained from the following Web site.

→ [http://www.necel.com/micro/en/designsupports/sampleprogram/78k0s/low\\_pin\\_count/index.html](http://www.necel.com/micro/en/designsupports/sampleprogram/78k0s/low_pin_count/index.html)

<78K0S/KB1+ microcontroller sample program (initial setting)>

Product	Title	Lang	Date	PDF ?	source ?	Prj ?	SM+ ?
78K0S/KB1+	Initial Setting (LED Lighting Switch Control) <small>Comment</small>	ASM	Dec. 14 2007 Rev. 1.00	(1.6MB)	(3KB)	(8KB)	(1KB)
78K0S/KB1+	Initial Setting (LED Lighting Switch Control) <small>Comment</small>	C	Dec. 14 2007 Rev. 1.00	(1.6MB)	(2KB)	(7KB)	(1KB)

Application Note  
(\* .pdf)




Only source files  
(\* .zip)

Include files to be used  
with PM+ as well as  
SM+ for 78K0S/Kx1+  
(\* .zip)




Include microcontroller  
operation simulation  
files to be used with  
SM+ for 78K0S/Kx1+  
(\* .zip)



Click  to open a PDF file (Application Note).

Click , ,  to launch the download dialog box of a compressed file. Click the [Save] button to save the file to a desired location. Decompress the file after saving it.

<Downloading and decompressing a sample program (compressed file)>



Right-click and select [Extract All] from the pull-down menu.



Decompress the file in accordance with the following dialog boxes.

## 2.2 File Configuration

The following files can be downloaded from among the files listed in the table of sample programs.



Application Note (PDF file)



Only the source file is included (ZIP file). ⇒ <Procedure [3.1.1](#) → [3.2](#) → [4.1.1](#) → [4.1.3](#) → [4.2](#)>



The files to be used with integrated development environment PM+ and system simulator SM+ for 78K0S/Kx1+ are included (ZIP file). ⇒ <Procedure [3.1.2](#) → [3.2](#) → [4.1.2](#) → [4.2](#)>



The microcontroller operation simulation file to be used with system simulator SM+ for 78K0S/Kx1+ is included (ZIP file). ⇒ <Procedure [4.1.3](#)>

The configuration of the files to be downloaded is as follows.

File Name	Description	PDF (*.pdf) File	Compressed (*.zip) File Included		
UxxxxxxxxxANxx.pdf	Application Note of sample program	●			
main.asm (Assembly language version) ----- main.c (C language version)	Source file for hardware initialization processing and main processing of microcontroller		● Note 1	● Note 1	
op.asm	Assembler source file for setting the option byte (sets the system clock source)		●	●	
xxx.prw	Work space file for integrated development environment PM+			●	
xxx.prj	Project file for integrated development environment PM+			●	
xxx.pri xxx.prs xxx.prm	Project file for system simulator SM+ for 78K0S/Kx1+			● Note 2	
xxx.pnl	I/O panel file for system simulator SM+ for 78K0S/Kx1+ (used for checking peripheral hardware operations)			● Note 2	●
xxx0.wvo	Timing chart file for system simulator SM+ for 78K0S/Kx1+ (used for checking waveforms)			<b>Note 3</b>	●

- Notes**
1. “main.asm” is included with the assembly language version, and “main.c” with the C language version.
  2. SM+ for 78K0S/Kx1+ is not supported with the 78K0S/KU1+ microcontroller (as of July, 2008). It is therefore not included with the 78K0S/KU1+ microcontroller.
  3. This compressed file (source files + project file) does not include “xxx0.wvo”, but it need not be additionally downloaded, because the timing chart itself is saved into the project file.

## CHAPTER 3 REGISTERING INTEGRATED DEVELOPMENT ENVIRONMENT PM+ PROJECTS AND EXECUTING BUILD


This chapter describes how to register integrated development environment PM+ projects and how to execute build, using the 78K0S/KB1+ microcontroller sample program (initial setting) as an example. A project must be registered before executing build in PM+.

**Remark** For the details of how to operate PM+, refer to the [PM+ Project Manager User's Manual](#).


### 3.1 Project Registration

The project registration method varies, depending on the file to be downloaded.

#### 3.1.1 Project registration (only source files)

This section describes how to register a project, using the assembly language source file that has been downloaded by clicking the  icon of the 78K0S/KB1+ microcontroller sample program (initial setting).

- (1) Start PM+.
- (2) Select [New Workspace] from the [File] menu.



- (3) The [New WorkSpace - Step 1/9 [Workspace Information]] dialog box will be displayed. Set the following items.

**(a) Workspace File Name**

Specify the name of the file to which the workspace information is to be saved. (In the example shown below, the file name is entered as "initial".)

**(b) Folder**

Specify the folder in which the workspace file and project file are to be saved. Click the [Browse] button to open the [Browse for Folder] dialog box and specify any folder. (In the example below, the arbitrarily created "work" folder under the default folder ("bin" folder in which PM+ is located) is specified.)

**(c) Project Group Name**

Specify the name of the project group to be displayed on the Project window. (In the example below, the group name is entered as "Initialization".)


**(d) Microcontrollers Name**

To use the 78K0S/Kx1+ microcontroller sample program, select “78K0S” from the drop-down list displayed by clicking [▼].

**(e) Device Name**

Select the sample program of the product to be used. Select from the drop-down list displayed the name of the device to be used, by clicking [▼]. (In the example below, the 78K0S/KB1+ microcontroller product “uPD78F9232” is selected.)


After setting items (a) to (e), click the [Next] button.



(4) The [New WorkSpace - Step 2/9 [Select Tools]] dialog box will be displayed. Set the tool versions in the order of the following procedure.

- <1> Click the [Detail Setting] button.
- <2> The [Tool Version Detail Setting] dialog box will be displayed. Set the RA78K0S version to W2.00 or later and click the [OK] button.<sup>Note</sup>
- <3> The tools and their versions selected in step <2> will be set. Click the [Next] button.

**Note** To use the C language source file, set the CC78K0S version to W2.01 or later.




(5) The [New Workspace - Step 7/9 [Setup Source Files]] dialog box will be displayed. Set the source files in the order of the following procedure.


<1> Click the [Add] button.

<2> The [Add Source Files] dialog box will be displayed. Select the source files and click the [Open] button. (In the example below, "main.asm" and "op.asm" are selected from the location where the files have been decompressed in [CHAPTER 2 PREPARING SAMPLE PROGRAMS](#), and the [Open] button is clicked.)

<3> The source files selected in step <2> will be specified. Click the [Next] button.




(6) The [New Workspace - Step 8/9 [Select Debugger]] dialog box will be displayed. Click the [Next] button.




Click

(7) The [New Workspace - Step 9/9 [Confirmation]] dialog box will be displayed. Confirm the settings and click the [Finish] button.




Click

- (8) A workspace will be created and the project will be registered. Perform build operation after project registration. (Refer to [3.2 Executing Build](#).)




- (9) To save the information of the currently opened workspace and project with the same file name, do so in the following manner.
- Select [Save Workspace] from the [File] menu (to save the workspace while it is kept opened).
  - Select [Close Workspace] from the [File] menu (to close and save the workspace).
  - Select [Exit PM+] from the [File] menu (to terminate PM+ after saving the workspace).

- Remarks 1.** After starting PM+ for the second time, PM+ is set to automatically start the previous project by default when PM+ is started.
- 2.** After project registration, the following settings can be changed by selecting [Project Settings] from the [Project] menu.
- Changing the project title (In the example below, "Initialization" is changed to "C".)
  - Changing the device file (In the example below, "uPD78F9232" is changed to "uPD78F9234".)
  - Adding and deleting source files (In the example below, "main.asm" is changed to "main.c".)
  - Setting the tools and their versions







### 3.1.2 Project registration (source files and project file)

This section describes how to register a project, using the assembly language sample program (source program + project file) that has been downloaded by clicking the  icon of the 78K0S/KB1+ microcontroller sample program (initial setting).


- (1) Start PM+.
- (2) Select [Open Workspace] from the [File] menu.




- (3) The [Open Workspace] dialog box will be opened. Select a workspace file (\*.prw) and click the [Open] button. (In the example below, "initial.prw" is selected from the location where the files have been decompressed in [CHAPTER 2 PREPARING SAMPLE PROGRAMS](#), and the [Open] button is clicked.)



- (4) The project will be registered. After project registration, check the device file set by default and change the setting as required. Select [Project Settings] from the [Project] menu.



- (5) The [Project Settings] dialog box will be displayed. The device with the largest ROM or RAM size (“uPD78F9234” in the example below) is set as the Device Name by default. Select the device name to be used (“uPD78F9232” in the example below) and click the [OK] button.




- (6) The device file will be changed. After changing the device file, perform build operation. (Refer to [3.2 Executing Build.](#))
- (7) To save the information of the currently opened workspace and project with the same file name, do so in the following manner.
- Select [Save Workspace] from the [File] menu (to save the workspace while it is kept opened).
  - Select [Close Workspace] from the [File] menu (to close and save the workspace).
  - Select [Exit PM+] from the [File] menu (to terminate PM+ after saving the workspace).

**Remarks 1.** After starting PM+ for the second time, PM+ is set to automatically start the previous project by default when PM+ is started.

**2.** After project registration, the following settings can be changed by selecting [Project Settings] from the [Project] menu.

- Changing the project title
- Changing the device file
- Adding and deleting source files
- Setting the tools and their versions

For details, refer to [Remark 2 in 3.1.1](#). (Refer to [\(4\) to \(6\) in 3.1.2](#) when only changing the device files.)

 [Column] Tab width in a source program

The source of a sample program is set to be easy to view when the tab width is set to eight characters. It is recommended to change the setting by the following procedure, because with PM+ the tab width is set to four characters by default.

<1> Select [PM+ Settings] from the PM+ [Tool] menu.


<2> The PM+ Settings dialog box will be displayed. Click the [View] tab.

<3> Set [Memorize number of Tab characters each Window] to “8” and click the [OK] button.

### 3.2 Executing Build


After performing the settings described in 3.1.1 or 3.1.2, execute build by clicking the buttons on the build bar.

When build is executed, a HEX file (\*.hex) is created in the folder in which the workspace file (\*.prw) is located. If a programming environment is available, the HEX file can be written to the microcontroller flash memory.



#### (a) [Build] button ( )


Click the [Build] button to execute build. When the source files are built normally, the message "I3500: Build completed normally." will be displayed. Click the [OK] button.



[4.1 Starting SM+](#)

**(b) [Rebuild] button (  )**


Click the [Rebuild] button to execute rebuild. When the source files are rebuilt normally, the message “I3500: Build completed normally.” will be displayed. Click the [OK] button.

**[Column] Build errors**

Change the compiler option setting according to the following procedure when the error message “A006 File not found ‘C:\NECTOOLS32\LIB78K0S\s0sl.rel’” or “\*\*\* ERROR F206 Segment ‘@@@DATA’ can’t allocate to memory - ignored.” is displayed, when building with PM+.

- <1> Select [Compiler Options] from the [Tool] menu.
- <2> The [Compiler Options] dialog box will be displayed. Select the [Startup Routine] tab.
- <3> Uncheck the [Using Fixed Area of Standard Library] check box. (Leave the other check boxes as they are.)

A RAM area of 118 bytes that has been secured as a fixed standard library area will be enabled for use when the [Using Fixed Area of Standard Library] check box is unchecked; however, the standard libraries (such as the getchar function and malloc function) will be disabled for use.

The [Using Fixed Area of Standard Library] check box is unchecked by default when the file that has been downloaded by clicking the  icon is used in this sample program.

## CHAPTER 4 OPERATION CHECK USING SYSTEM SIMULATOR SM+

This chapter describes how a sample program operates with system simulator SM+ for 78K0S/Kx1+, using the 78K0S/KB1+ microcontroller sample program (initial setting) as an example.

**Caution** SM+ for 78K0S/Kx1+ is not supported with the 78K0S/KU1+ microcontroller (as of July, 2008). The operation of the 78K0S/KU1+ microcontroller therefore cannot be checked with SM+ for 78K0S/Kx1+.

### 4.1 Starting SM+

When SM+ for 78K0S/Kx1+ W1.02 (hereinafter "SM+") is used in an environment of PM+ Ver. 6.30, SM+ cannot be selected as the debugger. In this case, start SM+ using method (a) or (b) described below, while keeping PM+ running after building a project has been completed.

#### (a) When starting SM+ in PM+

- <1> Select [Register Ex-tool] from the [Tool] menu and register "SM+ for 78K0S/Kx1+".
  - <2> Select [Ex-tool Bar] from the [View] menu to display the SM+ icon on the PM+ toolbar.
  - <3> Start SM+ by clicking the SM+ icon.
- (See the PM+ help for details of how to register external tools.)


#### (b) When not starting SM+ in PM+

- Start SM+ from the Windows start menu.

When SM+ is started, the start screen differs depending on the downloaded file.


#### 4.1.1 SM+ start screen (only source files)

(1) When SM+ is started, the [Configuration] dialog box will be opened. Click the [OK] button.




**Remark** Set the clock frequency and other settings in the [Configuration] dialog box, depending on the program. Such settings are not required in the sample program (initial setting) example shown above, because a high-speed internal oscillator is used.

(2) The message “Wf700: Do you want to download Load Module File?” will be displayed. Click the [Yes] button.





(3) The Main window of SM+ will be displayed.



[4.1.3 Opening a simulation file \(only source files\)](#)

**4.1.2 SM+ start screen (source files and project file)**


When SM+ is started, the Main window ([Source] window + simulation windows) will be displayed.



[4.2 Simulation](#)

### 4.1.3 Opening a simulation file (only source files)

When only source files are downloaded (by clicking ) , only the [Source] window will be opened in the Main window of SM+.

The simulation windows are added in the Main window of SM+ by using a simulation file (downloaded by clicking ) . They are added through the following procedure.

- (1) Select [Open] from the [Simulator] menu to open the dialog box for selecting a simulation file. Change [Files of type] to "All Files (\*.\*)", select a simulation file, and click the [Open] button. (In the example shown below, "initial0.pnl" and "initial0.wvo" are selected from the location where the files have been decompressed in [CHAPTER 2 PREPARING SAMPLE PROGRAMS](#), and the [Open] button is clicked.)


**Caution** Multiple files cannot be selected in the file selection dialog box. When multiple simulation files have been prepared, open the simulation windows by selecting one file at a time.

The figure illustrates the procedure for opening simulation files in SM+. It consists of three main parts:


- Opening the File Selection Dialog:** The 'Simulator' menu is accessed, and 'Open...' is selected. This opens the 'Open' dialog box. The 'Look in:' field shows the folder 'U18752E\_78K0SKB1P\_SM\_0704\_V'. The files 'initial0.pnl' and 'initial0.wvo' are listed. The 'Files of type:' is set to 'All Files (\*.\*)'. The 'File name:' field contains 'initial0.pnl'. Red annotations indicate: 'Select the folder, select the I/O panel file (\*.pnl), and click the [Open] button.'
- Main Window State:** The main SM+ window shows the 'Source' window with assembly code and the 'initial0.pnl' I/O Panel window. A green arrow points to the I/O Panel window with the label '[I/O Panel] window'.
- Opening a Timing Chart File:** The 'Open' dialog box is shown again. This time, 'initial0.wvo' is selected in the file list, and the 'File name:' field contains 'initial0.wvo'. Red annotations indicate: 'Select the folder, select the timing chart file (\*.wvo), and click the [Open] button.'



- (2) The simulation windows will be added in the Main window of SM+. (In the example shown below, the [I/O Panel] window and [Timing Chart] window are added.)




[4.2 Simulation](#)


**Remark** When source files and a project file have been downloaded (by clicking ) , the simulation windows will be automatically opened in the Main window of SM+ which is started after build execution, because an SM+ simulator file has been prepared in advance.

## 4.2 Simulation

This section confirms how the 78K0S/KB1+ microcontroller sample program (initial setting) operates, by using the SM+ simulation functions.


**Remark** For the details of how to operate SM+, refer to the [SM+ System Simulator Operation User's Manual](#).

- (1) Click  ([Restart] button). The program will be executed after the CPU is reset and the following screen will be displayed.




- (2) Click the [SW1] and [SW2] buttons in the [I/O Panel] window, during program execution. Check the lighting of [LED1] to [LED3] in the [I/O Panel] window, as well as the waveforms in the [Timing Chart] window change, depending on the combination of the [SW1] and [SW2] buttons.


Example 1. SW1: ON, SW2: OFF




Example 2. SW1: OFF, SW2: ON



Example 3. SW1: ON, SW2: ON




Example 4. SW1: OFF, SW2: OFF



**Remark** H: High level, L: Low level

[Supplement] The changes in the data values of ports 2 and 4 can be checked by using the SM+ watch function (refer to 5.6 [Watch] Window).

- <1> Select [Watch] from the [Browse] menu to open the [Watch] window.
- <2> Click [Add] to open the [Add Watch] window. (At this time, the [Watch] window is kept opened.)
- <3> Enter "P4" in the [Name] field and click the [Add] button to register "P4" in the [Watch] window. (At this time, the [Add Watch] window is kept opened.)
- <4> Next, enter "P2" in the [Name] field and click the [OK] button to register "P2" in the [Watch] window and close the [Add Watch] window.



<5> Execute the program and click the [SW1] and [SW2] buttons in the [I/O Panel] window. Check that the data values of P2 and P4 in the [Watch] window change, depending on the combination of the [SW1] and [SW2] buttons.

Combination of SW1 and SW2	Data Value in [Watch] Window
SW1: ON, SW2: OFF	P2: 0x06, P4: 0x08
SW1: OFF, SW2: ON	P2: 0x05, P4: 0x01
SW1: ON, SW2: ON	P2: 0x03, P4: 0x00
SW1: OFF, SW2: OFF	P2: 0x07, P4: 0x09


## CHAPTER 5 MAIN SM+ FUNCTIONS

This chapter describes the main functions of the SM+ windows.

**Remark** For the details of how to operate SM+, refer to the [SM+ System Simulator Operation User's Manual](#).


### 5.1 [Source] Window

This window is used to display source files or text files.




#### (a) Point mark area

This area is used for the event setting status and program code display, as well as breakpoint setting. A breakpoint can be set by clicking the asterisk (“\*”) of the location to which it is to be set.



**(b) Current PC mark area**

The “>” mark, which indicates the current PC value (PC register value), is displayed in this area. By double-clicking this area, the user program can be executed up to the double-clicked line.



**(c) Line number/address display area**

This area displays the line number of a source file or text file.

**(d) Source text display area**









This area displays source texts and text files.

Yellow indicates the current PC line, and red indicates lines where a valid breakpoint is set.

**(e) Function buttons**

Search...	Searches a character string (opens the [Source Search] dialog box).
<<	Searches forward (upward on screen) for the specified character string.
>>	Searches backward (downward on screen) for the specified character string.
Stop (during a search)	Stops searching.
Watch	Adds contents, such as a selected variable, to the [Watch] window.
Quick...	Temporarily displays the contents, such as a selected variable, in the [Quick Watch] dialog box.
Refresh	Updates the contents of the window with the latest data.
Close	Closes the [Source] window.



Click the following buttons on the toolbar to execute the source program displayed on the [Source] window.

 (Stop)	Stops execution during user program execution. Same function as selecting [Stop] from the [Run] menu.
 (Restart)	Resets the CPU and executes the user program. Same function as selecting [Restart] from the [Run] menu.
 (Go)	Executes the user program from the current PC without resetting the CPU. Same function as selecting [Go] from the [Run] menu.
 (Ignore break point and Go)	Ignores the set breakpoints and executes the user program. Same function as selecting [Ignore break points and Go] from the [Run] menu.
 (Return)	The user program is executed until execution returns. Same function as selecting [Return Out] from the [Run] menu. <b>Caution This command is used for functions described in C language.</b>
 (Step in)	Step execution (executes instructions in the program one by one.) If a function or subroutine is called, its instructions are executed one by one. Same function as selecting [Step In] from the [Run] menu.
 (Next Over)	Next step execution (executes the program, assuming a function/call statement as one step.) If a function or subroutine is called, its instructions are not executed on a step-by-step basis. Same function as selecting [Next Over] from the [Run] menu.
 (CPU Reset)	Resets the CPU. Same function as selecting [CPU Reset] from the [Run] menu.

The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [Source] window. The three main functions that can be selected from the context menu are described next.


<1> Mix

Select [Mix] from the context menu (displayed by right-clicking anywhere on the [Source] window) for a combined display of the source file and the disassembly of the program on the [Source] window.




<2> Add Watch

Select [Add Watch] from the context menu (displayed by right-clicking anywhere on the [Source] window) to open the [Add Watch] dialog box. Specify the data and click the [OK] button in this dialog box to register the specified data in the [Watch] window.



Enter "P2" (P2 register) and click the [OK] button.






<3> Come Here


Select [Come Here] from the context menu (displayed by right-clicking anywhere on the [Source] window) to execute the program, from the address indicated by the current PC register up to the address where the cursor has been placed, after which a break occurs.

While the program is being executed, the break event currently set does not occur.




## 5.2 [Timing Chart] Window


This window displays in the form of a timing chart input signals and output signals for pins.



(a) Pin area

This area displays the names of pins to be displayed in the [Timing Chart] window.


Select [Select Pin] from the context menu (displayed by right-clicking anywhere on the (b) Waveform area), select [Select Pin] from the [Edit] menu, or click the  button on the toolbar to open the [Select Pin] dialog box. Items, such as pin names, can be changed in this dialog box.



**(b) Waveform area**

This area displays as a timing chart the data of the pins specified in the (a) Pin area.


The magnification of the timing chart display can be selected by selecting [Zoom] from the [View] menu or using  $\times 1$  on the toolbar.



**(c) Marker area**





This area displays the headers of markers A and B.

The markers can be set by selecting [Move markerA] and [Move markerB] from the context menu (displayed by right-clicking anywhere on the (b) Waveform area). The placed markers can be dragged to the desired locations.




**(d) Information bar**

This area can be displayed or hidden via the [View] menu or the [Information bar].


 100.00	Displays the time from the simulation start to the marker A location.
 300.00	Displays the time from the simulation start to the marker B location.
 200.00	Displays the time between markers A and B as an absolute value.
 MainClk	Displays the unit of the time information.


The unit of the time information displayed on the Information bar can be changed by selecting [Time Unit] from the [Edit] menu.





### 5.3 [I/O Panel] Window


This window is used to create a pseudo target system. This window is used to display and manipulate connected parts.











Click  on the toolbar or select [Select] from the [Figure] menu to select an object in the [I/O Panel] window.




Click  on the toolbar or select [Simulation Mode] from the [Figure] menu to select an object in the [I/O Panel] window or to simulate the input to a connected part.




The connected parts can be added to the [I/O Panel] window by clicking the following buttons on the toolbar. By double-clicking the connected parts in the [I/O Panel] window, the dialog box opens and the information of the connected parts can be set.


 (Button creation)	Switch A button can be connected to any pin. An input value can be given to the connected pin by clicking the displayed button. Same function as selecting [Button] from [Parts] on the menu bar.
 (Key matrix creation)	A key matrix consists of multiple pins connected in a matrix array, wherein each contact represents a key, and clicking a key results in a specific state. A key matrix can be connected to any pin, and data can be input using multiple keys. Same function as selecting [Key Matrix] from [Parts] on the menu bar.
 (Level gauge creation)	Used for inputting analog data, such as power supply voltage. Any data within a given range can be set. Any value within a specified range can be assigned to a pin connected to an A/D converter. Same function as selecting [Level Gauge] from [Parts] on the menu bar.
 (LED creation)	LED (Light Emitting Diode) An LED can be connected to any pin, and the output from the pin can be indicated by switching the LED on or off. Same function as selecting [LED] from [Parts] on the menu bar.
 (7-segment LED creation)	A product that consists of 7 LEDs configured to represent a numeric figure. When the output from the pin to which the digit signal is assigned is active, the corresponding 7-segment LED switches on or off. Same function as selecting [7-segment LED] from [Parts] on the menu bar.
 (14-segment LED creation)	A product that consists of 14 LEDs configured to represent an alphabetic character. When the output from the pin to which the digit signal is assigned is active, the corresponding 14-segment LED switches on or off. Same function as selecting [14-segment LED] from [Parts] on the menu bar.
 (Matrix LED creation)	A product that consists of multiple LEDs arranged in a matrix array. When the output from the pin to which the digit signal is assigned is active, the corresponding matrix LED switches on or off. Same function as selecting [Matrix LED] from [Parts] on the menu bar.
 (Buzzer creation)	Buzzer A buzzer connected to a pin indicates with a bitmap or buzzer sound the output information from the connected pin. Same function as selecting [Buzzer] from [Parts] on the menu bar.

An example of the display of the connected parts is shown below.



## 5.4 [Assemble] Window

This window is used to display the disassembly of a program. Select [Assemble] from the [Browse] menu or click the  button on the toolbar to open the [Assemble] window.



### (a) Point mark area

This area is used for the event setting status display and breakpoint setting. A breakpoint can be set by clicking the asterisk (“\*”) of the location to which it is to be set.

### (b) Current PC mark area

The “>” mark, which indicates the current PC value (PC register value), is displayed in this area. By double-clicking this area, the user program can be executed up to the double-clicked line.

### (c) Address specification area

This area displays the disassembly start address.

### (d) Disassemble display area

This area displays the labels and code data of addresses, and disassembled mnemonics. Yellow indicates the current PC line, and red indicates lines where a valid breakpoint is set.


### (e) Function buttons

Search...	Searches a character string (opens the [Assemble Search] dialog box).
<<	Searches forward (upward on screen) for the specified character string.
>>	Searches backward (downward on screen) for the specified character string.
Stop (during a search)	Stops searching.
Watch	Adds contents, such as a selected variable, to the [Watch] window.
Quick...	Temporarily displays the contents, such as a selected variable, in the [Quick Watch] dialog box.
Refresh	Updates the contents of the window with the latest data.
Close	Closes the [Assemble] window.

The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [Assemble] window. The three main functions that can be selected from the context menu are described next.

<1> Move


Select [Move] from the context menu (displayed by right-clicking anywhere on the [Assemble] window) to open the [Address Move] dialog box. Specify an address value and click the [OK] button in this dialog box to move the disassembly start address to the specified address value.





<2> Add Watch

Select [Add Watch] from the context menu (displayed by right-clicking anywhere on the [Assemble] window) to open the [Add Watch] dialog box. Specify the data and click the [OK] button in this dialog box to register the specified data in the [Watch] window.




Enter "P2" (P2 register) and click the [OK] button.




<3> Come Here

Select [Come Here] from the context menu (displayed by right-clicking anywhere on the [Assemble] window) to execute the program, from the address indicated by the current PC register up to the address where the cursor has been placed, after which a break occurs.


While the program is being executed, the break event currently set does not occur.




The program is executed up to the address where the cursor is placed, and then a break occurs.



### 5.5 [Memory] Window

This window is used to display memory contents. Select [Memory] from the [Browse] menu or click the  button on the toolbar to open the [Memory] window.




**(a) Address display area**

This area displays memory addresses.

**(b) Memory display area**

This area is used to display and change memory contents.

Memory contents are changed through direct entry. Changes are displayed in red and the contents of the changes are written to the target memory by pressing the Enter key. The previous values can be discarded by pressing the ESC key. Up to 256 bytes can be changed at one time.




(c) Function buttons

Search...	Searches a character string or memory contents (opens the [Assemble Search] dialog box).
<<	Searches forward (upward on screen) for the specified character string or memory contents.
>>	Searches backward (downward on screen) for the specified character string or memory contents.
Stop (during a search)	Stops searching.
Refresh	Updates the contents of the window with the latest data.
Modify...	Rewrites the memory contents during program execution via the [DMM] dialog box.
Close	Closes the [Memory] window.

The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [Memory] window. The three main functions that can be selected from the context menu are described next.


<1> ASCII display

Select [Ascii] from the context menu (displayed by right-clicking anywhere on the [Memory] window) to display the ASCII display area. ASCII characters of the memory contents can be displayed and changed in this area.




<2> Selecting the numbering system display

Select [Bin], [Oct], [Dec], or [Hex] from the context menu (displayed by right-clicking anywhere on the [Memory] window) to change the numbering system display of the memory display area (hexadecimal display by default).





<3> Selecting the display unit

Select [Nibble] (4-bit units), [Byte] (8-bit units), [Word] (16-bit units), or [Double Word] (32-bit units) from the context menu (displayed by right-clicking anywhere on the [Memory] window) to change the display unit of the memory display area (byte display by default).



5.6 [Watch] Window

This window is used to display the shifts in data values registered. Select [Watch] from the [Browse] menu or click the  button on the toolbar to open the [Watch] window.



(a) Symbol name display area

This area is used to display variable names, symbol names and types, and tag names of structures or unions registered in the [Add Watch] dialog box.


(b) Data value display/setting area

This area is used to display and change data values. The values are updated when execution is stopped.

(c) Function buttons

Add...	Rewrites the watch data via the [Add Watch] dialog box.
Delete	Deletes the selected watch data from the window.
Up	Moves the selected line one line up.
Down	Moves the selected line one line down.
Refresh	Updates the contents of the window with the latest data.
Close	Closes the [Watch] window.


An example in which the [Add...] function button is used to register data to the [Watch] window is shown below.




The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [Watch] window. The main function that can be selected from the context menu is described next.


- Selecting the numbering system display  
The data value numbering system can be selected from the context menu (displayed by right-clicking anywhere on the [Watch] window).

Bin	Displays the selected line in binary numbers.
Oct	Displays the selected line in octal numbers.
Dec	Displays the selected line in decimal numbers.
Hex	Displays the selected line in hexadecimal numbers.
String	Displays the selected line as a character string.
Proper (default)	Displays the selected line in accordance with the setting of the [Debugger Option] dialog box (selected from [Debugger Option] in the [Option] menu) (default: hexadecimal).



### 5.7 [Register] Window


This window is used to display registers. Select [Register] from the [Browse] menu or click the  button on the toolbar to open the [Register] window.




**(a) General-purpose register display area**

This area is used to display general-purpose registers.

The plus sign (“+”) indicates a 16-bit register whose display can be expanded. Double-click “+” to display the two register names and register values (“+” changes to “-”). Double click the minus sign (“-”) to cancel the expanded display.




Register values are changed through direct entry. Changes are displayed in red and the contents of the changes are written to the target memory by pressing the Enter key. The previous values can be discarded by pressing the ESC key.




**(b) Control register display area**

This area is used to display control registers.

The plus sign (“+”) indicates a register whose display can be expanded. Double-click “+” to display the flag names and flag values (“+” changes to “-”). Double click the minus sign (“-”) to cancel the expanded display.



Register values are changed through direct entry. Changes are displayed in red and the contents of the changes are written to the target memory by pressing the Enter key. The previous values can be discarded by pressing the ESC key.




**(c) Function buttons**

Refresh	Updates the contents of the window with the latest data.
Close	Closes the [Register] window.

The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [Register] window. The two main functions that can be selected from the context menu are described next.


<1> Add Watch

Select on the window the name of the register to be added, and select [Add Watch] from the context menu (displayed by right-clicking anywhere on the [Register] window) to open the [Add Watch] dialog box. Check that the selected register name is added to the [Name:] column and click the [OK] button to register the specified data in the [Watch] window.




<2> Selecting the numbering system display


Select [Bin], [Oct], [Dec], or [Hex] from the context menu (displayed by right-clicking anywhere on the [Register] window) to change the numbering system display of the [Register] window (hexadecimal display by default).





### 5.8 [SFR] Window

This window is used to display registers. Select [SFR] from the [Browse] menu or click the  button on the toolbar to open the [SFR] window.



**(a) SFR name display area**


This area is used to display SFR names and I/O port names. If the value of an I/O port address is not defined, the I/O port name is displayed in a light color.

**(b) Attribute display area**

This area is used to display the attributes of SFRs and I/O ports. Read/write attributes, access types, and absolute addresses are displayed from the left side to the right.

**(c) SFR content display area**

This area is used to display the contents of SFRs and I/O ports. Values are changed through direct entry. Changes are displayed in red and the contents of the changes are written to the target memory by pressing the Enter key. The previous values can be discarded by pressing the ESC key.




**(d) Function buttons**

Refresh	Updates the contents of the window with the latest data.
Close	Closes the [SFR] window.

The menu (context menu) will be displayed if the right mouse button is clicked anywhere on the [SFR] window. The four main functions that can be selected from the context menu are described next.


<1> Move

Select [Move] from the context menu (displayed by right-clicking anywhere on the [SFR] window) to open the [Address Move] dialog box. Specify an address value or SFR name and click the [OK] button in this dialog box to move the display start address to the specified address value.




<2> Add Watch

Select on the window the name of the register to be added, and select [Add Watch] from the context menu (displayed by right-clicking anywhere on the [SFR] window) to open the [Add Watch] dialog box. Check that the selected register name is added to the [Name:] column and click the [OK] button to register the specified data in the [\[Watch\] window](#).




<3> Selecting the numbering system display

Select [Bin], [Oct], [Dec], or [Hex] from the context menu (displayed by right-clicking anywhere on the [SFR] window) to change the numbering system display of the [SFR] window (hexadecimal display by default).




<4> Selecting the sort method

Select [Sort By Name], [Sort By Address], or [UnSort] from the context menu (displayed by right-clicking anywhere on the [SFR] window) to change the way the SFR names and I/O port names are sorted on the [SFR] window ([UnSort] by default).



Not sorted



Sorted by names (alphabetical order)

## CHAPTER 6 RELATED DOCUMENTS

Document Name	Japanese/English	
78K0S/KU1+ User's Manual	<a href="#">PDF</a>	
78K0S/KY1+ User's Manual	<a href="#">PDF</a>	
78K0S/KA1+ User's Manual	<a href="#">PDF</a>	
78K0S/KB1+ User's Manual	<a href="#">PDF</a>	
78K/0S Series Instructions User's Manual	<a href="#">PDF</a>	
RA78K0S Assembler Package User's Manual	Language	<a href="#">PDF</a>
	Operation	<a href="#">PDF</a>
CC78K0S C Compiler User's Manual	Language	<a href="#">PDF</a>
	Operation	<a href="#">PDF</a>
PM+ Project Manager User's Manual	<a href="#">PDF</a>	
SM+ System Simulator Operation User's Manual	<a href="#">PDF</a>	
Flash Programming Manual (Basic) (MINICUBE2) Information	78K0S/KU1+	<a href="#">PDF</a>
	78K0S/KY1+	<a href="#">PDF</a>
	78K0S/KA1+	<a href="#">PDF</a>
	78K0S/KB1+	<a href="#">PDF</a>
78K0S/Kx1+ Sample Program (Initial Settings) LED Lighting Switch Control Application Note	<a href="#">PDF</a>	

## APPENDIX REVISION HISTORY

Edition	Date Published	Page	Revision
2nd edition	September 2008	–	–

*For further information,  
please contact:*

**NEC Electronics Corporation**  
1753, Shimonumabe, Nakahara-ku,  
Kawasaki, Kanagawa 211-8668,  
Japan  
Tel: 044-435-5111  
<http://www.necel.com/>

**[America]**

**NEC Electronics America, Inc.**  
2880 Scott Blvd.  
Santa Clara, CA 95050-2554, U.S.A.  
Tel: 408-588-6000  
800-366-9782  
<http://www.am.necel.com/>

**[Europe]**

**NEC Electronics (Europe) GmbH**  
Arcadiastrasse 10  
40472 Düsseldorf, Germany  
Tel: 0211-65030  
<http://www.eu.necel.com/>

**Hanover Office**  
Podbielskistrasse 166 B  
30177 Hannover  
Tel: 0 511 33 40 2-0

**Munich Office**  
Werner-Eckert-Strasse 9  
81829 München  
Tel: 0 89 92 10 03-0

**Stuttgart Office**  
Industriestrasse 3  
70565 Stuttgart  
Tel: 0 711 99 01 0-0

**United Kingdom Branch**  
Cygnus House, Sunrise Parkway  
Linford Wood, Milton Keynes  
MK14 6NP, U.K.  
Tel: 01908-691-133

**Succursale Française**  
9, rue Paul Dautier, B.P. 52  
78142 Velizy-Villacoublay Cédex  
France  
Tel: 01-3067-5800

**Sucursal en España**  
Juan Esplandiú, 15  
28007 Madrid, Spain  
Tel: 091-504-2787

**Tyskland Filial**  
Täby Centrum  
Entrance S (7th floor)  
18322 Täby, Sweden  
Tel: 08 638 72 00

**Filiale Italiana**  
Via Fabio Filzi, 25/A  
20124 Milano, Italy  
Tel: 02-667541

**Branch The Netherlands**  
Steijgerweg 6  
5616 HS Eindhoven  
The Netherlands  
Tel: 040 265 40 10

**[Asia & Oceania]**

**NEC Electronics (China) Co., Ltd**  
7th Floor, Quantum Plaza, No. 27 ZhiChunLu Haidian  
District, Beijing 100083, P.R.China  
Tel: 010-8235-1155  
<http://www.cn.necel.com/>

**Shanghai Branch**  
Room 2509-2510, Bank of China Tower,  
200 Yincheng Road Central,  
Pudong New Area, Shanghai, P.R.China P.C:200120  
Tel:021-5888-5400  
<http://www.cn.necel.com/>

**Shenzhen Branch**  
Unit 01, 39/F, Excellence Times Square Building,  
No. 4068 Yi Tian Road, Futian District, Shenzhen,  
P.R.China P.C:518048  
Tel:0755-8282-9800  
<http://www.cn.necel.com/>

**NEC Electronics Hong Kong Ltd.**  
Unit 1601-1613, 16/F., Tower 2, Grand Century Place,  
193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: 2886-9318  
<http://www.hk.necel.com/>

**NEC Electronics Taiwan Ltd.**  
7F, No. 363 Fu Shing North Road  
Taipei, Taiwan, R. O. C.  
Tel: 02-8175-9600  
<http://www.tw.necel.com/>

**NEC Electronics Singapore Pte. Ltd.**  
238A Thomson Road,  
#12-08 Novena Square,  
Singapore 307684  
Tel: 6253-8311  
<http://www.sg.necel.com/>

**NEC Electronics Korea Ltd.**  
11F., Samik Lavied'or Bldg., 720-2,  
Yeoksam-Dong, Kangnam-Ku,  
Seoul, 135-080, Korea  
Tel: 02-558-3737  
<http://www.kr.necel.com/>