

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

32176 Group

Combination of Input Pin and DMAC

1. Overview

The reference sample program combined input pin and DMAC for 32176 group appears on this document.

2. Introduction

These application examples in this document are used in the following microcomputers and conditions.

- Microcomputer: 32176 Group (M32176FnVFP, M32176FnTFP)
- Operating frequency: 20 to 40 MHz (The sample program is compiled assuming a frequency of 40 MHz.)
- Operating Board: Starter kit for 32176 Group

3. Sample program for Combination of input pin and DMAC

3.1 Outline of Sample program

In this sample program, DMA2 starts at rising edge of external signal inputted from TIN18, dummy transmission is started. Transmission counter of DMA2 decrement every dummy transmission so by reading out that value numbers of input event can be measured.




Figure3.1.1 Configuration of Sample for Combination of input pin and DMAC
(Simple event counter using DMAC)

3.2 Description of a reference program

Note: The registers used are indicated as (register name: bit name).

3.2.1 Various initialization functions (init_func())

- (1) Call the port initialization function
- (2) Call the DMAC initialization function

3.2.2 Port initialization functions (port_init())

- (1) Initial setting of output port
 - Set Port Input Permit bit of Port Input Special Function Control Register as permit inputting (PICNT: PIEN0)
 - Initialize P11 Data Register (P11DATA)
 - Set P11 Direction Register as output mode. (P11DIR)
 - Set P11 Operation Mode Register as input/output port. (P11MOD)

Note: If a Direction Register is set as output before setting up a Data Register, an unfixed value is outputted until writing will be performed to a Data Register.

- (2) Initial setting of input port
 - Set P13 Direction Register to input mode (P13DIR)
 - Set Port P132 operation mode bit to TIN18 (P13MOD: P132MOD)
 - Set TIN18 as rising edge is valid (TINCR3: TIN18S)

3.2.3 DMAC initializing Function (dma_init())

- (1) Initial Setting of DMA2
 - Set DMA2 interrupt disable. (DM04ITMK: DMITMK2)
 - Clear DMA2 interrupt request. (DM04ITMK: DMITST2)
 - Set DMA2 source address. (DM2SA)
 - Set DMA2 destination address. (DM2DA)
(It is set same address because only operate transmission)
 - Set 256 times as DMA2 transmission number. (DM2TCT)
- (2) Set DMA2 channel control register (DM2CNT)
 - Starting at inputting TIN18 to DMA2 transmission request factor.
 - Set DMA2 transmission enables.
 - Set DMA2 transmission size to 8 bit.

3.2.4 Main Function (main())

- (1) Call the interrupt prohibitive function
- (2) Call the various initialization functions
- (3) Call the interrupt permit function
- (4) Infinite loop waiting for Interrupt with outputting DMA2 transmission count value to port P11

3.3 Sample program

The sample program for combination of input pin and DMAC is shown below.

Note that the sample program below requires the SFR definition file. The latest SFR definition file can be downloaded from Renesas Technology website. When using the SFR definitions file, adjust the path setting to match the operating computer environment.

3.3.1 TIN_DMA.c

```

1  /* FILE COMMENT *****
2  *      M32R C Programming          Rev. 1.01
3  *      < Sample Program for 32176 >
4  *      < TIN-DMAC >
5  *
6  *      Copyright (c) 2004 Renesas Technology Corporation
7  *      All Rights Reserved
8  *      *****/
9
10 /*****/
11 /*      Include file          */
12 /*****/
13
14 #include          "..\inc\sfr32176_pragma.h"
15
16 /*****/
17 /*      Definition of external reference          */
18 /*****/
19
20 extern void          DisInt( void );          /* Interrupt disable function */
21 extern void          EnInt( void );          /* Interrupt enable function */
22
23 /*****/
24 /*      Function prototype declaration          */
25 /*****/
26
27 void          main(void);
28 void          init_func(void);          /* Initial setup function */
29 void          port_init(void);          /* Initialize port */
30 void          dma_init(void);          /* Initialize DMA */
31
32 /*****/
33 /*      Define macro          */
34 /*****/
35
36 /* DMAC setting data */
37
38          /* 0123 4567          */
39 #define DMA2_INIT          0x2c          /* 0010 1100B DMA2 channel control register
*/
40          /* |||| |||+--- Destination address fixed
*/
41          /* |||| ||+---- Source address fixed
*/
42          /* |||| |+----- Transfer size of 8-bit
*/
43          /* |||| +----- Transfer enabled
*/
44          /* ||+----- 10: start upon TIN18 input signal
*/
45          /* |+----- No transfer request
*/
46          /* +----- Normal mode
*/
47
48 /* TIN setting data */
49
50          /* 0123 4567 89AB CDEF
*/
51 #define TIN18_MASK          0x3000u          /* 0011 0000 0000 0000B TIN input processing control
register 3 */
52 #define TIN18_R_Edge          0x1000u          /* 0001 0000 0000 0000B
*/

```

```

53                                     /*  ++----- TIN 18 rising edge
*/
54
55 /*****
56 /*          Variable definition          */
57 /*****
58
59 UCHAR DMA_DUMMY;
60
61 /*****FUNC COMMENT*****/
62 * Function name : init_func()
63 *-----
64 * Description  : - Initialize ICU
65 *-----
66 * Argument    : -
67 *-----
68 * Returns     : -
69 *-----
70 * Notes      :
71 /*****FUNC COMMENT END*****/
72 void init_func(void)
73 {
74     port_init();           /* Initialize those related to port */
75     dma_init();           /* Initialize DMA */
76 }
77
78 /*****FUNC COMMENT*****/
79 * Function name : port_init()
80 *-----
81 * Description  : - Initialize port
82 *-----
83 * Argument    : -
84 *-----
85 * Returns     : -
86 *-----
87 * Notes      :
88 /*****FUNC COMMENT END*****/
89 void port_init(void)
90 {
91     USHORT temp16;
92
93     PICNT = PIEN0;        /* Enable port input */
94
95     /*** LED output port ***/
96
97     P11DATA = 0x00;      /* Output data (must be set prior to
mode) */
98     P11DIR = 0xff;      /* P110-P117 : Output mode */
99     P11MOD = 0x00;      /* P110-P117 : Input/output port */
100
101     /*** Switch input port ***/
102
103     P13DIR = 0x00;      /* PP130-P137 : Input mode */
104     P13MOD |= 0x0020u;  /* P132:TIN18 */
105     temp16 = TINCR3;
106     TINCR3 = ( temp16 & ~TIN18_MASK) | TIN18_R_Edge; /* Set rise on TIN18 to be the active
edge */
107 }
108
109
110 /*****FUNC COMMENT*****/
111 * Function name : dma_init()
112 *-----
113 * Description  : - Initialize DMAC
114 *           :   DMA2: transferred upon TIN18 input signal
115 *-----
116 * Argument    : -
117 *-----
118 * Returns     : -
119 *-----
120 * Notes      : Transfer is dummy
121 *           :   Restart is required if the number of transfers is 256 or more
122 /*****FUNC COMMENT END*****/
123 void dma_init(void)
124 {
125     /*** DMA2 initial setting ***/

```

```

126
127     DM04ITMK |= DMITMK2;                /* Inhibit DMA2 interrupt */
128     DM04ITST = (~DMITST2) & 0xFFu;    /* Clear DMA2 interrupt request */
129
130     DM2SA = (USHORT)&DMA_DUMMY;        /* Source address -> dummy */
131     DM2DA = (USHORT)&DMA_DUMMY;        /* Destination address -> dummy */
132
133     DM2TCT = 0xff;                      /* Number of DMA2 transfer (256 times) */
134     DM2CNT = DMA2_INIT;                 /* Start and enable transfer upon TIN18 input
signal */
135 }
136
137 /*****FUNC COMMENT*****/
138 * Function name : main()
139 *-----*
140 * Description   : - Start DMA2 upon rising edge of TIN18 and count the
141 *                 : number of transfers, then output number of edge
142 *                 : inputs (number of transfers) to LED (PORT11)
143 *-----*
144 * Argument     : -
145 *-----*
146 * Returns      : -
147 *-----*
148 * Notes        : Transfer counter is counting down from 255
149 *****/
150 void main(void)
151 {
152     /*** Initialize microcomputer ***/
153
154     DisInt();                            /* Disable interrupt */
155
156     init_func();
157
158     EnInt();                             /* Enable interrupt */
159
160     while(1) {
161         P11DATA = (255 - DM2TCT);        /* Display the value for DM2TCT on LED
*/
162     }
163 }

```

3.4 Timing of operation

Timing of operation in this reference program is shown below.




Figure3.4.1 Timing Diagram for combination sample of input pin and DMAC

4. Reference Documents

- 32176 Group User's Manual (Rev.1.01)
- M32R Family Software Manual (Rev.1.20)
- M3T-CC32R V.4.30 User's Manual (Compiler)
- M3T-CC32R V.4.30 User's Manual (Assembler)

(Please get the latest one from Renesas Technology Corp. website.)

5. Website and Support Center

- Renesas Technology Corp. website
<http://www.renesas.com/>
- Inquires for all Renesas products and technical inquiries for the M32R Family products:
Customer Support Center: csc@renesas.com

Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	Dec.09.05	—	First edition issued

 Keep safety first in your circuit designs!

1. Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.
Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

 Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
2. Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein.
The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.
Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (<http://www.renesas.com>).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.
Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.