

---

# R-IN, RZ/T1, EC-1, TPS-1 Groups

R01AN3544EJ0100

Rev.1.00

May 17, 2017

## Software PLC Guide: Configuring Projects and Creating User Interfaces

---

### Outline

This application note explains the procedure for running evaluation boards with on-chip microcontrollers of the R-IN, RZ/T1, EC-1, and TPS-1 Groups in connection with the CODESYS software programmable logic controller (PLC).

By connecting a software PLC with an evaluation board, users can read commands transferred from the controller and responses from the evaluation board.

### Target Devices

R-IN32M3-EC

R-IN32M3-CL

RZ/T1

EC-1

TPS-1

## Contents

<b>1. Creating a Project and Ensuring Connection with Devices .....</b>	<b>3</b>
<b>1.1 Starting the CODESYS and Creating a New Project.....</b>	<b>3</b>
<b>1.2 Adding a Slave Device.....</b>	<b>6</b>
<b>1.3 Connecting to the Software PLC .....</b>	<b>7</b>
<b>1.4 Setting the Device Network.....</b>	<b>10</b>
<b>1.5 Ensuring Connection of the Device .....</b>	<b>11</b>
<b>2. Creating and Simulating a User Interface.....</b>	<b>13</b>
<b>3. Website and Support.....</b>	<b>20</b>

## 1. Creating a Project and Ensuring Connection with Devices

This section describes the following procedures.

- Creating a project
- Adding a device
- Running a project
- Ensuring connection of the device

This section covers how to build new projects and how to add new devices and make connection with them. Refer to the startup manual (CODESYS\_StartupGuide\_rev\*.\*.pdf) regarding the procedure for programming.

Please obtain from Links company site. <http://linx.jp/download/codesysv3>

This application note describes how to add a new device to the CODESYS program, with a PROFINET I/O stack, taken as an example. See section 1.3, Connecting to the Software PLC, for executing an existing project.

### 1.1 Starting the CODESYS and Creating a New Project


#### (1) Starting the CODESYS

Select "All Programs" > 3S CODESYS > CODESYS > CODESYS Vx.x (x.x represents the version number) from the Windows start menu.

You can also startup the program by double-clicking on the "CODESYS" icon, which will be created on the desktop after the installation of the program.


#### (2) Creating a New Project

Select "New Project" from the "File" menu to create a new project.




In the "New Project" window, select "Projects" from the "Categories" section and "Standard project" from the "Templates" section.

Then, specify the name of the project and its location and click on "OK".




In the "Standard Project" window, select the controller and programming language you wish to use from the drop-down lists for "Device" and "PLC\_PRG in". For this example, select "CODESYS Control Win V3" and "Structured Text (ST)", respectively. After that, click on "OK" to open the new project.



The "Device" tree for the newly created project will be displayed as shown below.

The components that belong to "Device (CODESYS Control Win V3)" are managed in a tree structure.



## 1.2 Adding a Salve Device

To add a device, you need to install an applicable device information file.

ESI, EDS, and Generalized Station Description Markup Language (GSDML) files are provided with the release package of the protocol stack.


Install the appropriate file for the device you want to add with reference to the application note for the given protocol;

For PROFINET: R01AN3545EJ0100

For EtherNetIP: R01AN3546EJ0100

For EtherCAT: R01AN3547EJ0100

Complete addition of the target device by following the procedure given in the corresponding application note. The added device will be indicated as shown within the red rectangle in the figure below.




### 1.3 Connecting to the Software PLC


This section gives the procedure for connection to the target software PLC from the CODESYS development environment via a gateway.

#### (1) Starting the Gateway Server


Check the state of the gateway server on the system tray. If the server is down, click on the " " icon and select "Start Gateway" to start the server up. Usually, the server will automatically be started as a standard service on booting of Windows and its status is indicated in the system tray<sup>Note</sup> in the lower-right corner of the desktop.




Note: If you cannot find the icon in the system tray, start the server up by the following procedure:  
Click on "All Programs" > 3S CODESYS > CODESYS Gateway V3 > CODESYS Gateway V3.  
If the icon still does not show up, reboot the PC you are using.




(2) **Starting the Software PLC**

Check the state of the software PLC on the system tray. If the program is stopped, click on the "  " icon and select "Start PLC" to start the program up. Usually, the program will automatically be started as a standard service on booting of Windows and its status is indicated in the system tray<sup>Note</sup> in the lower-right corner of the desktop.




Note: If you cannot find the icon in the system tray, start the server up by the following procedure:  
 Click on "All Programs" > 3S CODESYS > CODESYS Control Win V3 > CODESYS Control Win V3 SysTray.  
 If the icon still does not show up, reboot the PC you are using.






### (3) Configuring Connection with the Software PLC

Make connection settings for connecting the software PLC service from your development environment. Double-click on the "Device (CODESYS Control Win V3)" in the "Device" tree. On the "Device" tabbed page, select "Connection settings" and click on the "Scan network..." button.



The "Select Device" window opens and a search for available devices that can use the local network automatically starts. Finding a software PLC service constitutes success and the name of the corresponding PC will be indicated. Double-click on the PC name to make a connection.

If the service will not be found, check the settings described in previous sections, (1)Starting the Gateway Server and (2)Starting the Software PLC.



## 1.4 Setting the Device Network

Network settings for the device you have added to the system in section 1.2 Adding a Salve Device are required. For details, refer to the application note for the given protocol;

For PROFINET: R01AN3545EJ0100


For EtherNetIP: R01AN3546EJ0100

For EtherCAT: R01AN3547EJ0100


## 1.5 Ensuring Connection of the Device

This section describes how to run a program on the CODESYS development environment and how to ensure connection of the device.


Select "Build" from the "Build" menu.





Select "Login" from the "Online" menu.







Select "Start" from the "Debug" menu. The project will automatically start on Windows.



The states of connection will be indicated next to each device name. Successful connection is indicated by the "  " icon as shown in the tree view below.



The icons indicating status of each device is listed below.

-  : The application is connected to the PLC and is running.
-  : The application is connected to the PLC but is not running.
-  : Error. Check the error contents and the settings of the device.
-  : There is no device information in the device repository. Review the device information file and re-install it.

## 2. Creating and Simulating a User Interface


This section includes the following procedures:

- Displaying the development environment screen
- Implementation example
- Relating variables to components and to the I/O ports of devices


The CODESYS development environment allows the creation of user interfaces. You can access all internal variables used in the PLC program on the screen as well as monitoring and changing the parameters. Here, as an example, placement of components in the display for the development environment and the association of variables with those components and to preset I/O ports so that they can be handled from the master display are explained.

### (1) Adding Components

Components to be placed on a user-interface display need to be added to the "Device" tree before creating one. Right-click on "Application" in the tree and select "Add Object", then "Visualization...".




Selected component is added in the "Device" tree.



**(2) Development Pane**

Double-clicking on "Visualization" in the tree displays the development pane.



Development pane

The main pane for structuring user-interface displays. Place the components you will be using here.

Toolbox

The toolbox provides basic components for placements in the development pane. As well as such as graphs, tables, and labels, meters, switches, progress bars, and other items are available.

Users can select the desired components from this box and place them in the development pane.

Properties

Parameters for the components placed on the development pane are monitored and changed from here. The internal variables of the PLC program are also handled within this pane.


### (3) Placing Components

Configuring a user interface for use in data transfer with a given device is explained, taking PROFINET I/O as an example. Here, the descriptions are on the assumption that the devices have 8-bit I/O ports.

Creating a sample display and setting variables:


1. Groups of LEDs and switches in the development pane, each consisting of eight members so as to match the width of the I/O ports of the given device, are to form the interface.
2. Switch the display in the Toolbox to "Common controls" and select "GroupBox", then place two boxes on the development pane by dragging and dropping. The names of the group boxes can be edited in the "Text" menu in the "Properties" pane.
3. Place components in each group as follows;
  - i. LED group: Select "Rectangle" from the "Basic" group and place eight rectangles in the box for LEDs.
  - ii. Switch group: Select "Lamps/Switches/Bitmaps" then "DipSwitch". Place eight of them in the box for switches.
  - iii. Give labels to each element such as "LE\*\*" and "SW\*\*" by dragging and dropping from "Label".

After the above actions, the display will be configured as shown below.




The tools added in the previous steps need to be related to internal variables in order to use them in a program.

Open the "PLC\_PRG" tabbed page by double-clicking on its name in the "Device" tree. Define BYTE variables in the lines where variables are to be declared.



Variables corresponding to the tools selected in the development pane are designated in the "Properties" pane.


Relate variables to the elements of the interface bit-by-bit.





Configuring the I/O ports of the given device:


If the device information file for the device you have added in section 1.2, Adding a Slave Device, includes the I/O settings, the information will be reflected in the "Device" tree. Below is an example of 8-bit input and output ports added to the tree.



Note that these I/O ports are still not available in the CODESYS environment because they have not been related to appropriate variables.

Here, we define global variables for them since we want to use them in a general way.

Variables are defined in the Global Variable List (GVL). Right-click on the "Application" in the "Device" tree and select "Add Object", then "Global variable list..." to open the GVL window. Click on "Add" to add a list in the tree.




Open the GVL tabbed page by double-clicking the name newly added in the "Device" tree. Define global variables as in the screenshot below.

```


1 {attribute 'qualified_only'}
2 VAR_GLOBAL
3   dataIn8PNI : BYTE; // Input (8bit data)
4   dataOut8PNI : BYTE; // Outuut (8bit data)
5 END_VAR
    
```

Open the tabbed page for the target I/O port by double-clicking on the name in the "Device" tree. In the "PNIO Module I/O Mapping" sub-tabbed page, configure variables under the "Variable" menu.



**(4) Result of Running the Program**


On the "PLC\_PRG" tabbed page, write the source code in the code-writing section with defined variables as in the example below.



Running the above program produces the following operations:

- The system receives data from the connected device and switches the LEDs on or off in response.
- The system sends the state of the switches to the connected device and obtains the desired operation from the application on the device.

An image of the operations is given below.



### 3. Website and Support

Renesas Electronics Website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/contact/>

All trademarks and registered trademarks are the property of their respective owners.

## Revision History

Rev.	Date	Description	
		Page	Summary
1.00	May. 17, 2017	—	First edition issued

## General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

### 1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

### 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

### 3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

### 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

### 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

- The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
  2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
  3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
  4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
  5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.  
Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
  6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
  7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
  8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
  9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
  10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
  11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
  12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.  
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



### SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

#### Renesas Electronics America Inc.

2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130

#### Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3  
Tel: +1-905-237-2004

#### Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.  
Tel: +44-1628-585-100, Fax: +44-1628-585-900

#### Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

#### Renesas Electronics (China) Co., Ltd.

Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

#### Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333  
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

#### Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2265-6688, Fax: +852 2886-9022

#### Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan  
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

#### Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

#### Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

#### Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HALII Stage, Indiranagar, Bangalore, India  
Tel: +91-80-67208700, Fax: +91-80-67208777

#### Renesas Electronics Korea Co., Ltd.

12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141