

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

Precautions on Using the H8S/2214 E6000 Emulator

Thank you for purchasing the H8S/2214 E6000 emulator.

Please note the followings when using this version of the H8S/2214 E6000 emulator.

1 Precautions on Using the Emulator

1.1 Devices that cannot be Emulated Independently by E6000

When the following devices are emulated, an expansion board and a user cable are required besides the E6000 H8S/2214 station (HS2214EPI61H or HS2214EPI62H). Therefore, do not select the corresponding devices when the following expansion boards and user cables are disconnected.

Emulation Device	Expansion Board and User Cable	Type Number
H8S/2218, H8S/2217	User cable for H8S/2218	HS2218ECN61H
H8S/2212, H8S/2211, H8S/2210	User cable for H8S/2212	HS2212ECN61H
H8S/2215, H8S/2215A, H8S/2215B, H8S/2215C	User cable for H8S/2215	HS2215ECN61H or HS2215ECB62H
H8S/2277R, H8S/2277	H8S/2276R series expansion I/O board for E6000 emulator or H8S/2276 series expansion I/O board for E6000 emulator	HS2276REIO61H or HS2276EIO61H

1.2 Memory Mapping

When using the H8S/2214 platform, emulator memory and user memory cannot be mapped in each of address area blocks listed below at the same time. If this is attempted, the previously mapped area will be changed into a guarded area.

Block name	Address area	Block name	Address area
SB0	H'000000-H'01FFFF	LB0	H'100000-H'1FFFFFFF
SB1	H'020000-H'03FFFF	LB1	H'200000-H'3FFFFFFF
SB2	H'040000-H'05FFFF	LB2	H'400000-H'5FFFFFFF
SB3	H'060000-H'07FFFF	LB3	H'600000-H'7FFFFFFF
SB4	H'080000-H'09FFFF	LB4	H'800000-H'9FFFFFFF
SB5	H'0A0000-H'0BFFFF	LB5	H'A00000-H'BFFFFFFF
SB6	H'0C0000-H'0DFFFF	LB6	H'C00000-H'DFFFFFFF
SB7	H'0E0000-H'0FFFFFFF	LB7	H'E00000-H'FFFFFFF

1.3 USB Module of the H8S/2215

- Displaying the [IO] Window
In the USB registers, USB Endpoint Information Registers 00_0 to 22_4 (UEPIR00_0 to UEPIR22_4) are defined as other modules (USB_Endpoint_Information_Registers).
- Access Area
The USB module is allocated to the external bus area of area 6 (H'C00000 to H'DFFFFFFF). Therefore, the access area that has been traced for this area is displayed in the external area (EXT-8). There is no display of 'Internal IO' for areas H'C00000 to H'DFFFFFFF by the [Target Device Configuration] item in the [Memory] sheet of the [Status] window.

1.4 USB and RTC Modules of the H8S/2218, H8S/2212

- Access Area

The USB and RTC modules are allocated to the external bus area of area 6 (H'C00000 to H'DFFFFFF) and area 7 (H'E00000 to H'FFFFFF), respectively.

Therefore, the access area that has been traced for this area is displayed in the external area (EXT-8).

There is no display of 'Internal IO' for areas H'C00000 to H'DFFFFFF by the [Target Device Configuration] item in the [Memory] sheet of the [Status] window.

1.5 Voltage Follower Circuit

When setting the Vccdown detection voltage in the voltage follower circuit, make the setting be at least 2.6 V or higher.

1.6 Reserved Area to be Changed for External Address Area

The reserved area that can be changed for the external address area by clearing the RAME bit in the system control register (SYSCR) to 0 is used as the external address area, change the attribute of this area from 'User Guarded' to 'User Read-write' or 'User Read-only' in the [Memory Mapping] dialog box that is displayed by selecting [Emulator -> Memory Resource...] from the [Setup] menu, before loading the user program.

However, if other attributes than 'User Guarded' are set, an accessing-error break for this area will not occur.

Be careful when the reserved area (RAME = 1) is also used as the external address area (RAME = 0).

1.7 Event

1.7.1 Combination of Address-Range and Data Compare-Byte

When an address range is set as the address condition and byte data as the data condition, a break will occur only at even addresses in the address range. When an address range is set as the address condition, do not set an odd address as the Address Lo condition. Otherwise, a break will not occur even when the conditions are satisfied.

1.7.2 Removing Software Breakpoints during Execution of the User Program

Do not remove Software breakpoints in the source window, [Disassembly] window, or [Label] window during execution of the user program.

1.7.3 Recovery of Software Breakpoints by the Session File

Information on Software breakpoints that was saved in the session file is not available until a load module is loaded. If necessary, load a load module or set new Software breakpoints.

1.8 Display of the Memory Content and Operation of Memory

1.8.1 Operating Memory during Execution of the User Program

The memory copy, memory compare, memory fill, and memory test functions are not available during execution of the user program. These command lines are not available either.

1.8.2 Memory Test

- Memory Content after Execution of a Memory Test

The content of memory in the specified range after execution of a memory test will not be guaranteed. The contents of windows that display memory, such as the [Memory] window, are not automatically updated after a memory test. Be careful if you want to continue debugging.

- MT Command

When an incorrect parameter has been specified for the MT command, the command line window may display the message “UNKNOWN ERROR –nnnnnnnnnn”. Enter the correct parameter. The command line window displays the message “Open this document” after ending the MT command. Ignore this message because it is not concerned with the result of the MT command.

1.8.3 Updating the Memory Content during Execution of the User Program

Updating the content of the [Memory] window during execution of the user program when either of the following conditions is satisfied causes the displayed values to be incorrect:

- [Enable read and write on the fly] in the [Configuration Properties] dialog box has been disabled
- Stepping (step-in, step-over, or step-out) is being performed
- The emulator is in sleep mode, software standby mode, watch mode, or subsleep mode.

In those cases, the correct values will be displayed when the content of the window is updated after the program has stopped. This also applies to the windows [Disassembly], [Image View], [IO], [Watch], and [Waveform].

Updating of the [Monitor] window or [Watch] window by reading values with the monitoring function is available even with those conditions.

1.8.4 MEMORY_MOVE Command

Do not select the V/N option in the MEMORY_MOVE command. Writing to memory by the MEMORY_MOVE command always requires verification.

1.9 The Load/Save of File

1.9.1 Access Size of Download Modules

When you specify a download module for debug settings, do not select 4 or 8 for [Access size] in the [Download Module] dialog box.

1.9.2 Loading a File in the SYSROF Format

No program in the SYSROF format can be loaded. Any program for debugging must be created in the Elf/Dwarf2 format.

1.9.3 FILE_LOAD Command

Do not specify V in the FILE_LOAD command. Use the FILE_VERIFY command to verify memory.

1.9.4 FILE_SAVE Command

The content of memory cannot be saved in the Elf/Dwarf2 format.

1.10 Emulation

1.10.1 Temporary Breakpoints

- Run... (Run menu)

Do not set temporary breakpoints to an area wherein Software Break (User Read-only) cannot be set. Otherwise, user program execution will not stop at the breakpoint. Moreover, the On Chip Breakpoint may remain. In this case, delete the breakpoint from the [Breakpoints] window.

1.10.2 Rate of Stepping

- To perform stepping continuously with the [Image View] or [Waveform] window open, do not select "0 seconds" as the delay.
- Do not perform stepping continuously if you have specified the realtime update of the [Image] or [Waveform] window.

1.10.3 Go to Cursor

The [Go to Cursor] function uses one Software breakpoint. Note the followings:

- To use the [Go to Cursor] function, the number of Software breakpoints must be 255 or less.
- To use the [Go to Cursor] function for the ROM area on the target system, do not use the On Chip Breakpoint by the Software break.

1.10.4 Note on Occurrence of Breaks

When a break occurs during execution of the user program with a dialog box open, the state of High-performance Embedded Workshop may not transit to the breaking state. In this case, close the dialog box and select [Halt Program] from the [Debug] menu or press the [Halt Program] button on the toolbar. You can check whether a break has occurred or not by the RUN lamp (LED) on the emulator station. The RUN lamp (LED) is illuminated while the user program is running.

1.10.5 Execution Status Display

- Execution Status Display on Status Bar

At memory access wait, not the address where the access is halted, but the next fetched address is displayed.

1.10.6 Source-Level Execution

- Step

Even standard C libraries are executed. To return to a higher-level function, enter Step Out. In a for statement or a while statement, executing a single step does not move execution to the next line. To move to the next line, execute two steps.

1.11 The Load/Save of the Session File

Load the file after you confirm that the H/W environment is the same as that when the last session file was loaded.

Note that the operation of High-performance Embedded Workshop may become incorrect when Target Clock is chosen at the time when the session file was saved and Target was not connected at the time when the session file was loaded.

1.12 Assembling and Disassembling

1.12.1 Line Assembly

- Input Radix

Regardless of the Radix setting, the default for line assembly input is decimal. Specify H' or 0x as the radix for a hexadecimal input.

- Address Space Size

In absolute addressing mode, specify the size (:16, etc.)

1.13 Note on [Registers] Window Operation during Program Execution

During program execution, when the [Registers] window is double-clicked, a dialog box to change the register contents is displayed. However, the operation to change the register contents is invalid during program execution.

1.14 [IO] Window

1.14.1 Contents of the [IO] Window

The invalid module display and bit information display in the [IO] window are not supported.

1.15 Source File

1.15.1 Note on Moving Source File Position after Creating Load Module

When the source file is moved after the load module has been created, the [Open] dialog box, which specifies the source file, may be displayed during debugging of the created load module. Select the corresponding source file.

1.15.2 Columns in the Source Window

The columns Event and EXT.2 Trigger in the source window may be switched. You can identify these columns by displaying a popup menu on either of them.

1.15.3 Event Column

When different actions have been set on an address from the windows [Event] and [Trace], note the followings:

- Deletion and change for settings may not be available on the [Event] column.
- If eight or more points have been set as the start points in execution time measurement (Timer On), changing the settings on the [Event] column may prevent further changes.

Deletion and change for settings must be made in the [Event] window or [Trace] window.

1.16 Watch

1.16.1 Local Variables at Optimization

Depending on the generated object code, local variables in a C source file that is compiled with the optimization option enabled will not be displayed correctly. Check the generated object code by displaying the [Disassembly] window.

1.16.2 Variable Name Specification

When a name other than a variable name, such as a symbol name or a function name, is specified, no data is displayed.

1.16.3 Display of float- and double-type Variables

Do not enable the automatic update of float- and double-type variables. The values of float- and double-type variables will not be correctly displayed if they are automatically updated during execution of the user program. If you want to check the values, use the monitoring function ([Monitor] window).

1.16.4 Synchronization with the [Monitor] window

Do not enable the automatic update of float- and double-type variables. The values of float- and double-type variables will not be correctly displayed if they are automatically updated during execution of the user program. If you want to check the values, use the monitoring function ([Monitor] window).

1.17 Command Line Interface

- **Specifying a File**
If a file is specified in the relative path format for a command line parameter, an access to the file may not be available. A file must be specified in the absolute path format when using a command line.
- **Batch File**
If the message “Not currently available” is displayed while executing a batch file, enter the sleep command. Adjust the length of sleep time since it varies according to the operating environment.
Example: When “Not currently available” is displayed during memory_fill execution:
 sleep d'3000
 memory_fill 0 ffff 0
- **Overwrite File**
In Command Line Interface, a file that has the same name as the output file is overwritten without asking the user.
- **Log File**
To change the target platform due to a change of the session while logging of the command line window, halt logging.
- **GO_TILL Command**
If the GO_TILL command executed by specifying “wait” as the parameter is terminated with an error, the command processing may not be available. In such cases, select [Stop] in the popup menu of the command line window to perform the command processing.

1.18 Monitoring Function

1.18.1 Changing Monitor Settings during User Program Execution

If you change the monitor settings in the [Monitor] window during execution of the user program, the initial values will be undefined.

1.19 Installation and Uninstallation

1.19.1 Uninstallation from [Tool Administration]

Note that a message dialog box appears for confirmation if the folder to be removed includes a file other than those installed. Even though this dialog box is displayed, press the [Ignore] button to continue uninstallation.

1.19.2 [Add/Remove Programs Properties] of the Control Panel

Note the followings:

- Uninstalling from [Add/Remove Programs Properties] of the control panel only removes folders and files of the product most recently installed if several products that conform to High-performance Embedded Workshop have been installed. Use the explorer to remove the folders and files of the rest of the products.
- Once uninstallation is attempted, even products that were not removed may not operate correctly. If you want to use these products, re-install them.

1.19.3 Usage with Other Products

To install the SuperH™ RISC engine C/C++ compiler package or H8S, H8/300 series C/C++ compiler package after installing the E6000 emulator software for High-performance Embedded Workshop, select [High-performance Embedded Workshop] as the component to be installed in [Select Components] during installation of the compiler package.

2 User's Manual

2.1 Emulator User's Manual

In the E6000 emulator user's manual, some screen bitmap may be different from actual ones.