

# RX63T144 Group

Renesas Starter Kit Tutorial Manual  
For e<sup>2</sup>studio

RENESAS MCU  
RX Family / RX600 Series

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corporation without notice. Please review the latest information published by Renesas Electronics Corporation through various means, including the Renesas Electronics Corporation website (<http://www.renesas.com>).

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.  
(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.  
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

## Disclaimer

By using this Renesas Starter Kit (RSK), the user accepts the following terms:

The RSK is not guaranteed to be error free, and the entire risk as to the results and performance of the RSK is assumed by the User. The RSK is provided by Renesas on an "as is" basis without warranty of any kind whether express or implied, including but not limited to the implied warranties of satisfactory quality, fitness for a particular purpose, title and non-infringement of intellectual property rights with regard to the RSK. Renesas expressly disclaims all such warranties. Renesas or its affiliates shall in no event be liable for any loss of profit, loss of data, loss of contract, loss of business, damage to reputation or goodwill, any economic loss, any reprogramming or recall costs (whether the foregoing losses are direct or indirect) nor shall Renesas or its affiliates be liable for any other direct or indirect special, incidental or consequential damages arising out of or in relation to the use of this RSK, even if Renesas or its affiliates have been advised of the possibility of such damages.

## Precautions

The following precautions should be observed when operating any RSK product:

This Renesas Starter Kit is only intended for use in a laboratory environment under ambient temperature and humidity conditions. A safe separation distance should be used between this and any sensitive equipment. Its use outside the laboratory, classroom, study area or similar such area invalidates conformity with the protection requirements of the Electromagnetic Compatibility Directive and could lead to prosecution.

The product generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off or on, you are encouraged to try to correct the interference by one or more of the following measures;

- ensure attached cables do not lie across the equipment
- reorient the receiving antenna
- increase the distance between the equipment and the receiver
- connect the equipment into an outlet on a circuit different from that which the receiver is connected
- power down the equipment when not in use
- consult the dealer or an experienced radio/TV technician for help NOTE: It is recommended that wherever possible shielded interface cables are used.

The product is potentially susceptible to certain EMC phenomena. To mitigate against them it is recommended that the following measures be undertaken;

- The user is advised that mobile phones should not be used within 10m of the product when in use.
- The user is advised to take ESD precautions when handling the equipment.

The Renesas Starter Kit does not represent an ideal reference design for an end product and does not fulfil the regulatory standards for an end product.

# How to Use This Manual

## 1. Purpose and Target Readers

This manual is designed to provide the user with an understanding of the RSK hardware functionality, and electrical characteristics. It is intended for users designing sample code on the RSK platform, using the many different incorporated peripheral devices.

The manual comprises of an overview of the capabilities of the RSK product, but does not intend to be a guide to embedded programming or hardware design. Further details regarding setting up the RSK and development environment can found in the User's manual.

Particular attention should be paid to the precautionary notes when using the manual. These notes occur within the body of the text, at the end of each section, and in the Usage Notes section.

The revision history summarizes the locations of revisions and additions. It does not list all revisions. Refer to the text of the manual for details.

The following documents apply to the RX63T Group. Make sure to refer to the latest versions of these documents. The newest versions of the documents listed may be obtained from the Renesas Electronics Web site.

Document Type	Description	Document Title	Document No.
User's Manual	Describes the technical details of the RSK hardware.	RSKRX63T144 User's Manual for e <sup>2</sup> studio	R20UT2121EG
Tutorial	Provides a guide to setting up RSK environment, running sample code and debugging programs.	RSKRX63T144 Tutorial Manual for e <sup>2</sup> studio	R20UT2122EG
Quick Start Guide	Provides simple instructions to setup the RSK and run the first sample, on a single A4 sheet.	RSKRX63T144 Quick Start Guide for e <sup>2</sup> studio	R20UT2123EG
Schematics	Full detail circuit schematics of the RSK.	RSKRX63T144 Schematics	R20UT2116EG
Hardware Manual	Provides technical details of the RX63T microcontroller.	RSKRX63T Hardware Manual	R01UH0331EJ

## 2. List of Abbreviations and Acronyms

Abbreviation	Full Form
ADC	Analog to Digital Converter
CD	Compact Disk
E1	E1 Emulator
E20	E20 Emulator
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LVD	Low Voltage Detect
ROM	Read-Only Memory
RSK	Renesas Starter Kit
USB	Universal Serial Bus

# Table of Contents

1. Overview.....	7
1.1 Purpose.....	7
1.2 Features.....	7
2. Introduction.....	8
2.1 Note Regarding Source Code.....	8
3. Project Workspace.....	9
3.1 Introduction.....	9
3.2 Starting e <sup>2</sup> studio and Importing Sample Code.....	9
3.3 Build Configurations and Debug Sessions.....	13
3.3.1 Build Configuration.....	13
3.3.2 Debug Configuration.....	13
3.4 Running the Tutorial.....	15
4. Basic Debugging the Tutorial Program.....	16
4.1 Program Initialisation.....	16
4.2 Main Function.....	19
5. Additional Information.....	23

## 1. Overview

### 1.1 Purpose

This RSK is an evaluation tool for Renesas microcontrollers. This manual describes how to get the RSK tutorial started, and basic debugging operations.

### 1.2 Features

This RSK provides an evaluation of the following features:

- Renesas microcontroller programming
- User code debugging
- User circuitry such as switches, LEDs and a potentiometer
- Sample application
- Sample peripheral device initialisation code

The RSK board contains all the circuitry required for microcontroller operation.

## 2. Introduction

This manual is designed to answer, in tutorial form, the most common questions asked about using a Renesas Starter Kit (RSK). The tutorials help explain the following:

- How do I compile, link, download and run a simple program on the RSK?
- How do I build an embedded application?
- How do I use Renesas' tools?

Files referred to in this manual are installed using the project generator as you work through the tutorials. The tutorial examples in this manual assume that installation procedures described in the RSK Quick Start Guide have been completed. Please refer to the quick start guide for details of preparing the configuration.

<p>These tutorials are designed to show you how to use the RSK and are not intended as a comprehensive introduction to e<sup>2</sup>studio, compiler toolchains or the E1 emulator. Please refer to the relevant user manuals for more in-depth information.</p>
--

### 2.1 Note Regarding Source Code

During the project generation, it is possible that the line numbers for source code illustrated in this document do not match exactly with that in the actual source files. It is also possible that the source address of instructions illustrated in this manual differs from a user's code compiled from the same source. These differences are minor, and do not affect the functionality of the sample code or the validity of this accompanying manual.


### 3. Project Workspace

#### 3.1 Introduction


e<sup>2</sup>studio is an open source integrated development tool that allows the user to write, compile, program and debug a software project on many of the Renesas microcontrollers.

#### 3.2 Starting e<sup>2</sup>studio and Importing Sample Code



- Start e<sup>2</sup>studio by selecting it from Start Menu. The first dialog box to appear will be the Workspace Launcher.
- Click 'Browse' and select a suitable location to store your workspace, using the 'Create New Folder' option as necessary. Click 'OK'.




- In the Toolchain registry dialog. Select Renesas Toolchains. RXC v1.02.01.00. Click on Register. A dialog will appear "Selected Toolchains were successfully integrated with e2studio". Click OK.




- Click 'Yes' when presented with the 'Administrator Privilege' dialog box.




- The e<sup>2</sup>studio welcome splash screen will appear. Click the 'Go to the workbench' arrow button on the far right.



- Once the e<sup>2</sup>studio environment has initialised, right click in the Project Explorer window and click 'Import...'




- The Import dialog box will now show. Expand the 'General' folder icon, and select "Existing Projects into Workspace", then click 'Next'.




- The Import dialog box will now allow you to specify the project to import. Click the 'Browse' button, and locate the following directory:

C:\Renesas\Workspace\RSK\RSKRX63T144

- Ensure that the 'Copy projects into workspace' option is ticked, and then click 'Finish'.



- Click on Tutorial from the list of projects in the 'Project Explorer' on the left hand side.



### 3.3 Build Configurations and Debug Sessions

#### 3.3.1 Build Configuration

The e<sup>2</sup>studio workspace will be created with several build configurations – the two we will address in this manual are ‘HardwareDebug’ and ‘Release’.


##### Release

This build mode has optimisation turned on, and provides little debug information. The C code instruction execution may appear to be out of order, due to the way compiler optimises the code. This build configuration is intended for final ROM-programmable code.

##### HardwareDebug


This build mode has all optimisation turned off, and provides full debug information. This is the best configuration to use while developing code. C code instruction execution will be linear.

- Click the top level tutorial project folder again, and then the arrow next to the build button (hammer icon), and select the ‘HardwareDebug’ option.
- e<sup>2</sup>studio will now build the code.




#### 3.3.2 Debug Configuration


- Click the arrow next to the debug button (bug icon). Select ‘Debug Configurations...’.



- The ‘Debug Configuration’ dialog box will appear. Click the small arrow next to ‘Renesas GDB Hardware Debugging’ option.
- The build configurations for each project will appear. Select the entry for the Tutorial project.




- The Debug Configurations control page will then show for the Tutorial project. Change the main tab to 'Debugger', and the secondary tab to 'Connection Settings'. Check through the debugger settings. If you intend to use an external power supply, set the 'Power Target From The Emulator' option to No (drop down menu).
- Refer to the RSK's User Manual for details of power supply configurations.




**Note:** e<sup>2</sup>studio will display a warning dialog box if you attempted to connect with an incorrect power supply setting.

- Click the 'Apply' button to save the changes.
- Click the 'Debug' button to continue. e<sup>2</sup>studio will now connect to the debugger, and download the code to the target.



- e<sup>2</sup>studio may display a dialog box, asking if you would like to switch to the 'Renesas Debug perspective'. Click 'Remember my decision' to prevent this dialog box from appearing in future. Click 'Yes'
- The new e<sup>2</sup>studio perspective layout is optimised for debugging.





- After downloading the code, the File window will open the 'PowerON\_Reset\_PC()'.

```

* Return value : none
*****
void PowerON_Reset_PC (void)
{
    /* Initialise the MCU process
    set_intb((__sectop("C$VECT")))
    set_fpsw(FPSW_INIT);

```

- To change back to the default 'C/C++' perspective, from the menu bar select:
- Window > Open Perspective > Other
- The 'Open Perspective' dialog box will appear. Click on the desired perspective to select it then click 'OK'.
- Alternatively, click on the button with the double arrow in the top right corner of the screen, as shown opposite, and select the 'C/C++' option that appears.



### 3.4 Running the Tutorial

- Refer to the main.c file for instructions on how to configure the RSK and run the sample code.
- Once the code has been downloaded, click the 'Resume' toolbar button (see image) to run the code to the main function. The main function is set as the program entry point by default. The program counter will stop on the first instruction in the main function.
- Click the 'Resume' button to run the rest of the code
- It is recommended that you run the entire tutorial demo first, before continuing to debug it.




# 4. Basic Debugging the Tutorial Program

This section will look at basic debugging functionality in e<sup>2</sup>studio.


## 4.1 Program Initialisation

Before the main program can run, the microcontroller must be configured. The following parts of the tutorial program are used exclusively for initialising the RSK device so that the main function can execute correctly. The initialisation code is run every time the device is reset via the reset switch or from a power reboot.

- After downloading the code, navigate to the Project Explorer window on the right hand side.



- Click the arrow next to the Tutorial project to expand the folder contents, and then click the arrow next to the 'src' folder to show the source files.



- Double click on 'hwsetup.c' to open the file.

- Breakpoints can be set by double clicking within the column width space indicated by the red box. The column width is hereafter referred to as the breakpoint column.
- On the line with instruction `ConfigureOperatingFrequency()`, double click next to the vertical line to set a breakpoint.

```
void HardwareSetup (void)
```

Note:

The alternative to the above method requires reverting back to the default 'C/C++' perspective.

If in the C/C++ perspective, set the mouse cursor on the instruction, then from the menu bar select Run > Toggle Breakpoint.

```
*****
void HardwareSetup (void)
{
    ConfigureOperatingFrequency ();
    ConfigureOutputPorts ();
    ConfigureInterrupts ();
    EnablePeripheralModules ();
}
```

- Press 'Resume' on the Debug toolbar.
- The debugger should now hit the breakpoint inside the HardwareSetup function definition. This function groups together several key functions that are used to ensure the device is setup correctly before the main program is executed.



```
***** hardware_setup.c *****
- /*****
* Function Name : HardwareSetup
* Description  : Contains all the setup functions called at device restart
* Argument    : none
* Return value : none
*****
- void HardwareSetup (void)
{
  ConfigureOperatingFrequency();
  ConfigureOutputPorts();
  ConfigureInterrupts();
  EnablePeripheralModules();
}
- /*****
* End of function HardwareSetup
*****
```

- Click 'Step Into' to enter the ConfigureOperatingFrequency function.



- The ConfigureOperatingFrequency function is used to set the speed of the system clocks.

```

80  /*****
81  * Function Name : ConfigureOperatingFrequency
82  * Description   : Configures the clock settings for each of
83  * Argument      : none
84  * Return value  : none
85  *****/
86 ffff86c8 void ConfigureOperatingFrequency (void)
87 {
88     /* Declare and initialise a loop count variable */
89 ffff86ca uint16_t i = 0;
90
91     /* Protection off */
92 ffff86d0 SYSTEM.PRCR.WORD = 0xA503;
93
94     /* Specify a clock stabilisation time, greater than 10ms
95     (21.845 msec) */
96     /* XTAL = 12MHz, Period = 83.3 ns, ( {MOSCWTCR = 0x0E} 2
97     = 21.845 ms */
98 ffff86de SYSTEM.MOSCWTCR.BYTE = 0x0E;
99
100    /* 4194304 state (default)*/
101    /* wait over 12ms @PLL=192MHz(12MHz*16) */
102 ffff86e8 SYSTEM.PLLWTCR.BYTE = 0x0F;
103
104    /* x16 @PLL */

```

- The list of initialised system clocks is shown on the opposite screenshot.
- We will now skip past the hardware setup functions to look at the tutorial's main program code.

```

resetprg.c hwsetup.c X main.c
-
/* Configure the clocks as follows -
Clock Description          Frequency
-----
PLL Clock frequency.....192MHz
System Clock Frequency.....96MHz
Peripheral Module Clock B.....48MHz
FlashIF Clock.....48MHz
External Bus Clock.....48MHz */
SYSTEM.SCKCR.LONG = 0x21821211;


```

For further details regarding hardware configuration, please refer to the RSKRX63T User's Manual and the RX63T Hardware Manual.

## 4.2 Main Function

This section will examine the program code called from within the main() function.

- Find the main.c file from the Project Explorer, and then double-click it to open the file in the text editor.



- Set a breakpoint at the call to the main() function by double clicking the column next to void main (void).

```

113
114
115
116
117
118
119
120
121
122
123
124
125
126
127 ffff8a88 | Init_LCD();
128
129
130 ffff8a8c /* Displays the Renesas splash screen */
131 ffff8a9a Display_LCD(LCD_LINE1, "Renesas");
132 Display_LCD(LCD_LINE2, NICKNAME);
133
134 ffff8aa9 /* Begins the initial LED flash sequence */
135 Flash_LED();
136
137 ffff8aad /* Begins the ADC-varying flash Sequence */
138 Timer_ADC();
139
140 ffff8ab1 /* Begins the static variable test */
141 static_test();
  
```

The E1 emulator features an advanced logic-based event point trigger system, and full instruction on its use is outside the scope of this tutorial. For further details, please refer to the RX Family E1/E20 Emulator User's Manual

- Press 'Resume' on the  Debug toolbar.

- The code will execute to the **RSKRX63T-L** At this point all the device initialisation will have been completed. The code window will open 'main.c' and show the new position of the program counter.

- Right click the 'Flash\_LED()' function call and select 'Run to Line' to execute the program up to this line. The 'Init\_LCD()' function call enables and configures the LCD panel, and 'Display\_LCD()' will write "Renesas" on the top line and "RX63T-L" onto the bottom line

- Set a breakpoint on the 'timer\_adc()' function call by double-clicking in the breakpoint column

```

115
116
117
118
119
120
121
122
123
124
125
126
127 ffff8a88
128
129
130 ffff8a8c
131 ffff8a9a
132
133
134 ffff8aa9
135
136
137 ffff8aad
138
139
140 ffff8ab1
141
142
143 ffff8ab4
144

```

```

/*****
* Function Name : main
* Description   : The main program function. Display
                  onto the LCD display, then calls t
                  functions. The function then calls
                  before waiting in an infinite whil
* Argument      : none
* Return value  : none
*****/
void main (void)
{
    /* Initialise the debug LCD */
    Init_LCD();

    /* Displays the Renesas splash screen */
    Display_LCD(LCD_LINE1, "Renesas");
    Display_LCD(LCD_LINE2, NICKNAME);

    /* Begins the initial LED flash sequence */
    Flash_LED();

    /* Begins the ADC-varying flash Sequence */
    Timer_ADC();

    /* Begins the static variable test */
    static_test();

    /* Infinite while loop */
    while (1)
    {

```

```

133
134 ffff8aa9
135
136
137 ffff8aad
138
139
140 ffff8ab1
141
142
143 ffff8ab4

```

```

    /* Begins the initial LED flash sequence */
    Flash_LED();

    /* Begins the ADC-varying flash Sequence */
    Timer_ADC();

    /* Begins the static variable test */
    static_test();

    /* Infinite while loop */
    while (1)
    {

```

- Click the 'Step Into'  button to step into the 'Flash\_LED()' function.

- The program counter should now move into the Flash\_LED function definition. This function periodically polls the user switches and flashes all the LEDs 200 times or until a user switch has been pressed.

```

65
66 ffff85a4
67
68
69
70
71
72
73 ffff85a6
74
75
76 ffff85ac
77
78 ffff85df
79
80
81
82
83
84 ffff8601
85
86
87
88 ffff8637
89

```

```

void Flash_LED (void)
{
    /* Variable used to count down the number of
    static uint16_t flash_count = 0xC8;

    /* Declare a delay count variable */
    uint32_t ulled_Delay = 0;

    /* Flash the LEDs for 200 times or until a us
    while ((0 == g_switch_flag) && (--flash_coun
    {
        for (ulled_Delay = 0; ulled_Delay < 40000
        {
            /* delay */
        }

        /* Toggles the LEDs after a specific dela
        Toggle_LED();
    }

    /* Reset the g_switch_flag flag variable */
    g_switch_flag = 0;
}

```

- Click 'Resume' to continue the program, and then push any switch to proceed. The program should halt at the event point set on the Timer\_ADC function call.

- Press 'Step Into'  twice to step into the start\_timer function.

- The start\_timer function configures the timer CMT1 to periodically flash the LEDs. And timer CMT2 to provide a simple delay function.

- Press 'Step Return'  button to exit the start\_timer function, then press 'Step Into'.

The program should now reach the start\_adc function

- Press resume to continue with program execution.  The start\_adc function configures the ADC unit to make repeat conversions of the voltage from the potentiometer RV1.

- Set a breakpoint at 'static\_test'.

- Press F8 to resume the code,  where it will then halt at the break point on the static\_test function call.

```

102  /*****
103  * Function Name : start_timer
104  * Description   : Configures CMT channel 1 to call th
105  *               : function which starts the AD conver
106  * Argument     : none
107  * Return value  : none
108  *****/
109  static void start_timer (void)
110  {
111      /* Protection off */
112      SYSTEM.PRCR.WORD = 0xA503;
113
114      /* Cancel the CMT1 module clock stop mode */
115      MSTP_CMT1 = 0;
116
117      /* Cancel the CMT2 module clock stop mode */
118      MSTP_CMT2 = 0;
119
120      /* Protection on */
121      SYSTEM.PRCR.WORD = 0xA500;
122
123      /* Set CMT1 interrupt priority level to 10 */
124      TPR(CMT1, CMT1) = 0xA;
125
126  }
127
128  static void start_adc (void)
129  {
130      /* Protection off */
131      SYSTEM.PRCR.WORD = 0xA503;
132
133      /* Cancel the S12AD module clock stop mode */
134      MSTP_S12AD = 0;
135
136      /* Protection on */
137      SYSTEM.PRCR.WORD = 0xA500;
138
139      /* Clear the S12AD interrupt flag */
140      IR(S12AD, S12ADI) = 0x0;
141
142      /* Set the S12AD interrupt level to 5 */
143      IPR(S12AD, S12ADI) = 0x5;
144
145      /* Begins the ADC-varying flash Sequence */
146      Timer_ADC();
147
148      /* Begins the static variable test */
149      static_test();
150
151      /* Infinite while loop */
152      while (1)
153      {
154          /* Do nothing */
155      }
156  }
    
```

- Press F5 to step into the function. 
- The static\_test function initialises a character string with the contents of a static variable; then gradually replaces it, letter by letter, with another static string.
- Click 'Resume' or press F8 to resume the program code. You should observe the word 'STATIC' appear on the second LCD line, to be gradually replaced with the string 'TESTTEST'. The program then reverts the LCD back to the original message of 'RX63T144'.

```

152
153
154
155
156
157
158
159
160
161
162
163
164 ffff8ac0 static void static_test (void)
165 {
166     /* Declare loop count variable */
167 ffff8ac2 uint8_t uicount = 0;
168
169     /* Write cStr variable, "STATIC" to LCD */
170 ffff8ac8 Display_LCD(LCD_LINE2, cStr);
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

```


- This Press the 'Suspend' button to halt program execution. 

This is the extent of the tutorial code.

## 5. Additional Information

### Technical Support

For details on how to use e<sup>2</sup>studio, refer to the help file by opening e<sup>2</sup>studio and clicking 'Help' and selecting 'Help Contents'.



Parts of the sample code provided with the RSKRX63T144 can be reproduced using the 'Applilet3 for RX63T' code generator tool. Applilet can be downloaded from the Renesas website. Source files and functions generated by Applilet are prefixed with 'r\_' and 'R\_', respectively.

For information about the RX63T series microcontrollers refer to the RX63T Group Hardware Manual.

For information about the RX63T assembly language, refer to the RX600 Series Software Manual.

Online technical support and information is available at: <http://www.renesas.com/rskrx63t>

### Technical Contact Details

***Please refer to the contact details listed in section 7 of the "Quick Start Guide".***

General information on Renesas microcontrollers can be found on the Renesas website at: <http://www.renesas.com/>

### Trademarks

All brand or product names used in this manual are trademarks or registered trademarks of their respective companies or organisations.

### Copyright

This document may be, wholly or partially, subject to change without notice. All rights reserved. Duplication of this document, either in whole or part is prohibited without the written permission of Renesas Electronics Europe Limited.

© 2013 Renesas Electronics Europe Limited. All rights reserved.

© 2013 Renesas Electronics Corporation. All rights reserved.

© 2013 Renesas Solutions Corp. All rights reserved.

REVISION HISTORY	RSKRX63T Tutorial Manual
------------------	--------------------------

Rev.	Date	Description	
		Page	Summary
1.00	Dec 06, 2013	¾	First Edition issued

---

Renesas Starter Kit Tutorial Manual

Publication Date: Rev. 1.00 Dec 06, 2013

Published by: Renesas Electronics Corporation

---



## Renesas Electronics Corporation

<http://www.renesas.com>

### SALES OFFICES

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

**Renesas Electronics America Inc.**

2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130

**Renesas Electronics Canada Limited**

1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada  
Tel: +1-905-898-5441, Fax: +1-905-898-3220

**Renesas Electronics Europe Limited**

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K  
Tel: +44-1628-651-700, Fax: +44-1628-651-804

**Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-65030, Fax: +49-211-6503-1327

**Renesas Electronics (China) Co., Ltd.**

7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

**Renesas Electronics (Shanghai) Co., Ltd.**

Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China  
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

**Renesas Electronics Hong Kong Limited**

Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

**Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei, Taiwan  
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

**Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

**Renesas Electronics Malaysia Sdn.Bhd.**

Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

**Renesas Electronics Korea Co., Ltd.**

11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141

# RX63T144 Group