

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

M16C PC4701 Emulator Debugger V.1.02

User's Manual

Renesas Microcomputer Development
Environment System

Active X, Microsoft, MS-DOS, Visual Basic, Visual C++, Windows and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.

IBM and AT are registered trademarks of International Business Machines Corporation.

Intel and Pentium are registered trademarks of Intel Corporation.

Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated.

All other brand and product names are trademarks, registered trademarks or service marks of their respective holders.

Keep safety first in your circuit designs!

- Renesas Technology Corporation and Renesas Solutions Corporation put the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection of the Renesas Technology product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation, Renesas Solutions Corporation or a third party.
- Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation and Renesas Solutions Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors. Please also pay attention to information published by Renesas Technology Corporation and Renesas Solutions Corporation by various means, including the Renesas home page (<http://www.renesas.com>).
- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation and Renesas Solutions Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation or Renesas Solutions Corporation for further details on these materials or the products contained therein.

For inquiries about the contents of this document or product, fill in the text file the installer generates in the following directory and email to your local distributor.

\\SUPPORT\Product-name\SUPPORT.TXT

Renesas Tools Homepage <http://www.renesas.com/en/tools>

Overview

The High-performance Embedded Workshop is a Graphical User Interface intended to ease the development and debugging of applications written in C/C++ programming language and assembly language for Renesas microcomputers. Its aim is to provide a powerful yet intuitive way of accessing, observing and modifying the debugging platform in which the application is running.

This help explains the function as a "debugger" of High-performance Embedded Workshop.

Target System

The Debugger operates on the emulator PC4701 system.

Supported CPU

This help explains the debugging function corresponding to the following CPUs.

- M32C/80, M16C/80 Series
Note: In this help, the information which depends on this CPU is described as "for M32C".
- M16C/60, M16C/30, M16C/Tiny, M16C/20, M16C/10 Series
Note: In this help, the information which depends on this CPU is described as "for M16C/R8C".
- 740 Family
Note: In this help, the information which depends on this CPU is described as "for 740".

(Blank Page)

1. Features	1
1.1 Real-Time RAM Monitor Function.....	1
1.1.1 RAM Monitor Area	1
1.1.2 Sampling Period	2
1.1.3 Related Windows	2
1.2 Break Functions.....	3
1.2.1 Software Breaks Function.....	3
1.2.2 Hardware Break	4
1.2.3 Protect Break.....	5
1.3 Real-Time Trace Function	6
1.3.1 Trace Area.....	6
1.3.2 Trace Condition Setting	7
1.3.3 Trace Data Write Condition	7
1.4 Time Measurement Function	8
1.4.1 The Measurement Condition	8
1.5 Coverage Function	9
1.5.1 Coverage Measurement Area.....	9
1.5.2 Related Windows	9
1.6 Real-Time OS Debugging Function.....	10
1.7 GUI Input/Output Function	10
2. About the Emulator PC4701	11
2.1 Communication methods	11
2.2 Function table	11
3. Before starting the debugger	12
3.1 Communication method by emulator.....	12
3.1.1 USB Interface	12
3.1.2 LAN Interface	12
3.1.3 LPT Interface.....	12
3.1.4 Proprietary Parallel Interface.....	13
3.2 Download of Firmware.....	14
3.3 Setting before emulator starts.....	15
3.3.1 USB communication with the Emulator	15
3.3.2 LAN communication with the Emulator	16
3.3.3 Proprietary parallel communication with emulators by Windows XP/2000/NT 4.0.....	18
3.3.4 LAN communication with emulators by Windows Me/98/XP/2000.....	19
4. Preparation before Use	20
4.1 Workspaces, Projects, and Files	20
4.2 Starting the High-performance Embedded Workshop	21
4.2.1 Creating a New Workspace (Toolchain Used).....	22
4.2.2 Creating a New Workspace (Toolchain Not Used).....	27
4.3 Starting the Debugger	32
4.3.1 Connecting the Emulator	32
4.3.2 Ending the Emulator.....	32
5. Setup the Debugger	33
5.1 Init Dialog.....	33
5.1.1 MCU Tab.....	34
5.1.2 Debugging Information Tab.....	36
5.1.3 F/W and Work Area Tab.....	37
5.1.4 Memory Extension Mode Tab	38

5.1.5 Clock Tab	41
5.1.6 Script Tab.....	42
5.2 Setting of the Communication Interface	43
5.2.1 Setting of the USB Interface	43
5.2.2 Setting of the LPT Interface	44
5.2.3 Setting of the LAN Interface.....	45
5.2.4 Setting of the Parallel Interface.....	46
5.2.5 Setting of the Serial Interface.....	47
5.3 Setup the Debugger for M32C	48
5.3.1 Emem Dialog.....	48
5.4 Setup the Debugger for M16C/R8C.....	52
5.4.1 Map Command.....	52
5.5 Setup the Debugger for 740.....	53
5.5.1 Map Command.....	53
5.6 Method of making MCU file	54
5.6.1 Method of making MCU file (the M16C/R8C Debugger)	54
5.6.2 Method of making MCU file (the 740 Debugger)	55

Tutorial

57

6. Tutorial	59
6.1 Introduction.....	59
6.2 Usage	60
6.2.1 Step1 : Starting the Debugger	60
6.2.2 Step2 : Checking the Operation of RAM.....	61
6.2.3 Step3 : Downloading the Tutorial Program	62
6.2.4 Step4 : Setting a Breakpoint	64
6.2.5 Step5 : Executing the Program	65
6.2.6 Step6 : Reviewing Breakpoints	67
6.2.7 Step7 : Viewing Register	68
6.2.8 Step8 : Viewing Memory	69
6.2.9 Step9 : Watching Variables.....	70
6.2.10 Step10 : Stepping Through a Program	72
6.2.11 Step11 : Forced Breaking of Program Executions.....	75
6.2.12 Step12 : Displaying Local Variables	76
6.2.13 Step13 : Stack Trace Function	77
6.2.14 What Next?	78

Reference

79

7. Windows/Dialogs	81
7.1 RAM Monitor Window	82
7.1.1 Extended Menus	84
7.1.2 Setting the RAM monitor area.....	85
7.2 ASM Watch Window	86
7.2.1 Extended Menus	87
7.3 C Watch Window.....	88
7.3.1 Extended Menus	89
7.4 Coverage Window.....	90
7.4.1 Extended Menus	91
7.4.2 Refer to the Source Line/the Executed Address	92
7.5 Script Window	93

7.5.1	Extended Menus	94
7.6	S/W Break Point Setting Window	95
7.6.1	Command Button.....	96
7.6.2	Setting and Deleting a Break Points from Editor(Source) Window	97
7.7	H/W Break Point Setting Window.....	98
7.7.2	Specify the Combinatorial Condition.....	103
7.7.3	Specify the Process ID	104
7.7.4	Command Button.....	104
7.7.5	Specify the Events (Instruction Fetch).....	105
7.7.6	Specify the Events (Memory Access)	109
7.7.7	Specify the Events (Bit Access).....	133
7.7.8	Specify the Events (Interrupt)	135
7.7.9	Specify the Events (External Trigger Signal)	137
7.7.10	Specify the Event Combination Condition	139
7.7.11	Specify the Process ID	142
7.8	Protect Window	143
7.8.1	Extended Menus	143
7.9	Trace Point Setting Window.....	144
7.9.1	Specify the Trace Event.....	145
7.9.2	Specify the Combinatorial Condition.....	148
7.9.3	Specify the Process ID	149
7.9.4	Specify the Trace Range.....	149
7.9.5	Specify the Trace Write Condition.....	150
7.9.6	Command Button.....	150
7.9.7	Specify the Events (Instruction Fetch).....	151
7.9.8	Specify the Events (Memory Access)	151
7.9.9	Specify the Events (Bit Access).....	151
7.9.10	Specify the Events (Interrupt)	151
7.9.11	Specify the Events (External Trigger Signal)	151
7.9.12	Specify the Event Combination Condition	151
7.9.13	Specify the Process ID	151
7.9.14	Specify the write condition.....	152
7.10	Time Measurement Window.....	156
7.10.1	Specify the Time Measurement Event.....	157
7.10.2	Time Measurement Condition	161
7.10.3	Command Button.....	161
7.10.4	Specify the Events (Instruction Fetch).....	162
7.10.5	Specify the Events (Memory Access)	162
7.10.6	Specify the Events (Bit Access).....	162
7.10.7	Specify the Events (Interrupt)	162
7.10.8	Specify the Events (External Trigger Signal)	162
7.10.9	Set the Measurement Condition	163
7.11	Trace Window.....	167
7.11.1	Configuration of Bus Mode.....	167
7.11.2	Configuration of Disassemble Mode	169
7.11.3	Configuration of Data Access Mode	170
7.11.4	Configuration of Source Mode.....	171
7.11.5	Extended Menus	172
7.11.6	Display of bus information on the M32C Debugger.....	173
7.11.7	Display of bus information on the M16C/R8C Debugger.....	175
7.11.8	Display of bus information on the 740 Debugger.....	177
7.12	Data Trace Window.....	178
7.12.1	Extended Menus	179
7.13	GUI I/O Window.....	180
7.13.1	Extended Menus	181
7.14	MR Window	182
7.14.2	Display the Task Status	184

7.14.3	Display the Ready Queue Status	188
7.14.4	Display the Timeout Queue Status	189
7.14.5	Display the Event Flag Status	191
7.14.6	Display the Semaphore Status	193
7.14.7	Display the Mailbox Status	195
7.14.8	Display the Data Queue Status	197
7.14.9	Display the Cycle Handler Status	199
7.14.10	Display the Alarm Handler Status	201
7.14.11	Display the Memory Pool Status	202
7.14.12	Display the Task Context	204
7.15	MR Trace Window	206
7.15.1	Extended Menus	208
7.15.2	Refer the Execution History of Task(MRxx Window)	209
7.16	MR Analyze Window	215
7.16.1	Configuration of CPU Occupancy Status Display Mode	215
7.16.2	Configuration of Ready State Duration Display Mode	216
7.16.3	Configuration of System Call History Display Mode	216
7.16.4	Extended Menus	217
7.16.5	Analyze the Execution History of Task	217
7.17	MR Task Pause Window	220
7.17.1	About Task Pause Function	220
7.17.2	Extended Menus	221
7.17.3	Pause the Specified Task	222
7.18	Task Trace Window	227
7.18.1	Extended Menus	228
7.18.2	Refer the Execution History of Task(Taskxx Window)	229
7.19	Task Analyze Window	234
7.19.1	Extended Menus	234
7.19.2	Analyze the Execution History of Task	235
8.	Table of Script Commands	236
8.1	Table of Script Commands (classified by function)	236
8.1.1	Execution Commands	236
8.1.2	File Operation Commands	236
8.1.3	Register Operation Commands	237
8.1.4	Memory Operation Commands	237
8.1.5	Assemble/Disassemble Commands	237
8.1.6	Software Break Setting Commands	237
8.1.7	Hardware Break Setting Commands	238
8.1.8	Real-time Trace Commands	238
8.1.9	Coverage Measurement Commands	238
8.1.10	Script/Log File Commands	238
8.1.11	Program Display Commands	238
8.1.12	Map Commands	239
8.1.13	Clock Command	239
8.1.14	WatchDog Timer Commands	239
8.1.15	C Language Debugging Commands	239
8.1.16	Real-time OS Command	239
8.1.17	Utility Commands	239
8.2	Table of Script Commands (alphabetical order)	240
9.	Writing Script Files	242
9.1	Structural Elements of a Script File	242
9.1.1	Script Command	243
9.1.2	Assign Statement	243
9.1.3	Conditional Statement	243
9.1.4	Loop Statement(while,endw) and Break Statement	244
9.1.5	Comment statements	244

9.2 Writing Expressions.....	245
9.2.1 Constants	245
9.2.2 Symbols and labels	246
9.2.3 Macro Variables.....	247
9.2.4 Register variables.....	248
9.2.5 Memory variables.....	248
9.2.6 Line Nos.	248
9.2.7 Character constants	249
9.2.8 Operators	249
10. C/C++ Expressions	250
10.1 Writing C/C++ Expressions	250
10.1.1 Immediate Values.....	250
10.1.2 Scope Resolution.....	251
10.1.3 Mathematical Operators	251
10.1.4 Pointers	251
10.1.5 Reference.....	251
10.1.6 Sign Inversion.....	252
10.1.7 Member Reference Using Dot Operator	252
10.1.8 Member Reference Using Arrow.....	252
10.1.9 Pointers to Members.....	253
10.1.10 Parentheses.....	253
10.1.11 Arrays.....	253
10.1.12 Casting to Basic Types	253
10.1.13 Casting to typedef Types	254
10.1.14 Variable Name.....	254
10.1.15 Function Name	254
10.1.16 Character Constants.....	254
10.1.17 Character String Literals.....	254
10.2 Display Format of C/C++ Expressions	255
10.2.1 Enumeration Types	255
10.2.2 Basic Types	255
10.2.3 Pointer Types.....	256
10.2.4 Array Types.....	257
10.2.5 Function Types	257
10.2.6 Reference Types.....	257
10.2.7 Bit Field Types.....	257
10.2.8 When No C Symbol is Found	258
10.2.9 Syntax Errors.....	258
10.2.10 Structure and Union Types.....	258
11. Display the Cause of the Program Stoppage	259
12. Attention	260
12.1 Common Attention.....	260
12.1.1 File operation on Windows.....	260
12.1.2 Area where software breakpoint can be set	261
12.1.3 Get or set C variables	261
12.1.4 Function name in C++	262
12.1.5 Debugging multi modules	262
12.1.6 Synchronized debugging.....	262
12.1.7 Down-load of Firmware.....	262
12.1.8 Restriction of LPT port.....	263
12.1.9 Notes for coverage function.....	264
12.1.10 Emulator reset switch	264
12.1.11 Debugging Resource on Emulator	264
12.2 Attention of the M32C Debugger	265
12.2.1 Stack area used by the emulator	265

12.2.2	Interrupt stack pointer when resetting the target program	265
12.2.3	Option of C Compiler/Assembler/Linker	265
12.2.4	Target MCU HOLD terminal.....	265
12.2.5	Hardware Event	265
12.2.6	Time Measurement Resource.....	266
12.2.7	CPU rewrite	266
12.2.8	MR STK script command	266
12.3	Attention of the M16C/R8C Debugger	267
12.3.1	Map of stack area used by the emulator.....	267
12.3.2	Options for compiler, assembler, and linker	267
12.3.3	TASKING C Compiler	267
12.3.4	Target MCU HOLD terminal.....	267
12.3.5	Hardware Event	268
12.3.6	Operating frequency of MCU	268
12.3.7	The correspondence OS version of task pause function.....	268
12.3.8	Memory Space Expansion	268
12.3.9	Watch dog timer.....	268
12.3.10	CPU rewrite	269
12.3.11	MR STK script command	269
12.4	Attention of the 740 Debugger	270
12.4.1	Setting of Memory Map.....	270
12.4.2	Emulation Pod M37515T-RPD.....	270
12.4.3	Stack area used by the emulator	270
12.4.4	Specify the Clock.....	270
12.4.5	Watch dog timer.....	270
12.4.6	Option of C Compiler/Assembler/Linker	270
12.4.7	About the single-step execution and the program break function in the internal RAM area of the mcu	271
12.4.8	Debugging in the 16-Timer functions	271
12.4.9	Hardware Event	271
12.4.10	Operating frequency of MCU	271
12.5	Option of C Compiler/Assembler/Linker.....	272
12.5.1	When Using NCxx	272
12.5.2	When Using the Assembler Package for 740 Family.....	272
12.5.3	When Using the IAR C Compiler (EW)	273
12.5.4	When Using the IAR C Compiler (ICC).....	274
12.5.5	When Using the TASKING C Compiler (EDE)	275
12.5.6	When Using the TASKING C Compiler (CM)	275
12.5.7	When Using the IAR EC++ Compiler (EW)	276

Setup of Debugger

(Blank Page)

1. Features

1.1 Real-Time RAM Monitor Function


This function allows you to inspect changes of memory contents without impairing the realtime capability of target program execution.

The PC4701 emulator system contains a 1-Kbyte RAM monitor area (which cannot be divided into smaller areas).

This debugger supports the real time RAM monitor function which allows you to reference the memory data without sacrificing real time performance during execution of the target program.

1.1.1 RAM Monitor Area

This debugger provides a 1KB of RAM monitor area, which can be placed at any continuous addresses.



1.1.2 Sampling Period

Sampling cycle means the display update interval.

You can specify this function in any window which supports the RAM monitor. (The interval of 100 ms is set by default.)

The actual sampling cycle may take longer time than the specified cycle depending on the operating environment. (Sampling cycle depends on the following environments.)

- Communication interface
- Number of the RAM Monitor windows displayed
- Size of the RAM Monitor window displayed
- Number of ASM watch points within the RAM monitor area of the ASM Watch window
- Number of C watch points within the RAM monitor area of the C Watch window

1.1.3 Related Windows

The window where the function of the real time RAM monitor function can be used is shown below.

- RAM Monitor Window
- ASM Watch Window
- C Watch Window

1.2 Break Functions

1.2.1 Software Breaks Function

Software Break breaks the target program before execution of the command at the specified address. This break point is called software breakpoint.

The software breakpoint is set/reset in the Editor (Source) window or in the S/W Breakpoint Setting window. You can also disable/enable a software breakpoint temporarily.

You can specify up to 64 software breakpoints. When specifying two or more software breakpoints, the breakpoint combination is based on the OR logic. (Arrival to any one of breakpoints breaks the target program.)

1.2.1.1 Setting of software breakpoint

The software breakpoint can be set by the following windows.

- Editor (Source) Window
- S/W Break Point Setting Window

You can double-click the mouse to set/reset the software breakpoint in the Editor (Source) window.

You can also switch to temporarily disable/enable the software breakpoint in the S/W Breakpoint Setting window.

1.2.1.2 Area where software breakpoint can be set

The area which can be set for software breakpoint varies depending on the product.

For the areas available for software breakpoint, see the following:

"12.1.2 Area where software breakpoint can be set"

1.2.2 Hardware Break

This function causes the target program to stop upon detecting a data read/write to memory, instruction execution, or the rising/falling edge of the input signal fed from an external trace cable. The contents of events that can be set vary with each target MCU.

The following designations are available as break events:

- Address designation
 - Instruction fetch
 - Memory access
 - Bit access
- External trigger designation
- Interruption


The number of events that can be specified are six events of all. For the address designation method, instruction fetch and memory access allow the range designation and logical condition designation, in addition to the normal one-address designation. Moreover, instruction fetch allows you to specify the function name.

Memory access allows you to specify the comparison data to read/write data related to the specified address in the same manner as when setting the H/W breakpoint. It also allows mask designation to the comparison data.

These break events can be combined as below:

- Trace when all of the valid events are established (AND condition)
- Trace when all of the valid events are established at the same time (simultaneous AND condition)
- Trace when one of the valid events is established (OR condition)
- Trace upon entering a break state during state transition (State Transition condition)

When transitional conditions set in an interstate pass are met, a state transition occurs, in which case the target program can be made to stop upon entering a break state. The conceptual diagram shown below depicts the relationship between state and pass.



State transition break allows you to select "specified task only" (or "other than specified task") as the break condition to meet the real time OS.

1.2.3 Protect Break

This function causes the target program to stop upon detecting a data write to the ROM area or an access to an unused area (read/write or instruction execution).

Protect Break is a function to detect a write of data to the ROM area and an access (read, write, command execution) to an unused area and stop the target program.

1.2.3.1 Protect Attribute


You can specify the following attributes in byte.

- Access Disable
- Read Only
- R/W Enable

1.2.3.2 Access Protect Area

A protect area is a continuous 256-KB area starting from the 64KB boundary. Its start address is called protect base address.

The protect base address immediately after starting the emulator is set to 0h.



The entire protect area is set to "R/W Enable" by default at start of the emulator.

1.2.3.3 Set Method of Protect Break

The two types of designation methods are provided:

- To fetch the memory attribute from the target program section information
- To specify the memory attribute of any area

1.3 Real-Time Trace Function

This function records a target program execution history.

Up to 32K cycles of execution history can be recorded. This record allows inspecting the bus information, executed instructions, and source program execution path for each cycle.

The real-time trace function records the execution history of the target program.

The execution history is referred to in the tracing window.

The execution history can be referred to in the following mode.


- **BUS mode**
This mode allows you to inspect cycle-by-cycle bus information. The display content depends on the MCU and emulator system used. In addition to bus information, this mode allows disassemble, source line or data access information to be displayed in combination.
- **Disassemble mode**
This mode allows you to inspect the executed instructions. In addition to disassemble information, this mode allows source line or data access information to be displayed in combination.
- **Data access mode**
This mode allows you to inspect the data read/write cycles. In addition to data access information, this mode allows source line information to be displayed in combination.
- **Source mode**
This mode allows you to inspect the program execution path in the source program.

1.3.1 Trace Area

The 32K cycles execution history can be referred to with this debugger.

The trace area of the following 5 mode is being supported.

- **Break**
32K cycles before target program stops
- **Before**
32K cycles before trace point
- **About**
16K cycles either side of trace point
- **After**
32K cycles after trace point
- **Full**
Until 32K cycles are written in the trace memory



"Break" is set by default. To refer the execution history before stopping the target program, use "Break" (designation of trace event is not required).

To refer the execution history at any position, or to continue execution of the target program, specify the trace event and change the trace range.

1.3.2 Trace Condition Setting

The following designations are available as trace events:

- Address designation
 - Instruction fetch
 - Memory access
 - Bit access
- External trigger designation (eight events)
- Interruption

The number of events that can be specified are six events of all. These break events can be combined as below:

- Trace when all of the valid events are established (AND condition)
- Trace when all of the valid events are established at the same time (And(same time) condition)
- Trace when one of the valid events is established (OR condition)
- Trace upon entering a break state during state transition (State Transition condition)

You can select "specified task only" (or "other than specified task") as the trace condition to meet the real time OS.

1.3.3 Trace Data Write Condition

Trace data write conditions can be specified.

You can specify the following write conditions:

- Write conditions unlimited (default)
- Cycles from the start event established to the end event established
- Only cycles where the start event is established
- Cycles from the start event established to the start event unestablished
- Other than cycles from the start event established to the end event established
- Other than cycles where the start event is established
- Other than cycles from the start event established to the start event unestablished

1.4 Time Measurement Function

The time measurement function allows you to measure the maximum, minimum, and average execution times and measurement counts of a specified zone.

With this debugger, time can be measured up to four points simultaneously.

1.4.1 The Measurement Condition

The measurement condition of the zone time can specify the following in each measurement zone.

- Execution time of the specified function
- Time between two events
- Time between event establishments
- Time of event occurrence period

1.5 Coverage Function

Coverage Measurement is a function to record the addresses executed (accessed) by the target program (C0 coverage).

After stopping execution of the target program, you can understand which addresses are not executed yet.


By using the coverage measurement function in the test process, you can check for missing test items.

1.5.1 Coverage Measurement Area

The coverage measurement area is any continuous 256 KB area starting from the 64 KB boundary.

The starting address is called coverage base address.

The coverage base address immediately after starting the emulator is set to 0h.



1.5.2 Related Windows

Refer to the coverage measurement result in the following windows.

- Editor (Source) Window
- Memory Window
- Coverage Window

1.6 Real-Time OS Debugging Function

This function debugs the realtime OS-dependent parts of the target program that uses the realtime OS.

This function helps to show the status of the realtime OS and inspect a task execution history, etc.

The debugger for 740 can't show the status of the realtime OS.

1.7 GUI Input/Output Function

This function simulates the user target system's key input panel (buttons) and output panel on a window.

Buttons can be used for the input panel, and labels (strings) and LEDs can be used for the output panel.

2. About the Emulator PC4701

The PC4701 emulator system is a generic term used for the 8/16-bit MCU emulators. It can be used in combination with the emulation pod for the PC4701 to debug application programs for each MCU.

2.1 Communication methods

The supported communication methods vary with the type of emulator used.

I/F	Emulator		
	PC4701U	PC4701M	PC4701HS
USB	Support	-	-
LAN	Support	-	Support
LPT	Support	Support	-
Proprietary parallel	-	Support	Support
Serial	-	Support	Support

Depending on communication methods, it is necessary to set up some items before the debugger can be started. Please see "3.3 Setting before emulator starts "

2.2 Function table

The supported functions vary with the type of emulator used.

PC4701U/M/HS	
S/W Break	64 points
H/W Break	6 points
Real-Time Trace	32K Cycles
RAM Monitor	1K bytes area
C0 Coverage	256K bytes area
Time Measurement	Go to Stop / 4 points interval
Protect Break	Access Protect

3. Before starting the debugger

3.1 Communication method by emulator

The supported communication methods are as follows. (The supported communication methods vary with the type of emulator used.)

USB, LAN, LPT, Proprietary parallel, Serial

3.1.1 USB Interface

Supported only when using the PC4701U emulator.

- The supported host computer OS is Windows Me/98/2000/XP. USB communication cannot be used in any other OS.
- Compliant with USB Standard 1.1.
- Connections via USB hub are not supported.
- By connecting the host computer and the emulator with USB cable, it is possible to install the supported device drivers using a wizard.
- The necessary cable is included with the emulator.

3.1.2 LAN Interface

Supported only when using the PC4701U/HS emulator.

- The IP address, etc. must be set in the emulator before it can be connected in a LAN.
- To communicate with the emulator via a LAN on Windows Me/98/2000/XP, Windows' registry information must partly be modified.
- The PC4701U emulator in a LAN can be connected to the PC4701Us on another network connected to the LAN via a router.
- The emulators PC4701U and PC4701HS use different LAN cables. Specifically, the PC4701U uses LAN cable (10BASE-T only) generally available on the market, whereas the PC4701HS uses the LAN cable (10BASE-T/5) included with it.
- The host computer and the emulator can be connected directly.

3.1.3 LPT Interface

Supported only when using the PC4701U/M emulator.

- This communication uses the host computer's parallel (printer) interface.
- The necessary cable is included with the emulator.
- Four communication modes are supported that include ECP, EPP, Byte, and Nibble. Communication modes that can be supported depend on the host computer's BIOS settings. (Communication modes may not always be used even when they are supported by BIOS.)

3.1.4 Proprietary Parallel Interface

Supported only when using the PC4701HS emulator.

- The host computer must have a dedicated interface board, the PCA4202G02, incorporated in it (only the ISA bus is supported). The necessary cable is included with the emulator.
- When using this communication on Windows NT 4.0/2000/XP, a device driver must separately be set.

3.1.4.1 Serial Interface

Supported only when using the PC4701M/HS emulator.

- This communication uses the host computer's serial interface.
- The necessary cable is included with the emulator.

3.2 Download of Firmware

It is necessary to download the firmware which corresponds to connected Emulation Pod when the debugger is started to the emulator.


- You have changed your emulation pod.
- The firmware downloaded to the emulator is unknown one.
- You have setup the debugger for the first time.
- You have upgraded emulator debugger.

Press the system reset switch within two seconds after powering up the PC4701 to establish the maintenance mode.

This debugger searches the version of the firmware downloaded to the emulator at start. Also when the firmware downloaded to the emulator is of old version, a mode which drives this debugger to download firmware is set.

When this debugger gets started while the emulator is set in the mode which drives the debugger to download firmware forcedly, the following dialog is opened at start.

Click the OK button to download the firmware.



ATTENTION

- If the emulator being used is the PC4701HS, use other communication methods (dedicated parallel or serial) to download the firmware.
- Before the firmware can be downloaded by the emulator in a LAN connection, the IP address, etc. must first be registered in the emulator.

3.3 Setting before emulator starts

3.3.1 USB communication with the Emulator

Connection of USB devices is detected by Windows' Plug & Play function. The device driver needed for the connected USB device is automatically installed.

3.3.1.1 Install of USB device driver

The USB devices connected are detected by Windows' Plug & Play function. The installation wizard for USB device drivers starts after the device had been detected. The following shows the procedure for installing the USB device drivers.

1. Connect the host computer and the emulator with USB cable.
2. Set the emulator's communication interface switch to the "USB" position. Then turn on the power to the emulator.
3. The dialog box shown below appears.



Go on following the wizard, and a dialog box for specifying the setup information file (inf file) is displayed. Specify the musbdrv.inf file stored in a location below the directory where this debugger is installed.

ATTENTION

- Before the USB device drivers can be installed, the debugger you use must already be installed. Install this debugger first.
- USB communication can be used only in Windows Me/98/2000/XP, and cannot be used in any other OSs.
- When using Windows 2000/XP, a user who install the USB device driver need administrator rights.
- During installation, a message may be output indicating that the device driver proper musbdrv.sys cannot be found. In this case, specify the musbdrv.sys which is stored in the same directory as is the musbdrv.inf file.

3.3.2 LAN communication with the Emulator


Before the emulator can be connected in a LAN, the IP address, etc. must first be registered in the emulator. For the emulator in default settings, the utility "setip.exe" included with the debugger may be used to set the IP address, etc. in the emulator.

3.3.2.1 Setting of the LAN Interface using the SETIP.EXE


The utility "SETIP" included with this debugger may be used to set the IP address, etc. in the emulator while in default settings. SETIP detects the Emulator's in default settings that are connected to the same network. SETIP is stored in a location below the directory where this debugger is installed . The file name is "setip.exe".

To register the IP address in the emulator, follow the procedure described below.

1. Connect the emulator with LAN cable to the same network (same subnet) as the host computer is connected.
2. Set the emulator's communication interface switch to the "LAN" position. Then turn on the power to the emulator.
3. Start SETIP. When SETIP has started up, the dialog box shown below appears, choose the emulator of use, click the OK button.




4. Click the OK button, and showing information on the emulator connected to the network. (This information consists of the MAC address followed by the serial number of the emulator.)




To register the IP address, click the Next button. To cancel registration, click the Close button. If not displayed, check whether the communication interface switch is set correctly and after temporarily turning off the power, turn it back on again. Then click the Search button.

- Click the Next button, and the dialog box shown below appears. Set the IP address, subnet mask, port number, and default gateway IP address. When using the emulator on the same network's same subnet mask, the default gateway IP address may be omitted.



Use any 4-digit number to specify the port number. (Enter that number when starting the debugger.) For details about the contents of the IP address, subnet mask, and default gateway to be specified, contact your network administrator.

- Click the Set button on the dialog box. The IP address, etc. that have been set are registered in the emulator. When registered correctly, the dialog box shown below appears.



After checking the contents of the dialog box, click the OK button.

- Temporarily turn off the power to the emulator and turn it back on again. The registered IP address becomes effective after the emulator is powered up again.


ATTENTION

- If multiple Emulators in default settings are connected on the same network, only the first emulator detected is displayed.
- The emulators which have had an IP address already set cannot be detected by SETIP. In such a case, connect to the emulator through another communication interface and re-register the IP address from the Init dialog box that appears. For details on how to set IP addresses from the Init dialog box, see "5.2.3Setting of the LAN Interface."

3.3.3 Proprietary parallel communication with emulators by Windows XP/2000/NT 4.0

If you are using this debugger in a combination of Windows XP/2000/NT 4.0 + the parallel I/F, you need to specify the start address of I/O addresses (7 bytes) to the device driver for PCA4202G02, (The I/O address for PCA4202G02 is set to 100h initially.) You can set this setting with setPca4202.exe included with this debugger. The above programs are installed in the directory where this debugger is installed. At the first time of using this debugger, or when you want to change the I/O address for PCA4202G02 because of conflict with other devices, please follow the procedure of the setting described below.

1. Execute setPca4202.exe included with this debugger. The dialog box shown below will appear.



2. Find the I/O address that is set on the PCA4202G02 parallel board and input it in hexadecimal into the I/O Address input field. Click "OK" button.
3. Restart Windows XP/2000/NT 4.0.

ATTENTION

- Make sure setPca4202.exe is executed by one who is authorized as an Administrator. No one but the user who has the authority of an Administrator can install the device driver.
- For detail about parallel board PCA4202G02, refer to "PCA4202G02 Instruction Manual".

3.3.4 LAN communication with emulators by Windows Me/98/XP/2000

Please execute registry setting program (Sack.exe) before starting the debugger. It is necessary for LAN communication with emulators by Windows Me/98/XP/2000 to set the following registry.

OS	Key	Data
Windows Me/98	HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\VxD\MSTCP\SackOpts	0(REG_SZ)
Windows XP/2000	HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\Tcpip\Parameters\SackOpts	0(REG_DWORD)

You can clear the registry with executing the program "UnSack.exe". The above programs are installed in the directory where this debugger is installed.

ATTENTION

Make sure Sack.exe and UnSack.exe is executed by one who is authorized as an Administrator.(Windows XP/2000) No one but the user who has the authority of an Administrator can install the device driver.

Note

Windows Me/98/XP/2000 TCP supports "Selective Acknowledgments (SACK)" as documented in RFC 2018. SACK gives higher performance in the network which have high bandwidth and long round-trip delays like satellite channels.

SACK support is enabled by default in Windows Me/98/XP/2000. It is necessary for LAN communication with emulators by Windows Me/98/XP/2000 to disable SACK support. Setting the above registry can disable SACK support.

Note that when you use the network which have high bandwidth and long round-trip delays like satellite channels, the performance with SACK support disabled is lower than with enabled.


4. Preparation before Use

Please run the High-performance Embedded Workshop and connect the emulator .
In addition, in order to debug with this product, it is necessary to create a workspace.

4.1 Workspaces, Projects, and Files

Just as a word processor allows you to create and modify documents, this product allows you to create and modify workspaces.

A workspace can be thought of as a container of projects and, similarly, a project can be thought of as a container of project files. Thus, each workspace contains one or more projects and each project contains one or more files.




Workspaces allow you to group related projects together. For example, you may have an application that needs to be built for different processors or you may be developing an application and library at the same time. Projects can also be linked hierarchically within a workspace, which means that when one project is built all of its "child" projects are built first.

However, workspaces on their own are not very useful, we need to add a project to a workspace and then add files to that project before we can actually do anything.

4.2 Starting the High-performance Embedded Workshop

Activate the High-performance Embedded Workshop from [Programs] in the [Start] menu. The [Welcome!] dialog box is displayed.



In this dialog box, A workspace is created or displayed.

- [Create a new project workspace] radio button:
Creates a new workspace.
- [Open a recent project workspace] radio button:
Uses an existing workspace and displays the history of the opened workspace.
- [Browse to another project workspace] radio button:
Uses an existing workspace;
this radio button is used when the history of the opened workspace does not remain.

In the case of Selecting an Existing Workspace, select [Open a recent project workspace] or [Browse to another project workspace] radio button and select the workspace file (.hws).

Please refer to the following about the method to create a new workspace.

Refer to "4.2.1 Creating a New Workspace (Toolchain Used)"

Refer to "4.2.2 Creating a New Workspace (Toolchain Not Used)"

* When debugging the existing load module file with this product, a workspace is created by this method.

The method to create a new workspace depends on whether a toolchain is or is not in use. Note that this product does not include a toolchain. Use of a toolchain is available in an environment where the C/C++ compiler package for the CPU which you are using has been installed.

For details on this, refer to the manual attached to your C/C++ compiler package.


4.2.1 Creating a New Workspace (Toolchain Used)

4.2.1.1 Step1 : Creation of a new workspace

In the [Welcome!] dialog box that is displayed when the High-performance Embedded Workshop is activated, select the [Create a new project workspace] radio button and click the [OK] button.

Creation of a new workspace is started.

The following dialog box is displayed.




1. Select the target CPU family
In the [CPU family] combo box, select the target CPU family.
2. Select the target toolchain
In the [Tool chain] combo box, select the target toolchain name when using the toolchain.
3. Select the project type
In the [Project type] list box, select the project type to be used.
In this case, select "Application" .
(Please refer to the manual attached to your C/C++ compiler package about the details of the project type which can be chosen.)
4. Specify the workspace name and project name
 - In the [Workspace Name] edit box, enter the new workspace name.
 - In the [Project Name] edit box, enter the project name. When the project name is the same as the workspace name, it needs not be entered.
 - In the [Directory] edit box, enter the directory name in which the workspace will be created.
Click the [Browse...] button to select a directory.

After a setting, click the [OK] button.

4.2.1.2 Step2 : Setting for the Toolchain

A wizard for the project creation starts.



Here, the following contents are set.

- toolchain
- the setting for the real-time OS (when using)
- the setting for the startup file, heap area, stack area, and so on


Please set required information and click the [Next] button.

The contents of a setting change with C/C++ compiler packages of use. Please refer to the manual attached to your C/C++ compiler package about the details of the contents of a setting.

4.2.1.3 Step 3: Selecting of the Target Platform

Select the target system used for your debugging (emulator, simulator).

When the setting for the toolchain has been completed, the following dialog box is displayed.




1. Selecting of the Target type
In the [Target type] list box, select the target CPU type.
2. Selecting of the Target Platform
In the [Targets] area, the target for the session file used when this debugger is activated must be selected here.
Check the box against the target platform. (And choose other target as required.)

And click the [Next] button.

4.2.1.4 Step4 : Setting the Configuration File Name

Set the configuration file name for each of the all selected target.


The configuration file saves the state of High-performance Embedded Workshop except for the target (emulator, simulator).



The default name is already set. If it is not necessary to change, please click the [next] button as it is.

4.2.1.5 Step5 : The check of a created file name

Finally, confirm the file name you create. The files which will be generated by the High-performance Embedded Workshop are displayed. If you want to change the file name, select and click it then enter the new name.



This is the end of the emulator settings.

Exit the Project Generator following the instructions on the screen.


4.2.2 Creating a New Workspace (Toolchain Not Used)

When debugging the existing load module file with this product, a workspace is created by this method.

4.2.2.1 Step1 : Creation of a new workspace

In the [Welcome!] dialog box that is displayed when the High-performance Embedded Workshop is activated, select the [Create a new project workspace] radio button and click the [OK] button.

Creation of a new workspace is started. The following dialog box is displayed.




1. Select the target CPU family
In the [CPU family] combo box, select the target CPU family.
2. Select the target toolchain
In the [Tool chain] combo box, select "None". In this case, toolchain is not used.
(When the toolchain has not been installed, the fixed information is displayed in this combo box.)
3. Select the project type
(When the toolchain is not used, it is displayed on a [Project Type] list box as "Debugger only - Target Name". Select it. (When two or more project types are displayed, please select one of them.)
4. Specify the workspace name and project name
 - In the [Workspace Name] edit box, enter the new workspace name.
 - In the [Project Name] edit box, enter the project name. When the project name is the same as the workspace name, it needs not be entered.
 - In the [Directory] edit box, enter the directory name in which the workspace will be created. Click the [Browse...] button to select a directory.

After a setting, click the [OK] button.

4.2.2.2 Step 2: Selecting of the Target Platform

Select the target system used for your debugging (emulator, simulator).
A wizard starts and the following dialog box is displayed.




1. Selecting of the Target type
In the [Target type] list box, select the target CPU type.
2. Selecting of the Target Platform
In the [Targets] area, the target for the session file used when this debugger is activated must be selected here.
Check the box against the target platform. (And choose other target as required.)

And click the [Next] button.

4.2.2.3 Step3 : Setting the Configuration File Name

Set the configuration file name for each of the all selected target.

The configuration file saves the state of High-performance Embedded Workshop except for the target (emulator, simulator).



The default name is already set. If it is not necessary to change, please click the [next] button as it is. This is the end of the emulator settings.


Exit the Project Generator following the instructions on the screen.

And the dialog for the setup of a debugger is also displayed at this time . If preparation of an emulator is completed, set up the debugger in this dialog box and connect with an emulator.

4.2.2.4 Step4 : Registering the Load modules to be downloaded

Finally, register the load module file to be used.

Select [Debug Settings...] from the [Debug] menu to open the [Debug Settings] dialog box.




1. Select the product name to be connected in the [Target] drop-down list box.
2. Select the format of the load module to be downloaded in the [Default Debug Format] drop-down list box.

Format Name	Contents
IEEE695_RENESAS	IEEE-695 format file (When Using NCxx)
IEEE695_IAR	IEEE-695 format file (When Using IAR cross tool)
IEEE695_TASKING	IEEE-695 format file (When Using Tasking cross tool)
ELF/DWARF2_IAR	ELF/DWARF2 format file (When Using IAR cross tool)
ELF/DWARF2_TASKING	ELF/DWARF2 format file (When Using Tasking cross tool)
Intel-Hex+Sym	Intel Hex format file with Symbol format file (When Using SRA74)
IEEE695_ICC740	IEEE-695 format file (When Using ICC740)

This debugger does not support the object formats, which are not shown in the drop down list.

3. Then register the corresponding download module in the [Download Modules] list box. A download module can be specified in the dialog opened with a [Add...] button.



- Enter the offset at which to load the download module in the [Offset] edit box.
- Select the format of the download module in the [Format] edit box. Please refer to the upper table about the format name of a download module.
- Enter the full path and filename of the download module in the [Filename] edit box.
- Specifies the access size for the current download module in the [Access size] list box.

After that, click the [OK] button.

ATTENTION

"Access size" and "Perform memory verify during download" is ignored. The access size is always set to 1 and the verification does not work.

4.3 Starting the Debugger


The debugging can be started by connecting with an emulator.

4.3.1 Connecting the Emulator

Connect the emulator by simply switching the session file to one in which the setting for the emulator use has been registered.

The session file is created by default. The session file has information about the target selected when a project was created.

In the circled list box in the following tool bars, select the session name including the character string of the target to connect.



After the session name is selected, the dialog box for setting the debugger is displayed and the emulator will be connected.

4.3.2 Ending the Emulator

The emulator can be exited by using the following methods:


1. Selecting the "DefaultSession"
Select the "DefaultSession" in the list box that was used at the time of emulator connection.
2. Exiting the High-performance Embedded Workshop
Select [Exit] from the [File] menu. High-performance Embedded Workshop will be ended.

The message box, that asks whether to save a session, will be displayed when an emulator is exited. If necessary to save it, click the [Yes] button. If not necessary, click the [No] button.

5. Setup the Debugger

5.1 Init Dialog

The Init dialog box is provided for setting the items that need to be set when the debugger starts up. The contents set from this dialog box are also effective the next time the debugger starts. The data set in this dialog remains effective for the next start.



The tabs available on this dialog box vary with each product used. For details, click the desired tab name shown in the table below.


Tab Name	Product Name		
	The debugger for M32C	The debugger for M16C/R8C	The debugger for 740
MCU	Exist	exist	exist
Debugging Information	Exist	exist	exist
F/W and Work Area	---	exist	---
Memory Extension Mode	---	exist	---
Clock	Exist	exist	exist
Script	Exist	exist	exist

You can open the Init dialog using either one of the following methods:

- After the debugger gets started, select Menu - [Setup] -> [Emulator] -> [System...].
- Start Debugger while holding down the Ctrl key.

5.1.1 MCU Tab

The specified content becomes effective when the next being start.



5.1.1.1 Specifying the MCU file



Click the "Refer" button.

The File Selection dialog is opened. Specify the corresponding MCU file.

- An MCU file contains the information specific to the target MCU.
- The specified MCU file is displayed in the MCU area of the MCU tab.

If the corresponding MCU file is not contained in the debugger/emulation pod, you must create a new MCU file. To do this, see the following:

"5.6 Method of making MCU file "

5.1.1.2 Setting of the Communication Interface

The displayed data varies depending on the specified communication interface.

The available communication interface varies depending on the products.

The following shows the setting for each communication interface.

- Refer to "5.2.1Setting of the USB Interface"
- Refer to "5.2.2Setting of the LPT Interface"
- Refer to "5.2.3Setting of the LAN Interface"
- Refer to "5.2.4Setting of the Parallel Interface"
- Refer to "5.2.5Setting of the Serial Interface"

5.1.1.3 Executing Self-Check

Specify this option to execute self-check* on the emulator when the debugger starts up.




Be sure to select the above check box only when you want to perform self-check at startup. Specify this option in the following cases:

- When the firmware cannot be downloaded
- When although the firmware is successfully downloaded, the debugger does not start
- When the MCU goes wild or something is wrong with the trace results and you want to check whether the emulator is operating normally.

Select the check box to close the Init dialog box. After connecting to the emulator and confirming the firmware, the debugger will immediately start self-check on the emulator. (Self-check takes about 30 seconds to 1 minute.)

If an error is found in this self-check, the debugger displays the content of the error and is finished. When the self-check terminated normally, the dialog box shown below is displayed. When you click OK, the debugger starts up directly in that state.



This specification is effective only when the debugger starts up.

* Self-check refers to the function to check the emulator's internal circuit boards for memory condition, etc. Refer to the user's manual of your emulator for details about the self-check function.

5.1.1.4 Specifying Clock Frequency

Specify the operation clock of the target MCU within the MCU Clock field in the Time Count Resource group (in units of MHz).




Specify the MCU clock and the clock divide ratio.

If you are using the MCU at 10 MHz divided by 4, for example, enter "10" on the left side and "4" on the right side of the text box.

If no values are set in the clock divide ratio specifying area, it is assumed that the clock is not divided (i.e., the same as you would specify the value 1).

5.1.1.5 Using/unusing the watchdog timer


Specify whether or not to use the watchdog timer. (By default, the watchdog timer is unused.) This specification exist for the M32C debugger only.



When debugging the target system that uses a watchdog timer, select the check box shown above.


5.1.2 Debugging Information Tab

The specified content becomes effective when the next being download.



5.1.2.1 display the compiler used and its object format

Display the compiler used and its object file format.



Please specify the compiler used and its object file format in the dialog opened by menu [Debug] -> [Debug Settings...].

5.1.2.2 Specify the Storing of Debugging Information

There are two methods for storing debugging information: on-memory and on-demand.

Select one of these two methods. (The on-memory method is selected by default.)

To select the on-demand method, click the On Demand check box.

- On-memory method
Debugging information is stored in the internal memory of your computer.
This method is suitable when the load module (target program) size is small.
- On-demand method
Debugging information is stored in a reusable temporary file on the hard disk of your computer.
Because the stored debugging information is reused, the next time you download the same load module it can be downloaded at high speed.
This method is suitable when the load module (target program) size is large.

Notes

- If the load module size is large, the on-memory method may be inefficient because it requires a very large amount of time for downloading. In such a case, select the on-demand method.
- In the on-demand method, a folder in which to store a reusable temporary file is created in the folder that contains the downloaded load module. This folder is named after the load module name by the word "~INDEX_" to it. If the load module name is "sample.abs", for example, the folder name is "~INDEX_sample". This folder is not deleted even after quitting the debugger.

5.1.3 F/W and Work Area Tab

The specified content becomes effective when the next being start. In this tab, only the debugger for M16C/R8C exists.

The screenshot shows a configuration dialog box with two main sections. The top section, labeled 'F/W', contains two radio buttons: 'Default' (which is selected) and 'Select'. Below these is a list box labeled 'F/W Name' containing the value 'M30600'. The bottom section, labeled 'Work Area', contains a text box labeled 'Work Area Start Address' with the value '2c00'.

5.1.3.1 Select the Firmware File

This is a close-up of the 'F/W' configuration group. It shows the 'Default' radio button selected and the 'Select' radio button unselected. The 'F/W Name' list box is populated with 'M30600'.

Usually, click the Default radio button in the F/W group.

Click the Select radio button when you have to download firmware different from the one described in the MCU file.

The F/W Name list box is enabled only when you click the Select radio button.

5.1.3.2 Specify the Work Area

This is a close-up of the 'Work Area' configuration group. It shows a text box labeled 'Work Area Start Address' with the value '2c00' entered.

In the Work Area Start Address field in the Work Area group, specify the top address of the area to be used as the work area.

The emulator uses the MCU internal reservation area (unused area) as the debugging work area (about 10 bytes).

Specify the work area so that it is accommodated in its MCU internal reservation area.


The default work area top address is 2C00h.

To debug a microcomputer (ex. 20K-byte RAM version if the M16C/62 group) whose work area is within the internal RAM area, you must change the work area.

5.1.4 Memory Extension Mode Tab


This tab enabled only when the MCU tab in the Init dialog is used to specify the MCU file of the microcomputer (M16C/62 group) which supports the memory space expansion function.

The specified data remains effective for the next start. In this tab, only the debugger for M16C/R8C exists.



5.1.4.1 Select the Memory Space Extension Mode

Select the memory space extension mode.



- When you use a normal mode, Please click the "Normal" radio button.
- When you use extension mode 1, Please click the "Mode1" radio button.
- When you use extension mode 2, Please click the "Mode2" radio button.

The data of the eighth line of the selected MCU (data which specifies whether or not memory extension mode is required) is used to determine whether or not memory extension mode has to be selected.

If the eighth line contains a '1', The memory extension mode selection area is active. If the line contains a '0' or nothing, the memory extension mode selection area is inactive.

ATTENTION

The functions may be restricted depending on the type of memory space expansion mode.

Extension Mode 1

- When the memory space expansion area is displayed in the dis-assemble mode in the Program window or the Source window, the displayed data may be different from what you would expect through the operation accompanying redrawing of the window, such as up/down scroll, during execution of the target program.
- The following emulator functions are implemented by analyzing the bus information (address bus, data bus).
 - RAM monitor function (RAM Monitor window, C Watch window)
 - Coverage measurement function (Coverage window, Coverage command)
 - Memory protect function (Protect window, Protect command)

MCU accesses the program bank if Fetch (command) is specified for the bank duplicated area, and the data bank if Read/Write is specified for the bank duplicated area. In above cases, a signal which can distinguish which bank accesses the bus information is not output. Therefore, the above function may not work as expected.

- The memory reference commands are added, which reference the internal ROM in the bank duplicated area in the dump format (see the table below).

You cannot use the DA command during execution of the target program.

Command name	Abbreviation
DumpByte2	DB2
DumpWord2	DW2
DumpLword2	DL2

- If you use the Memory Reference/Change command for the bank duplicated area before MCU is switched from the normal mode to the memory space expansion mode1 by the target program, the function may not work as expected.
- The memory map shows the following data after the debugger gets started.

Start Address	End Address	Map	Attention
00000	003FF	External	Cannot be changed (SFR area).
00400	03FFF	Internal	The internal RAM area cannot be changed.
04000	2FFFF	External	Cannot be changed.
30000	FFFFFF	Internal	

Extension Mode 2

- The memory reference commands are added, which reference the internal ROM in the bank duplicated area in the dump format (see the table below).

A memory reference command with the bank specification is added. The memory reference/the change to the bank repetition area must use the following commands.

Command name	Abbreviation
DumpByte2	DB2
DumpWord2	DW2
DumpLword2	DL2
SetMemoryByte2	MB2
SetMemoryWord2	MW2
SetMemoryLword2	ML2
FillByte2	FB2
FillWord2	FW2
FillLword2	FL2
Move2	-
MoveWord2	MoveW2

- The following emulator functions are implemented by analyzing the bus information (address bus, data bus).
 - RAM monitor function (RAM Monitor window, C Watch window)
 - Coverage measurement function (Coverage window, Coverage command)
 - Memory protect function (Protect window, Protect command)
 - Hardware event (H/W break event*, Real-time trace event*, Time measurement event)

MCU switches the bank to be accessed based on the value in the bank selection register. A signal which can distinguish which bank accesses the bus information is not output. Therefore, the above function may work as expected.

*By specifying Simultaneous And (AND logic) (same time) for the hardware event and the bank selection register, both of which are detected as the combined condition in the State Transient Break/Trace window, the hardware event for the bank duplicated area can be detected.

- If you use the Memory Reference/Change command for the bank duplicated area before MCU is switched from the normal mode to the memory space expansion mode 2 by the target program, the function may not work as expected.
- The memory map shows the following data after the debugger gets started.

Start Address	End Address	Map	Attention
00000	003FF	External	Cannot be changed (SFR area).
00400	3FFFF	Internal	The internal RAM area cannot be changed.
40000	BFFFF	External	Cannot be changed.
C0000	FFFFFF	Internal	

5.1.5 Clock Tab

The specified content becomes effective when the next being start.



The image shows a screenshot of the 'Clock Tab' settings in a debugger. It features two sections: 'Main' and 'Sub'. Each section contains two radio button options: 'Internal' and 'External'. In the 'Main' section, the 'Internal' radio button is selected. In the 'Sub' section, the 'External' radio button is selected.

5.1.5.1 Specify the Target Clock

Change the setting by synchronizing with the clock used by the target microcomputer. (Internal is set by default.)

(The debugger for 740 does not have designation of Sub clock.)



This is an identical screenshot to the one above, showing the 'Clock Tab' settings. The 'Main' section has 'Internal' selected, and the 'Sub' section has 'External' selected.

Select Internal to set the internal clock, and External to set the external clock.

5.1.6 Script Tab

The specified content becomes effective when the next being start.



5.1.6.1 Automatically Execute the Script Commands

To automatically execute the script command at start of Debugger, click the "Refer" button to specify the script file to be executed.



By clicking the "Refer" button, the File Selection dialog is opened.

The specified script file is displayed in the "Init File:" field.

To disable auto-execution of the script command, erase a character string displayed in the "Init File:" field.

5.2 Setting of the Communication Interface

5.2.1 Setting of the USB Interface

USB communication uses the personal computer's USB interface. It is compliant with USB 1.1.

USB communication can only be used on the PC4701U emulator.

Before USB communication can be performed, the computer must have a dedicated device driver installed in it. For details on how to install USB device drivers, see "3.3.1.1 Install of USB device driver."

For connection by USB communication, click the "USB" radio button on the MCU tab.



The screenshot shows a control panel for the MCU tab. At the top, there are five radio buttons for selecting the communication interface: Parallel, Serial, LAN, LPT, and USB. The USB radio button is selected. Below the radio buttons, there is a label "Serial No:" followed by a text input field with a dropdown arrow on the right. To the right of the input field is a button labeled "Target..."


The currently USB-connected emulators are listed in the Serial No. area. Select the serial No. of the emulator you want to connect.

5.2.2 Setting of the LPT Interface

LPT communication uses a parallel interface (printer interface) of the personal computer.

LPT communication can only be used on the PC4701U/M emulator.

To set the LPT communication, click the "LPT" radio button of the MCU tab in the Init dialog. The setting looks like the figure below.



The screenshot shows a dialog box for setting the LPT interface. At the top, there are five radio buttons: Parallel, Serial, LAN, LPT (which is selected), and USB. Below the radio buttons, there are two dropdown menus. The first is labeled 'Type:' and is set to 'AUTO'. The second is labeled 'I/O Address:' and is set to '378h'. To the right of the dropdown menus, there is a 'Target...' button and a 'Self Check' checkbox which is currently unchecked.

Specify the mode for data transfers in the Type field.

- The LPT interface has four modes for data transfers, Nibble, Byte, ECP, and EPP. Their modes are documented in the IEEE-1284 standard. The mode possible to use depends on the PC with the debugger.
- When selecting AUTO, the debugger detect the LPT interface at the start and select a mode possible to use which give better performance automatically. In some PC, the debugger cannot detect the most suitable mode. Check the mode which the LPT interface in the PC have and select it from Nibble, Byte, ECP or EPP, if cannot.
- Start the BIOS setup program of the PC for checking the mode possible to use. How to start and use the BIOS setup program depends on each PC, so refer the manuals of the PC.

Display of BIOS Setup	Communication Mode
SPP, Standard Parallel Port, Output Only	Nibble
Bidirectional, Bi-directional	Byte
ECP, Extended Capabilities Port	ECP
EPP, Enhanced Parallel Port	EPP

The address displayed in the parallel port base address field is the I/O address.

Specify the I/O address set in the BIOS setup program, in the I/O Address field. (The following addresses are possible to be specified)

- 378h
- 278h

5.2.3 Setting of the LAN Interface

LAN communication uses a LAN interface of the personal computer.

Before using LAN, you must register the emulator IP address, port number and subnet mask to the emulator itself (Otherwise, LAN is not available).

Then, set LAN communication.


LAN communication can only be used on the PC4701U/HS emulator.

LAN communication with emulators by Windows Me/98/2000/XP

It is necessary for LAN communication with emulators by Windows Me/98/2000/XP to set the registry. For details, see "3.3 Setting before emulator starts".

5.2.3.1 Setting the IP Address and Subnet Mask

Start the debugger using other communication method. After it gets started, select Menu - [Setup]->[Emulator]->[System...] to open the Init dialog. Then, click the Target button of MCU tab. The Target dialog will be opened.



Specify the emulator IP address in the IP Address field, port number in the Port field, and subnet mask in the SubNetMask field. (The emulator IP address must be registered in the network environment in advance.)

When the PC7501 or PC4701U is used, the Default Gateway area becomes effective. Please specify the IP address of the default gateway. When the PC7501 or PC4701U is used on the identical sub net mask of identical network, it is possible to omit the IP address of the default gateway.


- Specify the IP address, subnet mask and Default Gateway in decimal byte by byte, by separating every 4 bytes with a period. For details on the IP address and subnet mask, consult with your network manager.
- A port number set in the Port field is used to identify the communication process of the server (emulator) in LAN (TCP/IP) communications. Specify the port number which has been set in the emulator in hexadecimal. (Do not add a prefix which shows a base.)

Click the "OK" button in the Target dialog. The Target dialog is then closed and the Init dialog appears again. Click the "OK" button.

Then, exit from the debugger.

5.2.3.2 Setting of the LAN Interface

To set the LAN communication, click the "LAN" radio button of the MCU tab in the Init dialog. The setting looks like the figure below.



The screenshot shows a dialog box with five radio buttons at the top: Parallel, Serial, LAN (selected), LPT, and USB. Below the buttons are two text input fields: 'IP Address:' containing '10.15.63.151' and 'Port:' containing '4700'. To the right of the IP field is a 'Target...' button, and below the Port field is a 'Self Check' checkbox.

Specify the IP address of the connected emulator in the IP address field.

Specify the IP address, in bytes, in decimal. Delimit each 4 bytes with a period. The port No. is the ID No. for the communication process of the server (emulator) on the LAN (TCP/IP).

Specify, in hexadecimal (Don't describe prefix which shows a cardinal number), the port No. set on the emulator.

5.2.3.3 LAN connection by couple 1 with emulator

Emulators can be connected by LAN (TCP/IP) to a commercially available LAN card inserted in a PC by using a cross conversion cable for 10BASE-T (also commercially available). A HUB is not necessary in this case.

The cross conversion cable for 10BASE-T converts the male connector of the 10BASE-T of a straight LAN cable that is included with the emulators to that of a cross LAN cable.

Connect a cross conversion cable to the male connector of the 10BASE-T of the straight LAN cable connected to the emulator; then, connect the male connector of the cross conversion cable to the LAN card.


The LAN communications can be set up the same way as normal one.

5.2.4 Setting of the Parallel Interface

Special parallel communication uses a special parallel interface board PCA4202G02 (option), which is inserted in the extension slot (ISA bus) of the personal computer.

Special parallel communication can only be used on the PC4701HS emulator.

To set the parallel communication, click the "Parallel" radio button of the MCU tab in the Init dialog. The setting looks like the figure below.



The screenshot shows a dialog box with five radio buttons at the top: Parallel (selected), Serial, LAN, LPT, and USB. Below the buttons are two fields: 'Host:' with a dropdown menu showing 'IBM-PC/AT' and 'I/O Address:' with a text input field containing '100'. To the right of the Host field is a 'Target...' button, and below the I/O Address field is a 'Self Check' checkbox.

Specify the I/O address in the I/O Address field, which is the I/O address set on the parallel interface board, in hexadecimal (Don't describe prefix which shows a cardinal number).

- Please specify the value of the hexadecimal number for the I/O address. (Don't describe prefix which shows a cardinal number)
- For detail about parallel board PCA4202G02, refer to "PCA4202G02 Instruction Manual".

ATTENTION

Combination of Windows NT 4.0/2000/XP and Parallel Interface

It is necessary to set the I/O address used for the device driver for a parallel communication.

Please refer to "Setting before emulator starts"3.3 Setting before emulator starts"


5.2.5 Setting of the Serial Interface

Serial communication uses a serial interface (RS-232C) of the personal computer.

This communication method is available for all the PC4701 emulator series.

Serial communication can only be used on the PC4701M/HS emulator.

To set the Serial communication, click the "Serial" radio button of the MCU tab in the Init dialog. The setting looks like the figure below.




The image shows a dialog box for setting the serial interface. At the top, there are five radio buttons: "Parallel", "Serial", "LAN", "LPT", and "USB". The "Serial" radio button is selected. Below the radio buttons, there are two rows of controls. The first row has a label "Port:" followed by a dropdown menu showing "COM1" and a "Target..." button. The second row has a label "Baud Rate:" followed by a dropdown menu showing "38400" and a checkbox labeled "Self Check".

Specify the communications port in the Port field and the baud rate in the Baud Rate field.

5.3 Setup the Debugger for M32C

5.3.1 Emem Dialog

In the Emem dialog box, setting information on the user target. The Emem dialog box opens after closing the Init dialog box.



The tabs available on this dialog box vary with each product used. For details, click the desired tab name shown in the table below.


Tab Name	Contents
Status	Specify the processor mode.
Emulation Memory	Specify the emulation memory area.

To keep the Emem dialog box closed next time the debugger is started, check "Next Hide" at the bottom of the Emem dialog box. You can open the Emem dialog using either one of the following methods:

- After the debugger gets started, select Menu - [Setup] -> [Emulator] -> [Target...].

5.3.1.1 Status Tab

The specified content becomes effective when the next being start.



5.3.1.1.1. *Select the Processor Mode*

Specify the processor mode for the target system.




Either the following can be specified.

- Single-chip Mode
Single-chip Mode
- Memory Expansion
Memory Expansion Mode
- Microprocessor
Microprocessor Mode

5.3.1.1.2. *Inspecting the MCU status*


Clicking this tab displays the status of each MCU pin. It allows to check whether the MCU pin status matches the processor mode to be set.



If the slider is at the middle position, it means that the value is indeterminate.

5.3.1.2 Emulation Memory Tab

The specified content becomes effective when the next being start.



5.3.1.2.1. *Debug monitor's bank address settings*

This product allocates a 64-Kbyte contiguous address area as the emulator's work area for use by the debug monitor.

Specify any bank that the target system does not use. The debug monitor uses a 64-Kbyte area from the start address of the specified bank.

(Example: If the specified bank is "F0," then the debug monitor uses a 64-Kbyte area beginning with address F000000h.)



Debug Monitor Bank Address:

- The bank specified here cannot have its contents referenced or set. The contents of this area when displayed in the Memory window or the Program/Source window's disassemble display mode may not be correct.
- The following bank addresses cannot be specified:
 - MCU internal resources (e.g., SFR and RAM areas)
 - DRAM area and multiplexed area
 - Interrupt vector area

5.3.1.2.2. *Automatic emulation memory allocation for the internal ROM*

When single-chip or memory extension mode is selected, emulation memory is automatically allocated to the internal ROM area.

The automatically allocated internal ROM address range is displayed in this field.




Internal ROM Area: F80000 - FFFFFFF is allocated.

5.3.1.2.3. *Emulation memory allocation for an extended area*

When memory extension or microprocessor mode is selected, emulation memory can be allocated to the extended area to be debugged (in up to four areas).

Here, allocate memory for the debug target area and specify its mapping information.



	Bank	Length	Map
Area 1:	<input type="text" value="c0"/>	<input type="text" value="1MB"/>	<input type="text" value="INTERNAL"/>
Area 2:	<input type="text" value="c2"/>	<input type="text" value="256KB"/>	<input type="text" value="EXTERNAL"/>
Area 3:	<input type="text" value="0"/>	<input type="text" value="256KB"/>	<input type="text" value="No Use"/>
Area 4:	<input type="text" value="0"/>	<input type="text" value="256KB"/>	<input type="text" value="No Use"/>

Follow the procedure described below.

Bank (Set bank address)	Specify the bank address of the debug target area to be allocated in hexadecimal. If specified as C0, C00000h is the start address of the debug target area.
Length (Specify size of area)	Specify the size of the debug target area (256 bytes or 1 Mbytes). If Length is specified to be "256 bytes," banks 00, 04, 08, and up to FC (every four banks) are specified for Bank; if Length is specified to be "1 Mbytes," banks 00, 10, 20, and up to F0 (every 16 banks) are specified for Bank.
Map (Specify area map)	Specify the mapping information ("Internal" or "External") for the specified area. If no area is specified, select "No Use." Internal The area specified to be "Internal" is mapped into the internal area (emulation memory). External The area specified to be "External" is mapped into the external area (external resources in the target system).

- Areas for which "No Use" is selected for Map and those not specified here are mapped into external areas.
If compared to the case where areas are explicitly specified to be "External," the only difference is a download speed. (Downloading into these areas is slower than downloading into the areas specified to be "External.")
- The internal ROM area is automatically mapped into the emulation memory. Therefore, there is no need to set here.
- Be careful that the debug areas will not overlap.
- Make sure the total size of the specified debug target areas does not exceed the emulation memory size of the emulation pod used.
The size of emulation memory that can be allocated varies with each emulation pod. (Consult the user's manual of your emulation pod.)

The setting of the emulation memory area varies depending on the specified processor mode.

- Single-chip Mode
You do not need to specify the area to be assigned as the emulation memory.
The internal ROM area is automatically mapped into the emulation memory. The address range of the automatically mapped area is displayed in the Internal ROM Area: field.
- Memory Expansion Mode(8bit and 16bit)
If you have an area to be assigned as the emulation memory in addition to internal ROM area, specify it separately.
The internal ROM area is automatically mapped into the emulation memory. The address range of the automatically mapped area is displayed in the Internal ROM Area: field.
- Microprocessor Mode(8bit and 16bit)
Specify the area to be assigned separately. (There is no area which is automatically assigned.)

ATTENTION

- The mapping setting data specified using the Map command is not reflected to the Emem dialog box.
- Set the emulation memory areas in the order of usage priority.
The emulation memory areas to be set by the Map command are numbered, ignoring the unused (Not Use) areas.
Accordingly, the emulation memory areas set in the Emem dialog box and the emulation memory area numbers set by the Map command will be mismatched.

5.4 Setup the Debugger for M16C/R8C

5.4.1 Map Command

The memory map information must be altered to suit the target microcomputer's memory space by Map command.

Area	Mapping	Note
SFR	External	
Internal RAM	Internal	
Internal ROM	Internal	
External ROM	External	Memory Expansion Mode, Microprocessor Mode

Note

- The emulator temporarily uses the area from FFCh to FFFFh as a stack. Set this area as Internal. If you want to set this area to External be sure to prepare read-/write-unprotected memory for the area.
- When using the memory space expansion function on the M16C/62 Series microcomputer, set the areas whose addresses are duplicated to External. (The duplicated area depends on memory.)
 - Memory space expansion mode 1: 4000h to 2FFFFh
 - Memory space expansion mode 2: 40000h to BFFFFh

5.5 Setup the Debugger for 740

5.5.1 Map Command

The memory map information must be altered to suit the target microcomputer's memory space by Map command.

Area	Mapping	Note
SFR	External	
RAM	External	
Internal ROM	Internal	
External ROM	External	Memory Expansion Mode, Microprocessor Mode

- Internal
Enables the emulator's internal resources. The internal ROM area must be set for Internal because it is always emulated with the emulator's internal resources. If an external area is not allocated memory, you can use the emulator's internal memory by setting that area for Internal.
- External
Enables resources external to the emulator (including the internal SFR and RAM areas). The internal SFR and internal RAM areas must always be set for External. To enable the memory allocated for an external area, set that area for External.

The memory map attributes immediately after the emulator has started up are External for 0h-3FFFh and Internal for 4000h-FFFFh. Use the MAP command to look up or alter the memory map information. Execute the MAP command from the script window.

ATTENTION

- [the case that the internal ROM area is located to the address before 4000h]
If the internal ROM area of the target mcu is located to the address before 4000h, please change the mapping of this area to INTERNAL.
Example)
when the internal ROM area is located from 1080h:
1080 to 3FFF -> Internal
- [About special settings when using the M38000TL2-FPD]
Always set the internal SFR and internal RAM areas for External. However, if the target MCU's RAM area is larger than the RAM included in the emulator MCU, set that area for Internal.
Example)
When the RAM area included in the emulator MCU is 40-1FF and the target MCU's internal RAM area is 40-2FF
40 to 1FF -> External
200 to 2FF -> Internal

5.6 Method of making MCU file

5.6.1 Method of making MCU file (the M16C/R8C Debugger)

The following content is sequentially described in the MCU file.

Specify the MCU name to the file name, and specify "mcu" to the file extension.

1. Start address of SFR area
2. End address of SFR area
3. Start address of internal RAM area
4. End address of internal RAM area
5. Start address of ROM area
6. End address of ROM area
7. File name of the Firmware *1
8. MCU type (whether memory space extension mode has to be specified or not)*2

Specify the addresses in hex format, and don't add any prefix which describe its radix.

*1 Specify the addresses in hex format, and don't add any prefix which describe its radix.

MCU	Firmware file name
M16C/60 group	M30600
M16C/61 group	M30600
M16C/62 group	M30620B
M16C/20 series	M30620B

There is a case that the emulation pod need the different firmware from the listed firmware, when the emulation pod is re-modeled.

*2 Specify whether the MCU: supports the memory space extension function or not.

When the MCU supports the function (EX: M16C/62 group), specify "1", the other case, specify "0".

Only when "1" is specified, the setting for memory space extension mode is available in Memory Extension Mode tab of INIT Dialog

ATTENTION

- The areas specified as the ROM in the MCU file are write-protected from the program. Even if the write command is executed to the area, no value is written. However, you can use the Dump command to write values to memory. (This is enabled only when the Internal area is mapped by the MAP command.)
- If the RAM is assigned to the same area, you must change the setting of the MCU file.

5.6.1.1 Example

0
3FF
400
2BFF
F0000
FFFFFF
M30600
0

5.6.2 Method of making MCU file (the 740 Debugger)

The following content is sequentially described in the MCU file.

Please describe information on 1-4 referring to the data book on MCU used.

1. Number of stack page selection bit
2. Address of CPU mode register
3. End address of stack*1
4. Address of reset vector
5. POD number*2
6. Firmware name
7. MCU Information No.*3

*1End address of stack

Specify the last address of the area to be used as the stack. Consider the initial value of the stack page selection bit in the CPU mode register. (The initial value of the stack page selection bit depends on the microcomputer.) For a microcomputer which sets the stack page selection bit initial value to "0", the allowable designation range is a 0 page address range (0h to FFh). For a microcomputer which sets the stack page selection bit initial value to "1", the allowable designation range is a 1 page address range (100h to 1FFh).

*2POD number

Pod Name	POD No.	Firmware File	Correspondence MCU
M38000T-FPD	0	M38000	7200/7450/7470/38000/ 7500Series(7507,7510,7515,7520 Group) *4
M38000TL-FPD			
M38000TL2-FPD			
M37207T-RPD	80	M38000	M37102,M37201,M37202,M37204,M37207
M37515T-RPD	40	M38000	7515/3850/3851 Group
M37610T-RPD	2	M37600	7610 Group
M37640T-RPD	4	M37600	7640 Group
M37690T-RPD	1	M37600	7690 Group
M38749T-RPD	40	M38000	3874Group

*4MCU where emulator MCU does not exist is excluded.

Target firmware name

Omit "u.s", "h.s", or "l.s", which mean types of emulators.

*3MCU Information No.

Please describe the MCU information No. referring to the following tables.

MCU Name	MCU Information No.
M3753x,M3754x	01
M376xx	02
Others	00

ATTENTION

For a new MCU, new POD number, new firmware name and new MCU information number may be used.

5.6.2.1 Example

2
3B
FF
FFFC
0
M38000
00

Tutorial

(Blank Page)

6. Tutorial

6.1 Introduction

This section describes the main functions of this debugger by using a tutorial program. The tutorial programs are installed to the directory ¥Workspace¥Tutorial of the drive you installed High-performance Embedded Workshop. There are workspaces for each targets and each MCUs. Please select the corresponding one to your system, and open the workspace file (*.hws) from the menu [Open Workspace...].

The tutorial program is based on the C program that sorts ten random data items in ascending or descending order.

The tutorial program performs the following actions:

- The tutorial function generates random data to be sorted.
- The sort function sorts the generated random data in ascending order.
- The change function then sorts the data in descending order.

Note

After recompilation, the addresses may differ from those given in this section.

When using the assembler package for 740 family

The tutorial program for the assembler package for 740 family is prepared. If you use the assembler package for 740 family, please use it.

- Please read this tutorial with replacing function names with subroutine name. (e.g. replace "function sort()" with "subroutine sort")
- About the source file name, also please replace it with the corresponding one.
- The diagrams in this tutorial are for C program. The displayed diagram for the assembler program may different from them.
- Step9 and Step12 are descriptions of C program.

6.2 Usage

Please follow these instructions:

6.2.1 Step1 : Starting the Debugger

6.2.1.1 Preparation before Use

To run the High-performance Embedded Workshop and connect the emulator, refer to "4 Preparation before Use".

6.2.1.2 Setup the Debugger

If it connects with an emulator, the dialog box for setting up a debugger will be displayed. Please set up the debugger in this dialog box.

To setup the debugger in this dialog box, refer to "5 Setup the Debugger".

After the setup of a debugger, it will function as a debugger.

6.2.2 Step2 : Checking the Operation of RAM


Check that RAM is operating correctly. Display and edit the contents of the memory in the [Memory] window to check that the memory is operating correctly.

Note

The memory can be installed on the board in some microcomputers. In this case, however, the above way of checking the operation of memory may be inadequate. It is recommended that a program for checking the memory be created.

6.2.2.1 Checking the Operation of RAM


Select [Memory] from the [CPU] submenu of the [View] menu and enter the RAM address (Here, enter H'400) in the [Display Address] edit boxes. The [Scroll Start Address] and [Scroll End Address] editing box is left to a default setting. (By default, the scroll range is set to 0h to the maximum address of MCU.)



Note

The settings of the RAM area differ depending on the product. For details, refer to the hardware manual.

Click the [OK] button. The [Memory] window is displayed and shows the specified memory area.




Placing the mouse cursor on a point in the display of data in the [Memory] window and double-clicking allows the values at that point to be changed.

6.2.3 Step3 : Downloading the Tutorial Program

6.2.3.1 Downloading the Tutorial Program

Download the object program to be debugged. The download file and the address to be downloaded will depend on the target mcu you use. Please replace the screen image and addresses with corresponding one to your target mcu.


- The Debugger for M16C/R8C or M32C
Select [Download module] from [Tutorial.x30] under [Download modules].
- The Debugger for 740
If you use the C Compiler Package for 740 Family, select [Download module] from [Tutorial.695] under [Download modules].
If you use the Assembler Package for 740 Family, select [Download module] from [Tutorial.hex] under [Download modules].



6.2.3.2 Displaying the Source Program

This debugger allows the user to debug a user program at the source level.

Double-click [tutorial.c] under [C source file]. A [Editor(Source)] window opens and the contents of a "Tutorial.c" file are displayed.



Select the [Format Views...] option from the [Setup] menu to set a font and size that are legible, if necessary.

Initially the [Editor(Source)] window shows the start of the user program, but the user can use the scroll bar to scroll through the user program and look at the other statements.

6.2.4 Step4 : Setting a Breakpoint


A software breakpoint is a basic debugging function.

The [Editor(Source)] window provides a very simple way of setting a software breakpoint at any point in a program.

6.2.4.1 Setting a Software Breakpoint

For example, to set a software breakpoint at the sort function call:

Double-click the [S/W breakpoints] column on the line containing the sort function call.



```
tutorial.c
28 f0227      init(&sam);
29
30 f0234      for (i = 0; i < 10; i++) {
31 f023f          j = rand();
32 f024b          if(j < 0) {
33 f0250              j = -j;
34
35 f0259              a[i] = j;
36          }
37 f026f          sort(a);
38 f0276          change(a);
39
40 f027d          sam.s0=a[0];
41 f0285          sam.s1=a[1];
42 f028d          sam.s2=a[2];
43 f0295          sam.s3=a[3];
44 f029d          sam.s4=a[4];
45 f02a5          sam.s5=a[5];
46 f02ad          sam.s6=a[6];
47 f02b5          sam.s7=a[7];
48 f02bd          sam.s8=a[8];
49 f02c5          sam.s9=a[9];
```


The red symbol will appear on the line containing the sort function call. This shows that a softwarebreak breakpoint has been set.

6.2.5 Step5 : Executing the Program


Execute the program as described in the following:

6.2.5.1 Resetting of CPU


By default, CPU is not reset after downloading a program.

To reset the CPU, select [Reset CPU] from the [Debug] menu, or click the [Reset CPU] button  on the toolbar.

6.2.5.2 Executing the Program

To execute the program, select [Go] from the [Debug] menu, or click the [Go] button  on the toolbar.

The program will be executed up to the breakpoint that has been set, and an arrow will be displayed in the [S/W Breakpoints] column to show the position that the program has halted.



```

tutorial.c
28  f0227  init(&sam);
29
30  f0234  for (i = 0; i < 10; i++) {
31  f023f      j = rand();
32  f024b      if(j < 0) {
33  f0250          j = -j;
34
35  f0259      }
36          a[i] = j;
37  f026f  }
38  f0276  sort(a);
39      change(a);
40
41  f027d      sam.s0=a[0];
42  f0285      sam.s1=a[1];
43  f028d      sam.s2=a[2];
44  f0295      sam.s3=a[3];
45  f029d      sam.s4=a[4];
46  f02a5      sam.s5=a[5];
47  f02ad      sam.s6=a[6];
48  f02b5      sam.s7=a[7];
49  f02bd      sam.s8=a[8];
50  f02c5      sam.s9=a[9];


```

Note


When the source file is displayed after a break, a path of the source file may be inquired. In this case, please specify the location of a source file.

6.2.5.3 Reviewing Cause of the Break

The break factor is displayed in the [Output] window.



The user can also see the cause of the break that occurred last time in the [Status] window. Select [Status] from the [CPU] submenu of the [View] menu. After the [Status] window is displayed, open the [Platform] sheet, and check the Status of Cause of last break.




Please refer to "11 Display the Cause of the Program Stoppage " about the notation of a break factor.

6.2.6 Step6 : Reviewing Breakpoints

The user can see all the breakpoints set in the program in the [S/W Break Points] window.

6.2.6.1 Reviewing Breakpoints

Select [S/W Break Points] from the [Break] submenu of the [View] menu. The [S/W Break Points] window is displayed.




This window allows the user to set or change breakpoints, define new breakpoints, and delete, enable, or disable breakpoints.

6.2.7 Step7 : Viewing Register

The user can see all registers/flags value in the [Register] window.

6.2.7.1 Viewing Register

Select [Registers] from the [CPU] submenu of the [View] menu. The [Register] window is displayed. The figure below shows a Register window of the debugger for M16C/R8C.



N...	Value	R...
R0	0024	Hex
R1	0F00	Hex
R2	0000	Hex
R3	0000	Hex
A0	06E6	Hex
A1	0000	Hex
FB	0718	Hex
USP	06C2	Hex
ISP	0A20	Hex
PC	0F026F	Hex
SB	0400	Hex
INTB	0FFD00	Hex

IPL	U	I	O	B	S	Z	D	C
0	1	0	0	0	0	1	0	1

6.2.7.2 Setting the Register Value

You can change a register/flag value from this window.

Double-click the register line to be changed. The dialog is opened. Enter the value to be changed.



PC - Set Value

Value : 0F026F

Radix : Hex

Set As: Whole Register


OK Cancel

6.2.8 Step8 : Viewing Memory


When the label name is specified, the user can view the memory contents that the label has been registered in the [ASM Watch] window.

6.2.8.1 Viewing Memory

For example, to view the memory contents corresponding to `__msize` in word size:
Select [ASM Watch] from the [Symbol] submenu of the [View] menu, open the [ASM Watch] window.
And click the [ASM Watch] window with the right-hand mouse button and select [Add...] from the popup menu, enter `__msize` in the [Address] edit box, and set Word in the [Size] combo box.



Click the [OK] button. The [ASM Watch] window showing the specified area of memory is displayed.



6.2.9 Step9 : Watching Variables


As the user steps through a program, it is possible to watch that the values of variables used in the user program are changed.

If the downloaded program is the program generated by the assembler package for 740 family, you can not watch variables in C watch window.


6.2.9.1 Watching Variables

For example, set a watch on the long-type array a declared at the beginning of the program, by using the following procedure:

Click the left of displayed array a in the [Editor(Source)] window to position the cursor, and select [Add C Watch...] with the right-hand mouse button. The [Watch] tab of [C watch] window in which the variable is displayed opens.



The user can click mark '+' at the left side of array a in the [C Watch] window to watch all the elements.



6.2.9.2 Registering Variable


The user can also add a variable to the [C Watch] window by specifying its name.

Click the [C Watch] window with the right-hand mouse button and select [Add...] from the popup menu.

The following dialog box will be displayed. Enter variable i.



Click the [OK] button. The [C Watch] window will now also show the int-type variable i.



6.2.10 Step10 : Stepping Through a Program

This debugger provides a range of step menu commands that allow efficient program debugging.

1. Step In
Executes each statement, including statements within functions(subroutines).
2. Step Out
Steps out of a function(subroutine), and stops at the statement following the statement in the program that called the function(subroutine).
3. Step Over
Executes a function(subroutine) call in a single step.
4. Step...
Steps the specified times repeatedly at a specified rate.

6.2.10.1 Executing [Step In] Command

The [Step In] command steps into the called function(subroutine) and stops at the first statement of the called function(subroutine).

To step through the sort function, select [Step In] from the [Debug] menu, or click the [Step In] button



on the toolbar.


The PC cursor moves to the first statement of the sort function in the [Editor(Source)] window.

```
sort.c
16 f0087      p_sam->s5 = 0;
17 f009f      p_sam->s6 = 0;
18 f00b7      p_sam->s7 = 0;
19 f00cf      p_sam->s8 = 0;
20 f00e7      p_sam->s9 = 0;
21 f00ff      }
22
23           sort(long #a)
24 f0102      ↪ {
25           long t;
26           int i, j, k, gap;
27
28           gap = 5;
29           while( gap > 0 ){
30               for( k=0; k<gap; k++){
31                   for( i=k+gap; i<10; i=i+gap ){
32                       for( j=i-gap; j>=k; j=j-gap){
33                           if( a[j]>a[j+gap]){
34                               t = a[j];
35                               a[j] = a[j+gap];
```


6.2.10.2 Executing [Step Out] Command

The [Step Out] command steps out of the called function(subroutine) and stops at the next statement of the calling statement in the main function.

To step out of the sort function, select [Step Out] from the [Debug] menu, or click the [Step Out]

button  on the toolbar.

The PC cursor slips out of a sort function, and moves to the position before a change function.



```
tutorial.c
31 f023f j = rand();
32 f024b if(j < 0) {
33 f0250 j = -j;
34 }
35 f0259 a[i] = j;
36 }
37 f026f sort(a);
38 f0276 change(a);
39
40 f027d sam.s0=a[0];
41 f0285 sam.s1=a[1];
42 f028d sam.s2=a[2];
43 f0295 sam.s3=a[3];
44 f029d sam.s4=a[4];
```

Note

It takes time to execute this function. When the calling source is clarified, use [Go To Cursor].


6.2.10.3 Executing [Step Over] Command

The [Step Over] command executes a function(subroutine) call as a single step and stops at the next statement of the main program.

To step through all statements in the change function at a single step, select [Step Over] from the

[Debug] menu, or click the [Step Over] button  on the toolbar.

The PC cursor moves to the next position of a change function.




6.2.11 Step11 : Forced Breaking of Program Executions

This debugger can force a break in the execution of a program.


6.2.11.1 Forced Breaking of Program Executions

Cancel all breaks.

To execute the remaining sections of the main function, select [Go] from the [Debug] menu or the [Go]

button  on the toolbar.

The program goes into an endless loop. To force a break in execution, select [Halt Program] from the

[Debug] menu or the [Halt] button  on the toolbar.

6.2.12 Step12 : Displaying Local Variables

The user can display local variables in a function using the [C Watch] window.

If the downloaded program is the program generated by the assembler package for 740 family, you can not watch variables in C watch window.


6.2.12.1 Displaying Local Variables

For example, we will examine the local variables in the tutorial function, which declares four local variables: a, j, i, and sam.

Select [C Watch] from the [Symbol] submenu of the [View] menu. The [C Watch] window is displayed. By default, [C watch] window has four tabs as following:

- [Watch] tab
Only the variable which the user registered is displayed.
- [Local] tab
All the local variables that can be referred to by the scope in which the the PC exists are displayed. If a scope is changed by program execution, the contents of the [Local] tab will also change.
- [File Local] tab
All the file local variables of the file scope in which the PC exists are displayed. If a file scope is changed by program execution, the contents of the [File Local] tab will also change.
- [Global] tab
All the global variables currently used by the downloaded program are displayed.

Please choose the [Local] tab, when you display a local variable.



Click mark '+' at the left side of array a in the [Locals] window to display the elements.

When the user refers to the elements of array a before and after the execution of the sort function, it is clarified that random data is sorted in descending order.


6.2.13 Step13 : Stack Trace Function

The debugger uses the information on the stack to display the names of functions in the sequence of calls that led to the function to which the program counter is currently pointing.

The debugger for 740 doesn't support the stack trace function.

6.2.13.1 Reference the function call status


Double-click the [S/W Breakpoints] column in the sort function and set a software breakpoint.



To execute the user program from the reset vector address, select [Reset Go] from the [Debug] menu,

or click the [Reset Go] button  on the toolbar.

After the break in program execution, select [Stack Trace] from the [Code] submenu of the [View] menu to open the [Stack Trace] window.



The upper figure shows that the position of the program counter is currently at the selected line of the sort() function, and that the sort() function is called from the tutorial() function.

6.2.14 What Next?

This tutorial has described the usage of this debugger.

Sophisticated debugging can be carried out by using the emulation functions that the emulator offers. This provides for effective investigation of hardware and software problems by accurately isolating and identifying the conditions under which such problems arise.

Reference

(Blank Page)

7. Windows/Dialogs

The window of this debugger is shown below.

When the window name is clicked, the reference is displayed.

Window Name	View Menu
RAM Monitor Window	[View]->[CPU]->[RamMonitor]
ASM Watch Window	[View]->[Symbol]->[ASMWatch]
C Watch Window	[View]->[Symbol]->[CWatch]
Coverage Window	[View]->[Code]->[Coverage]
Script Window	[View]->[Script]
S/W Break Point Setting Window	[View]->[Break]->[S/W Break Points]
H/W Break Point Setting Window	[View]->[Break]->[H/W Break Points]
Protect Window	[View]->[Break]->[Protect]
Trace Point Setting Window	[View]->[Trace]->[Trace Points]
Time Measurement Window	[View]->[Trace]->[Time Measure]
Trace Window	[View]->[Trace]->[Trace]
Data Trace Window	[View]->[Trace]->[Data Trace]
GUI I/O Window	[View]->[Graphic]->[GUI I/O]
MR Window *	[View]->[RTOS]->[MR]
MR Trace Window *	[View]->[RTOS]->[MR Trace]
MR Analyze Window *	[View]->[RTOS]->[MR Analyze]
MR Task Pause Window *	[View]->[RTOS]->[MR Task Pause]
Task Trace Window	[View]->[RTOS]->[Task Trace]
Task Analyze Window	[View]->[RTOS]->[Task Analyze]

*: The 740 debuggers are not supported.


For the reference of the following windows, refer to the help attached to a High-performance Embedded Workshop main part.

- Differences Window
- Map Window
- Command Line Window
- Workspace Window
- Output Window
- Disassembly Window
- Memory Window
- IO Window
- Status Window
- Register Window
- Image Window
- Waveform Window
- Stack Trace Window

7.1 RAM Monitor Window

The RAM monitor window is a window in which changes of memory contents are displayed while running the target program.

The relevant memory contents are displayed in dump form in the RAM monitor area by using the realtime RAM monitor function. The displayed contents are updated at given intervals (by default, every 100 ms) while running the target program.



- This system provides a 1Kbytes of RAM monitor area, which can be placed at any continuous addresses.
- The RAM monitor area can be changed to any desired address range.
Refer to "7.1.2 Setting the RAM monitor area" for details on how to change the RAM monitor area. The default RAM monitor area is mapped into a 1-Kbyte area beginning with the start address of the internal RAM.
- The display content updating interval can be set for each window individually.
The actual updating interval at which the display contents are actually updated while running the target program is shown in the title field of the Address display area.
- The background colors of the data display and code display areas are predetermined by access attribute, as shown below.

Access attribute	Background color
Read accessed address	Green
Write accessed address	Red
Non-accessed address	White

The background colors can be changed.

ATTENTION

- The RAM monitor window shows the data that have been accessed through the bus. Therefore, changes are not reflected in the displayed data unless they have been accessed via the target program as in the case where memory is rewritten directly from an external I/O.
- If the data in the RAM monitor area are displayed in lengths other than the byte, it is possible that the data will have different memory access attributes in byte units. If bytes in one data have a different access attribute as in this case, those data are enclosed in parentheses when displayed in the window. In that case, the background color shows the access attribute of the first byte of the data.

```
001B 00C8 00D2 0000 007C
0000 0000 0000 0000 0000
0000 (007C) FF8C 0000 0000
0000 0000 0000 0050 0000
```

- The displayed access attributes are initialized by downloading the target program.
- The interval time at which intervals the display is updated may be longer than the specified interval depending on the operating condition (shown below).
 - Host machine performance/load condition
 - Communication interface
 - Window size (memory display range) or the number of windows displayed

7.1.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.


Menu		Function
RAM Monitor Area...		Set RAM monitor base address.
Sampling Period...		Set RAM monitor sampling period.
Clear		Clear access attribute.
Up		Moves display position to the immediately preceding RAM monitor area (smaller address)
Down		Moves display position to the immediately following RAM monitor area (larger address)
Address...		Display from specified address.
Scroll Area...		Specify scroll range.
Data Length	1byte	Display in 1Byte unit.
	2bytes	Display in 2Byte unit.
	4bytes	Display in 4Byte unit.
	8bytes	Display in 8Byte unit.
Radix	Hex	Display in Hexadecimal.
	Dec	Display in Decimal.
	Single Dec	Display in Signed Decimal.
	Oct	Display in Octdecimal.
	Bin	Display in Binary.
Code	ASCII	Display as ASCII character.
	SJIS	Display as SJIS character.
	JIS	Display as JIS character.
	UNICODE	Display as UNICODE character.
	EUC	Display as EUC character.
	Float	Display as Floating-point.
	Double	Display as Double Floating-point.
Layout	Label	Switch display or non-display of Label area.
	Register	Switch display or non-display of Register area.
	Code	Switch display or non-display of Code area.
Column...		Set the number of columns displayed on one line.
Split		Split window.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.1.2 Setting the RAM monitor area

Choose the popup menu [RAM Monitor Area...] in the RAM monitor window.

The Set RRAM Area dialog box shown below will appear.

The start address of the currently set RAM monitor area and the range of the RAM monitor area are displayed in the Start and the Area fields of this dialog box. (No values can be entered in the Size field.)



Use this dialog box to change the position of the RAM monitor area.

- Specify the RAM monitor area by its start address. The size cannot be changed (fixed to 1 Kbyte).
- The start address can be specified in 0x10 byte units.
If you specify a non-aligned address value, it is rounded off to the nearest address value in 0x10 byte units before being set.

7.1.2.1 Changing the RAM Monitor Area


The start address of the RAM monitor area can be changed.

Specify the start address of the RAM monitor area in the Start field of the Set RRAM Area dialog box. (No values can be entered in the Size field.)

7.2 ASM Watch Window

The ASM watch window is a window in which you can register specific addresses as watchpoints and inspect memory contents at those addresses.

If a registered address resides within the RAM monitor area, the memory content at that address is updated at given intervals (by default, every 100 ms) during program execution.



- The addresses to be registered are called the "watchpoints." One of the following can be registered:
 - Address (can be specified using a symbol)
 - Address + Bit number
 - Bit symbol
- The registered watchpoints are saved in the debugger when the ASM watch window is closed and are automatically registered when the window is reopened.
- If symbols or bit symbols are specified for the watchpoints, the watchpoint addresses are recalculated when downloading the target program.
- The invalid watchpoints are marked by "-<not active>-" when displayed on the screen.
- The order in which the watchpoints are listed can be changed by a drag-and-drop operation.
- The watchpoint expressions, sizes, radices and datas can be changed by in-place editing.

ATTENTION

- The RAM monitor obtains the data accessed through the bus. Any change other than the access from the target program will not be reflected.
- If the display data length of the RAM monitor area is not 1 byte, the data's access attribute to the memory may varies in units of 1 byte. In such a case that the access attribute is not unified within a set of data, the data's access attribute cannot be displayed correctly. In this case, the background colors the access attribute color of the first byte of the data.


7.2.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Add...		Add watchpoint.
Add Bit...		Add bit-label watchpoint.
Remove		Remove the selected watchpoint.
Remove All		Remove all watchpoints.
Set...		Set new data to selected watchpoint.
Radix	Bin	Display in Binary.
	Dec	Display in Decimal.
	Hex	Display in Hexadecimal.
Refresh		Refresh memory data.
Layout	Address Area	Switch display or non-display of Address area.
	Size Area	Switch display or non-display of Size area.
RAM Monitor	Enable RAM Monitor	Switch enable or disable RAM monitor function.
	Sampling Period...	Set RAM monitor sampling period.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.3 C Watch Window

The C Watch Window displays C/C++ expressions and their values (results of calculations). The C/C++ expressions displayed in the C Watch Window are known as C watchpoints. The displays of the results of calculating the C watchpoints are updated each time a command is executed. When RAM monitor function is effective and the C watch points are within the RAM monitor area, the displayed values are updated during execution of the target program.



- Variables can be inspected by scope (local, file local or global).
- The display is automatically updated at the same time the PC value changes.
- Variable values can be changed.
- The display radix can be changed for each variable individually.
- Any variable can be registered to the Watch tab, so that it will be displayed at all times:
 - The registered content is saved for each project separately.
 - If two or more of the C watch window are opened at the same time, the registered
- The C watchpoints can be registered to separate destinations by adding Watch tabs.
- Variables can be registered from another window or editor by a drag-and-drop operation.
- The C watchpoints can be sorted by name or by address.
- Values can be inspected in real time during program execution by using the RAM monitor function.

ATTENTION

- You cannot change the values of the C watch points listed below:
 - Bit field variables
 - Register variables
 - C watch point which does not indicate an address (invalid C watch point)
- If a C/C++ language expression cannot be calculated correctly (for example, when a C/C++ symbol has not been defined), it is registered as invalid C watch point. It is displayed as "--<not active>--". If that C/C++ language expression can be calculated correctly at the second time, it becomes an effective C watch point.
- The display settings of the Local, File Local and Global tabs are not saved. The contents of the Watch tab and those of newly added tabs are saved.
- The RAM monitor obtains the data accessed through the bus. Any change other than the access from the target program will not be reflected.
- The variables, which are changed in real-time, are global variables and file local variables only.
- If the display data length of the RAM monitor area is not 1 byte, the data's access attribute to the memory may varies in units of 1 byte. In such a case that the access attribute is not unified within a set of data, the data's access attribute cannot be displayed correctly. In this case, the background colors the access attribute color of the first byte of the data.

7.3.1 Extended Menus


This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Add...		Add C watchpoint.
Remove		Remove the selected C watchpoint.
Remove All		Remove all C watchpoints.
Initialize		Reevaluates the selected C watchpoint.
Set New Value...		Set new data to selected C watchpoint.
Radix	Hex	Display in Hexadecimal.
	Bin	Display in Binary.
	Default	Display in Default Radix.
	Toggle(All Variables)	Change radix (toggle).
Refresh		Refresh memory data.
Hide type name		Hide type names from variables.
Show char* as string		Selects whether to display char* type as a string.
Sort	Sort by Name	Sort variables by its name.
	Sort by Address	Sort variables by its address.
RAM Monitor	Enable RAM Monitor	Switch enable or disable RAM monitor function.
	Sampling Period...	Set RAM monitor sampling period.
Add New Tab...		Add new tab.
Remove Tab		Remove the selected tab.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.4 Coverage Window

The Coverage window allows you to reference the coverage measurement result of the functions of the target program downloaded. The coverage which can be measured is C0 coverage.

Two types of windows are provided: the Coverage window in which you can check the start address/end address of the functions and coverage measurement results; and the Editor window in which you can check execution/non-execution by source line.



- The coverage measurement area is an any 256 KB area starting from the 64 KB boundary. (The top address of the coverage measurement area is called coverage base address. By default, the coverage base address is set to 0h.)
- By double-clicking any function line, the corresponding function appears in the Editor(Source) window.
- During coverage measurement, "-%" appears in the coverage display area.
- You can change the display ratio between the function name display area and the function range display area, using the mouse.

7.4.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Select source file...		Select a source file for checking the coverage.
Auto Refresh		Refresh coverage measurement result automatically.
Refresh		Refresh coverage measurement result.
Clear		Clear coverage measurement result .
Base...		Change coverage base address.
File	Save...	Save coverage measurement result to file.
	Load...	Load coverage measurement result from file.
Layout	Address	Switch display or non-display of Address area.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

*:The debugger for 740 doesn't support, because the entire memory area is coverage area.

7.4.2 Refer to the Source Line/the Executed Address


It is possible to refer in the Editor(Source) Window or Memory Window.

7.4.2.1 Refer in the Editor(Source) Window

In the Editor(Source) window, a display of Coverage Measurement is set to "Disable" by default.

To enable the display, check the [Coverage] check box in the dialog box opened by choosing the main menu - [Edit] -> [Define Column Format]. The column for a coverage measurement display is displayed on all Editor (Source) windows.


And select popup menu - [Columns] -> [Coverage] in the Editor (Source) window, A column can be set up for each Editor (Source) windows.



7.4.2.2 Refer in the Memory Window

In the Memory window, a display of Coverage Measurement is set to "Disable" by default.


To enable the display, select popup menu - [Coverage] -> [On/Off] in the Memory window.



7.5 Script Window

The Script Window displays the execution of text -format script commands and the results of that execution.

Script commands can be executed using a script file or interactively. You can also write script commands in the script file so that they are automatically executed. The results of script command execution can also be stored in a previously specified log file.



- The Script Window has a view buffer that stores the results of executing the last 1000 lines. The results of execution can therefore be stored in a file (view file) without specifying a log file.
- When a script file is opened, the command history area changes to become the script file display area and displays the contents of the script file. When script files are nested, the contents of the last opened script file are displayed. The script file display area shows the line currently being executed in inverse vide.
- When a script file is open, you can invoke script commands from the command input area provided the script file is not being executed.
- The Script Window can record the history of the executed commands to a file. This function is not the same as the log function. This function records not the result but only the executed commands, so the saved files can be used as the script files.


7.5.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Script	Open...	Open script file.
	Run	Run script file.
	Step	One step execution of script file.
	Close	Close script file.
View	Save...	Save view buffer to file.
	Clear	Clear view buffer.
Log	On...	Open log file and start recording (start output to file).
	Off	Close log file and end recording (stop output to file).
Record	On...	Record the executed commands to a file.
	Off	Stop recording the executed commands.
Copy		Copy the selection and put it on the Clipboard.
Paste		Insert Clipboard contents.
Cut		Cut the selection and put it on the Clipboard.
Delete		Erase the selection.
Undo		Undo the last action.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.6 S/W Break Point Setting Window

The S/W Break Point Setting window allows you to set software break points. Software breaks stop the execution of instructions immediately before the specified break point.



- If you have set multiple software breakpoints, program execution stops when any one software break address is encountered (OR conditions).
- You can continue to set software breakpoints until you click the "Close" button to close the S/W Break Point Setting Window.
- You can clear, enable or disable software breakpoints selected by clicking in the software breakpoint display area. You can also enable and disable software breakpoints by double-clicking on them.
- Click on the "Save" button to save the software break points in the file. To reload software break point settings from the saved file, click the "Load" button. If you load software break points from a file, they are added to any existing break points.

7.6.1 Command Button


The buttons on this window has the following meanings.

Button	Function
Load...	Load setting information from a file in which it was saved.
Save...	Save the contents set in the window to a file.
Help	Display the help of this window.
Add	Add the break point.
Refer...	Open file selection dialog box.
Close	Close the window.
Delete	Remove the selected break point.
Delete All	Remove all break points.
Enable	Enable the selected break points.
All Enable	Enable all break points.
Disable	Disable the selected break point.
All Disable	Disable all break points.
View	Shows the selected breakpoint positions in the Editor(Source) window.

7.6.2 Setting and Deleting a Break Points from Editor(Source) Window

The area which can be set in the software breakpoint is different according to the product. Please refer to "12.1.2Area where software breakpoint can be set" for details.

You can set break points in the Editor(Source) Window. To do so, double-click the break point setting area ("S/W breakpoints" column) for the line in which you want to set the break. (A red marker is displayed on the line to which the break point was set.)




You can delete the break point by double-clicking again in the break point setting area ("S/W breakpoints" column).

In the Editor(Source) window, a display of "S/W breakpoints" column is set to "Enable" by default. To erase this column, deselect the [S/W breakpoints] check box in the dialog box opened by choosing the main menu - [Edit] -> [Define Column Format]. The "S/W breakpoints" column is erased from all Editor (Source) windows. And select popup menu - [Columns] -> [S/W breakpoints] in the Editor (Source) window, A column can be set up for each Editor (Source) windows.

7.7 H/W Break Point Setting Window


The H/W Breakpoint Setting window is used to set hardware breakpoints for the Emulators.



- The events listed below can be specified as break events. If the contents of events are altered, they are marked by an asterisk (*) on the title bar. The asterisks (*) are not displayed after setting up the emulator.
 - The debugger for M32C
Memory Access, Bit Access, External Trigger
(* Can be substituted by memory access. (Access type = Read))
 - The debugger for M16C/R8C
Fetch, Memory Access, Bit Access, Interrupt, External Trigger
 - The debugger for 740
Fetch, Memory Access, Bit Access, Interrupt, External Trigger
- Events at up to six points can be used.
- These events can be combined in one of the following ways:
 - Break when all of the valid events are established (AND condition)
 - Break when all of the valid events are established at the same time (simultaneous AND condition)
 - Break when one of the valid events is established (OR condition)
 - Break upon entering a break state during state transition (State Transition condition)
- At the time the debugger starts up, the hardware breaks have no effect.


7.7.1.1 Specify the Break Event

To set events, double-click to select the event you want to set from the event setting area of the H/W Break Point Setting Window. This opens the dialog box shown below.




Following events can be set by specifying Event Type in this dialog box.

-
- When FETCH is selected
Breaks for the instruction fetch.
(The debugger for M32C not support. When using these products, use memory access instead.)



- When DATA ACCESS is selected
Breaks for the memory access.



- When BIT SYMBOL is selected
Breaks for the bit access.

The screenshot shows a dialog box titled "Bit Symbol" with the following fields and options:

- Bit** section:
 - Address: 400 (with a dropdown arrow and a small icon)
 - Bit No.: 2 (with a spinner control)
 - Bit Symbol: (with a dropdown arrow)
- Condition** section:
 - Access: WRITE (with a dropdown arrow)
 - Value: 1 (with a dropdown arrow)
- Summary text box:


```
ACCESS: WRITE  
ADDRESS: _pool  
CONDITION: (addr) == 000400, (data&0004) == 0004
```

- When INTERRUPT is selected
Breaks for the interrupt occurrence or termination.
(The debugger for M32C not support.)

The screenshot shows a dialog box titled "Interrupt" with the following options:

- Occurrence
- Termination

-
- When TRIGGER is selected
Breaks for the status of signal input from external trace cable.




7.7.2 Specify the Combinatorial Condition

To specify a combinatorial condition, specify the desired condition from the combinatorial condition specification area.


- When AND or OR is selected

In the event specification area, the event used and a pass count for that event can be specified. To alter the pass count, while the event to alter is being selected, click the pass count value of that event.




- When AND (Same Time) is selected

In the event specification area, the event used can be specified. No pass counts can be specified.




- When State Transition is selected

Click the Details... button, and the dialog box shown below appears. Specification by a state transition diagram or sequential specification can be used. If the content of any event is altered, it is marked with an asterisk (*) on the title bar. Once conditions are set in the emulator, asterisks are not displayed. A time-out time in each state can also be specified.



7.7.3 Specify the Process ID

By specifying a process ID, it is possible to detect only event establishment under specific conditions.



Example: Enable only the event that occurs in a specific task when using the realtime OS.

7.7.4 Command Button

The buttons on this window has the following meanings.

Button	Function
Reset	Discards the contents being displayed in the window and loads contents from the emulator in which they were set.
Save...	Saves the contents set in the window to a file.
Load...	Loads event information from a file in which it was saved.
Set	Sends the contents set in the window to the emulator.
Close	Closes the window.


7.7.5 Specify the Events (Instruction Fetch)

To specify an instruction fetch event, change the event select dialog box's Event Type to "FETCH". The event is established when instruction is fetched from the specified address or any address in the specified address range.

7.7.5.1 Instruction Fetch of Specified Address

Set as below.


Example) Instruction fetch at address 80000h



7.7.5.2 Instruction Fetch of Specified Address Area(In)

Set as below.


Example) Instruction fetch at address 80000h to 80FFFh



7.7.5.3 Instruction Fetch of Specified Address Area(Out)

Set as below.


Example) Instruction fetch at any address other than the range 80000h to 80FFFh




7.7.5.4 Entering/exiting to specified function

Set as below.

Example) Entering a break to function name "wait"



Example) Exiting from function name "wait"



7.7.6 Specify the Events (Memory Access)

To specify a memory access event, change the event select dialog box's Event Type to "DATA ACCESS". The event is established when memory is accessed at the specified address or under conditions set for the specified address range.

7.7.6.1 Memory Access(The debugger for M32C)

ATTENTION

It is not detected that data access to the odd addresses in word-size access.

7.7.6.1.1. Writing/Reading a Specified Address

Set as below.

Example) Writing to even address 400h

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Address' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section includes a 'Range' dropdown set to '(addr) == Address1', 'Address1' set to '400', and 'Address2' set to '000000'. There are checkboxes for 'Function', 'Source File', and 'Function'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400'. 'OK' and 'Cancel' buttons are at the bottom right.

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Data' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section includes a 'Range' dropdown set to 'Not Specify', 'Data 1' set to '0000', 'Data 2' set to '0000', 'Access' set to 'WRITE', and a 'Mask' checkbox with '0000' next to it. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400'. 'OK' and 'Cancel' buttons are at the bottom right.

Example) Writing byte length data 32h to even address 400h

The dialog box 'A1 - Set Event Status' has the 'Event Type' set to 'DATA ACCESS'. The 'Address' tab is selected. The 'Setting' section shows 'Range' as '(addr) == Address1'. 'Address1' is set to '000400' and 'Address2' is set to '000000'. There are checkboxes for 'Function', 'Source File', and 'Function'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400, (data&00FF) == 0032'. 'OK' and 'Cancel' buttons are at the bottom right.

The dialog box 'A1 - Set Event Status' has the 'Event Type' set to 'DATA ACCESS'. The 'Data' tab is selected. The 'Setting' section shows 'Range' as '(data) == Data1'. 'Data 1' is set to '32' and 'Data 2' is set to '0000'. 'Access' is set to 'WRITE' and there is a 'Mask' checkbox set to '0000'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400, (data) == 0032'. 'OK' and 'Cancel' buttons are at the bottom right.

Example) Writing byte length data 32h to odd address 401h
Contents of settings vary with each product and bus width.
(8 bits bus width)

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Address' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(addr) == Address1'. Below this, 'Address1' is set to '000401' and 'Address2' is set to '000000'. There are checkboxes for 'Function', 'Source File', and 'Function', all of which are currently unchecked. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000401', and 'CONDITION: (addr) == 000401, (data&00FF) == 0032'. 'OK' and 'Cancel' buttons are at the bottom right.

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Data' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(data) == Data1'. Below this, 'Data 1' is set to '32' and 'Data 2' is set to '0000'. The 'Access' dropdown is set to 'WRITE', and the 'Mask' checkbox is checked with a value of '00FF'. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000401', and 'CONDITION: (addr) == 000401, (data&00FF) == 0032'. 'OK' and 'Cancel' buttons are at the bottom right.

(16 bits bus width)

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 401 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000401
CONDITION: (addr) == 000401, (data&FF00) == 3200

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (data) == Data1

Data 1: 3200 Data 2: 0000

Access: WRITE Mask: FF00

ACCESS: WRITE
ADDRESS: 000401
CONDITION: (addr) == 000401, (data&FF00) == 3200

OK Cancel

Example) Writing word length data 1234h to even address 400h

Contents of settings vary with each product and bus width.

(8 bits bus width)

Please specify "And" of the 1st point and the 2nd point for a combination condition.

1st point

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Address' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(addr) == Address1'. Below this, 'Address1' is set to '400' and 'Address2' is set to '00040F'. There are checkboxes for 'Function', 'Source File', and 'Function', all of which are currently unchecked. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400, (data&00FF) == 0034'. 'OK' and 'Cancel' buttons are at the bottom right.

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Data' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(data) == Data1'. Below this, 'Data 1' is set to '0034' and 'Data 2' is set to '0000'. The 'Access' dropdown is set to 'WRITE', and the 'Mask' checkbox is checked with a value of '00FF'. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: (addr) == 000400, (data&00FF) == 0034'. 'OK' and 'Cancel' buttons are at the bottom right.

2nd point

A2 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&00FF) == 0012

OK Cancel

A2 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (data) == Data1

Data 1: 0012 Data 2: 0000

Access: WRITE Mask: 00FF

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&00FF) == 0012

OK Cancel

(16 bits bus width)

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File :
Function :

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data) == 1234

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (data) == Data1

Data 1: 1234 Data 2: 0000

Access: WRITE Mask: FFFF

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data) == 1234

OK Cancel

Example) Writing data 10h - 3Fh to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, 0010 <= (data&00FF) <= 003F

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: Data1 <= (data) <= Data2

Data 1: 10 Data 2: 3F

Access: WRITE Mask: 0000

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, 0010 <= (data) <= 003F

OK Cancel

7.7.6.1.2. Reading/writing data to the specified address range

Set as below.

Example) Writing data to addresses ranging from 400h to 40Fh

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Address1 <= (addr) <= Address2

Address1: 400 Address2: 40F

Function:

Source File :

Function :

ACCESS: WRITE
ADDRESS: 000400
CONDITION: 000400 <= (addr) <= 00040F

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Not Specify

Data 1: 0000 Data 2: 0000

Access: WRITE Mask: 0000

ACCESS: WRITE
ADDRESS: 000400
CONDITION: 000400 <= (addr) <= 00040F

OK Cancel

7.7.6.1.3. Reading/writing data to addresses outside the specified range

Set as below.

Example) Writing data to addresses below 7FFh

The dialog box 'A1 - Set Event Status' has 'Event Type' set to 'DATA ACCESS'. The 'Address' tab is selected. The 'Setting' section shows 'Range' as '(addr) <= Address1', 'Address1' as '7FF', and 'Address2' as '00040F'. There are checkboxes for 'Function', 'Source File', and 'Function'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 0007FF', and 'CONDITION: (addr) <= 0007FF'. 'OK' and 'Cancel' buttons are at the bottom right.

The dialog box 'A1 - Set Event Status' has 'Event Type' set to 'DATA ACCESS'. The 'Data' tab is selected. The 'Setting' section shows 'Range' as 'Not Specify', 'Data 1' as '0000', 'Data 2' as '0000', 'Access' as 'WRITE', and a 'Mask' checkbox with '0000'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 0007FF', and 'CONDITION: (addr) <= 0007FF'. 'OK' and 'Cancel' buttons are at the bottom right.

7.7.6.2 Memory Access(The debugger for M16C/R8C)

7.7.6.2.1 Writing/Reading a Specified Address

Set as below.

Example) Writing to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Not Specify

Data 1: 0000 Data 2: 0000

Access: WRITE Mask: 0000

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400

OK Cancel

Example) Writing byte length data 32h to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 000400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&00FF) == 0032

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (data) == Data1

Data 1: 0032 Data 2: 0000

Access: WRITE Mask: 00FF

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&00FF) == 0032

OK Cancel

Example) Writing byte length data 32h to odd address 401h
Contents of settings vary with each product and bus width.
(8 bits bus width)

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Address' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(addr) == Address1'. Below this, 'Address1' is set to '401' and 'Address2' is set to '000000'. There are checkboxes for 'Function', 'Source File', and 'Function', all of which are currently unchecked. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000401', and 'CONDITION: (addr) == 000401, (data&FF00) == 3200'. 'OK' and 'Cancel' buttons are at the bottom right.

The screenshot shows the 'A1 - Set Event Status' dialog box with the 'Data' tab selected. The 'Event Type' is set to 'DATA ACCESS'. The 'Setting' section has a 'Range' dropdown set to '(data) == Data1'. Below this, 'Data 1' is set to '3200' and 'Data 2' is set to '0000'. The 'Access' dropdown is set to 'WRITE', and the 'Mask' checkbox is checked with 'FF00' in the adjacent field. At the bottom of the dialog, the following text is displayed: 'ACCESS: WRITE', 'ADDRESS: 000401', and 'CONDITION: (addr) == 000401, (data&FF00) == 3200'. 'OK' and 'Cancel' buttons are at the bottom right.

(16 bits bus width)

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 000401 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000401
CONDITION: (addr) == 000401, (data&00FF) == 0032

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (data) == Data1

Data 1: 32 Data 2: 0000

Access: WRITE Mask: 00FF

ACCESS: WRITE
ADDRESS: 000401
CONDITION: (addr) == 000401, (data&00FF) == 0032

OK Cancel

Example) Writing word length data 1234h to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data) == 1234

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (data) == Data1

Data 1: 1234 Data 2: 0000

Access: WRITE Mask: FFFF

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data) == 1234

OK Cancel

Example) Writing data 10h - 3Fh to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: (addr) == Address1

Address1: 400 Address2: 000000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, 0010 <= (data&00FF) <= 003F

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address | Data

Setting

Range: Data1 <= (data) <= Data2

Data 1: 10 Data 2: 3F

Access: WRITE Mask: 00FF

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, 0010 <= (data&00FF) <= 003F

OK Cancel

7.7.6.2.2. Reading/writing data to the specified address range

Set as below.

Example) Writing data to addresses ranging from 400h to 40Fh

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Address1 <= (addr) <= Address2

Address1: 400 Address2: 40F

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 000400
CONDITION: 000400 <= (addr) <= 00040F

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Not Specify

Data 1: 0000 Data 2: 0000

Access: WRITE Mask: 0000

ACCESS: WRITE
ADDRESS: 000400
CONDITION: 000400 <= (addr) <= 00040F

OK Cancel

7.7.6.2.3. Reading/writing data to addresses outside the specified range

Set as below.

Example) Writing data to addresses below 7FFh

The dialog box 'A1 - Set Event Status' has 'Event Type' set to 'DATA ACCESS'. The 'Address' tab is selected. The 'Setting' section shows 'Range' as '(addr) <= Address1', 'Address1' as '7FF', and 'Address2' as '00040F'. There are checkboxes for 'Function', 'Source File', and 'Function'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 0007FF', and 'CONDITION: (addr) <= 0007FF'. 'OK' and 'Cancel' buttons are at the bottom right.

The dialog box 'A1 - Set Event Status' has 'Event Type' set to 'DATA ACCESS'. The 'Data' tab is selected. The 'Setting' section shows 'Range' as 'Not Specify', 'Data 1' as '0000', 'Data 2' as '0000', 'Access' as 'WRITE', and a 'Mask' checkbox with '0000'. The summary text at the bottom reads: 'ACCESS: WRITE', 'ADDRESS: 0007FF', and 'CONDITION: (addr) <= 0007FF'. 'OK' and 'Cancel' buttons are at the bottom right.



7.7.6.3 Memory Access(The debugger for 740)

The debugger For 740, a write of word length data to the even address cannot be detected, either.

7.7.6.3.1. Writing/Reading a Specified Address

Set as below.

Example) Writing to even address 400h



Example) Writing byte length data 32h to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (addr) == Address1

Address1: 0400 Address2: 0000

Function:

Source File :

Function :

ACCESS: WRITE
ADDRESS: 0400
CONDITION: (addr) == 0400, (data&00FF) == 0032

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (data) == Data1

Data 1: 0032 Data 2: 003f

Access: WRITE Mask: 00

ACCESS: WRITE
ADDRESS: 0400
CONDITION: (addr) == 0400, (data&00FF) == 0032

OK Cancel

Example) Writing data 10h - 3Fh to even address 400h

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (addr) == Address1

Address1: 0400 Address2: 0000

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 0400
CONDITION: (addr) == 0400, 0010 <= (data&00FF) <= 003F

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Data1 <= (data) <= Data2

Data 1: 0010 Data 2: 003f

Access: WRITE Mask: 00

ACCESS: WRITE
ADDRESS: 0400
CONDITION: (addr) == 0400, 0010 <= (data&00FF) <= 003F

OK Cancel

7.7.6.3.2 Reading/writing data to the specified address range

Set as below.

Example) Writing data to addresses ranging from 400h to 40Fh

The dialog box 'A1 - Set Event Status' has a title bar with the same text. The 'Event Type' dropdown is set to 'DATA ACCESS'. The 'Address' tab is selected. In the 'Setting' section, the 'Range' dropdown is set to 'Address1 <= (addr) <= Address2'. Below it, 'Address1' is set to '400' and 'Address2' is set to '40F'. There are checkboxes for 'Function', 'Source File', and 'Function', all of which are currently unchecked. At the bottom of the dialog, there is a text box containing the following text: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: 000400 <= (addr) <= 00040F'. 'OK' and 'Cancel' buttons are at the bottom right.

The dialog box 'A1 - Set Event Status' has a title bar with the same text. The 'Event Type' dropdown is set to 'DATA ACCESS'. The 'Data' tab is selected. In the 'Setting' section, the 'Range' dropdown is set to 'Not Specify'. Below it, 'Data 1' is set to '0000' and 'Data 2' is set to '0000'. The 'Access' dropdown is set to 'WRITE'. There is a checkbox for 'Mask' which is unchecked, and its value is set to '0000'. At the bottom of the dialog, there is a text box containing the following text: 'ACCESS: WRITE', 'ADDRESS: 000400', and 'CONDITION: 000400 <= (addr) <= 00040F'. 'OK' and 'Cancel' buttons are at the bottom right.

7.7.6.3.3. Reading/writing data to addresses outside the specified range

Set as below.

Example) Writing data to addresses below 7FFh

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: (addr) <= Address1

Address1: 7FF Address2: 00040F

Function:

Source File:

Function:

ACCESS: WRITE
ADDRESS: 0007FF
CONDITION: (addr) <= 0007FF

OK Cancel

A1 - Set Event Status

Event Type: DATA ACCESS

Address Data

Setting

Range: Not Specify

Data 1: 0000 Data 2: 0000

Access: WRITE Mask: 0000

ACCESS: WRITE
ADDRESS: 0007FF
CONDITION: (addr) <= 0007FF

OK Cancel

7.7.7 Specify the Events (Bit Access)

To specify a bit access event, change the event select dialog box's Event Type to "BIT SYMBOL". The event is established when the specified bit at the specified address or specified bit symbol is accessed under specified conditions.

7.7.7.1 Writing/Reading a Specified Bit

Set as below.

Example) Writing "0" to bit 2 at address 400h

A1 - Set Event Status

Event Type: BIT SYMBOL

Bit

Address: 000400 Bit No: 2

Bit Symbol:

Condition

Access: WRITE

Value: 0

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&0004) == 0000

OK Cancel

7.7.7.1.1. Writing/Reading a Specified Bit Symbol

Set as below.

Example) Writing "1" to bit symbol "bitsym"

A1 - Set Event Status

Event Type: BIT SYMBOL

Bit

Address: 000400 Bit No: 2

Bit Symbol: bitsym

Condition

Access: WRITE

Value: 1

ACCESS: WRITE
ADDRESS: 000400
CONDITION: (addr) == 000400, (data&0004) == 0004


OK Cancel

7.7.8 Specify the Events (Interrupt)

To specify an interrupt event, change Event Type in the event select dialog box to "INTERRUPT". When an interrupt is generated or finished, the event is established.


7.7.8.1 Interrupt Occurrence

Set as below.




7.7.8.2 Interrupt Termination

Set as below.




Example) Fall of EXT1(brown) signal



7.7.9.2 Combination of rise/fall edges

Set as below.

Example) Rise of EXT0 (white)/EXT7 (purple) signal, fall of EXT1 (brown) signal



7.7.10 Specify the Event Combination Condition

Use the Combination group of the event setting windows to specify the combinatorial conditions of events.

The combination of two or more events can be used.


One of the following combinatorial conditions can be selected.

AND	All of the specified events are established
AND(Same Time)	The specified events are established at the same time
OR	One of the specified events is established
STATE TRANSITION	Established upon entering a break state in the state transition diagram

Pass counts (number of times passed) can be specified for each event (1-255). If the specified combinatorial condition is AND (Same Time), no pass counts can be set (fixed to 1).


7.7.10.1 Select AND, OR

Change the Combination group to "AND" to specify AND for the combinatorial condition, or "OR" to specify OR for the combinatorial condition. Next, check (turn on) an event in the event specification area that you want to use, and specify a pass count for that event. To alter the pass count, while the event to alter is being selected, click the pass count value of that event.



7.7.10.2 Select AND(Same Time)

Change the Combination group to "AND (Same Time)". Next, check (turn on) an event in the event specification area that you want to use. No pass counts can be specified (fixed to 1).




7.7.10.3 Select State Transition

Change the Combination group to "State Transition". The Detail... button included in the Combination group becomes useful, so click that button. This opens the State Setting window. In this window, State Transition can be specified using a state transition diagram or sequentially. A state time-out time can also be specified.

Specification by a state transition diagram Use the state transition diagram of the State Transition group. Click any button here to select the event you want to use. For the button above the arrow, specify the event necessary to go to the state indicated by the arrow. For the button above the state (elliptical display part), specify the event necessary to reset the pass count of each state and reset the time count of that state. Pass counts can be specified from the popup menu that appears when selecting an event.


Example: After conditions are met in order of events A1 and A2, event A3 is not established and event A4 is established



Sequential specification

Use the buttons included in the Sequential group. Pass counts can be specified from the popup menu that appears when selecting an event. The contents set here are reflected in the state transition diagram.

Example: Events A1, A2, and A3 that occur successively in that order are established



7.7.11 Specify the Process ID

By specifying a task name (task number), it is possible to enable only the events that occurred in the specified task.


7.7.11.1 Specify the Task

Only the events from a specified task can be detected. Events from other than a specified task can also be detected.

Check the Enable check box included in the PID group of the event setting window. When this check box is checked, the Detail... button to the right of it is enabled.



Click the Detail... button included in the PID group. This opens the Process ID Setting dialog box.




In the PID Setting area, specify the memory address in which to store the execution task, the data size, and the task number (or task name). Mask can also be specified for the task number. In the Condition group, click the radio button "==".

To enable events in other than a specified task, click the radio button "!=".

ATTENTION


In PID settings, always be sure to specify an even address for the Address area.

In the PID Event area, check the check box for the event you want to enable. Only the checked events become the target to be debugged.



7.8 Protect Window

The Protect window sets the protect break (memory protect) function of the emulator.



- The protect break function is disabled at start of the debugger.
- Three types of protect break attributes are provided as below:
 - Access Disable (read/write disabled, display in red)
 - Read Only (write disabled, display in yellow)
 - R/W Enable (read/write enabled, display in sky blue)
- The protect break area is a 256 KB continuous area starting from the 64 KB boundary.
- You can use the following two methods to set protect break.
 - Specify from the target program session information.
 - Specify the memory attribute of the desired address range.

7.8.1 Extended Menus


This window has the following popup menus that can be brought up by right-clicking in the window.

Menu	Function
Section	Set protect break attribute by the section information.
Base Address...*	Change protect base address.
Attribute...	Set protect break attribute.
Mode	Switch enable or disable protect break function.
Toolbar display	Display toolbar.
Customize toolbar...	Open toolbar customize dialog box.
Allow Docking	Allow window docking.
Hide	Hide window.

*:The debugger for 740 doesn't support, because the entire memory area is protection area.

7.9 Trace Point Setting Window


The Trace Point Setting window is used to set trace points.



- The events listed below can be specified as trace events. If the contents of events are altered, they are marked by an asterisk (*) on the title bar. The asterisks (*) are not displayed after setting up the emulator.
 - The debugger for M32C
Memory Access, Bit Access, Trigger
(* Can be substituted by memory access. (Access type = Read))
 - The debugger for M16C/R8C
Fetch, Memory Access, Bit Access, Interrupt, Trigger
 - The debugger for 740
Fetch, Memory Access, Bit Access, Interrupt, Trigger
- Events at up to six points can be used.
- These events can be combined in one of the following ways:
 - Trace when all of the valid events are established (AND condition)
 - Trace when all of the valid events are established at the same time (simultaneous AND condition)
 - Trace when one of the valid events is established (OR condition)
 - Trace upon entering a break state during state transition (State Transition condition)


7.9.1 Specify the Trace Event

To set events, double-click to select the event you want to set from the event setting area of the Trace Point Setting Window. This opens the dialog box shown below.



Following events can be set by specifying Event Type in this dialog box.

- When FETCH is selected
Traces for the instruction fetch.
(The debugger for M32C not support. When using these products, use memory access instead.)




- When DATA ACCESS is selected
Traces for the memory access.

The screenshot shows a configuration window for 'DATA ACCESS'. It has two tabs: 'Address' and 'Data', with 'Data' selected. Under the 'Setting' section, there is a 'Range' dropdown menu set to 'Data1 <= (data) <= Data2'. Below this are two input fields: 'Data 1:' with the value '0000' and 'Data 2:' with the value '0000'. There is an 'Access:' dropdown menu set to 'R/W' and a checked checkbox for 'Mask:' with the value 'FFFF'. At the bottom of the window, a text box displays the following configuration summary:
ACCESS: R/W
ADDRESS: _data
CONDITION: (addr) == 00042C, 0000 <= (data) <= 0000


- When BIT SYMBOL is selected
Traces for the bit access.

The screenshot shows a configuration window for 'BIT SYMBOL'. It has a 'Bit' section with two radio buttons: 'Address:' (selected) and 'Bit Symbol:'. The 'Address:' radio button is selected, with an 'Address:' dropdown menu set to '400' and a 'Bit No.' spinner set to '2'. There is a small icon next to the 'Address:' dropdown. Below the 'Bit' section is a 'Condition' section with an 'Access:' dropdown menu set to 'WRITE' and a 'Value:' dropdown menu set to '1'. At the bottom of the window, a text box displays the following configuration summary:
ACCESS: WRITE
ADDRESS: _pool
CONDITION: (addr) == 000400, (data&0004) == 0004

- When INTERRUPT is selected
Traces for the interrupt occurrence or termination.
(The debugger for M32C not support.)



- When TRIGGER is selected
Traces for the status of signal input from external trace cable.



7.9.2 Specify the Combinatorial Condition

To specify a combinatorial condition, specify the desired condition from the combinatorial condition specification area.

- When AND or OR is selected

In the event specification area, the event used and a pass count for that event can be specified. To alter the pass count, while the event to alter is being selected, click the pass count value of that event.

PASS	EVENT
<input checked="" type="checkbox"/>	1 B1
<input type="checkbox"/>	1 B2
<input checked="" type="checkbox"/>	1 B3
<input type="checkbox"/>	1 B4
<input type="checkbox"/>	1 B5
<input type="checkbox"/>	1 B6


- When AND (Same Time) is selected

In the event specification area, the event used can be specified. No pass counts can be specified.

PASS	EVENT
<input checked="" type="checkbox"/>	1 B1
<input type="checkbox"/>	1 B2
<input checked="" type="checkbox"/>	1 B3
<input type="checkbox"/>	1 B4
<input type="checkbox"/>	1 B5
<input type="checkbox"/>	1 B6


- When State Transition is selected

Click the Details... button, and the dialog box shown below appears. Specification by a state transition diagram or Sequential specification can be used. If the content of any event is altered, it is marked with an asterisk (*) on the title bar. Once conditions are set in the emulator, asterisks are not displayed. A time-out time in each state can also be specified.



7.9.3 Specify the Process ID


By specifying a process ID, it is possible to detect only event establishment under specific conditions.



Example: Enable only the event that occurs in a specific task when using the realtime OS.

7.9.4 Specify the Trace Range


For the PC4701 emulator debugger, 32K cycles equivalent of data can be recorded.



Break	Stores the 32K cycles (-32K to 0 cycles) to the point at which the target program stops.
Before	Stores the 32K cycles (-32K to 1 cycles) to the point at which the trace point is passed.
About	Stores the 32K cycles (-16K to 16K cycles) either side of the trace point.
After	Stores the 32K cycles (0 to 32K cycles) of trace data after the trace point.
Full	Stores the 32K cycles (-32K to 0 cycles) of trace data after the trace starts.




7.9.5 Specify the Trace Write Condition

Conditions for cycles to be written to trace memory can be specified.



Total	Writes all cycles.
Pick up	Writes only the cycles where specified condition holds true.
Exclude	Writes only the cycles where specified condition does not hold true.

Also, following three write modes are supported.

	Only cycles where specified event is established
	Cycles from where specified event is established to where specified event is not established
	Cycles from where start event is established to where end event is established

7.9.6 Command Button

The buttons on this window has the following meanings.

Button	Function
Reset	Discards the contents being displayed in the window and loads contents from the simulator in which they were set.
Save...	Saves the contents set in the window to a file.
Load...	Loads event information from a file in which it was saved.
Set	Sends the contents set in the window to the simulator.
Close	Closes the window.

7.9.7 Specify the Events (Instruction Fetch)

How to set events for fetch is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.5 Specify the Events (Instruction Fetch) "

7.9.8 Specify the Events (Memory Access)

How to set events for memory access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.6 Specify the Events (Memory Access) "

7.9.9 Specify the Events (Bit Access)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.7 Specify the Events (Bit Access) "

7.9.10 Specify the Events (Interrupt)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.8 Specify the Events (Interrupt) "

7.9.11 Specify the Events (External Trigger Signal)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.9 Specify the Events (External Trigger Signal) "

7.9.12 Specify the Event Combination Condition

How to set combination of events is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.10 Specify the Event Combination Condition"

7.9.13 Specify the Process ID

How to set combination of events is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.11 Specify the Process ID"


7.9.14 Specify the write condition

Trace data write conditions can be specified.


You can specify the following write conditions:

1. Write conditions unlimited (default)
2. Cycles from the start event established to the end event established
3. Only cycles where the start event is established
4. Cycles from the start event established to the start event unestablished
5. Other than cycles from the start event established to the end event established
6. Other than cycles where the start event is established
7. Other than cycles from the start event established to the start event unestablished


To specify condition 1, choose "Total" from the list box of the window's "Write Condition" item.




To specify conditions 2 to 4, choose "Pick Up" and click the "Detail..." button to open the "Realtime-trace Write Condition" dialog box.




- For condition 2, choose the Mode shown below and set the Start and End events.




- For condition 3, choose the Mode shown below and set the Start event.




- For condition 4, choose the Mode shown below and set the Start event.




Similarly, when specifying conditions 5 to 7, choose "Exclude" and click the "Detail..." button to open the Realtime-trace Write Condition dialog box.




- For condition 5, choose the Mode shown below and set the Start and End events.



- For condition 6, choose the Mode shown below and set the Start event.




- For condition 7, choose the Mode shown below and set the Start event.



7.10 Time Measurement Window

The Time Measurement window displays the minimum/maximum/average execution time and measurement count at any measurement point. The execution time of up to 4 measurement points can be measured simultaneously.

You can specify the event for the measurement condition in the same manner as when specifying events in the Trace Point Setting Window.



- If the contents of events are altered, they are marked by an asterisk (*) on the title bar. The asterisks (*) are not displayed after setting up the emulator.

ATTENTION


- The Trace Point Setting Window and the Time Measure Windows use the same resource of the emulator. If the event settings are modified in Time Measure Window, settings of the Trace Point Setting Window are modified, too.
- As the count resource for time measurement, specify the MCU cycle (operation clock of the target mcu) instead of the emulator clock (16MHz), in the init dialog. If you specify the emulator clock, the measurement result will be incorrect.

7.10.1 Specify the Time Measurement Event

The events listed below can be specified as measurement events.


- The debugger for M32C
Memory Access, Bit Access, External Trigger (* Can be substituted by memory access. (Access type = Read))
- The debugger for M16C/R8C
Fetch, Memory Access, Bit Access, Interrupt, External Trigger
- The debugger for 740
Fetch, Memory Access, Bit Access, Interrupt, External Trigger

To set events, double-click to select the event you want to set from the event setting area of the Time Measurement Window. This opens the dialog box shown below.




Following events can be set by specifying Event Type in this dialog box.

- When FETCH is selected
Measures for the instruction fetch.
(The debugger for M32C not support. When using these products, use memory access instead.)



- When DATA ACCESS is selected
Measures for the memory access.



- When BIT SYMBOL is selected
Measures for the bit access.

The dialog box is titled "Bit Symbol" and contains the following fields:

- Bit**
 - Address: 400 (with a dropdown arrow and a small icon)
 - Bit Symbol: (empty dropdown)
 - Bit No.: 2 (with a spinner control)
- Condition**
 - Access: WRITE (with a dropdown arrow)
 - Value: 1 (with a dropdown arrow)
- Summary**


```
ACCESS: WRITE
ADDRESS: _pool
CONDITION: (addr) == 000400, (data&0004) == 0004
```

- When INTERRUPT is selected
Measures for the interrupt occurrence or termination.
(The debugger for M32C not support.)

The dialog box is titled "Interrupt" and contains the following fields:


- Occurrence
- Termination

-
- When TRIGGER is selected
Measures for the status of signal input from external trace cable.



7.10.2 Time Measurement Condition

For the time measurement conditions, the following can be specified for each measurement interval.



	Measures the time in an interval from where the start event is established till where the end event is established.
	Measures the time from where an event is established till where the next event is established.
	Measures the time from where an event is established till where the event is not established.
	Measures the execution time of functions. The start address and the end address of the function are automatically registered for the start event and the end event, respectively. The measurement result includes the execution time of other functions that have been called from within the specified function.
	Measures the execution time of functions. The start address and the end address of the function are automatically registered for the start event and the end event, respectively. The measurement result does not include the execution time of other functions that have been called from within the specified function.

7.10.3 Command Button

The buttons on this window has the following meanings.

Button	Function
Reset	Discards the contents being displayed in the window and loads contents from the emulator in which they were set.
Save...	Saves the contents set in the window to a file.
Load...	Loads event information from a file in which it was saved.
Set	Sends the contents set in the window to the emulator.
Close	Closes the window.

7.10.4 Specify the Events (Instruction Fetch)

How to set events for fetch is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.5 Specify the Events (Instruction Fetch) "

7.10.5 Specify the Events (Memory Access)

How to set events for memory access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.6 Specify the Events (Memory Access) "

7.10.6 Specify the Events (Bit Access)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.7 Specify the Events (Bit Access) "

7.10.7 Specify the Events (Interrupt)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.8 Specify the Events (Interrupt) "

7.10.8 Specify the Events (External Trigger Signal)

How to set events for bit access is same as the way for H/W Break Point Setting Window.
For detail about the setting, refer to "7.7.9 Specify the Events (External Trigger Signal) "

7.10.9 Set the Measurement Condition


For the debugger, the following measurement conditions can be specified.

- Measure the execution time between the events.
- Measure a period at which intervals events occur.
- Measure the time at which events are established.

By specifying a function name, it is possible to measure the execution time of that function. Up to four measurement intervals can be specified. To specify measurement intervals, click any line (MP1-MP4) in the Measurement Point group of the Interval Time Measure Window. This opens a dialog box for specifying measurement conditions.


7.10.9.1 Measure the execution time between the events

1. Set the measurement events (measurement start event and measurement end event).
2. Specify the following in the Measurement Condition Designation dialog.




7.10.9.2 Measure the event occurrence cycle

1. Set the measurement event (measurement start event only).
2. Specify the following in the Measurement Condition Designation dialog.



7.10.9.3 Measure the event establishment time

1. Set the measurement event (measurement start event only).
2. Specify the following in the Measurement Condition Designation dialog.




7.10.9.4 Measure the execution time of the specified function (1)

Measure the execution time of the specified function.

In this mode, the function top address is automatically registered to the measurement start event, and the function end address to the measurement end address.

The measurement result contains the execution time of other function called within the specified function.

Specify the following in the Measurement Condition Designation dialog.




7.10.9.5 Measure the execution time of the specified function (2)

Measure the execution time of the specified function.

In this mode, the function address range is automatically registered to the measurement start event. The measurement result does not contain the execution time of other function called within the specified function.

Specify the following in the Measurement Condition Designation dialog.



ATTENTION

When the target function calls the other functions, the first measurement finishes at the first calling the other function, and the second measurement begins at the returning to the target function from the first one.

7.11 Trace Window

The Trace Window is used to display the results of real-time trace measurement.

- Bus mode
This mode allows you to inspect cycle-by-cycle bus information. The display content depends on the MCU and simulator system used. In addition to bus information, this mode allows disassemble, source line or data access information to be displayed in combination.
- Disassemble mode
This mode allows you to inspect the executed instructions. In addition to disassemble information, this mode allows source line or data access information to be displayed in combination.
- Data access mode
This mode allows you to inspect the data read/write cycles. In addition to data access information, this mode allows source line information to be displayed in combination.
- Source mode
This mode allows you to inspect the program execution path in the source program.

The measurement result is displayed when a trace measurement has finished. When a trace measurement restarts, the window display is cleared.

The range of a trace measurement can be altered in the Trace Point Setting Window. For details about this window, refer to "7.9 Trace Point Setting Window." With default settings, the trace information immediately before the program has stopped is recorded.

7.11.1 Configuration of Bus Mode

When bus mode is selected, trace information is displayed in bus mode. Bus mode is configured as shown below.

The display content in bus mode differs depending on the MCU or simulator system used.

Cycle	Label	Address	Data	BUS	BIU	R/W	RMT	CPU	QB	B-T	Q-T	76543210	H'm's:ms.us
-07958		00042C	00DE	16b	DW	R	0	RW	0	1	1	11111111	00"00'00:055.114
-07957		0F01DC	7AF3	16b	IW	R	0	--	2	1	1	11111111	00"00'00:055.114
-07956	_Func_Exec	0F01DE	F27C	16b	IW	R	0	--	4	1	1	11111111	00"00'00:055.115
-07955		00042C	00DF	16b	DW	W	0	CB	3	1	1	11111111	00"00'00:055.115
-07954		0007E8	0083	16b	DW	R	0	--	3	1	1	11111111	00"00'00:055.115
-07953		0007EA	FF0F	16b	DB	R	0	--	3	1	1	11111111	00"00'00:055.115
-07952		0007EA	FF0F	16b	--	--	1	--	3	1	1	11111111	00"00'00:055.115
-07951		0F0083	FDFF	16b	IB	R	0	QC	1	1	1	11111111	00"00'00:055.115
-07950		0F0084	012C	16b	IW	R	0	--	3	1	1	11111111	00"00'00:055.115
-07949		0F0086	F50F	16b	IW	R	0	CB	4	1	1	11111111	00"00'00:055.115

(1) (2) (3) (4)

7.11.2 Configuration of Disassemble Mode

When disassemble mode is selected while bus mode is unselected, trace information is displayed in disassemble mode. Disassemble mode is configured as shown below.

Cycle	Address	Obj-code	Label	Mnemonic	h' m' s: ms. us
-18960	0F0199	730BF0		MOV.W RO, -10H[FB]	00"00'00:054.427
-18957	0F019C	C91BFD		ADD.W #1H, -3H[FB]	00"00'00:054.427
-18953	0F019F	FEC1		JMP.B F0161H	00"00'00:054.427
-18948	0F0161	778BFD0A00		CMP.W #000AH, -3H[FB]	00"00'00:054.428
-18943	0F0166	7DCA39		JGE F01A1H	00"00'00:054.428
-18938	0F01A1	7DF2		EXITD	00"00'00:054.428
-18929	0F0087	F50600		JSR.W _randam_ F008EH	00"00'00:054.429
-18920	0F008E	7CF204	_randam_access	ENTER #04H	00"00'00:054.429
-18916	0F0091	FDD40B0F		JSR.A _rand F0BD4H	00"00'00:054.430
-18906	0F0BD4	75C06D4E	_rand	MOV.W #4E6DH, RO	00"00'00:054.430
-18904	0F0BD8	75C2C641		MOV.W #41C6H, R2	00"00'00:054.430
-18902	0F0BDC	754F4004		PUSH.W 0440H	00"00'00:054.430
-18898	0F0BE0	754F3E04		PUSH.W 043EH	00"00'00:054.431
-18893	0F0BE4	FEO1		JMP.B F0BE6H	00"00'00:054.431
-18889	0F0BE6	FD1C0COF		JSR.A _i4mulU F0C1CH	00"00'00:054.431
-18879	0F0C1C	EC50	_i4mulU	PUSHM R1, R3	00"00'00:054.432
-18875	0F0C1E	75B107		MOV.W 7H[SP], R1	00"00'00:054.432
-18870	0F0C21	7121		MULU.W R2, R1	00"00'00:054.432
-18865	0F0C23	7312		MOV.W R1, R2	00"00'00:054.433
-18863	0F0C25	75B109		MOV.W 9H[SP], R1	00"00'00:054.433
-18859	0F0C28	7101		MULU.W RO, R1	00"00'00:054.433
-18854	0F0C2A	A112		ADD.W R1, R2	00"00'00:054.433

(1) (2) (3) (4)

1. Address display area: Shows addresses corresponding to instructions. Double-click here to bring up a dialog box to search for addresses.
2. Object code display area: Shows the object codes of instructions.
3. Label display area: Shows labels corresponding to instruction addresses. Double-click here to bring up a dialog box to search for addresses.
4. Mnemonic display area: Shows the mnemonics of instructions.

Other display areas are the same as in bus mode.

In addition to disassemble information, the window can display source line or data access information in combination. In this case, the display will be similar to the one shown below.

Cycle	Address	Obj-code	Label	Mnemonic	DataAccess	h' m' s: ms. us
	LOCAL.C, 42:		for (i = 0; i < 10; i++) {			
-19026	0F0161	778BFD0A00		CMP.W #000AH, -3H[FB]	(0007E3 09 R)	00"00'00:054.423
					(0007E4 00 R)	
-19021	0F0166	7DCA39		JGE F01A1H		00"00'00:054.423
	LOCAL.C, 43:		char localScope_char = 'a';			
-19019	0F0169	C661FF		MOV.B #61H, -1H[FB]		00"00'00:054.423
	LOCAL.C, 44:		long localScope_long = 0;			
-19017	0F016C	D90BF9		MOV.W #0H, -7H[FB]	(0007E5 61 W)	00"00'00:054.423
-19014	0F016F	D90BFB		MOV.W #0H, -5H[FB]	(0007DF 00 W)	00"00'00:054.423

7.11.3 Configuration of Data Access Mode

When data access mode is selected while bus mode and disassemble mode are unselected, trace information is displayed in data access mode. Data access mode is configured as shown below.

Cycle	Label	DataAccess	h' m' s: ms. us
-05012	_global_struct	(00047C 42 W)	00'00'00:055.299
-05007		(00047D 05 W)	00'00'00:055.299
-05006		(00047E 00 W)	00'00'00:055.299
-05001		(00047F 06 W)	00'00'00:055.299
-05000		(000480 00 W)	00'00'00:055.299
-04995		(000481 00 W)	00'00'00:055.300
-04994		(000482 00 W)	00'00'00:055.300
-04989		(000483 10 W)	00'00'00:055.300
-04984		(000484 0020 W)	00'00'00:055.300
-04977		(000486 0030 W)	00'00'00:055.301
-04972		(0007E4 0000 W)	00'00'00:055.301
-04971		(0007E4 0000 R)	00'00'00:055.301
-04964		(0007E2 0000 W)	00'00'00:055.302
-04963		(0007E2 0000 R)	00'00'00:055.302
-04957		(0007E4 0000 R)	00'00'00:055.302
-04949		(0007E2 0000 R)	00'00'00:055.302
-04939	_global_array	(00044A 0000 W)	00'00'00:055.303
-04938		(0007E2 0000 R)	00'00'00:055.303
-04935		(0007E2 0001 W)	00'00'00:055.303
-04929		(0007E2 0001 R)	00'00'00:055.304
-04924		(0007E4 0000 R)	00'00'00:055.304
-04916		(0007E2 0001 R)	00'00'00:055.305

(1)

1. Data access display area: Shows data access information. If the information displayed here is "000400 1234 W," for example, it means that data "1234H" was written to the address 000400H in 2-byte width.


Other display areas are the same as in bus mode.

In addition to data access information, the window can display source line information in combination. In this case, the display will be similar to the one shown below.

Cycle	Label	DataAccess	h' m' s: ms. us
	GLOBAL.C, 44:	global_struct.m_short = 5;	
-05012	_global_struct	(00047C 42 W)	00'00'00:055.299
	GLOBAL.C, 45:	global_struct.m_long = 6;	
-05007		(00047D 05 W)	00'00'00:055.299
-05006		(00047E 00 W)	00'00'00:055.299
-05001		(00047F 06 W)	00'00'00:055.299
-05000		(000480 00 W)	00'00'00:055.299
	GLOBAL.C, 47:	global_struct.m_struct.m_uchar = 0x10;	
-04995		(000481 00 W)	00'00'00:055.300
-04994		(000482 00 W)	00'00'00:055.300

7.11.4 Configuration of Source Mode

When only source mode is selected, trace information is displayed in source mode. Source mode is configured as shown below.



1. Line number display area: Shows the line number information of the displayed file. Double-click here to bring up a dialog box to change the displayed file.
2. Address display area: Shows addresses corresponding to source lines. Double-click here to bring up a dialog box to search for addresses.
3. Referenced cycle display area: Shows the currently referenced cycle that is marked by ">>." Furthermore, the addresses corresponding to source lines, if any, are marked by "-."
4. Source display area: Shows the content of the source file.
5. File name: Shows the file name of the currently displayed source file.
6. Referenced cycle: Shows the currently referenced cycle.
7. Referenced address: Shows the address corresponding to the currently referenced cycle.
8. Referenced time: Shows the time information corresponding to the currently referenced cycle.

Other display areas are the same as in bus mode.

7.11.5 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
BUS		Display the information of BUS mode.
DIS		Display the information of Disassemble mode.
SRC		Display the information of Source mode.
DATA		Display the information of Data access mode.
View	Cycle...	Changes the displayed position by specifying a cycle.
	Address...	Changes the displayed position by searching an address.
	Source...	Display a selected source file.
Time	Absolute Time	Shows elapsed time from the time the program started running up to now in terms of absolute time.
	Differences	Shows a differential time from the immediately preceding displayed cycle.
	Relative Time	Shows a relative time from the currently selected cycle.
Trace	Forward	Changes the direction of search to forward direction.
	Backward	Changes the direction of search to reverse direction.
	Step	Searches in Step mode in the specified direction of search.
	Come	Searches in Come mode in the specified direction of search.
	Stop	Stops trace measurement in the middle and displays the measured content at the present point of time.
	Restart	Restarts trace measurement.
Layout...		Change layout of the corrent view.
Copy		Copy selected lines.
Save...		Save trace data to file.
Load...		Load trace data from file.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.11.6 Display of bus information on the M32C Debugger

From left to right, the contents are as follows:

- Address
- The status of the address bus
- Data
- The status of the data bus
- BUS
- The width of the external data bus ("8b" for an 8-bit data bus, and "16b" for a 16-bit data bus)
- BIU
- This shows the status between the BIU (bus interface unit) and memory, and BIU and I/O.

Representation	BIU status
-	No access
WAIT	Executing wait instruction
RBML	Read access (bytes, ML on)
F	Fetch access
QC	Discontinuous Fetch access (queue buffer)
RWML	Read access (words, ML on)
INT	Interrupt acknowledge
RB	Read access (bytes)
WB	Write access (bytes)
DRB	Read access by DMA (bytes)
DWB	Write access by DMA (bytes)
RW	Read access (words)
WW	Write access (words)
DRW	Read access by DMA (words)
DWW	Write access by DMA (words)

- R/W
- Shows the status of the data bus ("R" for r ead, "W" for wr it e, "-" for no access).
- RWT
- This signal shows the effective position in the bus cycle ("0" when effective. Address, Data, and BIU signals are valid when RWT is "0").
- CPU, OPC, OPR
- This shows the signal between CPU and BIU. In the column "CPU", the data shows whether CPU accesses BIU or not . In the Column "OPC", the data shows the byte size of read operat ion code. In the Column "OPR", the data shows the byte size of read operand.

Representation			Status	
CPU	OPC	OPR	Operation code size	Operand size
-	-	-	No accessing	
CPU	0	1	0byte	1byte
CPU	0	2	0byte	2bytes
CPU	0	3	0byte	3bytes
CPU	1	0	1byte	0byte
CPU	1	1	1byte	1byte
CPU	1	2	1byte	2bytes
CPU	1	3	1byte	3bytes
CPU	2	0	2bytes	0byte
CPU	2	1	2bytes	1byte
CPU	2	2	2bytes	2bytes
CPU	3	0	3bytes	0byte
CPU	3	1	3bytes	1byte
DMA	-	-	DMA accessing	
DMAT	-	-	DMA accessing(terminal count)	

- B-T
Shows the level of the external break trigger (the EXTIN7 pin of the external trace signal input cable). High level = "1", Low level = "0".
- Q-T
Shows the level of the external trace trigger (the EXTIN6 pin of the external trace signal input cable). High level = "1", Low level = "0".
- 76543210
Shows the status of the 8-bit external signal (pins EXTIN0 to EXTIN7 of the external trace signal input cable). High level = "1", Low level = "0".
- h" m' s: ms.us
Show the elapsed time from the target program beginning.

7.11.7 Display of bus information on the M16C/R8C Debugger

From left to right, the contents are as follows:

- Address
The status of the address bus
- Data
The status of the data bus
- BUS
The width of the external data bus ("8b" for an 8-bit data bus, and "16b" for a 16-bit data bus)
- BIU
This shows the status between the BIU (bus interface unit) and memory, and BIU and I/O.

Display format	Status
-	No change
DMA	Data access other than a CPU cause such as DMA
INT	Start of INTACK sequence
IB	Instruction code read due to CPU cause (bytes)
DB	Data access due to CPU cause (bytes)
IW	Instruction code read due to CPU cause (words)
DW	Data access due to CPU cause (words)

- R/W
Shows the status of the data bus ("R" for read, "W" for write, "-" for no access).
- RWT
This signal shows the effective position in the bus cycle ("0" when effective. Address, Data, and BIU signals are valid when RWT is "0").
- CPU
Shows the status between CPU and BIU (bus interface unit)

Display format	Status
-	No change
CB	Operation code read (bytes)
RB	Operand read (bytes)
QC	Instruction queue buffer clear
CW	Operation code read (words)
RW	Operand read (words)

- QN
Shows the number of bytes stored in the instruction queue buffer in the range 0 to 4.
- B-T
Shows the level of the external break trigger (the EXTIN7 pin of the external trace signal input cable). High level = "1", Low level = "0".
- Q-T
Shows the level of the external trace trigger (the EXTIN6 pin of the external trace signal input cable). High level = "1", Low level = "0".
- 76543210
Shows the status of the 8-bit external signal (pins EXTIN0 to EXTIN7 of the external trace signal input cable). High level = "1", Low level = "0".
- h" m' s: ms.us
Show the elapsed time from the target program beginning.


7.11.8 Display of bus information on the 740 Debugger

From left to right, the contents are as follows:

- Address
The status of the address bus
- Data
The status of the data bus
- Sync
This signal is output when fetching an instruction op-code. When an op-code is being fetched, this signal indicates a logic 1. This Sync value is sometimes displayed as '(1)'. In this case, it denotes a dummy Sync meaning that the instruction on the line is not actually executed.
- Read
This signal determines the direction of the data bus. When data is to be read, this signal indicates a logic 0.
- Write
This signal determines the direction of the data bus. When data is to be written, this signal indicates a logic 0.
- B-T
Shows the level of the external break trigger (the EXTIN7 pin of the external trace signal input cable). High level = "1", Low level = "0".
- Q-T
Shows the level of the external trace trigger (the EXTIN6 pin of the external trace signal input cable). High level = "1", Low level = "0".
- 76543210
Shows the status of the 8-bit external signal (pins EXTIN0 to EXTIN7 of the external trace signal input cable). High level = "1", Low level = "0".
- h" m' s: ms.us
Show the elapsed time from the target program beginning.

7.12 Data Trace Window

The Data Trace Window is used to analyze the results of real-time trace measurements and graphically show data access information.



- In the data reference area, you can inspect memory values at the point of a cycle currently in interest or the values of registered C variables.
- In the access history reference area, you can see the history of accesses to registered addresses in chart form.
- In conjunction with the Trace Window, you can inspect memory values at the point of a cycle you are watching in the Trace Window. Conversely, you can show the cycle in the Trace Window which you are watching in the Data Trace Window.


7.12.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Analyze Trace Data		Analyze the realtime-trace data.
Set Cycle...		Specify the display cycle.
Sync with Trace Window		Synchronize with Trace Window.
Data Length	1byte	Display in 1Byte unit.
	2bytes	Display in 2Byte unit.
	4bytes	Display in 4Byte unit.
Radix	Hex	Display in Hexadecimal.
	Dec	Display in Decimal.
Address...		Display from specified address.
Add C Watch		Add C watchpoint.
Remove C Watch		Remove the selected C watchpoint.
Hide Type Name		Hide type names from variables.
Add...		Adds new watch item into Access History Reference Area.
Remove		Removes the selected watch item from Access History Reference Area.
Zoom	Zoom In	Increase the display scale.
	Zoom Out	Decrease the display scale.
	Zoom...	Specify the display scale.
Marker	Start Marker	Move the start marker in the display area.
	End Marker	Move the end marker in the display area.
	Indicator	Move the indicator in the display area.
	Adjust	Set cycle range between markers.
Change Grid Interval...		Change the grid interval.
Change Row Setting...		Change setting of the selected row.
Color...		Change the display color.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.13 GUI I/O Window

The GUI I/O window allows you for port input by creating a user target system key input panel (button) in the window and clicking the created button. And this window also allows you to implement the user target system output panel in the window.



- You can arrange the following parts on the window.
 - Label (character string)
Displays/erases a character string specified by the user when any value is written to the specified address (bit).
 - LED
Changes the display color of any area when any value is written to the specified address (bit). (Substitution for LED ON)
 - Button
A virtual port input can be executed at the time the button is pressed.
 - Text
Display the text string.
- You can also save the created panel in a file and reload it.
- You can set up to 200 address points to the created part. If different addresses are set to the individual parts, you can arrange up to 200 parts.

7.13.1 Extended Menus


This window has the following popup menus that can be brought up by right-clicking in the window.

Menu	Function
Select Item	Select an I/O item.
Delete	Delete the selected I/O item.
Copy	Copy the selected I/O item.
Paste	Paste the copied I/O item.
Create Button	Create a new button item.
Create Label	Create a new label item.
Create LED	Create a new LED item.
Create Text	Create a new text item.
Display grid	Display the grid line.
Save...	Save I/O panel file.
Load...	Load I/O panel file.
Sampling Period...	Set RAM monitor sampling period.
Toolbar display	Display toolbar.
Customize toolbar...	Open toolbar customize dialog box.
Allow Docking	Allow window docking.
Hide	Hide window.

7.14 MR Window

Use the MR Window to display the status of the realtime OS.
The debugger for 740 doesn't support this function.

You can only use the MR Window when you have downloaded a program that uses the realtime OS (if the downloaded program does not use the MR, nothing is displayed in the MR Window when it is opened.)



The screenshot shows a window titled "MR" with a toolbar and a table of task information. The table has the following columns: ID, StaAddr, (name), Pri, Status, wup_count, timeout, flg_ptn, and flg_mode. The data is as follows:

ID	StaAddr	(name)	Pri	Status	wup_count	timeout	flg_ptn	flg_mode
1	0F17F8H	(_main)	1	RUN	0000H	----	----	-----
2	0F1A68H	(_task2)	2	RDY	0000H	----	----	-----
3	0F1A76H	(_task3)	2	SUS	0000H	----	----	-----
4	0F1A84H	(_task4)	1	WAI(SLP)	0000H	----	----	-----
5	0F1A9AH	(_task5)	1	WAI(SLP)-SUS	0000H	----	----	-----
6	0F1AB0H	(_task6)	1	WAI(DLY)	0000H	7FFFH	----	-----
7	0F1ACAH	(_task7)	1	WAI(DLY)-SUS	0000H	7FFFH	----	-----
8	0F1AE4H	(_task8)	1	WAI(FLG)	0000H	----	1111H	TWF_ORW
9	0F1B02H	(_task9)	1	WAI(FLG)-SUS	0000H	----	1111H	TWF_ORW

- You can open the MR window as many as the number of display modes .
- By clicking the desired button, the MR window display mode changes and the display data also changes.
- By double-clicking the desired task line, you can display the context data of the task.
- You can drag the cursor to change the width of the display area in each mode.
- If the downloaded program does not use MR, you cannot select all the menu which will select the display mode.
- The supported display mode is as follows.

If a target program created by MR30 or MR308 conformed to uITRON4 is downloaded, this window supports the displays listed below.

- Task status
- Ready queue status
- Timeout queue status
- Event flag status
- Semaphore status
- Mailbox status
- Data queue status
- Cyclic handler status
- Alarm handler status
- Memory pool status

If a target program created by MR30 or MR308 conformed to uITRON3 is downloaded, this window supports the displays listed below.

If a target program created on MR30 V.1.00 is downloaded, the MPL mode cannot be used on MR30. (You cannot select the menu which changes the current mode to the MPL mode.)

- Task status
- Ready queue status
- Timeout queue status
- Event flag status
- Semaphore status
- Mailbox status
- Cyclic handler status
- Alarm handler status
- Memory pool status

ATTENTION

Please use the startup file (crt0mr.axx/start.axx) whose contents matches with the version of MRxx, when you make downloaded program. The MR Window and MR command will not run properly if the startup file you uses don't match with the version of MRxx.

7.14.1.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Mode	Task	Displays Task status.
	Ready Queue	Displays Ready status.
	Timeout Queue	Displays Timeout status.
	Event Flag	Displays Event Flag status.
	Semaphore	Displays Semaphore status.
	Mailbox	Displays Mailbox status.
	Data Queue	Displays Data Queue status.
	Cyclic Handler	Displays Cyclic Handler status.
	Alarm Handler	Displays Alarm Handler status.
	Memory Pool	Displays Memory Pool status.
	Message Buffer	Displays Message Buffer status.
	Port	Displays Port status.
Mailbox(with Priority)	Displays Mailbox(with Priority) status.	
Context...		Displays Context.
Layout	Status Bar	Switch display or non-display of status bar.
Refresh		Refresh memory data.
RAM Monitor	Enable RAM Monitor	Switch enable or disable RAM Monitor function.
	Sampling Period...	Set RAM Monitor sampling period.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.14.2 Display the Task Status

In the MR window, select Popup Menu - [Mode] -> [Task].

ID	StaAddr	(name)	Pri	Status	wup_count	timeout	flg_ptn	flg_mode
1	0F17F8H	(_main)	1	RUN	0000H	----	----	----
2	0F1A68H	(_task2)	2	RDY	0000H	----	----	----
3	0F1A76H	(_task3)	2	SUS	0000H	----	----	----
4	0F1A84H	(_task4)	1	WAI(SLP)	0000H	----	----	----
5	0F1A9AH	(_task5)	1	WAI(SLP)-SUS	0000H	----	----	----
6	0F1AB0H	(_task6)	1	WAI(DLY)	0000H	7FFFH	----	----
7	0F1ACAH	(_task7)	1	WAI(DLY)-SUS	0000H	7FFFH	----	----
8	0F1AE4H	(_task8)	1	WAI(FLG)	0000H	----	1111H	TWF_ORW
9	0F1B02H	(_task9)	1	WAI(FLG)-SUS	0000H	----	1111H	TWF_ORW

By double-clicking any line, the information on the task context is displayed in the Context dialog. For details on the Context dialog, see "7.14.12 Display the Task Context"

The following data is displayed in the status bar.

Current Run Task:[1] (_main)

7.14.2.1 Display the Task Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the tasks defined in the configuration are listed in the order of ID number. The function of each item is as described below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Items	Contents
ID	Task ID
StaAddr	Starting address of task
(name)	Task name
Pri	Priority
Status*1	Task status
wup_count	Wake-up count
timeout	Timeout value
flg_ptn	Wait bit pattern of event flag
flg_mode*2	Wait cancellation condition of event flag

- *1Task Status

Display	Status
RUN	Run status
RDY	Ready Status
SUS	Suspend status
DMT	Dormant status
WAI(SLP)	Sleep state
WAI(SLP)-SUS	Sleep state(double wait)
WAI(DLY)	Time wait state duw to dly_tsk
WAI(DLY)-SUS	Time wait state duw to dly_tsk(double wait)
WAI(FLG)	Event flagwait status
WAI(FLG)-SUS	Event flagwait status(double wait)
WAI(SEM)	Semaphore wait status
WAI(SEM)-SUS	Semaphore wait status(double wait)
WAI(MBX)	Message wait status
WAI(MBX)-SUS	Message wait status(double wait)
WAI(SLP-TMO)	Sleep state with time-out
WAI(SLP-TMO)-SUS	Sleep state with time-out(double wait)
WAI(FLG-TMO)	Event flag wait state with time-out
WAI(FLG-TMO)-SUS	Event flag wait state with time-out(double wait)
WAI(SEM-TMO)	Semaphore wait state with time-out
WAI(SEM-TMO)-SUS	Semaphore wait state with time-out(double wait)
WAI(MBX-TMO)	Message wait state with time-out
WAI(MBX-TMO)-SUS	Message wait state with time-out(double wait)

- *2Display the Wait Cancellation Condition of Event Flag

flg_mode	Status
TWF_ANDW	Waits for all bits set in the wait bit pattern to be set (AND wait)
TWF_ANDW+TWF_CLR	Clears the event flag to 0 when an AND wait has occurred and the task wait status has been cancelled
TWF_ORW	Waits for any one bit set in the wait bit pattern to be set (OR wait)
TWF_ORW+TWF_CLR	Clears the event flag to 0 when an OR wait has occurred and the task wait status has been cancelled

7.14.2.2 Display the Task Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the tasks defined in the configuration are listed in the order of ID number. The function of each item is as described below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Items	Contents
ID	Task ID
Name	Task name
Pri	Priority
Status*1	Task status
Wupcnt	Wake-up count
Actcnt	Activated count
Tmout	Timeout value
Flgptn	Wait bit pattern of event flag
Wfmode*2	Wait cancellation condition of event flag

- *1Task Status


Display	Status
RUN	Run status
RDY	Ready Status
SUS	Suspend status
DMT	Dormant status
WAI(SLP)	Sleep state
WAI(SLP)-SUS	Sleep state(double wait)
WAI(DLY)	Time wait state due to dly_tsk
WAI(DLY)-SUS	Time wait state due to dly_tsk(double wait)
WAI(FLG)	Event flagwait status
WAI(FLG)-SUS	Event flagwait status(double wait)
WAI(SEM)	Semaphore wait status
WAI(SEM)-SUS	Semaphore wait status(double wait)
WAI(MBX)	Message wait status
WAI(MBX)-SUS	Message wait status(double wait)
WAI(SDTQ)	Transmission data wait status
WAI(SDTQ)-SUS	Transmission data wait status(double wait)
WAI(RDTQ)	Reception data wait status
WAI(RDTQ)-SUS	Reception data wait status(double wait)
WAI(VSDTQ)	Transmission extended data wait status
WAI(VSDTQ)-SUS	Transmission extended data wait status(double wait)
WAI(VRDTQ)	Reception extended data wait status
WAI(VRDTQ)-SUS	Reception extended data wait status(double wait)
WAI(MPF)	Fixed length memory pool wait
WAI(MPF)-SUS	Fixed length memory pool wait(double wait)
WAI(SLP-TMO)	Sleep state with timeout
WAI(SLP-TMO)-SUS	Sleep state with timeout(double wait)
WAI(FLG-TMO)	Event flag wait state with timeout
WAI(FLG-TMO)-SUS	Event flag wait state with timeout(double wait)
WAI(SEM-TMO)	Semaphore wait state with timeout
WAI(SEM-TMO)-SUS	Semaphore wait state with timeout(double wait)
WAI(MBX-TMO)	Message wait state with time-out
WAI(MBX-TMO)-SUS	Message wait state with timeout(double wait)
WAI(SDTQ-TMO)	Transmission data with timeout wait status
WAI(SDTQ-TMO)-SUS	Transmission data with timeout wait status(double wait)
WAI(RDTQ-TMO)	Reception data with timeout wait status
WAI(RDTQ-TMO)-SUS	Reception data with timeout wait status(double wait)
WAI(VSDTQ-TMO)	Transmission extended data with timeout wait status
WAI(VSDTQ-TMO)-SUS	Transmission extended data with timeout wait status(double wait)
WAI(VRDTQ-TMO)	Reception extended data with timeout wait status
WAI(VRDTQ-TMO)-SUS	Reception extended data with timeout wait status(double wait)
WAI(MPF-TMO)	Fixed length memory pool with timeout wait
WAI(MPF-TMO)-SUS	Fixed length memory pool with timeout wait(double wait)

- *2Display the Wait Cancellation Condition of Event Flag

Wfmode	Status
TWF_ANDW	Waits for all bits set in the wait bit pattern to be set (AND wait)
TWF_ORW	Waits for any one bit set in the wait bit pattern to be set (OR wait)

7.14.3 Display the Ready Queue Status

In the MR window, select Popup Menu - [Mode] -> [Ready Queue].



The following data is displayed in the status bar.



7.14.3.1 Display the Ready Queue Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

The function of each item is as described below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
Pri	Displays priority
RdyQ	Shows the ID Nos. and task names of tasks in the ready queue

- Up to 8 characters of the task name is displayed in the RdyQ field. When the task name exceeds 8 characters, the extra characters are omitted.

7.14.3.2 Display the Ready Queue Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)


The function of each item is as described below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
Pri	Displays priority
Ready Queue	Shows the ID Nos. and task names of tasks in the ready queue

- Up to 8 characters of the task name is displayed in the Ready Queue field. When the task name exceeds 8 characters, the extra characters are omitted.

7.14.4 Display the Timeout Queue Status

In the MR window, select Pop-up Menu - [Mode] -> [Timeout Queue].



7.14.4.1 Display the Timeout Queue Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

The function of each item is as described below.

Tasks waiting at present are displayed in the descending order of timeout value. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
Value	Shows the timeout value of each task
ID(name)	Shows the ID No. and task name of the tasks in the timeout queue

- Following character strings are used to indicate the type of wait state.

Character string	Wait state
[slp]	Wait due to tslp_tsk
[dly]	Wait due to dly_tsk
[flg]	Wait due to twai_flg
[sem]	Wait due to twai_sem
[mbx]	Wait due to trcv_msg

- When a task connected to the timeout queue is in the state of forced waiting (double waiting), a string "[s]", which indicates double waiting, is appended to a string displayed in the ID (name) field.

Normal display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]

7.14.4.2 Display the Timeout Queue Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

The function of each item is as described below.

Tasks waiting at present are displayed in the descending order of timeout value. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
Tmout	Shows the timeout value (ms) of each task
ID(Name)	Shows the ID No. and task name of the tasks in the timeout queue

- Following character strings are used to indicate the type of wait state.


Character string	Wait state
[slp]	Wait due to tslp_tsk
[dly]	Wait due to dly_tsk
[flg]	Wait due to twai_flg
[sem]	Wait due to twai_sem
[mbx]	Wait due to trcv_mbx
[mpf]	Wait due to tget_mpf
[sdtq]	Wait due to tsnd_dtq
[rdtq]	Wait due to trcv_dtq
[vsdtq]	Wait due to vtsnd_dtq
[vrtdq]	Wait due to vtrcv_dtq

- When a task connected to the timeout queue is in the state of forced waiting (double waiting), a string "[s]", which indicates double waiting, is appended to a string displayed in the ID(Name) field.

Normal display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]

7.14.5 Display the Event Flag Status

In the MR window, select Popup Menu - [Mode] -> [Event Flag].



7.14.5.1 Display the Event Flag Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the event flags defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of event flag
flg_ptn	Bit pattern of each event flag
flagQ	Task ID Nos. and task names in the event flag queue

- When a task connected to the event flag queue is in the state of waiting with timeout enabled (waiting in twai_flg), a string "[tmo]", which indicates a state of waiting with timeout enabled, is appended to a string displayed in the flag Q field.
When a task connected to the event flag queue is in the state of forced waiting (double waiting), a string "[s]", which indicates double waiting, is appended to a string displayed in the flag Q field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the flag Q field.If a task name exceeds 8 characters, the extra characters are omitted.

7.14.5.2 Display the Event Flag Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the event flags defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of event flag
Flgatr	Attribute of each event flag
Flgptn	Bit pattern of each event flag
Flag Queue	Task ID Nos. and task names in the event flag queue

- The following are displayed in the Flgatr area:

TA_TFIFO	Task wait queue is in FIFO order
TA_TPRI	Task wait queue is in task priority order
TA_WSGL	Only one task is allowed to be in the waiting state for the eventflag
TA_WMUL	Multiple tasks are allowed to be in the waiting state for the eventflag
TA_CLR	Eventflag's bit pattern is cleared when a task is released from the waiting state for that eventflag


- When a task connected to the event flag queue is in the state of waiting with timeout enabled (waiting in twai_flg), a string "[tmo]", which indicates a state of waiting with timeout enabled, is appended to a string displayed in the Flag Queue field.
When a task connected to the event flag queue is in the state of forced waiting (double waiting), a string "[sl]", which indicates double waiting, is appended to a string displayed in the Flag Queue field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the Flag Queue field.
If a task name exceeds 8 characters, the extra characters are omitted.

7.14.6 Display the Semaphore Status

In the MR window, select Popup Menu - [Mode] -> [Semaphore].



7.14.6.1 Display the Semaphore Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the SEMs defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of semaphore
Def_cnt	Default value of semaphore counter
Count	Semaphore count
semQ	Task ID Nos. and task names in the semaphore queue

- When a task connected to the SEM queue is in the state of waiting with timeout enabled (waiting in twai_sem), a string "[tmo]", which indicates a state of waiting with timeout enabled, is appended to a string displayed in the semQ field.
When a task connected to the SEM queue is in the state of forced waiting (double waiting), a string "[s]", which indicates double waiting, is appended to a string displayed in the semQ field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the semQ field. If a task name exceeds 8 characters, the extra characters are omitted.

7.14.6.2 Display the Semaphore Status (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the SEMs defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of semaphore
Sematr	Attribute of each semaphore
Semcnt	Semaphore count
Semaphore Queue	Task ID Nos. and task names in the semaphore queue

-
- The following are displayed in the Sematr area:

TA_TFIFO	Task wait queue is in FIFO order
TA_TPRI	Task wait queue is in task priority order


- When a task connected to the SEM queue is in the state of waiting with timeout enabled (waiting in twai_sem), a string "[tmo]", which indicates a state of waiting with timeout enabled, is appended to a string displayed in the Semaphore Queue field.
When a task connected to the SEM queue is in the state of forced waiting (double waiting), a string "[s]", which indicates double waiting, is appended to a string displayed in the Semaphore Queue field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the Semaphore Queue field. If a task name exceeds 8 characters, the extra characters are omitted.

7.14.7 Display the Mailbox Status

In the MR window, select Popup Menu - [Mode] -> [Mailbox].



7.14.7.1 Display the Mailbox Status (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the mail boxes defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of mailbox
Msg_cnt	Number of messages in each mailbox
MAXmsg	Maximum number of messages that can be contained in each mailbox
Wait Queue(Message)	The messages stored in the mailbox or ID No. and task name of tasks waiting for messages

- The WaitQueue (Message) field shows a string "Msg" when a message is stored (when Msg_cnt as described above is non-zero), and then displays the stored message. When no message is stored (when Msg_cnt is zero), the WaitQueue field displays a string "Task" if a task waiting for a message exists, and then displays the ID number and name of the task waiting for a message.
- When a task connected to the mail box queue is in the state of waiting with timeout enabled (waiting in trcv_msg), a string "[tmo]", which indicates the state of timeout enabled, is appended to a string displayed in the WaitQueue (Message) field. When a task connected to the mail box queue is in the state of forced waiting (Double waiting), a string "[s]", which indicates the state of double waiting, is appended to a string displayed in the WaitQueue (Message) field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the WaitQueue (Message) field. If a task name exceeds 8 characters, the extra characters are omitted.

7.14.7.2 Display the Mailbox Status (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the mail boxes defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of mailbox
Mbxatr	Attribute of each mailbox
Mailbox Queue (Wait)	ID No. and task name of tasks waiting for messages
Mailbox Queue (Message)	The messages stored in the mailbox

- The following are displayed in the Mbxatr area:

TA_TFIFO	Task wait queue is in FIFO order
TA_TPRI	Task wait queue is in task priority order
TA_MFIFO	Message queue is in FIFO order
TA_MPRI	Message queue is in message priority order

- When a task connected to the mail box queue is in the state of waiting with timeout enabled (waiting in `trev_mbx`), a string "[tmo]", which indicates the state of timeout enabled, is appended to a string displayed in the Mailbox Queue (Wait) field.


When a task connected to the mail box queue is in the state of forced waiting (Double waiting), a string "[s]", which indicates the state of double waiting, is appended to a string displayed in the Mailbox Queue (Wait) field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the Mailbox Queue (Wait) field. If a task name exceeds 8 characters, the extra characters are omitted.

7.14.8 Display the Data Queue Status

In the MR window, select Pop-up Menu - [Mode] -> [Data Queue].



7.14.8.1 Display the Data Queue Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the data queues defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of data queue
Dtqatr	Attribute of each data queue
Dtcnt	Number of messages in each data queue
Dtqsz	Maximum number of messages that can be contained in each data queue
Data Queue (Wait)	ID No. and task name of tasks waiting for message transmission waiting or message reception waiting
Data Queue (Data)	The messages stored in the data queue

- The display of the ID field varies depending on which one is specified, the standard data(32 bits) or the extended data(16 bits).

MR308/4

- If the standard data(32 bits), the ID field displays a string "[32]" and data queue ID number.
- If the extended data(16 bits), the ID field displays a string "[16]" and data queue ID number.

MR30/4

- If the standard data(16 bits), the ID field displays a string "[16]" and data queue ID number.
- If the extended data(32 bits), the ID field displays a string "[32]" and data queue ID number.

- The following are displayed in the Dtqatr area:

TA_TFIFO	Task wait queue is in FIFO order
TA_TPRI	Task wait queue is in task priority order


-
- The Data Queue (Wait) field displays a string "Send" if a task waiting for a message sending, and then displays the ID number and name of the task waiting for a message sending. Also, if a task waiting for a message receiving, displays a string "Receive" and then displays the ID number and name of the task waiting for a message receiving.
 - When a task connected to the data queue is in the state of waiting with timeout enabled , a string "[tmo]", which indicates the state of timeout enabled, is appended to a string displayed in the Data Queue (Wait) field.
When a task connected to the data queue is in the state of forced waiting (Double waiting), a string "[s]", which indicates the state of double waiting, is appended to a string displayed in the Data Queue (Wait) field.

Normal Display	26(_task26)
Display when in WAIT-SUSPEND	26(_task26)[s]
Display when in WAIT-SUSPEND with time out	26(_task26)[tmo][s]

- Up to 8 characters can be displayed in the task name in the Data Queue (Wait) field.If a task name exceeds 8 characters, the extra characters are omitted.

7.14.9 Display the Cycle Handler Status

In the MR window, select Pop-up Menu - [Mode] -> [Cyclic Handler].



ID	StaAddr	(name)	interval	count	Status
1	0F1C56H	(_cycle1)	0064H	0064H	TCY_ON
2	0F1C58H	(_cycle2)	03E8H	03E8H	TCY_OFF
3	0F1C5AH	(_cycle3)	01F4H	01F4H	TCY_ON
4	0F1C5CH	(_cycle4)	0258H	0258H	TCY_ON
5	0F1C5EH	(_cycle5)	00C8H	00C8H	TCY_OFF
6	0F1C60H	(_cycle6)	012CH	012CH	TCY_ON
7	0F1C62H	(_cycle7)	0190H	0190H	TCY_ON
8	0F1C64H	(_cycle8)	015EH	015EH	TCY_ON

7.14.9.1 Display the Cycle Handler Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the cycle handlers defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of cycle handler
StaAddr	Starting address of cycle handler
(name)	Name of cycle handler
interval	Interrupt interval
count	Interrupt count
Status	Activity status of cycle start handler

- The following are displayed in the Status area:

TCY_ON	Cycle handler enabled
TCY_OFF	Cycle handler disabled

7.14.9.2 Display the Cycle Handler Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the cycle handlers defined in the configuration are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)


Item	Contents
ID	ID No. of cycle handler
Name	Name of cycle handler
Cycphs	The activation phase (by the millisecond)
Cyctim	The activation cycle time (by the millisecond)
Tmout	The amount of time by the millisecond remaining before the cyclic handler's next activation time
Status	Activity status of cycle start handler

- The following are displayed in the Status area:

TCYC_STA	Cycle handler is in an operational state
TCYC_STP	Cycle handler is in a non-operational state

7.14.10 Display the Alarm Handler Status

In the MR window, select Popup Menu - [Mode] -> [Alarm Handler].



ID	StaAddr	(name)	AlarmTime
2	0F1C68H	(_alarm2)	0000H : 0000H : ABCDH
6	0F1C70H	(_alarm6)	0000H : 1000H : 0003H
1	0F1C66H	(_alarm1)	0000H : ABCDH : 1000H
7	0F1C72H	(_alarm7)	000DH : 0013H : 1001H
3	0F1C6AH	(_alarm3)	00CDH : 0003H : 0003H
4	0F1C6CH	(_alarm4)	00CDH : 0003H : 0353H
5	0F1C6EH	(_alarm5)	00CDH : 0AA3H : 0001H

When the realtime OS is MRxx conformed to uITRON specifications V.3.0, the following data is displayed in the status bar.

Remain Handler:7 (Now System Clock Count = 0000H:0000H:018AH)

7.14.10.1 Display the Alarm Handler Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Of all the cycle start handlers defined in the configuration, only those which are not started yet at present are listed in the ascending order of start time. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of alarm handler
StaAddr	Starting address of alarm handler
(name)	Name of alarm handler
AlarmTime	Starting time of alarm handler

7.14.10.2 Display the Alarm Handler Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Of all the cycle start handlers defined in the configuration, only those which are not started yet at present are listed in the ascending order of start time. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of alarm handler
Name	Name of alarm handler
Almtim	The amount of time by the millisecond remaining before the alarm handler's activation time
Status	Activity status of alarm handler

- The following are displayed in the Status area:

TALM_STA	Alarm handler is in an operational state
TALM_STP	Alarm handler is in a non-operational state

7.14.11 Display the Memory Pool Status

In the MR window, select Popup Menu - [Mode] -> [Memory Pool].

ID	BaseAddr	Blk size	Total Blk cnt	Free Blk cnt (map)
[F]1	0007B2H	80	4	2 (-----1100)
[F]2	0008F2H	10	10	9 (-----111111110)
[F]3	000956H	30	16	15 (111111111111110)
[V]1(1)	0018B6H	24	--	1
1(2)	000000H	56	--	0
1(3)	000000H	120	--	0
1(4)	001A96H	248	--	6

7.14.11.1 Display the Memory Pool Status(When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

All the memory pools defined in the configuration are listed in the order of ID number. (The fixed length data comes first, and the optional length data comes after the fixed length data.) The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.3.0.)

Item	Contents
ID	ID No. of memory pool
BaseAddr	Base address of memory pool
Blk_Size	Block size of memory pool
Total Blk_cnt	Total block count of memory pool
Free Blk_cnt(map)	Number of unused blocks and information on unused memory blocks (bit information)

- The display of the ID field varies depending on which one is specified, fixed length or optional length.
 - If the data is of fixed length, the ID field displays a string "[F]" and memory pool ID number.
 - For an arbitrary length, the contents displayed on the first line are the character string "[V]," a memory pool ID number, and a block ID number. Displayed on the second to fourth lines are the memory pool ID and block ID numbers. The block ID numbers are enclosed in parentheses.
- When specifying the optional length memory pool, "--" is displayed in the Total Blk_cnt field. No bit information is displayed in the Free Blk_cnt (map) field.
- When specifying the fixed-length memory pool, the display format of each bit in the memory block information in Free Blk_cnt (map) is as shown below:

item	Contents
'0'	Memory block in use (busy)
'1'	Memory block not in use (ready)
','	No memory block

7.14.11.2 Display the Memory Pool Status(When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

All the memory pools are listed in the order of ID number. The function of each item is listed below. (When the realtime OS is MRxx conformed to uITRON specifications V.4.0.)

Item	Contents
ID	ID No. of memory pool
Mplatr	Attribute of each memory pool
Mpladr	Base address of memory pool
Mplsz	Size of memory pool
Blkcnt	Total block count of fixed length memory pool
Fblkcnt	Number of unused blocks and information on unused memory blocks
Memory Pool Queue	Displays the ID number and name of tasks waiting in the memory pool.

- The following are displayed in the Mplatr area:

TA_TFIFO	Task wait queue is in FIFO order
TA_TPRI	Task wait queue is in task priority order

- The display of the ID field varies depending on which one is specified, fixed length or optional length.
 - If the data is of fixed length, the ID field displays a string "[F]" and memory pool ID number.
 - For an arbitrary length, the contents displayed on the first line are the character string "[V]," a memory pool ID number, and a block ID number. Displayed on the second to fourth lines are the memory pool ID and block ID numbers. The block ID numbers are enclosed in parentheses.


7.14.12 Display the Task Context

7.14.12.1 Display the Task Context

In the MR window, select Popup Menu - [Context...].

The Context dialog box is opened. The Context dialog box is used to reference/specify the context information of the specified task.

You can also open the Context dialog box by double-clicking the data display area in the task state display mode .



Enter the task ID number in the Task ID field and click the View button (or press the Enter key).

The context of the specified task appears in the Context field.


If the task entered in the Task ID field is "RUN" or "DMT" when clicking the View button, the context is not displayed. (In the Context field, only the task ID and task state are displayed.)

- If a task ID number which does not exist is entered in the Task ID field when clicking the View button, an error occurs.

7.14.12.2 Change the task context

Enter the task ID number in the Task ID field in the Context dialog and click the Set button. The Set Context dialog is opened.

The Set Context dialog is used to set the specified context register value of the specified task.



Specify the register to be changed in the Register field list box and enter the value to be set in the "Value:" field.

If an expression description set in the "Value:" field is wrong, or if the specified value is outside the allowable range set for the specified register, an error occurs.

7.15 MR Trace Window

The MR Trace window measures the task execution history of a program using the real time OS and displays the result graphically.

The debugger for 740 doesn't support this function.

In addition to the task execution history, a history of various other operations each are traced and displayed, including interrupt processing, task state transition, and system call issuance.


This window is available only when a target program which uses our real time OS (MRxx) is downloaded.

For MR30

- For MR30, this window is available for V. 2.00 or later version. If a target program created on MR30 V. 1.00 is downloaded, the MR Trace window will not function and not display any data.

For MR308

- The history of the high-speed interrupt can not record and display.



The content of each item is as follows.

Items	Contents
VEC*1	Indicates a software interrupt number.
table	Indicates the interrupt vector table number.
ID	Indicates a task ID number.
(name)	Indicates an interrupt routine name, task name, idle processing (display "idle"), and unknown name(displayed "unknown").

When moving the mouse to the information displayed in the window, the pop up window as below is opened, showing the detailed information.

Interrupt handling or task execution history

```
ID=D' 3 (_task3)
begin:00'00'00:003.008
end:00'00'00:003.015
(end-begin):00'00'00:000.007
```

System call issue history

```
rcv_msg
mbxid=D' 1
E_OK
pk_msg(R1)=H' 1234
pk_msg(R2)=H' 5678
begin:00'00'00:002.861
```

Task state transition history

```
WAI(MBX)
begin:00'00'00:002.880
end:00'00'00:003.167
(end-begin):00'00'00:000.286
```

Following information is displayed in the status bar.

- Time value at which start marker is positioned
- Time value at which end marker is positioned
- Time width of a range indicated by start and end markers
- Time value at which indicator is positioned
- Scale factor of display
- Time width of grid line interval
- Range of measurement (trace) result

The grid lines are displayed using the start marker as the radix point.

The grid lines are displayed using the start marker as the radix point. The scale is displayed, using the time at which the start marker is positioned as 0, with the left (forward in time) set to "minus" and the right (backward in time) set to "plus".

The grid lines allow you to roughly understand the interrupt occurrence cycle and process time.

The interval time width of the displayed grid lines appears in the "Grid" area of the status bar.

The time value in the MR Trace window means the execution elapsed time using the program execution start time as 0 in all the cases. On the contrary, the numeric value above the grid lines (scale) in the MR Trace window is a relative value using the start marker as 0 (the grid interval is specified in the Value dialog).

It has nothing to do with the time value. (This is provided so that you can see the window easily.)

Note

The software interrupt number*1 is different according to product. For details about which interrupt number is assigned to which system call, refer to the MRxx Reference Manual, "Assemble Language Interface."

7.15.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Start Marker		Move the start marker in the display area.
End Marker		Move the end marker in the display area.
Indicator		Move the indicator in the display area.
Adjust		Adjust range of start and end marker to full width of display area Adjust.
Expand		Expand scale factor of display.
Reduce		Reduce scale factor of display.
Trace Stop		Stop measuring.
Trace Restart		Restarts measuring.
Search...		Search for history of system calls.
Trace Range	After	Set measurement range condition to After.
	Break	Set measurement range condition to Break.
Value...		Set value.
Color...		Change display color.
Init Order...		Reset the task order on the display.
Toolbar display		Display toolbar.
Customize toolbar...		Open toolbar customize dialog box.
Allow Docking		Allow window docking.
Hide		Hide window.

7.15.2 Refer the Execution History of Task(MRxx Window)

You can reference the task execution history in the MR Trace window. You can reference the execution history statistical processing result in the MR Analyze window. These windows are available for a target program using our real time OS (MRxx).

7.15.2.1 Select the Trace Range

To measure the task execution history, the real time trace function is used. Click the "After" button (or, select Menu - [Trace Range] ->[After]) or "Break" button (or, select Menu - [Trace Range] -> [Break]) in the MR Trace window.

After	Stores the cycles of trace data after the trace point.
Break	Stores the cycles to the point at which the trace point is passed.

Execute the target program. Record the information required to know the task execution history in the trace memory.

ATTENTION

A trace point set in the Trace Point Setting dialog is disabled.

7.15.2.2 Stop the Task Execution History Measurement


Click the "Stop" button in the Task Trace window. (Or, select Menu - [Trace Stop].) The measurement results so far are displayed in the MR Trace window.

7.15.2.3 Restart the Task Execution History Measurement

Click the "Restart" button in the Task Trace window. (Or, select Menu - [Trace Restart].) When restarting the trace measurement, all the measurement results so far are deleted.

7.15.2.4 Refer the Execution History of Task

You can reference the task execution transition in the MR Trace window.



By moving the mouse to any information displayed in the window, the following window is opened, showing the detailed information.

Interrupt handling or task execution history

```
ID=D' 3 ( _task3)
begin:00'00'00:003.008
end:00'00'00:003.015
(end-begin):00'00'00:000.007
```

System call issue history


```
rcv_msg
mbxid=D' 1
E_OK
pk_msg(R1)=H' 1234
pk_msg(R2)=H' 5678
begin:00'00'00:002.861
```

Task state transition history

```
WAI(MBX)
begin:00'00'00:002.880
end:00'00'00:003.167
(end-begin):00'00'00:000.286
```


7.15.2.4.1. Search the History of System Call Issue

Click the "Search" button in the tool bar. The Search dialog is opened. (Or, select Menu - [Search ...].)



Specify the search condition.

With the function code (R0: Function Code) and error code (R0: Error Code), you can specify multiple values (OR condition). Other items are searched based on the AND condition.

Then, specify the search direction. The debugger searches the items in the direction specified in the dialog, using the position pointed by the indicator as the radix point.

When the debugger does not check all the search items, the subsequent system call issuance history in the search direction will be a search result. Click the Find Next button. The debugger searches the system call issuance history corresponding to the specified condition. The specified items are searched using the AND condition.

If the search condition is met, the indicator is moved to that point.

7.15.2.4.2. Change the display magnification


Click the "Expand" button or "Reduce" button in the tool bar. (Or, select Menu - [Expand] or [Reduce].)

The display is expanded or reduced using the left corner of the graph area as the radix point. By default, the display is expanded or reduced with display scale of 1.5.

The display scale appears in the "Scale:*" field in the status bar.


The default expansion/reduction scale is 1.5. To change the scale, select Menu - [Value ...].

The Value dialog is opened. Specify the display expansion/reduction scale.




7.15.2.4.3. Change the grid line display interval

Select Menu - [Value ...]. The Value dialog is opened. Specify the display time interval.



7.15.2.4.4. *Change the task display order*

Drag the task/interrupt routine to be moved (the left portion of the graph) to the destination.



To initialize the display order, select Menu - [Init Order].

7.15.2.4.5. *Display the specific task only*

Click the task/interrupt routine to be hidden (the left portion of the graph). Every time you click, the setting is switched between "Display" and "Hide".


7.15.2.4.6. *Change the display color*

Select Menu - [Color...]. The Color dialog is opened.

Click the button corresponding to the desired item. The Color Setting dialog is opened. Change the display color in the dialog.

7.15.2.5 Measure the Execution Time of Task

You can measure the execution time between the markers by changing the positions of start marker and end marker in the MR Trace window.



Drag the start marker position and end marker position.
The time interval between the markers is displayed in the status bar.

Note

[Definition of time value in the MR Trace window]

The time value in the MR Trace window indicates the execution elapsed time which sets the program execution start point to 0 in all the cases.

On the contrary, a numeric value above the grid line (scale) in the MR Trace window is a relative value which sets the start marker to 0 (the grid interval is specified in the Value dialog), which has nothing to do with the time value. (It is provided so that you can see the window easily.)

7.15.2.5.1 Move the Marker

Each marker can be moved by dragging. When moving the mouse on the marker, the cursor shape changes. Then, start dragging.

The start marker moves into the window (left portion) by clicking the "Start Marker" button in the tool bar. (Or, select Menu - [Start Marker].)

The end marker moves into the window (right portion) by clicking the "End Marker" button. (Or, select Menu - [End Marker].)

The indicator moves into the window (center) by clicking the "Indicator" button. (Or, select Menu - [Indicator].)

The other markers can move only to the specified positions listed below.

- Position to which the interrupt processing or task execution transits
- Position to which the task state transits
- Position where the system call issuance history is displayed

7.16 MR Analyze Window

The MR Analyze window displays the result of the measurement data statistically analyzed within the range specified by the start marker and the end marker in the MR Trace window.

The debugger for 740 doesn't support this function.

The MR Analyze window supports three display mode as below:

- CPU occupation state by interrupt/task
- Ready time by task
- List of system call issuance histories (You can extract and display the history based on the specific condition.)

The MR Analyze window functions together with the MR Trace window.

This window is available only when a target program using our real time OS (MRxx) is downloaded.

7.16.1 Configuration of CPU Occupancy Status Display Mode

The CPU occupation state display mode is used to display the CPU occupation time and ratio by interrupt/task.

The MR Trace window shows the statistical results within the range specified by the start marker and end marker.

VEC	table	ID	(name)	Num	Max Run Time	Min Run Time	Avg Run Time	Total Run Time	Ratio%	0	25	50	75	100
32	OFFD80		(_SYSCALL0)	17	00"00"00:000.033	00"00"00:000.013	00"00"00:000.022	00"00"00:000.378	0.23					
33	OFFD84		(_SYSCALL1)	5	00"00"00:000.020	00"00"00:000.019	00"00"00:000.019	00"00"00:000.099	0.06					
38	OFFD98		(_SYSCALL2)	3	00"00"00:000.028	00"00"00:000.028	00"00"00:000.028	00"00"00:000.084	0.05					
			Idle	6	00"00"00:000.017	00"00"00:000.002	00"00"00:000.006	00"00"00:000.036	0.02					
		1	(_task1)	11	00"00"00:014.003	00"00"00:000.001	00"00"00:008.957	00"00"00:098.528	60.02					
		2	(_task2)	3	00"00"00:013.003	00"00"00:000.001	00"00"00:008.669	00"00"00:026.008	15.84					
		3	(_task3)	2	00"00"00:013.006	00"00"00:000.003	00"00"00:006.504	00"00"00:013.009	7.92					
		4	(_task4)	2	00"00"00:013.003	00"00"00:000.001	00"00"00:006.502	00"00"00:013.005	7.92					
		5	(_task5)	2	00"00"00:013.007	00"00"00:000.003	00"00"00:006.505	00"00"00:013.011	7.93					
			Unknown	0	00"00"00:000.000	00"00"00:000.000	00"00"00:000.000	00"00"00:000.000	0.00					

By clicking the maximum execution time/minimum execution time display area of each line, you can search interrupt to the clicked line or process history at the maximum/minimum execution time of the task.

The search result is pointed by the indicator which moves to the target position in the MR Trace window.

7.16.2 Configuration of Ready State Duration Display Mode

The ready state time display mode by task is used to display the results generated from statistical process of the time required from execution ready to transition to execution by task.

The statistical result is displayed within the range specified by the start marker and end marker in the MR Trace window.

ID	(name)	Num	Max	Min	Avg
1	{ task1 }	11	00"00'00:013.069	00"00'00:000.013	00"00'00:005.961
2	{ task2 }	3	00"00'00:000.080	00"00'00:000.009	00"00'00:000.032
3	{ task3 }	2	00"00'00:000.083	00"00'00:000.013	00"00'00:000.048
4	{ task4 }	2	00"00'00:000.093	00"00'00:000.009	00"00'00:000.051
5	{ task5 }	2	00"00'00:000.099	00"00'00:000.012	00"00'00:000.056

By clicking the maximum ready time/minimum ready time display area of the desired line, you can search the process history of the maximum ready time/minimum ready time of the task corresponding to the clicked line.

The search result is pointed by the indicator which moves to the target position in the MR Trace window.

7.16.3 Configuration of System Call History Display Mode

The system call issuance history list mode is used to list the system calls issued.

The system call issuance history is listed within the range specified by the start marker and end marker in the MR Trace window.

The number indicates a numeric value counted from the top system call within the measurable range.

No	System Call	Parameter	Return Parameter	TIME
7	wai_flg	wfmode=H'3 waiptn=H'1 flgid=D'1	E OK flgpptn=H'1	00"00'00:000.501
8	wai_sem	semid=D'1	E OK	00"00'00:000.533
9	rcv_msg	mbxid=D'1	E OK pk_msg(R1)=H'1234 pk	00"00'00:000.565
10	wup_tsk	tskid=D'2	E OK	00"00'00:000.594
11	slp_tsk		E OK	00"00'00:013.620
12	rsm_tsk	tskid=D'2	E OBJ	00"00'00:020.147
13	set_flg	setpntn=H'1 flgid=D'1	E OK	00"00'00:033.163
14	wai_flg	wfmode=H'3 waiptn=H'1 flgid=D'1	ercd=??? flgpptn=???	00"00'00:046.203
15	rsm_tsk	tskid=D'3	E OBJ	00"00'00:052.734
16	sig_sem	semid=D'1	E OK	00"00'00:065.751
17	wai_sem	semid=D'1	ercd=???	00"00'00:078.780
18	rsm_tsk	tskid=D'4	E OBJ	00"00'00:085.310
19	snd_msg	pk_msg(R1)=H'5678 pk_msg(R3)=H'12	E OK	00"00'00:098.327
20	rcv_msg	mbxid=D'1	ercd=??? pk_msg(R1)=??? pk	00"00'00:111.362

By clicking the desired line, you can search the system call issuance history to the clicked line.

The search result is pointed by the indicator which moves to the target position in the MR Trace window.

7.16.4 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu	Function
Run Time	CPU occupancy status display mode.
Rdy->Run	Ready state duration display mode.
System Call	System call history display mode.
Pick Up System Call...	Extract specified system calls display mode.
Toolbar display	Display toolbar.
Customize toolbar...	Open toolbar customize dialog box.
Allow Docking	Allow window docking.
Hide	Hide window.

7.16.5 Analyze the Execution History of Task

You can reference the execution history statistical processing in the MR Analyze window. The MR Analyze window functions together with the MR Trace window. If the MR Trace window is not open, or the MR Trace window does not show any data, the MR Analyze window will not function.

The execution history statistical processing function allows you to reference the following topics.

7.16.5.1.1. Refer the CPU Occupation State

Click the Run Time button in the tool bar. (Or, select Menu - [Run Time].) The MR Analyze window changes to the CPU occupation state display mode.

VEC	table	ID	(name)	Num	Max Run Time	Min Run Time	Avg Run Time	Total Run Time	Ratio%
32	0FFD80		(SYSCALL0)	17	00"00"00:000.033	00"00"00:000.013	00"00"00:000.022	00"00"00:000.378	0.23
33	0FFD84		(SYSCALL1)	5	00"00"00:000.020	00"00"00:000.019	00"00"00:000.019	00"00"00:000.099	0.06
38	0FFD98		(SYSCALL2)	3	00"00"00:000.028	00"00"00:000.028	00"00"00:000.028	00"00"00:000.084	0.05
			Idle	6	00"00"00:000.017	00"00"00:000.002	00"00"00:000.006	00"00"00:000.036	0.02
		1	(task1)	11	00"00"00:014.003	00"00"00:000.001	00"00"00:008.957	00"00"00:098.528	60.02
		2	(task2)	3	00"00"00:013.003	00"00"00:000.001	00"00"00:008.669	00"00"00:026.008	15.84
		3	(task3)	2	00"00"00:013.006	00"00"00:000.003	00"00"00:006.504	00"00"00:013.009	7.92
		4	(task4)	2	00"00"00:013.003	00"00"00:000.001	00"00"00:006.502	00"00"00:013.005	7.92
		5	(task5)	2	00"00"00:013.007	00"00"00:000.003	00"00"00:006.505	00"00"00:013.011	7.93
			Unknown	0	00"00"00:000.000	00"00"00:000.000	00"00"00:000.000	00"00"00:000.000	0.00

The window shows the CPU occupation time and ratio by interrupt processing and by task.

The data displayed is the statistical results for the range specified with the start marker and end marker in the MR Trace window.

By clicking the maximum execution time/minimum execution time display field of each line, you can search the processing history at the maximum execution time/minimum execution time of the task corresponding to the clicked line.

The search result is pointed by the indicator in the MR Trace window after the indicator moves to the destination position.

7.16.5.2 Refer the Ready Queue Time

Click the Ready->Run button in the tool bar. (Or, select Menu - [Rdy -> Run].)

Mark: 00"00'00:000.335 - 00"00'00:164.498 = 00"00'00:164.163

ID	(name)	Num	Max	Min	Avg
1	{ task1}	11	00"00'00:013.069	00"00'00:000.013	00"00'00:005.961
2	{ task2}	3	00"00'00:000.080	00"00'00:000.009	00"00'00:000.032
3	{ task3}	2	00"00'00:000.083	00"00'00:000.013	00"00'00:000.048
4	{ task4}	2	00"00'00:000.093	00"00'00:000.009	00"00'00:000.051
5	{ task5}	2	00"00'00:000.099	00"00'00:000.012	00"00'00:000.056

The time required from execution ready state to transition to execution state by task is processed statistically and displayed.

The data displayed is the statistical results of the range specified with the start marker and end marker in the MR Trace window.

By clicking the maximum ready time/minimum ready time display field of each line, you can search the processing history at the maximum ready time/minimum ready time of the task corresponding to the clicked line.

The search result is pointed by the indicator in the MR Trace window after the indicator moves to the destination position.

7.16.5.3 Refer the System Call Issuance History

Click the "System Call" button in the tool bar. (Or, select Menu - [System Call].)

Mark: 00"00'00:000.335 - 00"00'00:164.498 = 00"00'00:164.163

No	System Call	Parameter	Return Parameter	TIME
7	wai flg	wfmode=H'3 waiptn=H'1 flgid=D'1	E OK flgpfn=H'1	00"00'00:000.501
8	wai sem	semid=D'1	E OK	00"00'00:000.533
9	rcv msg	mbxid=D'1	E OK pk_msg(R1)=H'1234 pk	00"00'00:000.565
10	wup tsk	tskid=D'2	E OK	00"00'00:000.594
11	slp tsk		E OK	00"00'00:013.620
12	rsm tsk	tskid=D'2	E OBJ	00"00'00:020.147
13	set flg	setpfn=H'1 flgid=D'1	E OK	00"00'00:033.163
14	wai flg	wfmode=H'3 waiptn=H'1 flgid=D'1	ercd=??? flgpfn=???	00"00'00:046.203
15	rsm tsk	tskid=D'3	E OBJ	00"00'00:052.734
16	sig sem	semid=D'1	E OK	00"00'00:065.751
17	wai sem	semid=D'1	ercd=???	00"00'00:078.780
18	rsm tsk	tskid=D'4	E OBJ	00"00'00:085.310
19	snd msg	pk_msg(R1)=H'5678 pk_msg(R3)=H'12	E OK	00"00'00:098.327
20	rcv msg	mbxid=D'1	ercd=??? pk_msg(R1)=??? pk	00"00'00:111.362

The issued system calls are listed in chronological order of system call.


The data displayed is the statistical results for the range specified with the start marker and end marker in the MR Trace window.

By clicking each line, you can search the system call issuance history corresponding to the clicked line. The search result is pointed by the indicator in the MR Trace window after the indicator moves to the destination position.

7.16.5.3.1. Extract the Issuance History

Click the "Pick Up" button in the tool bar. (Or, select Menu - [Pick Up System Call...])

The dialog shown below is opened. Specify the search condition of the system call to be extracted and displayed.



Extract the issuance history of the system call which meets the specified condition and display it.

7.17 MR Task Pause Window


The MR Task Pause Window realizes the task pause function of the real time OS (MR308/MR30).

The debugger for 740 doesn't support this function.

You can pause and unpaue the specified task from this window.

The window can be used only when the program containing the system of the MR308/MR30 for the task pause functions and system clock timer is downloaded.

The MR30 task pause function is supported with MR30 V.3.00 or later. Previously installed target programs cannot be used with this window.



- The information (ID number, name, context PC value during "Pause") on all the tasks defined in the configuration file when creating the target program is displayed in the task pause display area. Select the target task for task pause from this display area.
- The specified program content is displayed in the task source display area. When performing "Come-pause", specify the stop position using the cursor in this display area.

7.17.1 About Task Pause Function

The task pause function is to pause/unpause only the specific task while executing the target system. When using the task pause function, you can specify the specific task while executing all the other tasks and interrupts.

Also, as debugging is available, such as "Come-pause" (pause at the location you specified), effective debugging is provided without affection to peripheral devices controlled by tasks or interrupts.

The following lists terminology definitions used in this section.

- PAUSE state
Indicates a state of the tasks that are stopped by the task pause function during execution of the target program.
- Pause
Indicates a process to make the specific task in the PAUSE state.
- Unpause
Indicates a process to make the specific task out of the PAUSE state.
- Come-pause
Indicates a process to pause the specific task at the specified address.

ATTENTION

Task pause function uses the address match interrupt of the MCU.

Don't use this function when the target program uses the address match interrupt.

If you use PC7501 emulator, this function is not available when you use address match interrupt break function.

7.17.2 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu	Function	
Task	Pause	Make the selected task in the PAUSE state.
	Come-pause	Make the selected task in the PAUSE state just before executing the code at the cursor in the program display view.
	Unpause	Make the selected task out of the PAUSE state.
Display	Source/Function...	Displays the beginning of the specified file/function.
	Address...	Displays the program from the specified address.
	Program Counter *	Displays the program from the current program counter value.
Mode	Source	Switches the view to the source mode.
	Mixed	Switches the view to the mixed mode.
	Disassembly	Switches the view to the disassembly mode.
Layout	Line	Shows/Hides the line number column.
	Address	Shows/Hides the address number column.
	Code	Shows/Hides the line code column.
Tab...	Changes Tab number.	
Toolbar display	Displays the toolbar.	
Customize toolbar...	Opens the toolbar customize dialog box.	
Allow Docking	Allows the window docking.	
Hide	Hides the window.	


*Operation in the MR task pause window is as follows when the program display location is changed by PC position specification.

- When the target task selected in the task pause display area is paused
-> Its display position is changed to the context PC position of the task.
- When the target task selected in the task pause display area is in a state other than "pause"
-> The display position is not changed.
- When the target task is selected from the task pause display area
-> The display position is changed to the position from the current program counter (in the same manner as the operation in the Source window).

7.17.3 Pause the Specified Task

Use the MR Task Pause window.

To open the MR Task Pause window, select Menu - [View] -> [RTOS] -> [MR Task Pause].




1. Click the ID field or (name) field in the task pause display field of the task line to be paused. After the target task is selected, the task ID number is displayed in the status bar.
2. If the selected task is in a state other than "Pause", the Pause button is enabled. Click the Pause button. The task selected at this timing is paused. (This is enabled only when the selected task is in the execution state.)

ATTENTION

You can pause the target task which is in the execution state only. If target task is in a state other than execution, the pause process is terminated while the target task is not being paused. (If this happens, an error dialog appears.)


If the timing at which the target task enters the execution state is hard to judge, use the task Come-pause (a function to pause only the specific task at specified position).

7.17.3.1 Pause Task Being Executed at a Specified Position



1. Click the ID field or (name) field of the task pause display field of the task line to be paused. After the target task is selected the task ID number appears in the status bar. In the task source display area, the program starting from the task start address is displayed (if the program is in a state other than Pause).
2. Click the line to be paused in the task source display area. The Come-pause button and Pause button are enabled.
3. Click the Come button. The selected task is paused at the position where the task is executed immediately before the cursor position.

7.17.3.2 Pause After a Paused Task is Executed up to Specified Position



1. Click the ID field or (name)field of the task pause display area of the target task. After the target task is selected, the task ID number is displayed in the status bar. In the task source display area, the program starting from the task's Pause position (context PC position) is displayed (if the program is in a state other than Pause).
2. Click the line to be paused in the task source display area. The Come-pause button and the Pause button are enabled.
3. Click the Come button. The selected task is released from the PAUSE state temporarily. The task is executed immediately before the cursor and then it gets paused again.


ATTENTION

When executing Come-pause, be sure to specify the cursor position at a position where the target task is passing during execution.

If the cursor is set not at the position described above but at an inappropriate position, the system does not operate normally, and, in some cases, the command process may never terminate. (Because the debugger has no means to judge whether the cursor position is correct or not, and it merely continues waiting until the target task executes the cursor position.)


If this happens, click the Stop button in the following dialog which appears during execution of Come-pause to stop the command processing.

7.17.3.3 Turn Pause of Certain Task Off



1. Click the ID field or (name) field in the task pause display area of the task line to be released from the PAUSE state. After the target task is selected, the task ID number is displayed in the status bar. The Unpause button is enabled (if the task is paused).
2. Click the Unpause button. The selected task is released from the PAUSE state.

7.17.3.4 Display Program Contents of Certain Task in Task Source Display Area




Click the ID field of (name) field in the task pause display area of the task line to be displayed. If the target task is paused, the task Pause position (context PC position) is displayed. If the target task is in a state other than Pause, the task start address is displayed. You can also use the View button and View menu to display any position.

7.18 Task Trace Window

The Task Trace window measures the task execution history of a program using the real time OS and display it graphically.

This window is available even when a target program using an OS other than our real time OS (MRxx) is downloaded.



The content of each item is as follows.

Items	Contents
ID	Indicates a task ID number.
(name)	Indicates an interrupt routine name, task name, idle processing (display "idle"), and unknown name(displayed "unknown").

When moving the mouse to the information displayed in the window, the pop up window as below is opened, showing the detailed information.

```
ID=D' 7 (_task7)
begin:00°00'00:722.055
end:00°00'00:753.305
(end-begin):00°00'00:031.250
```

The following information is displayed in the status bar.

- Time value at the start marker position
- Time value at the end marker position
- Time interval between the start marker and the end marker
- Time value at the indicator position
- Display scale
- Time width at grid line interval
- Measurement (trace) range

The grid lines are displayed using the start marker as the radix point.

The scale is displayed, using the time at which the start marker is positioned as 0, with the left (forward in time) set to "minus" and the right (backward in time) set to "plus".

The grid lines allow you to roughly understand the interrupt occurrence cycle and process time.

The interval time width of the displayed grid lines appears in the "Grid" area of the status bar.

The time value in the Task Trace window means the execution elapsed time using the program execution start time as 0 in all the cases.

On the contrary, the numeric value above the grid lines (scale) in the Task Trace window is a relative value using the start marker as 0 (the grid interval is specified in the Value dialog). It has nothing to do with the time value. (This is provided so that you can see the window easily.)

7.18.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu		Function
Start Marker		Move the start marker in the display area.
End Marker		Move the end marker in the display area.
Indicator		Move the indicator in the display area.
Adjust		Adjust range of start and end marker to full width of display area Adjust.
Expand		Increase scale factor of display.
Reduce		Decrease scale factor of display.
Trace Stop		Stop measuring.
Trace Restart		Restarts measuring.
Trace Range	After	Set measurement range condition to After.
	Break	Set measurement range condition to Break.
Value...		Set value.
Color...		Change display color.
RTOS...		Set target RTOS information.
Toolbar display		Displays the toolbar.
Customize toolbar...		Opens the toolbar customize dialog box.
Allow Docking		Allows the window docking.
Hide		Hides the window.

7.18.2 Refer the Execution History of Task(Taskxxx Window)

You can reference the task execution history in the Task Trace window.

You can reference the execution history statistical processing result in the Task Analyze window.

These windows are also available for a target program using an OS other than our real time OS (MRxx).

7.18.2.1 Prepare the Measurement

To measure the task execution history of the program using the real time OS, you must select the trace range in the Task Trace window and then execute the target program.


7.18.2.1.1 Set the Information of Realtime OS.

To use the Task Trace window, you must set the following information concerning the real time OS (the target real time OS) which are used by the downloaded program.

- Label name (address value) of the execution task ID storage area and its size
- Task start address expression

Open the Task Trace window. Select Menu - [View] -> [RTOS] -> [Task Trace].

When you select this menu at first time after starting PDxx, the RTOS Information dialog is opened before the Task Trace window is opened.



- When using our real time OS (MRxx)
 1. Click the "default" button. The MRxx information is set.
 2. Click the OK button. The Task Trace window is opened.
- When using a real time OS other than MRxx
 1. Specify the label (address is also available) of the execution task ID storage area in the PID Address field ; specify the size of the execution task ID storage area in the Size list box. If this information is not set correctly, you cannot use the Task Trace window.
 2. Specify the task start address expression in the Task Entry field. Describe the expression in the format in accordance with the description rules. Use a macro variable [% TaskID] in the address where the task ID number is supposed to assign. If this information is not set correctly, the task name is not displayed in the Task Trace window.
 3. Click the OK button. The Task Trace window is opened.

On debugger for 740, simply by clicking the default button, the OSEK OS information is set.

Once the real time OS information is set in this dialog, the information becomes effective from the next time.

To change the setting data, select [RTOS...] from popup menu by right-clicking on the window. The RTOS Information dialog is re-opened.

ATTENTION

When specifying WORD in the access size when performing PID setting in the RTOS Information dialog, you must observe the following limits. (If these conditions are not met, the system does not operate normally.)

- The PID information storage area is allocated to an even address.
- The PID information storage area is allocated to an area accessed with 16-bit bus width.

7.18.2.1.2. Select the Trace Range

The real time trace function is used for task execution history measurement.

Click the After button (or select [After] from popup menu by right-clicking on the window) or Break button (or or select [Break] from popup menu) in the Task Trace window.

After	Records a task execution history until the trace memory is filled with recorded data.
Break	Records a task execution history (as much as trace memory available) until before the target program stops.

Only an specific cycle required to know the task execution history is recorded in the trace memory.

ATTENTION

A trace point set in the Trace Point Setting dialog is disabled.

7.18.2.1.3. Start the Target Program

Execute the target program. Record the information required to know the task execution history in the trace memory.

When you select After for the trace range, the execution history is displayed in the Task Trace window immediately after the trace memory is filled or immediately after the target program stops.

When you select Break for the trace range, the execution history is displayed in the Task Trace window immediately after the target program stops.


You can stop task execution history measurement.

To do this, click the Stop button in the Task Trace window. (Or, select [Trace Stop] from popup menu by right-clicking on the window.)

To restart task execution history measurement, click the Restart button in the Task Trace window. (Or, select [Trace Restart] from popup menu by right-clicking on the window.)

7.18.2.2 Refer the Execution History of Task

You can reference task trace transition in the Task Trace window.



By moving the mouse to the information displayed in the window, a window of the following example is opened, showing the detailed information.

```
ID=D' 7 (_task7)
begin:00''00'00:722.055
end:00''00'00:753.305
(end-begin):00''00'00:031.250
```

7.18.2.2.1 Change the display magnification

Click the Expand button or Reduce button in the tool bar. (Or, select [Expand] or [Reduce] from popup menu by right-clicking on the window.)


The display is expanded or reduced using the left corner of the graph area as the radix point. By default, the display is expanded or reduced with display scale of 1.5.

The display scale appears in the "Scale:*" field in the status bar.

The default expansion/reduction scale is 1.5. To change the scale, select [Value ...] from popup menu by right-clicking on the window. The Value dialog is opened. Specify the display expansion/reduction scale.

7.18.2.2.2. Change the grid line display interval

Select [Value ...] from popup menu by right-clicking on the window. The Value dialog is opened. Specify the time interval in the display.




7.18.2.2.3. Change the task display order

Select [Color ...] from popup menu by right-clicking on the window. The Color dialog is opened. Click the button corresponding to the desired item. The Color Setting dialog is opened. Change the display color in the dialog.

7.18.2.3 Measure the Execution Time of Task

By changing the start marker position and end marker position in the Task Trace window, you can measure the execution time between the markers.



Drag the start marker position and end marker position.
The time interval between the markers is displayed in the status bar.

Note

Definition of time value in the Task Trace window

The time value in the Task Trace window indicates the execution elapsed time which sets the program execution start point to 0 in all the cases.

On the contrary, a numeric value above the grid line (scale) in the Task Trace window is a relative value which sets the start marker to 0 (the grid interval is specified in the Value dialog), which has nothing to do with the time value. (It is provided so that you can see the window easily.)

7.18.2.3.1. Move the Marker

Each marker can be moved by dragging. When moving the mouse on the marker, the cursor shape changes. Then, start dragging.

The start marker moves into the window (left portion) by clicking the Start Marker button in the tool bar. (Or, select [Start Marker] from popup menu by right-clicking on the window.)

The end marker moves into the window (right portion) by clicking the End Marker button. (Or, select [End Marker] from popup menu.)

The indicator moves into the window (center) by clicking the "Indicator" button. (Or, select [Indicator] from popup menu.)

Note that each marker can move only to the point where an event is established.

7.19 Task Analyze Window

The Task Analyze window displays the result of the measurement data statistically analyzed within the range specified by the start marker and the end marker in the Task Trace window.

The Task Analyze window displays the CPU occupation state.

The Task Analyze window functions together with the Task Trace window.

This window is available even when a target program using an OS other than our real time OS (MRxx) is downloaded.

The CPU occupation state display mode is used to display the CPU occupation time and ratio by task.

This mode shows the statistical result within the range specified by the start marker and end marker in the Task Trace window.

ID	(name)	Num	Max Run Time	Min Run Time	Avg Run Time	Total Run Time	Ratio%				
0	(-----)	1	00'00'00:005.195	00'00'00:005.195	00'00'00:005.195	00'00'00:005.195	0.33				
1	{_main}	115	00'00'00:007.305	00'00'00:000.767	00'00'00:001.541	00'00'00:177.287	11.30	█			
2	{_task002}	12	00'00'00:012.067	00'00'00:006.915	00'00'00:011.552	00'00'00:138.630	8.84	█			
3	{_task003}	12	00'00'00:012.597	00'00'00:006.892	00'00'00:012.111	00'00'00:145.332	9.27	█			
4	{_task004}	12	00'00'00:012.170	00'00'00:006.505	00'00'00:011.604	00'00'00:139.252	8.88	█			
5	{_task005}	12	00'00'00:012.277	00'00'00:006.577	00'00'00:011.795	00'00'00:141.540	9.02	█			
6	{_task006}	11	00'00'00:013.435	00'00'00:006.490	00'00'00:012.353	00'00'00:135.885	8.66	█			
7	{_task007}	11	00'00'00:013.020	00'00'00:006.790	00'00'00:012.431	00'00'00:136.745	8.72	█			
8	{_task008}	11	00'00'00:014.080	00'00'00:008.055	00'00'00:013.232	00'00'00:145.552	9.28	█			
9	{_task009}	11	00'00'00:013.642	00'00'00:007.277	00'00'00:012.663	00'00'00:139.295	8.88	█			
10	{_task010}	11	00'00'00:013.710	00'00'00:008.070	00'00'00:012.795	00'00'00:140.752	8.97	█			
11	{_task011}	11	00'00'00:011.892	00'00'00:006.290	00'00'00:011.193	00'00'00:123.132	7.85	█			
???	Unknown	0	00'00'00:000.000	00'00'00:000.000	00'00'00:000.000	00'00'00:000.000	0.00				

By clicking the maximum execution time/minimum execution time display area of each line, you can search process history of the task for the clicked line at the maximum/minimum execution time.

The search result is pointed by the indicator which moves to the target position in the Task Trace window.

7.19.1 Extended Menus

This window has the following popup menus that can be brought up by right-clicking in the window.

Menu	Function
Allow Docking	Allows the window docking.
Hide	Hides the window.

7.19.2 Analyze the Execution History of Task

You can reference the execution history statistical processing in the Task Analyze window. This window shows the CPU occupation time and ratio by task.

The Task Analyze window functions together with the Task Trace window. If the Task Trace window is not open, or the Task Trace window does not show any data, the Task Analyze window will not function.

ID	(name)	Num	Max Run Time	Min Run Time	Avg Run Time	Total Run Time	Ratio%	0	25	50	75	100
0	(-----)	1	00"00'00:005.195	00"00'00:005.195	00"00'00:005.195	00"00'00:005.195	0.33					
1	{ main}	115	00"00'00:007.305	00"00'00:000.767	00"00'00:001.541	00"00'00:177.287	11.30					
2	{ task002}	12	00"00'00:012.067	00"00'00:006.915	00"00'00:011.552	00"00'00:138.630	8.84					
3	{ task003}	12	00"00'00:012.597	00"00'00:006.892	00"00'00:012.111	00"00'00:145.332	9.27					
4	{ task004}	12	00"00'00:012.170	00"00'00:006.505	00"00'00:011.604	00"00'00:139.252	8.88					
5	{ task005}	12	00"00'00:012.277	00"00'00:006.577	00"00'00:011.795	00"00'00:141.540	9.02					
6	{ task006}	11	00"00'00:013.435	00"00'00:006.490	00"00'00:012.353	00"00'00:135.885	8.66					
7	{ task007}	11	00"00'00:013.020	00"00'00:006.790	00"00'00:012.431	00"00'00:136.745	8.72					
8	{ task008}	11	00"00'00:014.080	00"00'00:008.055	00"00'00:013.232	00"00'00:145.552	9.28					
9	{ task009}	11	00"00'00:013.642	00"00'00:007.277	00"00'00:012.663	00"00'00:139.295	8.88					
10	{ task010}	11	00"00'00:013.710	00"00'00:008.070	00"00'00:012.795	00"00'00:140.752	8.97					
11	{ task011}	11	00"00'00:011.892	00"00'00:006.290	00"00'00:011.193	00"00'00:123.132	7.85					
???	Unknown	0	00"00'00:000.000	00"00'00:000.000	00"00'00:000.000	00"00'00:000.000	0.00					

The displayed data is the statistical results of the range specified by the start marker and the end marker in the Task Trace window.

By clicking the maximum ready time/minimum ready time display field of each line, you can search the processing history at the maximum ready time/minimum ready time of the task corresponding to the clicked line.

The search result is pointed by the indicator in the Task Trace window after the indicator moves to the destination position.

8. Table of Script Commands

The following script commands are prepared.

The commands with yellow color displaying can be executed at run time.

The command to which "*" adheres behind is not supported according to the product.

8.1 Table of Script Commands (classified by function)

8.1.1 Execution Commands

Command Name	Short Name	Contents
Go	G	Program execution with breakpoints
GoFree	GF	Free run program execution
GoProgramBreak*	GPB	Run target program with software break point
GoBreakAt*	GBA	Run target program with software break point
Stop	-	Stops program execution
Status	-	Checks the operating status of the MCU
Step	S	Halts for user input until the specified time has elapsed
StepInstruction	SI	Step execution of instructions
OverStep	O	Overstep execution of source lines
OverStepInstruaction	OI	Overstep execution of instructions
Return	RET	Executes a source line return
ReturnInstruction	RETI	Executes an instruction return
Reset	-	Resets the target MCU
Time	-	Sets the run time display and checks the current setting

8.1.2 File Operation Commands

Command Name	Short Name	Contents
Load	L	Downloads the target program
LoadHex	LH	Downloads an Intel HEX-format file
LoadMot*	LM	Downloads a Motorola S-format file
LoadSymbol	LS	Loads source line/ASM symbol information
LoadIeee*	LI	Downloads IEEE-695 absolute-format files
Reload	-	Re-downloads the target program
UploadHex	UH	Outputs data to an Intel HEX-format file
UploadMot*	UM	Outputs data to a Motorola S-format file

8.1.3 Register Operation Commands

Command Name	Short Name	Contents
Register	R	Checks and sets a register value

8.1.4 Memory Operation Commands

Command Name	Short Name	Contents
DumpByte	DB	Displays the contents of memory (in 1-byte units)
DumpWord*	DW	Displays the contents of memory (in 2-byte units)
DumpLword*	DL	Displays the contents of memory (in 4-byte units)
SetMemoryByte	MB	Checks and changes memory contents (in 1-byte units)
SetMemoryWord*	MW	Checks and changes memory contents (in 2-byte units)
SetMemoryLword*	ML	Checks and changes memory contents (in 4-byte units)
FillByte	FB	Fills a memory block with the specified data (in 1-byte units)
FillWord*	FW	Fills a memory block with the specified data (in 2-byte units)
FillLword*	FL	Fills a memory block with the specified data (in 4-byte units)
Move	-	Moves memory blocks
MoveWord*	MOVEW	Moves memory blocks(in 2-byte units)

8.1.5 Assemble/Disassemble Commands

Command Name	Short Name	Contents
Assemble	A	Line-by-line assembly
DisAssemble	DA	Disassembles memory contents line by line
Module	MOD	Displays modules names
Scope	-	Sets and checks the effective local symbol scope
Section	SEC	Checks section information
Bit*	-	Checks and sets bit symbols
Symbol	SYM	Checks assembler symbols
Label	-	Checks assembler labels
Express	EXP	Displays an assembler expression

8.1.6 Software Break Setting Commands

Command Name	Short Name	Contents
SoftwareBreak	SB	Sets and checks software breaks
SoftwareBreakClear	SBC	Clears software breaks
SoftwareBreakClearAll	SBCA	Clears all software breaks
SoftwareBreakDisable	SBD	Disables software breakpoints
SoftwareBreakDisableAll	SBDA	Disables all software breaks
SoftwareBreakEnable	SBE	Enables software breakpoints
SoftwareBreakEnableAll	SBEA	Enables all software breaks
BreakAt	-	Sets a software breakpoint by specifying a line No.
BreakIn	-	Sets a software breakpoint by specifying a function

8.1.7 Hardware Break Setting Commands

Command Name	Short Name	Contents
HardwareBreak	HB	Sets and checks a hardware break
Protect	PT	Sets and checks protect breaks
BreakMode	BM	Sets and checks hardware break mode

8.1.8 Real-time Trace Commands

Command Name	Short Name	Contents
TracePoint	TP	Sets and checks a trace points
TraceData*	TD	Realtime trace data display
TraceList*	TL	Displays disassembled realtime trace data

8.1.9 Coverage Measurement Commands

Command Name	Short Name	Contents
Coverage	CV	Specifies and displays coverage measurement

8.1.10 Script/Log File Commands

Command Name	Short Name	Contents
Script	-	Opens and executes a script file
Exit	-	Exits the script file
Wait	-	Waits for an event to occur before command input
Pause	-	Waits for user input
Sleep	-	Halts for user input until the specified time has elapsed
Logon	-	Outputs the screen display to a log file
Logoff	-	Stops the output of the screen display to a log file
Exec	-	Executes external application

8.1.11 Program Display Commands

Command Name	Short Name	Contents
Func	-	Checks function names and displays the contents of functions
Up*	-	Displays the calling function
Down*	-	Displays a called function
Where*	-	Displays a function call status
Path	-	Sets and checks the search path
AddPath	-	Adds the search path
File	-	Checks a filename and displays the contents of that file

8.1.12 Map Commands

Command Name	Short Name	Contents
Map*	-	Checks and sets mapping data

8.1.13 Clock Command

Command Name	Short Name	Contents
Clock	CLK	Checks and changes the clock

8.1.14 WatchDog Timer Commands

Command Name	Short Name	Contents
WatchDogTimer*	WDT	Sets and checks the usage condition of the watchdog timer

8.1.15 C Language Debugging Commands

Command Name	Short Name	Contents
Print	-	Check value of specified C variable expression
Set	-	Set specified data in specified C variable expression

8.1.16 Real-time OS Command

Command Name	Short Name	Contents
MR*	-	Displays status of realtime OS (MRxx)

8.1.17 Utility Commands

Command Name	Short Name	Contents
Radix	-	Sets and checks the radix for numerical input
Alias	-	Specifies and checks command alias definitions
UnAlias	-	Cancel the alias defined for a command
UnAliasAll	-	Cancel all aliases defined for commands
Version	VER	Displays the version No.
Date	-	Displays the date
Echo	-	Displays messages
CD	-	Window open

8.2 Table of Script Commands (alphabetical order)

Command Name	Short Name	Contents
AddPath	-	Adds the search path
Alias	-	Specifies and checks command alias definitions
Assemble	A	Line-by-line assembly
Bit*	-	Checks and sets bit symbols
BreakAt	-	Sets a software breakpoint by specifying a line No.
BreakIn	-	Sets a software breakpoint by specifying a function
BreakMode	BM	Sets and checks hardware break mode
CD	-	Specifies and checks the current directory
Clock	CLK	Checks and changes the clock
Coverage	CV	Specifies and displays coverage measurement
Date	-	Displays the date
DisAssemble	DA	Disassembles memory contents line by line
Down*	-	Displays a called function
DumpByte	DB	Displays the contents of memory (in 1-byte units)
DumpLword*	DL	Displays the contents of memory (in 4-byte units)
DumpWord*	DW	Displays the contents of memory (in 2-byte units)
Echo	-	Displays messages
Exec	-	Executes external application
Exit	-	Exits the script file
Express	EXP	Displays an assembler expression
File	-	Checks a filename and displays the contents of that file
FillByte	FB	Fills a memory block with the specified data (in 1-byte units)
FillLword*	FL	Fills a memory block with the specified data (in 4-byte units)
FillWord*	FW	Fills a memory block with the specified data (in 2-byte units)
Func	-	Checks function names and displays the contents of functions
Go	G	Program execution with breakpoints
GoBreakAt*	GBA	Run target program with software break point
GoFree	GF	Free run program execution
GoProgramBreak*	GPB	Run target program with software break point
HardwareBreak	HB	Sets and checks a hardware break
Label	-	Checks assembler labels
Load	L	Downloads the target program
LoadHex	LH	Downloads an Intel HEX-format file
LoadIeee*	LI	Downloads IEEE-695 absolute-format files
LoadMot*	LM	Downloads a Motorola S-format file
LoadSymbol	LS	Loads source line/ASM symbol information
Logoff	-	Stops the output of the screen display to a log file
Logon	-	Outputs the screen display to a log file
Map*	-	Checks and sets mapping data
Module	MOD	Displays modules names
Move	-	Moves memory blocks
MoveWord*	MOVEW	Moves memory blocks(in 2-byte units)
MR*	-	Displays status of realtime OS (MRxx)
OverStep	O	Overstep execution of source lines
OverStepInstruaction	OI	Overstep execution of instructions

Path	-	Sets and checks the search path
Pause	-	Waits for user input
Print	-	Check value of specified C variable expression.
Protect	PT	Sets and checks protect breaks
Radix	-	Sets and checks the radix for numerical input
Register	R	Checks and sets a register value
Reload	-	Re-downloads the target program
Reset	-	Resets the target MCU
Return	RET	Executes a source line return
ReturnInstruction	RETI	Executes an instruction return
Scope	-	Sets and checks the effective local symbol scope
Script	-	Opens and executes a script file
Section	SEC	Checks section information
Set	-	Set specified data in specified C variable expression
SetMemoryByte	MB	Checks and changes memory contents (in 1-byte units)
SetMemoryLword*	ML	Checks and changes memory contents (in 4-byte units)
SetMemoryWord*	MW	Checks and changes memory contents (in 2-byte units)
Sleep	-	Halts for user input until the specified time has elapsed
SoftwareBreak	SB	Sets and checks software breaks
SoftwareBreakClear	SBC	Clears software breaks
SoftwareBreakClearAll	SBCA	Clears software breaks
SoftwareBreakDisable	SBD	Disables software breakpoints
SoftwareBreakDisableAll	SBDA	Disables all software breaks
SoftwareBreakEnable	SBE	Enables software breakpoints
SoftwareBreakEnableAll	SBEA	Enables all software breaks
Status	-	Checks the operating status of the MCU
Step	S	Step execution of source line
StepInstruction	SI	Step execution of instructions
Stop	-	Stops program execution
Symbol	SYM	Checks assembler symbols
Time	-	Sets the run time display and checks the current setting
TraceData*	TD	Realtime trace data display
TraceList*	TL	Displays disassembled realtime trace data
TracePoint	TP	Sets and checks a trace points
UnAlias	-	Cancels the alias defined for a command
UnAliasAll	-	Cancels all aliases defined for commands
Up*	-	Displays the calling function
UploadHex	UH	Outputs data to an Intel HEX-format file
UploadMot*	UM	Outputs data to a Motorola S-format file
Version	VER	Displays the version No.
Wait	-	Waits for an event to occur before command input
WatchDogTimer*	WDT	Sets and checks the usage condition of the watchdog timer
Where*	-	Displays a function call status

9. Writing Script Files

This debugger allows you to run script files in a Script Window. The script file contains the controls necessary for automatically executing the script commands.

9.1 Structural Elements of a Script File

You can include the following in script files:

- Script commands
- Assign statements
- Conditional statements (if, else, endi)
Program execution branches to the statement(s) to be executed according to the result of the conditional expression.
- Loop statements (while, endw)
A block of one or more statements is repeatedly executed according to the expression.
- break statement
Exits from the innermost loop.
- Comment statements
You can include comments in a script file. The comment statements are ignored when the script commands are executed.

Specify only one statement on each line of the script file. You cannot specify more than one statement on a line, or write statements that span two or more lines.

Notes

- You cannot include comments on the same lines as script commands.
- You can nest script files up to five levels.
- You can nest if statements and while statements up to 32 levels.
- If statements must be paired with endi statements, and while statements with endw statements in each script file.
- Expressions included in script files are evaluated as unsigned types. Therefore, operation cannot be guaranteed if you use negative values for comparison in if or while statements.
- You can specify up to 4096 characters per line. An error occurs if a line exceeds this number of characters.
- When a script file containing illegal commands is automatically executed (when you select [Option] -> [Script]-> [Run] from the Script Window menu after opening a script file, or click the button in the Script Window), execution of the script file continues even after the error is detected, except when the script line itself cannot be read. If an error is detected and the script file continues to be executed, operation after detection of the error cannot be guaranteed. Reliability cannot therefore be placed on the results of execution after an error has been detected.

9.1.1 Script Command

You can use the same script commands that you enter in the Script Window. You can also call script files from within other script files (nesting up to 10 levels).

9.1.2 Assign Statement

Assign statement s define and initialize macro variables and assign values. The following shows the format to be used.

```
%macro-variable = expression
```

- You can use alphanumerics and the underscore (`_`) in macro variable names. However , you cannot use a numeric to start a macro variable name.
- You can specify any expression of which the value is an integer between 0h and FFFFFFFFh to be assigned in a macro variable. If you specify a negative number, it is processed as twos complement.
- You can use macro variables within the expression.
- Always precede macro variables with the "%" sign.

9.1.3 Conditional Statement

In a conditional statement, different statements are executed according to whether the condition is true or false. The following shows the format to be used.

```
if ( expression )  
    statement 1  
else  
    statement 2  
endi
```

- If the expression is true (other than 0), statement 1 is executed. If false, (0), statement 2 is executed.
- You can omit the else statement. If omitted and the expression is false, execution jumps to the line after the endi statement.
- if statements can be nested (up to 32 levels).

9.1.4 Loop Statement(while,endw) and Break Statement

In loop statements, execution of a group of statements is repeated while the expression is true. The following shows the format to be used.

```
while ( expression )
    statement
endw
```

- If the expression is true, the group of statements is repeated. If false, the loop is exited (and the statement following the endw statement is executed).
- You can nest while statements up to 32 levels.
- Use the break statement to forcibly exit a while loop. If while statements are nested, break exits from the inner most loop.

9.1.5 Comment statements

You can include comments in a script file. Use the following format.

```
;character string
```

- Write the statement after a semicolon (;). You can include only spaces and tabs in front of the semicolon
- Lines with comment statements are ignored when the script file is executed.

9.2 Writing Expressions

This debugger allows you to use expressions for specifying addresses, data, and number of passes, etc. The following shows example commands using expressions.

```
>DumpByte TABLE1
>DumpByte TABLE1+20
```

You can use the following elements in expressions:

- Constants
- Symbols and labels
- Macro variables
- Register variables
- Memory variables
- Line Nos.
- Character constants
- Operators

9.2.1 Constants

You can use binary, octal, decimal, or hexadecimals. The prefix or suffix symbol attached to the numerical value indicates which radix is used.

The debugger for M32C and M16C/R8C and 740

	Hexadecimal	Decimal	Octal	Binary *
Prefix	0x,0X	@	None	%
Suffix	h,H	None	o,O	b,B
Examples	0xAB24 AB24h	@1234	1234o	%10010 10010b

*You can only specify % when the predetermined radix is hexadecimal.

- If you are inputting a radix that matches the predetermined radix, you can omit the symbol that indicates the radix (excluding binary).
- Use the RADIX command to set the predetermined value of a radix. However, in the cases shown below, the radix is fixed regardless of what you specify in a RADIX command.

Type	Radix
Address	Hex
Line No. No. of executions No. of passes	Dec

9.2.2 Symbols and labels

You can include symbols and labels defined in your target program, or symbols and labels defined using the Assemble command.

- You can include alphanumerics, the underscore (`_`), period (`.`), and question mark (`?`) in symbols and labels. However, do not start with a numeric.
- Symbols and labels can consist of up to 255 characters.
- Uppercase and lowercase letters are unique.

Product Name	Notes
The debugger for M32R, The debugger for M32C, The debugger for M16C/R8C,	<ul style="list-style-type: none">• You cannot include the assembler structured instructions, pseudo instructions, macro instructions, operation code, or reserved words (<code>.SECTION</code>, <code>.BYTE</code>, <code>switch</code>, <code>if</code>, etc.).• You cannot use strings that start with two periods (<code>..</code>) for symbols or labels.
The debugger for 740	<ul style="list-style-type: none">• You cannot use the register name.(<code>A,X,Y,S,PC,PS,P</code>)• You cannot include the assembler structured instructions, pseudo instructions, macro instructions, operation code, or reserved words (<code>.SECTION</code>, <code>.BYTE</code>, <code>switch</code>, <code>if</code>, etc.).• You cannot use strings that start with two periods (<code>..</code>) for symbols or labels. <code>.D0</code> to <code>.D65535</code>, <code>.F0</code> to <code>.F65535</code>, <code>.I0</code> to <code>.I56635</code>, <code>.S0</code> to <code>.S65535</code>, <code>..0</code> to <code>..65535</code>, <code>??0</code> to <code>??65535</code>

9.2.2.1 Local label symbol and scope

This debugger supports both global label symbols, which can be referenced from the whole program area, and local label symbols, which can only be referenced within the file in which they are declared. The effective range of local label symbols is known as the scope, which is measured in units of object files. The scope is switched in this debugger in the following circumstances:

- When a command is entered
The object file that includes the address indicated by the program counter becomes the current scope. When the SCOPE command is used to set the scope, the specified scope is the active scope.
- During command execution
The current scope automatically switches depending on the program address being handled by the command.

9.2.2.2 Priority levels of labels and symbols

The conversion of values to labels or symbols, and vice versa, is subject to the following levels of priority:

- Conversion of address values
 1. Local labels
 2. Global labels
 3. Local symbols
 4. Global symbols
 5. Local labels outside scope
 6. Local symbols outside scope

- Conversion of data values
 1. Local symbols
 2. Global symbols
 3. Local labels
 4. Global labels
 5. Local symbols outside scope
 6. Local labels outside scope

- Conversion of bit values
 1. Local bit symbols
 2. Global bit symbols
 3. Local bit symbols outside scope

9.2.3 Macro Variables

Macro variables are defined by assign statements in the script file. See Section "9.1.2 Assign Statement" in the Reference part for details. Precede variables with '%' for use as macro variables.

- You can specify alphanumerics and/or the underbar (`_`) in the variable name following the percent sign (%). However, do not start the names with a numeric.
- You cannot use the names of registers as variable names.
- Uppercase and lowercase letters are differentiated in variable names.
- You can define a maximum of 32 macro variables. Once defined, a macro variable remains valid until you quit the debugger.

Macro variables are useful for specifying the number of iterations of the while statement.

9.2.4 Register variables

Register variables are used for using the values of registers in an expression. Precede the name of the register with '%' to use it as a register variable. Use the following format. (The debugger for 740 can use '_' instead of '%'.)

Product Name	Register name
The debugger for M32C	PC, USP, ISP, INTB, FLB, SVF, SVP, VCT, DMD0,DMD1, DCT0, DCT1, DRC0, DRC1, DMA0,DMA1, DCA0, DCA1, DRA0, DRA1, 0R0, 0R1, 0R2, 0R3, 0A0, 0A1, 0FB, 0SB <- Bank 0 Register 1R0, 1R1, 1R2, 1R3, 1A0, 1A1, 1FB, 1SB <- Bank 1 Register
The debugger for M16C/R8C	PC, USP, ISP, SB, INTB, FLG 0R0, 0R1, 0R2, 0R3, 0A0, 0A1, 0FB <- Bank 0 Register 1R0, 1R1, 1R2, 1R3, 1A0, 1A1, 1FB <- Bank 1 Register
The debugger for 740	PC, A, X, Y, S, PS

Uppercase and lowercase letters are not unique in register names. You can specify either.

9.2.5 Memory variables

Use memory variables to use memory values in expressions. The format is as follows:

[Address].data-size

- You can specify expressions in addresses (you can also specify memory variables).
- The data size is specified as shown in the following table. (The debugger for 740 doesn't support four byte length.)

data Length	Debugger	Specification
1 Byte	All	B or b
2 Bytes	The debugger for M32R	H or h
	Other	W or w
4 bytes	The debugger for M32R	W or w
	The debugger for M32R, M16C/R8C	L or l

Example: Referencing the contents of memory at address 8000h in 2 bytes
[0x8000].W

- The default data size is word, if not specified.

9.2.6 Line Nos.

These are source file line Nos. The format for line Nos. is as follows:

```
#line_no
#line_no."source file name"
```

- Specify line Nos. in decimal.
- You can only specify line Nos. in which software breaks can be set. You cannot specify lines in which no assembler instructions have been generated, including comment lines and blank lines.
- If you omit the name of the source file, the line Nos. apply to the source file displayed in active Editor(Source) Window.
- Include the file attribute in the name of the source file.
- Do not include any spaces between the line No. and name of the source file.

9.2.7 Character constants

The specified character or character string is converted into ASCII code and processed as a constant.

- Enclose characters in single quote marks.
- Enclose character strings in double quote marks.
- The character string must consist of one or two characters (16 bits max.). If more than two characters are specified, the last two characters of the string are processed. For example, "ABCD" would be processed as "CD", or value 4344h.

9.2.8 Operators

The table below lists the operators that you can use in expressions.

- The priority of operators is indicated by the level, level 1 being the highest and level 8 the lowest. If two or more operators have the same level of priority, they are evaluated in order from the left of the expression.

Operator	Function	Priority level
()	Brackets	level 1
+, -, ~	Monadic positive, monadic negative, monadic logical NOT	level 2
*, /	Dyadic multiply, dyadic divide	level 3
+, -	Dyadic add, dyadic subtract	level 4
>>, <<	Right shift, left shift	level 5
&	Dyadic logical AND	level 6
, ^	Dyadic logical OR, dyadic exclusive OR	level 7
<, <=, >, >=, ==, !=	Dyadic comparison	level 8

10. C/C++ Expressions

10.1 Writing C/C++ Expressions

You can use C/C++ expressions consisting of the tokens shown below for registering C watchpoints and for specifying the values to be assigned to C watchpoints.

Token	Example
Immediate values	10, 0x0a, 012, 1.12, 1.0E+3
Scope	::name, classname::member
Mathematical operators	+, -, *, /
Pointers	*, **, ...
Reference	&
Sign inversion	-
Member reference using dot operator	Object.Member
Member reference using arrow	Pointer->Member, this->Member
Pointers to Members	Object.*var, Pointer->*var
Parentheses	(,)
Arrays	Array[2], DArray[2] [3], ...
Casting to basic types	(int), (char*), (unsigned long *), ...
Casting to typedef types	(DWORD), (ENUM), ...
Variable names and function names	var, i, j, func, ...
Character constants	'A', 'b', ...
Character string literals	"abcdef", "I am a boy.", ...

10.1.1 Immediate Values

You can use hexadecimals, decimals, octals as immediate values. Values starting with 0x are processed as hexadecimals, those with 0 as octals, and those without either prefix as decimals. Floating-point numbers can also be used to assign values to variables.

Notes

- You cannot register only immediate values as C watchpoints.
- The immediate value is effective only when it is used in C/C++ language expressions that specify C/C++ watchpoints or when it is used to specify the value to be assigned to those expressions. When using floating-point numbers, operation cannot be performed on an expression like 1.0+2.0.

10.1.2 Scope Resolution

The scope resolution operator `::` is available as following.

Global scope: `::variable name`

`::x`, `::val`

Class scope: `class name::member name`, `class name::class name::member name`, e.g.

`T::member`, `A::B::member`

10.1.3 Mathematical Operators

You can use the addition (+), subtraction (-), multiplication (*), and division (/) mathematical operators. The following shows the order of priority in which they are evaluated.

`(*)`, `(/)`, `(+)`, `(-)`

Notes

- There is no support currently for mathematical operators for floating point numbers.

10.1.4 Pointers

Pointers are indicated by the asterisk (*). You can use pointer to pointers **, and pointer to pointer to pointers ***, etc.

Examples: `"*variable_name"`, `"**variable_name"`, etc.

Notes

- Immediate values cannot be processed as pointers. That is, you cannot specify `*0xE000`, for example.

10.1.5 Reference

References are indicated by the ampersand (&). You can only specify `&variable_name`.

10.1.6 Sign Inversion

Sign inversion is indicated by the minus sign (-). You can only specify "-immediate_value" or "-variable_name". No sign inversion is performed if you specify 2 (or any even number of) minus signs.

Notes

- There is no support currently for sign inversion of floating point numbers.

10.1.7 Member Reference Using Dot Operator

You can only use "variable_name.member_name" for checking the members of structures and unions using the dot operator.

Example:

```
class T {
public:
int member1;
char member2;
};
class T t_cls;
class T *pt_cls = &t_cls;
```

In this case, t_cls.member1, (*pt_cls).member2 correctly checks the members.

10.1.8 Member Reference Using Arrow

You can only use "variable_name->member_name" for checking the members of structures and unions using the arrow.

Example:

```
class T {
public:
int member1;
char member2;
};
class T t_cls;
class T *pt_cls = &t_cls;
```

In this case, (&t_cls)->member1, pt_cls->member2 correctly checks the members.

10.1.9 Pointers to Members

Pointers to members using the "." or "->" operator can be referred only in the forms of variable name .* member name or variable name ->* member name.

Example:

```
class T {
public:
    int member;
};
class T t_cls;
class T *pt_cls = &t_cls;

int T::*mp = &T::member;
```

In this case, t_cls.*mp and tp_cls->*mp can correctly reference the variable of pointer-to-member type.

Note

- Note that the expression *mp cannot be considered as the variable of pointer-to-member type.

10.1.10 Parentheses

Use the '(' and ')' to specify priority of calculation within an expression.

10.1.11 Arrays

You can use the '[' and ']' to specify the elements of an array. You can code arrays as follows: "variable_name [(element_No or variable)] ", "variable_name [(element_No or variable)] [(element_No or variable)] ", etc.

10.1.12 Casting to Basic Types

You can cast to C basic types char, short, int, and long, and cast to the pointer types to these basic types. When casting to a pointer type, you can also use pointers to pointers and pointers to pointers to pointers, etc.

Note that if signed or unsigned is not specified, the default values are as follows:

Basic type	Default
char	unsigned
short	signed
int	signed
long	signed

Notes

- Of the basic types of C++, casts to bool type, wchar_t type, and floating-point type (float or double) cannot be used.
- Casts to register variables cannot be used.

10.1.13 Casting to typedef Types

You can use casting to typedef types (types other than the C basic types) and the pointer types to them. When casting to a pointer type, you can also use pointers to pointers and pointers to pointers to pointers, etc.

Notes

- You cannot cast to struct or union types or the pointers to those types.

10.1.14 Variable Name

Variable names that begin with English alphabets as required under C/C++ conventions can be used.

The maximum number of characters for variable name is 255.

And 'this' pointer is available.

10.1.15 Function Name

Function names that begin with English alphabets as required under C conventions can be used.

In the case of C++, no function names can be used.

10.1.16 Character Constants

You can use characters enclosed in single quote marks (') as character constants. For example, 'A', 'b', etc. These character constants are converted to ASCII code and used as 1-byte immediate values.

Notes

- You cannot register character constants only as C watchpoints.
- Character constants are valid only when used in a C/C++ expression that specifies a C watchpoint, and when specifying a value to be assigned (character constants are processed in the same manner as immediate values).

10.1.17 Character String Literals

You can use character strings enclosed in double quote marks (") as character string literals. Examples are "abcde", "I am a boy.", etc.

Notes

- Character string literals can only be placed on the right side of an assignment operator in an expression. They can only be used when the left side of the assignment operator is a char array or a char pointer type. In all other cases, a syntax error results.

10.2 Display Format of C/C++ Expressions

C/C++ expressions in the data display areas of the C Watch Windows are displayed as their type name, C/C++ expression (variable name), and result of calculation (value), as shown below.

The following describes the display formats of the respective types.

10.2.1 Enumeration Types

- When the result (value) of calculation has been defined, its name is displayed.
`(DATE) date = Sunday(all Radices)_`
- If the result (value) of calculation has not been defined, it is displayed as follows:
`(DATE) date = 16 (when Radix is in initial state)`
`(DATE) date = 0x10 (when Radix is hex)`
`(DATE) date = 000000000010000B (when Radix is binary)`

10.2.2 Basic Types

- When the result of calculation is a basic type other than a char type or floating point type, it is displayed as follows:
`(unsigned int) i = 65280 (when Radix is in initial state)`
`(unsigned int) i = 0xFF00 (when Radix is hex)`
`(unsigned int) i = 1111111100000000B (when Radix is binary)`
- When the result of calculation is a char type, it is displayed as follows:
`(unsigned char) c = 'J' (when Radix is in initial state)`
`(unsigned char) c = 0x4A (when Radix is hex)`
`(unsigned char) c = 10100100B (when Radix is binary)`
- When the result of calculation is a floating point, it is displayed as follows:
`(double) d = 8.207880399131839E-304 (when Radix is in initial state)`
`(double) d = 0x10203045060708 (when Radix is hex)`
`(double) d = 000000010.....1000B (when Radix is binary)`
`(..... indicates abbreviation)`


10.2.3 Pointer Types

- When the result of calculation is a pointer type to other than a char* type, it is displayed in hexadecimal as follows:
`(unsigned int *) p = 0x1234 (all Radices)`
- When the result of calculation is a char* type, you can select the display format of the string or a character in the C Watch window's menu [Display String].
 - string types
`(unsigned char *) str = 0x1234 "Japan" (all Radices)`
 - character types
`(unsigned char *) str = 0x1234 (74 'J') (all Radices)`

! When the result of calculation is a char* type, it is displayed as follows:

```
(unsigned char *) str = 0x1234 "Jap(all Radices)
```

If the string contains a non-printing code prior to the code to show the end of the string (0), it is displayed up to the non-printing character and the closing quote mark is not displayed.



You can double-click on lines indicated by a '+' to see the members of that structure or union. The '+' changes to a '-' while the members are displayed. To return to the original display, double click the line, now indicated by the '-'.

10.2.4 Array Types

- When the result of calculation is an array type other than a char [] type, the starting address is displayed in hex as follows:


```
(signed int [10]) z = 0x1234(all Radices)_
```
- When the result of calculation is a char [] type, it is displayed as follows:

```
(unsigned char [10]) str = 0x1234 "Japan"(all Radices)
```

If the string contains a non-printing code prior to the code to show the end of the string (0), it is displayed up to the non-printing character and the closing quote mark is not displayed.

```
(unsigned char [10]) str = 0x1234 "Jap(all Radices)
```

Also if the string contains more than 80 characters, the closing quote mark is not displayed. When the C/C++ expression is an array type as same as pointer type, a '+' is display to the left of the type name. You can see the elements of the array by using this indicating. (for the details, refer "10.2.3 Pointer Types") When the number of the array elements is more than 100, the following dialog box open. Specify the number of the elements in the dialog box.



The elements from the index specified in "Start" to the index specified in "End" are displayed. If you specify the value more than the max index of the array, the value is regarded as max index of the array. When you click the "Cancel" button, the elements are not displayed.

10.2.5 Function Types

- When the result of calculation is a function type, the starting address is displayed in hex as follows:

```
(void()) main = 0xF000(all Radices)
```

10.2.6 Reference Types

- When the result of calculation is a reference type, the reference address is displayed in hex as follows:

```
(signed int &) ref = 0xD038(all Radices)
```

10.2.7 Bit Field Types

- When the result of calculation is a bit field type, it is displayed as follows:

```
(unsigned int :13) s.f = 8191(when Radix is in initial state)
(unsigned int :13) s.f = 0x1FFF(when Radix is hex)
(unsigned int :13) s.f = 1111111111111B(when Radix is binary)
```

10.2.8 When No C Symbol is Found

If the calculated expression contained a C symbol that could not be found, it is displayed as follows:

```
( ) x = <not active>(all Radices)
```

10.2.9 Syntax Errors

- When the calculated expression contains a syntax error, it is displayed as follows:


```
( ) str*(p = <syntax error>(all Radices)  
(where str*(p is the syntax error)
```

10.2.10 Structure and Union Types

- When the result of calculation is a structure or union type, the address is displayed in hex as follows:

```
(Data) v = 0x1234 (all Radices)
```

If, as in structures and unions, the C/C++ expression consists of members, a '+' is displayed to the left of the type name (tag name).



You can double-click on lines indicated by a '+' to see the members of that structure or union. The '+' changes to a '-' while the members are displayed. To return to the original display, double click the line, now indicated by the '-'. This function allows you to check the members of structures and unions.

Attention

If a variable is declared with the same name as the type definition name declared by typedef, you cannot reference that variable.

- Register Variables

When the result of calculation is a register variable, "register" is displayed to the left of the type name as follows:

```
(register signed int) j = 100
```


11. Display the Cause of the Program Stoppage

If the program is stopped by the debug function, the cause of the stoppage is displayed in the Output window or Status window ([Platform] sheet).

The contents of a display and the meaning of "the cause of the stoppage" are as follows.

Display	The cause of the stoppage
Halt	The stop by the [Halt Program] button/menu
S/W break	Software break
Address match interrupt break	Address interrupt break
H/W event, Combination	Hardware break, logical combination AND or AND(same time)condition was met
H/W event, Combination, Ax	Hardware break, logical combination OR condition was met (Ax: The event number of which condition was met.)
H/W event, State transition, from xx	Hardware break, State Transition condition was met (from xx: previous state (start, state1, state2))
H/W event, State transition, Timeout	Hardware break, State Transition, Time Out condition was met
H/W event, Access protect error	Protect break

Note

To be able to show the cause of break or not depends on the connected target. Some targets may always show "Halt" or show "---".

12. Attention

12.1 Common Attention

12.1.1 File operation on Windows

1. File Name and Directory Name
 - Do not use directory names or filenames that include blanks.
 - Operation is not guaranteed if your directory names and filenames include kanji.
 - Use only one period in a filename.
2. Specify the File and Directory
 - You cannot use ".." to specify two levels upper directories.
 - You cannot use a network pathname. You must allocate a drive.

12.1.2 Area where software breakpoint can be set

The area which can be set for software breakpoint varies depending on the type of MCU.

12.1.2.1 The debugger for M32C

The area which can be set for software breakpoint varies depending on the processor mode.

Processor Mode	Can be set area
Single Chip	Internal RAM, Internal ROM
Memory Extension	Internal RAM, Internal ROM Emulation memory (Only the Internal area)
Micro Processor	Internal RAM Emulation memory (Only the Internal area)

To stop the target program outside the emulation memory area, use the Come execution.

12.1.2.2 The debugger for M16C/R8C

The RAM / ROM area memory-mapped in the area set as Internal can be designated for software breakpoint.

12.1.2.3 The debugger for 740

Only the ROM area memory-mapped in the area set as Internal can be designated for software breakpoint.

You cannot set software breakpoint in ROM areas memory-mapped in the SFR area, RAM area or other areas set as External.

12.1.3 Get or set C variables

- If a variable is declared with the same name as the type definition name declared by typedef, you cannot reference that variable.
- Values cannot be changed for register variables and bit fields.
- Values cannot be changed for 64 bit width variables (long long, double, and so on).
- Values cannot be changed for C/C++ expressions that do not indicate the memory address and size.
- For the sake of optimization, the C compiler may place different variables at the same address. In this case, values of the C variable may not be displayed correctly.
- Literal character strings can only be substituted for char array and char pointer type variables.
- No arithmetic operations can be performed on floating point types.
- No sign inversion can be performed on floating point types.
- Casting cannot be performed on floating point types.
- Casting cannot be performed on register variables.
- Casting cannot be performed on structure types, union types, or pointer types to structure or union types.
- Character constants and literal character strings cannot contain escape sequences.

12.1.4 Function name in C++

- When you input the address using the function name in setting display address, setting break points, and so on, you can not specify the member function, operator function, and overloaded function, of a class.
- You can not use function names for C/C++ expression
- No script commands (e.g., breakin and func) can be used in which function names are specified for arguments.
- In address value specifying columns of dialog boxes, no addresses can be specified using function names.

12.1.5 Debugging multi modules

If you register two or more absolute module file in one session, you can download only one file in same time.

If you register one absolute module file and one or more machine language file in one session, you can download all file in same time.

12.1.6 Synchronized debugging

Synchronized debugging function is not available.

12.1.7 Down-load of Firmware

To start the debugger, a firmware corresponding to the connected emulation pod or emulation probe must be downloaded to the emulator.

- The emulation pod or emulation probe has been changed.
- A unknown firmware is downloaded to the emulator.
- The debugger is used for the first time.
- The debugger has been upgraded.

In one of the above cases, you must perform the following operation before starting the debugger. Press the emulator system reset switch within 2 seconds after turning ON the emulator power switch. Then, the emulator enters a mode in which the firmware is forced to be downloaded.

12.1.8 Restriction of LPT port

1. The emulator uses a printer (parallel) port during LPT communications with personal computer. The IAR C compiler also uses this printer (parallel) port.
When using the personal computer and the emulator during LPT communications, a problem arises that you cannot compile a program using the IAR C compiler.
If this happens, you must take either of the countermeasures listed below:
 - Connect the personal computer to the emulator in any mode other than the ECP mode.
 - Start compiling the program after the debugger is terminated.
2. When you debug programs using the LPT parallel interface on the host PC running Windows XP, the following symptoms may appear:
 - The debugger becomes frozen.
 - The debugger's operation gets extraordinarily slower.
 - Communication errors arise and the emulator debugger stops operating.
 - Various types of errors other than communication errors also take place successively. In this case, the emulator debugger continues operating however.

The cause of this problem is that if the debugger is invoked while the standard driver Parport.sys of Windows XP is communicating with the LPT port, the debugger is unable to communicate with the emulator. Then, this problem can be circumvented in either of the following methods; however, you need to take no measures if you have not experienced it in your PC under the above-mentioned conditions:

- Execute the utility program to fix (LptFix.exe).
LptFix.exe disables the Parport.sys driver. Then, if any device other than the emulator is connected to the LPT port after LptFix.exe is executed, the device may not operate properly. In such a case you are encouraged to adopt method shown below.
- If you launch the emulator for the first time after starting the PC, invoke the debugger one or more minutes after the emulator starts operating. Otherwise, you can invoke the debugger immediately after the emulator has started.

Here is the usage of LptFix.exe:

1. Invoke the command prompt and move to the folder where the LptFix.exe file resides.
2. Enter the following command on the command line:

```
-----  
>LptFix  
-----
```

3. Restart the PC.

If LptFix.exe is executed, be sure to make it ineffective to enable the Parport.sys driver as explained below, every time after ending debugging operations and disconnecting the emulator. To make LptFix.exe ineffective to enable Parport.sys, execute following command line:

```
-----  
>LptFix /U  
-----
```

12.1.9 Notes for coverage function

Coverage Measurement is a function to record the addresses accessed by the target program. These accessed addresses will flow to the microcomputer address bus. This may cause unexecuted addresses to be treated as executed addresses when calculating coverage.

12.1.10 Emulator reset switch

If system reset of the emulator does not function normally, terminate the debugger, turn ON the emulator again, and restart the debugger. Then re-download the program.

12.1.11 Debugging Resource on Emulator

The debugging resource on the emulator is shared the window/between the dialogs plurals. Therefore, either of the window/the dialog which can be used at the same time is only one.

Trace Event	<ul style="list-style-type: none">• Trace Point Setting Window(TracePoint Command)• MR Trace Window/MR Analyze Window• Task Trace Window/Task Analyze Window• Time Measurement Window
-------------	--

12.2 Attention of the M32C Debugger

12.2.1 Stack area used by the emulator

The emulator uses the interrupt stack area as a work area (20 bytes).

Before starting debugging, be sure to reserve the user stack area + 20-byte area.

12.2.2 Interrupt stack pointer when resetting the target program

The emulator sets the interrupt stack pointer (ISP) to 0500h when resetting the target program.

Remember that the interrupt stack pointer (ISP) is set to 0000h on a unit at the production stage.

12.2.3 Option of C Compiler/Assembler/Linker

The information may not be downloaded/debugged normally depending on the option designation of the compiler, assembler, and linker.

Please refer to the following for the option specification.

Refer to "12.5 Option of C Compiler/Assembler/Linker"

The compiler that can be used by M32C debugger:

- NCxx
- the IAR EC++ Compiler
- the IAR C Compiler

12.2.4 Target MCU HOLD terminal

When the target MCU HOLD terminal is set to LOW, you cannot stop execution of the target program.

Set the HOLD terminal to High and try to stop the target program again.

Even if the HOLD terminal is set to LOW for a short period of time, you may stop the target program with the HOLD terminal set to LOW.

If this happens, try to stop the target program again.

12.2.5 Hardware Event

- The debugger does not support a command fetch (Fetch) or an interrupt as a hardware event.
- If you specify word-length (2-byte length) data from an odd address as an event in the following data accesses, the event is not detected. Also, even when any other bit of the address that contains a specified bit is accessed during bit access, the event may become effective.
 - Hardware Break Event
 - Real-time Trace Event
 - Time Measurement Event
- In the PID setting, you can specify the access size (BYTE/WORD). However, if you specify an odd address in the "Address:" field, you cannot specify the WORD size.

12.2.6 Time Measurement Resource

You need to specify the operating frequency of mcu for debugger to calculate the time for Trace window, Time measurement window, or other functions.

You can set it in MCU tab of INIT dialog box. If you use the mcu at 10MHz div 8, please enter 10 and 8 to edit boxes.

12.2.7 CPU rewrite

You can not debug the program using CPU rewrite.

12.2.8 MR STK script command

- The MR STK BASE command automatically sets the area where the stack consumption can be measured. The area set by this command is range of 256KB including the start address of the system stack. If you want to set other area, please use not the MR STK BASE script command but the CoVerage BASE script command.

12.3 Attention of the M16C/R8C Debugger

12.3.1 Map of stack area used by the emulator

The M16C/60, M16C/20 series emulators use a stack area of 4 bytes from 0FFFCh to 0FFFFh that is accessed at power-on reset.

The emulator cannot start up normally unless these 4 bytes of memory can be accessed for read/write. Therefore, if one of the following two conditions hold true, use the four bytes of 0FFFCh to 0FFFFh in INTERNAL setting until the emulator finishes setting the interrupt stack pointer (ISP) after a reset.

- When in systems that go from the single-chip mode to the memory extension or the microprocessor mode after a reset, you are using the four bytes of 0FFFCh to 0FFFFh in EXTERNAL setting.
- When in systems that start up in microprocessor mode after a reset, you are using the four bytes of 0FFFCh to 0FFFFh in EXTERNAL setting and do not have any external read/writable memory.

12.3.2 Options for compiler, assembler, and linker

The information may not be downloaded/debugged normally depending on the option designation of the compiler, assembler, and linker.

Please refer to the following for the option specification.

Refer to "12.5 Option of C Compiler/Assembler/Linker"

The compiler that can be used by M16C/R8C debugger:

- NCxx
- the IAR EC++ Compiler
- the IAR C Compiler
- the TASKING C Compiler

12.3.3 TASKING C Compiler

When you debug programs compiled by the TASKING C Compiler "CCM16", the type of bit field is fixed on "unsigned short int". Because CCM16 outputs the debug information for the type of bit field as "unsigned short int."

12.3.4 Target MCU HOLD terminal

When the target MCU HOLD terminal is set to LOW, you cannot stop execution of the target program. Set the HOLD terminal to High and try to stop the target program again. Even if the HOLD terminal is set to LOW for a short period of time, you may stop the target program with the HOLD terminal set to LOW. If this happens, try to stop the target program again.

12.3.5 Hardware Event

- If you specify word-length (2-byte length) data from an odd address as an event in the following data accesses, the event is not detected. Also, even when any other bit of the address that contains a specified bit is accessed during bit access, the event may become effective.
 - Hardware Break Event
 - Real-time Trace Event
 - Time Measurement Event
- To detect a byte access to an odd address in 8 bit bus width, specify the compare data to HI-BYTE.
- You cannot specify a PID data in word-length, when the specified PID address is an odd address.

12.3.6 Operating frequency of MCU

You need to specify the operating frequency of mcu for debugger to calculate the time for Trace window, Time measurement window, or other functions.

You can set it in MCU tab of INIT dialog box. If you use the mcu at 10MHz div 8, please enter 10 and 8 to edit boxes.

12.3.7 The correspondence OS version of task pause function

The task pause function is available when downloading a target program in which the system for the task pause function, supported by MR30 V.3.00 or later version, is installed.

If the MR30 version is V.3.00 Release 1, the following phenomenon may occur.

- If a program issues a system call such as `rel_wai` or `irel_wai` to a task which is changed to "Pause" using the task pause function, the "Pause" state of the task is reset.
In this case, the MR Task Pause window shows the task information different from the real task state.

This phenomenon will not occur on a target program in which MR30 V3.10 Release 1 or later is installed.

12.3.8 Memory Space Expansion

- C watch window, Memory window, and other debugging windows can not show correct values, when it shows the expanded area of the memory space expansion function. Debugging windows does not consider the bank register.
- In MODE2 of memory space expansion, the area bank7 is always set the map as EXTERNAL.

Please refer to the "5.1.4 Memory Extension Mode Tab".

12.3.9 Watch dog timer

You can not debug the program using Watch dog timer. While debugging, please do not start WDT.

12.3.10 CPU rewrite

You can not debug the program using CPU rewrite.

12.3.11 MR STK script command

- The MR STK BASE command automatically sets the area where the stack consumption can be measured. The area set by this command is range of 256KB including the start address of the system stack. If you want to set other area, please use not the MR STK BASE script command but the CoVerage BASE script command.

12.4 Attention of the 740 Debugger

12.4.1 Setting of Memory Map

The map attributes immediately after the emulator has started up are External for 0h-3FFFh and Internal for 4000h-FFFFh. The memory map information must be altered to suit the target microcomputer's memory space. It is similar in the case of the microcomputer that inside ROM area begins from the 4000h past.

Please refer to "5.5 Setup the Debugger for 740" for details.

12.4.2 Emulation Pod M37515T-RPD

When you use emulation pod M37515T-RPD, you must be specify "40" to the fifth line (POD number specification line) of the MCU file. MCU which becomes an object is as follows.

- 7515 Group
- 3850 Group
- 3851 Group

12.4.3 Stack area used by the emulator

The emulator uses the user stack area as a work area (3 bytes).

Before starting debugging, be sure to reserve the user stack area + 3 byte area.

12.4.4 Specify the Clock

When following Emulation Pod is used, the target clock becomes external clock fixation (The specified clock is invalid).

- M38000T-FPD
- M38000TL-FPD
- M38000TL2-FPD

12.4.5 Watch dog timer

When the watch dog timer is enabled, operations other than free-run of the target program are inhibited. Before starting debugging, disable the watch dog timer.

12.4.6 Option of C Compiler/Assembler/Linker

The information may not be downloaded/debugged normally depending on the option designation of the compiler, assembler, and linker.

Please refer to the following for the option specification.

Refer to "12.5 Option of C Compiler/Assembler/Linker"

The compiler that can be used by 740 debugger:

- the Assembler Package for 740 Family SRA74
- the IAR C Compiler

12.4.7 About the single-step execution and the program break function in the internal RAM area of the mcu

When debugging with the emulation pod M38000L2-FPD, single-step execution and program break function in the internal RAM area are not available.

When debugging the program transferred to the internal RAM area, please use the free-run execution and the trace function.

12.4.8 Debugging in the 16-Timer functions

The microcomputer (38B5 group etc.) which supports 16 bit timer has undermentioned limitations.

- [Precaution 1]
Outputs for the 16-bit timer may be invalid in the Memory Window etc. when the program execution is suspended by breaking or single-stepping during writing to the higher/lower order byte of the 16-bit timer.

For example:

```
[TIMER_LOW] = [DATA1]
[TIMER_HIGH] = [DATA2] <- when a break occurs here
```

- [Precaution 2]
Writing a value (with the Memory Window) into the 16-bit timer will be fail when the program execution is suspended by breaking or single-stepping during writing to the higher/lower order byte of the 16-bit timer.

For example:

```
[DATA1] = [TIMER_LOW]
[DATA2] = [TIMER_HIGH] <- when a break occurs here
```

These problems caused by the microcomputer's specifications. In a microcomputer with the 16-bit timer, the timer is written in the order of the lower byte and the higher byte. And reading from the timer in reverse order.

Therefore, if a break occurs as shown in the Precaution 1 or 2, an incorrect value will be read or written by displaying or setting a value of the 16-bit timer in the Memory Window.

12.4.9 Hardware Event

If you specify any other bit of the address that contains a specified bit is accessed during bit access, the event may become effective in the following data accesses.

- Hardware Break Event
- Real-time Trace Event
- Time Measurement Event

12.4.10 Operating frequency of MCU

You need to specify the operating frequency of mcu for debugger to calculate the time for Trace window, Time measurement window, or other functions.

You can set it in MCU tab of INIT dialog box. If you use the mcu at 10MHz div 8, please enter 10 and 8 to edit boxes.

12.5 Option of C Compiler/Assembler/Linker

We do not evaluate other settings, so we can not recommend to append other options.

12.5.1 When Using NCxx

When -O, -OR or -OS option is specified at compilation, the source line information may not be generated normally due to optimization, causing step execution to be operated abnormally.

To avoid this problem, specify -ONBSD (or -Ono_Break_source_debug) option together with -O, -OR or OS option.

12.5.2 When Using the Assembler Package for 740 Family

Please assemble according to the following procedures and link.

At assemble

- "-c" option
outputs debugging information concerned with source line to a relocatable file.

Note

When the directive comand .FUNC is specified to a function in a source file, if "-c" option is used, the name of the function will be not available. Please do not use the option to make the name available.

- "-s" option
outputs local labels, local .equ symbols and local .bequ symbols to a relocatable file.

At link

- "-s" option
generates a symbol file.

We do not evaluate other settings, so we can not recommend to append other options.

12.5.2.1 Command Execution Examples

The following shows examples of entering commands depending on the product

- The Debugger for 740

```
>sra74 -c -s main.a74<Enter>
>sra74 -c -s sub.a74<Enter>
>link74 main sub , , -s<Enter>
```

12.5.3 When Using the IAR C Compiler (EW)

Please specify the project setting by following process.

1. The Setting in the IAR Embedded Workbench

When you select the menu [Project] -> [Options...], the dialog for "Options For Target " target"" will open. In this dialog, please select the "XLINK" as category, and set the project setting.

 - Output Tab

In the "Format" area, check the "Other" option, and select the "ieee-695" as "Output Format".
 - Include Tab

In the "XCL File Name" area, specify your XCL file (ex: lnkm16c.xcl).
2. Edit the XCL file

Add the command line option "-y" to your XCL file. The designation of "-y" option varies depending on the product.

Product Name	-y Option
The debugger for M32C	-ylmb
The debugger for M16C/R8C	-ylmb
The debugger for 740	-ylmba

3. Build your program after the setting above.

We do not evaluate other settings, so we can not recommend to append other options.

12.5.4 When Using the IAR C Compiler (ICC)

12.5.4.1 Specify the Option

Please compile according to the following procedures and link.

- At compilation
Specify the "-r" option.
- Before linking
Open the linker's option definition file (extension .xcl) to be read when linking and add "-FIEEE695" and "-y" options. The designation of "-y" option varies depending on the product.

Product Name	-y Option
The debugger for M32C	-ylmb
The debugger for M16C/R8C	-ylmb
The debugger for 740	-ylmba

At link

Specify the linker's option definition file name using "-f" option.

We do not evaluate other settings, so we can not recommend to append other options.

12.5.4.2 Command Execution Examples

The following shows examples of entering commands depending on the product

- The debugger for M32C

```
>ICCMC80 -r file1.c<Enter>
>ICCMC80 -r file2.c<Enter>
>XLINK -o filename.695 -f lnkm80.xcl file1 file2<Enter>
```
- The debugger for M16C/R8C

```
>ICCM16C -r file1.c<Enter>
>ICCM16C -r file2.c<Enter>
>XLINK -o filename.695 -f lnkm16c.xcl file1 file2<Enter>
```
- The debugger for 740

```
>ICC740 -r file1.c<Enter>
>ICC740 -r file2.c<Enter>
>XLINK -o filename.695 -f lnk7400t.xcl file1 file2<Enter>
```

The XCL file name varies depending on the product and memory model. For details, see the ICCxxxx manual.

12.5.5 When Using the TASKING C Compiler (EDE)

Please specify the project setting by following process.

1. Select menu - [EDE]->[C Compiler Option]->[Project Options...]. The "M16C C Compiler Options [Project Name]" dialog opens.
Please set as follows by this dialog.
 - Optimize Tab
Please specify "No optimization" by Optimization level.
 - Debug Tab
Please check only ""Enable generation of any debug information(including type checking)"" and "Generate symbolic debug information".
2. Select menu - [EDE]->[Linker/Locator Options...]. The "M16C Linker/Locator Options [Project Name]" dialog opens.
Please set as follows by this dialog.
 - Format Tab
Please specify "IEEE 695 for debuggers(abs)" by Output Format.
3. Build your program after the setting above.

We do not evaluate other settings, so we can not recommend to append other options.

12.5.6 When Using the TASKING C Compiler (CM)

12.5.6.1 Specify the Option

Please specify "-g" and "-O0" options when compiling.

In the options other than the above-mentioned, the operation check is not done. Please acknowledge that the options other than the above-mentioned cannot be recommended.

12.5.6.2 Command Execution Examples

The following shows examples of entering commands.

```
>CM16 -g -O0 file1.c<Enter>
```

12.5.7 When Using the IAR EC++ Compiler (EW)

Please specify the project setting by following process.

1. The Setting in the IAR Embedded Workbench
When you select the menu [Project] -> [Options...], the dialog for "Options For Target " target"" will open. In this dialog, please select the "XLINK" as category, and set the project setting.
 - Output Tab
In the "Format" area, check the "Other" option, and select the "elf/dwarf" as "Output Format".
 - Include Tab
In the "XCL File Name" area, specify your XCL file (ex: lnkm32cf.xcl).
2. Edit the XCL file
Add the command line option "-y" to your XCL file. The designation of "-y" option varies depending on the product.

Product Name	-y Option
The debugger for M32C	-yspc
The debugger for M16C/R8C	-yspc

3. Build your program after the setting above.

We do not evaluate other settings, so we can not recommend to append other options.

M16C PC4701 Emulator Debugger V.1.02
User's Manual

Publication Date: Aug. 01, 2006 Rev.1.00

Published by: Sales Strategic Planning Div.
 Renesas Technology Corp.

Edited by: Microcomputer Tool Development Department
 Renesas Solutions Corp.

M16C PC4701 Emulator Debugger V.1.02 User's Manual



Renesas Electronics Corporation

1753, Shimonumabe, Nakahara-ku, Kawasaki-shi, Kanagawa 211-8668 Japan

REJ10J1380-0100