

# **User Manual**

## **DA16200 AT GUI Tool**

### **UM-WI-004**

---

## Contents

<b>Contents</b> .....	<b>2</b>
<b>Figures</b> .....	<b>3</b>
<b>1 Terms and Definitions</b> .....	<b>4</b>
<b>2 References</b> .....	<b>4</b>
<b>3 Introduction</b> .....	<b>5</b>
3.1 Certification Mode .....	5
3.2 Network Mode .....	5
3.3 OTP Mode .....	5
<b>4 How to Connect</b> .....	<b>6</b>
4.1 USB to Serial Driver .....	6
<b>5 DA16200 SDK or Firmware Selection</b> .....	<b>6</b>
<b>6 How to Run GUI with DA16200 EVK</b> .....	<b>7</b>
6.1 Connection and Running .....	7
6.2 COM Port and Baud Rate Configuration .....	9
6.3 RF Certification Mode .....	10
6.4 TX Test Mode .....	11
6.5 RX Test Mode .....	12
<b>7 Network Mode</b> .....	<b>14</b>
7.1 Station Mode .....	15
7.2 AP Mode .....	17
7.3 Data Transfer (TCP/UDP) .....	18
7.3.1 TCP Server .....	19
7.3.2 TCP Client .....	20
7.3.3 UDP Session .....	20
7.3.4 Data Exchange .....	21
7.3.5 Data Transfer on DPM Mode .....	22
7.4 MQTT Client .....	23
7.4.1 Configuration .....	23
7.4.2 Data Exchange .....	24
7.4.3 MQTT on DPM Mode .....	24
7.5 TLS Setting .....	25
<b>8 OTP Mode Setup</b> .....	<b>26</b>
<b>Revision History</b> .....	<b>27</b>

## Figures

Figure 1: DA16200 EVK GUI.....	5
Figure 2: Development Kit Connections.....	7
Figure 3: AT GUI .....	8
Figure 4: RS232 Setup – Disconnected .....	9
Figure 5: RS232 Setup – Connected .....	9
Figure 6: Debug Console – Connected .....	9
Figure 7: Certification Mode Configuration.....	10
Figure 8: Tx Test Mode Configuration .....	11
Figure 9: Debug Console – TX Mode .....	11
Figure 10: Start and Stop TX.....	12
Figure 11: Debug Console – Start TX .....	12
Figure 12: Debug Console – Stop TX .....	12
Figure 13: Rx Configuration.....	13
Figure 14: Network Mode Configuration.....	14
Figure 15: Setup Window – Station Mode.....	15
Figure 16: Station Mode – SCAN .....	15
Figure 17: Station Mode – Choose AP and Connect .....	16
Figure 18: Debug Console – Connect to AP .....	16
Figure 19: Setup Window – AP Mode .....	17
Figure 20: AP Configuration .....	17
Figure 21: Debug Console – AP Configuration .....	18
Figure 22: DHCP Configuration.....	18
Figure 23: Debug Console – DHCP Configuration.....	18
Figure 24: Data Transfer Tab .....	19
Figure 25: TCP Server Open.....	19
Figure 26: TCP Server Connection with a Client .....	19
Figure 27: TCP Client Connection to a Server .....	20
Figure 28: UDP Session Open .....	20
Figure 29: TCP Server Data Transfer .....	21
Figure 30: TCP Client Data Transfer.....	21
Figure 31: UDP Session Data Transfer.....	21
Figure 32: TCP/UDP Data Reception.....	22
Figure 33: DPM Mode Setting .....	22
Figure 34: MQTT Client Tab.....	23
Figure 35: MQTT PUBLISH Transfer .....	24
Figure 36: MQTT PUBLISH Reception .....	24
Figure 37: TLS Setting Tab .....	25
Figure 38: OTP Mode .....	26

## 1 Terms and Definitions

AP	Access Point
AT	AT Command Interpreter Software Subsystem, or Attention
CoAP	Constrained Application Protocol
DHCP	Dynamic Host Configuration Protocol
EVK	Evaluation Kit
GUI	Graphical User Interface
HTTP	Hypertext Transfer Protocol
MFC	Microsoft Foundation Class
MQTT	Message Queuing Telemetry Transport
OTP	One-Time Programmable
PC	Personal Computer
QFN	Quad Flat No-Lead
SDK	Software Development Kit
SSID	Service Set Identifier
STA	STation
TCP	Transmission Control Protocol
TLS	Transport Layer Security
UART	Universal Asynchronous Receiver Transmitter
UDP	User Datagram Protocol
USB	Universal Serial Bus

## 2 References

- [1] DA16200, Datasheet, Dialog Semiconductor
- [2] DA16200, SDK Programmer Guide, User Manual, Dialog Semiconductor
- [3] DA16200, EVK User Guide, Dialog Semiconductor
- [4] DA16200, AT Command User Guide, Dialog Semiconductor

## DA16200 AT GUI Tool

### 3 Introduction

The DA16200 GUI tool lets users control the DA16200 EVK in a GUI environment. There are three modes of operation: Certification mode, Network mode, and OTP mode (see [Figure 1](#)).




Figure 1: DA16200 EVK GUI

#### 3.1 Certification Mode

This mode is for Wi-Fi RF test (Tx power, Rx sensitivity, and so on) also known as “TEST Mode”.

#### 3.2 Network Mode

With Network mode, the Station or AP mode of the DA16200 is tested.

- **AP mode:** Soft-AP test with configurable parameters like SSID, security, DHCP Server, and so on
- **Station mode:** STA test to search and connect to an Access Point and check/test the STA function

After the network mode is set, the user can test the TCP/UDP or the MQTT and manage the TLS certificates.

- **Data Transfer:** message exchange through the TCP Server/Client, and UDP session
- **MQTT Client:** message exchange through the MQTT protocol
- **TLS Setting:** management of TLS certificate that is set (e.g. Root CA, Client Certificate, Client Private Key)

#### 3.3 OTP Mode

This mode is for **power calibration** and **temperature calibration with OTP memory location**.

---

**DA16200 AT GUI Tool**

## 4 How to Connect

### 4.1 USB to Serial Driver

The DA16200 evaluation board supports USB to serial interface. The user connects to DA16200 EVK with the PC through a micro-USB cable and then two COM ports will be detected automatically.

One (UART0) is for console command and the other (UART1) is for AT command. Normally, the higher number COM port is for AT commands and the lower number COM port is for the console.

- Required the FT232 Driver installation for Windows
  - In most cases, it will be installed automatically

The FTDI driver for the FT2232 FTDI chip used on DA16200 EVK is available for download at the following link: [http://www.ftdichip.com/Drivers/CDM/CDM21224\\_Setup.zip](http://www.ftdichip.com/Drivers/CDM/CDM21224_Setup.zip)

- See the EVK User Guide [3] to find information about the UART1 port. AT GUI tool uses UART1 port
- To update with a new DA16200 firmware, see the DA16200 EVK User Guide [3]

## 5 DA16200 SDK or Firmware Selection

There are several types of SDK and firmware for DA16200 such as Generic and Manufacture that can be found in DA16200 SDK/Image packages. Consider the kinds of tests you plan to determine which SDK or firmware should be picked up.

- Certification or OTP Mode:
  - SDK: DA16200\_SDK\_Manufacture\_QFN\_xxx.zip
  - Firmware: DA16200\_IMG\_Manufacture\_QFN
- Network Mode:
  - SDK: DA16200\_SDK\_Generic\_QFN xxx.zip
    - The `__SUPPORT_ATCMD__` where can be found in `config_generic_sdk.h` file should be enabled.

```
[\\apps\da16200\get_started\inc\config_generic_sdk.h]
```

```
// AT-CMD features
#define    __SUPPORT_ATCMD__                // Support AT-CMD
```

- Firmware: ATCMD firmware should be picked such as DA16200\_IMG\_Generic\_QFN\_ATCMD, DA16200\_IMG\_Generic\_FcCSP\_LP\_ATCMD or DA16200\_IMG\_Generic\_FcCSP\_NP\_ATCMD depending on SoC package type

## 6 How to Run GUI with DA16200 EVK

### 6.1 Connection and Running

DA16200 AT GUI program is a single executable file.

**NOTE**

If there is an error with the message "a DLL file (e.g. *vcruntime140.dll* or *mfc1400u.dll*) is missing", then install Microsoft Visual Studio redistributable package (<https://www.microsoft.com/en-us/download/details.aspx?id=48145>) or copy the .dll file into the Windows system folder (C:\Windows\System32 or C:\Windows\SysWOW64).

The program setup sequence is:

1. Connect the DA16200 Development Kit to the host PC as shown in
- 2.
3. [Figure 2](#).




Figure 2: Development Kit Connections

**NOTE**

See the EVK User Guide [\[3\]](#) to know which port to use.

DA16200 AT GUI Tool

- 4. Start the AT GUI program.




Figure 3: AT GUI



DA16200 AT GUI Tool

6.2 COM Port and Baud Rate Configuration

- When the AT GUI program runs, the connection status is red (not connected). If the program does not detect any COM port, click the **Refresh** button to refresh the COM Port. See [Figure 4](#).




Figure 4: RS232 Setup – Disconnected

- Select a COM port and click the **OPEN** button and wait for a few seconds. See [Figure 5](#) and [Figure 6](#).
  - The connection status will soon change to a green color and the **Connection Status** field shows “Connected” in a green color. This means that communication is OK




Figure 5: RS232 Setup – Connected

- In the **Debug Console** window (in the black box), the message “Echo on” is shown




Figure 6: Debug Console – Connected

### 6.3 RF Certification Mode

To enable certification mode:

1. Open the **Settings** tab. See [Figure 7](#).
2. In the **RF Mode** area, select the **Certification Mode** check box.





Figure 7: Certification Mode Configuration

## DA16200 AT GUI Tool


### 6.4 TX Test Mode

1. Open the **Certification Mode** tab. See [Figure 8](#).



**Figure 8: Tx Test Mode Configuration**

2. Click the **Mode Select** button ([Figure 8](#)). A confirmation message is shown as in [Figure 9](#). This is a normal state.




**Figure 9: Debug Console – TX Mode**

3. Select the **Data Rate**, **Channel**, and **Power** for the purpose of the test.
  - **Packet mode**: this is the normal test mode with packet generation mode. Offers the possibility to adjust duty of RF Burst at time domain
  - **Cont mode**: Continuous TX out mode. This mode is for TX power test and so on. In this mode, TX packet is generated continuously over 95% duty cycle
  - **CW mode**: Only single sinewave tone out mode. This mode is for freq err check
  - **Data Rate**: Choose modulation type to test
  - **Power**: Select or tune the power level. ("0" step is Maximum). The difference between power steps is about 0.8~1 dB/1step
  - **Size**: You can adjust the duty rate with this number. However, the size is not linear as the number, so to set the exact number you need equipment like a spectrum analyzer to check the value. (Equipment setting is set to zero span setting or burst mode setting)

DA16200 AT GUI Tool

To do TX packet generation:

- To start and stop TX packet generation, use the **Start TX** button and the **Stop TX** button. If you want to make changes for another condition, click **Stop TX** before a new test is started



Start TX

Stop TX

Figure 10: Start and Stop TX

For example: there is a test setting with 802.11n MCS7, channel 1, 100 bytes packet and power grade 0.

- When the **Start TX** button is clicked, messages as shown in Figure 11 will be shown

```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
```

Figure 11: Debug Console – Start TX

- When you click the **Stop TX** button, messages as shown in Figure 12 will be shown

```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
AT+RFTXSTOP
OK
```

Figure 12: Debug Console – Stop TX

6.5 RX Test Mode

The settings are made in the **RX Setting** area. See Figure 13.

DA16200 AT GUI Tool

- **Channel:** Support CH1 ~ CH13
- **Test Time:** Maximum 3600 s (Duration is 1 second fixed)

RX Setting

Channel : CH1 (2412MHz) Start RX

Test Time : 0 Seconds Clear Stat

(0 for infinite)

Time :  /  s

Valid	<input style="width: 90%;" type="text"/>	Packets
FCS Error	<input style="width: 90%;" type="text"/>	Packets
PHY Error	<input style="width: 90%;" type="text"/>	Packets
Overflow Error	<input style="width: 90%;" type="text"/>	Packets
Total Packet	<input style="width: 90%;" type="text"/>	Packets
Error Rate	<input style="width: 90%;" type="text"/>	%

Figure 13: Rx Configuration

- RX Packet Rate
  - $FCS + PHY + Overflow\ packet / Total\ packet = Error\ rate$

## 7 Network Mode

To enable network mode:

1. Open the **Settings** tab.
2. Select the **Network Mode** checkbox. See [Figure 14](#).




Figure 14: Network Mode Configuration

DA16200 AT GUI Tool

7.1 Station Mode

1. In the **Mode Select:** field, select **Station Mode**.
  - The network mode is changed. Next, DA16200 reboots and the station mode setup window opens. See [Figure 15](#)




Figure 15: Setup Window – Station Mode

2. Click the **Scan** button to scan APs. See [Figure 16](#).




Figure 16: Station Mode – SCAN

DA16200 AT GUI Tool

3. When scanning is finished, choose one AP in the list. See [Figure 17](#).
4. Click the **Connect** button.
5. If required by the security mode of the AP, fill in a password or key index.




Figure 17: Station Mode – Choose AP and Connect



Figure 18: Debug Console – C onnect to AP



DA16200 AT GUI Tool

7.2 AP Mode

1. In the **Mode Select** field, select **AP Mode**.
  - The network mode changes, DA16200 reboots and the AP Mode setup window opens. See [Figure 19](#)




Figure 19: Setup Window – AP Mode

2. Set the fields SSID, Password, Country, Channel, and Security mode. See [Figure 20](#).
3. Click the **Confirm** button.




Figure 20: AP Configuration

DA16200 AT GUI Tool

- The Debug Console window messages appears as shown in [Figure 21](#)




Figure 21: Debug Console – AP Configuration

- In the **DHCP Server** area, make the required settings for the IP addresses and click the **Confirm** button. See [Figure 22](#).
  - When a client is connected, the MAC address will be shown as in [Figure 23](#)




Figure 22: DHCP Configuration




Figure 23: Debug Console – DHCP Configuration

### 7.3 Data Transfer (TCP/UDP)

The DA16200 GUI tool provides data transfer functions with TCP/UDP. Before messages are sent with this tool, connect the DA16200 to an access point as shown in Section [7.1](#). Then click the **Data**

**Transfer** tab. If DA16200 succeeds to connect to an AP, the IP address will be filled in. See [Figure 24](#).




**Figure 24: Data Transfer Tab**

The DA16200 provides three kinds of sessions: TCP server, TCP client, and UDP session. The user can use these three simultaneously.


### 7.3.1 TCP Server

To use TCP server, fill in a port number and click the **Connect** button on the **TCP Server** line. When a server is opened, the **X** will change to **O**. See [Figure 25](#).



**Figure 25: TCP Server Open**

The user can connect to the DA16200 TCP server with tools for data exchange like the IO Ninja. When a client connects successfully, its information will be shown as in [Figure 26](#). The DA16200 TCP server can accept up to eight client sessions.



**Figure 26: TCP Server Connection with a Client**

DA16200 AT GUI Tool

7.3.2 TCP Client

To connect to a TCP server, fill in the IP address and port number of the server and click the **Connect** button on the **TCP Client** line. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See [Figure 27](#).




Figure 27: TCP Client Connection to a Server

7.3.3 UDP Session

To open a UDP session, fill in a port number and click the **Start** button. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See [Figure 28](#). TODO:




Figure 28: UDP Session Open

DA16200 AT GUI Tool

7.3.4 Data Exchange

To send a message to a peer, first select a session. Each session is slightly different in method.

- **TCP Server:** Select the **TCP Server** checkbox > Select the destination IP in the drop-down list > Type a message > Click the **Send** button (see [Figure 29](#))




Figure 29: TCP Server Data Transfer

- **TCP Client:** Select the **TCP Client** checkbox > Type a message > Click the **Send** button (see [Figure 30](#))




Figure 30: TCP Client Data Transfer

- **UDP Session:** Select the **UDP Session** checkbox > Enter the destination IP and port number > Type a message > Click the **Send** button (see [Figure 31](#))




Figure 31: UDP Session Data Transfer

## DA16200 AT GUI Tool

When a session receives a message from a peer, the message is shown in the message window. See [Figure 32](#).




Figure 32: TCP/UDP Data Reception

### 7.3.5 Data Transfer on DPM Mode

The DA16200 GUI provides TCP/UDP sockets operation in DPM (DA16200 power-save) mode. See [Figure 33](#).




Figure 33: DPM Mode Setting

- **DPM Button:** DPM mode Start/End
- **DPM\_STATUS:** DPM state (Disabled / DPM init... / DPM Sleep / DPM wake-up)
- **Sleep Button:** DA16200 returns to DPM sleep state (only available DPM wake-up state)

To initiate TCP/UDP sockets in DPM mode:

1. Open sockets user wants to.
2. Click the **DPM** button to start DPM mode.
3. After all sockets are ready in DPM mode, the **DPM\_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a TCP or UDP messages from a peer, it is shown in the message window like in [Figure 32](#).

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM wake-up".
2. Select the session to send, type a message, and click the **Send** button.
3. After sending messages, click the **Sleep** button. The **DPM\_STATUS** will change to "DPM sleep".

To exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM\_STATUS** will change to "Disabled".

## DA16200 AT GUI Tool

### 7.4 MQTT Client

The DA16200 GUI tool provides data transfer functions with MQTT protocol. Before messages are sent with this tool, connect the DA16200 to an access point as shown in Section 7.1. Click the **MQTT Client** tab.

#### 7.4.1 Configuration

Before a connection is made to an MQTT broker, set the required fields for the connection information. See Figure 34.

The screenshot shows the MQTT Client configuration interface. It features a 'Connect' button and a close 'X' button. The 'Broker' section includes fields for IP address (1) and port number (2). The 'Keep-Alive Period' is set to 3600 seconds (5). The 'Login' section has fields for ID (6) and password (7). The 'QoS' is set to 0 (8) and 'TLS' is set to 0 (9). A 'Reset All' button (10) is available. The 'Subscriber' section has a 'Topic' field (3) with '+' and '-' buttons. The 'Publisher' section has a 'Topic' field (4) and a 'Save' button. A large text area is provided for message content. At the bottom, there are buttons for 'DPM', 'Sleep', and 'PUBLISH'.

Figure 34: MQTT Client Tab

1. Broker IP address
2. Broker port number
3. Subscriber topics (up to 4)
4. Publisher topic
5. Sending PINGREQ cycle (second)
6. Login ID
7. Login password
8. MQTT QoS (0~2)
9. TLS use (0 or 1)
10. Reset all configuration to default

## DA16200 AT GUI Tool

When the DA16200 MQTT client succeeds to connect, the letter **X** will change to **O**. Moreover, the user can send a PUBLISH message to the broker or receive a message.

### 7.4.2 Data Exchange

To exchange a message with the broker, connect the MQTT Client.

To send a PUBLISH, type the message and click the **PUBLISH** button. See [Figure 35](#).




Figure 35: MQTT PUBLISH Transfer

When the client receives a message from the broker, the message is displayed in the message window. See [Figure 36](#).




Figure 36: MQTT PUBLISH Reception

### 7.4.3 MQTT on DPM Mode

The DA16200 GUI provides MQTT client operation in DPM mode. There is the DPM mode setting as shown in [Figure 33](#) in MQTT Client tab.

To initiate MQTT client in DPM mode:

1. After setting up, connect to a MQTT Broker.
2. Click the **DPM** button to start DPM mode.
3. After the MQTT client session is ready in DPM mode, the **DPM\_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a PUBLISH from the broker, it is shown in the message window like [Figure 36](#).

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM wake-up".
2. Type a message and click the **PUBLISH** button.
3. After sending messages, click the **Sleep** button. The **DPM\_STATUS** will change to "DPM sleep".



And to exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM\_STATUS** will change to "Disabled".

### 7.5 TLS Setting

The user can store a TLS certificate that is set with this tool for MQTT, HTTPs, CoAPs, and so on. There are three kinds of items: Root CA, Client Certificate, and Private Key.

DA16200 can only process Privacy Enhanced Mail type(.pem). To enter the certificates directly, input the text and click the **Upload** button with the TLS item selection. If this is done successfully, <Content exists> will appear in the window. See [Figure 37](#).

If the user has TLS certificate files with PEM type, click **File Search** and select the file. The text will be loaded in the window.




Figure 37: TLS Setting Tab

## DA16200 AT GUI Tool

### 8 OTP Mode Setup

To enable OTP mode:

1. Open the **OTP Mode** tab.
2. Click the **OPT Enable** checkbox
  - The current OTP data is as shown in [Figure 38](#)




Figure 38: OTP Mode

**Power calibration** and **temperature calibration** has been completed for the chipset by Dialog and it may not need to be done by the customer.

**Freq Offset cal:** the range of frequency offset calibration is 0x0 ~ 0x7F.

#### MAC Address Setup

DA16200 has 4 slots to store MAC addresses. The 1st slot is written by Dialog. The user can use 3 slots to write their own MAC address. The MAC address written in the OTP must be an even number. it is used for WLAN0 MAC address (for STA interface), and the next number is automatically used for WLAN1 MAC address (for Soft-AP interface).

To write the MAC address, give a MAC address in the first empty slot and click the **Write** button, then the new address substitutes for the previous address.

## Revision History

Revision	Date	Description
1.7	28-Mar-2022	Update logo, disclaimer, copyright.
1.6	19-Aug-2021	Applied changes to SDK folder hierarchy
1.5	06-Jan-2021	Revised as the user interface changes of the tool.
1.4	21-Aug-2020	4.3.5 Data Transfer on DPM Mode Modification 4.4.3 MQTT on DPM Mode Modification Figure 36: MQTT Client Tab Change Figure 45: Solution Explorer Tab
1.3	06-Apr-2020	TCP/UDP, MQTT, and TLS added, GUI Build added
1.2	31-Oct-2019	Finalized for publication
1.1	15-Oct-2019	Editorial review
1.0	03-Jul-2019	First Release.

---

**DA16200 AT GUI Tool**

---

**Status Definitions**

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

**RoHS Compliance**

Dialog Semiconductor's suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

---

## DA16200 AT GUI Tool

---

### Important Notice and Disclaimer

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES (“RENESAS”) PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES “AS IS” AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu

Koto-ku, Tokyo 135-0061, Japan

[www.renesas.com](http://www.renesas.com)

### Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

<https://www.renesas.com/contact/>

### Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.