

R0E521500MCU00 Release Notes - Read this before using this product -

Renesas Solutions Corp.

This document contains the information necessary for using this product. Be sure to read this before using the product.

Introduction

The R0E521500MCU00 is an MCU unit for the R8C/5x Series of Renesas 16-bit MCUs.

Product outline

This product consists of the following two products.

- (1) MCU unit: R0E521500MCU00
This is an MCU unit (board) for the R8C/5x Series.
- (2) M16C R8C E100 Emulator Software
The Included software is stored in the CD-ROM.
- M16C R8C E100 Emulator Debugger
This is a control software specifically designed for the R8C E100 Emulator to control the R0E521500MCU00 emulator.

For the Latest Information

Visit our website (URL below). Please use this website providing the latest information of Renesas tool products. Furthermore, the latest version of the included software (emulator debugger and evaluation version C compiler package) can be downloaded.

<http://www.renesas.com/tools>

Setup Guide

	<i>For details, refer to...</i>
1. Check the contents	>> "Package Components"
2. Install emulator debugger	>> "Installing the Included Software Products"
3. Register your R0E521500MCU00	>> R0E521500MCU00 User's Manual "User Registration"
4. Setup hardware and turn on the emulator	>> R0E521500MCU00 User's Manual "Chapter 2. Setup"
5. Start up the High-performance Embedded Workshop and the emulator debugger.	>> R0E521500MCU00 User's Manual "Chapter 3. Tutorial"
6. For usage of each product	>> R0E521500MCU00 User's Manual "Chapter 5. Debugging Functions"

Package Components

Check to see if your product package contains all of the following items before using the product.

1	R0E521500MCU00 MCU unit	1
2	R0E521500MCU00 Release Notes (this document)	1
	R0E521500MCU00 Release Notes (Japanese)	1
3	Repair Request Sheet (English)	1
	Repair Request Sheet (Japanese)	1
4	CD-ROM - M16C R8C E100 Emulator Software	1

If any of these items are missing or found faulty, please contact your local distributor.

Operating Environment of the Included Software Products

The operating environments of the included software products are shown below.

(1) Operating environment of the host machine (Windows® XP)

Host machine	IBM PC/AT compatibles
OS	Windows® XP 32-bit editions *1 *2
CPU	Pentium 4 running at 1.6 GHz or more recommended
Memory	1 Gbyte plus 10 times the file size of the load module or larger recommended

(2) Operating environment of the host machine (Windows Vista® or Windows® 7)

Host machine	IBM PC/AT compatibles
OS	Windows Vista® 32-bit editions *1 *3 Windows® 7 32-bit editions / 64-bit editions *1
CPU	Pentium 4 running at 3 GHz or Core 2 Duo running at 1 GHz or more recommended
Memory	2 Gbytes plus 10 times the file size of the load module or larger recommended (32-bit editions) 3 Gbytes plus 10 times the file size of the load module or larger recommended (64-bit editions)

*1 Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

*2 The 64-bit editions of Windows® XP are not supported.

*3 The 64-bit editions of Windows Vista® are not supported.

Installing the Included Software Products

After inserting the included CD-ROM into the host machine's CD-ROM drive, the installation window will open. Select the product to be installed and click "Install" button.

Before installing the software, check that the High-performance Embedded Workshop is not started up on the PC environment you use and that any Renesas emulator is not connected to the PC.

* If using Windows® 7, Windows Vista® or Windows® XP as the host machine OS, have the software installed by someone of administrator access level. Installation cannot be completed by users with lower access level status.

When a PC Running Windows Vista® Cannot Communicate with the Emulator

After connecting the E100 emulator to the host machine, power on the emulator. Then open the Device Manager and select Renesas USB Driver, and open its [Properties] dialog box. On [General] tab you can check the [Device status]. If it does not show "This device is working properly.", follow the procedure listed below to install the USB driver manually.

1. Double click dpinst.exe stored in the attached CD-ROM, in a directory:
<drive name>\e100_m16c\drivers\for_32bit\Renesas_E_Series_USB, to execute dpinst.exe.
2. You'll see a [User Account Control] dialog box titled "An unidentified program wants access to your computer" and stating "Don't run the program unless you know where it's from or you've used it before." To continue the installation, click [Allow].
- *dpinst.exe is a driver package installation utility provided by Microsoft.
3. When [Device Driver Installation Wizard] appears, click the [Next] button.
4. A dialog box appears asking "Would you like to install this device software?" Then, click the [Install] button.
5. When the driver installation is complete, click the [Finish] button on the [Device Driver Installation Wizard].

Precautions for Using the Included Software Products

Release notes are installed during the software installation. Read it before using the software product.

* Electronic manuals and release notes are included in the software package. To view electronic documents, download Adobe Reader from Adobe Systems website (<http://www.adobe.com/>). Adobe and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

To Contact Us

For technical information on this product and the emulator debugger, contact us from the following URL.

<http://www.renesas.com/inquiry>

Applicable MCU Groups

The R0E521500MCU00 is available for the R8C/5x Series MCUs by using with the following converter boards.

Converter board	Applicable MCU Groups
R0E53054ECFK60 (PLQP0048KB-A)	: R8C/54E, 54F, 54G and 54H Groups
R0E53036ACFK40 (PLQP0064KB-A)	: R8C/56E, 56F, 56G and 56H Groups

Restrictions on Using the Emulator

This product has the following restrictions. Note that these restrictions apply only when using the emulator. When using an actual MCU, check the hardware manual of the MCU. For restrictions other than listed below, check the R0E521500MCU00 User's Manual.

- (1) Note on the Processor Mode Register 0 (PM0):
The R8C/5x Group actual MCU and this product differ in the initial value of the processor mode register 0 (PM0, address 0004h).

This product: 02h
R8C/5x Group actual MCU: 00h

When using this product, be sure that bit 1 of PM0 remains "1" as initially set. If bit 1 of PM0 is cleared to "0", the emulator will become uncontrollable.
Also, when using this product, please be sure that only a bit-manipulating instruction is used for a write to bit 3 (PM03) of processor mode register 0 (PM0, address 0004h). If this bit is inadvertently written to, shut down the power to the emulator and restart.

- (2) Note on the Low-current-consumption Read Mode:
Do not stop the user program during the low-current-consumption read mode. If the user program is halted during the low-current-consumption read mode, values in the flash ROM area cannot be read correctly until the MCU is reset thereafter.
- (3) Note on Non-maskable Interrupts:
When using this product, do not use the non-maskable interrupts listed below. If one of these non-maskable interrupts contends with another interrupt, the occurrence of the intended non-maskable interrupt may delay. Note, however, that this does not apply for the actual MCU.

- (1) Watchdog timer
- (2) Oscillation stop detection
- (3) Voltage monitor 1
- (4) Voltage monitor 2

- (4) Note on Program Stoppage and Hardware Breaks:
If an operation to stop the program is performed or a hardware break occurs in the emulator debugger, be aware that the program does not stop until after the period described below ends.

- Providing that interrupts are enabled, a period from when a request for an interrupt whose priority level (selected by a register bit) is higher than the IPL is generated till when the interrupt routine is entered

Note: If the above interrupt request is for an interrupt nested in another or disabled by clearing the I flag to "0", it will take a longer time than otherwise before the interrupt routine is entered. In this case, the timing with which the program is halted is delayed that much.

Note, however, that this does not apply to software breaks.

- (5) Note on Peripheral Clock Select Register (PCLKR1):
In order to rewrite the peripheral clock select register 1 (PCLKR1, address 0000Fh) while using this product, you need to first set bit 0*1 of the protect register (PRCR, address 00007h) and bit 5*2 of the protect register (EPRR, address 0025Fh) to "1". Once the rewrite on PCLKR1 is complete, set bit 0 of PRCR and bit 5 of EPRR back to "0"*3. The actual MCU does not have the protect register EPRR, the setting of which, however, does not affect the actual operation.

*1: Bit 0 of the protect register (PRCR, address 00007h) controls whether to enable or disable writing to the PCLKR1 register on the actual MCU.

*2: Bit 5 of the protect register (EPRR, address 0025Fh) controls whether to enable or disable writing to the PCLKR1 register on this product.

*3: When using this product, note that the PCLKR1 register is rewritable if bit 5 of EPRR is "1" even if bit 0 of PRCR is "0". Make sure to set bit 5 of EPRR back to "0".

- (6) Note on the PLL Clock:
When using this product, be aware that the high-speed on-chip oscillator cannot be used as the clock source for the PLL frequency synthesizer.

- (7) Note on the Low-speed On-chip Oscillator Oscillation Stop Bit (CM14):
When the low-speed on-chip oscillator is selected for the operating clock, the low-speed on-chip oscillator oscillation stop bit (CM14, bit 4 at address 0009h) in the actual MCU is disabled from being set to "1" (= stop). In this product, however, this bit can be set to "1" (= stop).

- (8) Note on Oscillation Stop Detection at WAIT Time:
When using this product, leave oscillation stop detection turned off during WAIT mode. This is because this function may not work normally during WAIT mode.

- (9) Note on the timer RB2:
To use the output event of timer RB2 along with the event link controller (ELC) in this product, follow the procedure described below.

- (1) If interrupt handling based on timer RB2 is unnecessary, set bits 2–0 (IVL2–IVL0 bits) of TRB2IC_0 and 1 registers to 000b to disable interrupts.
- (2) Set up the DTC-related registers so that DTC transfers based on underflow of timer RB2 are executed. At this time, be sure the repeat mode is selected and that the source and destination registers are mapped to a free RAM area, etc. where they can be accessed without affecting the system.
- (3) Set bit 7 (TRBIE) of TRBIR register to "1" to enable the timer RB2 interrupt.

- (10) Note on the Pin Assignment Select Register (PMCSEL)
When the 48-pin product is selected, the values for the pin assignment select bit are different between the R8C/5x Group actual MCU and this product.

48-pin product standard pin assignment:	This product PMCSEL=000b	R8C/5x Group actual MCU PMCSEL=011b
48-pin product communication function priority pin assignment:	PMCSEL=001b	PMCSEL=100b

- (11) Note on Power Supply Voltage of the User System
To use this product, the power supply voltage range of the user system must be $2.7[V] \leq V_{CC} \leq 5.5[V]$. A voltage of 2.7 [V] or lower makes the emulator uncontrollable.