

## **RX24U Group**

Renesas Starter Kit Sample Code (CS+ for CC-RX)

## R01AN3846EJ0100 Rev.1.00

Apr 26, 2017

APPLICATION NOTE

#### Introduction

Renesas Starter Kits (RSK) are supplied as complete development systems for the selected microcontroller. The kit includes an evaluation board, portable On-Chip Debugger, and a set of peripheral sample code.

#### **Target Device**

RX24U Group

#### **Development Environment**

IDE: CS+ V5.00.00 Compiler: CC-RX v2.06.00 Hardware: Renesas Starter Kit for RX24U

#### Contents <contents header>

1.	Installation	2
2.	Opening the sample projects	2
3.	Opening the Sample Code and Source Files	3
4.	Source Code Functionality	4



#### 1. Installation

The CS+ IDE should already be installed on the user's personal computer (PC). It is assumed that the following software and versions are installed:

- Renesas CS+ Version V5.00.00
- CC-RX Tool Chain Version v2.06.00

Create a new folder, for example 'C:\Renesas\Workspace\RSK\RSKRX24U'. Copy the application note zip package 'an-r01an3846ej0100-rx24u-rsk.zip' downloaded from the website to this folder and extract it here.

#### 2. Opening the sample projects

Open CS+ from the Windows Start button by selecting 'All Programs > Renesas Electronics CS+ > CS+ for CC(RL78,RX,RH850)'.

CS+ for CC - [Start]										-	Ð	$\times$
File Edit View Project Build De	ebug Tool	Window Help										Ô
🚳 Start 🔒 📄 🗿 🐰 🖻	n m   9	@ ## ∰	AA	-	- : @r @r	- 3	1 🐻 🗅 🐂 🔘	🗩 🕞 👘 👘 🖉 🕘	CI No			
					1							
Project Tree 7 X	🖏 Start											• x
2 🕜 🙎 🗃		r Learn Abo	ut CCL								-	
		GO	We recommend	d reading the tutori ntains the informat	ial to find out what can b tion on how to effectively	edone in CS+. use CS+.					L	1
		Create No	A new project of	an be created. an also be create	d by reusing the file con	iguration registered to an	existing project.					Ē
		Create Ne	w Multi-core	Project							+	5
		Open Exis	sting Project								-	5
Drop here to open the project file(*.mtpj).		GO	Loads the proje Recent Proje 1. RSKRX24 2. RSK+RX6	cts IU_Tutorial	so be opened directly fro	m the following link.	Favorite Proj Nothing	ects				
		Open Exis	sting e² studio	/CubeSuite/	High-performan	ce Embedded Wo	orkshop/PM+ Proj	ect			-	Ē.
			The project cre	ated with e <sup>2</sup> studio	o and the old IDF can be	converted to the CS+ proi	ect					· ·
	Output											д <b>х</b>
	Program IronPyth Stack Us Update 1	figurator Plu Analyzer Plu hon Console I sage Tracer <sub>t</sub> Manager Plug	ig-ind Plug-ind -ind									^
	You can [EOF] All Mess		n Manager] dial	og to enable	these plug-ins.							~ •
F7 Open Help for S F2 Rename	F3 Fi	nd Next	F4 Replace Next	F5 Go	FE Build & Dov	mloa F7 Build Project	FB Ignore Break an	F9 Set/Delete Break	tep Over F77 S	Step In	He Jump to I	Function
											DISCO	NNECT

To open the project select 'Project > Open Project...' from the menu bar.

S+ for CC -	[Start]	
File Edit View	Project Build Debug Tool Window Help	
🕅 Start 🔒	Create New Project	
	🔀 Open Project	
Project Tree	Favorite Projects	•



#### Select Tutorial project as an example.

Navigate to 'C:\Renesas\Workspace\RSK\RSKRX24U\Tutorial' folder and select the file 'RSKRX24U\_Tutorial.mtpj'. Click <Open>.

🚳 Open Project								×		
← → ~ ↑ 🛄 > This PC > Local Disk (C:) > Wokspace > RSK > RSKRX24U > Tutorial > 🗸 👌 Search Tutorial										
Organize 🔻 New folder								•		
		^	Name	Date modified	Туре		Size			
RSK			cg_src	4/26/2017 1:16 PM	File fold	ler				
RSKRX24U			doc	4/26/2017 1:16 PM	File fold	ler				
Application			RSKRX24U_Tutorial.mtpj	3/27/2017 8:26 PM	MTPJ Fi	le	8,998 KI	В		
Async_Serial										
Low_Power_Mode		RX224U_Tutorial.mtpj       Vame         Date modified       Type         Size       4/26/2017 1:16 PM         File folder       60 c         W       712017 8:26 PM         MTPJ File       8,998 KB								
System_Input_Captu	ure			Search Tutorial Search Tuto						
Timer_PWM										
📙 Tutorial		~								
— File name:	RSKRX24U_Tutorial.mtpj				~	-				
						Open				

#### 3. Opening the Sample Code and Source Files

Once the Tutorial project is open, the source code and all dependent files can be opened in the editor by expanding the folders in the 'Project Tree' and double clicking the files listed. Files are grouped according to type. A number of separate projects are provided. Each project contains sample code for a specific peripheral.

RSKRX24U_Tutorial - CS+ for CC - [Project ]	ree]									-	٥	×
File Edit View Project Build Debug Tool	Window H	elp										Ô
🚳 Start   退 📄 🗿 🐰 🐚 🖄 🕬	○ # #	an a	<b>-</b> 100%	- 🙀 🦙 Debug	- 1	🔋 🖓 🗣 👘 🔘	D 14) 🔞   9	a ça 🖕 👗				
💋 Solution List 👘 🥅 💭 🖳 🗔												
Project Tree 4	< 📝 r cq r	main.c										• x
2 🕜 🙎 🔳		🗈 🤉 🔊 🛛 Colur	nns•									-
SKRX24U Tutorial (Project)       R5524UEAuFB (Microcontroller)       CGe Generator (Disigni Tool)       RX E2 Lite (Debug Tool)	Line ( ↓ 1 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 6 7 8 9 10 11 12 12 12 12 12 12 12 12 13 14 15 16 17 16 10 10 10 10 10 10 10 10 10 10	<pre>/* DISCLAIMER     DISCLAIMER     This softwar     No other use     applicable 1     THIS SOFTWAR     OR STATUTORY     NON-INFRINCE     LAW, NEITHER     INDIRECT, SP     ITS AFFILIAT     Reneass rese     of this soft     following li     http://www.r      Copyright (C     Copyright (C     Copyright (C     Copyright (C     Copyright (C     Copyright (C)     Cool-Chain     Description     Creation Dat </pre>	e is supplie s are author aws, includi E IS PROVIDE MENT. ALL S RENESAS ELE CIAL, INCII ES HAVE BEEN HAVE	Renesas Electronics Co. c rator for RX24U V1.02.0 xFB implements main functi	AKES NO INTIES O SSLY DI A ANY OF JAMAGES LITY OF make cha gree to Continent	Renesas Electro MARRANTIESREGARP F MERCHANTABILIT SCLAIMED.TO THE ITS AFFILIATED FOR ANY REASON F SUCH DAMAGES. Dupes to this sof the additional t	mics Corporation NING THIS SOFTWU Y, FINESS FOR MAXIMUM EXTENT COMPANIES SHALL ELLATED TO THIS Stware and to di- erms and conditions served.	on and is prof ARE, WHETHER I A PARTICULAR PERMITTED NO: L BE LIABLE FK SOFTWARE, EVI iscontinue the tions found by	sected under al EXPRESS, IMPLIE PURPOSE AND F PROHIBITED BY FR ANY DIRECT, EN IF RENESAS O a availability y accessing the	D		× ×
FI Open Help for P_ F2 Rename F3 F	ind Next	F4 Replace Next	F5 Go	F& Build & Downloa F7 Buil	d Project	FB Ignore Break an	F9 Set/Delete Break	FHI Step Over	F77 Step In	FH2 Ju	ump to Fu	unction
										X	DISCONI	NECT



#### 4. Source Code Functionality

Each project is specifically written to run on the appropriate RSK. However, this source code can be useful as an example of peripheral initialization even without the RSK.

Each project includes a Description.txt file that describes the functionality of that sample. There will also be a C source file that includes "main" in the name, for example "r\_cg\_main.c". This source file includes the C function main().



#### Website and Support

Renesas Electronics Website <u>http://www.renesas.com/</u>

#### Inquiries

http://www.renesas.com/contact/

#### Product Information

https://www.renesas.com/rskrx24u

All trademarks and registered trademarks are the property of their respective owners.



## **Revision History**

		Description						
Rev.	Date	Page	Summary					
1.00	Apr 26, 2017	-	First edition issued					

#### General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

#### 1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

— The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

 The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

The reserved addresses are provided for the possible future expansion of functions. Do not
access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.
- 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

 The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

#### 1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information. 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other disputes involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawing, chart, program, algorithm, application examples 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others. 4. You shall not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics products 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below "Standard": Computers: office equipment: communications equipment: test and measurement equipment: audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment: and industrial robots etc. "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc. Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (space and undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics 6. When using the Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat radiation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions or failure or accident arising out of the use of Renesas Electronics products beyond such specified ranges 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please ensure to implement safety measures to guard them against the possibility of bodily injury, injury or damage caused by fire, and social damage in the event of failure or malfunction of Renesas Electronics products, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures by your own responsibility as warranty for your products/system. Because the evaluation of microcomputer software alone is very difficult and not practical, please evaluate the safety of the final products or systems manufactured by you. 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please investigate applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive carefully and sufficiently and use Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations. 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall not use Renesas Electronics products or technologies for (1) any purpose relating to the development, design, manufacture, use, stockpiling, etc., of weapons of mass destruction, such as nuclear weapons, chemical weapons, or biological weapons, or missiles (including unmanned aerial vehicles (UAVs)) for delivering such weapons, (2) any purpose relating to the development, design, manufacture, or use of conventional weapons, or (3) any other purpose of disturbing international peace and security, and you shall not sell, export, lease, transfer, or release Renesas Electronics products or technologies to any third party whether directly or indirectly with knowledge or reason to know that the third party or any other party will engage in the activities described above. When exporting, selling, transferring, etc., Renesas Electronics products or technologies, you shall comply with any applicable export control laws and regulations promulgated and administered by the governments of the countries asserting jurisdiction over the parties or transactions. 10. Please acknowledge and agree that you shall bear all the losses and damages which are incurred from the misuse or violation of the terms and conditions described in this document, including this notice, and hold Renesas Electronics harmless, if such misuse or violation results from your resale or making Renesas Electronics products available any third party.

Notice

11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.

12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

Refer to "http://www.renesas.com/" for the latest and detailed information

(Rev.3.0-1 November 2016)

# RENESAS

#### SALES OFFICES

#### **Renesas Electronics Corporation**

http://www.renesas.com

Renesas Electronics America Inc.<br/>2801 Soci Boulevard Santa Clara, CA 95050-2549, U.S.A.<br/>Tel: +1-408-588-6000, Fax: +1-408-588-6130Renesas Electronics Canada Limited<br/>9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3<br/>Tel: +1-905-237-2004Renesas Electronics Europe Limited<br/>Dukes Meadow, Milboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K<br/>Tel: +44-1628-585-100, Fax: +44-1628-585-900Renesas Electronics Europe GmbH<br/>Arcadiastrasse 10, 40472 Disseldorf, Germany<br/>Tel: +49-211-65030, Fax: +44-1628-585-900Renesas Electronics Chring Loo, Ltd.<br/>Room 1709, Quantum Phaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China<br/>Tel: +49-211-65030, Fax: +48-211-6303-1327Renesas Electronics (Shanghai) Co., Ltd.<br/>Toom 7.07 Quantum Phaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China<br/>Tel: +49-210-8235-1155, Fax: +86-10-8235-7679Renesas Electronics (Shanghai) Co., Ltd.<br/>Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333<br/>Tel: +86-21-2226-6088, Fax: +86-21-2226-0999Renesas Electronics Taiwan Co., Ltd.<br/>1367, No. 363, Fu Shing North Road, Taipei 10543, Taiwan<br/>Tel: +852-2456-6088, Fax: +852-2486-9022Renesas Electronics Taiwan Co., Ltd.<br/>137, No. 363, Fu Shing North Road, Taipei 10543, Taiwan<br/>Tel: +862-213-59000, Fax: +852-2475-9600Renesas Electronics Taiwan Co., Ltd.<br/>1367, No. 363, Fu Shing North Road, Taipei 10543, Taiwan<br/>Tel: +852-2475-9600, Fax: +852-2475-96070Renesas Electronics Malaysia Gan.Bdd.<br/>Did Bothemer Road, Unit #06-02 Philtux Innovation Centre, Singapore 339949<br/>Tel: +65-6213-0200, Fax: +65-6213-0300Renesas Electronics Malaysia Sdn.Bdd.<br/>Tel: +66-6213-0200, Fax: +65-62175-9670Renesas Electronics Malaysia Sdn.Bdd.<br/>Tel: +60-63