

NEC

User's Manual

EMMA2SL/P DVB-S Reference Board

Document No. S18606EE1V0UM00

Date published January 2007

© NEC Electronics 2007

Printed in Germany

The information in this document is subject to change without notice. Before using this document, please confirm that this is the latest version. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.

Legal Notes

- **The information contained in this document is being issued in advance of the production cycle for the product. The parameters for the product may change before final production or NEC Electronics Corporation, at its own discretion, may withdraw the product prior to its production.**
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special", and "Specific". The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics products before using it in a particular application.
 - "Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.
 - "Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).
 - "Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC product in your application, please contact the NEC office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

NEC Electronics Corporation

1753, Shimonumabe, Nakahara-ku,
Kawasaki, Kanagawa 211-8668, Japan
Tel: 044 4355111
<http://www.necel.com/>

[America]

NEC Electronics America, Inc.
2880 Scott Blvd.
Santa Clara, CA 95050-2554,
U.S.A.
Tel: 408 5886000
<http://www.am.necel.com/>

[Europe]

NEC Electronics (Europe) GmbH
Arcadiastrasse 10
40472 Düsseldorf, Germany
Tel: 0211 65030
<http://www.eu.necel.com/>

United Kingdom Branch

Cygnus House, Sunrise Parkway
Linford Wood, Milton Keynes
MK14 6NP, U.K.
Tel: 01908 691133

Succursale Française

9, rue Paul Dautier, B.P. 52
78142 Velizy-Villacoublay Cédex
France
Tel: 01 30675800

Sucursal en España

Juan Esplandiú, 15
28007 Madrid, Spain
Tel: 091 5042787

Tyskland Filial

Täby Centrum
Entrance S (7th floor)
18322 Täby, Sweden
Tel: 08 6387200

Filiale Italiana

Via Fabio Filzi, 25/A
20124 Milano, Italy
Tel: 02 667541

Branch The Netherlands

Steijgerweg 6
5616 HS Eindhoven,
The Netherlands
Tel: 040 2654010

[Asia & Oceania]

NEC Electronics (China) Co., Ltd
7th Floor, Quantum Plaza, No. 27
ZhiChunLu Haidian District,
Beijing 100083, P.R.China
Tel: 010 82351155
<http://www.cn.necel.com/>

NEC Electronics Shanghai Ltd.

Room 2511-2512, Bank of China
Tower,
200 Yincheng Road Central,
Pudong New Area,
Shanghai 200120, P.R. China
Tel: 021 58885400
<http://www.cn.necel.com/>

NEC Electronics Hong Kong Ltd.

12/F., Cityplaza 4,
12 Taikoo Wan Road, Hong Kong
Tel: 2886 9318
<http://www.hk.necel.com/>

NEC Electronics Taiwan Ltd.

7F, No. 363 Fu Shing North Road
Taipei, Taiwan, R.O.C.
Tel: 02 27192377

NEC Electronics Singapore Pte. Ltd.

238A Thomson Road,
#12-08 Novena Square,
Singapore 307684
Tel: 6253 8311
<http://www.sg.necel.com/>

NEC Electronics Korea Ltd.

11F., Samik Lavied'or Bldg., 720-2,
Yeoksam-Dong, Kangnam-Ku, Seoul,
135-080, Korea Tel: 02-558-3737
<http://www.kr.necel.com/>

Table of Contents

Chapter 1	Introduction	7
1.1	Document Scope	7
1.2	Acronyms	7
1.3	References	7
1.4	Numeric Convention	8
Chapter 2	Mechanical	9
2.1	Dimensions	9
2.2	Connectors	9
2.2.1	Rear of the board	9
2.2.2	Front of the board	9
Chapter 3	Electrical	11
3.1	Operating and storage temperature range	11
3.2	Power supply	11
3.3	Si2110 DVB-S Satellite Receiver Front End	11
3.4	EJTAG and JTAG debug interfaces	11
3.5	UART interfaces	12
3.6	Smart Card interface	13
3.7	SCART Switch interface	13
3.8	Modem interface	13
3.9	Front Panel interface	13
Chapter 4	Memory implementation	15
4.1	DDR SDRAM	15
4.2	Flash	15
Chapter 5	I²C bus addresses	16
5.1	I ² C Channel 0	16
5.2	I ² C Channel 1	16

Chapter 1 Introduction

1.1 Document Scope

The EMMA2SL/P DVB-S Reference board is a hardware tool that allows the features and functionality of the EMMA2SL/P MPEG2 decoder device to be tested.

This document provides details of the hardware features and interfaces that are available on the reference board.

1.2 Acronyms

EMMA	Enhanced Multi Media Architecture
MPEG	Motion Picture Experts Group
DVB-S	Digital Video Broadcasting Satellite
LNB	Low Noise Block
VCR	Video Cassette Recorder
SCART	Syndicat des Constructeurs d'Appareils Radiorécepteurs et Téléviseurs
TV	Television
CVBS	Composite Video and Blanking Signal
Y/C	Luminance/Chrominance (S-Video format)
Red Green Blue	Red Green Blue
SP/DIF	Sony Philips Digital Interface
DC	Direct Current
GND	Ground
UART	Universal Asynchronous Receiver Transmitter
FUART	Fast Universal Asynchronous Receiver Transmitter
RX	Receiver
TX	Transmitter
IR	Infra-Red
IC	Integrated Circuit
ISO	International Standards Organisation
AC	Alternating Current
EJTAG	Enhanced Joint Test Action Group interface
JTAG	Joint Test Action Group interface
PC	Personal Computer
DAC	Digital to Analogue Converter
I ² C	Philips serial bus 2 wire protocol

1.3 References

Latest reference board schematics: [nec_stb_v2.2_20070111.pdf](#).

1.4 Numeric Convention

Hexadecimal	0XXXXXXXX
Binary	'XX'
Decimal	XXXX
Mega Byte	XXMB
Mega Bit	XXMb

Chapter 2 Mechanical

2.1 Dimensions

The EMMA2SL/P DVB-S Reference board is the size of a typical set top box. Static electricity handling precautions should be followed when handling the board. Figure 1 shows the layout of the board.

2.2 Connectors

2.2.1 Rear of the board

F Type Dish Input

The satellite dish input is provided via a standard 'F Type' connector. The board can provide full LNB power switching for polarity and band.

Modem

An RJ11 connector is provided for telephone line connection to the modem.

VCR SCART

A 21-pin VCR SCART is provided that supports CVBS & Y/C video output from EMMA2SL/P and RGB video switching.

TV SCART

A 21-pin TV SCART is provided that supports RGB video output from EMMA2SL/P.

Coaxial SP/DIF

SP/DIF output from EMMA2SL/P is supported via a phono connector.

Power

The power jack on the rear of the board must be supplied with 12V DC. Note that the centre pin is +12V and the outer core is GND.

2.2.2 Front of the board

Debug UARTs

There are 2 debug UART headers provided on the board. J3000 provides a full UART pin out and J3001 provides an RX/TX only UART. Note that external RS-232 level converters are required for the UARTs as this is not provided by the board.

Push buttons

There are 4 push buttons provided; S301, S302, S303, S304, their functions are plus, minus, standby and enter respectively.

IR receiver

An IR receiver IC is provided and is connected to the IR input on EMMA2SL/P.

Smart Card connector

A smart card connector is provided for ISO compliant smart cards. The smart card connector is connected to Smart Card Interface 0 on EMMA2SL/P.




Figure 2-1 Reference board layout

Chapter 3 Electrical

3.1 Operating and storage temperature range

The ambient operating temperature range of the reference board is 0 to 50°C.

3.2 Power supply

The reference board is powered using the provided external AC-DC power supply which is 12V DC output.

3.3 Si2110 DVB-S Satellite Receiver Front End

The DVB-S input is provided by a Silicon Laboratories Si2110 device with full LNB control (schematic reference Si2110 U100). The transport stream output from the Si2110 device is directly connected to the parallel transport stream input on the EMMA2SL/P device.

3.4 EJTAG and JTAG debug interfaces

Connector J300 is an EJTAG-compliant debug interface with the following pin out:

Pin	Description	Pin	Description
1	TARGET RESET	2	GROUND (0V)
3	TARGET DATA IN	4	GROUND (0V)
5	TARGET DATA OUT	6	GROUND (0V)
7	TARGET MODE SELECT	8	GROUND (0V)
9	TARGET CLOCK	10	GROUND (0V)
11	SYSTEM RESET	12	Not used
13	DEVICE INTERRUPT	14	3.3 V

Connector J301 is a JTAG debug interface with the following pin out:

Pin	Description	Pin	Description
1	JTAG CLOCK	2	GROUND (0V)
3	JTAG DATA OUT	4	V _{CC} (+ 3.3 V)
5	JTAG MODE SELECT	6	Not used
7	JTAG RESET	8	Not used
9	JTAG DATA IN	10	GROUND (0V)

Jumper JP3000 is used to set the EMMA2SL/P RDATA13 strap pin, which selects EJTAG or JTAG mode. When JP3000 is in the left position, JTAG mode is selected. When JP3000 is in the right position, EJTAG mode is selected.

3.5 UART interfaces

J3000 is wired as a full FUART and is connected to EMMA2SL/P FUART1B (Alternate Mode 15). The pin out of J3000 is compatible with a standard PC serial port adaptor (9 way D male 1:1 wiring). J3000 has the following pin out:

Pin	Description	Pin	Description
1	DCD	2	RXD
3	TXD	4	DTR
5	GROUND (0V)	6	DSR
7	RTS	8	CTS
9	RI	10	Not used

Note In order to use FUART1B via J3000, resistors R5000-R5005 must be removed from the board.

J3001 is wired as a RX/TX only FUART and is connected to EMMA2SL/P FUART0 (Alternate Mode 13). The pin out of J3001 is compatible with a standard PC serial port adaptor. J3001 has the following pin out:

Pin	Description	Pin	Description
1	Not used	2	RXD
3	TXD	4	Not used
5	GROUND (0V)	6	Not used
7	Not used	8	Not used
9	Not used	10	Not used

Note For both UARTs no level translation is provided on the reference board. External RS-232 level converters are required. 1 external RS-232 level converter and 1 serial port adaptor cable are supplied with the reference board.

3.6 Smart Card interface

The Smart Card interface is provided by a Philips TDA8024 device (schematic reference U304). The clock to the TDA8024 device can be isolated via tri-state buffer U3000. EMMA2SL/P PPORT32 (SM0_CCTR) controls the enabling and disabling of the tri-state buffer. When PPORT32 is LOW the clock is gated from the TDA8024 device and when HIGH the clock is supplied to the TDA8024 device. The TDA8024 device is interfaced with EMMA2SL/P Smart Card Interface 0 (Alternate Mode 7). The clock frequency selection pins on the TDA8024 device (pins 1 & 2) may be controlled via EMMA2SL/P PPORT30 & PPORT31 respectively (CLK_DIV1, CLK_DIV2). By default CLK_DIV1 and CLK_DIV2 are set to '10'.

3.7 SCART Switch interface

The SCART Switch interface is provided by a AKM AK4705 device (schematic reference U400). This device provides the video switching and audio DAC conversion. The interrupt signal from the AK4705 device is connected to EMMA2SL/P PPORT18 (AV_INT). The power down control to the AK4705 device is controlled by EMMA2SL/P PPORT19 (AV_ONOFF), and is disabled (LOW) by default.

3.8 Modem interface

The Modem interface is provided by a Silicon Laboratories Si2434 device (U500), which can operate in V.90, V.34, V.32BIS, V.22BIS modes. The interrupt signal from the Si2434 device is connected to EMMA2SL/P PPORT21 (MODEM_INT). The Escape pin (online/offline) on the Si2434 device is controlled by EMMA2SL/P PPORT20 (MODEM_ONOFF).

3.9 Front Panel interface

4 switches and a front panel header are implemented on the reference board, which are controlled via spare EMMA2SL/P PPORT signals. The following table lists the PPORTs and their functions:

PPORT	Signal	Function
PPORT24	LED_RED	Red LED control
PPORT25	LED_GREEN	Green LED control
PPORT26	STANDBY_SW	Standby switch
PPORT27	ENTER_SW	Enter switch
PPORT28	PLUS_SW	Plus switch
PPORT29	MINUS_SW	Minus switch

The following table shows the pin out of the front panel connector J302:

Pin	Description	Pin	Description
1	IR_IN	2	STANDBY_SW
3	SCK	4	ENTER_SW
5	SDOUT	6	PLUS_SW
7	Not used	8	MINUS_SW
9	Not used	10	LED_RED
11	Not used	12	LED_GREEN

Chapter 4 Memory implementation

4.1 DDR SDRAM

An Elpida EDD1216AATA-6B-E device provides 128 Mbit (16 MBytes) of DDR SDRAM memory operated in 16-bit mode.

4.2 Flash

A Spansion GL032A90FF device provides 32 Mbit (4 MBytes) of flash memory operated in 16-bit mode.

Chapter 5 I²C bus addresses

5.1 I²C Channel 0

The following table lists the I²C devices and their corresponding I²C address for EMMA2SL/P I²C Channel 0:

Device	I ² C address
X24128 16K x 8 E2PROM (U306)	0xA0
AK4705 SCART switch (U400)	0x22

5.2 I²C Channel 1

The following table lists the I²C devices and their corresponding I²C address for EMMA2SL/P I²C Channel 1:

Device	I ² C address
Si2110 DVB-S Satellite Receiver	0xD0