

Precautions on Using Flash Development Toolkit

READ this document before using .this toolkit
KEEP the document handy for future reference.

1. The action when the FDT sends "Timeout error"

(1) When you use the FDT with the following conditions, you may get "Timeout error"

- Using low performance and small RAM PC
- Using upload function
- Using verify function after programming the flash data
- At the beginning of adjustment of baud rate

Please change baud rate to lower rate, when you get this error.

(2) When you get a message "ERROR : Error while reading timed response"
at the connection to a device, please change baud rate to lower rate.

2. Setting of Project Properties

When you change baud rate, frequency or other values, please close the project properties window. Closing the window makes changed values effective.

3. Selection of 1200bps communication

FDT supports only H8/38024F device with 1200bps communication speed.

Please don't select 1200bps communication speed with other devices.

4. Connection with an adapter board(Flash Development Module)

When a target device is a USB boot product (e.g. H8S/2215UF), connection with an adapter board(Flash Development Module) cannot be performed.