### Old Company Name in Catalogs and Other Documents

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <a href="http://www.renesas.com">http://www.renesas.com</a>

April 1<sup>st</sup>, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<a href="http://www.renesas.com">http://www.renesas.com</a>)

Send any inquiries to http://www.renesas.com/inquiry.



#### Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights
  of third parties by or arising from the use of Renesas Electronics products or technical information described in this document.
  No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights
  of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



# PCA7429G02

User's Manual

PROM Programming Adapter for M37272E8SP/ M37272EFSP

- Microsoft, MS, MS-DOS, Windows and Windows NT are registered trademarks of Microsoft Corporation.
- IBM, AT, PS/2 and OS/2 are registered trademarks of International Business Machines Corporation.
- IC61-080-081, IC61-080-046 and IC61-080-079 are products of Yamaichi Electronics Co., Ltd.
- AXS4803M19 and AXS4802M1 are products of Matsushita Electric Works, Ltd.
- HQPACK, NQPACK, TQPACK, YQPACK, YQSOCKET and YQ-Guide are products of Tokyo Eletech Corporation.

#### Keep safety first in your circuit designs!

Renesas Technology Corporation and Renesas Solutions Corporation put the maximum effort into making semiconductor products better
and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal
injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate
measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any
malfunction or mishap.

#### Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection of the Renesas Technology product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation, Renesas Solutions Corporation or a third party.
- Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation and Renesas Solutions Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors. Please also pay attention to information published by Renesas Technology Corporation and Renesas Solutions Corporation by various means, including the Renesas home page (http://www.renesas.com).
- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation and Renesas Solutions Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation or Renesas Solutions Corporation for further details on these materials or the products contained therein.

#### Precautions to be taken when using this product

- This product is a development supporting unit for use in your program development and evaluation stages. In mass-producing your program you have finished developing, be sure to make a judgment on your own risk that it can be put to practical use by performing integration test, evaluation, or some experiment else.
- In no event shall Renesas Solutions Corporation be liable for any consequence arising from the use of this product.
- Renesas Solutions Corporation strives to renovate or provide a workaround for product malfunction at some charge or without charge.
   However, this does not necessarily mean that Renesas Solutions Corporation guarantees the renovation or the provision under any circumstances.
- This product has been developed by assuming its use for program development and evaluation in laboratories. Therefore, it does not fall
  under the application of Electrical Appliance and Material Safety Law and protection against electromagnetic interference when used in
  Japan.

Renesas Tools Homepage http://www.renesas.com/en/tools

### **Contents**

1. Precautions for Safety	4
1.1 Safety Symbols and Meanings	4
2. Introduction	6
2.1 Things to Check When Unpacking	6
3. Specifications	7
4. How to Write the Program	8
4.1 Programming Procedure	8
4.2 Attaching Adapter to PROM Programmer	9
4.3 Setting Jumper Switches	10
4.4 Inserting MCU into Adapter	10
4.5 Precautions When Handling Adapter	11
4.6 Setting Programming Area	11
5. Recommended PROM Programmers	12
6. Memory Map	13
7. How to Request for Support	14

## To use the product properly

### **Precautions for Safety:**



- Both in this User's Manual and on the product itself, several icons are used to insure proper handling of this product and also to prevent injuries to you or other persons, or damage to your properties.
- The icons' graphic images and meanings are given in "Chapter 1. Precautions for Safety" (page 4). Be sure to read this chapter before using the product.

### **Chapter 1. Precautions for Safety**

In both the user's manual and on the product itself, several icons are used to insure proper handling of this product and also to prevent injuries to you or other persons, or damage to your properties.

This chapter describes the precautions which should be taken in order to use this product safely and properly. Be sure to read this chapter before using this product.

#### 1.1 Safety Symbols and Meanings



If the requirements shown in the "WARNING" sentences are ignored, the equipment may cause serious personal injury or death.

If the requirements shown in the "CAUTION" sentences are ignored, the equipment may malfunction.

It means important information on using this product.

In addition to the three above, the following are also used as appropriate. \( \sum \) means WARNING or CAUTION.

Example: A CAUTION AGAINST AN ELECTRIC SHOCK means PROHIBITION.

Example: (S) DISASSEMBLY PROHIBITED

means A FORCIBLE ACTION.

Example: **CABLE FROM THE RECEPTACLE.** 

The following pages describe the symbols "WARNING", "CAUTION", and "IMPORTANT".

### **⚠ WARNING**

### **Warnings for Use Environment:**



- This equipment is to be used in an environment with a maximum ambient temperature of 35°C. Care should be taken that this temperature is not exceeded.
- Select the proper programming mode of the PROM programmer.

### **CAUTION**

#### **Cautions to Be Taken for This Product:**



- Do not disassemble or modify this product. Disassembling or modifying this product can cause damage. Disassembling and modifying the product will void your warranty.
- Use caution when handling this product. Be careful not to apply a mechanical shock such as falling.
- Do not directly touch the connector pins of this product.
- Be careful with the static electricity when handling this product and the MCU.

### When not using this product for a long time:

- (1) Attach the connector pins of this product to the conductive sponge.
- (2) Put it into a conductive polyvinyl, and keep it in the package case shipped from the factory.
- (3) Store it in the place where humidity and temperature are low and direct sunshine does not strike.

### **IMPORTANT**

### When Using The Product:

- Attach this product to the IC socket on the PROM programmer properly.
- Insert the MCU to the IC socket of this product properly.
- When inserting and pulling out the MCU, be sure to keep the IC socket side above and horizontal.
- Be sure to set the programming area according to your PROM programmer.
- Do not use the PROM programmer's device identification code readout function.

### 2. Introduction

This product is a PROM programming adapter for 8-bit microcomputers of 7200 Series. The adapter is a tool that can be used to write a program into internal ROM of microcomputers using a commercially available PROM programmer.

This manual describes the specifications and operational procedures of PCA7429G02.

Figure 2.1 shows the external view of the PCA7429G02 and its constituent parts.




Figure 2.1 External view and constituent parts of PCA7429G02

### 2.1 Things to Check When Unpacking

This product consists of following parts. Check to see that it contains all of the components shown in Table 2.1 below.

Table 2.1 Contents

Main unit	PCA7429G02	
Connector	PCA7402E (32-pin)	
User's manual	PCA7429G02 User's Manual (This manual)	

If any part is missing or there is any doubt about your product package, contact your local distributor.

## 3. Specifications

Table 3.1 lists specifications of the PCA7429G02.

Table 3.1 Specifications of PCA7429G02

MCU type		M37272E8SP, M37272EFSP		
Operating clock frequency		8MHz (Supplied by the ceramic oscillator mounted on the adapter)		
Power supply		Supplied from V <sub>CC</sub> of PROM programmer		
MCU socket		IC59-4206-G4 (Yamaichi Electronics Co., Ltd.)		
Board configuration	PCA7429G02	Board to insert the programmable MCU (IC socket is mounted on this board.)		
	PCA7402E	Board to connect to the PROM programmer (Standard 32-pin pin-header is mounted on it.)		

### 4. How to Write the Program

This chapter describes procedures you need to follow when writing a program. For details on how to operate the PROM programmer, refer to the user's manual included with the PROM programmer.

#### 4.1 Programming Procedure

Follow procedures (1) to (8) to write a program.

(1) Read the program.

Read the program into the PROM programmer.



(2) Attach the adapter to the PROM programmer. (see section 4.2)



(3) Set the jumper switch (SW1). (see Section 4.3)



(4) Insert the MCU into the adapter. (see section 4.4)



(5) Set the programming area. (see section 4.6) \*1

Using the PROM programmer, set the programming area of MCU.



(6) Check to erase the program area. \*2

Using the PROM programmer's erase check function, check whether data can be written into the MCU's program area.



(7) Write the program into the MCU. \*2

Write the program into the program area of the MCU using the PROM programmer.



(8) Check to verify the program area. \*2

Check to verify the program area of the MCU using the PROM programmer. Check whether the program is written into the MCU correctly.

#### Notes:

- \*1 Be sure to set the programming area. Otherwise the mode's shift to the programming mode may not be performed successfully. The erase check function etc. may not also be performed completely.
- \*2 For some PROM programmers, steps (6) to (8) are automatically performed.

### 4.2 Attaching Adapter to PROM Programmer

As shown in Figure 4.1, attach the adapter's bottom board (PCA7402E) to the IC socket of PROM programmer, with the pin No. 1 of the adapter matched to the pin No. 1 of the IC socket.

Be careful when attaching to the PROM programmer because incorrect insertion can cause fatal damage to the MCU.




Figure 4.1 Attaching adapter to PROM programmer

#### 4.3 Setting Jumper Switches

Switch settings for SW1 is shown in Table 4.1 and Figure 4.2 below.

Table 4.1 Switch settings for SW1

MCU type name	SW1
M37272E8SP	E8
M37272EFSP	EF




Figure 4.2 Switch settings for SW1

#### 4.4 Inserting MCU into Adapter

As shown in Figure 4.3 insert the MCU into the IC socket, with the pin No. 1 of the MCU matched to the pin No. 1 of the IC socket on the adapter.

Be careful when inserting the MCU because incorrect insertion can cause fatal damage to the MCU.




Figure 4.3 Inserting MCU

### 4.5 Precautions When Handling Adapter

Don't touch the connector in the IC socket and the pins on the PROM programmer connector. Otherwise it can cause an electrical insulation failure because of dirt.

When not using, attach the connector pins of this product to the conductive sponge as it was shipped from the factory.

### 4.6 Setting Programming Area

Always be sure to specify the programming area before writing the program into the MCU. This is also required for devices programmed using a PROM programmer.

Table 4.2 Programming Areas

MCU type name	MCU area	PROM programmer		ROM area
	WCO area	Device	Programming area	of MCU
M37272E8SP	OSD ROM area	- M5M27C101 -	1400 <sub>16</sub> : 3BFF <sub>16</sub>	1400 <sub>16</sub> : 3BFF <sub>16</sub>
	Internal ROM area		8000 <sub>16</sub> : FFFF <sub>16</sub>	8000 <sub>16</sub> : FFFF <sub>16</sub>
M37272EFSP	OSD ROM area		11400 <sub>16</sub> : 13BFF <sub>16</sub>	11400 <sub>16</sub> : 13BFF <sub>16</sub>
	Internal ROM area		1000 <sub>16</sub> : FFFF <sub>16</sub>	1000 <sub>16</sub> : FFFF <sub>16</sub>

## 5. Recommended PROM Programmers

The PROM programmers listed in Table 5.1 are recommended for the adapter. Using the actual product, we have verified that these PROM programmers can be used to write programs without problem. Nonconformity occurred by using other PROM programmers can not be supported. For the latest type of the PROM programmer, please contact the manufacturer to confirm whether it can be used for your product.

Table 5.1 Recommended PROM programmers

Manufacturer	Type name	Device	Programming voltage (VPP)	
Advantest	R4945	M5M27C101	12.5V	
	R4945A	mode	12.50	

## 6. Memory Map

Figures 6.1 and 6.2 show the MCU and the PROM programmer memory maps (programming areas).




Figure 6.1 Memory map (M37272E8SP)





Figure 6.2 Memory map (M37272EFSP)

### 7. How to Request for Support

After checking this manual, fill in the following information and email to your local distributor.

For prompt response, please specify the following information:

- (1) Contact address
  - Company name
  - Department
  - Responsible person
  - Phone number
  - Fax number
  - E-mail address
- (2) Product information
  - Name of the programming adapter
  - Serial number
  - Date of purchase
  - Target MCU
  - Symptoms (Fails blank check/Cannot write a program/Fails verification etc.)
  - Detailed symptoms
  - How often does the problem occur? (2 out of 10 etc.)
  - When did the problem start to occur? (Since purchase/Used to work correctly)
  - Type name of the PROM programmer (Advantest R4945A etc.)
  - Specified device when writing to PROM (M27C101 etc.)
  - Specified programming area when writing to PROM
  - Switch settings of the adapter when writing to PROM



## PCA7429G02 User's Manual

