

■Renesas Flash Driver and EEPROM Emulation Software Target MCU List for RL78

2025/12
R20UT5631EJ0100

- This list is a compilation of the target MCUs of the RL78 family Renesas Flash Driver and EEPROM Emulation Software.
RFD and EES can be used with the target MCUs in this list.
The items [R-x] ([R-1], [R-2], etc.) in the list are items used in RFD and EES.
For details, refer to the user's manual of the target software.
- RFD and EES cannot be used on MCUs other than those listed in the "Target MCUs".
- RL78/x1x (RL78/G1x, and RL78/F1x, and ...etc.) products cannot use RFD RL78 Type 0x and EES RL78 Type 0x.
For the target flash libraries of RL78/x1x, see the self RAM List (R20UT2944).

Target Software: Renesas Flash Driver RL78 Type 01
EEPROM Emulation Software RL78 Type 01

Target MCUs

MCU Group	Code Flash memory		User RAM		Data Flash memory		[R-1]	[R-2]	[R-3]	[R-4]	[R-5]	[R-6]	[R-7]	[R-8]	Target MCU name
	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	RAM Start Address	ROM End Address 1	ROM End Address 2	Data Flash End Address	OCD_ROM	Trace_RAM	END_BLOCK	CATEGORY	
RL78/G22	32K	0x00000 - 0x07FFF	4K	0xFE00 - 0xFFEF	2K	0xF1000 - 0xF17FF	0xFE00	0x07FFF	-	0xF17FF	0x07E00	0xFF300	16	01	R7F102GxC (x = 4, 6, 7, 8, A, B, C, E, F, G)
	64K	0x00000 - 0x0FFFF	4K	0xFE00 - 0xFFEF	2K	0xF1000 - 0xF17FF	0xFE00	0x0FFFF	-	0xF17FF	0x0FE00	0xFF300	32	01	R7F102GxE (x = 4, 6, 7, 8, A, B, C, E, F, G)
RL78/G23	96K	0x00000 - 0x17FFF	12K	0xFC00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xFC00	0x0FFF	0x17FFF	0xF2FFF	0x17E00	0xFD300	48	01	R7F100GxF (x = A, B, C, E, F, G, J, L)
	128K	0x00000 - 0x1FFFF	16K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x1FFFF	0xF2FFF	0x1FE00	0xFC300	64	01	R7F100GxG (x = A, B, C, E, F, G, J, L, M, P)
	192K	0x00000 - 0x2FFFF	20K	0xFA00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xFA00	0x0FFF	0x2FFFF	0xF2FFF	0x2FE00	0xFB300	96	01	R7F100GxH (x = A, B, C, E, F, G, J, L, M, P)
	256K	0x00000 - 0x3FFFF	24K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x3FFFF	0xF2FFF	0x3FE00	0xFA300	128	01	R7F100GxJ (x = A, B, C, E, F, G, J, L, M, P, S)
	384K	0x00000 - 0x5FFFF	32K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x5FFFF	0xF2FFF	0x5FE00	0xF8300	192	01	R7F100GxK (x = F, G, J, L, M, P, S)
	512K	0x00000 - 0x7FFFF	48K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x7FFFF	0xF2FFF	0x7FE00	0xF4300	256	01	R7F100GxL (x = F, G, J, L, M, P, S)
	768K	0x00000 - 0xBFFFF	48K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0xBFFFF	0xF2FFF	0xBFE00	0xF4300	384	01	R7F100GxN (x = F, G, J, L, M, P, S)
RL78/G24	64K	0x00000 - 0x0FFFF	12K	0xFC00 - 0xFFEF	4K	0xF1000 - 0xF1FFF	0xFC00	0x0FFF	-	0xF1FFF	0xFE00	0xFD300	32	02	R7F101GxE (x = 6, 7, 8, A, B, E, F, G, J, L)
	128K	0x00000 - 0x1FFFF	12K	0xFC00 - 0xFFEF	4K	0xF1000 - 0xF1FFF	0xFC00	0x0FFF	0x1FFFF	0xF1FFF	0x1FE00	0xFD300	64	02	R7F101GxG (x = 6, 7, 8, A, B, E, F, G, J, L)

Target Software: Renesas Flash Driver RL78 Type 11
EEPROM Emulation Software RL78 Type 11

Target MCUs

MCU Group	Code Flash memory		User RAM		Data Flash memory		[R-1]	[R-2]	[R-3]	[R-4]	[R-5]	[R-6]	[R-7]	—	Target MCU name
	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	RAM Start Address	ROM End Address 1	ROM End Address 2	Data Flash End Address	OCD_ROM	Trace_RAM	END_BLOCK	—	
RL78/L23	64K	0x00000 - 0x0FFFF	16K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	-	0xF2FFF	0x0FE00	0xFC300	32	-	R7F100LxE (x = F, G, J, L)
	128K	0x00000 - 0x1FFFF	16K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x1FFFF	0xF2FFF	0x1FE00	0xFC300	64	-	R7F100LxG (x = F, G, J, L, M, P)
	256K	0x00000 - 0x3FFFF	32K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x3FFFF	0xF2FFF	0x3FE00	0xF8300	128	-	R7F100LxJ (x = F, G, J, L, M, P)
	512K	0x00000 - 0x7FFFF	32K	0xF00 - 0xFFEF	8K	0xF1000 - 0xF2FFF	0xF00	0x0FFF	0x7FFFF	0xF2FFF	0x7FE00	0xF8300	256	-	R7F100LxL (x = F, G, J, L, M, P)

Target Software: **Renesas Flash Driver RL78 Type 02**
 EEPROM Emulation Software RL78 Type 02

Target MCUs

MCU Group	Code Flash memory		User RAM		Data Flash memory		[R-1]	[R-2]	[R-3]	[R-4]	[R-5]	[R-6]	[R-7]	[R-8]	Target MCU name
	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	RAM Start Address	ROM End Address 1	ROM End Address 2	Data Flash End Address	OCD_ROM	Trace_RAM	Hot plug-in	END_BLOCK	
RL78/F23	128K	0x00000 - 0x1FFFF	12K	0xFCF00 - 0xFFEFF	8K	0xF1000 - 0xF2FFF	0xFCF00	0x0FFFF	0x1FFFF	0xF2FFF	0x1FE00	0xFD300	0xFD500	128	R7F123FxG (x = B, G, L, M)
RL78/F24	256K	0x00000 - 0x3FFFF	24K	0xF9F00 - 0xFFEFF	16K	0xF1000 - 0xF4FFF	0xF9F00	0x0FFFF	0x3FFFF	0xF4FFF	0x3FE00	0xFA300	0xFA500	256	R7F124FxJ (x = B, G, L, M, P)

Target Software: **Renesas Flash Driver RL78 Type 03**
 EEPROM Emulation Software RL78 Type 03

Target MCUs

MCU Group	Code Flash memory		User RAM		Data Flash memory		[R-1]	[R-2]	[R-3]	[R-4]	[R-5]	[R-6]	[R-7]	[R-8]	Target MCU name
	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	Size (bytes)	Start/End Address	RAM Start Address	ROM End Address 1	ROM End Address 2	Data Flash End Address	OCD_ROM	Trace_RAM	Hot plug-in	END_BLOCK	
RL78/F22	128K	0x00000 - 0x1FFFF	12K	0xFCF00 - 0xFFEFF	8K	0xF1000 - 0xF2FFF	0xFCF00	0x0FFFF	0x1FFFF	0xF2FFF	0x1FE00	0xFD300	0xFD500	64	R7F122FxG (x = 7, B, G)
RL78/F25	512K	0x00000 - 0x7FFFF	40K	0xF5F00 - 0xFFEFF	16K	0xF1000 - 0xF4FFF	0xF5F00	0x0FFFF	0x7FFFF	0xF4FFF	0x7FE00	0xF6300	0xF6500	256	R7F125FxL (x = G, L, M, P)

- All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corporation without notice.
- Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.