

RENESAS TECHNICAL UPDATE

TOYOSU FORESIA, 3-2-24, Toyosu, Koto-ku, Tokyo 135-0061, Japan
Renesas Electronics Corporation

Product Category	MPU/MCU		Document No.	TN-RH8-A0004A/E	Rev.	1.00
Title	RH850/D1x Flash Memory User's Manual Change		Information Category	Technical Notification		
Applicable Product	RH850/D1x	Lot No.	Reference Document	RH850/D1x Flash Memory User's Manual: Hardware Interface (R01UH0523EJ0110 Rev.1.10)		
		All				

1. Description

There is unnecessary information on Reading the Configuration Setting Area of the user's manual.

This RENESAS Technical update will mention of them.

The following parts that are canceled with a red line are unnecessary.

6.3.18 Reading the Configuration Setting Area

When reading the configuration setting area to check the value written by "Config Program" command, set the FCUFSEL bit in the FCUFAREA register to "1". Setting the FCUFSEL bit to "1" disables reading of the user area. The software that reads the configuration setting area must be executed on the internal RAM. For the address map for the area for configuration settings, see **Table 6.5**.

~~A configuration setting "authentication ID" stored area cannot be read without SELF-ID authentication.~~




Figure 6.22 Flow of Reading of the Configuration Setting Area

2. Workaround

None.

3. Final handling

The above updates will be applied to the next revision of RH850/D1x Flash Memory User's Manual: Hardware Interface Rev.1.10.