

# **RX23T Group**

Renesas Starter Kit Sample Code for e2 studio

## APPLICATION NOTE

R01AN3139EG0100 Rev.1.00 Jan 12, 2016

## Introduction

Renesas Starter Kits (RSK) are supplied as complete development systems for the selected microcontroller. The kit includes an evaluation board, portable On-Chip Debugger, and a set of peripheral sample code.

#### **Target Device**

RX23T

#### **Development environment**

IDE: e<sup>2</sup> studio v4.0.2 Compiler: Renesas RXC v2.03.00 Hardware: Renesas Starter Kit for RX23T

#### Contents

1.	Installation	2
2.	Creating the Project Workspace	2
3.	Opening Sample Code and Source Files	7
4.	Source Code Functionality	7
5.	Website and Support	8



#### 1. Installation

This section assumes that e<sup>2</sup> studio and the Renesas RXC toolchain are already installed.

Create a new folder, for example 'C:\Renesas\Workspace\RSK\RSKRX23T'. Copy the application note zip package 'an\_r01an3139eg0100\_rx23t\_rsk.zip' downloaded from the website to this folder.

#### 2. Creating the Project Workspace

Open  $e^2$  studio by clicking the Windows Start button, select All Programs > Renesas Electronics e2 studio > Renesas e2 studio.

e <sup>2</sup>	Workspace Launcher		×
Select a w	orkspace		
	ores your projects in a folder called a workspace. orkspace folder to use for this session.		
<u>W</u> orkspace:	C:\Users\QAUser\My Documents\e2_studio\workspace		✓ <u>B</u> rowse
Use this a	s the default and do not ask again	ОК	Cancel


#### Select <OK>

r Toolchain Registry	
	Register Cancel
✓ Enable 'Toolchain integration' on startup	

In the 'Toolchain Registry' dialog select the 'Renesas Toolchains' and 'RXC v2.03.00' checkboxes. Click <Register>.



The 'Information' dialog below appears. Click <OK>.




On the 'Welcome' screen select the 'Go to the e2 studio workbench' icon as shown below.





1. Right click in the project explorer window and click <Import...>





2. The 'Import - Select' dialog will now appear. Expand the "General" folder icon, and select "Existing Projects into Workspace", then click 'Next'.

e <sup>2</sup> Import	
Select Choose import source.	Ľ
Select an import source:	
type filter text	
<ul> <li>✓ General</li> <li>Q Archive File     <li>Convert CCRX to GNURX Project     <li>Existing Projects into Workspace     <li>File System     <li>File System     <li>HEW Project     <li>Preferences     <li>Rename &amp; Import Existing C/C++ Project into Workspace     <li>Fenesas Common Project File     <li>C/C++     <li>Code Generator     <li>C/C+     <li>Code Generator     <li>CVS     <li>Install     <li>Mun/Debug     <li>Team     </li> </li></li></li></li></li></li></li></li></li></li></li></li></li></li></li></li></ul>	
(?) < <u>B</u> ack <u>N</u> ext > <u>Finish</u>	Cancel



3. The 'Import – Import Projects' dialog will now appear. Select 'Select archive file', click the <Browse> button and locate the folder created earlier 'C:\Renesas\Workspace\RSK\RSKRX23T'. Click <Finish> to import the project.

e <sup>2</sup> Import					
Import Projects Select a directory to search	for existing Eclipse pro	ijects.			
<ul> <li>Select root directory:</li> <li>Select archive file:</li> <li>Projects:</li> <li>Application (Application (Application))</li> <li>Async_Serial (Async</li> <li>Low_Power_Mode (I)</li> <li>System_Input_Captu</li> <li>Timer_PWM (Timer,</li> <li>Tutorial (Tutorial)</li> </ul>	_Serial) Low_Power_Mode) ıre (System_Input_Cap		_r01an3139eg010	0_n23t_rsk.zip	Browse Browse Select All Deselect All Refresh
Options     Search for nested project     Gopy projects into work     Hide projects that alread     Working sets     Add project to working	space dy exist in the workspa	ce			
Add project to working Working sets:	) SELS	< <u>B</u> ack	Next >	Finish	S <u>e</u> lect

4. If prompted select the checkbox to trust certificates;

e <sup>a</sup> Selection Needed	×
Do you trust these certificates?	
REE-EDC release dept; REE-EDC; Renesas Electronics Europe Gm	ьн
Select All Dese	lect All
<ul> <li>REE-EDC release dept; REE-EDC; Renesas Electronics Europe Gmb REE-EDC release dept; REE-EDC; Renesas Electronics Europe C</li> </ul>	
Details	
? ОК Са	incel




#### 3. Opening Sample Code and Source Files

Once imported into e<sup>2</sup> studio select a project from the project list in the "Project Explorer". Click the arrow next to it to expand the folder contents.

Clicking the arrow next to the 'doc' folder will show the document files. The document 'description.txt' provides a functional description of the sample.

Clicking the arrow next to the 'src' folder will show the source files.



#### 4. Source Code Functionality

Each source code project is specifically written to run on the appropriate RSK. However, this source code can be useful as an example of peripheral initialization even without the RSK.

Each sample project will contain a C source file that includes "main" in the name, for example "r\_cg\_main.c". This source file will include the C function main().



#### 5. Website and Support

Renesas Electronics Website <u>http://www.renesas.com/</u>

#### Inquiries

http://www.renesas.com/contact/

#### Support

http://www.renesas.com/rskrx23t

All trademarks and registered trademarks are the property of their respective owners.



### **Revision History**

	Date	Descript	ion	
Rev.		Page	Summary	
1.0	Jan 12, 2016		First edition.	

#### General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.
- 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

 The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access
  these addresses; the correct operation of LSI is not guaranteed if they are accessed.
- 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal.
   Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.
- 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

— The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

#### Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for
  the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use
  of these circuits, software, or information.
- Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
- \*Standard\*: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries. (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its maiority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



#### SALES OFFICES

**Renesas Electronics Corporation** 

http://www.renesas.com

Refer to "http://www.renessas.com/" for the latest and detailed information. Renesas Electronics America Inc. 2001 Scott Boulevard Samta Clara, CA 95050-2549, U.S.A. Tel: +1408-588-6000, Fax: +1408-588-6130 Renesas Electronics Canada Limited 2521 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3 Tel: +1905-237-2004 Renesas Electronics Europe Limited Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K Tel: +44-1625-855-100, Fax: +44-1628-585-900 Renesas Electronics Europe Imited Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K Tel: +44-1625-855-100, Fax: +44-128-585-900 Renesas Electronics Europe GmbH Arcadiastrasse 10, 40472 Düsseldorf, Germany Tel: +49-211-6503-0, Fax: +49-211-6503-1327 Renesas Electronics (China) Co., Ltd. Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China Tel: +86-10-2225-7155, Fax: +86-10-3225-7679 Renesas Electronics Hong Maj Co., Ltd. Unit 301. Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333 Tel: +86-21-226-0888, Fax: +86-21-226-0899 Renesas Electronics Hong Kong Limited Unit 1801.1161, 16/F., Tower 2, Grand Contury Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong Tel: +852-2265-6688, Fax: +862-2405-990 Renesas Electronics Taiwan Co., Ltd. 80 Bendemeer Road, Unit #06-102 Hyllux Innovation Centre, Singapore 339949 Tel: +856-24175-9900, Fax: +888-24175-9970 Renesas Electronics Majayais Adn.Bd. Unit 1207. Block B, Menara Amorop, Amorop Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tel: +656-21300, Fax: +665-213000 Renesas Electronics Majayais Adn.Bd. Unit 1207. Block B, Menara Amorop, Amorop Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tel: +656-213000, Fax: +60-67200, Tex: +03-07955-9510 Renesas Electronics Majaysia Sdn.Bd. No.777C, 100 Feel Road, HALLI Stage, Indianagar, Bangalore, India Tel: +65-2455-9300, Fax: +9