

RX72T Group

Renesas Starter Kit Sample Code (CS+ for CC-RX)

Introduction

Renesas Starter Kits (RSK) are supplied as complete development systems for the selected microcontroller. The kit includes an evaluation board, portable On-Chip Debugger, and a set of peripheral sample code.

Target Device

RX72T Group

Development Environment

IDE: CS+ V8.12.0 Compiler: CC-RX v3.06.00 Hardware: Renesas Starter Kit for RX72T

Contents

1.	Installation	2
2.	Opening the sample projects	2
3.	Opening the Sample Code and Source Files	3
4.	Source Code Functionality	3
5.	Website and Support	4
Rev	ision History	5



1. Installation

The CS+ IDE should already be installed on the user's personal computer (PC). It is assumed that the following software and versions are installed:

- Renesas CS+ Version V8.12.00
- CC-RX Tool Chain Version v3.06.00

Create a new folder, for example 'C:\Renesas\Workspace\RSK\RSKRX72T'. Copy the application note zip package 'an-r01an4777ej0200-rx72t-rsk.zip' downloaded from the website to this folder and extract it here.

2. Opening the sample projects

Open CS+ from the Windows Start button by selecting 'All Programs > Renesas Electronics CS+ > CS+ for CC(RL78,RX,RH850)'.

CS+ for CC - [Start]										- 0	×	١,
<u>File Edit View Project Build Deb</u>	ug <u>I</u> ool <u>\</u>	<u>V</u> indow <u>H</u> elp									Ø 6	3
🙉 <u>S</u> tart 🛃 🗐 🗿 💥 🐚	10			100% 👻 🐻 🞯		- X 6 4	h 🖲 🕑 🗠 🗑	193 Ca Ga 1				
< < < < < < < < < < < < < < < < < < <												
Project Tree 4 X	🖏 Start										-	×
2 0 2 2	Learn About CS+ We recommend reading the tutorial to find out what can be done in CS+. The tutorial contains the information on how to effectively use CS+.											
		GO GO Create New Open Existin	A new project can be A new project can al Multi-core Pro g Project Loads the project of Recent Projects	so be created by reusing the file co joct CS+. Can also be opened directly fi		-, -	avorite Projects				+	
Drop here to open the project file(*.mtpj).	Smart I	Browser	1. RSKRX72T_Tu	tona		<i></i>	Nothing					×
	Refresh			 Search in Renesas Web Sites 					Your region: An	oricac	* 🗢	
	Device: -			Search Mitchelds Web Sites					rour regioni An	Terreus		
		formation related v			RENESAS							^
					Context help in	the Smart Browser						
			~		Select any item	vou are interested in fi	e Smart Browser pushes a rom the list at left since lo	nd searches useful inform or in to MvRenesas	nation on current situa		Understood	
F1 F2	F3	ext Help 🔘 Noti	fications / User's N		ApplicationNotes	Tool News	F9	FIB Full-screen	FTI	FI2	92	•
rc rc	1.2	C1	r.a	ra	11	r a	1.2	run rull-screen	<u>EU</u>			_

To open the project select 'Project > Open Project...' from the menu bar.

OS+ for CC - [Start]								
File Edit View	Project Build Debug Tool Window Help							
🚳 Start 🛛 🛃	Create New Project							
9999	🛃 Open Project							
Project Tree	Favorite Projects							



Select Tutorial project as an example.

Navigate to 'C:\Renesas\Workspace\RSK\RSKRX72T\Tutorial' folder and select the file 'RSKRX72T_Tutorial.mtpj'. Click <Open>.

Open Project					>	<
← → × ↑ 📙 « Local Di	isk (C:) → Renesas	> Workspace > RSK > RSKRX72T >	Tutorial >	Search Tu	torial 🔎	
Organize 🔻 New folder					EE 🕶 🔟 💡	
RSK	^	Name	Date modified	Туре	Size	
RSKRX72T		doc	4/23/2019 1:34 PM	File folder		
Application		src .	4/23/2019 1:34 PM	File folder		
Async_Serial		RSKRX72T_Tutorial.mtpj	2/15/2019 10:05 AM	MTPJ File	456 KB	
Low_Power_Mode						
System_Bootloade	er					
System_Bootloade	er_Application					
System_Input_Cap	oture					
Timer_PWM						
📙 Tutorial	~					
File <u>n</u> ame:	RSKRX72T_Tutoria	l.mtpj		✓ Project F	ile (*.mtpj) V	
				<u>O</u> pe	n Cancel	

3. Opening the Sample Code and Source Files

Once the Tutorial project is open, the source code and all dependent files can be opened in the editor by expanding the folders in the 'Project Tree' and double clicking the files listed. Files are grouped according to type. A number of separate projects are provided. Each project contains sample code for a specific peripheral.

RSKRX72T_Tutorial - CS+ for CC - [Project Tree]									- 0 ×
e <u>E</u> dit <u>V</u> iew <u>P</u> roject <u>B</u> uild <u>D</u> ebug <u>T</u> ool <u>W</u> ind	ow <u>H</u> elp								🤤 🎯 i
🕵 <u>Start</u> 🔒 🗐 🗿 🐰 🐚 🖺 🔊 (२)	aa 🏨 🏨	▼ 100% ▼	🛛 🗑 🗑 Debu	•	× 6 0	h 🖲 🕑 🗠 🚳	82 Ç2 82 🕅		
🖓 🖓 🖉 🧐 🥵 🛄 💭 📮 🖓 📓	Solution List								
Project Tree 🕴 🐺 🗙	Main.c								-
O 2 2	11 10 - 2 - 2	Columner							
B-RSKRX72T Tutorial (Project)		columns.							
R5F572TKCxFB (Microcontroller)	1 =/***********	*****	******	*****	*****	******			
	2 * DISCLAIN								
						use with Renesas prod ation and is protected up			
- Program Analyzer (Analyze Tool)	5 * applicable	laws, including cop	yright laws.			1			
🖃 🎒 File						SREGARDING THIS SO			D
C Source Files						NTABILITY, FITNESS F TO THE MAXIMUM FX			(
ascii.c	9 * LAW, NEI	THER RENESAS EI	ECTRONICS CO	RPORATION NOR	ANY OF ITS AFF	ILIATED COMPANIES	SHALL BE LIABLE F	OR ANY DIRECT.	
······································						EASON RELATED TO 1	HIS SOFTWARE, EV	VEN IF RENESAS OR	1
r rsk debug.c		IATES HAVE BEEN				S. scontinue the availabilit			
r_rsk_switch.c						ns found by accessing t			
🗑 🔜 Dependencies	14 * following I								
Text Files	15 * http://www 16 *	v.renesas.com/discla	limer						
· Smart Configurator		(C) 2018 Renesas E	Electronics Corpor	ation. All rights rese	ved.				
	18		******	*****	*****	*******			
	19 =/************************************	: main.c							
	21 * Version	: 1.00							
		: R5F572TKCxFB							
	23 * Tool-Chai 24 * H/W Platfe	n : CCRX orm : RSKRX72T							
		n : This file impleme	ents main function						
	. <								
	Output								
	All Messages								
	Output @ Smart Bro	wser 🔢 Error List							
F2 F3	F4	FS	FB	F7	FB	F9	FID Full-screen	FN	FI2

4. Source Code Functionality

Each project is specifically written to run on the appropriate RSK. However, this source code can be useful as an example of peripheral initialization even without the RSK.

Each project includes a description.txt file that describes the functionality of that sample. There will also be a C source file that includes "main" in the name, for example "main.c". This source file includes the C function main().



5. Website and Support

Renesas Electronics Website http://www.renesas.com/

Inquiries

http://www.renesas.com/contact/

All trademarks and registered trademarks are the property of their respective owners.



Revision History

Description			ion
Rev.	Date	Page	Summary
1.00	Apr 23.2019	-	First edition issued.
2.00	Oct.28.2024	-	Fix the "System_BootLoader" sample project. Update development environment. -IDE: CS+ V8.12.00 -Compiler: CC-RX v3.06.00



General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power is supplied until the power is supplied until the power reaches the level at which reseting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a systemevaluation test for the given product.

Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
- Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
- 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
- Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
 "Standard". Computers: office computers office computers of the product's quality grade, as indicated below.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

- 6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
- This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note1) "Renease Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan www.renesas.com

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit: www.renesas.com/contact/.

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.