## Old Company Name in Catalogs and Other Documents

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1<sup>st</sup>, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.

#### Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anticrime systems; safety equipment; and medical equipment not specifically designed for life support.
  - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majorityowned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



# SH7145 Group

## DMA in Dual Address Mode

#### Introduction

The DMAC (Direct Memory Access Controller) is used to perform DMA data transfer from the on-chip RAM to externally connected SRAM by direct address transfer in dual address mode.

#### Target Device

SH7145F

#### Contents

1.	Specifications	. 2
	Description of Functions	
	Description of Operation	
	Description of Software	
	Flowchart	
6.	Program Listing	11

#### 1. Specifications

The DMAC (Direct Memory Access Controller) of the SH7145 is used to perform DMA transfer of data from the onchip RAM to externally connected SRAM by direct address transfer in dual address mode. The transfer request mode of the DMAC is set to auto-request, and five 32-bit data items (or a total of 20 bytes) are transferred.




Figure 1 illustrates data transfer by the DMAC; table 1 shows the DMAC settings.

Figure 1 Data Transfer Using DMAC

Table 1	DMAC	Settings
---------	------	----------

Setting Item	Description
Address mode	Dual address mode
Transfer mode	Direct address transfer mode
Transfer request	Auto-request (Transfer requests are generated by bit manipulations.)
Number of transfers	Five times (A total of 20 bytes of data is transferred.)
Bus mode	Burst mode
Transfer source address	On-chip RAM [H'FFFFE000] (Auto-incremented according to data size after transfer)
Transfer destination address	SRAM [H'00400000] allocated to CS1 space (Auto-incremented according to data size after transfer)
Transfer data size	Longword (32 bits)
Interrupt	Transfer end interrupt is enabled.



#### 2. Description of Functions

In this sample task, the DMAC is used for DMA transfer of data from the on-chip RAM of the SH7145 to external SRAM.

#### 2.1 DMAC (Direct Memory Access Controller)

Data transfer is performed in dual address mode. Figure 2 is a block diagram of DMAC module channel 0 (ch0); below, functions are explained referring to figure 2.




Figure 2 DMAC Block Diagram (ch0)

# RENESAS

- The DMAC can perform high-speed data transfer, in place of the CPU, between external devices with DACK (transfer request acknowledge signal), external memory devices, memory-mapped external devices, and on-chip peripheral modules.
- The DMAC can be activated by either an external request or a request from an on-chip module. The on-chip modules that can generate DMAC activating requests are MTU, A/D1, SCI0, and SCI1. When auto-request is set by the CHCR\_0 register, DMA transfer can be performed by the DMAC alone by setting the DE bit in CHCR\_0 to 1.
- The DMA source address register\_0 (SAR\_0) is a 32-bit register which specifies the transfer source address. SAR\_0 has a counting function that can be selected by the DMA channel control register\_0 (CHCR\_0) from among three modes: fixed, auto-increment, and auto-decrement modes. During DMA operation, SAR\_0 always indicates the next transfer source address.
- The DMA destination address register\_0 (DAR\_0) is a 32-bit register which specifies the transfer destination address. DAR\_0 has a counting function that can be selected by the DMA channel control register\_0 (CHCR\_0) from among three modes: fixed, auto-increment, and auto-decrement modes. During DMA operation, DAR\_0 always indicates the next transfer destination address.
- The DMA transfer count register\_0 (DMATCR\_0) is a 32-bit register which specifies the number of transfers. The lower 24 bits are used to specify the number of transfers while the upper eight bits of this register are always 0. When writing, the upper eight bits should always be set to 0. If the DMATCR\_0 is set to H'000000, this is recognized as the maximum value, and 16,777,216 transfers are performed. During DMAC operation, this register is auto-decremented and indicates the number of remaining transfers .
- The DMA channel control register\_0 (CHCR\_0) is a 32-bit register which specifies the operation mode, transfer method, and other parameters for channel 0.
- The DMA operation register (DMAOR) is a 16-bit register which specifies the transfer mode for the entire DMAC.



#### 3. Description of Operation

Figure 3 and table 2 describe the operation timing.




Figure 3 Operation by Direct Address Transfer in Dual Address Mode

#### Table 2 Explanation of Processing

	Software Processing	Hardware Processing
(1)	Set the DE bit in CHCR_0 to 1 after all other settings have been made (DMAC_0 operation is started.)	Output a transfer source address to the internal address bus.
(2)		Output data from the on-chip RAM to the internal data bus.
(3)	_	Output CS1, WRH and WRL signals, an address, and data to the external buses.
(4)		Increment SAR_0 and DAR_0.
(5)	_	Repeat steps (1) through (4) above until DMATCR_0 reaches 0.



#### **Description of Software** 4.

#### 4.1 **Modules**

Table 3 describes the modules used in this sample task.

#### Table 3 Description of Modules

Module Name	Label Name	Function
Main routine	main	Sets up the DMAC and pin functions, and starts transfer by the DMAC.
Transfer end interrupt routine	cmt_int	Stops DMAC operation.

#### 4.2 **Internal Registers**

Table 4 describes the internal registers used in this sample task. The settings are the values used in this sample task and are different from their initial values.

#### Table 4 Description of Internal Registers

Register				
Name	Bit	Bit Name	Setting	Function
MSTCR1				Module standby control register 1
	9	MSTP25	0	DMAC Standby Control
	8	MSTP24	0	When MSTP25 = 0 and MSTP24 = 0, the standby state
				of the DMAC is cancelled.
DMAOR			H'0001	DMAC operation register
	15 to 10		0	Reserved
	9	PR1	0	Priority Mode 1, 0
	8	PR0	0	These bits specify the priority order of channels for
				execution.
	7 to 3		0	Reserved
	2	AE	0	Address Error Flag
	1	NMIF	0	NMI Flag
	0	DME	1	DMAC Master Enable
				When DME = 1, enables operation on all channels of the
				DMAC.

# RENESAS

Register	Dit	Dit Name	O attitu a	
Name	Bit	Bit Name	Setting	Function
CHCR_0	31 to 21		H'00005434 0	DMA channel control register_0 Reserved
	20	 DI	0	Direct/Indirect Select
	20	DI	0	
				Only valid for channel 3. Invalid in this sample task because only channel 0 is used.
	19	RO	0	Source Address Reload
	10	NO	0	Only valid for channel 2. Invalid in this sample task
				because only channel 0 is used.
	18	RL	0	Request Check Level
				When RL = 0, DRAK output is active-high.
	17	AM	0	Acknowledge Mode
				When $AM = 0$ , DACK is output during data read cycles.
	16	AL	0	Acknowledge Level
				When AL = 0, DACK output is active-high.
	15	DM1	0	Destination Address Mode 1, 0
	14	DM0	1	When DM1 = 0 and DM0 = 1, the transfer destination
				address is incremented.
	13	SM1	0	Source Address Mode 1, 0
	12	SM0	1	When SM1 = 0 and SM0 = 1, the transfer source
				address is incremented.
	11	RS3	0	Resource Select 3, 2, 1, 0
	10	RS2	1	These bits specify the transfer request source.
	9	RS1	0	When RS [3, 2, 1, 0] = 0100, auto-request (DMAC
	8	RS0	0	transfer request generated by software) is selected.
	7		0	Reserved
	6	DS	0	DREQ Select
				When $DS = 0$ , external requests are detected by the low level on the $\overline{DREQ}$ pin.
	5	ТМ	1	Transmit Mode
				When TM = 1, transfers are performed in burst mode.
	4	TS1	1	Transmit Size 1, 0
	3	TS0	0	When TS [1,0] = 10, transfers are performed in longword size.
	2	IE	1	Interrupt Enable
				When IE = 1, an interrupt request is issued after the specified number of transfers have ended.
	1	TE	0	Transfer End
	I		0	Set to 1 when the specified number of transfers have
				ended.
	0	DE	0	DMAC Enable
	-		-	When auto-request is selected, transfer by the DMAC is
				started when this bit is set to 1.
BCR1			H'602F	Bus control register
	5	A1LG	1	Longword Access Setting for CS1 Space
				When A1LG = 1, CS1 space is accessed in longword.



Register				
Name	Bit	Bit Name	Setting	Function
PACRH			H'5000	Port-A control register H
				Sets port A pins to function as WRHH and WRHL.
PACRL1			H'1540	Port-A control register L1
				Sets port A pins to function as $\overline{\text{RD}}$ , $\overline{\text{WRH}}$ , $\overline{\text{WRL}}$ , and $\overline{\text{CS1}}$ .
PBCR1			H'000A	Port-B control register 1
				Sets port B pins to function as A21 and A20.
PBCR2			H'A005	Port-B control register 2
				Sets port B pins to function as A19 to A16.
PCCR			H'FFFF	Port-C control register
				Sets port C pins to function as A15 to A0.
PDCRH1			H'5555	Port-D control register H1
				Sets port D pins to function as D31 to D24.
PDCRH2			H'5555	Port-D control register H2
				Sets port D pins to function as D23 to D16.
PDCRL1			H'FFFF	Port-D control register L1
				Sets port D pins to function as D15 to D0, in combination with PDCRL2.
PDCRL2			H'0000	Port-D control register L2
				Sets port D pins to function as D15 to D0, in combination with PDCRL1.

### 4.3 RAM Usage

Table 5 describes the RAM usage in this sample task.


#### Table 5 Description of RAM

Label Name	Function	Address	Used in
Data[0-4]	Stores data for DMAC transfer. Area for storing 20 bytes (4 bytes $\times$ 5) of data	Area from H'FFFFE000 in the on-chip RAM	Main routine




#### 5. Flowchart

#### 5.1 Main Routine





### 5.2 Transfer End Interrupt Routine





#### 6. Program Listing

```
/* SH7145F Application Note
                                                         */
/*
                                                         */
/* Function
                                                         */
/* :DMAC0(Dual Address Mode)
                                                         */
/*
                                                         */
/* External input clock :12.5MHz
/* Internal CPU clock :50MHz
                                                         */
                                                         * /
/* Internal peripheral clock :25MHz
                                                         */
/*
                                                         */
/* Written 2003/12 Rev.1.0
                                                         */
#include "iodefine.h"
#include <machine.h>
/*----- Symbol Definition -----*/
           5
#define NUM
#define SRAM ADDR 0x00400000
/*----- Function Definition -----*/
void main(void);
void dmac int(void);
void dummy_f(void);
/*----- RAM allocation Definition -----*/
unsigned long Data[NUM];
/* Main Program
                                                         */
void main( void )
{
  Data[0] = 0x11111111;
  Data[1] = 0x22222222;
  Data[2] = 0x33333333;
  Data[3] = 0x44444444;
  Data[4] = 0x55555555;
                              /* Transmission data
                                                         * /
  P STBY.MSTCR1.BIT.MSTP25 = 0;
  P STBY.MSTCR1.BIT.MSTP24 = 0;
                             /* Disable DMAC standby mode
                                                         */
  // Set BSC
                                                         */
  P BSC.BCR1.BIT.A1LG = 0x1;
                             /* CS1 is long-word access
```



```
// Set pin function
P PORTD.PDCRH1.WORD = 0x5555;
P PORTD.PDCRH2.WORD = 0x5555;
P PORTD.PDCRL1.WORD = 0xFFFF;
P PORTD.PDCRL2.WORD = 0x0000;
                                         /* Set PD31-0 -> D31-0
                                                                                   */
P PORTB.PBCR1.WORD |= 0x000A;
                                          /* Set A21,A20
                                                                                   */
P PORTB.PBCR2.WORD |= 0xA005;
                                         /* Set A19-A16
                                                                                   */
P PORTC.PCCR.WORD = 0xFFFF;
                                         /* Set A15-A0
                                                                                   */
P_PORTA.PACRH.WORD |= 0x5000;
P_PORTA.PACRL1.WORD |= 0x1540;
                                         /* Set WRHH,WRHL
                                                                                   */
                                         /* Set RD,WRH,WRL,CS1
                                                                                   */
// Set DMAC
P DMAC.DMAOR.BIT.DME = 1;
                                          /* DMAC enable
                                                                                   */
*/
                                          /* Set of source address
                                                                                   */
P DMACO.DARO = SRAM ADDR;
P DMACO.DMATCRO = NUM;
                                          /* Set of times of transmission
                                                                                   */
P DMAC0.CHCR0.BIT.DE = 0;
                                         /* Clear DE bit
                                                                                   */
P DMAC0.CHCR0.LONG = 0 \times 00005434;
       // [31-21] = 0 : Reserve
       // [20] = 0 : Direct address mode
       // [19]
                = 0 : Source address in not reload
       // [18] = 0 : DRAK is high-active
       // [17] = 0 : DACK outputs is read-cycle
       // [16] = 0 : DACK is high-active
                     : Transmission address is increment
       // [15-14] = 2
       // [13-12] = 2 : Source address is increment
       // [11-8] = 4 : Auto-request
       // [7] = 0 : Reserve
                = 0
                     : DREQ is detected with falling edge
       // [6]
       // [5] = 1 : Burst mode
       // [4-3] = 2 : Transmission size is long-word
                = 1 : DEIO interrupt enable
       // [2]
       // [1] = 0
       // [0] = 0 : DMAC0 disable
P INTC.IPRC.BIT.DMAC0 = 10;
                                          /* Set DEI0 interrupt level
                                                                                   */
set_imask(0);
                                          /* Clear interrupt mask level
                                                                                   */
P DMAC0.CHCR0.BIT.DE = 1;
                                          /* DMAC transmission start
                                                                                   */
while(1);
                                          /* LOOP
                                                                                   */
```

}



/**************************************	***************************************	***************
/* Interruption Program		*/
/******	*******	********
/*********	*******	*******
/* DEI0 Interruption Program		* /
/***********	* * * * * * * * * * * * * * * * * * * *	* * * * * * * * * * * * * * * /
<pre>#pragma interrupt(dmac_int)</pre>		
<pre>void dmac_int(void)</pre>		
{		
// Transmission end process		
P_DMAC0.CHCR0.LONG &= 0xFFFFFF8;	/* Clear IE,TE,DE bit	*/
P_DMAC.DMAOR.WORD &= 0xFFFE;	/* DMAC disable	*/
; /************************************	*****	******
/* Other Interruption Program		*/
/*****	*****	********
<pre>#pragma interrupt(dummy_f)</pre>		
void dummy_f(void)		
{		
/* Other Interrupt */		
}		



## **Revision Record**

		Descript	lion	
Rev.	Date	Page	Summary	
1.00	Sep.16.04	_	First edition issued	



#### Keep safety first in your circuit designs!

**(ENESAS** 

1. Renesas Technology Corp. puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.

Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

#### Notes regarding these materials

- 1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corp. product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corp. or a third party.
- 2. Renesas Technology Corp. assumes no responsibility for any damage, or infringement of any thirdparty's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- 3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corp. without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corp. or an authorized Renesas Technology Corp. product distributor for the latest product information before purchasing a product listed herein.

The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corp. assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

Please also pay attention to information published by Renesas Technology Corp. by various means, including the Renesas Technology Corp. Semiconductor home page (http://www.renesas.com).

- 4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corp. assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
- 5. Renesas Technology Corp. semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corp. or an authorized Renesas Technology Corp. product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- 6. The prior written approval of Renesas Technology Corp. is necessary to reprint or reproduce in whole or in part these materials.
- 7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.

Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.

8. Please contact Renesas Technology Corp. for further details on these materials or the products contained therein.