

A Note on Using High-performance Embedded Workshop

Please take note of the following problem in using High-performance Embedded Workshop:

- With transferring load modules from PC to debugging platform
-

1. Product and Versions Concerned

High-performance Embedded Workshop
V.4.02.00 through V.4.04.01

2. Description

When you open the Debug menu, select Download, and then select All Download Modules or pathname of load module file to transfer load module(s) from PC to debugging platform, application errors may arise.

3. Conditions

This problem occurs if the following conditions are all satisfied when you open the Debug menu, select Download, and then select All Download Modules or pathname of load module file to transfer load module(s):

- (1) The "Run to main function on reset" check box in the Debug tab of the Options dialog box has been checked.
- (2) The "Use Disassembly source-mode as primary debug view" check box in the same tab in (1) above has also been checked.
- (3) The Disassembly window is not open.

4. Workarounds

To transfer load module from PC to debugging platform, double-click the load module file displayed in the Projects tab in the Workspace window, or use the pop-up menu that appears when you right-click the icon of the "Download modules" folder displayed in the above tab.

5. Schedule of Fixing the Problem

We plan to fix this problem in the next release of the product.

[Disclaimer]

The past news contents have been based on information at the time of publication. Now changed or invalid information may be included. The URLs in the Tool News also may be subject to change or become invalid without prior notice.

© 2010-2016 Renesas Electronics Corporation. All rights reserved.