

[Notes]

R20TS0877EJ0100
 Rev.1.00
 Oct. 01, 2022

Renesas Starter Kit+ for RZ/T2M
 USB-Serial Conversion and Quick Start Guide

Outline

When using the Renesas Starter Kit+ for RZ/T2M, note the following points.

1. Performing terminal output by USB-serial conversion
2. Quick Start Guide

1. Performing Terminal Output by USB-Serial Conversion

1.1 Applicable Products

Product name: Renesas Starter Kit+ for RZ/T2M

Part number: RTK9RZT2M0S00000BE

Serial number: 240493~240592




Figure 1: Serial No. location (CPU board solder side)




Figure 2: Serial No. location (side of the product box)

1.2 Details

If you connect CN16 of the Renesas Starter Kit+ for RZ/T2M to a PC with a USB cable to perform USB-serial conversion terminal in/output, the kit may not be recognized by the PC.




Figure 3: CN16 location

1.3 Workaround

Remove the USB cable from CN16 and reinsert it into the same port. Repeat until the kit is recognized.

2. Quick Start Guide

2.1 Applicable Products

Product name: Renesas Starter Kit+ for RZ/T2M

Part number: RTK9RZT2M0S00000BE

Serial number: 240493~240592

For the locations of the serial number, see Figure 1 and 2 above.

2.2 Details

The Quick Start Guide attached to the product is that of another product. Download the correct guide from the web page below.

<https://www.renesas.com/rskrzt2m>

Revision History

Rev.	Date	Description	
		Page	Summary
1.00	Oct.01.22	-	First edition issued

Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.

The past news contents have been based on information at the time of publication. Now changed or invalid information may be included.

The URLs in the Tool News also may be subject to change or become invalid without prior notice.

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/