

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

---

## M16C/60 Series and M16C/20 Series

### General-purpose Program for Variable Vector Table

---

#### 1. Abstract

This program shows an example for setting variable vector tables and an example for using software interrupts.

#### 2. Introduction

A variable vector table is a 256-byte interrupt vector table whose start address (IntBase) is indicated by the content of the interrupt table register (INTB). The variable vector table in this program has its start address at FE000H. The variable vector table has individual vector tables each comprised of 4 bytes, and each vector table contains the start address of an interrupt routine.

There are software interrupt numbers (0 to 63) available for each vector table. The INT instruction uses these software interrupt numbers. No labels can be used in place of the software interrupt numbers. Peripheral I/O interrupts are assigned software interrupt numbers 0 to 31. In this program, software interrupt number 21 is used for timer A0 and software interrupt number 22 is used for timer A1. Software interrupt numbers 32 to 63 are used for software interrupts. This type of interrupt is generated by the INT instruction. Therefore, software interrupts are used in the same way as a subroutine by using the INT instruction. The INT instruction is executed even when interrupts are disabled. After interrupts are disabled (FCLR I) in this program, INT#22 and INT#32 are executed regardless of whether or not the interrupt enable flag (I) is set.

### 3. The example of a reference program

```

;*****
; *
; M16C General-purpose Programs *
; CPU : M16C *
; *
;*****
VromTOP      .EQU      0F0000H          ; Declares start address of ROM
Vistack      .EQU      002C00H          ; Interrupt stack pointer
Vintbase     .EQU      0FE000H          ; Declares interrupt vector table
                                                ; address
;
;=====
; Title      : Variable vector table
; Outline    : Description example of variable vector table and software interrupt
;=====
                .SECTION    PROGRAM, CODE
                .ORG        VromTOP      ; ROM area
MAIN:
    LDC        #Vistack, ISP          ; Sets interrupt stack pointer
    LDINTB     #Vintbase              ; Sets interrupt table register
;
    MOV.W     #100-1, TA0             ; Sets timer A0 counter
    MOV.B     #00000001B, TA0IC      ; Sets interrupt level 1 for timer A0
    MOV.W     #1000-1, TA1           ; Sets timer A1 counter
    MOV.B     #00000010B, TA1IC      ; Sets interrupt level 2 for timer A1
;
    MOV.B     #00000011B, TABSR      ; Timers A0 and A1 start counting
;
    FSET      I                      ; Enables interrupts
;
    INT       #21                    ; Performs timer A0 interrupt
                                        ; processing
                                        ; (TIMER_A0 is executed)
;
    FCLR      I                      ; Disables interrupts
;
    INT       #22                    ; Performs timer A1 interrupt
                                        ; processing
                                        ; (TIMER_A1 is executed)
;
    INT       #32                    ; Performs SOFTINT label interrupt
                                        ; processing

;(Here is your program.)

```

```

TIMER_A0:
    ;(Here is your program.)
    REIT
TIMER_A1:
    ;(Here is your program.)
    REIT
SOFTINT:
    ;(Here is your program.)
    REIT
NOTUSE:
    REIT
;
        .SECTION    SPECIAL,ROMDATA
        .ORG      Vintbase          ; Variable vector table area
;-----
; Peripheral I/O interrupt vector table
;-----
        .LWORD    NOTUSE           ; Software interrupt number 0
        .LWORD    NOTUSE           ; Software interrupt number 1
;
        .ORG      Vintbase+84
        .LWORD    TIMER_A0        ; Software interrupt number 21
        .LWORD    TIMER_A1        ; Software interrupt number 22
;
        .ORG      Vintbase+128     ; Software interrupt area
;-----
; Software interrupt vector table
;-----
        .LWORD    SOFTINT         ; Software interrupt number 32
        .LWORD    NOTUSE         ; Software interrupt number 33
;
        .END                      ;

```

#### 4. Reference

SOFTWARE MANUAL

M16C/60 M16C/20 Series SOFTWARE MANUAL

(Acquire the most current version from Renesas web-site)

#### 5. Web-site and contact for support

Renesas Web-site

<http://www.renesas.com>

Contact for Renesas technical support

Mail to : [support\\_apl@renesas.com](mailto:support_apl@renesas.com)

REVISION HISTORY

Rev.	Date	Description	
		Page	Summary
1.00	Jul 08, 2002	-	First edition issued

Keep safety first in your circuit designs!

1. Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
2. Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein.  
The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.  
Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (<http://www.renesas.com>).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.  
Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.