
R8C/M12A Group

Setting Example of System Base Clock

R01AN0092EJ0100

Rev. 1.00

July 19, 2011

Abstract

This document describes a method of setting the system base clock switching operation in the R8C/M12A Group.

Product

R8C/M12A Group

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.

Contents

1.	Specifications	3
2.	Operation Confirmation Conditions	4
3.	Software: Sample Program 1	5
3.1	Operation Overview	5
3.2	Required Memory Size	5
3.3	Flowcharts	6
3.3.1	Main Processing	6
3.3.2	System Clock Setting	6
4.	Software: Sample Program 2	7
4.1	Operation Overview	7
4.2	Required Memory Size	7
4.3	Flowcharts	8
4.3.1	Main Processing	8
4.3.2	System Clock Setting	8
5.	Software: Sample Program 3	9
5.1	Operation Overview	9
5.2	Required Memory Size	9
5.3	Flowcharts	10
5.3.1	Main Processing	10
5.3.2	System Clock Setting	10
6.	Software: Sample Program 4	11
6.1	Operation Overview	11
6.2	Required Memory Size	12
6.3	Functions	12
6.4	Function Specifications	12
6.5	Flowcharts	13
6.5.1	Main Processing	13
6.5.2	System Clock Setting	13
6.5.3	System Base Clock Switching	14
7.	Sample Code	15
8.	Reference Documents	15

1. Specifications

The system base clock is switched as follows:

- Low-speed on-chip oscillator (no division) → High-speed on-chip oscillator (no division)
- Low-speed on-chip oscillator (no division) → Low-speed on-chip oscillator (divided-by-8)
- Low-speed on-chip oscillator (no division) → XIN clock (no division)
- Low-speed on-chip oscillator (no division) → XIN clock (no division) → High-speed on-chip oscillator (no division)

In this document, no division of system clock (f) is used for the CPU clock (fs).

Table 1.1 lists the Peripheral Function and Its Application. Figures 1.1 to 1.4 show the Transition Diagram of the System Base Clock (Sample Programs 1 to 4).

Table 1.1 Peripheral Function and Its Application

Peripheral Function	Application
Clock generation circuit	System base clock switching




Figure 1.1 Transition Diagram of the System Base Clock (Sample Program 1)




Figure 1.2 Transition Diagram of the System Base Clock (Sample Program 2)




Figure 1.3 Transition Diagram of the System Base Clock (Sample Program 3)




Figure 1.4 Transition Diagram of the System Base Clock (Sample Program 4)

2. Operation Confirmation Conditions

The sample code accompanying this application note has been run and confirmed under the conditions below.

Table 2.1 Operation Confirmation Conditions

Item	Contents
MCU used	R8C/M12A Group
Operating frequencies	Sample program 1 <ul style="list-style-type: none"> • High-speed on-chip oscillator clock: 20 MHz (typical) • System clock (f): 20 MHz • CPU clock (fs): 20 MHz Sample program 2 <ul style="list-style-type: none"> • Low-speed on-chip oscillator clock: 125 kHz (typical) • System clock (f): 15.625 kHz • CPU clock (fs): 15.625 kHz Sample program 3 <ul style="list-style-type: none"> • XIN clock: 20 MHz • System clock (f): 20 MHz • CPU clock (fs): 20 MHz Sample program 4 <ul style="list-style-type: none"> • XIN clock: 20 MHz • High-speed on-chip oscillator clock: 20 MHz (typical) • System clock (f): 20 MHz • CPU clock (fs): 20 MHz
Operating voltage	5.0 V (2.7 to 5.5 V)
Integrated development environment	Renesas Electronics Corporation High-performance Embedded Workshop Version 4.07
C compiler	Renesas Electronics Corporation M16C Series, R8C Family C Compiler V.5.45 Release 01 Compile options -D__UART0__ -c -finfo -dir "\$(CONFIGDIR)" -R8C (Default setting is used in the integrated development environment.)

3. Software: Sample Program 1

3.1 Operation Overview

- (1) No division of fLOCO (low-speed on-chip oscillator) is automatically selected for fBASE (system base clock) after reset.
- (2) Set the HOCOE bit in the OCOCR register to 1, oscillate fHOCO (high-speed on-chip oscillator), and wait until oscillation stabilizes by a program.
- (3) Set the HSCKSEL bit in the SCKCR register to 1 and select fHOCO for fHSCK (high-speed clock).
- (4) Set 00h to the PHISEL register and select no division of fBASE for f (system clock).
- (5) Set the SCKSEL bit in the CKSTPR register to 1 and switch fBASE from fLOCO to fHSCK.
- (6) Set bits PHISSEL2 to PHISSEL0 in the SCKCR register to 000b and select no division of f for fs (CPU clock).

Refer to r01an0092_src_sample1.c for a sample program.

Figure 3.1 shows the Timing Diagram of the Sample Program 1 Setting.




Figure 3.1 Timing Diagram of the Sample Program 1 Setting

3.2 Required Memory Size

Table 3.1 lists the Required Memory Size.

Table 3.1 Required Memory Size

Memory Used	Size	Remarks
ROM	70 bytes	In the r01an0092_src_sample1.c module
RAM	0 bytes	In the r01an0092_src_sample1.c module
Maximum user stack usage	10 bytes	
Maximum interrupt stack usage	0 bytes	

The required memory size varies depending on the C compiler version and compile options.

3.3 Flowcharts

3.3.1 Main Processing

Figure 3.2 shows the Main Processing.




Figure 3.2 Main Processing

3.3.2 System Clock Setting

Figure 3.3 shows the System Clock Setting.




Figure 3.3 System Clock Setting

4. Software: Sample Program 2

4.1 Operation Overview

- (1) No division of fLOCO (low-speed on-chip oscillator) is automatically selected for fBASE (system base clock) after reset.
- (2) Set 08h to the PHISEL register and select fBASE divided-by-8 of for f (system clock).
- (3) Set the SCKSEL bit in the CKSTPR register to 0 and select fLOCO for fBASE.
- (4) Set bits PHISSEL2 to PHISSEL0 in the SCKCR register to 000b and select no division of f for fs (CPU clock).

Refer to r01an0092_src_sample2.c for a sample program.

Figure 4.1 shows the Timing Diagram of the Sample Program 2 Setting.




Figure 4.1 Timing Diagram of the Sample Program 2 Setting

4.2 Required Memory Size

Table 4.1 lists the Required Memory Size.

Table 4.1 Required Memory Size

Memory Used	Size	Remarks
ROM	44 bytes	In the r01an0092_src_sample2.c module
RAM	0 bytes	In the r01an0092_src_sample2.c module
Maximum user stack usage	6 bytes	
Maximum interrupt stack usage	0 bytes	

The required memory size varies depending on the C compiler version and compile options.

4.3 Flowcharts

4.3.1 Main Processing

Figure 4.2 shows the Main Processing.




Figure 4.2 Main Processing

4.3.2 System Clock Setting

Figure 4.3 shows the System Clock Setting.




Figure 4.3 System Clock Setting

5. Software: Sample Program 3

5.1 Operation Overview

- (1) No division of fLOCO (low-speed on-chip oscillator) is automatically selected for fBASE (system base clock) after reset.
- (2) Set bits CKPT1 and CKPT0 in the EXCKCR register to 11b (P4_6: XIN, P4_7: XOUT), start fXIN (XIN clock), and wait until oscillation stabilizes by a program.
- (3) Set the HCKSEL bit in the SCKCR register to 0 and select fXIN for fHCK (high-speed clock).
- (4) Set 00h to the PHISEL register and select no division of fBASE for f (system clock).
- (5) Set the SCKSEL bit in the CKSTPR register to 1 and switch fBASE from fLOCO to fHCK.
- (6) Set bits PHISSEL2 to PHISSEL0 in the SCKCR register to 000b and select no division of f for fs (CPU clock).

Refer to r01an0092_src_sample3.c for a sample program.

Figure 5.1 shows the Timing Diagram of the Sample Program 3 Setting.




Figure 5.1 Timing Diagram of the Sample Program 3 Setting

5.2 Required Memory Size

Table 5.1 lists the Required Memory Size.

Table 5.1 Required Memory Size

Memory Used	Size	Remarks
ROM	70 bytes	In the r01an0092_src_sample3.c module
RAM	0 bytes	In the r01an0092_src_sample3.c module
Maximum user stack usage	10 bytes	
Maximum interrupt stack usage	0 bytes	

The required memory size varies depending on the C compiler version and compile options.

5.3 Flowcharts

5.3.1 Main Processing

Figure 5.2 shows the Main Processing.




Figure 5.2 Main Processing

5.3.2 System Clock Setting

Figure 5.3 shows the System Clock Setting.




Figure 5.3 System Clock Setting

6. Software: Sample Program 4

6.1 Operation Overview

- (1) No division of fLOCO (low-speed on-chip oscillator) is automatically selected for fBASE (system base clock) after reset.

mcu_init(): System clock setting

- (2) Set bits CKPT1 and CKPT0 in the EXCKCR register to 11b (P4_6: XIN, P4_7: XOUT), start fXIN (XIN clock), and wait until oscillation stabilizes by a program.
 (3) Set the HSCKSEL bit in the SCKCR register to 0 and select fXIN for fHCK (high-speed clock).
 (4) Set 00h to the PHISEL register and select no division of fBASE for f (system clock).
 (5) Set the SCKSEL bit in the CKSTPR register to 1 and switch fBASE from fLOCO to fHCK.
 (6) Set bits PHISSEL2 to PHISSEL0 in the SCKCR register to 000b and select no division of f for fs (CPU clock).

clock_change(): System base clock switching

- (7) Set the HOCOEN bit in the OCOCR register to 1, start fHOCO (high-speed on-chip oscillator), and wait until oscillation stabilizes by a program.
 (8) Set the HSCKSEL bit in the SCKCR register to 1 and switch fHCK from fXIN to fHOCO.
 (9) Set 00h to the PHISEL register and select no division of fBASE for f.
 (10) Set the SCKSEL bit in the CKSTPR register to 1 and select fHCK for fBASE.
 (11) Set bits PHISSEL2 to PHISSEL0 in the SCKCR register to 000b and select no division of f for fs.

Refer to r01an0092_src_sample4.c for a sample program.

Figure 6.1 shows the Timing Diagram of the Sample Program 4 Setting.




Figure 6.1 Timing Diagram of the Sample Program 4 Setting

6.2 Required Memory Size

Table 6.1 lists the Required Memory Size.

Table 6.1 Required Memory Size

Memory Used	Size	Remarks
ROM	128 bytes	In the r01an0092_src_sample4.c module
RAM	0 bytes	In the r01an0092_src_sample4.c module
Maximum user stack usage	10 bytes	
Maximum interrupt stack usage	0 bytes	

The required memory size varies depending on the C compiler version and compile options.

6.3 Functions

Table 6.2 lists the Functions.

Table 6.2 Functions

Function Name	Outline
mcu_init	System clock setting
clock_change	System base clock switching

6.4 Function Specifications

The following tables list the sample code function specifications.

mcu_init	
Outline	System clock setting
Header	None
Declaration	void mcu_init(void)
Description	Set the system clock.
Argument	None
Returned value	None
Remark	—

clock_change	
Outline	System base clock switching
Header	None
Declaration	void clock_change(void)
Description	Set the high-speed on-chip oscillator (no division) for the system base clock.
Argument	None
Returned value	None
Remark	—

6.5 Flowcharts

6.5.1 Main Processing

Figure 6.2 shows the Main Processing.




Figure 6.2 Main Processing

6.5.2 System Clock Setting

Figure 6.3 shows the System Clock Setting.




Figure 6.3 System Clock Setting

6.5.3 System Base Clock Switching

Figure 6.4 shows the System Base Clock Switching.




Figure 6.4 System Base Clock Switching

7. Sample Code

Sample code can be downloaded from the Renesas Electronics website.

8. Reference Documents

R8C/M12A Group User's Manual: Hardware Rev.1.02

The latest version can be downloaded from the Renesas Electronics website.

Technical Update/Technical News

The latest information can be downloaded from the Renesas Electronics website.

Website and Support

Renesas Electronics website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/inquiry>

Revision History	R8C/M12A Group Setting Example of System Base Clock
------------------	--

Rev.	Date	Description	
		Page	Summary
1.00	July 19, 2011	—	First edition issued

All trademarks and registered trademarks are the property of their respective owners.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this manual, refer to the relevant sections of the manual. If the descriptions under General Precautions in the Handling of MPU/MCU Products and in the body of the manual differ from each other, the description in the body of the manual takes precedence.

1. Handling of Unused Pins

Handle unused pins in accord with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between Products

Before changing from one product to another, i.e. to one with a different part number, confirm that the change will not lead to problems.

- The characteristics of MPU/MCU in the same group but having different part numbers may differ because of the differences in internal memory capacity and layout pattern. When changing to products of different part numbers, implement a system-evaluation test for each of the products.

Notice

- All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
- Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.
2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.
Tel: +1-408-586-6000, Fax: +1-408-586-6130

Renesas Electronics Canada Limited
1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.
Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH
Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.
Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

Renesas Electronics Hong Kong Limited
Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.
13F, No. 363, Fu Shing North Road, Taipei, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.
1 HarbourFront Avenue, #06-10, Keppel Bay Tower, Singapore 098632
Tel: +65-6213-0200, Fax: +65-6276-8001

Renesas Electronics Malaysia Sdn.Bhd.
Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jin Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd.
11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141