

# **RL78 Family**

## **AES Library: Introduction Guide**

## Introduction

This document explains AES Library for the RL78 Family (hereafter referred to as "AES Library") that depends on MCUs. The AES Library is the software library incorporated in the RL78 Family and includes the data encryption/decryption functions that use the AES encryption technology. Also it is designed in dedicated algorithm and fully-tuned up by assembly language.

And AES Library package also has GCM Library corresponds "Galois/Counter Mode (GCM)".

Please refer to the User's Manual to know how to use this software library.

## Target Device

RL78/G14(S3 core), RL78/G23(S3 core),

This software can be used for all RL78 Family MCUs that belongs into S2 core or S3 core.

This software cannot be used for small memory RL78 Family MCUs for example RL78/G10.

For memory usage for this software, please refer to the ROM/RAM/Stack size section in this document.

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.

## Contents

1.	Structure of This Product	2
2.	Product Specifications	
2.1	API Function	4
2.2	API How to use library functions	5
3.	CC-RL	6
3.1	Development environment	6
3.2	ROM / RAM / Stack Size / Performance	6
4.	IAR Embedded Workbench	8
4.1	Development environment	
4.2	ROM / RAM / Stack Size / Performance	8
5.	LLVM	10
5.1	Development environment	
5.2	ROM / RAM / Stack Size / Performance	10



## 1. Structure of This Product

This product includes the following data.

ame				Des	scription		
mple prog	ple program (r20an0151xx0201-rl78-aes)						
	prkspace <dir></dir>						
Do	Document (doc) <dir></dir>						
	Engl						
		r20uw0068ej0201-aes.pdf			User's manual		
			an0151ej0201-rl78-aes.pdf	Introduction Guide (this document)			
	Japanese (ja)						
	r20uw0068jj0201-aes.pdf				User's manual		
			an0151jj0201-rl78-aes.pdf	_	Introduction Guide		
libs	src <d< td=""><td>IR&gt;</td><td></td><td>Driv</td><td>/er storage folder</td></d<>	IR>		Driv	/er storage folder		
	aes	<di< td=""><td>R&gt;</td><td>AES</td><td>S Library</td></di<>	R>	AES	S Library		
		src	<dir></dir>		S Library source		
			aes128Ecb_small.c	128	-bit ECB mode AES API function definition		
			aes128Cbc_small.c	128	-bit CBC mode AES API function definition		
			aes256Ecb_small.c	256	-bit ECB mode AES API function definition		
			aes256Cbc_small.c	256	-bit CBC mode AES API function definition		
			aes128Ecb_big.c	128	-bit ECB mode AES API function definition		
			aes128Cbc_big.c	128-bit CBC mode AES API function definition			
			aes256Ecb_big.c		256-bit ECB mode AES API function definition		
			aes256Cbc_big.c	256-bit CBC mode AES API function definition			
			aes128.h		128-bit CBC mode AES core		
			aes256.h		256-bit CBC mode AES core		
			r_aesEcb.h	ECB mode AES core			
			r_aes_version.c	AES	S version file		
			r_aesSbox.h	Def	inition of SBOX table for AES		
			r_aes_development.h	AES file	S library function name definition macro header		
		inclu	ude <dir></dir>	AES	S library header		
			r_aes.h	AES	S library header file		
			r_mw_version.h	Ver	sion data header file		
			r_stdint.h	type	edef header file		
	gcm <dir></dir>		GC	M Library			
		src	<dir></dir>	GCM Library source			
			r_gcm.c	GC	M Library source		
			r_gcm_version.c	GC	M version file		
		incl	ude <dir></dir>	GC	M library header		
			r_gcm.h	GC	M library header file		
			r_stdint.h		edef header file		
			 r_mw_version.h	Ver	sion data header file		



## Table 2 AES Library Product Files (2/2)

ame					Description
ample program (r20an0151xx0201-rl78_aes)					
wo	orkspace	<dir:< td=""><td>&gt;</td><td></td><td></td></dir:<>	>		
	CS+ <	:DIR>			CS+ project folder
	ae	es_rl78	3_sim	_sample <dir></dir>	G23 sample project folder
		src	<di< td=""><td>२&gt;</td><td>program storage folder</td></di<>	२>	program storage folder
			mai	n.c	sample main
			mai	n.h	sample main header
			r_g	cm_driver.c	sample GCM Driver
			r_g	cm_driver.h	sample GCM Driver header
			r_sa	ample_aes128.c	sample AES128
			r_sa	ample_aes256.c	sample AES256
			r_sa	ample_gcm_dec.c	sample GCM mode(decode)
			r_sa	ample_gcm_enc.c	sample GCM mode(encode)
			r_te	est_data.c	sample test data
			r_te	est_data.h	sample test data header
			libs	rc <dir></dir>	link to libsrc
			smo	c_gen <dir></dir>	Smart configurator auto-generated folder
				general	Common header file / source file storage folder
				r_bsp	Initialization code register definition storage folder
				r_config	Driver initialization config header storage folder
	e <sup>2</sup> stud	io <d< td=""><td>IR&gt;</td><td></td><td>e<sup>2</sup> studio project folder</td></d<>	IR>		e <sup>2</sup> studio project folder
	C	CCRL aes_rl78_sim_sample <dir> LLVM</dir>			sample project for CCRL
				sim_sample <dir></dir>	sample project for G23
	LL				sample project for LLVM
		aes_rl78_sim_sample <dir></dir>			sample project for G23
IAR					IAR project folder
	ae	es_rl78	3_sim	_sample <dir></dir>	sample project for G23



## 2. Product Specifications

## 2.1 API Function

AES library, GCM library supports the following library API functions.

All pointer-type arguments have the \_\_\_\_near type qualifier, and the data to be pointed to must be in the near area.

Table 3 Library Functions (API) of AES Library

API	Outline
R_Aes_128_Keysch	AES 128-bit Key Schedule
R_Aes_128_Ecbenc	AES 128-bit Encryption Function (ECB Mode)
R_Aes_128_Ecbdec	AES 128-bit Decryption Function (ECB Mode)
R_Aes_128_Cbcenc	AES 128-bit Encryption Function (CBC Mode)
R_Aes_128_Cbcdec	AES 128-bit Decryption Function (CBC Mode)
R_Aes_256_Keysch	AES 256-bit Key Schedule
R_Aes_256_Ecbenc	AES 256-bit Encryption Function (ECB Mode)
R_Aes_256_Ecbdec	AES 256-bit Decryption Function (ECB Mode)
R_Aes_256_Cbcenc	AES 256-bit Encryption Function (CBC Mode)
R_Aes_256_Cbcdec	AES 256-bit Decryption Function (CBC Mode)

#### Table 4 Library Functions (API) of GCM Library

API	Outline
R_gcm_enc	GCM Encryption Function
R_gcm_dec	GCM Decryption Function
R_gcm_enc_start	GCM Start Encryption Function
R_gcm_dec_start	GCM Start Decryption Function
R_gcm_repeat	GCM Repeat Function



## 2.2 API How to use library functions

When using the library function, it is necessary to specify the file to be built as follows according to the API to be used.

Table 5 Build target file corresponding to each API

API	Build target file
R_Aes_128_Keysch	aes128Ecb_small.c, aes128Ecb_big.c, r_aes_version.c
R_Aes_128_Ecbenc	
R_Aes_128_Ecbdec	
R_Aes_256_Keysch	aes256Ecb_small.c, aes256Ecb_big.c, r_ aes_version.c
R_Aes_256_Ecbenc	
R_Aes_256_Ecbdec	
R_Aes_128_Keysch	aes128Cbc_small.c, aes128Cbc_big.c, r_ aes_version.c
R_Aes_128_Cbcenc	
R_Aes_128_Cbcdec	
R_Aes_256_Keysch	aes256Cbc_small.c, aes256Cbc_big.c, r_ aes_version.c
R_Aes_256_Cbcenc	
R_Aes_256_Cbcdec	
R_gcm_enc	r_gcm.c
R_gcm_dec	r_gcm_version.c
R_gcm_enc_start	
R_gcm_dec_start	
R_gcm_repeat	



## 3. CC-RL

## 3.1 Development environment

Please use the same or a later version of the toolchain listed below:

Integrated Development Environment:

CS+ for CC V8.05.00

e<sup>2</sup> studio 2021-04 (21.4.0)

 C compiler: CC-RL V1.09.00

## 3.2 ROM / RAM / Stack Size / Performance

The various sizes and processing cycles when building with the following options are described for reference.

Compiler options

-cpu=S3 -memory\_model=medium -Odefault

Link options

-NOOPtimize

### Table 6 ROM, RAM, and Stack Size of AES Library

API	ROM (*1) (*2)	RAM	Stack
R_Aes_128_Keysch			26
R_Aes_128_Ecbenc			96
R_Aes_128_Ecbdec			282
R_Aes_128_Cbcenc			156
R_Aes_128_Cbcdec	47.074		368
R_Aes_256_Keysch	17,871	0	32
R_Aes_256_Ecbenc			96
R_Aes_256_Ecbdec			346
R_Aes_256_Cbcenc			156
R_Aes_256_Cbcdec	1		432

(\*1) A value in case all the APIs is used. This value changes with the number of APIs to be used.



The ROM, RAM, and stack size of GCM Library functions (API) are shown below (Unit = byte):

### Table 7 ROM, RAM, and Stack Size of GCM Library

API	ROM	RAM	Stack (*1)
R_gcm_enc			662
R_gcm_dec			658
R_gcm_enc_start	5,381	0	38
R_gcm_dec_start			38
R_gcm_repeat			596

(\*1) This is the value when combined with the AES library including the driver part.

#### Table 8 AES Library Performance

API	time [us] @ system clock = 32MHz		
AFI	1 block	3 blocks	
R_Aes_128_Keysch	100		
R_Aes_128_Ecbenc	200	200	
R_Aes_128_Ecbdec	500	500	
R_Aes_128_Cbcenc	200	200	
R_Aes_128_Cbcdec	500	500	
R_Aes_256_Keysch	110		
R_Aes_256_Ecbenc	300	300	
R_Aes_256_Ecbdec	700	700	
R_Aes_256_Cbcenc	300	300	
R_Aes_256_Cbcdec	700	700	

#### Table 9 GCM Library Performance

API	Кеу Туре	time [ms] @ system clock = 32MHz		
API		1 block	3 blocks	
R_gcm_enc	128 bit	5.0	8.3	
	256 bit	15.2	18.7	
R_gcm_dec	128 bit	5.0	8.2	
	256 bit	5.3	8.8	

Notes: 1. These values are calculated using atag = 16 byte, ivec = 12 byte, add = 1 block.

2. This processing speed may fluctuate with inputting data (plain text/cipher text).

3. Performance of R\_gcm\_enc\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_enc().

4. Performance of R\_gcm\_dec\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_dec().



## 4. IAR Embedded Workbench

### 4.1 Development environment

Please use the same or a later version of the toolchain listed below:

- Integrated Development Environment:
   IAR Embedded Workbench for Renesas RL78 version 4.21.1
- C compiler:

IAR C/C++ Compiler for Renesas RL78 : 4.20.1.2260 (4.20.1.2260)

## 4.2 ROM / RAM / Stack Size / Performance

The various sizes and processing cycles when building with the following options are described for reference.

Compiler options

--core=S3 --code\_model=far --data\_model=near --near\_const\_location=rom0 -e -Oh

--calling\_convention=v2

API	ROM (*1)	RAM	Stack
R_Aes_128_Keysch			48
R_Aes_128_Ecbenc			136
R_Aes_128_Ecbdec			330
R_Aes_128_Cbcenc			210
R_Aes_128_Cbcdec	40.070	0	420
R_Aes_256_Keysch	18,879	0	48
R_Aes_256_Ecbenc			136
R_Aes_256_Ecbdec			394
R_Aes_256_Cbcenc			210
R_Aes_256_Cbcdec			484

### Table 10 ROM, RAM, and Stack Size of AES Library

(\*1) A value in case all the APIs is used. This value changes with the number of APIs to be used.



The ROM, RAM, and stack size of GCM Library functions (API) are shown below (Unit = byte):

Table 11 ROM, RAM, and Stack Size of GCM Library

API	ROM	RAM	Stack (*1)
R_gcm_enc			806
R_gcm_dec			808
R_gcm_enc_start	8,110	0	18
R_gcm_dec_start			18
R_gcm_repeat			666

(\*1) This is the value when combined with the AES library including the driver part.

#### Table 12 AES Library Performance

API	time [us] @ system clock = 32MHz	
AFI	1 block	3 blocks
R_Aes_128_Keysch	300	
R_Aes_128_Ecbenc	1,400	1,400
R_Aes_128_Ecbdec	2,700	2,700
R_Aes_128_Cbcenc	1,500	1,500
R_Aes_128_Cbcdec	2,800	2,800
R_Aes_256_Keysch	300	
R_Aes_256_Ecbenc	1,900	1,900
R_Aes_256_Ecbdec	3,800	3,800
R_Aes_256_Cbcenc	2,000	2,000
R_Aes_256_Cbcdec	3,900	3,900

There is difference in performance for each library (Device, Code model, Data model settings)

#### Table 13 GCM Library Performance

API	Кеу Туре	time [ms] @ system clock = 32MHz	
AFI		1 block	3 blocks
R_gcm_enc	128bit	10.7	17.9
	256bit	28.2	36.5
R_gcm_dec	128bit	10.8	17.8
	256bit	12.7	21.1

Notes: 1. These values are calculated using atag = 16 byte, ivec = 12 byte, add = 1 block.

2. This processing speed may fluctuate with inputting data (plain text/cipher text).

3. Performance of R\_gcm\_enc\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_enc().

4. Performance of R\_gcm\_dec\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_dec().



## 5. LLVM

## 5.1 Development environment

Please use the same or a later version of the toolchain listed below:

- Integrated Development Environment: e2 studio 2022-01 (22.1.0)
- C compiler:

LLVM for Renesas RL78 10.0.0.202203

## 5.2 ROM / RAM / Stack Size / Performance

The various sizes and processing cycles when building with the following options are described for reference.

Compiler options

CPU Type : S3-core

Optimization Level : Optimize size (-Os)

API	ROM (*1)	RAM	Stack
R_Aes_128_Keysch			58
R_Aes_128_Ecbenc			82
R_Aes_128_Ecbdec	21,273		276
R_Aes_128_Cbcenc			160
R_Aes_128_Cbcdec		<u>_</u>	398
R_Aes_256_Keysch		0	58
R_Aes_256_Ecbenc			82
R_Aes_256_Ecbdec			340
R_Aes_256_Cbcenc			160
R_Aes_256_Cbcdec			462

(\*1) A value in case all the APIs is used. This value changes with the number of APIs to be used.

# The ROM, RAM, and stack size of GCM Library functions (API) are shown below (Unit = byte): **Table 15 ROM, RAM, and Stack Size of GCM Library**

API	ROM	RAM	Stack (*1)
R_gcm_enc			670
R_gcm_dec			670
R_gcm_enc_start	10,185	0	38
R_gcm_dec_start			38
R_gcm_repeat			502

(\*1) This is the value when combined with the AES library including the driver part.



### Table 16 AES Library Performance

API	time [us] @ system clock = 32MHz		
API	1 block	3 blocks	
R_Aes_128_Keysch	190		
R_Aes_128_Ecbenc	620	1,840	
R_Aes_128_Ecbdec	1,140	2,450	
R_Aes_128_Cbcenc	650	1,930	
R_Aes_128_Cbcdec	1,190	3,520	
R_Aes_256_Keysch	240		
R_Aes_256_Ecbenc	860	2,590	
R_Aes_256_Ecbdec	1,860	3,670	
R_Aes_256_Cbcenc	900	2,670	
R_Aes_256_Cbcdec	1,890	5,650	

#### Table 17 GCM Library Performance

API	Кеу Туре	time [ms] @ system clock = 32MHz	
AFI		1 block	3 blocks
R_gcm_enc	128bit	9.9	16.4
	256bit	10.9	17.8
R_gcm_dec	128bit	10.0	16.5
	256bit	10.9	18.0

Notes: 1. These values are calculated using atag = 16 byte, ivec = 12 byte, add = 1 block.

2. This processing speed may fluctuate with inputting data (plain text/cipher text).

3. Performance of R\_gcm\_enc\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_enc().

4. Performance of R\_gcm\_dec\_start() and R\_gcm\_repeat() combination is same as R\_gcm\_dec().



## Website and Support

Renesas Electronics Website <u>http://www.renesas.com/</u>

Inquiries

http://www.renesas.com/contact/

All trademarks and registered trademarks are the property of their respective owners.



## **Revision History**

		Description		
Rev.	Date	Page	Summary	
1.00	Mar 31, 2012	_	First edition issued	
1.01	Nov 30, 2012	_	Add Function of AES-192 and AES-256.	
1.02	Mar 29, 2013		Added GCM Library.	
1.03	Apr 19, 2013		Update	
			5. ROM / RAM / Stack Size	
			7. Performance	
			8. Version Information	
1.04	Apr 20, 2013		Update	
			8. Version Information	
1.05	Apr 23, 2013		Update	
		2	File name of document in Table 1.	
1.06	Aug 30, 2013	—	Updated "Structure of This Product" section for package	
			version V.1.04 Release 01.	
			CubeSuite+ version info to section.3, Added IAR version info to section.4.	
			Changed 3.7. Notes section, because additional of libraries for each model.	
			Added 5. Software Update Information section.	
1.07	Dec 01, 2015	_	Updated "Structure of This Product" section, "Software Update	
			Information"section, "Performance" and etc for package	
			version V.1.05 Release 00.	
			Added 4. CS+ for CC section.	
2.00	Apr 21, 2021	_	The product configuration, software update history, library	
			performance, etc. have been updated according to the	
			package version V.1.06 Release 00.	
2.01	Jun 30, 2022		Supported LLVM.	



# General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

#### 1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

#### 2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power is supplied until the power is supplied until the power reaches the level at which reseting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

#### 6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a systemevaluation test for the given product.

#### Notice

- Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
- 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
- 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
- 5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
- 6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

- 7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
- 8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
- 12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
- This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
   Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

### **Corporate Headquarters**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

www.renesas.com

#### Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## **Contact information**

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit: <a href="http://www.renesas.com/contact/">www.renesas.com/contact/</a>.