

---

[Upgrade to revision]

R20TS0381EJ0100

Rev.1.00

Flash Self Programming Library Type01 Package Ver.3.00

Jan. 16, 2019

for RL78 Family

---

## Outline

We have updated the flash self-programming library Type01 package for RL78 family. The main feature of the update is an integration of Japanese and European release versions of the packages.

## 1. Integrated Packages

- (1) Flash Self Programming Library Type01 Package Ver.2.21B for RL78 Family, Japanese Release

Target region: Mainland China/ Hong Kong/ Singapore/ South & Southeast Asia/ Oceania/  
India/ South Korea/ Taiwan

➤ Package file name:

Japanese version: JP\_R\_FSL\_RL78\_T01\_V2.21\_B\_J.zip

English version: JP\_R\_FSL\_RL78\_T01\_V2.21\_B\_E.zip

- (2) Flash Self-Programming Library Package Type T01, European Release

Target region: Americas/ Brazil/ Europe/ Middle East/ Africa

➤ Package file name:

RENESAS\_FSL\_RL78\_T01E\_V1.20.zip

RENESAS\_FSL\_RL78\_T01E\_IARV2\_V1.00.zip

## 2. Description of Update

### 2.1 Integration of Packages

Japanese and European release versions of the packages listed in section 1 have been integrated and packaged in the installer.

The package after integration is listed below.

- Flash Self Programming Library Type01 Package Ver.3.00 for the RL78 Family

Package file name: FSL\_RL78\_Type01\_Installer\_V300.zip

No changes have been made to the included flash self-programming library for RL78 family.

For details about the supported MCUs of the library, refer to the following URL.

<https://www.renesas.com/search/keyword-search.html#genre=document&q=r20ut2944>

RL78 Family Self RAM list of Flash Self Programming Library

### 2.2 Release Note, Japanese Release Version

Target region: Mainland China/ Hong Kong/ Singapore/ South & Southeast Asia/ Oceania/  
India/ South Korea/ Taiwan

The release note has been updated from Ver.1.03 to Ver.1.04 and included in the package.

■ After update

- RL78 Family Flash Self-Programming Library Type01 Package Ver.3.00  
(for the CA78K0R/CC-RL Compiler) Release Note Rev.1.04

Document No. R20UT0777EJ0104

### 3. User's Manual

#### 3.1 RL78 Family Flash Self-Programming Library Type 01 User's Manual, Japanese Release

Target region: Mainland China/ Hong Kong/ Singapore/ South & Southeast Asia/ Oceania/ India/ South Korea/ Taiwan

User's Manual has been updated from Ver.1.04 to Ver.1.05.

The integrated user's manual is not included in the package. To use the user's manual, download it from the URL below.

<https://www.renesas.com/search/keyword-search.html?q=r01us0050ej>

(Scheduled to be released on January 21.)

- After update

- RL78 Family Flash Self-Programming Library Type01 User's Manual Rev.1.05  
Document No. R01US0050EJ0105

#### 3.2 RL78 Flash Self-programming Library Type T01, European Release

Target region: Americas/ Brazil/ Europe/ Middle East/ Africa

No change has been made to the European version of the User's Manual.

- Flash Self-programming Library Type T01, European Release

<https://www.renesas.com/search/keyword-search.html?q=R01US0016ED>

Document Number: R01US0016ED0105

- Flash Self-Programming Library Type T01, European Release, Differences between the IAR V2.xx Compiler Version and the CC-RL Compiler Version

<https://www.renesas.com/search/keyword-search.html?q=R20UT3541FJ>

Document No. R20UT3541FJ0101

### 4. Updated Self RAM List

We have updated the Self RAM list of flash self-programming library for RL78 family.

(Scheduled to be released on January 21.)

<https://www.renesas.com/search/keyword-search.html#genre=document&q=r20ut2944>

RL78 Family Self RAM list of Flash Self Programming Library

Document No. R20UT2944EJ0302

## 5. How to Obtain the Package

Follow the instructions below to obtain the package.

### 5.1 Download the Package

Download the package (zip file) from the following URL. (Scheduled to be released on January 21.)

<https://www.renesas.com/products/software-tools/tools/self-programming-library/code-flash-libraries.html>

Flash Self Programming Library Type01 Package Ver.3.00 for the RL78 Family  
[for the CA78K0R/CC-RL Compiler]

Package file name: FSL\_RL78\_Type01\_Installer\_V300.zip

### 5.2 Install the Library

Installing methods are different for the Japanese and European release versions.

➤ Japanese release version

Target region: Mainland China/ Hong Kong/ Singapore/ South & Southeast Asia/ Oceania/  
India/ South Korea/ Taiwan

(1) Decompress the downloaded package (zip file) and start the installer.

Installer file name: RENESAS\_RL78\_FSL\_T01\_3V00.exe

(2) Select “Asia/Oceania–English” from the pull-down menu and click “OK” button.

(3) Follow the instructions of the installer hereafter.

➤ European release version

Target region: Americas/ Brazil/ Europe/ Middle East/ Africa

(1) Decompress the downloaded package (zip file) and start the installer.

Installer file name: RENESAS\_RL78\_FSL\_T01\_3V00.exe

(2) Select “America/Europe/Middle East/Africa” from the pull-down menu and click “OK” button.

(3) Follow the instructions of the installer hereafter.

**Revision History**

Rev.	Date	Description	
		Page	Summary
1.00	Jan. 16, 2019	-	First edition issued

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061 Japan  
 Renesas Electronics Corporation

■Inquiry

<https://www.renesas.com/contact/>

Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.

The past news contents have been based on information at the time of publication. Now changed or invalid information may be included.

The URLs in the Tool News also may be subject to change or become invalid without prior notice.

All trademarks and registered trademarks are the property of their respective owners.