Date: May 30, 2017

# **RENESAS TECHNICAL UPDATE**

TOYOSU FORESIA, 3-2-24, Toyosu, Koto-ku, Tokyo 135-0061, Japan Renesas Electronics Corporation

Product Category	MPU/MCU	Document No.	TN-RZ*-A025A/E	Rev.	1.00	
Title	RZ/G Series User's Manual:Hardware Correc (DBSC3)	Information Category	Technical Notification			
		Lot No.				
Applicable Product	RZ/G Series RZ/G1H, M, N, and E	All lots	Reference Document	RZ/G Series User's Ma Rev.1.00 (R01UH0543EJ0100)	anual: Ha	rdware

This technical update describes document correction for RZ/G Series.

# [Summary]

RZ/G Series User's Manual: Hardware Correction (manual errata)

As PDMODE prohibits "10" setting, it deletes unnecessary description of Description.

# [Products]

RZ/G1H, M, N, and E

#### [Note]

There is no specification change (document correction only).

# [Correction]

(Cancelation line parts (abcd) are deleted and gray highlighted parts (efgh) are corrected.)

1. Section 15.3.38 Power-Down Configuration Register (DBPDNCNF) -> Description of PDMODE bit

# Current (from):

Bit	Bit Name	Initial Value	R/W	Description
1, 0	PDMODE	00	R/W	Power-Down/Self-Refresh Mode Bits
				When these bits are set to "01" and there has been no memory access for a certain period, the power-down entry command is issued to place the SDRAM in power-down mode. When these bits are set to "10" and there has been no memory access for a certain period, the self-refresh entry command is issued to place the SDRAM in self-refresh mode.
				00: Auto power-down mode and auto self-refresh mode are off.
				01: Auto power-down mode is on.
				Other settings are prohibited.

Date: May 30, 2017

Bit	Bit Name	Initial Value	R/W	Description
1, 0	PDMODE	00	R/W	Power-Down <del>/Self-Refresh</del> Mode Bits
				When these bits are set to "01" and there has been no memory access for a certain period, the power-down entry command is issued to place the SDRAM in power-down mode. When these bits are set to "10" and there has been no memory access for a certain period, the self-refresh entry command is issued to place the SDRAM in self-refresh mode.
				00: Auto power-down mode and auto self-refresh mode is off.
				01: Auto power-down mode is on.
				Other settings are prohibited.

- end of document -

