

RAA214020 SPICE Model

This document discusses the SPICE model for the RAA214020 LDO including the features supported and not supported by the model. To download the model, see the [RAA214020](#) product page.

Contents

1. Model Features	1
1.1 Device Performance Features Supported	1
1.2 Device Performance Features NOT Supported	1
2. Downloading and Running the Software	2
3. License Statement	4
4. Revision History	4

1. Model Features

This Pspice Macromodel is intended to give typical DC and AC performance characteristics under a wide range of external circuit configurations using compatible simulation platforms such as iSim PE.

1.1 Device Performance Features Supported

The following are the device performance features that are supported by this model:

- Device parameters are set to typical room temperature values
- Gain and phase
- Input noise terms including 1/f effects
- PSRR
- Transient V_{IN} , V_{OUT} , and Load. Reference the Excel spreadsheet that is included with the SPICE software ([Figure 1](#)) for test results (RAA214020 SPICE Model Validation.xlsx).
- Output current limit
- Enable and Disable function using the Enable pin
- Power-good using the PG pin
- UVLO <1V and 300Ω output impedance
- 300Ω output pull-down when part is disabled and $V_{IN} > 1V$
- 300Ω output pull-down when part is enabled and $1V < V_{IN} < 2.5V$

1.2 Device Performance Features NOT Supported

The following are the device performance features that are NOT supported by this model:

- Harmonic distortion effects
- Thermal effects and/or over-temperature
- Parameter variation
- Part-to-part performance variation because of normal process parameter spread
- Any performance difference arising from different packaging

2. Downloading and Running the Software

The RAA214020 SPICE model software can be down loaded from the [RAA214020](#) product page.

Save the file to a common directory for your SPICE simulations. This application note assumes you have a basic knowledge of running SPICE simulations. To open the software, click on the file titled

RAA214020SPICEMODELrev03.opj (highlighted in [Figure 1](#)). An Excel spreadsheet is also provided documenting the validation of the model..

Name	Date modified	Type	Size
RAA214020SPICEMODELrev03-PSpiceFiles	2/23/2021 11:28 AM	File folder	
22uF output Cap.lib	8/28/2020 4:45 PM	PSpice Model Libr...	1 KB
22uF output Cap.olb	8/28/2020 4:45 PM	OLB File	5 KB
22uFLabOutputCap.lib	8/31/2020 8:24 AM	PSpice Model Libr...	1 KB
22uFLabOutputCap.olb	8/31/2020 8:15 AM	OLB File	7 KB
22uFoutputCap.lib	8/28/2020 4:55 PM	PSpice Model Libr...	1 KB
22uFoutputCap.olb	8/28/2020 4:46 PM	OLB File	5 KB
CSET1uFcapo.lib	8/31/2020 10:13 AM	PSpice Model Libr...	1 KB
diodenoise.lib	8/31/2020 3:33 PM	PSpice Model Libr...	1 KB
nmosbottomcascode.lib	8/24/2020 7:01 AM	PSpice Model Libr...	1 KB
nmosdiffpair.lib	9/16/2020 2:26 PM	PSpice Model Libr...	1 KB
nmosnm28.lib	8/20/2020 4:49 PM	PSpice Model Libr...	1 KB
nmostopcascode.lib	7/13/2020 11:25 AM	PSpice Model Libr...	1 KB
nmostopcascode.lib	8/20/2020 11:46 AM	PSpice Model Libr...	1 KB
pmosbottomcascode.lib	8/20/2020 11:44 AM	PSpice Model Libr...	1 KB
pmoscascodepm16.lib	8/20/2020 3:43 PM	PSpice Model Libr...	1 KB
pmospm14.lib	8/20/2020 12:06 PM	PSpice Model Libr...	1 KB
pmospower.lib	8/21/2020 4:45 PM	PSpice Model Libr...	1 KB
pmostopcascode.lib	8/24/2020 6:59 AM	PSpice Model Libr...	1 KB
qstdnnpn.lib	8/13/2020 3:58 PM	PSpice Model Libr...	1 KB
RAA214020 SPICE Model Validation.xlsx	6/2/2021 11:58 AM	Microsoft Excel W...	1,216 KB
raa214020finaldesignrev03.opj	2/23/2021 9:44 AM	OPJ File	1 KB
RAA214020SPICEMODELrev03.DSN	5/3/2021 5:00 PM	DSN File	126 KB
RAA214020SPICEMODELrev03.opj	5/4/2021 3:05 PM	OPJ File	10 KB
RAA214020SPICEMODELREV03_0.DBK	5/3/2021 4:58 PM	DBK File	125 KB
schmitttriggerlh.lib	8/19/2020 10:01 AM	PSpice Model Libr...	1 KB
schmitttriggerll.lib	8/14/2020 2:11 PM	PSpice Model Libr...	1 KB
special.olb	8/18/2009 9:23 PM	OLB File	51 KB

Figure 1. RAA214020 SPICE Model Software

The screen shown in [Figure 2](#) appears. The test circuits for Noise, Gain Phase, PSRR, TransLoad, TransVIN, and TransVout are all setup. To run the different tests, click the down arrow and select the test you want to run (red arrow). You might need to right click on the specific test and **Make Root** to get it to run. To see the test setup, double click on **PAGE 1** and the schematic with the RAA214020 SubCKT appears. [Figure 3](#) shows the Noise test circuit.




Figure 2. SPICE Software Test Selection Window




Figure 3. RAA214020SUBCKTFDREV03 Noise Test Circuit

3. License Statement

The information in this SPICE model is protected under the United States copyright laws. Renesas Electronics Corporation hereby grants users of this macro-model hereto referred to as Licensee, a nonexclusive, nontransferable license to use this model as long as the Licensee abides by the terms of this agreement. Before using this macro-model, the Licensee should read this license. If the Licensee does not accept these terms, permission to use the model is not granted.

The Licensee may not sell, loan, rent, or license the macro-model, in whole, in part, or in modified form, to anyone outside the Licensee's company. The Licensee may modify the macro-model to suit his/her specific applications and the Licensee may make copies of this macro-model for use within their company only.

This macro-model is provided AS IS, WHERE IS AND WITH NO WARRANTY OF ANY KIND EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Renesas is not liable for special, collateral, incidental, or consequential damages in connection with or arising out of the use of this macro-model. Renesas reserves the right to make changes to the product and the macro-model without prior notice.

4. Revision History

Revision	Date	Description
1.0	Jun 18, 2021	Initial release.

IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Rev.1.0 Mar 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.