关于产品目录等资料中的旧公司名称

NEC电子公司与株式会社瑞萨科技于2010年4月1日进行业务整合(合并),整合后的新公司暨"瑞萨电子公司"继承两家公司的所有业务。因此,本资料中虽还保留有旧公司名称等标识,但是并不妨碍本资料的有效性,敬请谅解。

瑞萨电子公司网址: http://www.renesas.com

2010年4月1日 瑞萨电子公司

【发行】瑞萨电子公司(http://www.renesas.com)

【业务咨询】http://www.renesas.com/inquiry



Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights
 of third parties by or arising from the use of Renesas Electronics products or technical information described in this document.
 No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights
 of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



3858 群

定时器 Z1 的操作 (脉冲周期测量模式)

1. 要点

本篇资料介绍如何使用定时器 Z1 的脉冲周期测量模式,并举例说明如何应用该功能接收红外遥控信号的引导码。

2. 说明

该应用说明适用于以下条件:

采用的 MCU: 3858 群 振荡频率: 8MHz



3. 内容

3.1 脉冲周期测量功能说明




图 1 脉冲周期测量模式的时序图 (测量下降沿区间时)

说明

- (1) 通过将定时器 Z1 模式寄存器(地址 0028₁₆)的定时器 Z1 模式运行位(b2、b1、b0)设定为"010",并将定时器模式/事件计数模式转换位(b7)设为"0",选择脉冲周期测量模式。
- (2) 在选择高速和中速模式时,计数源为 $f(X_{IN})$ 的 1/2、1/4、1/8、1/16、1/32、1/64、1/128、1/256、1/512、1/1024 分频或 $f(X_{CIN})$;在选择低速模式时,计数源为 $f(X_{CIN})$ 的 1/2、1/4、1/8、1/16、1/32、1/64、1/128、1/256、1/512、1/1024 分频或 $f(X_{CIN})$ 。
- (3) 测量从 $CNTR_2$ 管脚的脉冲周期。当定时器 Z1 模式寄存器(地址 0028_{16})的 $CNTR_2$ 极性转换位(b5)为 "0"时,就在 $CNTR_2$ 管脚输入的下降沿到下一个下降沿的期间进行计数;为"1"时,就在 $CNTR_2$ 管脚输入的上升沿到下一个上升沿的期间进行计数。
- (4) 如果检测到测量结束/测量开始的有效边沿,就将定时器值的1的补码(测量值)写到定时器锁存器,并将"FFFF₁₆"设定到定时器。如果定时器发生下溢,就产生定时器 Z1 中断,将"FFFF₁₆"设定到定时器。
- (5) 如果读定时器 Z1, 就读取定时器锁存器(测量值)。测量值被保存到下一次测量结束。

3.2 红外遥控接收信号引导码示意图




图 2 红外遥控引导码定义示意图



- 说明
 - (1) 将遥控信号利用红外接收头去掉载波后输入到 CNTR2 管脚,信号波形如上图所示;
 - (2) 该引导码定义为两个脉冲周期,第一个脉冲 22T(6.094ms±5%), 第二个脉冲 27T(7.479ms±5%);
 - (3) 通过测定两个脉冲的周期长度判断是否为有效的遥控信号,如果有效继续接收处理遥控信号。本例中 MCU 接收到有效的遥控信号后,在 P1_7 输出一个 1 秒的低电平点亮一个 LED 作为指示。

3.3 寄存器设置

3858 群定时器 Z1 脉冲周期测量模式的寄存器设置。

(2) 设置端口P2方向寄存器

D7 D0 D0 P2D [地址 0005₁₆]

P22/CNTR2 输入模式

(3) 设置定时器Z1模式寄存器

TZ1M [地址 0028₁₆]


定时器Z1运行模式位
000: 定时器/事件计数器模式
001: 脉冲输出模式
010: 脉冲周期测量模式
011: 脉宽测量模式
100: 可编程波形发生模式
101: 可编程单触发发生模式
110: 禁止选择
111: 禁止选择
111: 禁止选择
111: 禁止选择

定时器模式/事件计数器模式转换位

(4) 设置定时器Y、Z1计数源设定选择寄存器 0100 TYZ1CSS [地址 002F₁₆] 定时器A计数源选择位 $0\ 0\ 0\ 0$: f(xin)/2 or f(xcin)/21011: $0\ 0\ 0\ 1$: f(xin)/4 or f(xcin)/40 0 1 0 : f(xin)/8 or f(xcin)/8 1100: 0 0 1 1 : f(xin)/16 or f(xcin)/16 1101: 禁止选择 0.100: f(xin)/32 or f(xcin)/321110: 0 1 0 1: f(xin)/64 or f(xcin)/64 1111: 0 1 1 0 : f(xin)/128 or f(xcin)/128 0 1 1 1: f(xin)/256 or f(xcin)/256 1 0 0 0: f(xin)/512 or f(xcin)/512 1 0 0 1: f(xin)/1024 or f(xcin)/1024 1010: f(xcin)








注意: 在写操作时,必须按照定时器Z1的低位(TZ1L),定时器Z1的高位(TZ1H)的顺序写两个寄存器; 在读操作时,必须按照定时器Z1的高位(TZ1H),定时器Z1的低位(TZ1L)的顺序读两个寄存器。


(6) 设置中断源选择寄存器



(7) 设置中断请求寄存器1




(8) 设置中断控制寄存器1



(9) 设置中断请求寄存器2




(10) 设置中断控制寄存器2






4. 程序流程图

4.1 主程序






4.2 红外遥控信号处理子程序(IR_Rcv)






4.3 CNTR₂中断服务子程序(I_CNTR0_CNTR2)



4.4 定时器 Z1 中断服务子程序(I_TimerZ1_CNTR2)





5. 参考例程

```
/****************************
  File name : rcc05b0038_0100_source.c
  Contents : Timer Z1 (Pulse Period Measurement Mode)
* Copyright(C) 2007. Renesas Technology Corp., All rights reserved.
  Version : 1.00 (2007-07-02)
*******************
/*************************
  Include
***********************
#include <stdio.h>
#include <intr740.h>
#include "sfr_3858.h"
/***********************************
  Definition
******************************
void IR_Rcv(void);
                                /* Led lamp */
#define LedLamp
                P1 7
#define Period1Max
                 1599
                                 /* 6.094ms*(1+5%) */
#define Period1Min
                 1447
                                /* 6.094ms*(1-5%) */
#define Period2Max
                 1963
                                /* 7.479ms*(1+5%) */
#define Period2Min 1776
                                 /* 7.479ms*(1-5%) */
typedef union {
                                 /* Define a type */
   unsigned int Word;
   struct {
     unsigned char LowByte;
     unsigned char HighByte;
   }Byte_Def;
}TwoByteUnion_Def;
zpage TwoByteUnion_Def PeriodValue; /* Declare an union */
#define PeriodWord PeriodValue.Word
#define PeriodLowByte PeriodValue.Byte_Def.LowByte #define PeriodHighByte PeriodValue.Byte_Def.HighByte
                                /* Declare a variable */
zpage unsigned char Rcv_Sts;
zpage unsigned char Rcv_Flag = 0;
                                /* Declare a variable */
/************************
   Main
**********************
```



```
void main(void){
                               /* Interrupt disable */
   disable_interrupt();
                               /* Binary mode */
    cld_instruction();
    CPUM = 0x0c;
                                /* Stack 1page */
    P1D = 0x80;
                                /* Set Port P1 direction register */
   P1 = 0xff;
                               /* Set Port P1 register */
    PULL2 = 0x00;
                               /* Set Port P22 pull-up control bit */
    P2D = 0x00;
                               /* Set Port P2 direction register */
   P2 = 0x00;
                               /* Set Port P2 register */
                               /* Set Timer Z1 mode register */
   TZ1M = 0x42;
    TYZ1CSS = 0x40;
                               /* Set Timer YZ1 Count register */
   TZ1L = 0xff;
                               /* Set Timer Z1(low) */
   TZ1H = 0xff;
                               /* Set Timer Z1(high) */
                               /* Set Timer Z2 mode register */
    TZ2M = 0x40;
   TZ2CSS = 0x06;
                               /* Set Timer Z2 Count register */
   TZ2L = 0x23;
                               /* Set Timer Z2(low) */
    TZ2H = 0xf4;
                                /* Set Timer Z2(high) */
                            /* Set Interrupt source selection register */
    INTSEL = 0 \times 08;
   nop_instruction();
    IREQ1 = 0x00;
                               /* All Interrupt Request Bit are cleared */
    IREQ2 = 0x00;
                               /* TimerZ1 Interrupt enable */
    IE TZ1C2 = 1;
    IE\_COC2 = 1;
                                /* CNTR2 Interrupt enable */
                               /* All Interrupt Request Bit are cleared */
    IREQ1 = 0x00;
    IREQ2 = 0x00;
   TZ1STP = 0;
                               /* Timer Z1 count start */
    enable_interrupt();
                               /* Interrupt enable */
   while(1){
       IR_Rcv();
    }
}
/**********************************
   Infrared Receive
*********************
void IR_Rcv(void){
 if (Rcv_Flag) {
   Rcv_Flag = 0;
    switch(Rcv_Sts){
       case 1:
          if ((PeriodWord > Period1Min) &&(PeriodWord < Period1Max)){</pre>
             Rcv_Sts = 2;  /* Trun to case2 */
          }
          else{
            Rcv_Sts = 1;
             PeriodLowByte = 0;
             PeriodHighByte = 0;
          }
          break;
          if ((PeriodWord > Period2Min) &&(PeriodWord < Period2Max)){</pre>
```



```
/* Trun to case3 */
            Rcv Sts = 3;
         }
         else{
            Rcv_Sts = 1;
            PeriodLowByte = 0;
            PeriodHighByte = 0;
         }
         break;
      case 3:
         IR_TZ2C3 = 0;
                                /* Clear TimerZ2 Interrup Request bit */
         TZ2L = 0x23;
                                /* Set Timer Z2(low) */
         TZ2H = 0xf4;
                                /* Set Timer Z2(high) */
         TZ2STP = 0;
                                /* Timer Z2 count start */
                                /* Output "0", light LED lamp */
         LedLamp = 0;
         while (!IR_TZ2C3){}
                                /* 1 second */
         IR_TZ2C3 = 0;
                                /* Clear TimerZ2 Interrup Request bit */
         LedLamp = 1;
                                /* Output "1", close LED lamp */
                                /* Timer Z2 count stop */
         TZ2STP = 1;
         break;
      default:
         Rcv_Sts = 1;
         PeriodLowByte = 0;
         PeriodHighByte = 0;
         break;
   }
}
   Interrupt CNTR2
*************************
void interrupt[6] I_CNTR0_CNTR2(void){
                                /* Receive request flag */
   Rcv_Flag = 1;
   PeriodLowByte = TZ1L;
                                 /* Read period measure value */
   PeriodHighByte = TZ1H;
}
/**********************************
   Interrupt TimerZ1
**********************
void interrupt[28] I_TimerZ1_CNTR2(void){
                                /* Reset receive status */
   Rcv_Sts = 1;
   Rcv_Flag = 0;
                                /* Clear receive request flag */
   PeriodWord = 0;
                                /* Clear variable value */
}
```



6. 参考文献

硬件手册

3858 群数据手册

(最新版本请从瑞萨科技网页上取得)

技术信息/技术更新

(最新信息请从瑞萨科技网页上取得)

公司主页和咨询窗口

瑞萨科技公司主页

http://www.cn.renesas.com

咨询

http://www.cn.renesas.com/inquiry

contact.china@renesas.com



修订记录

		修订内容	
Rev.	发行日	页	要点
1.00	2007.07.02	_	初版发行
1.01	2008.03.17	11	更新咨询邮箱地址,修改硬件手册名称



Notes regarding these materials

- This document is provided for reference purposes only so that Renesas customers may select the appropriate Renesas products for their use. Renesas neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Renesas or any third party with respect to the information in this document.
- 2. Renesas shall have no liability for damages or infringement of any intellectual property or other rights arising out of the use of any information in this document, including, but not limited to, product data, diagrams, charts, programs, algorithms, and application circuit examples.
- 3. You should not use the products or the technology described in this document for the purpose of military applications such as the development of weapons of mass destruction or for the purpose of any other military use. When exporting the products or technology described herein, you should follow the applicable export control laws and regulations, and procedures required by such laws and regulations.
- 4. All information included in this document such as product data, diagrams, charts, programs, algorithms, and application circuit examples, is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas products listed in this document, please confirm the latest product information with a Renesas sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas such as that disclosed through our website. (http://www.renesas.com)
- 5. Renesas has used reasonable care in compiling the information included in this document, but Renesas assumes no liability whatsoever for any damages incurred as a result of errors or omissions in the information included in this document.
- 6. When using or otherwise relying on the information in this document, you should evaluate the information in light of the total system before deciding about the applicability of such information to the intended application. Renesas makes no representations, warranties or guaranties regarding the suitability of its products for any particular application and specifically disclaims any liability arising out of the application and use of the information in this document or Renesas products.
- 7. With the exception of products specified by Renesas as suitable for automobile applications, Renesas products are not designed, manufactured or tested for applications or otherwise in systems the failure or malfunction of which may cause a direct threat to human life or create a risk of human injury or which require especially high quality and reliability such as safety systems, or equipment or systems for transportation and traffic, healthcare, combustion control, aerospace and aeronautics, nuclear power, or undersea communication transmission. If you are considering the use of our products for such purposes, please contact a Renesas sales office beforehand. Renesas shall have no liability for damages arising out of the uses set forth above.
- 8. Notwithstanding the preceding paragraph, you should not use Renesas products for the purposes listed below:
 - (1) artificial life support devices or systems
 - (2) surgical implantations
 - (3) healthcare intervention (e.g., excision, administration of medication, etc.)
 - (4) any other purposes that pose a direct threat to human life
 - Renesas shall have no liability for damages arising out of the uses set forth in the above and purchasers who elect to use Renesas products in any of the foregoing applications shall indemnify and hold harmless Renesas Technology Corp., its affiliated companies and their officers, directors, and employees against any and all damages arising out of such applications.
- 9. You should use the products described herein within the range specified by Renesas, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas shall have no liability for malfunctions or damages arising out of the use of Renesas products beyond such specified ranges.
- 10. Although Renesas endeavors to improve the quality and reliability of its products, IC products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Please be sure to implement safety measures to guard against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other applicable measures. Among others, since the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 11. In case Renesas products listed in this document are detached from the products to which the Renesas products are attached or affixed, the risk of accident such as swallowing by infants and small children is very high. You should implement safety measures so that Renesas products may not be easily detached from your products. Renesas shall have no liability for damages arising out of such detachment.
- 12. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written approval from Renesas.
- 13. Please contact a Renesas sales office if you have any questions regarding the information contained in this document, Renesas semiconductor products, or if you have any other inquiries.
- © 2008. Renesas Technology Corp., All rights reserved.



注意

本文只是参考译文,前页所载英文版"Cautions"具有正式效力。

关于利用本资料时的注意事项

- 1. 本资料是为了让用户根据用途选择合适的本公司产品的参考资料,对于本资料中所记载的技术信息,并非意味着对本公司或者第三者的知识产权及其他权利做出保证或对实施权力进行的承诺。
- 2. 对于因使用本资料所记载的产品数据、图、表、程序、算法及其他应用电路例而引起的损害或者对第三者的知识产权及其他权利造成侵犯,本公司不承担任何责任。
- 不能将本资料所记载的产品和技术用于大规模破坏性武器的开发等目的、军事目的或其他的军需用途方面。
 另外,在出口时必须遵守日本的《外汇及外国贸易法》及其他出口的相关法令并履行这些法令中规定的必要手续。
- 4. 本资料所记载的产品数据、图、表、程序、算法以及其他应用电路例等所有信息均为本资料发行时的内容,本公司有可能在未做事先通知的情况下,对本资料所记载的产品或者产品规格进行更改。所以在购买和使用本公司的半导体产品之前,请事先向本公司的营业窗口确认最新的信息并经常留意本公司通过公司主页(http://www.renesas.com)等公开的最新信息。
- 5. 对于本资料中所记载的信息,制作时我们尽力保证出版时的精确性,但不承担因本资料的叙述不当而致使顾客遭受损失等的任何相关责任。
- 6. 在使用本资料所记载的产品数据、图、表等所示的技术内容、程序、算法及其他应用电路例时,不仅要对所使用的技术信息进行单独评价,还要对整个系统进行充分的评价。请顾客自行负责,进行是否适用的判断。本公司对于是否适用不负任何责任。
- 7. 本资料中所记载的产品并非针对万一出现故障或是错误运行就会威胁到人的生命或给人体带来危害的机器、系统(如各种安全装置或者运输交通用的、医疗、燃烧控制、航天器械、核能、海底中继用的机器和系统等)而设计和制造的,特别是对于品质和可靠性要求极高的机器和系统等(将本公司指定用于汽车方面的产品用于汽车时除外)。如果要用于上述的目的,请务必事先向本公司的营业窗口咨询。另外,对于用于上述目的而造成的损失等,本公司概不负责。
- 除上述第7项内容外,不能将本资料中记载的产品用于以下用途。如果用于以下用途而造成的损失,本公司概不负责。
 - 1) 生命维持装置。
 - 2) 植埋于人体使用的装置。
 - 3) 用于治疗(切除患部、给药等)的装置。
 - 4) 其他直接影响到人的生命的装置。
- 9. 在使用本资料所记载的产品时,对于最大额定值、工作电源电压的范围、放热特性、安装条件及其他条件请在本公司规定的保证范围内使用。如果超出了本公司规定的保证范围使用时,对于由此而造成的故障和出现的事故,本公司将不承担任何责任。
- 10. 本公司一直致力于提高产品的质量和可靠性,但一般来说,半导体产品总会以一定的概率发生故障、或者由于使用条件不同而出现错误运行等。为了避免因本公司的产品发生故障或者错误运行而导致人身事故和火灾或造成社会性的损失,希望客户能自行负责进行冗余设计、采取延烧对策及进行防止错误运行等的安全设计(包括硬件和软件两方面的设计)以及老化处理等,这是作为机器和系统的出厂保证。特别是单片机的软件,由于单独进行验证很困难,所以要求在顾客制造的最终的机器及系统上进行安全检验工作。
- 11. 如果把本资料所记载的产品从其载体设备上卸下,有可能造成婴儿误吞的危险。顾客在将本公司产品安装到顾客的设备上时,请顾客自行负责将本公司产品设置为不容易剥落的安全设计。如果从顾客的设备上剥落而造成事故时,本公司将不承担任何责任。
- 12. 在未得到本公司的事先书面认可时,不可将本资料的一部分或者全部转载或者复制。
- 13. 如果需要了解关于本资料的详细内容,或者有其他关心的问题,请向本公司的营业窗口咨询。
- © 2008. Renesas Technology Corp., All rights reserved.