

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

## M16C/62A Group

### Operation of DMAC (one-shot transfer mode)

#### 1.0 Abstract

In one-shot transfer mode, choose functions from the items shown in Table 1. Operations of the circled items are described below.

**Table 1. Chosed functions**

Item	Set-up	
Transfer space	<b>○</b>	Fixed address from an arbitrary 1 M bytes space
		Arbitrary 1 M bytes space from a fixed address
		Fixed address from fixed address
Unit of transfer	<b>○</b>	8 bits
		16 bits


#### 2.0 Introduction

Operation (1) When software trigger is selected, setting software DMA request bit to “1” generates a DMA transfer request signal.

(2) If DMAC is active, data transfer starts, and the contents of the address indicated by the DMAi forward-direction address pointer are transferred to the address indicated by the DMAi destination pointer. When data transfer starts directly after DMAC becomes active, the value of the DMAi transfer counter reload register is reloaded to the DMAi transfer counter, and the value of the DMAi source pointer is reloaded by the DMAi forward-direction address pointer. Each time a DMA transfer request signal is generated, 1 byte of data is transferred. The DMAi transfer counter is down counted, and the DMAi forward-direction address pointer is up counted.


(3) If the DMA transfer counter underflows, the DMA enable bit changes to “0” and DMA transfer is completed. The DMA interrupt request bit changes to “1” simultaneously.

Figure 1 shows an example of operation



**Figure 1. Example of operation of one-shot transfer mode**

### 3.0 Set-up procedure



When software DMA request bit = "1"

Start DMA transmission

### 4.0 Programming Code

```

;*****
;
; M16C/62A Program Collection
;
; FILE NAME : rjj05b0062_src.a30
; CPU      : M16C/62A Group
; FUNCTION  : Operation of DMAC
;           (one-shot transfer mode)
; HISTORY   : 2003.05.16 Ver 1.00
;
; Copyright(C)2003, Renesas Technology Corp.
; Copyright(C)2003, Renesas Solutions Corp.
; All rights reserved.
;
;*****
;*****
;      Include
;*****
;      .LIST      OFF          ;Stops outputting lines to the assembler list file
;      .INCLUDE   sfr62a.inc   ;Reads the file that defined SFR
;      .LIST      ON          ;Starts outputting lines to the assembler list file
;
;*****
;      Symbol definition
;*****
ROM_TOP      .EQU    0F8000H   ;Start address of ROM
FIXED_VECT_TOP .EQU  0FFFDCH   ;Start address of fixed vector
C_CNT_DMA    .EQU    2        ;DMA transfer counter
;
;*****
;      Program area
;*****
;=====
;      Start up
;=====
;      .SECTION   PROGRAM, CODE ;Declares section name and section type
;      .ORG      ROM_TOP       ;Declares start address
RESET:
MOV.B   #03H, prcr      ;Removes protect
;                               ;Set processor mode registers 0 and 1
MOV.B   #00000000B, pm0 ; Single-chip mode
MOV.B   #00000000B, pm1 ; No expansion, No wait
;                               ;Set system clock control registers 0 and 1
MOV.B   #00001000B, cm0 ; Xcin-Xcout High
MOV.B   #00100000B, cm1 ; Xin-Xout High, Main clock is No divison
MOV.B   #00H, prcr      ;Protects all registers
;

```

```

=====
;      DMAC (one-shot transfer mode)
=====
MOV.B   #0, p0           ;Setting DMA destination
MOV.B   #0FFh, pd0

;
MOV.B   #00010001B, dm0con ;Setting DMA0 control register
;          ||||+-----;Transfer unit bit select bit (1:8bits)
;          ||||+-----;Repeat transfer mode select bit (0:Single transfer)
;          ||+-----;DMA request bit (0:DMA not requested)
;          |+-----;DMA enable bit (0:Disabled)
;          |+-----;Source address direction select bit (1:Forward)
;          +-----;Destination address direction select bit (0:Fixed)
MOV.B   #0000001B, dm0sl  ;Setting DMA0 request cause select register
;          |+++-----;DMA request cause select bit (0001:Software trigger)
;          +-----;Software DMA request bit (Set to "0")
;
MOV.W   #(SRC_DMA_TOP & 0FFFFh), sar0 ;Set DMA0 source pointer M,L
MOV.B   #(SRC_DMA_TOP >> 16), sar0h;Set DMA0 source pointer H
;
MOV.W   #(p0 & 0FFFFh), dar0 ;Set DMA0 destination pointer M,L
MOV.B   #(p0 >> 16), dar0h ;Set DMA0 destination pointer H
;
MOV.W   #(C_CNT_DMA-1), tcr0 ;Setting DMA0 transfer counter
;
MOV.B   #00011001B, dm0con ;Setting DMA0 control register
;          |+-----;Clear DMA request bit simultaneously
;          +-----;DMA enable bit (1:Enabled)
;
BSET    dsr_dm0sl        ;Start DMA transmission by
                        ;software DMA request bit = "1"
;
MAIN:
      JMP     MAIN

;
=====
;      Dummy interrupt processing program
=====
dummy:
      REIT
;
;*****
;      DMA source area ( ROM area )
;*****
      .SECTION    SRC_DMA, ROMDATA, ALIGN
SRC_DMA_TOP:
      .BYTE      01h, 02h    ;DMA transmission data
;

```

```
*****  
; Setting of fixed vector  
*****  
.SECTION    F_VECT, ROMDATA  
.ORG        FIXED_VECT_TOP  
  
;          .LWORD    dummy    ;Undefined instruction interrupt vector  
          .LWORD    dummy    ;Overflow (INT0 instruction) interrupt vector  
          .LWORD    dummy    ;BRK instruction interrupt vector  
          .LWORD    dummy    ;Address match interrupt vector  
          .LWORD    dummy    ;Single-step interrupt vector  
          .LWORD    dummy    ;Watchdog timer interrupt vector  
          .LWORD    dummy    ;DBC interrupt vector  
          .LWORD    dummy    ;NMI interrupt vector  
          .LWORD    RESET    ;Sets reset vector  
  
;          .END
```

**5.0 Reference**

**Renesas Technology Corporation Semiconductor Home page**  
<http://www.renesas.com/>

**Technical Support**

E-mail: [support\\_apl@renesas.com](mailto:support_apl@renesas.com)

**Data Sheet**

M16C/62A group Rev. C.1  
(Use the latest version on the Home page: <http://www.renesas.com/>)

**User's Manual**

M16C/62A group Rev. 1.0  
(Use the latest version on the Home page: <http://www.renesas.com/>)

Keep safety first in your circuit designs!

- Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
- Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors.  
Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.  
Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (<http://www.renesas.com>).
- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.