

# RAA730101

R02DS0014EJ0200

Rev.2.00

Feb 27, 2015

## 16-bit $\Delta\Sigma$ A/D converter IC with programmable gain instrumentation amplifier

### Overview

The RAA730101 is a 16-bit  $\Delta\Sigma$  A/D converter IC with a programmable gain instrumentation amplifier ideal for differential output sensors used for measuring flow and pressure. The RAA730101 incorporates a temperature sensor, a power supply for external sensor, and an internal reference voltage generator. Using Serial Peripheral Interface (SPI) communication or Universal Asynchronous Receiver Transmitter (UART) communication, the RAA730101 controls system configurations for each function block from an external device and outputs measured data to the external device. The RAA730101 also incorporates flash memory for storing system configurations for each function block. The RAA730101 uses a 36-pin FBGA package, which enables a more compact set design for measuring flow and pressure.

### Features

- 16-bit  $\Delta\Sigma$  A/D converter
- Programmable gain instrumentation amplifier (capable of gain adjustment from x1 to x32 and adjustment of offset voltage)
- Four analog input channels (differential input mode or single-ended input mode can be specified for each input channel)
- Temperature sensor (internally connected to 16-bit  $\Delta\Sigma$  A/D converter)
- Power supply for external sensor (output voltage: 1.2 to 2.2 V)
- Internal system clock (OSC) oscillator (clock frequency: 20 MHz (Typ.))
- Power-on reset (POR) circuit
- Serial interface (SPI or UART communication is selectable)
- 256-byte flash memory for storing system configuration data
- Operating voltage range:  $2.7\text{ V} \leq V_{DD} \leq 5.5\text{ V}$
- Operating temperature range:
  - 125°C models:  $-40^{\circ}\text{C} \leq T_A \leq 125^{\circ}\text{C}$  (during normal operation)
  - 105°C models:  $-40^{\circ}\text{C} \leq T_A \leq 105^{\circ}\text{C}$  (during normal operation)
  - 125°C and 105°C models:  $10^{\circ}\text{C} \leq T_A \leq 85^{\circ}\text{C}$  (during flash memory programming)
- Package: 36-pin plastic FBGA (4 mm × 4 mm, 0.5-mm pitch)


**Caution** Flash memory programming refers to erasing or writing of data in the flash memory.

### Applications

- Industrial equipment for measuring items such as pressure, flow, and temperature
- Healthcare equipment for measuring items such as blood pressure and weight

## Ordering Information

Pin count	Package	Part Number
36 pins	36-pin plastic FBGA (4 × 4)	RAA7301013CBG, RAA7301014CBG



## How to Read This Manual

It is assumed that the readers of this manual have general knowledge of electrical engineering, logic circuits, and microcontrollers.

- To gain a general understanding of functions  
→ Read this manual in the order of the Contents.
- Revised points  
→ The mark “<R>” shows major revised points.  
The revised points can be easily searched by copying an “<R>” in the PDF file and specifying it in the “Find what:” field.

## Conventions

Data significance:	Higher digits on the left and lower digits on the right
Active low representations:	$\overline{\text{xxx}}$ (overscore over pin and signal name)
Note:	Footnote for item marked with Note in the text
Caution:	Information requiring particular attention
Remark:	Supplementary information
Numerical representations:	Binary ... $\text{xxxx}$ or $\text{xxxxB}$
	Decimal ... $\text{xxxx}$
	Hexadecimal ... $\text{xxxxH}$

## Contents

1. Pin Connection .....	6
1.1 Pin layout (Top View) .....	6
1.2 Block diagram .....	7
1.3 Pin functions .....	8
1.4 Connection of unused pins .....	9
1.5 I/O circuits .....	10
2. Input Multiplexer .....	12
2.1 Overview .....	12
2.2 Block diagram .....	12
2.3 Registers controlling input multiplexers .....	13
3. Programmable Gain Instrumentation Amplifier (PGIA) .....	14
3.1 Overview .....	14
3.2 Block diagram .....	15
3.3 Input voltage range .....	16
3.3.1 Input voltage range in differential input mode .....	16
3.3.2 Input voltage range in single-ended input mode and internal temperature sensor input mode .....	17
3.4 Registers controlling the programmable gain instrumentation amplifier (PGIA) .....	18
4. 16-bit $\Delta\Sigma$ A/D Converter .....	20
4.1 16-bit $\Delta\Sigma$ A/D converter .....	20
4.1.1 Overview .....	20
4.1.2 Block diagram .....	20
4.1.3 Voltage input to the 16-bit $\Delta\Sigma$ A/D converter and A/D conversion result .....	21
4.2 Digital filter .....	22
4.2.1 Overview .....	22
4.2.2 Block diagram .....	22
4.3 Registers controlling the 16-bit $\Delta\Sigma$ A/D converter .....	24
4.4 Operation of A/D converter (AUTOSCAN) .....	31
5. SPI .....	34
5.1 Overview .....	34
5.2 SPI command format .....	34
5.3 Timing of SPI communication operations .....	36
5.4 Registers controlling SPI communication .....	38
5.5 Note on Using the SPI .....	38
6. UART .....	39
6.1 Overview .....	39
6.2 Registers controlling UART communication .....	41
6.3 UART reception (UART command format) .....	43
6.4 UART transmission .....	45
6.5 Communication flow .....	48
6.6 Note on Using the UART .....	49
6.7 PWM direct input .....	50
6.8 Differential output .....	51
7. Interrupt Signal Output Function (for SPI Communication) .....	52
7.1 Overview .....	52
7.2 Block diagram .....	52
7.3 Registers controlling the interrupt signal output function .....	53


7.4	Operation of interrupt signal output function .....	56
<b>8.</b>	<b>Power Supply Circuit .....</b>	<b>57</b>
8.1	Overview .....	57
8.2	Block diagram of power supply circuit.....	57
8.3	Internal reference voltage generator (VREF).....	58
8.3.1	Overview.....	58
8.3.2	Block diagram.....	58
8.3.3	Registers controlling the internal reference voltage generator (VREF).....	59
8.3.4	Operation of internal reference voltage generator (VREF).....	59
8.4	Sensor power supply (SBIAS).....	60
8.4.1	Overview.....	60
8.4.2	Block diagram.....	60
8.4.3	Registers controlling the sensor power supply (SBIAS).....	61
8.4.4	Operation of sensor power supply (SBIAS).....	62
8.5	LDO regulator.....	63
8.5.1	AREG (AV <sub>DD</sub> /IOV <sub>DD</sub> power supply circuit).....	63
8.5.2	CREG (ADV <sub>DD</sub> /DV <sub>DD</sub> power supply circuit).....	65
8.5.3	LDO regulator operation in sleep mode.....	66
<b>9.</b>	<b>Power Supply Configuration .....</b>	<b>67</b>
9.1	Overview .....	67
9.2	Block diagrams of power supply configurations .....	68
9.3	Sequence of power-on, power-off, and switching to standby mode .....	71
9.4	Settings for flash memory programming .....	75
9.4.1	Low-power access (mainly for read access) .....	75
9.4.2	Settings for bypassing AREG to RVDD (for power supply configuration 2).....	75
9.4.3	Protection of power/mode control register (CHIPCNT).....	76
<b>10.</b>	<b>Clock Configuration .....</b>	<b>77</b>
10.1	Overview .....	77
10.2	Block diagram.....	77
10.3	Registers controlling clocks.....	78
<b>11.</b>	<b>Temperature Sensor.....</b>	<b>79</b>
11.1	Overview .....	79
11.2	Registers controlling the temperature sensor .....	79
<b>12.</b>	<b>Power-on-Reset (POR) Circuit.....</b>	<b>80</b>
12.1	Overview .....	80
12.2	Block diagram.....	80
12.3	Registers controlling the power-on-reset (POR) circuit.....	81
12.4	Operation of power-on-reset (POR) circuit .....	81
<b>13.</b>	<b>Flash Memory .....</b>	<b>82</b>
13.1	Overview .....	82
13.2	Registers controlling the flash memory .....	83
13.3	Startup (power-on) sequence .....	84
13.4	Commands controlling the flash memory.....	86
13.4.1	Controlling the flash memory by using SPI commands.....	86
13.4.2	Controlling the flash memory by using UART commands.....	87
<b>14.</b>	<b>Application Examples .....</b>	<b>88</b>

15. Electrical Specifications .....	90
15.1 Absolute maximum ratings .....	90
15.2 Operating conditions .....	91
15.3 Supply current characteristics .....	91
15.4 Electrical specifications of each block .....	92
15.4.1 Programmable gain instrumentation amplifier and 16-bit $\Delta\Sigma$ A/D converter .....	92
15.4.2 Internal reference voltage generator (VREF) .....	94
15.4.3 Sensor power supply (SBIAS) .....	94
15.4.4 AREG ( $AV_{DD}/IOV_{DD}$ power supply circuit) .....	94
15.4.5 CREG ( $ADV_{DD}/DV_{DD}$ power supply circuit) .....	95
15.4.6 Power-on-reset (POR) circuit .....	96
15.4.7 Temperature sensor .....	96
15.4.8 Internal system clock (OSC) oscillator .....	97
15.4.9 Flash memory .....	97
15.4.10 Digital I/O .....	97
15.5 SPI access timing .....	98
15.6 Cumulative power-on time and wake-up time .....	99
16. Chip Identification .....	101
16.1 Overview .....	101
16.2 Register for chip identification .....	101
17. Package Drawings .....	102
Characteristics Curve ( $T_A = 25^\circ\text{C}$ , TYP.) (reference value) .....	103

# 1. Pin Connection

## 1.1 Pin layout (Top View)

- 4 × 4 mm / 36-pin TFBGA (0.50 mm pitch)




6	AGND1	SBIAS	AIN2N	AIN2P	AIN1P	AGND6
5	VREF	AGND2	AGND3	AGND5	AIN3N	AIN1N
4	CREG	AV <sub>DD</sub>	DGND3	AGND4	AIN4N	AIN3P
3	AREG	IOV <sub>DD1</sub>	SMODE	DGND4	ADV <sub>DD</sub>	AIN4P
2	RV <sub>DD</sub>	IOV <sub>DD2</sub>	INT	TX_B	MCLK	DV <sub>DD</sub>
1	DGND1	MOSI_RX	MISO_TX	SCLK	CS_B	DGND2
	A	B	C	D	E	F

- Cautions 1.** Make the potential of AGND (AGND1 to AGND6) and DGND (DGND1 to DGND4) the same.
2. Make the potential of ADV<sub>DD</sub> and DV<sub>DD</sub> the same.
  3. Connect IOV<sub>DD1</sub> and IOV<sub>DD2</sub> directly.
  4. Make RV<sub>DD</sub> greater than or equal to IOV<sub>DD</sub>.
  5. Connect RV<sub>DD</sub> to AGND via a capacitor (0.47 μF recommended).
  6. Connect AREG to AGND via a capacitor (0.47 μF recommended).
  7. Connect CREG to AGND via a capacitor (0.22 μF recommended).
  8. Connect SBIAS to AGND via a capacitor (0.22 μF recommended).
  9. Connect VREF to AGND via a capacitor (0.1 μF recommended).
  10. Connect ADV<sub>DD</sub> to AGND via a capacitor (0.1 μF recommended).

- Remarks 1.** In this document, AGND1, AGND2, AGND3, AGND4, AGND5, and AGND6 are referred to as *AGND*.
2. In this document, DGND1, DGND2, DGND3, and DGND4 are referred to as *DGND*.
  3. In this document, IOV<sub>DD1</sub> and IOV<sub>DD2</sub> are referred to as *IOV<sub>DD</sub>*.

1.2 Block diagram



## 1.3 Pin functions

Table 1.1 Pin functions

Pin No.	Pin name	Analog/digital	I/O	I/O level	Description
A1	DGND1	–	–	–	Digital circuit ground pin 1
A2	RV <sub>DD</sub>	–	–	–	Regulator power supply
A3	AREG	A	Output	RV <sub>DD</sub>	3.0 V LDO output pin for supplying AV <sub>DD</sub>
A4	CREG	A	Output	AV <sub>DD</sub>	2.1 V LDO output pin for supplying ADV <sub>DD</sub>
A5	VREF	A	Output	AV <sub>DD</sub>	VREF voltage monitor pin
A6	AGND1	–	–	–	Analog circuit ground pin 1
B1	MOSI_RX	D	Input	IOV <sub>DD</sub>	SPI serial data input/UART data reception pin
B2	IOV <sub>DD2</sub>	–	–	–	I/O circuit power supply pin 2
B3	IOV <sub>DD1</sub>	–	–	–	I/O circuit power supply pin 1
B4	AV <sub>DD</sub>	–	–	–	Analog circuit power supply pin
B5	AGND2	–	–	–	Analog circuit ground pin 2
B6	SBIAS	A	Output	AV <sub>DD</sub>	Externally-connected sensor power supply pin
C1	MISO_TX	D	Output	IOV <sub>DD</sub>	SPI serial data input/UART data transmission pin
C2	INT	D	Output	IOV <sub>DD</sub>	Interrupt signal output pin
C3	SMODE	D	Input	IOV <sub>DD</sub>	Serial interface mode select pin
C4	DGND3	–	–	–	Digital circuit ground pin 3
C5	AGND3	–	–	–	Analog circuit ground pin 3
C6	AIN2N	A	Input	AV <sub>DD</sub>	Input multiplexer 2 (programmable gain instrumentation amplifier input pin 2 (negative))
D1	SCLK	D	Input	IOV <sub>DD</sub>	SPI serial clock input pin
D2	TX_B	D	Output	IOV <sub>DD</sub>	UART data transmission pin
D3	DGND4	–	–	–	Digital circuit ground pin 4
D4	AGND4	–	–	–	Analog circuit ground pin 4
D5	AGND5	–	–	–	Analog circuit ground pin 5
D6	AIN2P	A	Input	AV <sub>DD</sub>	Input multiplexer 2 (programmable gain instrumentation amplifier input pin 2 (positive))
E1	CS_B	D	Input	IOV <sub>DD</sub>	SPI chip select/UART reception mode select pin
E2	MCLK	D	I/O	IOV <sub>DD</sub>	Oscillator clock monitor pin (1 MHz)/external clock input pin (4 MHz)
E3	ADV <sub>DD</sub>	–	–	–	A/D converter power supply
E4	AIN4N	A	Input	AV <sub>DD</sub>	Input multiplexer 4 (programmable gain instrumentation amplifier input pin 4 (negative))
E5	AIN3N	A	Input	AV <sub>DD</sub>	Input multiplexer 3 (programmable gain instrumentation amplifier input pin 3 (negative))
E6	AIN1P	A	Input	AV <sub>DD</sub>	Input multiplexer 1 (programmable gain instrumentation amplifier input pin 1 (positive))
F1	DGND2	–	–	–	Digital circuit ground pin 2
F2	DV <sub>DD</sub>	–	–	–	Digital circuit power supply pin
F3	AIN4P	A	Input	AV <sub>DD</sub>	Input multiplexer 4 (programmable gain instrumentation amplifier input pin 4 (positive))
F4	AIN3P	A	Input	AV <sub>DD</sub>	Input multiplexer 3 (programmable gain instrumentation amplifier input pin 3 (positive))
F5	AIN1N	A	Input	AV <sub>DD</sub>	Input multiplexer 1 (programmable gain instrumentation amplifier input pin 1 (negative))
F6	AGND6	–	–	–	Analog circuit ground pin 6

**Remark** The digital I/O pins are compatible with the CMOS interface and Schmitt-triggered input.



## 1.4 Connection of unused pins

Table 1.2 shows the connection of unused pins.

**Table 1.2 Connection of unused pins**

Pin name	Analog/ digital	I/O	I/O level	Description
AREG	A	Output	RV <sub>DD</sub>	Connect to AGND via a capacitor (0.47 μF recommended). (When AREGPD = 1, connect it to RV <sub>DD</sub> .)
CREG	A	Output	AV <sub>DD</sub>	Connect to AGND via a capacitor (0.22 μF recommended).
VREF	A	Output	AV <sub>DD</sub>	Connect to AGND via a capacitor (0.1 μF recommended).
SBIAS	A	Output	AV <sub>DD</sub>	Connect to AGND via a capacitor (0.22 μF recommended).
AIN1P	A	Input	AV <sub>DD</sub>	Directly connect to AGND.
AIN1N	A	Input	AV <sub>DD</sub>	
AIN2P	A	Input	AV <sub>DD</sub>	
AIN2N	A	Input	AV <sub>DD</sub>	
AIN3P	A	Input	AV <sub>DD</sub>	
AIN3N	A	Input	AV <sub>DD</sub>	
AIN4P	A	Input	AV <sub>DD</sub>	
AIN4N	A	Input	AV <sub>DD</sub>	
CS_B <sup>Note</sup>	D	Input	IOV <sub>DD</sub>	Directly connect to IOV <sub>DD</sub> or DGND.
SCLK	D	Input	IOV <sub>DD</sub>	Directly connect to DGND.
MOSI_RX	D	Input	IOV <sub>DD</sub>	Directly connect to IOV <sub>DD</sub>
MISO_TX	D	Output	IOV <sub>DD</sub>	Leave this pin open.
TX_B	D	Output	IOV <sub>DD</sub>	Leave this pin open.
SMODE	D	Input	IOV <sub>DD</sub>	Directly connect to IOV <sub>DD</sub> or DGND.
INT	D	Output	IOV <sub>DD</sub>	Leave this pin open.
MCLK	D	I/O	IOV <sub>DD</sub>	Leave this pin open.

**Note** In SPI communication, the CS\_B pin is surely used. In UART communication, the CS\_B pin is used only when PWM direct input function is used. For details about PWM direct input function, see **6.7 PWM direct input**.

1.5 I/O circuits

Figure 1.1 I/O circuit type (1/2)









Pin name	Equivalent circuit	Pin name	Equivalent circuit
CS_B SCLK MOSI_RX SMODE	 <p>Schmitt-triggered input with hysteresis characteristics</p>	INT	
MISO_TX TX_B		MCLK	 <p>Schmitt-triggered input with hysteresis characteristics</p>

Figure 1.1 I/O circuit type (2/2)

Pin name	Equivalent circuit	Pin name	Equivalent circuit
AIN1P AIN1N AIN2P AIN2N AIN3P AIN3N AIN4P AIN4N		VREF	
AREG		CREG SBIAS	

## 2. Input Multiplexer

### 2.1 Overview

The input multiplexer has five analog input channels, four of which (input multiplexers 1 to 4) can be used to input an external signal, and the remaining one of which (input multiplexer 5) is connected to the internal temperature sensor. For input multiplexers 1 to 4, differential input mode or single-ended input mode can be selected for each channel. If single-ended input mode is selected, an internal bias voltage (VBIAS) is connected to the channel.

An internal bias voltage (VBIAS) is also connected to the channel to which the output from the internal temperature sensor is connected. For details about the internal bias voltage, see 8. *Power Supply Circuit*.

### 2.2 Block diagram




Figure 2.1 Block diagram of input multiplexer

## 2.3 Registers controlling input multiplexers

The following kind of register is used to control input multiplexers.

- Input multiplexer x (x = 1 to 4) A/D conversion setting register 2 (CHxCNT2)

### (1) Input multiplexer x (x = 1 to 4) A/D conversion setting register 2 (CHxCNT2)

These registers are used to specify differential input mode or single-ended input mode for each input multiplexer.

After reset, these registers are initialized to 10H.

Address: 11H After reset: 10H R/W

	7	6	5	4	3	2	1	0
CH1CNT2	AINSEL1	0	0	AIN1OFT4	AIN1OFT3	AIN1OFT2	AIN1OFT1	AIN1OFT0

<b>AINSEL1</b>	<b>Control of input multiplexer 1</b>
0	Differential input
1	Single-ended input

**Caution** Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

Address: 14H After reset: 10H R/W

	7	6	5	4	3	2	1	0
CH2CNT2	AINSEL2	0	0	AIN2OFT4	AIN2OFT3	AIN2OFT2	AIN2OFT1	AIN2OFT0

<b>AINSEL2</b>	<b>Control of input multiplexer 2</b>
0	Differential input
1	Single-ended input

**Caution** Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

Address: 17H After reset: 10H R/W

	7	6	5	4	3	2	1	0
CH3CNT2	AINSEL3	0	0	AIN3OFT4	AIN3OFT3	AIN3OFT2	AIN3OFT1	AIN3OFT0

<b>AINSEL3</b>	<b>Control of input multiplexer 3</b>
0	Differential input
1	Single-ended input

**Caution** Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

Address: 1AH After reset: 10H R/W

	7	6	5	4	3	2	1	0
CH4CNT2	AINSEL4	0	0	AIN4OFT4	AIN4OFT3	AIN4OFT2	AIN4OFT1	AIN4OFT0

<b>AINSEL4</b>	<b>Control of input multiplexer 4</b>
0	Differential input
1	Single-ended input

**Caution** Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

## 3. Programmable Gain Instrumentation Amplifier (PGIA)

### 3.1 Overview

The programmable gain instrumentation amplifier (PGIA) features low offset voltage, low 1/f noise, and high impedance. The PGIA operates in differential input mode, single-ended input mode, or internal temperature sensor input mode, according to the setting of the input multiplexer used.


In differential input mode, a gain from  $\times 1$  to  $\times 32$  ( $G_{TOTAL}$ ) can be specified by combining the gain in the preamplifier ( $G_{SET1}$ ) and the gain in the post amplifier ( $G_{SET2}$ ) in the instrumentation amplifier. In single-ended input mode, it is recommended that you set to  $1\times$  gain. The gain cannot be changed in internal temperature sensor input mode.  $G_{SET1}$  and  $G_{SET2}$  are internally fixed to 1 ( $G_{TOTAL} = 1$ ).

A D/A converter for adjusting the offset voltage is connected to the post amplifier. In differential input mode and single-ended input mode, the offset voltage can be adjusted (from  $-175$  mV to  $+164$  mV, in 32 steps (5 bits)) by using this D/A converter. In internal temperature sensor input mode, the offset voltage cannot be adjusted. The D/A converter output is internally fixed to 0 mV.


For details about controlling the programmable gain instrumentation amplifier (PGIA), see **4.4 Operation of A/D converter (AUTOSCAN)**.

3.2 Block diagram

Differential input mode



Single-ended input mode



Internal temperature sensor input mode




Figure 3.1 Block diagram of programmable gain instrumentation amplifier (PGIA)

### 3.3 Input voltage range

This section describes the range of voltage input to the programmable gain instrumentation amplifier (PGIA). Figure 3.2 shows the input voltage range in differential input mode, single-ended input mode, and internal temperature sensor input mode.




Figure 3.2 Input voltage range

#### 3.3.1 Input voltage range in differential input mode

$V_{SIG}$  indicates the input-referred amplitude of the differential voltage input signal,  $V_{COM}$  indicates the input-referred common mode input voltage, and  $dOFR$  indicates the input-referred D/A converter output voltage for adjusting the offset voltage. The voltage input to an amplifier should be 0.2 to 1.6 V. Therefore, the signal that passes through the preamplifier in the instrumentation amplifier and is then input to the post amplifier must satisfy the conditions in Formula 3.1.

The signal that passes through the preamplifier in the instrumentation amplifier and is then output from the post amplifier must satisfy the conditions in Formula 3.2.

$$0.2 \text{ V} + \frac{|V_{SIG}| \times G_{SET1}}{2} \leq V_{COM} \leq 1.6 \text{ V} - \frac{|V_{SIG}| \times G_{SET1}}{2} \quad \dots \text{Formula 3.1}$$

$$-0.7 \text{ V} \leq (V_{SIG} + dOFR) \times G_{TOTAL} \leq 0.7 \text{ V} \quad \dots \text{Formula 3.2}$$

When  $dOFR = 0 \text{ mV}$ , the input signal is equivalent to the full-scale differential input voltage.  $V_{COM}$  can be expressed by using Formula 3.3, where  $V_{SIG} = V_{ID}$  (full-scale differential input voltage).

$$0.2 \text{ V} + \frac{|V_{ID}| \times G_{SET1}}{2} \leq V_{COM} \leq 1.6 \text{ V} - \frac{|V_{ID}| \times G_{SET1}}{2} \quad \dots \text{Formula 3.3}$$

Figure 3.3 shows the transition of the differential input voltage level in each phase in the programmable gain instrumentation amplifier (PGIA).






Figure 3.3 Transition of the differential input voltage level in the PGIA

### 3.3.2 Input voltage range in single-ended input mode and internal temperature sensor input mode

In single-ended input mode and internal temperature sensor input mode, the internal bias voltage ( $V_{BIAS} = 0.9 \text{ V (Typ.)}$ ) is connected to the inverting input in the programmable gain instrumentation amplifier (PGIA) as a reference voltage. On the other hand, the signal from input multiplexer  $x$  ( $x = 1$  to  $5$ ) is connected to the non-inverting input in the PGIA.

A differential signal in the range of 0.2 to 1.6 V is output based on the reference voltage in  $G_{TOTAL}=1$  (in settings of  $G_{SET1}=1$  and  $G_{SET2}=1$ ). Because  $V_{BIAS}$  offset gains by  $G_{TOTAL}$ , and affects the accuracy of ADC conversion results in higher gain setting, it is recommended to set  $G_{TOTAL}=1$  ( $G_{SET1}=1$  and  $G_{SET2}=1$ ) in single-ended mode.

For details about the internal bias voltage, see 8. **Power Supply Circuit.**

### 3.4 Registers controlling the programmable gain instrumentation amplifier (PGIA)

The following two kinds of registers are used to control the programmable gain instrumentation amplifier (PGIA).

- Input multiplexer x (x = 1 to 4) A/D conversion setting register 1 (CHxCNT1)
- Input multiplexer x (x = 1 to 4) A/D conversion setting register 2 (CHxCNT2)

(1) Input multiplexer x (x = 1 to 4) A/D conversion setting register 1 (CHxCNT1)

These registers are used to specify the gain of the programmable gain instrumentation amplifier for input multiplexer x (x = 1 to 4). After reset, these registers are initialized to 40H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 10H (x = 1), 13H (x = 2), 16H (x = 3), 19H (x = 4) After reset: 40H R/W

	7	6	5	4	3	2	1	0
CHxCNT1	AINxOSR2	AINxOSR1	AINxOSR0	AINxGC4	AINxGC3	AINxGC2	AINxGC1	AINxGC0

AINxGC4	AINxGC3	AINxGC2	AINxGC1	AINxGC0	Gain setting		
					GSET1	GSET2	GTOTAL
0	0	0	0	0	1	1	1
0	0	1	0	0	2	1	2
0	1	0	0	0	3	1	3
0	1	1	0	0	4	1	4
1	0	0	0	0	8	1	8
0	0	0	0	1	1	2	2
0	0	1	0	1	2	2	4
0	1	0	0	1	3	2	6
0	1	1	0	1	4	2	8
1	0	0	0	1	8	2	16
0	0	0	1	0	1	4	4
0	0	1	1	0	2	4	8
0	1	0	1	0	3	4	12
0	1	1	1	0	4	4	16
1	0	0	1	0	8	4	32
0	0	0	1	1	1	8	8
0	0	1	1	1	2	8	16
0	1	0	1	1	3	8	24
0	1	1	1	1	4	8	32
Other than above					Setting prohibited		

(2) Input multiplexer x (x = 1 to 4) A/D conversion setting register 2 (CHxCNT2)

These registers are used to adjust the offset voltage for input multiplexer x (x = 1 to 4). The doFR (doFR is the input-referred value) which is the output voltage from D/A converter for adjusting the offset voltage is calculated by using the following formula:

$$\text{(Input-referred) D/A converter output voltage doFR (mV)} = (-175 + 350/32 \times m) \times 1/G_{SET1}$$

(m = 0 to 31: A value set to the CHxCNT2 register)

After reset, these registers are initialized to 10H.

For details, see 4.4 Operation of A/D converter (AUTOSCAN).

Address: 11H (x = 1), 14H (x = 2), 17H (x = 3), 1AH (x = 4) After reset: 10H R/W

	7	6	5	4	3	2	1	0
CHxCNT2	AINSELx	0	0	AINxOFT4	AINxOFT3	AINxOFT2	AINxOFT1	AINxOFT0

AINxOFT4	AINxOFT3	AINxOFT2	AINxOFT1	AINxOFT0	m (steps)	doFR (mV)
0	0	0	0	0	0	-175.00 / G <sub>SET1</sub>
0	0	0	0	1	1	-164.06 / G <sub>SET1</sub>
0	0	0	1	0	2	-153.13 / G <sub>SET1</sub>
...	...	...	...	...	...	...
...	...	...	...	...	...	...
...	...	...	...	...	...	...
1	0	0	0	0	16	0
...	...	...	...	...	...	...
...	...	...	...	...	...	...
...	...	...	...	...	...	...
1	1	1	0	1	29	+142.19 / G <sub>SET1</sub>
1	1	1	1	0	30	+153.13 / G <sub>SET1</sub>
1	1	1	1	1	31	+164.06 / G <sub>SET1</sub>

Caution1. Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

2. doFR (mV) is fixed to 0 (Number of steps (m) = 16) in internal temperature sensor input mode.

## 4. 16-bit $\Delta\Sigma$ A/D Converter

### 4.1 16-bit $\Delta\Sigma$ A/D converter

#### 4.1.1 Overview

The RAA730101 incorporates a 16-bit  $\Delta\Sigma$  A/D converter. The signal from input multiplexer x (x = 1 to 5) is input to the 16-bit  $\Delta\Sigma$  A/D converter via the programmable gain instrumentation amplifier (PGIA). The A/D conversion result is filtered by the SINC3 digital filter and is then stored in an output register.

A/D conversion is performed based on the clock generated in the internal system clock (OSC) oscillator (sampling frequency = 1 MHz (Typ.)). An external clock can also be used. (For details, see **10. Clock configuration.**) A/D conversion is performed based on a built-in sequencer called AUTOSCAN. The data rate (A/D conversion speed) can be specified for each channel. For details, see **4.4 Operation of A/D converter (AUTOSCAN).**

#### 4.1.2 Block diagram





Figure 4.1 Block diagram of 16-bit  $\Delta\Sigma$  A/D converter

### 4.1.3 Voltage input to the 16-bit ΔΣ A/D converter and A/D conversion result

This section describes the relationship between the voltage input to the 16-bit ΔΣ A/D converter and A/D conversion result. Figure 4.2 and Table 4.1 show the A/D conversion result when the full-scale range of voltage can be input to the A/D converter.

Differential input mode



Single-ended input mode (G<sub>TOTAL</sub> = 1)

Internal temperature sensor input mode




Figure 4.2 Digital output (A/D conversion result) and analog input (voltage input to the A/D converter)

Table 4.1 A/D-converted data

Differential input mode		Single-ended input mode(G <sub>TOTAL</sub> =1) and internal temperature sensor input mode	
Voltage input to A/D converter	A/D conversion result (2's complement)	Voltage input to A/D converter	A/D conversion result (straight binary)
+700 mV / (G <sub>TOTAL</sub> )	32767	1.6 V	65535
0 V	0	0.9 V	32768
-700 mV / (G <sub>TOTAL</sub> )	-32768	0.2 V	0

The A/D conversion result shown in Table 4.1 can be calculated by using the following formulas.

- Differential input mode

Voltage input to A/D converter =  $(1.4 \text{ V}/G_{TOTAL}) \times (\text{ADC DATA1} / 2^{16})$

ADC DATA1: 16-bit A/D conversion result (higher 8 bits stored in ADCH and lower 8 bits stored in ADCL) expressed as 2's complement
- Single-ended input mode(G<sub>TOTAL</sub>=1) and internal temperature sensor input mode

Voltage input to A/D converter =  $(1.4 \text{ V}/G_{TOTAL}) \times (\text{ADC DATA2} / 2^{16}) + 0.2 \text{ V}$

ADC DATA2: 16-bit A/D conversion result (higher 8 bits stored in ADCH and lower 8 bits stored in ADCL) expressed as straight binary


## 4.2 Digital filter

### 4.2.1 Overview

A SINC3 digital filter is used to downsample A/D conversion results. The digital filter transfer function is expressed by using the following equation. M in the equation of the transfer function represents the factor of decimation by the digital filter, which is itself determined by the OSR (oversampling ratio) set in the AINxOSRn register (x = 0 to 5, n = 0 to 2).

$$H(z) = \left[ \frac{1}{M} \cdot \frac{1 - z^{-M}}{1 - z^{-1}} \right]^3$$

### 4.2.2 Block diagram




**Figure 4.3 Block diagram of digital filter**

Figure 4.3 shows the block diagram of the digital filter. Three integrators and three differentiators are cascaded. Considering the A/D converter stabilization time, clock synchronization at the input stage in the digital filter, and a delay caused due to three stages of the differentiator, four times the sampling period (= 4 x 1/fout) is required as the settling time. (Because the A/D converter stabilization time is fixed to 64 μs or longer, it takes five times the sampling period when M = 64.)

**Remark** The settling time is automatically generated in a built-in sequencer called AUTOSCAN

Figure 4.4 shows the SINC3 filter frequency response.



**Figure 4.4 SINC3 filter frequency response where M = 64 and M = 256**

### 4.3 Registers controlling the 16-bit $\Delta\Sigma$ A/D converter

The following six kinds of registers are used to control the 16-bit  $\Delta\Sigma$  A/D converter.

- A/D converter control register (ADCCNT)
- Input multiplexer x (x = 1 to 5) A/D conversion setting register 1 (CHxCNT1)
- Input multiplexer x (x = 1 to 5) A/D conversion setting register 3 (CHxCNT3)
- A/D conversion result register 1 (ADCC)
- A/D conversion result register 2 (ADCH)
- A/D conversion result register 3 (ADCL)



## (1) A/D converter control register (ADCCNT)

This register is used to start and stop A/D converter operation. This register is also used to enable or disable A/D conversion of input signals for each input multiplexer channel.

After reset, this register is cleared to 00H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 0FH After reset: 00H R/W

	7	6	5	4	3	2	1	0
ADCCNT	ADSTART	0	0	AIN5ADC	AIN4ADC	AIN3ADC	AIN2ADC	AIN1ADC

<b>AIN1ADC</b>	<b>Signal from input multiplexer 1</b>
0	Enable A/D conversion.
1	Disable A/D conversion.

<b>AIN2ADC</b>	<b>Signal from input multiplexer 2</b>
0	Enable A/D conversion.
1	Disable A/D conversion.

<b>AIN3ADC</b>	<b>Signal from input multiplexer 3</b>
0	Enable A/D conversion.
1	Disable A/D conversion.

<b>AIN4ADC</b>	<b>Signal from input multiplexer 4</b>
0	Enable A/D conversion.
1	Disable A/D conversion.

<b>AIN5ADC</b>	<b>Signal from input multiplexer 5 (temperature sensor)</b>
0	Enable A/D conversion.
1	Disable A/D conversion.

<b>ADSTART</b>	<b>Control of A/D converter</b>
0	Stop A/D conversion.
1	Start A/D conversion.

**Caution** Bits 6 and 5 are read-only. (When these bits are read, 0 is always returned.)

## (2) Input multiplexer x (x = 1 to 5) A/D conversion setting register 1 (CHxCNT1)

These registers are used to specify the data rate (A/D conversion speed) for input multiplexer x (x = 1 to 5).

After reset, these registers are initialized to 40H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 10H (x = 1), 13H (x = 2), 16H (x = 3), 19H (x = 4) After reset: 40H R/W

	7	6	5	4	3	2	1	0
CHxCNT1	AINxOSR2	AINxOSR1	AINxOSR0	AINxGC4	AINxGC3	AINxGC2	AINxGC1	AINxGC0

Address: 1CH (x = 5) After reset: 40H R/W

	7	6	5	4	3	2	1	0
CH5CNT1	AIN5OSR2	AIN5OSR1	AIN5OSR0	0	0	0	0	0

**Caution** Bits 4 to 0 are read-only. (When these bits are read, 0 is always returned.)

AINxOSR2	AINxOSR1	AINxOSR0	OSR (oversampling ratio)	Data rate (sps)
0	0	0	64	15625.000
0	0	1	128	7812.500
0	1	0	256	3906.250
0	1	1	512	1953.125
1	0	0	1024	976.563
1	0	1	2048	488.281
Other than above			Setting prohibited	

**Remark** The A/D converter sampling clock frequency is set to 1 MHz (Typ.).

(3) Input multiplexer x (x = 1 to 5) A/D conversion setting register 3 (CHxCNT3)

These registers are used to specify the number of A/D conversions per AUTOSCAN cycle for input multiplexer x (x = 1 to 5). The number of A/D conversions N can be expressed by using the formula below.

After reset, these registers are cleared to 00H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

$$N = 32 \times (2^n - 1) + m \times 2^n \text{ (} m \text{ and } n \text{ correspond to the values set to the CHxCNT3 register)}$$


Address: 12H (x = 1), 15H (x = 2), 18H (x = 3), 1BH (x = 4), 1EH (x = 5) After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHxCNT3	AINxCT7	AINxCT6	AINxCT5	AINxCT4	AINxCT3	AINxCT2	AINxCT1	AINxCT0

AINxCT4	AINxCT3	AINxCT2	AINxCT1	AINxCT0	m
0	0	0	0	0	0
0	0	0	0	1	1
0	0	0	1	0	2
...	...	...	...	...	...
1	0	0	0	0	16
...	...	...	...	...	...
1	1	1	0	1	29
1	1	1	1	0	30
1	1	1	1	1	31

AINxCT7	AINxCT6	AINxCT5	n
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	0	0	4
1	0	1	5
1	1	0	6
1	1	1	7

Up to 256 levels can be selected by combining  $m$  and  $n$ . The following figure shows the correlation between the number of A/D conversions and the number of levels (0 to 255) calculated by using the register value.



**Figure 4.5** The number of A/D conversions and the number of levels calculated by using the register value (0 to 255)

## (4) A/D conversion result register 1 (ADCC)

This is a read-only register that is used to check the A/D conversion result. You can check the A/D conversion result parameters including the checksum, overflow flag, and the channel of input multiplexer corresponding to the conversion result. For details about a checksum, see **6. UART**.

After reset, this register is cleared to 00H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 0CH After reset: 00H R/-

	7	6	5	4	3	2	1	0
ADCC	ADCC7	ADCC6	ADCC5	ADCC4	ADCC3	ADCC2	ADCC1	ADCC0

ADCC3	ADCC2	ADCC1	ADCC0	Checksum calculated from A/D conversion result
1 / 0	1 / 0	1 / 0	1 / 0	Checksum

ADCC4	Flag that indicates whether A/D conversion result overflowed
0	No overflow (within range)
1	Overflow occurred (causing the register value to be the maximum value)

ADCC7	ADCC6	ADCC5	The channel corresponding to the conversion result
0	0	0	Invalid
0	0	1	Input multiplexer 1 (AIN1P/AIN1N)
0	1	0	Input multiplexer 2 (AIN2P/AIN2N)
0	1	1	Input multiplexer 3 (AIN3P/AIN3N)
1	0	0	Input multiplexer 4 (AIN4P/AIN4N)
1	0	1	Input multiplexer 5 (temperature sensor)
1	1	0	Invalid
1	1	1	Invalid

## (5) A/D conversion result register 2 (ADCH)

This is a read-only register that is used to check the A/D conversion result. This register stores the higher 8 bits of the 16-bit conversion result.

After reset, this register is cleared to 00H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 0DH After reset: 00H R/-

	7	6	5	4	3	2	1	0
ADCH	ADCH7	ADCH6	ADCH5	ADCH4	ADCH3	ADCH2	ADCH1	ADCH0

## (6) A/D conversion result register 3 (ADCL)

This is a read-only register that is used to check the A/D conversion result. This register stores the lower 8 bits of the 16-bit conversion result.

After reset, this register is cleared to 00H.

For details, see **4.4 Operation of A/D converter (AUTOSCAN)**.

Address: 0EH After reset: 00H R/-

	7	6	5	4	3	2	1	0
ADCL	ADCL7	ADCL6	ADCL5	ADCL4	ADCL3	ADCL2	ADCL1	ADCL0

#### 4.4 Operation of A/D converter (AUTOSCAN)


All operations controlling the A/D conversion are based on a built-in sequencer called AUTOSCAN. The AUTOSCAN operation starts when "1" is written to the ADSTART bit of the A/D converter control register (ADCCNT). The signal from input channels is A/D-converted in round-robin fashion.

Use the AIN5ADC, AIN4ADC, AIN3ADC, AIN2ADC, and AIN1ADC bits of the A/D converter control register (ADCCNT) to control whether to A/D-convert the signal from each input channel.


Use input multiplexer x (x = 1 to 5) A/D conversion setting register 3 (CHxCNT3) to specify the number of times A/D conversion is to be performed in an active channel until execution shifts to the next channel. If CHxCNT3 is set to 00H, it specifies single-shot operation, which stops A/D conversion each time when a conversion ends.

Use the AINxOSR2, AINxOSR1, and AINxOSR0 bits of input multiplexer x (x = 1 to 5) A/D conversion setting register 1 (CHxCNT1) to specify the data rate (A/D conversion speed) on a conversion channel.


The A/D conversion result is stored in read-only registers ADCC (for storing the checksum, overflow status, and the A/D-converted channel of the input multiplexer), ADCH (for storing the higher 8 bits of the conversion result), and ADCL (for storing the lower 8 bits of the conversion result).




**Example 1** When skipping A/D conversion of the signal from input channels  
 $AIN5ADC = AIN3ADC = AIN1ADC = 0$ ,  $AIN4ADC = AIN2ADC = 1$   
 $AIN1CTn [7:0] = 1$ ,  $AIN3CTn [7:0] = 2$ ,  $AIN5CTn [7:0] = 3$



**Example 2** To perform single-shot A/D conversion of the signal from channel 3  
 $AIN3ADC = AIN2ADC = AIN1ADC = 0$ ,  $AIN5ADC = AIN4ADC = 1$   
 $AINxCTn [7:0] > 0$  ( $x = 1, 2$ ) \*Value of input multiplexer x ( $x = 1$  or  $2$ ) A/D conversion setting register  
 $AIN3CTn [7:0] = 0$  \*Value of input multiplexer 3 A/D conversion setting register



**Example 3** When only the signal from channel 2 is A/D converted successively  
 $AIN2ADC = 0$ ,  $AIN5ADC = AIN4ADC = AIN3ADC = AIN1ADC = 1$   
 $AIN2CTn [7:0] > 0$  \*Value of input multiplexer 2 A/D conversion setting register



**Remark** The settling time is automatically generated in a built-in sequencer called AUTOSCAN

**Figure 4.6 AUTOSCAN sequence**



To transfer the A/D conversion result to a microcontroller, three types of communication, UART, SPI, and SPI which does not use an interrupt signal (INT), can be used. The simplified timing charts for each communication type are shown below. For details, see 5. *SPI* and 6. *UART*.




Figure 4.7 AUTOSCAN interface timing

## 5. SPI

### 5.1 Overview

The SPI interface is used to allow control from external devices by using clocked communication via four lines: a serial clock line (SCLK), a serial data input line (MOSI\_RX), a serial data output line (MISO\_TX), and a chip select input line (CS\_B).

SPI communication or UART communication is selected according to the SMODE pin setting. If a high level is input to the SMODE pin, SPI communication is selected. If a low level is input to the SMODE pin, UART communication is selected. Some SPI pins are also used as UART pins, which are selected according to the SMODE pin setting (exclusive use).

- SMODE = 1: SPI communication (TGLSM = 0)
- SMODE = 0: UART communication (TGLSM = 0)


<R> There is a point to note when using the SPI of the RAA730101. For details, see **5.5 Note on Using the SPI**.

**Caution** Clear the TGLSM bit of the startup sequence/communication control register (STARTUP) to "0". For details, see **13. Flash Memory**.


### 5.2 SPI command format

An SPI access is established by using a short access command or long access command. Which to use is determined according to the command used. For the detailed command definitions, see the table *SPI commands*. Because reading data from the flash memory takes a long time to start, the flash read command requires an access cycle equivalent to two commands.

#### Short access command



#### Long access command



- R/W 0: Read mode      1: Write mode  
 R/F 0: Register      1: Flash memory

The following table shows the SPI commands.

**Table 5.1 SPI commands**

No.	Name	Command				Extension	Description
		C7	C6	C5	C4 to C0	E7 to E0	
1	Register Read	0	0	1	Address: 00h to 1Fh	–	Reads 1 byte of data from the specified register.
2	Register Write	1	0	1	Address: 00h to 1Fh	–	Writes 1 byte of data to the specified register.
3	Register Burst Read	0	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Reads the specified length of data from the specified register successively. (Starting from the specified address)
4	Register Burst Write	1	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Writes the specified length of data to the specified register successively. (Starting from the specified address)
5	Register All Write from Flash	1	0	0	01111	–	Copies all data stored in the register shadow in the flash memory to the specified register.
6	Buffer Refresh	1	0	0	01100	–	Copies the default configuration data to the register buffer.
7	Flash (Burst) Read <sup>Note 3</sup>	0	1	0	11111	Start address 00h to FFh	Reads data from the flash memory. Specifies the address from which to start reading data. (First command)
		0	1	0	11100	Data length 00h to FFh <sup>Note 2</sup>	Reads data from the flash memory. Specifies the length of data to be read. (Second command)
8	Flash Write	1	1	0	11111	Address: 00h to FFh	Writes 1 byte of data to the flash memory.
9	Flash All Erase <sup>Note 3</sup>	1	1	1	11010	–	Erases all data in the flash memory. (First command)
		1	1	1	01011	–	Erases all data in the flash memory. (Second command)

**Notes** 1. Data length = “sum of C3 to C0 values” + 1 (Up to 16 bytes)


2. Data length = “sum of E7 to E0 values” + 1 (Up to 256 bytes)

3. To (burst) read and erase data in the flash memory, accessing the flash memory by successively using two commands is required.


### 5.3 Timing of SPI communication operations

The timing of SPI communication operations is shown below.

< Register Read / Register Burst Read >




< Register Write / Register Burst Write / Flash Write <sup>Note</sup> >




**Notes** There is not *burst function* for Flash write. Only writing 1 Byte data is available.

< Register All Write from Flash / Buffer Refresh >




**Figure 5.1** Timing of SPI communication operations

< Flash (Burst) Read >



**Figure 5.2 Timing of SPI communication operations (read access to the flash memory)**

< Flash Erase >



**Figure 5.3 Timing of SPI communication operations (erasing all the data of the flash memory)**

## 5.4 Registers controlling SPI communication

The following register is used to control SPI communication.

- Startup sequence/communication control register (STARTUP)

### (1) Startup sequence/communication control register (STARTUP)

This register is used to control flash memory access during the startup sequence and select the communication mode.

After reset, this register is cleared to 00H. For details, see **13. Flash Memory**.

Be sure to clear the TGLSM bit to “0”.

Address: 1FH After reset: 00H R/–

	7	6	5	4	3	2	1	0
STARTUP	0	0	0	TGLSM	0	0	SDCOR	CPSOR

TGLSM	Control of SMODE pin function
0	UART communication is selected when SMODE = 0, and SPI communication is selected when SMODE = 1.
1	Setting prohibited

**Caution** Bits 7, 6, 5, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

## <R> 5.5 Note on Using the SPI

Pay attention to the following point when using the SPI.

When the communicating node enters the reset state, the levels on the CS\_B and SCLK pins become undefined and the result of the first SPI communication after the other party is released from the reset state may be failure.

When using a communication mode where the level on the SCLK pin becomes high while the level on CS\_B pin is high, confirm that the CHIPID can be read correctly after the other party is released from the reset state, and then start the communications that are actually required.

## 6. UART

### 6.1 Overview


A full duplex operational communication interface is available by using two lines: a serial data transmission line (TxD) and a serial data reception line (RxD). Using these two communication lines, a data frame (a packet ; its character length = 10-12bits), which consists of a start bit, data, parity bit, and stop bit, is transmitted and received asynchronously (using an internal baud rate) with a communicating node.

There is a point to note when using the UART of the RAA730101. For details, see **6.6 Note on Using the UART**.

SPI communication or UART communication is selected according to the SMODE pin setting. If a high level is input to the SMODE pin, SPI communication is selected. If a low level is input to the SMODE pin, UART communication is selected. Some UART pins are also used as SPI pins, which are selected according to the SMODE pin setting (exclusive used).

- SMODE = 1: SPI communication (TGLSM = 0)
- SMODE = 0: UART communication (TGLSM = 0)

**Caution** Clear the TGLSM bit of the startup sequence/communication control register (STARTUP) to "0". For details, see **13. Flash Memory**.



**Figure 6.1 UART packet format**

By default, the baud rate is 4.8 kbps, no parity, and the number of stop bits is 1. This default setting is used for the first communication after a power-on reset. If you want to use a setting other than the default for the first communication after a power-on reset, store the configuration data you want to use in the register shadow in the flash memory in advance. For details, see **13. Flash Memory**.

UART communication parameters such as the baud rate, parity bit, and stop bit can be selected by using a register. For details, see **6.2 Registers controlling UART communication**.

As special features, PWM direct input using the Rx pin and differential output using the Tx pin are available. For details, see **6.7 PWM direct input** and **6.8 Differential output**.

There is a time out feature for UART reception and transmission. For details, see **6.3 UART reception (UART command format)** and **6.4 UART transmission**.

The following shows an overview of the UART.

**Table 6.1 Overview of UART**

	Receiver side (Rx communication)	Transmitter side (Tx communication)
Baud rate	4.8 kbps (default) or 250 kbps (Selectable by using the RXBR bit in the setting register)	4.8 kbps (default) or 250 kbps (Selectable by using the TXBR bit in the setting register)
Signal format	NRZ <sup>Note 1</sup> or PWM <sup>Note 2</sup> (Selected according to the CS_B pin level)	NRZ <sup>Note 1</sup>
Packet format (character length = 10-12bits)	Start bit - 1 bit (fixed)	
	Data length - 8 bits (fixed) - LSB first	
	Parity setting - No parity (default) - Odd parity (Selectable by using the PEN and EPS bits in the setting register) - Even parity (Selectable by using the PEN and EPS bits in the setting register)	
	Number of stop bits - 1 bit (default) - 2 bits (Selectable by using the STB bit in the setting register register)	
Time-out time	Character length × 2	
Special function	PWM direct input	Differential output

- Notes**
1. NRZ: Non Return to Zero
  2. PWM: Pulse Width Modulation



## 6.2 Registers controlling UART communication

The following two kinds of registers are used to control UART communication.

- Startup sequence/communication control register (STARTUP)
- Clock/UART control register (UARTCNT)

### (1) Startup sequence/communication control register (STARTUP)

This register is used to control flash memory access during the startup sequence and select the communication mode. After reset, this register is cleared to 00H. For details, see **13. Flash Memory**.  
Be sure to clear the TGLSM bit to “0”.

Address: 1FH After reset: 00H R/-

	7	6	5	4	3	2	1	0
STARTUP	0	0	0	TGLSM	0	0	SDCOR	CPSOR

TGLSM	Control of SMODE pin function
0	UART communication is selected when SMODE = 0, and SPI communication is selected when SMODE = 1.
1	Setting prohibited

**Caution** Bits 7, 6, 5, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

(2) Clock/UART control register (UARTCNT)

This register is used to specify UART parameters and control the clock configuration.

After reset, this register is cleared to 00H.

Address: 08H After reset: 00H R/W

	7	6	5	4	3	2	1	0
UARTCNT	EXTCLK	MONIOUT	DIFFOUT	STB	EPS	PEN	TXBR	RXBR

<b>RXBR</b>	<b>Baud rate during reception</b>
0	4.8 kbps (default)
1	250 kbps

<b>TXBR</b>	<b>Baud rate during transmission</b>
0	4.8 kbps (default)
1	250 kbps

<b>PEN</b>	<b>Enabling/disabling the parity bit</b>
0	No parity (default)
1	A parity bit is generated (checked)

<b>EPS</b>	<b>Parity bit selection</b>
0	Odd parity (default): The number of 1s in each set of written bits must be an odd number.
1	Even parity: The number of 1s in each set of written bits must be an even number.

<b>STB</b>	<b>Number of stop bits</b>
0	1 bit (default)
1	2 bits

<b>DIFFOUT</b>	<b>Differential output during transmission</b>
0	Disable differential output (default)
1	Enabled differential output

**Remark** When DIFFOUT is set to 0, the output of the TX\_B pin becomes high impedance. The TX\_B pin can be left open when it is not used. For details, see **1.4 Connection of unused pins**.

### 6.3 UART reception (UART command format)


Like SPI commands, UART commands require a 1- or 2-byte packet for each command (see **5.2 SPI command format**). Message reception might take a time-out if the interval of each packet that makes up a message could not be within a period of two character length. If packet reception fails due to a time-out, the UART receiver is initialized.

There are two commands dedicated to UART communication. One is a "baud rate correction" command. If this command is received, a message that consists of 9-bits logical low level (= start bit + 0000\_0000b) is output from the transmission output pin. An external device can adjust the baud rate by counting the number of low cycles.


The other is a "Send request" command. If this command is received, a message that was transmitted last is transmitted again. By using this command, an external device can regain a message which was lost due to a parity error or checksum error. "Send request" is available only for a deferred response, which is described in a later section.

There is a point to note regarding the UART reception. For details, see **6.6 Note on Using the UART**.

#### Short access command



#### Long access command



R/W 0: Read mode    1: Write mode  
 R/F 0: Register    1: Flash memory

The following table shows the UART commands.

**Table 6.2 UART commands**

No.	Name	Command				Extension	Description
		C7	C6	C5	C4 to C0	E7 to E0	
1	Register Read	0	0	1	Address: 00h to 1Fh	–	Reads 1 byte of data from the specified register.
2	Register Write	1	0	1	Address: 00h to 1Fh	–	Writes 1 byte of data to the specified register.
3	Register Burst Read	0	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Reads the specified length of data from the specified register successively. (Starting from the specified address)
4	Register Burst Write	1	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h-1Fh	Writes the specified length of data to the specified register successively. (Starting from the specified address)
5	Register All Write from Flash	1	0	0	01111	–	Copies all data stored in the register shadow in the flash memory to the specified register.
6	Buffer Refresh	1	0	0	01100	–	Copies the default configuration data to the register buffer.
7	Flash (Burst) Read <sup>Note 3</sup>	0	1	0	11111	Start address 00h to FFh	Reads data from the flash memory. Specifies the address from which to start reading data. (First command)
		0	1	0	11100	Data length 00h to FFh <sup>Note 2</sup>	Reads data from the flash memory. Specifies the length of data to be read. (Second command)
8	Flash Write	1	1	0	11111	Address 00h to FFh	Writes 1 byte of data to the flash memory.
9	Flash All Erase <sup>Note 3</sup>	1	1	1	11010	–	Erases all data in the flash memory. (First command)
		1	1	1	01011	–	Erases all data in the flash memory. (Second command)
10	Baud rate correction	0	0	0	00000	–	Corrects the baud rate. (Only available in UART communication)
11	Send request	0	0	0	01111	–	Requests re-transmission of the message transmitted last. (Only available in UART communication)

- Notes**
1. Data length = “sum of C3 to C0 values” + 1 (Up to 16 bytes)
  2. Data length = “sum of E7 to E0 values” + 1 (Up to 256 bytes)
  3. To (burst) read and erase data in the flash memory, accessing the flash memory by successively using two commands is required.


### 6.4 UART transmission

A UART transmission message has three types of the structures shown below.


A type 1 message is transmitted in response to Register Read, Register Burst Read or Flash (Burst) Read command shown in the table of *UART commands*. A type 2 message is transmitted automatically when A/D conversion ends. A type 3 message is transmitted automatically when an interrupt request is generated. A type 3 message is equivalent to the INT signal used in SPI communication. (For details, see 7. *Interrupt signal output function (for SPI communication)*.)

Message transmission might take a time-out if the interval of each packet that makes up a message could not be within a period of two character length.


#### Type 1: Response to Register (Burst) Read or Flash (Burst) Read



#### Type 2: A/D conversion result



#### Type 3: Status report



**Figure 6.2 Transmission message structure**

The type 1 message consists of the header which describes the data length of read data, the start address of read data and read data. The maximum data length which the header can describe is 32 bytes. If the data length of read data is 32 bytes or more, an additional packet that indicates the actual data length (data length = n-1; 32 to 256 bytes) is inserted following to the header in the message.

The type 2 message consists of the header, A/D conversion result (higher bytes) and A/D conversion result (lower bytes). These three contents corresponds to the information of A/D conversion result register 1 (ADCC), A/D conversion result register 2 (ADCH), A/D conversion result register 3 (ADCL). The header of the type 2 message reserves the information of the checksum, the overflow status and the input channel which is A/D converted. The overflow flag in a type 2 header indicates whether the A/D conversion result has been clipped to the maximum value that can be stored in the register.

The type 3 message consists of the header which describes the status. The definitions of flags included in type 3 are shown below. These flags have the same meaning as that indicated in the interrupt signal flag indication register (INTFLAG). (For details, see **7.3 Registers controlling the interrupt signal output function.**) Note, however, that the F4 bit is not the ADC flag but the PE flag. This is because the A/D conversion result is transmitted automatically when the A/D conversion ends in UART communication, and therefore the ADC flag is not required.

Like SPI communication, the RAW flag is also set when the Buffer Refresh command (see No. 6 in the table *UART commands*) is executed.

- F0: Flash Read ready (FR flag)
- F1: Flash Write (FW flag)
- F2: Flash All Erase (FAE flag)
- F3: Register All Write (RAW flag)
- F4: Parity Error at the last reception (PE flag)


If the logic of one of the five flags included in a message becomes high, transmitting an interrupt request is enabled and the message is automatically transmitted. A communication error can be detected by checking the bit arrangement, even if a parity bit is disabled.

To transmit an A/D conversion result successively by using the UART, the baud rate must be set to 250 kbps. Even though the baud rate is set to 250 kbps, the communication speed becomes insufficient and UART transmission fails under the condition when the oversampling ratio (OSR) for A/D conversion is set to 64, or when the oversampling ratio (OSR) is set to 128 with the parity bit enabled or with the number of stop bits set to 2.


If A/D conversion result is not transmitted successively (but by just one time, or by single-shot), there is no restriction on the communication speed.

The checksum can be calculated as follows. When verifying the checksum from an external device, see the relevant checksum calculation.

How to calculate a checksum for type 1 (response to Register Read or Flash Read)



How to calculate a checksum for type 2 (A/D conversion result)



**Figure 6.3 Checksum calculation**

### 6.5 Communication flow

Some instant responses always occur, regardless of the command conditions including whether the command has finished normally or abnormally. In addition to instant responses, deferred responses are also sent asynchronously in terms of some commands.

Any new command is ignored until a series of command and response (including a deferred response) is completed. The table below shows the relationship between received commands and transmitted responses.

*Abnormal end* shown for type 3 (PE) indicates that an error such as a parity error and framing error has occurred, or an execution error such as a flash memory access being attempted while flash memory access is prohibited has occurred.

Because A/D conversion results are transmitted asynchronously, a *conflict* might occur. The messages of responses (data) are retained in the transmission buffer as much as possible. If the *conflict* continues for a long time, however, the transmission buffer becomes full, which causes the A/D conversion results to be lost because the transmission buffer is updated periodically. Therefore, it is not recommended to issue a reception command while A/D conversion results are transmitted.

**Table 6.3 Relationship between reception commands and transmitted responses**

Reception command			Transmitted response				
No.	Name	→	Instant response (normal end) <sup>Note 1</sup>	or	Instant response (abnormal end) <sup>Note 2</sup>	→	Deferred response <sup>Note 3</sup>
1	Register Read	→	Type 1	or	Type 3 (PE)		
2	Register Write	→	Type 3 (normal end)	or	Type 3 (PE)		
3	Register Burst Read	→	Type 1	or	Type 3 (PE)		
4	Register Burst Write	→	Type 3 (normal end)	or	Type 3 (PE)		
5	Register All Write from Flash	→	Type 3 (normal end)	or	Type 3 (PE)	→	Type 3 (RAW)
6	Buffer Refresh	→	Type 3 (normal end)	or	Type 3 (PE)	→	Type 3 (RAW)
7	Flash (Burst) Read (First command)	→	Type 3 (normal end)	or	Type 3 (PE)	→	Type 3 (FR)
	Flash (Burst) Read (Second command)	→	Type 1	or	Type 3 (PE)		
8	Flash Write	→	Type 3 (normal end)	or	Type 3 (PE)	→	Type 3 (FW)
9	Flash All Erase	→	Type 3 (normal end)	or	Type 3 (PE)	→	Type 3 (FAE)
10	Baud rate correction	→	Zero data (0000_0000b)	or	Type 3 (PE) <sup>Note 4</sup>		
11-1	Send request (when ADSTART = 0)	→	Type 3, excluding PE	or	Type 3 (PE)		
11-2	Send request (when ADSTART = 1)	→	Type 2	or	Type 3 (PE)		
A/D conversion results (when ADSTART = 1)						→	Type 2
-No reception command is required since A/D conversion results are transmitted automatically.							

- Notes**
- The type-3 (normal end) message indicates interrupt flag Fx = 0 (x = 0 to 4). ("00000111" in LSB first)
  - A type-3 (PE) response is transmitted if an error occurs during command reception or command execution. (A type-3 (PE) response = "00001111" in LSB first)
  - A deferred response is transmitted asynchronously when a flash memory access finished or the A/D conversion result is updated.
  - Four-bit zero data ("0000xxxx" in LSB first) always occurs, even if a command ends abnormally. Therefore, zero data ("00000000" in LSB first) that occurs when a command ends normally must be distinguished when adjusting the baud rate.



## 6.6 Note on Using the UART

Pay attention to the following point when using the UART.

### <R> (1) Disabling the reception by the UART

The receiver of UART turns to be disabled under the condition both Non parity (PEN = 0) and low-level signal is input to the pin of MOSI\_Rx for the period of the three times of character length or more. Once the receiver of UART becomes disabled, only power on reset by external power supply can make the receiver of UART enabled again.

The examples of condition which make the receiver of UART disabled are described below.

- After powered on, low-level signal continued to be input to the pin of MOSI\_Rx for more than 5ms.
- After the baud rate of the RAA730101 is set to be 250kbps (RXBR = 1), the external device tries to communicate with the RAA730101 using the baud rate of 4.8kbps.

To avoid the unexpected situation that the receiver of UART is disabled, be sure to carry the operations as described below into effect.

1. Connect the pin of MOSI\_Rx and the pin of MISO\_Tx to IOV<sub>DD</sub> via a resistor.
2. When the baud rate of the RAA730101 is set to be 250kbps (RXBR = 1), be sure to set the parity bit enabled (PEN = 1).

The parity bit enabled (PEN = 1) is recommended even if the baud rate of the RAA730101 is 4.8kbps (RXBR = 0). If you use the copy function from Register shadow of flash memory to register to set the baud rate 250kbps (RXBR = 1), you must set the parity bit enabled (PEN = 1) by the copy function, too. For details about the copy function from Register shadow of flash memory to register, see **13. Flash Memory**.

### <R> (2) Reading the ADSTART bit

While communications by the UART are in progress, and only then, the value of ADSTART bit cannot be read correctly. To check for the start of A/D conversion (whether writing to the ADSTART bit was successful or failed), check whether a type 3 normal end was returned as the instant response to the writing.

To check for the state of operation of the A/D converter (the value of the ADSTART bit), read the bit twice and treat the second value as the true value.

### 6.7 PWM direct input

In the RAA730101, the logic level of the NRZ signal can be set to high (= 1) or low (= 0) according to the duty ratio of the PWM signal. This feature assumes use in isolated communication. The PWM direct input feature is enabled by inputting a high level to the CS\_B pin. The logic level of the NRZ signal becomes high (= 1) when the duty of the PWM signal is 75%, and becomes low (= 0) when the duty of the PWM signal is 25%.

Conventionally, an analog filter has been used to demodulate the PWM signal to the NRZ signal. In the RAA730101, a digital PWM filter is used to directly input PWM, instead of the analog filter.




Figure 6.4 Special UART feature 1 - PWM direct input





Figure 6.5 Timing of PWM filtering

### 6.8 Differential output

Differential output is used to enlarge the output amplitude and improve noise robustness. Differential output can be enabled by setting the DIFFOUT bit of the Clock/UART control register (UARTCNT). For details, see 6.2 *Registers controlling UART communication*.



**Figure 6.6 Special UART feature 2 - Differential output**

## 7. Interrupt Signal Output Function (for SPI Communication)

### 7.1 Overview

The RAA730101 has an interrupt signal output function. This feature is available only when using SPI communication. The interrupt signal output function outputs a high level from the INT pin when A/D conversion or flash memory access finishes. By inputting this output signal to an external device connected to the RAA730101 as an interrupt (INT) signal, the status of A/D conversion or flash memory access can be reported to the external device. For details, see **7.4 Operation of interrupt signal output function**.

### 7.2 Block diagram




Figure 7.1 Structure of interrupt (INT) signal output function

### 7.3 Registers controlling the interrupt signal output function

The following three kinds of registers are used to control the interrupt signal output function.

- Interrupt mask setting register (INTMASK)
- Interrupt flag indication register (INTFLAG)
- Processing status indication register (STATUS)

(1) Interrupt mask setting register (INTMASK)

This register is used to enable or disable the output of interrupt signals.

After reset, this register is cleared to 00H.

Address: 04H After reset: 00H R/W

	7	6	5	4	3	2	1	0
INTMASK	0	0	0	MADC	MRAW	MFAE	MFW	MFR

<b>MFR</b>	<b>Outputting an interrupt signal in response to Flash Read</b>
0	Enable output of interrupts.
1	Disable output of interrupts. (Mask output of interrupts.)

<b>MFW</b>	<b>Outputting an interrupt signal in response to Flash Write</b>
0	Enable output of interrupts.
1	Disable output of interrupts. (Mask output of interrupts.)

<b>MFAE</b>	<b>Outputting an interrupt signal in response to Flash All Erase</b>
0	Enable output of interrupts.
1	Disable output of interrupts. (Mask output of interrupts.)

<b>MRAW</b>	<b>Outputting an interrupt signal in response to Register All Write</b>
0	Enable output of interrupts.
1	Disable output of interrupts. (Mask output of interrupts.)

<b>MADC</b>	<b>Outputting an interrupt signal in response to A/D conversion</b>
0	Enable output of interrupts.
1	Disable output of interrupts. (Mask output of interrupts.)

**Caution** Bits 7 to 5 are read-only. (When these bits are read, 0 is always returned.)

## (2) Interrupt flag indication register (INTFLAG)

This is a flag register that indicates whether an interrupt signal is ready to be output.

After reset, this register is cleared to 00H.

Address: 05H After reset: 00H R/-

	7	6	5	4	3	2	1	0
INTFLAG	0	0	0	ADC	RAW	FAE	FW	FR

<b>FR</b>	<b>Interrupt flag indication for Flash Read</b>
0	Output is not ready
1	Output is ready

<b>FW</b>	<b>Interrupt flag indication for Flash Write</b>
0	Output is not ready
1	Output is ready

<b>FAE</b>	<b>Interrupt flag indication for Flash All Erase</b>
0	Output is not ready
1	Output is ready

<b>RAW</b>	<b>Interrupt flag indication for Register All Write</b>
0	Output is not ready
1	Output is ready

<b>ADC</b>	<b>Interrupt flag indication for A/D conversion</b>
0	Output is not ready
1	Output is ready

**Caution** When bits 7 to 5 are read, 0 is always returned.

## (3) Processing status indication register (STATUS)

This register indicates the processing status of Flash Write, Flash ALL Erase, Register All Write, and A/D conversion. After reset, this register is cleared to 00H.

Address: 06H After reset: 00H R/-

	7	6	5	4	3	2	1	0
STATUS	0	0	0	ADCIP	RAWIP	FAEIP	FWIP	0

FWIP	Flash Write processing status
0	Processing finished
1	Processing in progress

FAEIP	Flash All Erase processing status
0	Processing finished
1	Processing in progress

RAWIP	Register All Write processing status
0	Processing finished
1	Processing in progress

ADCIP	A/D conversion processing status
0	Processing finished
1	Processing in progress

**Caution** When bits 7 to 5 and 0 are read, 0 is always returned.

### 7.4 Operation of interrupt signal output function

When any of the commands Flash Write, Flash ALL Erase, and Register All Write, or a command that triggers A/D conversion is executed by using SPI communication, the corresponding bit in the processing status indication register (STATUS) is set to 1. When the above processing has finished, the corresponding bit in the processing status indication register (STATUS) is cleared to 0. At this time, the corresponding bit in the interrupt flag indication register (INTFLAG) is set to 1, and a high-level interrupt (INT) signal is output from the INT pin. When the interrupt flag indication register (INTFLAG) is read, it is cleared to 0, and the output of the INT pin goes low.

When the first command of Flash Read is executed, the corresponding bit in the interrupt flag indication register (INTFLAG) is set to 1, and a high-level interrupt (INT) signal is output from the INT pin. When the second command of Flash Read is executed, the interrupt flag indication register (INTFLAG) is cleared to 0, and the output of the INT pin goes low.

The interrupt mask setting register (INTMASK) controls the high-level interrupt (INT) signal output from the INT pin. (See Figure 7.1 *Structure of interrupt signal output function.*) If operation of Flash Read, Flash Write, Flash ALL Erase, Register All Write, or A/D conversion is masked by using the interrupt mask setting register (INTMASK), a high-level interrupt (INT) signal is not output even when the operation has finished. Outputting an interrupt (INT) signal for A/D conversion and an accessing to the flash memory is exclusive. If the ADSTART bit of the A/D converter control register (ADCCNT) is set to 1, an interrupt (INT) signal for a flash memory access is not output. (For details, see 4.3 *Registers controlling the 16-bit  $\Delta\Sigma$  A/D converter.*)

Like SPI communication, the RAW flag is also set when the Buffer Refresh command (see No. 6 in the table *UART commands*) is executed. When the Buffer Refresh command is executed and its processing has finished, the corresponding bit in the interrupt flag indication register (INTFLAG) is set to 1, and a high-level interrupt (INT) signal is output from the INT pin.

Instead of using the INT pin, you can check the status of A/D conversion or an accessing to the flash memory by constantly monitoring the processing status indication register (STATUS).




Figure 7.2 Interrupt signal (INT) output timing (for Flash Write command)




Figure 7.3 Interrupt signal (INT) output timing (for Flash (Burst) Read command)




## 8. Power Supply Circuit

### 8.1 Overview

The RAA730101 has a power supply circuit for supplying power to internal circuits and external devices. The power supply circuit consists of a 2-channel bandgap reference circuit (high-precision BGR and low-power BGR), 2-channel LDO regulator (AREG and CREG), and a sensor (external device) power supply (SBIAS). For details about the power supply configuration, see **9. Power Supply Configuration**.

### 8.2 Block diagram of power supply circuit



Note Capacitance values are recommended values.

**Figure 8.1 Block diagram of power supply circuit**


### 8.3 Internal reference voltage generator (VREF)

#### 8.3.1 Overview

The internal reference voltage generator (VREF) consists of a high-precision BGR and an analog circuit reference voltage generator (AFE VREF). VREF generates a reference voltage for CREG and SBIAS based on the voltage output from the high-precision BGR. The voltage output from the high-precision BGR passes through SBIAS and AFE VREF, and is then used as a reference voltage in the A/D converter and D/A converter, and as an internal bias voltage (VBIAS) to be connected to input multiplexers. The high-precision BGR can achieve high precision in the output voltage because it is less dependent on the temperature.

By connecting an external capacitor of 0.1  $\mu\text{F}$  (recommended) to the VREF pin, the internal reference voltage generator (VREF) is equipped with a low-pass filter that consists of an on-chip resistor and this external capacitor.

#### 8.3.2 Block diagram



**Figure 8.2 Block diagram of internal reference voltage generator (VREF)**

### 8.3.3 Registers controlling the internal reference voltage generator (VREF)

The following register is used to control the internal reference voltage generator (VREF).

- Power/mode control register (CHIPCNT)

#### (1) Power/mode control register (CHIPCNT)

This register is used to set the internal reference voltage generator (VREF) to normal operation or sleep mode.

After reset, this register is cleared to 00H.

For details, see **8.3.4 Operation of internal reference voltage generator (VREF)**.

Address: 01H After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHIPCNT	0	0	PSTHRU	AREGPD	0	0	SENSPD	SLP

SLP	Control of sleep mode
0	Normal operation
1	Sleep mode

**Caution** Bits 7, 6, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

### 8.3.4 Operation of internal reference voltage generator (VREF)

The SLP bit of the power/mode control register (CHIPCNT) sets the high-precision BGR to sleep mode. To shift to sleep mode, the result of logical operations using data of the SLP bit and data input to the SMODE pin is used. When "1" is written to the SLP bit of the power/mode control register (CHIPCNT) during SPI communication (SMODE = 1), the high-precision BGR shifts to sleep mode and stops operating. During UART communication (SMODE = 0), on the other hand, the high-precision BGR is in normal operating mode.

When SBIAS stops operating, AFE VREF also stops operating even if the high-precision BGR operates normally. As a result, a reference voltage in the A/D converter and D/A converter, and an internal bias voltage (VBIAS) to be connected to input multiplexers, are not generated. For details about SBIAS, see **8.4 Sensor power supply (SBIAS)**.

## 8.4 Sensor power supply (SBIAS)


### 8.4.1 Overview

SBIAS supplies power to the sensor connected to the RAA730101. A reference voltage is input from VREF. SBIAS outputs a voltage between 1.2 and 2.2 V, which can be specified in units of 0.1 V. Output current of 5 mA or less can be provided. An external capacitor of 0.22  $\mu$ F (recommended) must be connected to the SBIAS pin.

SBIAS has a protection circuit against an overcurrent. When an overcurrent occurs, the protection circuit works to protect the internal circuits. SBIAS also has a circuit that monitors and detects the voltage output by SBIAS.

The reference voltage output from VREF passes through SBIAS and is then used as a reference voltage in the A/D converter and D/A converter, and as an internal bias voltage (VBIAS) to be connected to input multiplexers. For details, see **8.4.4 Operation of sensor power supply (SBIAS)**.

### 8.4.2 Block diagram



**Figure 8.3 Block diagram of sensor power supply (SBIAS)**

### 8.4.3 Registers controlling the sensor power supply (SBIAS)

The following two kinds of registers are used to control the sensor power supply (SBIAS).

- Power/mode control register (CHIPCNT)
- Sensor power supply voltage setting register (VSBIAS)

(1) Power/mode control register (CHIPCNT)

This register is used to set the sensor power supply (SBIAS) to normal operation or sleep mode, or stop the operation. After reset, this register is cleared to 00H.

For details, see **8.4.4 Operation of sensor power supply (SBIAS)**.

Address: 01H After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHIPCNT	0	0	PSTHRU	AREGPD	0	0	SENSPD	SLP

SLP	Control of sleep mode
0	Normal operation
1	Sleep mode

SENSPD	Control of SBIAS operation
0	Normal operation
1	Stops operation.

**Caution** Bits 7, 6, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

## (2) Sensor power supply voltage setting register (VSBIAS)

This register is used to specify the SBIAS output voltage. After reset, this register is cleared to 00H.

Address: 02H After reset: 00H R/W

	7	6	5	4	3	2	1	0
VSBIAS	0	0	0	0	VSBIAS3	VSBIAS2	VSBIAS1	VSBIAS0

VSBIAS3	VSBIAS2	VSBIAS1	VSBIAS0	Voltage output from sensor power supply (SBIAS) (in V)
0	0	0	0	1.2
0	0	0	1	1.3
0	0	1	0	1.4
0	0	1	1	1.5
0	1	0	0	1.6
0	1	0	1	1.7
0	1	1	0	1.8
0	1	1	1	1.9
1	0	0	0	2.0
1	0	0	1	2.1
1	0	1	0	2.2
Other than above				Setting prohibited

**Caution** Bits 7, 6, 5, and 4 are read-only. (When these bits are read, 0 is always returned.)

#### 8.4.4 Operation of sensor power supply (SBIAS)

In addition to supplying power to the sensor connected to the RAA730101, SBIAS is involved in generating reference voltages used in analog circuits, such as the reference voltage used in the A/D converter and D/A converter and an internal bias voltage (VBIAS) to be connected to input multiplexers.

SBIAS has a circuit that monitors and detects the voltage output by SBIAS (SBIASDET), and is used to start analog circuits such as AFE VREF, programmable gain instrumentation amplifier (PGIA), and A/D converter. When SBIASDET detects the SBIAS output voltage, SBIASDET is released, which enables analog circuits to start operating. When SBIASDET detects that the SBIAS output voltage has not risen normally, analog circuits stop operating.

When "1" is written to the SLP bit of the power/mode control register (CHIPCNT), SBIAS shifts to sleep mode and stops operating. When "1" is written to the SENSPD bit of the power/mode control register (CHIPCNT), SBIAS stops operating. In both cases, SBIASDET detects the SBIAS output voltage and analog circuits such as AFE VREF, PGIA, and A/D converter stop operating. When AFE VREF stops operating, a reference voltage in the A/D converter and D/A converter and an internal bias voltage (VBIAS) to be connected to input multiplexers are not generated.

## 8.5 LDO regulator

The LDO regulator consists of AREG ( $AV_{DD}/IOV_{DD}$  power supply circuit) and CREG ( $ADV_{DD}/DV_{DD}$  power supply circuit). For how to use AREG and CREG, see **9. Power Supply Configuration**.


### 8.5.1 AREG ( $AV_{DD}/IOV_{DD}$ power supply circuit)

#### 8.5.1.1 Overview

AREG generates a voltage based on the voltage output from the low-power BGR, and supplies power to  $AV_{DD}$  and  $IOV_{DD}$ . Output voltage is 3.0 V (Typ.). Output current of 50 mA or less can be provided. An external capacitor of 0.47  $\mu\text{F}$  (recommended) must be connected to the AREG output pin.

AREG has a protection circuit against an overcurrent and a low output voltage detector (ADET). For details about the AREG operation, see **8.5.1.4 Operation of AREG ( $AV_{DD}/IOV_{DD}$  power supply circuit)**.

#### 8.5.1.2 Block diagram



**Figure 8.4 Block diagram of AREG**

### 8.5.1.3 Registers controlling AREG (AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit)

The following register is used to control AREG (AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit).

- Power/mode control register (CHIPCNT)

#### (1) Power/mode control register (CHIPCNT)

This register is used to set AREG to normal operation or sleep mode, and controls the output status.

After reset, this register is cleared to 00H.

For details, see **8.5.1.4 Operation of AREG (AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit)**.

Address: 01H After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHIPCNT	0	0	PSTHRU	AREGPD	0	0	SENSPD	SLP

PSTHRU	AREGPD	AREG operating status	Voltage output from AREG pin
0	0	Normal operation	3.0 V
1	0	Operation stops.	RV <sub>DD</sub>
*	1	Operation stops.	Hi-Z

**Caution** Bits 7, 6, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

**Remark** \* ; don't care

### 8.5.1.4 Operation of AREG (AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit)

The AREGPD and PSTHRU bits of the power/mode control register (CHIPCNT) are used to set AREG to normal operation or sleep mode, and controls the output status.

AREG can be stopped and its output made invalid (high impedance) by writing "1" to the AREGPD bit after AREG starts operating normally. In this case, the AREG and RV<sub>DD</sub> pins must be connected externally so that oscillation does not start. In addition, power must be supplied to RV<sub>DD</sub>, AV<sub>DD</sub>, and IOV<sub>DD</sub> externally. For details, see **9. Power Supply Configuration**.

When "1" is written to the PSTHRU bit, AREG stops operating and the output from AREG is bypassed to RV<sub>DD</sub> inside the circuit. This bypass feature can be used when a voltage of 3.0 V or higher needs to be supplied to IOV<sub>DD</sub> during flash memory programming. For details, see **9. Power Supply Configuration**.

For details about the low output voltage detector (ADET), see **12. Power-on-Reset (POR) Circuit**.

**Caution** Flash memory programming refers to erasing or writing of data in the flash memory.




## 8.5.2 CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)

### 8.5.2.1 Overview

CREG generates a voltage based on the voltage output from the high-precision BGR, and supplies power to ADV<sub>DD</sub> and DV<sub>DD</sub>. Output voltage is 2.1 V (Typ.). Output current of 20 mA or less can be provided. An external capacitor of 0.22 μF (recommended) must be connected to the CREG output pin.

CREG has a protection circuit against an overcurrent and a low output voltage detector (CDET). For details about the CREG operation, see **8.5.2.4 Operation of CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)**.

### 8.5.2.2 Block diagram



**Figure 8.5 Block diagram of CREG**

### 8.5.2.3 Registers controlling CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)

The following register is used to control CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit).

- Power/mode control register (CHIPCNT)

#### (1) Power/mode control register (CHIPCNT)

This register is used to set CREG to normal operation or sleep mode.

After reset, this register is cleared to 00H.

For details, see 8.5.2.4 *Operation of CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)*.

Address: 01H After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHIPCNT	0	0	PSTHRU	AREGPD	0	0	SENSPD	SLP

SLP	Control of sleep mode
0	Normal operation
1	Sleep mode

**Caution** Bits 7, 6, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

### 8.5.2.4 Operation of CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)

The SLP bit of the power/mode control register (CHIPCNT) sets CREG to sleep mode. When "1" is written to the SLP bit of the power/mode control register (CHIPCNT), CREG shifts to sleep mode and enters the standby state. In the standby state, CREG operates at low power and outputs a current of 2 mA or less. The reference voltage source is switched from the high-precision BGR to the low-power BGR. Even in this state, power is supplied to the protection circuit and the low output voltage detector (CDET).

For details about the low output voltage detector (CDET), see 12. *Power-on-Reset (POR) Circuit*.

### 8.5.3 LDO regulator operation in sleep mode

How the LDO regulator operates in sleep mode differs depending on which of the SPI communication and UART communication is selected.

When "1" is written to the SLP bit of the power/mode control register (CHIPCNT) during SPI communication (SMODE = 1), the power supply circuits other than the low-power BGR, AREG, and CREG stop operating. When "1" is written to the SLP bit of the power/mode control register (CHIPCNT) during UART communication (SMODE = 0), the high-precision BGR, in addition to the low-power BGR, AREG, and CREG, can operate. The high-precision BGR operates during UART communication (SMODE = 0) so as to operate the internal system clock (OSC) oscillator.

In sleep mode, CREG is in standby mode (operates at low power) during SPI communication (SMODE = 1) and UART communication (SMODE = 0), whichever is selected.

## 9. Power Supply Configuration

### 9.1 Overview

The RA730101 can use the three power supply configurations shown below.

Configuration 1: External power supply (3.3 V to 5.5 V) =  $R_{VDD} = I_{OVDD}$ ,  $A_{REG} = A_{VDD}$ ,  $C_{REG} = A_{DVDD} = D_{VDD}$

Configuration 2: External power supply (3.3 V to 5.5 V) =  $R_{VDD}$ ,  $A_{REG} = A_{VDD} = I_{OVDD}$ ,  $C_{REG} = A_{DVDD} = D_{VDD}$

Configuration 3: External power supply (2.7 V to 3.6 V) =  $R_{VDD} = A_{VDD} = I_{OVDD}$ ,  $A_{REG}$  disabled ( $A_{REGPD} = 1$ ),  
 $C_{REG} = A_{DVDD} = D_{VDD}$

Table 9.1 shows the power supply configurations. For details, see **9.2 Block diagrams of power supply configurations**.

**Table 9.1 Overview of power supply configuration**

Settings specified in:	External power supply is connected to: (External power supply voltage)	$A_{REG}$ is connected to: ( $A_{REG} = 3.0$ V)	$C_{REG}$ is connected to: ( $C_{REG} = 2.1$ V)	See:
Configuration 1	$R_{VDD}$ , $I_{OVDD}$ (3.3 to 5.5 V)	$A_{VDD}$	$A_{DVDD}$ , $D_{VDD}$	Figure 9.1
Configuration 2	$R_{VDD}$ (3.3 to 5.5 V)	$A_{VDD}$ , $I_{OVDD}$	$A_{DVDD}$ , $D_{VDD}$	Figure 9.2
Configuration 3	$R_{VDD}$ , $A_{VDD}$ , $I_{OVDD}$ (2.7 to 3.6 V)	$R_{VDD}$ ( $A_{REGPD} = 1$ : Output disabled)	$A_{DVDD}$ , $D_{VDD}$	Figure 9.3

**Caution** The power supply voltage range of  $I_{OVDD}$  determines the range of the input and output voltages used for serial communication.

During flash memory programming, 5 V (Typ.) must be supplied to  $I_{OVDD}$ . To perform flash memory programming in any of the above power supply configurations, the settings need to be changed as shown in Table 9.2. For details, see **9.4 Settings for flash programming**.

**Table 9.2 Overview of power supply configuration (for flash memory programming)**

Settings specified in:	External power supply is connected to: (External power supply voltage)	$A_{REG}$ is connected to: ( $A_{REG} = 3.0$ V)	$C_{REG}$ is connected to: ( $C_{REG} = 2.1$ V)	See:
Configuration 1	$R_{VDD}$ , $I_{OVDD}$ (4.5 to 5.5 V)	$A_{VDD}$	$A_{DVDD}$ , $D_{VDD}$	-
Configuration 2	$R_{VDD}$ (4.6 to 5.5 V)	$A_{VDD}$ , $I_{OVDD}$ ( <b><math>P_{STHRU} = 1</math>: <math>A_{REG}</math> stops operating and the <math>A_{REG}</math> output is bypassed to <math>R_{VDD}</math>.</b> )	$A_{DVDD}$ , $D_{VDD}$	-
Configuration 3	$R_{VDD}$ , $A_{VDD}$ , $I_{OVDD}$ (4.5 to 5.5 V)	$R_{VDD}$ ( $A_{REGPD} = 1$ : $A_{REG}$ stopped)	$A_{DVDD}$ , $D_{VDD}$	-


**Cautions** 1. Flash memory programming refers to erasing or writing of data in the flash memory.

2. The power supply voltage range of  $I_{OVDD}$  determines the range of the input and output voltages used for serial communication.

### 9.2 Block diagrams of power supply configurations

Configuration 1: External power supply (3.3 V to 5.5 V) = RV<sub>DD</sub> = IOV<sub>DD</sub>, AREG = AV<sub>DD</sub>, CREG = ADV<sub>DD</sub> = DV<sub>DD</sub>

- Supply 3.3 V to 5.5 V from an external power source to RV<sub>DD</sub> and IOV<sub>DD</sub>. (Short RV<sub>DD</sub> and IOV<sub>DD</sub> externally.)
- Supply AV<sub>DD</sub> from AREG (3.0 V).
- Supply ADV<sub>DD</sub> and DV<sub>DD</sub> from CREG (2.1 V).



**Figure 9.1 Block diagram of power supply configuration 1**

Configuration 2: External power supply (3.3 V to 5.5 V) = RV<sub>DD</sub>, AREG = AV<sub>DD</sub> = IOV<sub>DD</sub>, CREG = ADV<sub>DD</sub> = DV<sub>DD</sub>

- Supply 3.3 V to 5.5 V from an external power source to RV<sub>DD</sub>.
- Supply AV<sub>DD</sub> and IOV<sub>DD</sub> from AREG (3.0 V).
- Supply ADV<sub>DD</sub> and DV<sub>DD</sub> from CREG (2.1 V).




Figure 9.2 Block diagram of power supply configuration 2

Configuration 3: External power supply (2.7 V to 3.6 V) = RV<sub>DD</sub> = AV<sub>DD</sub> = IOV<sub>DD</sub>, AREG disabled (AREGPD = 1), CREG = ADV<sub>DD</sub> = DV<sub>DD</sub>

- Supply 2.7 V to 3.6 V from an external power source to RV<sub>DD</sub>, AV<sub>DD</sub>, and IOV<sub>DD</sub>. (Short RV<sub>DD</sub>, AV<sub>DD</sub>, and IOV<sub>DD</sub> externally.)
- Set the AREGPD bit to 1 after circuits start operating normally. (Short AREG and RV<sub>DD</sub> externally.)
- Supply ADV<sub>DD</sub> and DV<sub>DD</sub> from CREG (2.1 V).




Figure 9.3 Block diagram of power supply configuration 3

### 9.3 Sequence of power-on, power-off, and switching to standby mode

Figures 9.4 to 9.7 show the timing at which to power on, power off, and switch to standby mode.




Figure 9.4 Timing chart 1 (for configurations 1 and 2, during SPI communication (SMODE = 1))




Figure 9.5 Timing chart 2 (for configuration 3, during SPI communication (SMODE = 1))







Figure 9.6 Timing chart 3 (for configurations 1 and 2, during UART communication (SMODE = 0))



**Figure 9.7** Timing chart 4 (for configuration 3, during UART communication (SMODE = 0))


## 9.4 Settings for flash memory programming

### 9.4.1 Low-power access (mainly for read access)

Setting the SENSPD bit of the power/mode control register (CHIPCNT) enables accessing (mainly for reading) the flash memory at low power. When "1" is written to the SENSPD bit of the power/mode control register (CHIPCNT), SBIAS stops operating and analog circuits such as the PGIA and A/D converter stop operating. These analog circuits are not used for accessing the flash memory, so power supply to these circuits can be stopped to reduce power consumption. For details, see [8.4.3 Registers controlling the sensor power supply \(SBIAS\)](#) and [8.4.4 Operation of sensor power supply \(SBIAS\)](#).

### 9.4.2 Settings for bypassing AREG to RV<sub>DD</sub> (for power supply configuration 2)

Even if IOV<sub>DD</sub> is connected to the AREG output as shown in power supply configuration 2, flash memory programming can be performed by setting the PSTHRU bit of the power/mode control register (CHIPCNT). When "1" is written to the PSTHRU bit of the power/mode control register (CHIPCNT), AREG stops operating and the output from AREG is bypassed to RV<sub>DD</sub> inside the circuit. For details, see [8.5.1.3 Registers controlling AREG \(AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit\)](#) and [8.5.1.4 Operation of AREG \(AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit\)](#).



Caution 5.0 V (typ.) is also applied to the serial communication pins.

**Figure 9.8 Bypassing AREG to RV<sub>DD</sub>**


### 9.4.3 Protection of power/mode control register (CHIPCNT)

If the value of the AREGPD or PSTHRU bit changes accidentally during operation, a critical error or a malfunction that cannot be detected easily might occur. To prevent such a problem, the power/mode control register (CHIPCNT) has two protective features.

One is write-protection of the AREGPD bit of the power/mode control register (CHIPCNT). This protects the AREGPD bit from being written, thus ensuring that its data is retained. The setting of the SLP bit of the power/mode control register (CHIPCNT) affects writing to the AREGPD bit. The SLP bit must be set to 1 to enable writing to the AREGPD bit. If the SLP bit is not set to 1, writing to the AREGPD bit is disabled and thus the current data of the AREGPD bit is retained. Note, however, that this protection does not work when the register data in the flash memory is copied.

The other protective feature is masking of the PSTHRU bit of the power/mode control register (CHIPCNT). The setting of the ADSTART bit of the A/D converter control register (ADCCNT) affects writing to the PSTHRU bit. If "1" is written to the ADSTART bit to start A/D conversion, the PSTHRU bit is masked and thus retains 0. Writing to the PSTHRU bit is enabled again when a power-on reset (POR) occurs.

Figure 9.9 shows an example for accessing the power/mode control register (CHIPCNT).



When the ADSTART bit is set to "1", PSTHRU is set to "0" and masked.

Figure 9.9 Protection of CHIPCNT register


# 10. Clock Configuration

## 10.1 Overview

The RAA730101 has an internal system clock (OSC) oscillator. This oscillator generates all the clocks required in each circuit (clock frequency = 20 MHz (Typ.)). The generated clock is divided and distributed to the A/D converter, UART, and flash memory controller. The ADC logic generates a clock for the A/D converter. The clock for the A/D converter can be monitored by using the MCLK pin.

An external clock can also be input to the A/D converter. In this case, the MCLK pin is used to input the external clock. An external clock is valid only during SPI communication (SMODE = 1). An external clock cannot be input during UART communication (SMODE = 0). For details, see **10.3 Registers controlling clocks**.

## 10.2 Block diagram



**Figure 10.1 Clock configuration**

**Remark** For details about MONIOUT and EXTCLK, see **10.3 Registers controlling clocks**.

### 10.3 Registers controlling clocks

The following register is used to control the clocks.

- Clock/UART control register (UARTCNT)

#### (1) Clock/UART control register (UARTCNT)

This register is used to specify UART parameters and control the clock configuration.

After reset, this register is cleared to 00H.

Address: 08H After reset: 00H R/W

	7	6	5	4	3	2	1	0
UARTCNT	EXTCLK	MONIOUT	DIFFOUT	STB	EPS	PEN	TXBR	RXBR

MONIOUT	Monitoring the MCLK pin output
0	Disable monitoring (default).
1	Enable monitoring.

EXTCLK	External clock input to the A/D converter
0	Disable external clock input (default).
1	Enable external clock input.

**Remark** When MONIOUT is set to 0, the logic level of the MCLK pin output is fixed to low (pulled down to DGND inside the IC.) When not using this pin, see **1.4 Connection of unused pins**.

## 11. Temperature Sensor

### 11.1 Overview

The RAA730101 has one on-chip temperature sensor channel. The output from the on-chip temperature sensor passes through input multiplexer 5 and the programmable gain instrumentation amplifier, and is then input to the A/D converter.

### 11.2 Registers controlling the temperature sensor

The following six kinds of registers are used to control the temperature sensor.

- A/D converter control register (ADCCNT)
- Input multiplexer 5 A/D conversion setting register 1 (CH5CNT1)
- Input multiplexer 5 A/D conversion setting register 3 (CH5CNT3)
- A/D conversion result register 1 (ADCC)
- A/D conversion result register 2 (ADCH)
- A/D conversion result register 3 (ADCL)


For details, see *4.3 Registers controlling the 16-bit  $\Delta\Sigma$  A/D converter*.

## 12. Power-on-Reset (POR) Circuit

### 12.1 Overview

The RAA730101 has a power-on-reset (POR) circuit. The POR circuit is built in as part of the power supply circuit and is used to monitor and detect the voltage output from the LDO regulators (AREG and CREG). The POR circuit consists of ADET, a circuit that monitors and detects the voltage output from AREG (or RV<sub>DD</sub> when AREG is bypassed) and CDET, a circuit that monitors and detects the voltage output from CREG. For details about the operation, see **12.4 Operation of power-on-reset (POR) circuit.**

### 12.2 Block diagram



**Figure 12.1 Block diagram of power-on-reset (POR) circuit**



### 12.3 Registers controlling the power-on-reset (POR) circuit

The following register is used to control the power-on-reset (POR) circuit

- Power/mode control register (CHIPCNT)

#### (1) Power/mode control register (CHIPCNT)

This register is used to switch the voltage to be monitored and detected by ADET, a circuit that monitors and detects the voltage output from AREG (or RV<sub>DD</sub> when AREG is bypassed).

After reset, this register is cleared to 00H.

For details, see **12.4 Operation of power-on-reset (POR) circuit**.

Address: 01H After reset: 00H R/W

	7	6	5	4	3	2	1	0
CHIPCNT	0	0	PSTHRU	AREGPD	0	0	SENSPD	SLP

PSTHRU	AREGPD	AREG operating status	ADET monitoring/detection target
0	0	Normal operation	Voltage output from AREG
1	0	Operation stops.	Voltage applied to RV <sub>DD</sub>
*	1	Operation stops.	Voltage applied to RV <sub>DD</sub>

**Caution** Bits 7, 6, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

**Remark** \* ; don't care

### 12.4 Operation of power-on-reset (POR) circuit

The POR signal is generated based on the results of voltage detection by ADET and CDET. If both circuits detect a voltage higher than the removal voltage, the POR signal goes high and the internal blocks becomes active. If either circuit detects a voltage lower than the detection voltage, the POR signal goes low and the internal blocks are reset.

The AREGPD and PSTHRU bits of the power/mode control register (CHIPCNT) are used to switch the voltage to be monitored and detected by ADET. When "1" is written to the AREGPD or PSTHRU bit, the voltage to be monitored and detected by ADET is switched from the AREG output voltage to the voltage applied to RV<sub>DD</sub>.

The POR circuit operates normally even if "1" is written to the SLP bit of the power/mode control register (CHIPCNT) and the power supply circuit enters sleep mode. For details, see **8. Power Supply Circuit**.

# 13. Flash Memory

## 13.1 Overview


The RAA730101 has a 256-byte flash memory for storing information specific to the sensor connected to the RAA730101, such as the sensor ID, initial values, calibration data, and RAA730101 internal register settings specified for the sensor.

The lower 32 bytes of the address space are defined as a register shadow that can be used to store the data to be copied to registers. Data stored in the register shadow is copied to the relevant registers in the startup sequence that starts after power-on. Data stored in the register shadow can also be copied to the relevant registers by using an SPI or UART command in response to a request during normal operation.

The flash memory can be read and written in bytes, but should be erased all at once.

Flash memory programming is prohibited while A/D conversion is being performed (ADSTART = 1). Flash memory programming in sleep mode (SLP = 1) is also prohibited.

For details about the operation, see *13.3 Startup (power-on) sequence*.



**Figure 13.1 Address space**

- Cautions**
- Flash memory programming refers to erasing or writing of data in the flash memory.
  - If more than 30 days have passed since the data of flash memory was erased last, be sure to erase the data of flash memory again, and then write the required data to flash memory.

## 13.2 Registers controlling the flash memory

The following register is used to control the flash memory.

- Startup sequence/communication control register (STARTUP)

### (1) Startup sequence/communication control register (STARTUP)

This register is used to control flash memory access during the startup sequence and select the communication mode. After reset, this register is cleared to 00H. For details, see **13.3 Startup (power-on) sequence**.

This is a read-only register and cannot be written by using an SPI or UART command. However, this register is updated when data in the register shadow is copied during the startup sequence. The updated value then becomes valid.

Be sure to clear the TGLSM bit to "0". The TGLSM bit is also updated when data in the register shadow is copied. The updated value then becomes valid.

Address: 1FH After reset: 00H R/-

	7	6	5	4	3	2	1	0
STARTUP	0	0	0	TGLSM	0	0	SDCOR	CPSOR


CPSOR	Copying data in the register shadow
0	Disable operation.
1	Enable operation.

SDCOR	Data transmission to an external device using UART communication
0	Disable operation.
1	Enable operation.

TGLSM	Control of SMODE pin function
0	UART communication is selected when SMODE = 0, and SPI communication is selected when SMODE = 1.
1	Setting prohibited

**Caution** Bits 7, 6, 5, 3, and 2 are read-only. (When these bits are read, 0 is always returned.)

### 13.3 Startup (power-on) sequence



**Figure 13.2 Startup (power-on) sequence**

After power-on reset, the default setting data of the RAA730101 such as trimming data is copied to the register buffer area automatically. (The default setting data is always copied automatically.) The default setting data can also be copied to the register buffer area by using an SPI or UART command during normal operation. For details, see **5. SPI** and **6. UART**.

Next, the CPSOR bit value stored in the register shadow is checked. If CPSOR is 1, the data in the register shadow are copied to the relevant registers. Then, the SDCOR bit value stored in the register shadow is checked. If SDCOR is 1, all 256 bytes of data in the user area in the flash memory are transmitted to the microcontroller connected to the RAA730101 by using UART communication. (This data is not transmitted in SPI communication.) The processes up to this point are automatically performed after power-on reset.

There is a programming window period in the interval from when the system starts up after power-on reset to when the first A/D conversion starts. Flash memory programming can only be performed in this period.

When ADSTART is set to 1 to trigger A/D conversion, flash memory programming can no longer be performed. This prevents the flash memory from being erased and overwritten unintentionally during operation. Flash memory programming is enabled again when power-on reset (POR) occurs.

Note that this operation occurs when ADSTART has been set to 1 by using an SPI or UART command. Flash memory programming is not disabled just by copying the value of ADSTART set to 1 in the register shadow to the relevant register.

**Cautions 1. Flash memory programming refers to erasing or writing of data in the flash memory.**

**2. When the copy function from the register shadow to the registers is used, see 6.6 *Note on Using the UART*.**

## 13.4 Commands controlling the flash memory

### 13.4.1 Controlling the flash memory by using SPI commands

**Table 13.1 SPI commands**

No.	Name	Command				Extension	Description
		C7	C6	C5	C4 to C0	E7 to E0	
1	Register Read	0	0	1	Address: 00h to 1Fh	–	Reads 1 byte of data from the specified register.
2	Register Write	1	0	1	Address: 00h to 1Fh	–	Writes 1 byte of data to the specified register.
3	Register Burst Read	0	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Reads the specified length of data from the specified register successively. (Starting from the specified address)
4	Register Burst Write	1	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Writes the specified length of data to the specified register successively. (Starting from the specified address)
5	Register All Write from Flash	1	0	0	01111	–	Copies all data stored in the register shadow in the flash memory to the specified register.
6	Buffer Refresh	1	0	0	01100	–	Copies the default configuration data to the register buffer.
7	Flash (Burst) Read <sup>Note 3</sup>	0	1	0	11111	Start address 00h to FFh	Reads data from the flash memory. Specifies the address from which to start reading data. (First command)
		0	1	0	11100	Data length 00h to FFh <sup>Note 2</sup>	Reads data from the flash memory. Specifies the length of data to be read. (Second command)
8	Flash Write	1	1	0	11111	Address: 00h to FFh	Writes 1 byte of data to the flash memory.
9	Flash All Erase <sup>Note 3</sup>	1	1	1	11010	–	Erase all data in the flash memory. (First command)
		1	1	1	01011	–	Erase all data in the flash memory. (Second command)

- Notes**
1. Data length = “sum of C3 to C0 values” + 1 (Up to 16 bytes)
  2. Data length = “sum of E7 to E0 values” + 1 (Up to 256 bytes)
  3. To (burst) read and erase data in the flash memory, accessing the flash memory by successively using two commands is required.

## 13.4.2 Controlling the flash memory by using UART commands

Table 13.2 UART commands


No.	Name	Command				Extension	Description
		C7	C6	C5	C4 to C0	E7 to E0	
1	Register Read	0	0	1	Address: 00h to 1Fh	–	Reads 1 byte of data from the specified register.
2	Register Write	1	0	1	Address: 00h to 1Fh	–	Writes 1 byte of data to the specified register.
3	Register Burst Read	0	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Reads the specified length of data from the specified register successively. (Starting from the specified address)
4	Register Burst Write	1	0	0	Data length 1xxx <sup>Note 1</sup>	Start address 00h to 1Fh	Writes the specified length of data to the specified register successively. (Starting from the specified address)
5	Register All Write from Flash	1	0	0	01111	–	Copies all data stored in the register shadow in the flash memory to the specified register.
6	Buffer Refresh	1	0	0	01100	–	Copies the default configuration data to the register buffer.
7	Flash (Burst) Read <sup>Note 3</sup>	0	1	0	11111	Start address 00h to FFh	Reads data from the flash memory. Specifies the address from which to start reading data. (First command)
		0	1	0	11100	Data length 00h to FFh <sup>Note 2</sup>	Reads data from the flash memory. Specifies the length of data to be read. (Second command)
8	Flash Write	1	1	0	11111	Address 00h to FFh	Writes 1 byte of data to the flash memory.
9	Flash All Erase <sup>Note 3</sup>	1	1	1	11010	–	Erase all data in the flash memory. (First command)
		1	1	1	01011	–	Erase all data in the flash memory. (Second command)
10	Baud rate correction	0	0	0	00000	–	Corrects the baud rate. (Only available in UART communication)
11	Send request	0	0	0	01111	–	Requests re-transmission of the message transmitted last. (Only available in UART communication)

- Notes**
1. Data length = “sum of C3 to C0 values” + 1 (Up to 16 bytes)
  2. Data length = “sum of E7 to E0 values” + 1 (Up to 256 bytes)
  3. To (burst) read and erase data in the flash memory, accessing the flash memory by successively using two commands is required.

# 14. Application Examples

Bidirectional SPI communication

- \*RV<sub>DD</sub> and IOV<sub>DD</sub> are externally connected.
- \*AV<sub>DD</sub> is supplied from AREG
- \*AIN1P and AIN1N pins: Differential input
- \*AIN2P pin: Single-ended input
- \*AIN2N, AIN3P, AIN3N, AIN4P, and AIN4N pins: Not used




Note Capacitance values are recommended values.

Figure 14.1 Example of connecting a sensor to a microcontroller (for SPI communication)



Bidirectional UART communication

- \*RV<sub>DD</sub> and IOV<sub>DD</sub> are externally connected.
- \*AV<sub>DD</sub> is supplied from AREG
- \*AIN1P and AIN1N pins: Differential input
- \*AIN2P pin: Single-ended input
- \*AIN2N, AIN3P, AIN3N, AIN4P, and AIN4N pins: Not used



Note Capacitance values are recommended values.

Figure 14.2 Example of connecting a sensor to a microcontroller (for UART communication)

## 15. Electrical Specifications

The electrical specifications shown in this section are verified under the following conditions unless otherwise specified.

- The temperature ranges are  $-40^{\circ}\text{C} \leq T_A \leq 125^{\circ}\text{C}$  (for 125 °C models),  $-40^{\circ}\text{C} \leq T_A \leq 105^{\circ}\text{C}$  (for 105 °C models).
- The power supply voltage ranges satisfy the values prescribed in **15.2 Operating conditions**.
- The Typ. value is the value when  $T_A = 25^{\circ}\text{C}$ .
- Differential input mode,  $F_S = 1 \text{ MHz}$ ,  $F_{\text{DATA}} = 3.90625 \text{ kpsps}$ ,  $\text{SBIAS} = 1.2 \text{ V}$ ,  $\text{dOFR} = 0 \text{ mV}$ ,  $\text{EXTCLK} = 0$ , and  $V_{\text{COM}} = 0.9 \text{ V}$ .

### 15.1 Absolute maximum ratings

Parameter	Symbol	Conditions	Ratings	Unit
Supply voltage	V <sub>DD1</sub>	RV <sub>DD</sub> , AV <sub>DD</sub> , IOV <sub>DD</sub>	-0.3 to +6.5	V
	V <sub>DD2</sub>	ADV <sub>DD</sub> , DV <sub>DD</sub>	-0.3 to +2.8	V
	V <sub>SS</sub>	AGND, DGND	-0.3 to +0.3	V
Input voltage	V <sub>I2</sub>	AIN1P, AIN1N, AIN2P, AIN2N, AIN3P, AIN3N, AIN4P, AIN4N	-0.3 to AV <sub>DD</sub> + 0.3 <sup>Note</sup>	V
	V <sub>I1</sub>	CS_B, SCLK, MOSI_RX, SMODE, MCLK	-0.3 to IOV <sub>DD</sub> + 0.3 <sup>Note</sup>	V
Output voltage	V <sub>O1</sub>	AREG	-0.3 to RV <sub>DD</sub> + 0.3 <sup>Note</sup>	V
	V <sub>O2</sub>	CREG, SBIAS, VREF	-0.3 to AV <sub>DD</sub> + 0.3 <sup>Note</sup>	V
	V <sub>O3</sub>	MISO_TX, TX_B, INT, MCLK	-0.3 to IOV <sub>DD</sub> + 0.3 <sup>Note</sup>	V
Output current, low	I <sub>oL</sub>	MISO_TX	10	mA
Operating ambient temperature	T <sub>A</sub>	In normal operating mode (for 125 °C models)	-40 to +125	°C
		In normal operating mode (for 105 °C models)	-40 to +105	°C
		During flash memory programming (for both 125 °C models and 105 °C models)	10 to 85	°C
Storage temperature	T <sub>STG</sub>		-55 to +150	°C

**Note** Must be 6.5 V or lower.

## 15.2 Operating conditions

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Range of power supply voltage for regulator	RV <sub>DD</sub>	AREG is operating	3.3	5.0	5.5	V
		AREG operation stopped	2.7	3.0	3.6	V
Range of power supply voltage for analog circuits	AV <sub>DD</sub>		2.7	3.0	3.6	V
Power supply voltage input to the A/D converter	ADV <sub>DD</sub>		2.0	2.1	2.2	V
Range of power supply voltage for digital circuits	DV <sub>DD</sub>		2.0	2.1	2.2	V
Range of power supply voltage for I/O circuits	IOV <sub>DD</sub>	RV <sub>DD</sub> ≥ IOV <sub>DD</sub> <sup>Note 1</sup>	2.7	5.0	5.5	V
Range of voltage for flash memory programming 1	V <sub>FP1</sub>	When V <sub>FP1</sub> = IOV <sub>DD</sub> <sup>Note 2</sup>	4.5		5.5	V
Range of voltage for flash memory programming 2	V <sub>FP2</sub>	When V <sub>FP2</sub> = RV <sub>DD</sub> <sup>Note 3</sup>	4.6		5.5	V

- Notes**
1. Make RV<sub>DD</sub> greater than or equal to IOV<sub>DD</sub>.
  2. For power supply configurations 1 and 3
  3. For power supply configuration 2 and when PSTHRU = 1

**Caution** Flash memory programming refers to erasing or writing of data in the flash memory.

## 15.3 Supply current characteristics

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Current consumption in sleep mode (total of analog and digital circuits)	I <sub>DD</sub> S1	S <sub>MODE</sub> = 1, S <sub>LP</sub> = 1, A <sub>REG</sub> PD = 0		3	20	μA
	I <sub>DD</sub> S2	S <sub>MODE</sub> = 1, S <sub>LP</sub> = 1, A <sub>REG</sub> PD = 1		1.5	15	μA
	I <sub>DD</sub> S3	S <sub>MODE</sub> = 0, S <sub>LP</sub> = 1, A <sub>REG</sub> PD = 0		550	850	μA
Analog power supply current (RV <sub>DD</sub> + AV <sub>DD</sub> + ADV <sub>DD</sub> )	I <sub>DD</sub> A1	During A/D conversion A <sub>REG</sub> PD = 0, S <sub>BIAS</sub> I <sub>OUT</sub> = 0 mA		1.3	1.7	mA
	I <sub>DD</sub> A2	S <sub>EN</sub> SPD = 1, S <sub>LP</sub> = 0, A <sub>REG</sub> PD = 0		0.35	0.5	mA
Digital power supply current (DV <sub>DD</sub> )	I <sub>DD</sub> D1	During A/D conversion		0.25	0.4	mA
	I <sub>DD</sub> D2	When reading from flash memory <sup>Note</sup>		1.3	1.7	mA
Current consumption in flash memory programming (IOV <sub>DD</sub> + DV <sub>DD</sub> )	I <sub>DD</sub> F1	When writing to flash memory 10°C ≤ T <sub>A</sub> ≤ 85°C		1.2	3	mA
	I <sub>DD</sub> F2	When erasing flash memory 10°C ≤ T <sub>A</sub> ≤ 85°C		1.2	2	mA

**Note** The current consumption under the condition that some data are written to flash memory.

**Caution** Flash memory programming refers to erasing or writing of data in the flash memory.

## 15.4 Electrical specifications of each block

### 15.4.1 Programmable gain instrumentation amplifier and 16-bit $\Delta\Sigma$ A/D converter

Analog input in differential input mode

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Full-scale differential input voltage range	$V_{ID}$	$V_{ID} = (AINxP - AINxN)$ ( $x = 1, 2, 3, 4$ )		$\pm 700$ /G <sub>TOTAL</sub>		mV
Input voltage range	$V_i$	Each of AINxP and AINxN pins ( $x = 1, 2, 3, 4$ )	0.2		1.6	V
Common mode input voltage	$V_{COM}$	$d_{OFFR} = 0$ mV	$0.2 + ( V_{ID}  \times G_{SET1})/2$		$1.6 - ( V_{ID}  \times G_{SET1})/2$	V
Input impedance	$Z_{IN}$		5			M $\Omega$

Analog input in single-ended input mode

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Input voltage	$V_i$	$G_{SET1} = 1, G_{SET2} = 1$	0.2		1.6	V
Input impedance	$Z_{IN}$		5			M $\Omega$

Programmable gain instrumentation amplifier and 16-bit  $\Delta\Sigma$  A/D converter (1/2)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Sampling frequency	$F_S$			1		MHz
Output data rate	$F_{DATA}$		(0.48828)		(15.625)	ksps
Gain setting range	$G_{TOTAL}$	$G_{TOTAL} = G_{SET1} \times G_{SET2}$	1		32	V/V
1st gain setting range	$G_{SET1}$			1, 2, 3, 4, 8		V/V
2nd gain setting range	$G_{SET2}$			1, 2, 4, 8		V/V
Offset adjustment bit range	$d_{OFFB}$			5		bit
Offset adjustment range	$d_{OFFR}$	Referred to input	$-175/G_{SET1}$		$+164/G_{SET1}$	mV
Offset adjustment steps	$d_{OFFS}$	Referred to input		$11/G_{SET1}$		mV

**Remark** In the specification column, values in parentheses are the target design values and therefore are not tested for shipment.

Programmable gain instrumentation amplifier and 16-bit  $\Delta\Sigma$  A/D converter (2/2)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Gain error	$E_G$		-10		10	%
Gain drift <sup>Note</sup>	$dE_G$	$G_{SET1} = 1, G_{SET2} = 1$ Excluding SBIAS drift			(22)	ppm/°C
Offset error	$E_{OS}$	$G_{SET1} = 1, G_{SET2} = 1$	-5		5	mV
Offset drift <sup>Note</sup>	$dE_{OS}$	$G_{SET1} = 1, G_{SET2} = 1$			(16)	$\mu V/^\circ C$
S/N	SNR	$G_{SET1} = 1, G_{SET2} = 1$ Excluding MEMS noise	82	85		dB
Common mode rejection ratio	CMRR	$f_{in} = 50 \text{ Hz}, G_{SET1} = 1, G_{SET2} = 1$	40	60		dB
Power supply rejection ratio	PSRR	$AV_{DD} = 3.0 \text{ V} + 0.1 \text{ V}_{pp} \text{ ripple}$ $f_{in} = 50 \text{ Hz}, G_{SET1} = 1, G_{SET2} = 1$	(60)	(70)		dB
A/D converter input clock frequency	$f_{ADC}$	EXTCLK = 1	3.8	4	4.2	MHz

**Note** Calculate the gain drift and offset drift by using the following expression:

(for 125 °C models)

For gain drift:  $(\text{MAX}(E_G(T_{(-40)} \text{ to } T_{(125)})) - \text{MIN}(E_G(T_{(-40)} \text{ to } T_{(125)}))) / (125^\circ\text{C} - (-40^\circ\text{C}))$

For offset drift:  $(\text{MAX}(E_{OS}(T_{(-40)} \text{ to } T_{(125)})) - \text{MIN}(E_{OS}(T_{(-40)} \text{ to } T_{(125)}))) / (125^\circ\text{C} - (-40^\circ\text{C}))$

MAX( $E_G(T_{(-40)} \text{ to } T_{(125)})$ ): The maximum value of gain error when the temperature range is -40°C to 125°C

MIN( $E_G(T_{(-40)} \text{ to } T_{(125)})$ ): The minimum value of gain error when the temperature range is -40°C to 125°C

MAX( $E_{OS}(T_{(-40)} \text{ to } T_{(125)})$ ): The maximum value of offset error when the temperature range is -40°C to 125°C

MIN( $E_{OS}(T_{(-40)} \text{ to } T_{(125)})$ ): The minimum value of offset error when the temperature range is -40°C to 125°C

(for 105 °C models)

For gain drift:  $(\text{MAX}(E_G(T_{(-40)} \text{ to } T_{(105)})) - \text{MIN}(E_G(T_{(-40)} \text{ to } T_{(105)}))) / (105^\circ\text{C} - (-40^\circ\text{C}))$

For offset drift:  $(\text{MAX}(E_{OS}(T_{(-40)} \text{ to } T_{(105)})) - \text{MIN}(E_{OS}(T_{(-40)} \text{ to } T_{(105)}))) / (105^\circ\text{C} - (-40^\circ\text{C}))$

MAX( $E_G(T_{(-40)} \text{ to } T_{(105)})$ ): The maximum value of gain error when the temperature range is -40°C to 105°C

MIN( $E_G(T_{(-40)} \text{ to } T_{(105)})$ ): The minimum value of gain error when the temperature range is -40°C to 105°C

MAX( $E_{OS}(T_{(-40)} \text{ to } T_{(105)})$ ): The maximum value of offset error when the temperature range is -40°C to 105°C

MIN( $E_{OS}(T_{(-40)} \text{ to } T_{(105)})$ ): The minimum value of offset error when the temperature range is -40°C to 105°C

**Remark** In the specification column, values in parentheses are the target design values and therefore are not tested for shipment.

### 15.4.2 Internal reference voltage generator (VREF)

(C<sub>OUT</sub> = 0.1 μF)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Output voltage	V <sub>OUT</sub>		0.76	0.8	0.84	V
Turn-on time	T <sub>ON</sub>	V <sub>OUT</sub> > 90%			(550)	μs

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

### 15.4.3 Sensor power supply (SBIAS)

(C<sub>OUT</sub> = 0.22 μF)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Output voltage range	V <sub>OUT</sub>		1.2		2.2	V
Output voltage setting steps	V <sub>STEP</sub>			0.1		V
Output voltage range	V <sub>A</sub>	0 mA ≤ I <sub>OUT</sub> ≤ 5 mA	-5		+5	%
Output current	I <sub>OUT</sub>		5			mA
Output current limit	I <sub>LIMIT</sub>			(40)	(60)	mA
Short-circuit current	I <sub>SHORT</sub>	V <sub>OUT</sub> = 0 V		40	65	mA
Load regulation	L <sub>R</sub>	0 mA ≤ I <sub>OUT</sub> ≤ 5 mA			15	mV
Power supply rejection ratio	PSRR	AV <sub>DD</sub> = 3.0 V + 0.1 V <sub>pp</sub> ripple f = 100 Hz, I <sub>OUT</sub> = 2.5 mA	(45)	(50)		dB
Turn-on time	T <sub>ON</sub>	V <sub>OUT</sub> > 90%			(250)	μs
Turn-off time	T <sub>OFF</sub>	V <sub>OUT</sub> < 10%			(5)	ms

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

### 15.4.4 AREG (AV<sub>DD</sub>/IOV<sub>DD</sub> power supply circuit)

(C<sub>OUT</sub> = 0.47 μF)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Output voltage	V <sub>OUT</sub>	0 mA ≤ I <sub>OUT</sub> ≤ 50 mA	2.85	3	3.15	V
Output current	I <sub>OUT</sub>		50			mA
Output current limit	I <sub>LIMIT</sub>			(110)	(150)	mA
Short-circuit current	I <sub>SHORT</sub>	V <sub>OUT</sub> = 0 V		40	65	mA
Load regulation	L <sub>R</sub>	1 mA ≤ I <sub>OUT</sub> ≤ 50 mA			40	mV
Power supply rejection ratio	PSRR	RV <sub>DD</sub> = 5.0 V + 0.1 V <sub>pp</sub> ripple f = 100 Hz, I <sub>OUT</sub> = 25 mA	(35)	(45)		dB
Turn-on time	T <sub>ON</sub>	RV <sub>DD</sub> ≥ 3.3 V, V <sub>OUT</sub> > 90%, I <sub>OUT</sub> = 0 mA			(1800)	μs

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

### 15.4.5 CREG (ADV<sub>DD</sub>/DV<sub>DD</sub> power supply circuit)

(C<sub>OUT</sub> = 0.22 μF, in normal operating mode)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Output voltage	V <sub>OUT</sub>	0 mA ≤ I <sub>OUT</sub> ≤ 20 mA	2	2.1	2.2	V
Output current	I <sub>OUT</sub>		20			mA
Output current limit	I <sub>LIMIT</sub>			(60)	(90)	mA
Short-circuit current	I <sub>SHORT</sub>	V <sub>OUT</sub> = 0 V		40	65	mA
Load regulation	L <sub>R</sub>	1 mA ≤ I <sub>OUT</sub> ≤ 20 mA			20	mV
Power supply rejection ratio	PSRR	AV <sub>DD</sub> = 3.0 V + 0.1 V <sub>pp ripple</sub> f = 100 Hz, I <sub>OUT</sub> = 10 mA	(45)	(50)		dB
Turn-on time	T <sub>ON</sub>	V <sub>OUT</sub> > 90%, I <sub>OUT</sub> = 0 mA including VREF turn-on time			(700)	μs
Turn-off time	T <sub>OFF</sub>	V <sub>OUT</sub> < 10%, I <sub>OUT</sub> = 0 mA			(5)	ms
Mode switching time 1	T <sub>SW1</sub>	Operating to Standby			(400)	μs
Mode switching time 2	T <sub>SW2</sub>	Standby to Operating Excluding VREF turn-on time			(150)	μs

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

(C<sub>OUT</sub> = 0.22 μF, on standby)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Output voltage	V <sub>OUT</sub>	0 mA ≤ I <sub>OUT</sub> ≤ 2 mA	2	2.1	2.2	V
Output current	I <sub>OUT</sub>		2			mA

### 15.4.6 Power-on-reset (POR) circuit

#### ADET (AREG/RV<sub>DD</sub> voltage monitor and detector)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Removal voltage	V <sub>POR</sub>	When AREG output voltage rises	2.4	2.5	2.6	V
Detection voltage 1	V <sub>PDR1</sub>	When AREG output voltage falls AREGPD = 0	2.2	2.3	2.4	V
Detection voltage 2	V <sub>PDR2</sub>	When RV <sub>DD</sub> input voltage falls AREGPD = 1	2.2	2.3	2.4	V

#### CDET (CREG voltage monitor and detector)

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Removal voltage	V <sub>POR</sub>	When CREG output voltage rises	1.82	1.9	1.98	V
Detection voltage	V <sub>PDR</sub>	When CREG output voltage falls	1.75	1.83	1.91	V

### 15.4.7 Temperature sensor

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Temperature coefficient for sensor	TC <sub>SNS</sub>		(-2.1)	(-1.8)	(-1.5)	mV/°C
Temperature sensor output voltage	V <sub>TEMP</sub>	T <sub>A</sub> = 25°C	580	680	780	mV

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.



### 15.4.8 Internal system clock (OSC) oscillator

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Clock frequency	$f_{OSC}$		19	20	21	MHz

### 15.4.9 Flash memory

( $10^{\circ}\text{C} \leq T_A \leq 85^{\circ}\text{C}$ , 4.5 (4.6)  $V^{\text{Note}} \leq IOV_{DD} \leq RV_{DD} \leq 5.5\text{ V}$ )

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Erase time	$T_{ER}$			(5)		ms
Write time	$T_{WR}$			(100)		$\mu\text{s}$
Number of rewrite times	$C_{EW}$		(100)			Times
Data retention period	$T_{DR}$		(10)			Years

**Note** Specify the voltage to be applied according to the power supply configuration used. For details, see **9 Power Supply Configuration** and see **15.2 Operating conditions** about the power supply voltage ranges.

**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

### 15.4.10 Digital I/O

Parameter	Symbol	Conditions	Min.	Typ.	Max.	Unit
Input voltage, high	$V_{IH}$	CS_B, SCLK, MOSI_RX, SMODE MCLK (EXTCLK = 1)	$0.7 \times IOV_{DD}$		$IOV_{DD}$	V
Input voltage, low	$V_{IL}$	CS_B, SCLK, MOSI_RX, SMODE MCLK (EXTCLK = 1)	0		$0.3 \times IOV_{DD}$	V
Output voltage, high	$V_{OH}$	MISO_TX, TX_B, INT, MCLK, IOH = -1 mA, $2.7\text{ V} \leq IOV_{DD} \leq 5.5\text{ V}$	$IOV_{DD} - 0.5$		$IOV_{DD}$	V
Output voltage, low 1	$V_{OL1}$	MISO_TX, TX_B, INT, MCLK, IOL = 1 mA, $2.7\text{ V} \leq IOV_{DD} \leq 5.5\text{ V}$	0		0.4	V
Output voltage, low 2	$V_{OL2}$	MISO_TX, IOL = 5 mA, $2.7\text{ V} \leq IOV_{DD} \leq 5.5\text{ V}$	0		0.7	V
Input leakage current	$I_{INL}$	CS_B, SCLK, MOSI_RX, SMODE MCLK (EXTCLK = 1)	-1		1	$\mu\text{A}$

15.5 SPI access timing




Figure 15.1 SPI access timing

IOV<sub>DD</sub> = 2.7 V to 5.5 V, C = 15 pF

Symbol	Description	Min.	Typ.	Max.	Unit
T <sub>cssu</sub>	From CS_B↓ to first SCLK↓ or to first SCLK↑	20			ns
T <sub>cshd</sub>	From SCLK↑ to CS_B↑	20			ns
T <sub>cshw</sub>	CS_B high-level width between transfers	80			ns
T <sub>ckpd</sub>	SCLK clock cycle	200 (500) <sup>Note</sup>			ns
T <sub>ckhw</sub>	SCLK high-level width	80			ns
T <sub>cklw</sub>	SCLK low-level width	80			ns
T <sub>wdsu</sub>	MOSI_RX setup time (to SCLK↑)	20			ns
T <sub>wdhd</sub>	MOSI_RX hold time (from SCLK↑)	20			ns
T <sub>rdly</sub>	From SCLK↓ to MISO_TX stabilizes			40	ns
T <sub>rdrel</sub>	From CS_B↑ to MISO_TX released			40	ns

**Note** The maximum clock cycle of the burst read access to the flash memory is 2 MHz.

### 15.6 Cumulative power-on time and wake-up time

CPSOR = SDCOR = 0


	Power-on time (μs)	Wake-up time (μs)	
		During SPI communication (SMODE = 1)	During UART communication (SMODE = 0)
Until serial communication is ready	(3300)	–	–
Until A/D conversion is ready	(3570)	(820)	(270)
Until the first A/D conversion ends	(3698 + 3T) <sup>Note</sup>	(948 + 3T) <sup>Note</sup>	(398 + 3T) <sup>Note</sup>
Based on	Power-on	SLP = 1 → 0	

**Note** T: Sampling time (= 1/f<sub>OUT</sub>)


**Remark** Values in parentheses are the target design values and therefore are not tested for shipment.

The figure 15.2 shows the status transition at power-on and the figure 15.3 shows the status transition at wake-up. Estimate the cumulative power-on time and wake-up time referring to the figure 15.2 and to the figure 15.3. It is possible to make a sufficient allowance of time as a safety margin according to the actual system of use. For details about each function in the figures below, see the relevant section described about that function.

In the figures below, it is assumed that ADSTART is set to 1 during the SBIAS stabilization time. If ADSTART is not set to 1 during that time, the timing when the actual A/D conversion starts is delayed according to the timing when ADSTART is set to 1.



**Figure 15.2 Cumulative power-on time**



**Figure 15.3 Cumulative wake-up time**

The example is added for explanation about the time required for SDCOR processing.

As the time required for SDCOR processing varies depending on the UART setting, calculate the SDCOR processing time by using the following equation:

$$t_{SDCOR} [\text{sec.}] = (1/\text{baud rate} [\text{bps}]) \times \text{packet length} [\text{bits}] \times (256 + 4) [\text{packets}]$$

In the figure 15.2, it is assumed that baud rate is 4.8 kbps, no parity bit, number of stop bits is 1, and then

$$t_{SDCOR} [\text{sec.}] = (1 / 4800) \times 10 \times (256 + 4) = 0.54 [\text{sec.}]$$

Considering the accuracy of clock frequency, add about +5% of 0.54 [sec.] as a safety margin and use the resulting 0.57 [sec.] for the setting.

## 16. Chip Identification

### 16.1 Overview

The RAA730101 has a chip identification register.

### 16.2 Register for chip identification

The following register is used for chip identification.

- Chip identification register (CHIPID)

(1) Chip identification register (CHIPID)

This is a read-only register storing chip ID. The initial value is 3AH.


Address: 00H After reset: 3AH R/-

	7	6	5	4	3	2	1	0
CHIPID	0	0	1	1	1	0	1	0

# 17. Package Drawings

4 x 4 mm/36-pin FBGA (0.50 mm pitch)

JEITA Package code	RENESAS code	Previous code	MASS(TYP.)[g]
P-TFBGA36-4x4-0.50	PTBG0036KA-A	P36F1-50-AA6	0.027







Reference Symbol	Dimension in Millimeters		
	Min	Nom	Max
D	3.90	4.00	4.10
E	3.90	4.00	4.10
A	—	—	1.10
A <sub>1</sub>	0.17	0.22	0.27
$e$	—	0.50	—
b	0.26	0.31	0.36
x	—	—	0.05
y	—	—	0.08
y <sub>1</sub>	—	—	0.20
Z <sub>D</sub>	—	0.75	—
Z <sub>E</sub>	—	0.75	—
w	—	—	0.20

© 2013 Renesas Electronics Corporation. All rights reserved.



Characteristics Curve (T<sub>A</sub> = 25°C, TYP.) (reference value)

- Programmable gain instrumentation amplifier and 16-bit  $\Delta\Sigma$  A/D converter

RV<sub>DD</sub> = IOV<sub>DD</sub> = 5.0V, AV<sub>DD</sub> = 3.0V, ADV<sub>DD</sub> = DV<sub>DD</sub> = 2.1V,  
 differential input mode, FS = 1MHz, SBIAS = 1.2V, d<sub>OFR</sub> = 0mV, G<sub>TOTAL</sub>=1




RV<sub>DD</sub> = IOV<sub>DD</sub> = 5.0V, AV<sub>DD</sub> = 3.0V, ADV<sub>DD</sub> = DV<sub>DD</sub> = 2.1V, differential input mode, FS = 1MHz,  
 F<sub>DATA</sub> = 3.90625kps, SBIAS = 1.2V, doFR = 0mV, OSR = 256, G<sub>TOTAL</sub>=1






- Internal reference voltage generator (VREF)

$R_{VDD} = I_{OVDD} = 5.0V$ ,  $A_{VDD} = 3.0V$ ,  $A_{DVDD} = D_{VDD} = 2.1V$ , differential input mode,  $F_S = 1MHz$ ,  
 $F_{DATA} = 3.90625ksps$ ,  $S_{BIAS} = 1.2V$ ,  $d_{OFR} = 0mV$ ,  $OSR = 256$ ,  $G_{TOTAL}=1$



- Temperature Sensor

$R_{VDD} = I_{OVDD} = 5.0V$ ,  $A_{VDD} = 3.0V$ ,  $A_{DVDD} = D_{VDD} = 2.1V$ , differential input mode,  $F_S = 1MHz$ ,  
 $F_{DATA} = 3.90625ksps$ ,  $S_{BIAS} = 1.2V$ ,  $d_{OFR} = 0mV$ ,  $OSR = 256$ ,  $G_{TOTAL}=1$



<b>Revision Record</b>	RAA730101 16-bit $\Delta\Sigma$ A/D converter IC with programmable gain instrumentation amplifier
------------------------	------------------------------------------------------------------------------------------------------

Rev.	Date	Description	
		Page	Summary
1.00	Mar 31, 2014	–	First edition issued
1.10	Jul 31, 2014	14	Modification of description in 3.1 Function of Programmable Gain Instrumentation Amplifier
		15	Addition of description in 3.2 Function of Single-ended input mode
		16	Addition of description in 3.3 Function of Single-ended input mode
		17	Addition of description in 3.3.2 Function of Single-ended input mode
		18	Deletion of note in A/D conversion setting register 1
		21	<ul style="list-style-type: none"> <li>• Addition of description in 4.1.3 Function of Single-ended input mode</li> <li>• Addition of description in 4.1 table of Single-ended input mode</li> </ul>
		32	Modification of Figure in Example 1
		92	Addition of Condition in Input voltage at single-ended input mode
2.00	Feb 27, 2015	All	The English expression has been corrected.
		34	Addition of description in 5.1 Overview
		38	Addition of 5.5 Note on Using the SPI
		49	Addition of title (1) Disabling the reception by the UART and description of (2) Reading the ADSTART bit in 6.6 Note on Using the UART

All trademarks and registered trademarks are the property of their respective owners.

EEPROM is a trademark of Renesas Electronics Corporation.

SuperFlash is a registered trademark of Silicon Storage Technology, Inc. in several countries including the United States and Japan.

Caution: This product uses SuperFlash® technology licensed from Silicon Storage Technology, Inc.

## NOTES FOR CMOS DEVICES

### ① VOLTAGE APPLICATION WAVEFORM AT INPUT PIN

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between  $V_{IL}$  (MAX) and  $V_{IH}$  (MIN) due to noise, etc., the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between  $V_{IL}$  (MAX) and  $V_{IH}$  (MIN).

### ② HANDLING OF UNUSED INPUT PINS

Unconnected CMOS device inputs can be cause of malfunction. If an input pin is unconnected, it is possible that an internal input level may be generated due to noise, etc., causing malfunction. CMOS devices behave differently than Bipolar or NMOS devices. Input levels of CMOS devices must be fixed high or low by using pull-up or pull-down circuitry. Each unused pin should be connected to  $V_{DD}$  or GND via a resistor if there is a possibility that it will be an output pin. All handling related to unused pins must be judged separately for each device and according to related specifications governing the device.

### ③ PRECAUTION AGAINST ESD

A strong electric field, when exposed to a MOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop generation of static electricity as much as possible, and quickly dissipate it when it has occurred. Environmental control must be adequate. When it is dry, a humidifier should be used. It is recommended to avoid using insulators that easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors should be grounded. The operator should be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions need to be taken for PW boards with mounted semiconductor devices.

### ④ STATUS BEFORE INITIALIZATION

Power-on does not necessarily define the initial status of a MOS device. Immediately after the power source is turned ON, devices with reset functions have not yet been initialized. Hence, power-on does not guarantee output pin levels, I/O settings or contents of registers. A device is not initialized until the reset signal is received. A reset operation must be executed immediately after power-on for devices with reset functions.

### ⑤ POWER ON/OFF SEQUENCE

In the case of a device that uses different power supplies for the internal operation and external interface, as a rule, switch on the external power supply after switching on the internal power supply. When switching the power supply off, as a rule, switch off the external power supply and then the internal power supply. Use of the reverse power on/off sequences may result in the application of an overvoltage to the internal elements of the device, causing malfunction and degradation of internal elements due to the passage of an abnormal current.

The correct power on/off sequence must be judged separately for each device and according to related specifications governing the device.

### ⑥ INPUT OF SIGNAL DURING POWER OFF STATE

Do not input signals or an I/O pull-up power supply while the device is not powered. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Input of signals during the power off state must be judged separately for each device and according to related specifications governing the device.

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.  
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.  
Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



### SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

**Renesas Electronics America Inc.**  
2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130

**Renesas Electronics Canada Limited**  
9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3  
Tel: +1-905-237-2004

**Renesas Electronics Europe Limited**  
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K  
Tel: +44-1628-585-100, Fax: +44-1628-585-900

**Renesas Electronics Europe GmbH**  
Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

**Renesas Electronics (China) Co., Ltd.**  
Room 1709, Quantum Plaza, No.27 ZhichunLu Haidian District, Beijing 100191, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

**Renesas Electronics (Shanghai) Co., Ltd.**  
Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333  
Tel: +86-21-2226-0888, Fax: +86-21-2226-0899

**Renesas Electronics Hong Kong Limited**  
Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2265-8688, Fax: +852-2886-9022

**Renesas Electronics Taiwan Co., Ltd.**  
13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan  
Tel: +886-2-8175-9600, Fax: +886-2-8175-9670

**Renesas Electronics Singapore Pte. Ltd.**  
80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

**Renesas Electronics Malaysia Sdn.Bhd.**  
Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jin Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

**Renesas Electronics India Pvt. Ltd.**  
No.777C, 100 Feet Road, HAL II Stage, Indiranagar, Bangalore, India  
Tel: +91-80-67208700, Fax: +91-80-67208777

**Renesas Electronics Korea Co., Ltd.**  
12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141