

RL78/G14

R01AN1660EJ0100

Rev.1.00

Apr 9, 2013

Motor control by RL78/G14 micro controller

Sensorless 120 degrees conducting control of permanent magnetic synchronous motor

Summary

This application note aims at explaining the sample program for operating the 3 phase permanent magnetic synchronous motor with sensorless 120° conducting method, by using the functions of RL78/G14.

Sample program is only to be used as reference and Renesas Electronics Corporation does not guarantee the operations. Before using sample program, carry out a thorough evaluation in a suitable environment.

Operation checking device

Operations of the sample program are checked by using the following device.

- RL78/G14 (R5F104LEAFP)

Table of Contents

1. Overview	2
2. System overview	3
3. Motor control method	10
4. Description of peripheral functions used	19
5. Description of control program	25

1. Overview

This application note explains an example of speed control by sensorless 120° conducting method of permanent magnetic synchronous motor, by using micro controller RL78/G14.

1.1 Usage of the system

This system (sample program) enables 120° conducting control by using RSSK ^(Note 1) for motor control (Low Voltage Motor Control Starter-Kit Evaluation System and permanent magnetic synchronous motor (FH6S20E-X81^{Note 2})).

For installation and technical support of 'RSSK for motor control', contact Sales representatives and dealers of Renesas Electronics Corporation.

Notes:

1. RSSK (Renesas Solution Starter Kit) is the product of Renesas Electronics Corporation.
2. FH6S20E-X81 is the product of NIDEC SERVO CORPORATION.
NIDEC SERVO CORPORATION. (<http://www.nidec-servo.com/en/index.html>)

1.2 Development environment

(1)Software development environment

Integrated development environment	CubeSuite+(V1.03.00)
------------------------------------	----------------------

(2)Hardware environment

On-chip debug emulator	E1
Micro controller used	RL78/G14(R5F104LEAFP)
Inverter board for motor control	Low Voltage Motor Control Starter-Kit Evaluation System (P03401-D1-001)
Permanent magnetic synchronous motor	FH6S20E-X81

2. System overview

Overview of this system is explained below.

2.1 Hardware configuration

Hardware configuration is shown below.




Figure 2-1 Hardware Configuration Diagram

2.2 Hardware specifications

2.2.1 User interface

List of user interfaces of this system is given in Table 2-1.

Table 2-1 User Interface

Item	Interface component	Function
Rotation speed	Variable resistance (VR1)	Rotation speed command value input (analog value)
START/STOP	Push switch (SW1)	Motor rotation start/stop command
ERROR RESET	Push switch (SW2)	Command of recovery from error status
LED1	Yellow Green LED	<ul style="list-style-type: none"> • At the time of motor rotation: ON • At the time of stop: OFF
LED2	Yellow Green LED	<ul style="list-style-type: none"> • At the time of error detection: ON • At the time of normal operation: OFF
RESET	Push switch (RESET)	System reset

List of interfaces of RL78/G14 micro controller of this system is given in Table 2-2.

Table 2-2 Port Interface

Port name	Function
P22 / ANI2	Inverter bus voltage measurement
P26 / ANI6	For rotation speed command value input (analog value)
P05	START/STOP push switch
P06	ERROR RESET push switch
P52	LED1ON/OFF control
P53	LED2ON/OFF control
P23 / ANI3	U phase voltage measurement
P24 / ANI4	V phase voltage measurement
P25 / ANI5	W phase voltage measurement
P15 / TRDIOB0	Port or non-complimentary PWM output (Up)
P14 / TRDIOD0	Port or non-complimentary PWM output (Un)
P13 / TRDIOA1	Port or non-complimentary PWM output (Vp)
P12 / TRDIOB1	Port or non-complimentary PWM output (Wp)
P11 / TRDIOC1	Port or non-complimentary PWM output (Vn)
P10 / TRDIOD1	Port or non-complimentary PWM output (Wn)
P137 / INTP0	PWM emergency stop input at the time of over current detection
RESET#	RESET

2.2.2 Peripheral functions

List of peripheral functions used in this system is given in Table 2-3.

Table 2-3 Peripheral Functions List

Peripheral function	Usage
A/D converter (ANI2, ANI3, ANI4, ANI5, ANI6)	<ul style="list-style-type: none"> • Rotation speed command value input • Inverter bus voltage measurement • U, V, W phase voltage measurement
Timer RD (TRD)	Non-complimentary PWM output using reset synchronous PWM mode (six outputs)
INTP0 input	In the case of over current detection, set ports executing PWM output to high impedance
Port (P10 – P15)	Motor control signal output by port output
Timer Array Unit (TAUS)	<ul style="list-style-type: none"> • 1 [ms] interval timer • Free run timer for rotation speed measurement

(1) A/D converter

The rotation speed command value input and Inverter bus voltage (Vdc) are measured by using 'A/D converter'.

For A/D conversion, set channel selection mode to 'Select mode' and conversion operation mode to 'One shot conversion mode' (use software trigger).

Conversion speed of the A/D converter is 2.375 [μ s] per channel and the smallest unit of conversion input value is given in Table 2-4.

Table 2-4 A/D Converter Correspondence Table

Item	Control value for A/D converter 1 bit	Channel
Rotation speed command	2048 [rpm]/512 = 4 [rpm] step (Speed range is 600 [rpm] to 2000 [rpm] for both CW/CCW)	ANI6
U, V, W phase voltage	30 [V]/1024 = 0.0293 [V]	ANI3, ANI4, ANI5
Bus voltage	30 [V]/1024 = 0.0293 [V]	ANI2

(2) Timer Array Unit (TAUS)

(a) 1 [ms] interval timer

1 [ms] interval timer uses 'Interval timer function' of Timer Array Unit TAUS. In this system, channel 0 is used.

(b) Free-run timer for speed measurement

Free-run timer for speed measurement uses 'Interval timer function' of Timer Array Unit TAUS. However, it does not use the interruption. In this system, channel 1 is used.

Table 2-5 Timer Array Unit Usage Channel

No	Usage
Channel 0	Interval timer for 1 [ms] generation
Channel 1	Free-run timer for rotation speed measurement
Channel 2	Not used in this system
Channel 3	Not used in this system

(3) Timer RD (TRD)

The 6-phase PWM output with saw-tooth wave modulation without dead time, is performed by using the reset synchronous PWM mode. Combination of motor control signal output and timer output pins is given in Table 2-6.

Table 2-6 Combination of Motor Control Signal Output and Timer Output Pins

Motor control signal	Timer output pin
Up	TRDIOB0
Un	TRDIOD0
Vp	TRDIOA1
Vn	TRDIOC1
Wp	TRDIOB1
Wn	TRDIOD1

This system enables “High” active PWM output on a 50 [μ s] cycle. Also, high impedance output is performed from the port executing the PWM output, when an over current is detected (at the time of input of “Low” to the INT0 port) by using the pulse output forced shut down function.

(4) General-purpose port

Motor control signals are created by using a port output along with the PWM output. Combination of motor control signal output and general-purpose ports in this system is given in Table 2-7.

Table 2-7 Combination of Motor Control Signal Output and General-Purpose Port

Motor control signal	General-purpose port
Up	P15
Un	P14
Vp	P13
Vn	P11
Wp	P12
Wn	P10

Note:

1. For the notes when switching the port from input mode to output mode, refer to RL78/G14 User’s Manual: Hardware.

(5) Interruption

List of interruptions in this system is given in Table 2-8.

Table 2-8 Usage Interruption List

Interruption name	Interruption source
INTTRD0	PWM carrier interruption
INTP0	At the time of over current detection (falling edge)
INTTM00	1 [ms] interval interruption

2.3 Software structure**2.3.1 Software file structure**

Folders and files structure of the sample program is given below.

Table 2-9 Folder and Files Structure of Sample Program

RL78G14_RSSK_SSNS_LESS_120_ICS_CSP_V100	inc	ics.h	Header for ICS
		main.h	Main function, user interface control header
		mtr_common.h	Header for common definition
		mtr_ctrl_rssk.h	Board dependent processing part header
		mtr_ctrl_rl78g14.h	RL78/G14 dependent processing part header
		mtr_ssns_less_120.h	Sensorless 120° conducting control dependent part header
		r_dsp.h	Header for operation library
		r_fixmath.h	Header for operation library
		r_stdint.h	Header for operation library
	lib	R_dsp_rl78.lib	Operation library
		ics_rl78g14.lib	ICS library
	src	main.c	Main function, user interface control
		mtr_ctrl_rssk.c	Board dependent processing part
		mtr_ctrl_rl78g14.c	RL78/G14 dependent processing part
		mtr_interrupt.c	Interruption handler
mtr_ssns_less_120.c		Sensorless 120° conducting control dependent part	

2.3.2 Module structure

Module structure of the sample program is described below.




Figure 2-2 Module Structure of Sample Program

2.4 Software specifications

Basic specifications of software of this system are given in Table 2-10.

Table 2-10 Software Basic Specifications

Item	Content
Control method	120° conducting method
Motor rotation start/stop	Determined depending on the level of SW1(P05) ("Low": Rotation start "High": stop) (If a speed command value from VR1 is less than 550 [rpm], determined as stop irrespective of level of SW1)
Position detection of rotor magnetic pole	Position detection by back electromotive force (back-EMF) (every 60°)
Carrier frequency(PWM)	20 [kHz]
Control cycle	<ul style="list-style-type: none"> • Zero-crossing determination is performed from back-EMF, for each carrier cycle • PWM duty settings and conduction pattern is determined when switching the pattern.
Rotation speed control range	600 [rpm] to 2000 [rpm] for both CW/CCW
Rotation speed operation	<ul style="list-style-type: none"> • At the time of pattern switching, calculates the rotation count from the time exceeded compared to last time • Interval timer is used for measurement of the edge intervals
Speed control (speed PI control)	Obtains the speed command value from input voltage of VR1 and performs speed control by PI control (5 [ms] cycle)
Processing stop for protection	<ul style="list-style-type: none"> • Disables the motor control signal output (six outputs), under any of the following three conditions <ol style="list-style-type: none"> 1. Inverter bus voltage exceeds 28 [V] (monitored for each 1 [ms]) 2. Rotation speed exceeds 16000 [rpm](electrical angle) (monitored for each 1 [ms]) 3. No zero-crossing signal is detected for 20 [ms] while the motor is running • Changes the port executing the PWM output to high impedance when an over current detection signal ("Low" is input to the INTPO port) is detected from external.

3. Motor control method

Sensorless 120° conducting control and speed control of the permanent magnetic synchronous motor, used in the sample program are explained here.

3.1 Sensorless 120° conducting control of the permanent magnetic synchronous motor

The sensorless control does not have a sensor for obtaining the permanent magnetic position, and hence the alternative to the sensor is required. The sensorless control of permanent magnetic synchronous motor, generally estimates the position by detecting the induced voltage (back-EMF).

The induced voltage in any closed circuit is proportion to the time rate of change of the magnetic flux through the circuit.

For example, consider the case where magnet gets close to the coil, as shown in Figure 3-1. In this case, since the interlinkage magnetic flux increase within the coil, coil generates the electromotive force that flows the current to prevent the increase of interlinkage magnetic flux in the direction of the figure. (The flux of opposite direction of the magnetic flux is occurred by the right-handed screw rule.)




Figure 3-1 Induced Voltage depending on the Coil and Magnet

This induced voltage E_m is expressed by the magnetic flux φ_m as the following formula.

$$E_m = \frac{d}{dt} \varphi_m \dots (1)$$

This event occurs even in the rotating permanent magnetic synchronous motor. When the permanent magnet is rotating, the induced voltage is generated by constantly changing interlinkage magnetic flux of each phase.




Figure 3-2 Induced Voltage in the Rotating Permanent Magnetic Synchronous Motor

Figure 3-3 shows the variation of interlinkage magnetic flux in the U phase. Size of the interlinkage magnetic flux is shown on the vertical (Y) axis and phase of the permanent magnet is shown on the horizontal (X) axis. Also, position for disposing the N pole of permanent magnet to coil is considered as $\theta = 0$.




Figure 3-3 Variation of Interlinkage Magnetic Flux

The Interlinkage magnetic flux of U phase changes in the cosine wave format.

If considered similarly for V phase, W phase, V phase and W phase deviate respectively by $2\pi/3$, $4\pi/3$ phase from U phase. The Interlinkage magnetic flux of the three phases is expressed by the following formula.

$$\begin{aligned} \varphi_u &= \varphi_m \cos \theta \\ \varphi_v &= \varphi_m \cos(\theta - \frac{2}{3}\pi) \\ \varphi_w &= \varphi_m \cos(\theta - \frac{4}{3}\pi) \end{aligned}$$

Also, the induced voltage of three phases is expressed by the following formula, by using formula (1), when the angle speed is considered as ω .

$$\begin{aligned} E_u &= \frac{d}{dt} \varphi_u = \frac{d}{dt} \varphi_m \cos \theta = -\omega \varphi_m \sin \theta = \omega \varphi_m \cos(\theta + \frac{\pi}{2}) \\ E_v &= \frac{d}{dt} \varphi_v = \frac{d}{dt} \varphi_m \cos(\theta - \frac{2}{3}\pi) = -\omega \varphi_m \sin(\theta - \frac{2}{3}\pi) = \omega \varphi_m \cos(\theta - \frac{\pi}{6}) \\ E_w &= \frac{d}{dt} \varphi_w = \frac{d}{dt} \varphi_m \cos(\theta - \frac{4}{3}\pi) = -\omega \varphi_m \sin(\theta - \frac{4}{3}\pi) = \omega \varphi_m \cos(\theta - \frac{5}{6}\pi) \end{aligned}$$

From this formula, it is understood that the induced voltage lead of $\pi/2$ phase from permanent magnetic flux. This means that if the induced voltage can be detected, position of the permanent magnet can be estimated.




Figure 3-4 Zero-crossing of the Induced Voltage

However, the induced voltage of each phase is not always detected while the motor is rotating.

During the driving in 120° conduction, conduction is performed to the two phases among the three phases and hence only the remaining one phase, to which conduction is not performed, can detect the induced voltage. Actually, position information is obtained by detecting the point of change in the sign of induced voltage (zero-crossing) occurring in non-conducting phase, which can detect the induced voltage.

In the three phases motor, this zero-crossing occurs for total six times, i.e. twice in each phase, in one rotation (electrical angle) of the motor. This means that the position for every 60° can be detected by this process in the same way as resolution of hall sensor.




Figure 3-5 Relation between Conducting Pattern and Zero-crossing

However, this zero-crossing detection signal cannot be used in the same way as the signal of the hall sensor.

The zero-crossing detection signal occurs at the point where phase is shifted $\pi/6$ from proper conduction pattern switching timing, as shown in Figure 3-5. Therefore, in the actual control, conduction pattern is switched at the point where phase is shifted $\pi/6$ from detecting the zero-crossing.

3.2 Zero-crossing detection method

Various zero-crossing detection methods are used. The method of detecting the zero-crossing by comparing the value of induced voltage with the center point voltage by the software, using the A/D converter of micro computer is introduced here. Since voltage is compared without the comparator, it is called as comparatorless method.




Figure 3-6 Comparatorless Method

Actually detecting the induced voltage, commutation voltage occurring when switching the conducting patterns and impact of the PWM of other phases must be considered. This impact is expressed in the format shown in Figure 3-7.




Figure 3-7 Overview Diagram of Impact of the Commutation and Other Phase PWM

In this system, this impact is removed by using the simple filter route and the software.

3.3 Start-up method

Induced voltage does not occur unless the permanent magnet is rotating. This means that the position of magnet cannot be estimated by using the induced voltage, at the time of starting.

Therefore, start-up method in this system synchronizes speed of the permanent magnet by generating a rotating magnetic field by forcibly switching the conduction pattern regardless of the position of permanent magnet.




Figure 3-8 Diagram of Start-up Operation

3.4 Position estimate operation

In this system, the virtual center voltage of the motor is calculated by the sum of A/D conversion voltage of each phase in each PWM control cycle. The pattern of '1' '0' is created by comparing the virtual motor center voltage with each phase voltage.

Then, the virtual hall sensor pattern is created by shifted $\pi/6$.

" $\pi/6$ " is estimated from the number of PWM control between zero-crossing.




Figure 3-9 Virtual Hall Sensor Pattern (When Chopping the Upper Arm)

3.5 Speed control

In this system, the motor rotation speed is calculated from a difference between the previous and current timer values by detecting the zero-crossing, at the time of switching the patterns while having the timer of channel 1 of timer array unit performed free running.

Furthermore, in this system, the calculation result is processed LPF.




Figure 3-10 Method of Calculating the Motor Rotation Speed

This system is using PI control for speed control. A voltage command value at any (discrete) time n is calculated by the following formula.

$$V[n] = V[n-1] + K_P \times (\text{err}[n] - \text{err}[n-1]) + K_I \times \text{err}[n]$$

V: Command value voltage

err: Deviation of rotation speed command value and rotation speed calculation value

K_P : Proportional gain K_I : Integral gain

Sensorless 120 degrees conducting control of permanent magnetic synchronous motor

Also, PWM control is used for the output voltage control. The PWM control is a control method that continuously adjusts the average voltage by varying the duty of pulse, as shown in Figure 3-11.




Figure 3-11 PWM control

Here, modulation factor m is defined as follows.

$$m = \frac{V}{E}$$

m: Modulation factor V: Command value voltage E: Inverter bus voltage

This modulation factor is reflected in the setting value of resistor that determines the PWM duty.

In this system, first 60° chopping is adopted and thus output voltage and speed are controlled. An example of motor control signal output waveforms at the time of first 60° chopping is given in Figure 3-12.




Figure 3-12 First 60° Chopping

4. Description of peripheral functions used

Peripheral functions used in this system are explained.

Following peripheral functions are explained in this chapter.

- External interruption function
- A/D converter function
- Timer Array Unit TAUS function
- Timer RD function

4.1 External interruption function

In this system, external interruptions are set as given in Table 4-1.

Table 4-1 External Interruption Setting Details

interruption	Item	Content	Usage
INTP0	Valid edge	Falling edge	Over current detection
	Interruption priority level	0	

4.2 A/D converter function

A/D converter converts the analog input to digital value. The target micro controller (RL78/G14), incorporates one circuit of 10 bit A/D converter. Analog input of twelve channels can be converted to digital values by controlling the conversion channel.

In this system, the A/D converter is set as given in Table 4-2.

Table 4-2 A/D Converter Setting Details

Channel	Item	Content	Conversion target
ANI6	Conversion time	2.375 [μ s]	Rotation speed command value
	Channel selection mode	Select mode	
	Conversion operation mode	One-shot conversion mode	
	Conversion starting conditions	Software trigger	
ANI3, ANI4, ANI5	Conversion time	2.375 [μ s]	U, V, W phase voltage
	Channel selection mode	Select mode	
	Conversion operation mode	One-shot conversion mode	
	Conversion starting conditions	Software trigger	
ANI2	Conversion time	2.375 [μ s]	Inverter bus voltage
	Channel selection mode	Select mode	
	Conversion operation mode	One-shot conversion mode	
	Conversion starting conditions	Software trigger	

4.3 Timer Array Unit TAUS function

The Timer Array Unit TAUS, consists of four 16-bit timers. Each 16 bit timer is called 'Channel' and can be used an independent timer as well as an advanced timer function, by combining multiple channels.




Figure 4-1 Timer Array Unit

In this system, the Timer Array Unit is set as given in Table 4-3.

Table 4-3 Timer Array Unit Setting Details

Channel	Item	Content	Usage
Channel 0	Operation mode of timer	Interval timer function	Timer for generating 1 [ms]
	Source clock	CK00	
	Count clock frequency	32 [MHz]	
	Interruption cycle	1 [ms]	
	Timer data resistor0 (TDR00) setting value	31999 (1 [ms]/31.25 [ns] - 1)	
Channel 1	Operation mode of timer	Interval timer function	Timer for speed calculation
	Source clock	CK01	
	Count clock frequency	125 [kHz]	
	Interruption cycle	524 [ms] (unused)	
	Timer data resistor1 (TDR01) setting value	65535	
Channel 2	Not used in this system		
Channel 3	Not used in this system		

Also, basic timings of the interval timer are shown in Figure 4-2.




Figure 4-2 Example of Basic Timings of Interval Timer (Example of Channel 0)

4.4 Timer RD function

Timer RD has two 16-bit timers (timer RD0 and timer RD1).

Following four modes are provided in timer RD.

- Timer mode
- Reset synchronous PWM mode
- Complementary PWM mode
- PWM3 mode

In this system, the timer RD is set as given in Table 4-4.

Table 4-4 Timer RD Setting Details

Timer used	Item	Content	Usage
Timer RD	Mode used	Reset synchronous PWM mode	Six phase PWM output
	PWM cycle	50 [μ s]	
	Count frequency	64 [MHz]	
	Output level	Initial output "Low", active level "High"	
	Buffer operations	None	
	Pulse output forced shutdown control	Valid (Output value at the time of shutdown: High impedance output)	
	Output port	Refer to Figure 4-3	

Note:

1. In reset synchronous mode, the timer RD outputs a waveform by combining the counters and registers of timer RD0 and timer RD1.

An example of PWM output waveform is shown in Figure 4-3.




Figure 4-3 Example of PWM Output Waveform In Reset Synchronous PWM Mode

4.5 Calculation of PWM duty setting using modulation factor

This part summarizes how to set duty in reset synchronous PWM mode.

Set the PWM cycle, in the TRDGRA0 register first. Accordingly, define a setting value of each compare register of TRDGRB0, TRDGRA1 and TRDGRB1. Each value set here determines duty of PWM of U phase, V phase and W phase respectively. Note that the setting values of compare registers vary in positive phase and negative phase even in case of setting the same duty.

Setting values of TRDGRA0, TRDGRB0, TRDGRA1 and TRDGRB1 are calculated by the following formula.

$$\begin{aligned} \text{TRDGRA0} &= \text{PWM cycle [s]} \times \text{Count clock frequency [Hz]} - 1 \\ \text{(Positive phase) TRDGRB0} &= \text{TRDGRA1} = \text{TRDGRB1} = \{(\text{TRDGRA0} + 1) / 100\} \times (100 - \text{duty [\%]}) \\ \text{(Negative phase) TRDGRB0} &= \text{TRDGRA1} = \text{TRDGRB1} = \{(\text{TRDGRA0} + 1) / 100\} \times \text{duty [\%]} - 1 \end{aligned}$$

From the modulation factor explained in section 3.5, values to be set to TRDGRB0, TRDGRA1 and TRDGRB1 are calculated by the following formula.

$$\begin{aligned} \text{(Positive phase) TRDGRB0} &= \text{TRDGRA1} = \text{TRDGRB1} = (\text{TRDGRA0} + 1) \times (1 - \text{modulation factor}) - 1 \\ \text{(Negative phase) TRDGRB0} &= \text{TRDGRA1} = \text{TRDGRB1} = (\text{TRDGRA0} + 1) \times \text{modulation factor} - 1 \end{aligned}$$

5. Description of control program

Control program of this system is explained here.

5.1 Control block diagram

In the sample program, a motor is driven by open loop control. After that, control is performed according to the following block diagram.




Figure 5-1 Control Block Diagram

Function is given below:

(1) Position detection of permanent magnet

Permanent magnetic position is detected by the zero-crossing of each phase of U, V and W.

(2) Rotation speed calculation

Rotation speed is calculated from the timer counter (TCR01) at the timing of detecting zero-crossing. The rotation speed calculation value is used in speed control.

(3) Speed control

Speed control is using PI control. The output value of speed PI control is set as a voltage command value.

(4) Processing stop for protection

Processing stop for protection prevents the motor or inverter from breakage due to over current, over voltage, over speed.

5.2 Contents of Control

5.2.1 Motor start/stop

Starting and stopping the motor are controlled by input from SW1 and VR1.

A general-purpose port (P05) is assigned to SW1. The sample program reads P05 port within the main loop. When P05 is at "Low" level, it is judged that the start switch is being pressed. On the other hand, when the level is switched to "High", the program determines to stop the motor.

Also, an analog input port (AN16) is assigned to VR1. Input to AN16 is A/D converted within the main loop and a rotation speed command value is generated (As for creation of the rotation speed command value, refer to 5.2.2). When the rotation speed command value is less than 550 [rpm], the program determines to stop the motor.




Figure 5-2 Conceptual Diagram of Start Switch External Circuit

5.2.2 Motor rotation speed command value, Inverter bus voltage, motor 3 phase voltage

(1) Motor rotation speed command value

The motor rotation speed command value N* can be set by A/D converting the output value (analog value) of VR1. The A/D converted VR1 values are used as rotation speed command value, as shown in Table 5-1.

Table 5-1 Conversion Ratio of Speed Command Value

Item		Conversion ratio (Command value N*: A/D conversion value)	Channel
Rotation speed command value	CW	0 [rpm] to 2048 [rpm]: 01FFH to 03FFH	ANI6
	CCW	0 [rpm] to 2048 [rpm]: 0000H to 01FFH	

(2) Inverter bus voltage

Inverter bus voltage is measured as given in Table 5-2.

It is used for modulation factor calculation and over voltage detection (When an over voltage is detected, PWM is stopped.).

Table 5-2 Inverter Voltage Conversion Ratio

Item	Conversion ratio (Inverter voltage Vdc: A/D conversion value)	Channel
Inverter bus voltage	0 [V] to 30 [V]: 0000H to 03FFH	ANI2




Figure 5-3 Conceptual Diagram of Inverter Voltage Measurement External Circuit

(3) U, V, W phase voltage

Voltage of U, V and W phase is calculated and is used for zero-crossing judgment as shown in Table 5-3.

Table 5-3 Conversion Ratio of U, V and W Phase Voltage

Item	Conversion ratio (Inverter voltage Vdc: A/D conversion value)	Channel
U, V, W phase voltage	0 [V] to 30 [V]: 0000H to 03FFH	ANI3, ANI4, ANI5




Figure 5-4 Conceptual diagram of U, V and W Phase Voltage Calculation External Circuit

5.2.3 Rotation speed operations

The rotation speed is calculated by using zero-crossing detection and free run timer (TAUS channel 01). In the timing of pattern switching by zero-crossing detection, counter value of free run timer is obtained from on the difference with the previously obtained value. Based on the difference, speed is calculated by the following formula.

$$\text{Rotation speed (N)} = (60 \times 125 \text{ [kHz]}) / \{(\text{last counter value} - \text{current counter value}) \times 6\}$$

Notes:

1. 125 [kHz] = (count clock frequency of free-run timer)
2. (x6) is done as the period for obtaining the counter value is $\pi/3$

In this sample program, LPF (migration average) processing is performed for the speed calculation result, before speed PI control.

5.2.4 Speed PI control

In this sample program, speed PI control is performed on a 5 [ms] cycle, to avoid the multiple executions of PI control till next pattern switching.

The voltage command value (V^*) is created as given below.

Proportional (P) term: $K_p \times (\text{current rotation speed deviation} - \text{last rotation speed deviation})$

Integral (I) term: $K_i \times (\text{current rotation speed deviation})$

Voltage command value (V^*) = previous voltage command value + proportional term + integral term

Notes:

1. Proportional gain (K_p): 0.0003
 2. Integral gain (K_i): 0.00001
- Values of K_p and K_i depend on the used system.

For details of PI control, refer to specialized books.

5.2.5 System protection function

This control program has the following five types of error status and enables emergency stop functions in case of occurrence of respective error.

• Over current error

An emergency stop signal (over current detection) from hardware forces the program to execute high impedance output to PWM the output port (emergency stop without involving CPU). The INTP0 port is used.

• Over voltage error

The inverter bus voltage is monitored, with 1 [ms] interval. When an over voltage is detected (when the voltage exceeds 28 [V]), CPU performs emergency stop. The threshold of the overvoltage error is set in consideration of the error of resistance and the supply voltage.

- Rotation speed abnormality error

The rotation speed calculation value is monitored with 1 [ms] interval. When an error value is detected in rotation speed values (in case of value over 16000 [rpm] (electrical angle), CPU performs emergency stop.

- Timeout error

When the zero cross doesn't detect for 20 [ms], CPU performs emergency stop.

- Induced voltage signal pattern error

The patterns created from each phase voltage of U, V, W are monitored. When an error pattern is detected, CPU performs emergency stop.

5.3 System resource

5.3.1 Interruption

List of interruptions used in this control program is given below.

Table 5-4 Interruption Resource

Interruption	Interruption handler	Interruption occurrence condition	Main function
Carrier synchronous interruption (INTTRD0)	void mtr_carrier_interrupt(void)	50 [μ s] (20 [kHz])	<ul style="list-style-type: none"> • Zero-crossing detection processing • Conduction pattern switching • Rotation speed operation • Clearing the motor stop determination counter value
Interval timer interruption (INTTM00)	void mtr_tau0_interrupt(void)	1 [ms] (1 [kHz])	<ul style="list-style-type: none"> • Speed PI control • Error monitoring • Control start time measurement
Over current detection interruption (INTP0)	void mtr_over_current_interrupt(void)	Over current detection	Over current protection

5.3.2 A/D converter input signal and used channels

List of used channels of A/D converter used in this control program is given below.

Table 5-5 A/D Converter Settings

Channel	Measurement signal	Range of setting value	Remark
ANI2	Inverter bus voltage	30 [V] / 5 [V]	Used in modulation factor calculation, over voltage protection
ANI3, ANI4, ANI5	Voltage of U, V and W phase	30 [V] / 5 [V]	Used in zero-crossing detection
ANI6	Rotation speed command value	CW: 2048 [rpm] / 2.5 [V] CCW: 2048 [rpm] / 2.5 [V]	Determined as limit in 2000 [rpm] and as stop in case of less than 550 [rpm]

5.3.3 Port function

List of port functions used in this control program is given below.

Table 5-6 Port Functions

Input/output	Port number	Function	Remark
Input	P05	START/STOP switch input	
	P06	ERROR RESET switch input	
output	P52	LED display during operation	
	P53	Error LED display	
	P15	U phase upper arm motor control signal port output (Up)	Logic setting is "High" active
	P14	U phase lower arm motor control signal port output (Un)	
	P13	V phase upper arm motor control signal port output (Vp)	
	P11	V phase lower arm motor control signal port output (Vn)	
	P12	W phase upper arm motor control signal port output (Wp)	
	P10	W phase lower arm motor control signal port output (Wn)	

5.3.4 PWM output part

List of PWM output parts used in this control program is given below.

Table 5-7 PWM Signals

Input/output	Output port	Function	Remark
output	TRDIOB0	U phase upper arm motor control signal PWM output (Up)	Logical setting is "High" active
	TRDIOD0	U phase lower arm motor control signal PWM output (Un)	
	TRDIOA1	V phase upper arm motor control signal PWM output (Vp)	
	TRDIOC1	V phase lower arm motor control signal PWM output (Vn)	
	TRDIOB1	W phase upper arm motor control signal PWM output (Wp)	
	TRDIOD1	W phase lower arm motor control signal PWM output (Wn)	

5.4 Function specifications

Multiple control functions are used in this control program. Lists of control functions are given below.

For detailed processing, refer to flowcharts or source files.

Table 5-8 Control Functions List (1/3)

File name	Function overview	Processing overview
main.c	main() Input: None Output : None	<ul style="list-style-type: none"> • Hardware initialization function call • User interface initialization function call • Main processing used variable initialization function call • Status transition and event execution function call • Main processing <ul style="list-style-type: none"> ⇒ Main processing execution function call ⇒ Watchdog timer clear function call
	ctrl_ui() Input: None Output : None	<ul style="list-style-type: none"> • Motor status change • Determination of rotation speed command value and rotation direction
	software_init() Input: None Output : None	Initialization of variables used in the main processing
mtr_ctrl_rssk.c	get_vr1() Input: None Output : (int16) ad_data / A/D conversion result	A/D conversion execution function call
	get_sw1() Input: None Output : (uint8) tmp_port / level of SW1	Obtaining the status of SW1
	get_sw2() Input: None Output : (uint8) tmp_port /level of SW2	Obtaining the status of SW2
	led1_on() Input: None Output : None	Turning LED1 ON
	led2_on() Input: None Output : None	Turning LED2 ON
	led1_off() Input: None Output : None	Turning LED1 OFF
	led2_off() Input: None Output : None	Turning LED2 OFF

Table 5-8 Control functions list (2/3)

File name	Function name	Processing overview
mtr_ssns_les_120.c	R_MTR_InitSequence() Input : None Output : None	Initialization of variables to use for sequence control
	R_MTR_ExecEvent() Input: (uint8)u1_event / occurred event Output : None	• Changing the status • Calling an appropriate processing execution function for the occurred event
	mtr_act_run () Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	• Variable initialization function call upon motor startup • Motor control startup function call • Output pattern determination function call
	mtr_act_stop () Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	Motor control stop function call
	mtr_act_none () Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	No processing is performed
	mtr_act_reset () Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	• Global variable initialization • Waiting for motor stop
	mtr_act_error() Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	Motor control stop function call
	mtr_pattern_set() Input: (uint8)u1_state / motor status Output : (uint8)u1_state / motor status	• Speed measurement function call • Conduction pattern determination • Motor control signal creation function call
	mtr_speed_calc () Input: None Output : None	Speed measurement calculation processing
	mtr_start_init () Input: None Output : None	Initializing only the variables required for motor startup
	mtr_pi_ctrl_speed () Input: None Output : None	Speed PI control
	R_MTR_SetSpeed () Input: (int16)ref_speed / Rotation speed command value Output : None	Rotation speed command value setting
	R_MTR_SetDir() Input: (uint8)dir / Rotation direction command value Output : None	Rotation direction setting
	R_MTR_GetSpeed () Input: None Output : (int16)g_s2_rpm / Rotation speed calculation value	Obtaining the rotation speed calculation value(electrical angle)
	R_MTR_GetStatus () Input: None Output : (uint8)g_u1_mode_system / motor status	Obtaining the motor status
	mtr_error_check() Input: None Output : None	Error monitoring and detection
mtr_detect_zerocross() Input: None Output : None	• Zero-crossing detection • Creating the pattern switching timing	

Table 5-8 Control functions list (3/3)

File name	Function name	Processing overview
mtr_interrupt.c	mtr_over_current_interrupt () Input: None Output : None	<ul style="list-style-type: none"> • Changing the motor status • Event processing selection function call • Pulse output forced shutdown flag clearing function call
	mtr_tau0_interrupt () Input: None Output : None	<ul style="list-style-type: none"> • Error check function call • Calling speed PI control function every 5 [ms] • Open loop startup control
	mtr_carrier_interrupt () Input: None Output : None	<ul style="list-style-type: none"> • Zero-crossing detection function call • Compare the match flag (IMFA) clear function call
mtr_ctrl_rl78g14.c	R_MTR_InitHardware () Input: None Output : None	Initializing clock and peripheral functions
	init_ui() Input: None Output : None	Initializing user usage peripheral functions
	mtr_ctrl_start () Input: None Output : None	Starting TAU0 count
	mtr_ctrl_stop() Input: None Output : None	<ul style="list-style-type: none"> • Stopping timer RD output • Stopping TAU0 count • Setting the motor control output port to inactive status • Waiting for motor rotation stop
	mtr_ctrl_error() Input: None Output : None	<ul style="list-style-type: none"> • Stopping timer RD output • Stopping TAU0 count • Setting the motor control output port to inactive status
	mtr_change_pattern() Input: (uint8)pattern / conduction pattern Output : None	<ul style="list-style-type: none"> • Output pattern setting • Changing the motor status when output pattern error occurs • Event processing selection function call
	mtr_get_adc() Input: (uint8)ad_ch / conversion channel Output : (int16)s2_temp / A/D conversion result	Executing the A/D conversion
	clear_wdt() Input: None Output : None	Clearing the watchdog timer
	mtr_clear_oc_flag () Input: None Output : None	Clearing the pulse output forced shutdown flag
mtr_clear_trd0_imfa() Input: None Output : None	Clearing the compare match flag (IMFA)	

5.5 Variables list

Lists of variables used in this control program are given below. Note that local variables are not described.

Table 5-9 Variables List (1/2)

Variable name	Type	Content	Remark
g_s2_max_speed	int16	Rotation speed command maximum value	Mechanical angle [rpm]
g_s2_min_speed	int16	Rotation speed command minimum value	Mechanical angle [rpm]
g_s2_margin_min_speed	int16	Rotation speed command minimum value for motor stop	Mechanical angle [rpm]
g_s2_ref_speed	int16	User setting rotation speed	Electrical angle [rpm]
g_u1_rot_dir	uint8	User setting rotation direction	0: CW 1: CCW
g_u1_motor_status	uint8	User motor status management	0 : Stop 1 : Rotating 2 : Error
g_u1_reset_req	uint8	Reset request flag	0: Turning SW2 ON at the time of error status 1: Turning SW2 OFF at the time of error status
g_u1_sw1_cnt	uint8	SW1 determination counter	Chattering removal
g_u1_sw2_cnt	uint8	SW2 determination counter	Chattering removal
g_u1_stop_req	uint8	VR1 stop command flag	Stop is determined when rotation speed command value is less than 550 [rpm]
g_u1_cnt_speed_pi	uint8	Speed PI control decimation counter	Speed PI control cycle 5 [ms] is counted
g_s2_pwm_duty	int16	Timer RD compare resister setting value	-
g_u1_openloop_period	uint8	Pattern switching cycle	Pattern switching cycle
g_u1_cnt_openloop_period	uint8	Pattern switching cycle counter	Counts 1 [ms] interruption frequency
g_u1_cnt_openloop_pattern	uint8	Pattern switching counter	Counts pattern switching frequency
g_u2_cnt_wait_stop	uint16	Motor rotation stop waiting counter	10 [ms] after motor stop processing is counted. (Note that the count is reset when a zero-crossing signal is detected.)
g_u1_flg_wait_stop	uint8	Motor rotation stop waiting flag	The flag set upon motor stop command. When no zero-crossing signal is detected for 10 [ms] after motor stop processing, the flag is cleared.
g_u2_run_mode	uint16	Operation mode management	1: Open loop mode 4: Normal operation mode
g_u1_error_status	uint8	Error status management	1: Over current error 2: Over voltage error 3: Rotation speed abnormality error 4: Timeout error 6: Induced voltage pattern error (0xff: Non-definition error)
g_u1_mode_system	uint8	Status management	0: Stop mode 1: Run mode 2: Error mode

Table 5-9 Variables list (2/2)

Variable name	Type	Content	Remark
g_u1_v_pattern	uint8	Conduction pattern	-
g_u1_direction	uint8	Rotation direction management	0: CW 1: CCW
g_s2_rpm	int16	Rotation speed operation value	Electrical angle [rpm]
g_f4_rpm_err	float32	Rotation speed deviation	Electrical angle [rpm]
g_f4_rpm_err_old	float32	Previous rotation speed deviation	Electrical angle [rpm]
g_s2_rpm_ref	int16	Rotation speed command value	Electrical angle [rpm]
g_f4_speed_pi_p	float32	Speed PI control proportional term	-
g_f4_speed_pi_i	float32	Speed PI control integral term	-
g_f4_speed_pi_kp	float32	Speed PI control proportional gain	-
g_f4_speed_pi_ki	float32	Speed PI control integral gain	-
g_f4_v_ref	float32	Voltage command value	Speed I control output value [V]
g_s2_vdc	int16	Inverter bus voltage A/D value	[V]
g_u2_cnt_timeout	uint16	Stop determination time measurement counter	Cleared when the conducting pattern is switched
g_u2_bemf_timer_cnt	uint16	Free run timer count value	TCR01
g_u2_bemf_timer_cnt_old	uint16	Last free run timer count value	-
g_u1_v_pattern_open	uint8	Conduction pattern for open loop	-
g_u1_v_pattern_num	uint8	Conduction pattern command number	-
g_u2_inv_vu	uint16	U phase voltage	
g_u2_inv_vv	uint16	V phase voltage	
g_u2_inv_vw	uint16	W phase voltage	
g_u2_inv_vn	uint16	Three phase voltage total value	-
g_u1_bemf_signal	uint8	Pattern created from induced voltage	-
g_u1_bemf_signal_old	uint8	Pattern created from the last induced voltage	-
g_u2_cnt_carrier	uint16	Carrier cycle interruption counter	-
g_u2_cnt_carrier_old	uint16	Last carrier interruption counter value	-
g_u2_angle_shift_cnt	uint16	Pattern switching timing command value	-
g_s2_angle_shift_adjust	int16	Pattern switching timing adjustment value	0, in this sample program
g_u1_def_state	uint8	Motor status definition	Array members • Stop mode • Run mode • Error mode
gp_u1_def_action	uint8	Action definition	Array members • Stop action • Run action • Error action • Reset action • No action

5.6 Macro definitions

List of macro definitions used in this control program is given below.

Table 5-10 Macro definitions list (1/5)

File name	Macro name	Definition value	Remark
main.h	M_CW	0	User setting rotation direction: CW
	M_CCW	1	User setting rotation direction: CCW
	MAX_SPEED	2000	Rotation speed command maximum value(Mechanical angle) [rpm]
	MIN_SPEED	600	Rotation speed command minimum value(Mechanical angle) [rpm]
	MARGIN_SPEED	50	Rotation speed command minimum value creation constants for stop (Mechanical angle) [rpm]
	MARGIN_MIN_SPEED	MIN_SPEED - MARGIN_SPEED	Rotation speed command minimum value for motor stop (Mechanical angle) [rpm]
	SW_ON	0	Active in case of "Low"
	SW_OFF	1	Active in case of "Low"
	CHATTERING_CNT	10	Chattering removal
	VR1_SCALING	4	Speed command value creation constant
	ADJUST_OFFSET	0x1FF	Speed command value offset adjustment constant
	POLE_PAIR	7	Pole pairs
	REQ_CLR	0	VR1 stop command flag clearing
REQ_SET	1	VR1 stop command flag setting	

Table 5-10 Macro definitions list (2/5)

File name	Macro name	Definition value	Remark
mtr_ctrl_rl78g14.h	MTR_PWM_TIMER_FREQ	64	Timer RD count frequency [MHz]
	MTR_TAU1_FREQ	125000	Timer Array Unit channel 1 Count frequency [Hz]
	MTR_PORT_UP	P1.5	U phase (Positive phase) output port
	MTR_PORT_UN	P1.4	U phase (Negative phase) output port
	MTR_PORT_VP	P1.3	V phase (Positive phase) output port
	MTR_PORT_VN	P1.1	V phase (Negative phase) output port
	MTR_PORT_WP	P1.2	W phase (Positive phase) output port
	MTR_PORT_WN	P1.0	W phase (Negative phase) output port
	MTR_TAU1_CNT	TCR01	Timer count resister for speed measurement
	MTR_ADCCH_VR1	6	VR1 A/D conversion channel
	MTR_ADCCH_VDC	2	Inverter bus voltage A/D conversion channel
	MTR_ADCCH_VU	3	U phase voltage A/D conversion channel
	MTR_ADCCH_VV	4	V phase voltage A/D conversion channel
	MTR_ADCCH_VW	5	W phase voltage A/D conversion channel
	MTR_MAX_VDC	24	Limit of the voltage command value [V]
	MTR_VDC_RESOLUTION	30 / 1023	Inverter bus voltage resolution
	MTR_PORT_SW1	P0.5	SW1 input port
	MTR_PORT_SW2	P0.6	SW2 input port
	MTR_PORT_LED1	P5.2	LED1 output port
	MTR_PORT_LED2	P5.3	LED2 output port
MTR_LED_ON	0	Active in case of "Low"	
MTR_LED_OFF	1		

Table 5-10 Macro Definitions List (3/5)

File name	Macro name	Definition value	Remark
mtr_ssns_less_120.h	MTR_CARRIER_FREQ	20	PWM carrier frequency [kHz]
	MTR_START_DUTY	10	PWM duty initial value [%]
	MTR_OPENLOOP_START_PERIOD	6	Pattern switching cycle initial value [ms]
	MTR_OPENLOOP_CHANGE_CNT	84	Pattern switching cycle change count value
	MTR_CHANGE_MODE_PERIOD	4	Sensorless control transition cycle [ms]
	MTR_PATTERN_CW_U_V	5	CW virtual hall sensor value
	MTR_PATTERN_CW_U_W	4	
	MTR_PATTERN_CW_V_W	6	
	MTR_PATTERN_CW_V_U	2	
	MTR_PATTERN_CW_W_U	3	
	MTR_PATTERN_CW_W_V	1	
	MTR_PATTERN_CCW_U_V	4	CCW virtual hall sensor value
	MTR_PATTERN_CCW_W_V	5	
	MTR_PATTERN_CCW_W_U	1	
	MTR_PATTERN_CCW_V_U	3	
	MTR_PATTERN_CCW_V_W	2	
	MTR_PATTERN_CCW_U_W	6	
	MTR_SPEED_PI_DECIMATION	4	Speed PI control decimation count [ms]
	MTR_SPEED_PI_KP	0.0003	Proportional gain
	MTR_SPEED_PI_KI	0.00001	Integral gain
	MTR_CARRIER_SET	$1000 / \text{MTR_CARRIER_FREQ} * \text{MTR_PWM_TIMER_FREQ} - 1$	PWM cycle register setting value
	MTR_START_DUTY_SET	$((\text{MTR_CARRIER_SET} + 1) / 100) * \text{MTR_START_DUTY} - 1$	PWM duty setting register initial value
	MTR_RATE_DUTY	$\text{MTR_START_DUTY} / 100$	PWM duty initial value
	MTR_MAX_PWM_DUTY	$((\text{MTR_CARRIER_SET} + 1) / 100) * 57 - 1$	PWM duty setting register maximum value
	MTR_MIN_PWM_DUTY	$((\text{MTR_CARRIER_SET} + 1) / 100) * 17 - 1$	PWM duty setting register minimum value
	MTR_SPEED_LIMIT	16000	Speed abnormality error determination value (electrical angle) [rpm]

Table 5-10 Macro Definitions List (4/5)


File name	Macro name	Definition value	Remark
mtr_ssns_less_120.h	MTR_OVERVOLTAGE_LIMIT	28	Over voltage error determination value [V]
	MTR_TIMEOUT_CNT	20	Stop determination time [ms]
	MTR_SHIFT_ADJUST	0	Pattern switching timing adjustment value
	MTR_RPM_CALC_BASE	$60 * MTR_TAU1_FREQ / 6$	Constant for speed measurement
	MTR_PATTERN_ERROR	0	Conducting pattern
	MTR_UP_PWM_VN_ON	1	
	MTR_UP_PWM_WN_ON	2	
	MTR_VP_PWM_UN_ON	3	
	MTR_VP_PWM_WN_ON	4	
	MTR_WP_PWM_UN_ON	5	
	MTR_WP_PWM_VN_ON	6	
	MTR_UP_ON_VN_PWM	7	
	MTR_UP_ON_WN_PWM	8	
	MTR_VP_ON_UN_PWM	9	
	MTR_VP_ON_WN_PWM	10	
	MTR_WP_ON_UN_PWM	11	
	MTR_WP_ON_VN_PWM	12	
	MTR_CW	0	
	MTR_CCW	1	Rotation direction setting value: CCW
	MTR_OVERSIZE_LIMIT	38	Speed deviation minimum value
	MTR_FLG_CLR	0	Constant for flag clear
MTR_FLG_SET	1	Constant for flag setting	
MTR_STOP_WAIT_CNT	200	Period to wait for stop [ms]	

Table 5-10 Macro Definitions List (5/5)


File name	Macro name	Definition value	Remark
mtr_ssns_less_120.h	MTR_OPENLOOP_MODE	0x01	Open loop mode
	MTR_BEMF_120_MODE	0x04	Sensorless operation mode
	MTR_OVER_CURRENT_ERROR	1	Over current error
	MTR_OVER_VOLTAGE_ERROR	2	Over voltage error
	MTR_OVER_SPEED_ERROR	3	Rotation speed abnormality error
	MTR_TIMEOUT_ERROR	4	Timeout error
	MTR_BEMF_ERROR	6	Induced voltage pattern error
	MTR_UNKNOWN_ERROR	0xff	Undefined error
	MTR_MODE_STOP	0	Stop status
	MTR_MODE_RUN	1	Rotating status
	MTR_MODE_ERROR	2	Error status
	MTR_SIZE_STATE	3	Status count
	MTR_EVENT_STOP	0	Motor stop event
	MTR_EVENT_RUN	1	Motor startup event
	MTR_EVENT_ERROR	2	Motor error event
	MTR_EVENT_RESET	3	Motor reset event
	MTR_SIZE_EVENT	4	Events count

5.7 Control flow (flow chart)


(1) Main process




(2) Carrier cycle interruption process



(3)1 [ms] interruption process



(4) Over current interruption process



Website and support

Renesas Electronics Website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/contact/>

All trademarks and registered trademarks are the property of their respective owners.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this manual, refer to the relevant sections of the manual. If the descriptions under General Precautions in the Handling of MPU/MCU Products and in the body of the manual differ from each other, the description in the body of the manual takes precedence.

1. Handling of Unused Pins

Handle unused pins in accord with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.

In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable.

When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between Products

Before changing from one product to another, i.e. to one with a different type number, confirm that the change will not lead to problems.

- The characteristics of MPU/MCU in the same group but having different type numbers may differ because of the differences in internal memory capacity and layout pattern. When changing to products of different type numbers, implement a system-evaluation test for each of the products.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.
"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.
Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.

2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.
Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited

1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.
Tel: +44-1628-651-700, Fax: +44-1628-651-804

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

Renesas Electronics Hong Kong Limited

Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd.

11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141