
RZ/T2H Group

Dual Encoder Sample Program

Summary

This application note explains a sample program that simultaneously connects two different encoders, one compliant with the A-format™ version 2.0 communication protocol specification (“A-format™ v2 Specification”) and the other with the EnDat 2.2 Specification. This sample program acquires and displays information for each by using the RZ/T2H Encoder interface.

The major features of the program are listed below.

- Simultaneous connection of encoders compliant with the A-format™ v2 specification and encoders compliant with the EnDat 2.2 specification.
- Supports A-format™ v2 command codes.
- Obtains angle information, etc. from an encoder conforming to the A-format™ v2 specification (MAR-M50A from Nikon).
- Supports the mode command and the MRS codes used in EnDat 2.2.
- Obtains angle information, etc. from an encoder (EQN1035 from HEIDENHAIN) compliant with EnDat 2.2 specifications.

Target Device

RZ/T2H

When applying the sample program covered in this application note to another microcomputer, modify the program according to the specifications for the target microcomputer and conduct an extensive evaluation of the modified program.

Table of Contents

| | |
|---|----|
| 1. Specifications | 5 |
| 2. Operating Environment..... | 6 |
| 3. Peripheral Modules..... | 7 |
| 3.1 Pins..... | 7 |
| 4. Software | 8 |
| 4.1 A-format Driver Function | 8 |
| 4.2 EnDat Driver Function | 8 |
| 4.3 File Structures | 8 |
| 4.4 Functions | 9 |
| 4.5 Specifications of A-format API Functions | 11 |
| 4.5.1 R_A_AS_Open | 11 |
| 4.5.2 R_A_AS_Close..... | 11 |
| 4.5.3 R_A_AS_GetVersion..... | 12 |
| 4.5.4 R_A_AS_Control | 12 |
| 4.5.5 A-format Control Commands..... | 13 |
| 4.6 Specification of A-format User-defined Functions..... | 16 |
| 4.6.1 a_as_txerr_callback | 16 |
| 4.6.2 a_as_rxset_callback..... | 17 |
| 4.6.3 a_as_rxend_callback..... | 18 |
| 4.6.4 a_as_elctimer_callback..... | 19 |
| 4.7 A-format Interrupt Handlers..... | 20 |
| 4.7.1 a_as0_int_isr | 20 |
| 4.7.2 a_as1_int_isr | 20 |
| 4.7.3 a_as2_int_isr | 20 |
| 4.7.4 a_as3_int_isr | 20 |
| 4.7.5 a_as4_int_isr | 21 |
| 4.7.6 a_as5_int_isr | 21 |
| 4.7.7 a_as6_int_isr | 21 |
| 4.7.8 a_as7_int_isr | 21 |
| 4.7.9 a_as8_int_isr | 21 |
| 4.7.10 a_as9_int_isr | 22 |
| 4.7.11 a_as10_int_isr | 22 |
| 4.7.12 a_as11_int_isr | 22 |
| 4.7.13 a_as12_int_isr | 22 |
| 4.7.14 a_as13_int_isr | 22 |
| 4.7.15 a_as14_int_isr | 23 |
| 4.7.16 a_as15_int_isr | 23 |
| 4.7.17 a_as_err_isr..... | 23 |

| | | |
|---------|---|----|
| 4.8 | Specifications of EnDat API Functions..... | 24 |
| 4.8.1 | R_ENDAT_Open..... | 24 |
| 4.8.2 | R_ENDAT_Close..... | 24 |
| 4.8.3 | R_ENDAT_GetVersion..... | 25 |
| 4.8.4 | R_ENDAT_Control..... | 25 |
| 4.8.5 | EnDat Control Commands..... | 26 |
| 4.9 | Specifications of EnDat User-defined Functions..... | 27 |
| 4.9.1 | enc_init_tclk_wait_callback..... | 27 |
| 4.9.2 | enc_init_reset_wait_callback..... | 27 |
| 4.9.3 | enc_init_mem_wait_callback..... | 28 |
| 4.9.4 | enc_init_pram_wait_callback..... | 28 |
| 4.9.5 | enc_init_cable_wait_callback..... | 29 |
| 4.9.6 | endat_callback..... | 29 |
| 4.9.7 | endat_poscon_callback..... | 30 |
| 4.9.8 | endat_rdst_callback..... | 30 |
| 4.10 | EnDat Interrupt Handlers..... | 30 |
| 4.10.1 | endat0_rx_int_isr..... | 30 |
| 4.10.2 | endat1_rx_int_isr..... | 31 |
| 4.10.3 | endat2_rx_int_isr..... | 31 |
| 4.10.4 | endat3_rx_int_isr..... | 31 |
| 4.10.5 | endat4_rx_int_isr..... | 31 |
| 4.10.6 | endat5_rx_int_isr..... | 32 |
| 4.10.7 | endat6_rx_int_isr..... | 32 |
| 4.10.8 | endat7_rx_int_isr..... | 32 |
| 4.10.9 | endat8_rx_int_isr..... | 32 |
| 4.10.10 | endat9_rx_int_isr..... | 33 |
| 4.10.11 | endat10_rx_int_isr..... | 33 |
| 4.10.12 | endat11_rx_int_isr..... | 33 |
| 4.10.13 | endat12_rx_int_isr..... | 33 |
| 4.10.14 | endat13_rx_int_isr..... | 34 |
| 4.10.15 | endat14_rx_int_isr..... | 34 |
| 4.10.16 | endat15_rx_int_isr..... | 34 |
| 4.11 | Interrupts..... | 35 |
| 4.12 | Constant and Error Code..... | 35 |
| 4.13 | Fixed-width Integer Types..... | 41 |
| 4.14 | Structures, Unions, and Enumerated Types..... | 42 |
| 4.14.1 | A-format Structures..... | 42 |
| 4.14.2 | A-format Unions..... | 45 |
| 4.14.3 | A-format Enumerated Types..... | 45 |
| 4.14.4 | EnDat Structures..... | 46 |
| 4.14.5 | EnDat Unions..... | 50 |

| | |
|--|----|
| 4.14.6 EnDat Enumerated Types | 51 |
| 4.15 Description of the Sample Program | 52 |
| 4.15.1 Operation Outline | 52 |
| 4.15.2 Sample Program Functions | 54 |
| 4.15.3 Specifications of Sample Program Functions | 55 |
| 4.15.4 Variables Used in the A-format Sample Program | 63 |
| 4.15.5 Constants Used in the A-format Sample Program | 63 |
| 4.15.6 Variables of EnDat Sample Program | 64 |
| 4.15.7 Constants of EnDat Sample Program | 65 |
| 4.15.8 Flowchart of Main Processing | 66 |
| 4.15.9 Dual Encoder Operation Sequence..... | 80 |
| 4.15.10 Console Commands | 88 |
| 4.15.11 Procedure of Channel Changing | 91 |
| 5. Sample Code..... | 95 |
| Revision History | 96 |

1. Specifications

Table 1.1 lists the peripheral modules to be used and their applications and Figure 1.1 shows the operating environment when the sample code is being executed.

Table 1.1 Peripheral Modules and Applications

| Peripheral Module | Application |
|---|---|
| Multi-Protocol Encoder I/F | RZ/T2H has 16 channels of encoder interface. The encoder interface communicates the respective encoder by selecting a module with A-format v2 specification and a module with EnDat 2.2 specification for each channel. |
| Interrupt controller (ICU) | Multi-Protocol Encoder I/F interrupt control |
| General PWM Timer (GPT) | Generation of event cycles to be input to ELC |
| Event Link Controller (ELC) | Link events output by GPT to Multi-Protocol Encoder I/F |
| Serial Communication Interface (SCI) UART | Asynchronous communications of the SCI are used for COM port communications by using USB interface. It is used for console interface of the sample program. |




Figure 1.1 Operating Environment

Note: Contact the encoder manufacturer for the cable length that can transmit and receive.

2. Operating Environment

The sample code covered in this application note is for the environment below.

Table 2.1 Operating Environment

| Item | Description | |
|--|---|---------------------------------------|
| MCU | RZ/T2H Group | |
| Operating frequency *1 | CR52 ver. | CPUCLK = 1000 MHz (Cortex®-R52 CPU0) |
| | CA55 ver. | CPUCLK = 1200 MHz (Cortex®-A55 Core0) |
| Operating voltage | 0.8 V (Core) / 1.1 V (DDR) / 1.8 V (PLL, etc.) / 3.3 V (I/O) | |
| Integrated development environment *2 | IAR Systems: IAR Embedded Workbench® for Arm® RENESAS: e² studio | |
| Board | RZ/T2H Evaluation Board (RTK9RZT2Hxxxxxxx) | |
| Devices (function to be used on the board) | None | |

Note 1. This sample program has a CR52 version that runs on the CPU core Cortex®-R52 and a CA55 version that runs on the CPU core Cortex®-A55. CR52 ver. and CA55 ver. are descriptions of the respective version.

Note 2. Refer to the RZ/T2H Group Encoder I/F Dual sample program Release Note to check the version number of the integrated development environment.

3. Peripheral Modules

The basics of the peripheral modules, operating modes, and registers are described in the “RZ/T2H Group User’s Manual: Hardware”.

3.1 Pins

Table 3.1 lists the pins used and their functions.

Table 3.1 Used Pins and Their Functions *

| Channel | Pin Name | I/O Port | Input/Output | Voltage Domain | Description |
|-----------|---------------------|----------|--------------|----------------|--------------------|
| AFMT0 | ENCIFOE00 (D/R) | P14_3 | Output | VDD3 | Data output enable |
| | ENCIFDO00 (REQ) | P14_4 | Output | VDD33 | Data output |
| | ENCIFDI00 (SDAT) | P14_5 | Input | VDD33 | Data input |
| ENDAT_CH1 | ENCIFCK1 (TCLK1) | P33_2 | Output | VDD1833_3 | Clock output |
| | ENCIFOE1 (DE1) | P33_3 | Output | VDD1833_3 | Data output enable |
| | ENCIFDO1 (DATA_DV1) | P33_4 | Output | VDD1833_3 | Data output |
| | ENCIFDI1 (DATA_RC1) | P33_5 | Input | VDD1833_3 | Data input |

Note: How to change A-format channel and EnDat 2.2 channel is written in “4.15.11 Procedure of Channel Changing”.

4. Software

4.1 A-format Driver Function

The functions of the A-format driver are listed below.

- 1 Initial settings
- 2 Transmission of command codes
- 3 Acquisition of reception data

4.2 EnDat Driver Function

The functions of the EnDat driver are listed below.

- 1) Initial settings
 - A) Initialization of the encoder (Encoder with battery unit is not supported)
 - B) Settings of propagation delay compensation
- 2) Transmission of the following request information
 - A) Mode command
 - B) MRS Code
 - C) Parameters
- 3) Reception of the encoder data
 - A) Positional value
 - B) Parameters
 - C) Additional information *

Note: In this document, "additional information" represents the additional data 1 and 2. For details, see the "EnDat Specification" which is available from HEIDENHAIN GmbH on request.

4.3 File Structures

For the file structure, refer to the release note for the RZ/T2H Group Encoder I/F Dual Encoder sample program.

4.4 Functions

Table 4.1 lists the functions for A-format. Table 4.2 lists the functions for EnDat.

Table 4.1 A-format Functions

| Category | Function Name | Page Number |
|------------------------------|------------------------|-------------|
| A-format driver API function | R_A_AS_Open | 11 |
| | R_A_AS_Close | 11 |
| | R_A_AS_GetVersion | 12 |
| | R_A_AS_Control | 12 |
| User-defined functions | a_as_txerr_callback | 16 |
| | a_as_rxset_callback | 17 |
| | a_as_rxend_callback | 18 |
| | a_as_elctimer_callback | 19 |
| Interrupt-handlers | a_as0_int_isr | 20 |
| | a_as1_int_isr | 20 |
| | a_as2_int_isr | 20 |
| | a_as3_int_isr | 20 |
| | a_as4_int_isr | 21 |
| | a_as5_int_isr | 21 |
| | a_as6_int_isr | 21 |
| | a_as7_int_isr | 21 |
| | a_as8_int_isr | 21 |
| | a_as9_int_isr | 22 |
| | a_as10_int_isr | 22 |
| | a_as11_int_isr | 22 |
| | a_as12_int_isr | 22 |
| | a_as13_int_isr | 22 |
| | a_as14_int_isr | 23 |
| | a_as15_int_isr | 23 |
| a_as_err_isr | 23 | |

Table 4.2 EnDat Functions

| Category | Function Name | Page Number |
|----------------------------|------------------------------|-------------|
| EnDat driver API functions | R_ENDAT_Open | 24 |
| | R_ENDAT_Close | 24 |
| | R_ENDAT_GetVersion | 25 |
| | R_ENDAT_Control | 25 |
| User-defined functions | enc_init_tclk_wait_callback | 27 |
| | enc_init_reset_wait_callback | 27 |
| | enc_init_mem_wait_callback | 28 |
| | enc_init_pram_wait_callback | 28 |
| | enc_init_cable_wait_callback | 29 |
| | endat_callback | 29 |
| | endat_poscon_callback | 30 |
| | endat_rdst_callback | 30 |
| Interrupt-handlers | endat0_rx_int_isr | 30 |
| | endat1_rx_int_isr | 31 |
| | endat2_rx_int_isr | 31 |
| | endat3_rx_int_isr | 31 |
| | endat4_rx_int_isr | 31 |
| | endat5_rx_int_isr | 32 |
| | endat6_rx_int_isr | 32 |
| | endat7_rx_int_isr | 32 |
| | endat8_rx_int_isr | 32 |
| | endat9_rx_int_isr | 33 |
| | endat10_rx_int_isr | 33 |
| | endat11_rx_int_isr | 33 |
| | endat12_rx_int_isr | 33 |
| | endat13_rx_int_isr | 34 |
| | endat14_rx_int_isr | 34 |
| | endat15_rx_int_isr | 34 |

4.5 Specifications of A-format API Functions

4.5.1 R_A_AS_Open

| R_A_AS_Open | |
|--------------------|--|
| Synopsis | Starts controlling operation of the encoder. |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Open(const int32_t id, r_a_as_info_t* p_info); |
| Description | This function is used for the following initial settings of the AFMT module. <ol style="list-style-type: none"> 1. Release A-format Interface from the module-stop state 2. Setting of the encoder interface 3. Setting of the communication parameters (for BRSEL register) 4. Setting for enabling interrupts. |
| Argument | id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.) R_A_AS0_ID : Specifies channel 0. R_A_AS1_ID : Specifies channel 1. : : R_A_AS15_ID : Specifies channel 15. Others : Setting is not allowed. p_info : Sets information about the encoder Designate the address of the structure r_a_as_info_t where encoder information is stored. |
| Return value | R_A_AS_SUCCESS: Normal termination R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id or p_info member variable of the structure r_a_as_info_t is not specified.) R_A_AS_ERR_ACCESS: Abnormal termination (The channel is already opened.) |
| Note | This function configures the encoder interface. If this function is executed after power for the encoder has been switched on, send CDF8 eight consecutive times to clear the status flag after executing this function. Calling this API function from within a callback function is not allowed. |

4.5.2 R_A_AS_Close

| R_A_AS_Close | |
|---------------------|---|
| Synopsis | Stops controlling operation of the encoder |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Close(const int32_t id); |
| Description | This function stops controlling operation of the encoder on the designated channel. |
| Argument | id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.) R_A_AS0_ID : Specifies channel 0 R_A_AS1_ID : Specifies channel 1 : : R_A_AS15_ID : Specifies channel 15. Others : Setting is not allowed. |
| Return Value | R_A_AS_SUCCESS: Normal termination R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id is not specified.) R_A_AS_ERR_ACCESS: Abnormal termination (A request is being transmitted.) |
| Note | Calling this API function from within a callback function is not allowed. |

4.5.3 R_A_AS_GetVersion

R_A_AS_GetVersion

| | |
|--------------|--|
| Synopsis | Acquire the version number of the encoder interface driver. |
| Header | r_a_as_rzt2_if.h |
| Declaration | uint32_t R_A_AS_GetVersion(const r_a_as_type_t type); |
| Description | This function acquires the version number of the A-format driver. |
| Argument | type : Designate R_A_AS_A_FORMAT. |
| Return value | A major part of the version number is stored in the sixteen MSBs and the minor part of the version number is stored in the sixteen LSBs. |
| Supplement | If the other type is designated, 0xFFFFFFFF will be returned. |
| Note | Calling this API function from within a callback function is not allowed. |

4.5.4 R_A_AS_Control

R_A_AS_Control

| | |
|--------------|---|
| Synopsis | Controlling operation of the encoder. |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Control(const int32_t id, const r_a_as_cmd_t cmd, void *const p_buf); |
| Description | This function controls operations of the encoder by using the cmd argument. See "4.5.5 A-format Control Commands" for the operation of the control commands. |
| Argument | id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.) R_A_AS0_ID : Specifies channel 0. R_A_AS1_ID : Specifies channel 1. : : R_A_AS15_ID : Specifies channel 15. Others : Setting is not allowed. cmd : Command For the list of the commands, see "Table 4.10 Control Commands of the R_A_AS_Control Function". p_buf : Arguments corresponding to each cmd. |
| Return value | R_A_AS_SUCCESS: Normal termination R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id or cmd is not specified.) See "4.5.5, A-format Control Commands" and "Table 4.10 Control Commands of the R_A_AS_Control Function" for other returned values. |
| Note | Be sure to call R_A_AS_Open before calling this function. Calling this API function from within a callback function is not allowed. |

4.5.5 A-format Control Commands

(1) R_A_AS_CMD_SET_PARAM

R_A_AS_CMD_SET_PARAM

| | |
|--------------|--|
| Synopsis | Sets request information |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Control(const int32_t id, const r_a_as_cmd_t cmd, void *const p_buf); |
| Description | This function sets request information. |
| Argument | <p>id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.)</p> <p>R_A_AS0_ID : Specifies channel 0.</p> <p>R_A_AS1_ID : Specifies channel 1.</p> <p>: :</p> <p>R_A_AS15_ID : Specifies channel 15.</p> <p>Others : Setting is not allowed.</p> <p>cmd : Designate R_A_AS_CMD_SET_PARAM.</p> <p>p_buf : Request information</p> <p>Designate the pointer to the structure r_a_as_req_t where the request information is stored. See section "4.14.1(2) r_a_as_req_t" for details.</p> |
| Return value | <p>R_A_AS_SUCCESS: Normal termination</p> <p>R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id is not specified, p_buf is null, or structure r_a_as_req_t member of the p_buf is not specified.)</p> <p>R_A_AS_ERR_ACCESS: Abnormal termination (The channel is not started.)</p> |
| Note | <p>This control command is utilized only for setting request information. Transmission of commands to the encoder proceeds by using the following control commands.</p> <ul style="list-style-type: none"> • R_A_AS_CMD_TX_TRG • R_A_AS_CMD_TX_ELC <p>Calling this control command from within a callback function is not allowed.</p> |

(2) R_A_AS_CMD_ELC_DISABLE

R_A_AS_CMD_ELC_DISABLE

| | |
|--------------|--|
| Synopsis | Disables input of the ELC event triggers |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Control(const int32_t id, const r_a_as_cmd_t cmd, void *const p_buf); |
| Description | This function disables event input triggers from the ELC. |
| Arguments | <p>id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.)</p> <p>R_A_AS0_ID : Specifies channel 0.</p> <p>R_A_AS1_ID : Specifies channel 1.</p> <p>: :</p> <p>R_A_AS15_ID : Specifies channel 15.</p> <p>Others : Setting is not allowed.</p> <p>cmd : Designate R_A_AS_CMD_ELC_DISABLE.</p> <p>p_buf : Not used. (Designate NULL.)</p> |
| Return value | <p>R_A_AS_SUCCESS: Input of the ELC event trigger is disabled.</p> <p>R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id is not specified.)</p> <p>R_A_AS_ERR_ACCESS: Abnormal termination (The ELC event trigger is not in progress or the channel is not started.)</p> |
| Note | Calling this control command from within a callback function is not allowed. |

(3) R_A_AS_CMD_TX_TRG**R_A_AS_CMD_TX_TRG**

| | |
|--------------|---|
| Synopsis | Starts transmission of requests to the encoder |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Control(const int32_t id, const r_a_as_cmd_t cmd, void *const p_buf); |
| Description | This function starts transmission of requests to the encoder. In normal reception, a callback function which corresponds to the interrupt source being enabled is called every time a transmission of request is made. See section “4.6.1 a_as_txerr_callback” to “4.6.3 a_as_rxend_callback”. |
| Arguments | <p>id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.)</p> <p>R_A_AS0_ID : Specifies channel 0.</p> <p>R_A_AS1_ID : Specifies channel 1.</p> <p>: :</p> <p>R_A_AS15_ID : Specifies channel 15.</p> <p>Others : Setting is not allowed.</p> <p>cmd : Designate R_A_AS_CMD_TX_TRG.</p> <p>p_buf : Not used. (Designate NULL.)</p> |
| Return value | <p>R_A_AS_SUCCESS: Normal termination.</p> <p>R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id is not specified.)</p> <p>R_A_AS_ERR_BUSY: Abnormal termination (Transfer is in progress.)</p> <p>R_A_AS_ERR_ACCESS: Abnormal termination (The channel is not started.)</p> |
| Note | <p>This control command is utilized only for starting transmission of requests to the encoder.</p> <p>Use this command after setting request information by using control command R_A_AS_CMD_SET_PARAM.</p> <p>Calling this control command from within a callback function is not allowed.</p> |

(4) R_A_AS_CMD_TX_ELC**R_A_AS_CMD_TX_ELC**

| | |
|--------------|--|
| Synopsis | Starts transmission of requests to the encoders in response to the input of an ELC event trigger. |
| Header | r_a_as_rzt2_if.h |
| Declaration | int32_t R_A_AS_Control(const int32_t id, const r_a_as_cmd_t cmd, void *const p_buf); |
| Description | <p>This function enables input of the ELC event trigger, and starts the transmission of requests to the encoder.</p> <p>In normal reception, a callback function which corresponds to the interrupt source being enabled is called every time a transmission of request is made. See section “4.6.1 a_as_txerr_callback” to “4.6.3 a_as_rxend_callback”</p> <p>An error code R_A_AS_ERR_BUSY is returned if this control command is executed while the ELC event trigger is in progress.</p> |
| Argument | <p>id : Designates the ID code to be used. (It is defined in r_a_as_rzt2_dat.h.)</p> <p style="margin-left: 2em;">R_A_AS0_ID : Specifies channel 0.</p> <p style="margin-left: 2em;">R_A_AS1_ID : Specifies channel 1.</p> <p style="margin-left: 2em;">: :</p> <p style="margin-left: 2em;">R_A_AS15_ID : Specifies channel 15.</p> <p style="margin-left: 2em;">Others : Setting is not allowed.</p> <p>cmd : Designate R_A_AS_CMD_TX_ELC.</p> <p>p_buf : Not used. (Designate NULL.)</p> |
| Return value | <p>R_A_AS_SUCCESS: Normal termination</p> <p>R_A_AS_ERR_INVALID_ARG: Abnormal termination (The id is not specified.)</p> <p>R_A_AS_ERR_BUSY: Abnormal termination (Transfer or the ELC event trigger is in progress.)</p> <p>R_A_AS_ERR_ACCESS: Abnormal termination (The channel is not started.)</p> |
| Note | <p>This control command is utilized only for starting transmission of requests to the encoder. Use this command after setting request information by using control command R_A_AS_CMD_SET_PARAM.</p> <p>Calling this control command from within a callback function is not allowed.</p> |

4.6 Specification of A-format User-defined Functions

4.6.1 a_as_txerr_callback

| a_as_txerr_callback | |
|----------------------------|--|
| Synopsis | Callback function that conveys the result of transmission and reception when a timeout error is generated in normal reception. |
| Header | - |
| Declaration | void a_as_txerr_callback (r_a_as_result_t * p_result); |
| Description | <p>This is a callback function to be registered by the function R_A_AS_Control (R_A_AS_CMD_SET_PARAM). This function conveys the result of transmission and reception in normal reception. This function is called when an interrupt request is generated in response to a timeout error (AFMTi_TMOU). After this function is processed, the function a_as_rxend_callback() is called, too.</p> <p>This function is the context of the interrupt handler. To ensure interrupt responsiveness, return quickly. The function name is an example and can be set freely.</p> |
| Argument | <p>p_result : Result of transmission and reception</p> <p>This is the pointer to the array where the result of transmission and reception declared by the structure r_a_as_result_t is stored.</p> <p>See "Table 4.3 Result of Transmission and Reception Stored in Each Array Element" for each element.</p> <p>The result of transmission and reception for the encoder address specified by the function R_A_AS_Control(R_A_AS_CMD_SET_PARAM) is updated.</p> <p>See "Table 4.4 Results of Transmission and Reception" for details.</p> |
| Return value | None |
| Note | <p>If the ELC event trigger is enabled, the result of transmission and reception should be acquired within the timer interval.</p> <p>Depending on the timing of response from the encoder, this callback function may be called even if the function R_A_AS_Close, or R_A_AS_Control (R_A_AS_CMD_ELC_DISABLE) have been executed.</p> |

4.6.2 a_as_rxset_callback

| a_as_rxset_callback | |
|---------------------|---|
| Synopsis | Callback function that conveys the result of transmission and reception when the setting of received data is complete in normal reception. |
| Header | - |
| Declaration | void a_as_rxset_callback(r_a_as_result_t * p_result); |
| Description | <p>This is a callback function to be registered by the function R_A_AS_Control(R_A_AS_CMD_SET_PARAM). This function conveys the result of transmission and reception in normal reception. This function is called when an interrupt request is generated in response to completion of the data reception (AFMTi_EOF). After this function is processed, the function a_as_rxend_callback() is called, too.</p> <p>This function is the context of the interrupt handler. To ensure interrupt responsiveness, return quickly. The function name is an example and can be set freely.</p> |
| Argument | <p>p_result : Result of transmission and reception</p> <p>This is the pointer to the array where the result of transmission and reception declared by the structure r_a_as_result_t is stored.</p> <p>See “Table 4.3 Result of Transmission and Reception Stored in Each Array Element” for the contents of each element. The result of transmission and reception for the encoder address specified by the function R_A_AS_Control(R_A_AS_CMD_SET_PARAM) is updated.</p> <p>See “Table 4.4 Results of Transmission and Reception” for details.</p> |
| Return value | None |
| Note | <p>If the ELC event trigger is enabled, the result of transmission and reception should be acquired within the timer interval.</p> <p>Depending on the timing of response from the encoder, this callback may be called even if the function R_A_AS_Close or R_A_AS_Control(R_A_AS_CMD_ELC_DISABLE) has been executed.</p> |

4.6.3 a_as_rxend_callback

a_as_rxend_callback

| | |
|--------------|--|
| Synopsis | Callback function that conveys the result of transmission and reception when the reception of data has been completed in normal reception. |
| Header | - |
| Declaration | <code>void a_as_rxend_callback (r_a_as_result_t * p_result);</code> |
| Description | This is a callback function to be registered by the function <code>R_A_AS_Control (R_A_AS_CMD_SET_PARAM)</code> . This function conveys the result of transmission and reception in normal reception. When a timeout error interrupt (<code>AFMTi_TMOUT</code>) or a completion of the data reception interrupt (<code>AFMTi_EOF</code>) is generated, it is called following the function <code>a_as_txerr_callback()</code> or the function <code>a_as_rxset_callback()</code> . This function is the context of the interrupt handler. To ensure interrupt responsiveness, return quickly. The function name is an example and can be set freely. |
| Argument | <code>p_result</code> : Result of transmission and reception This is the pointer to the array where the result of transmission and reception declared by the structure <code>r_a_as_result_t</code> is stored. See "Table 4.3 Result of Transmission and Reception Stored in Each Array Element" for the contents of each element. The result of transmission and reception for the encoder address specified by the function <code>R_A_AS_Control(R_A_AS_CMD_SET_PARAM)</code> is updated. See "Table 4.4 Results of Transmission and Reception". |
| Return value | None |
| Note | If the ELC event trigger is enabled, the result of transmission and reception should be acquired within the timer interval. Depending on the timing of response from the encoder, this callback may be called even if the function <code>R_A_AS_Close</code> or <code>R_A_AS_Control(R_A_AS_CMD_ELC_DISABLE)</code> has been executed. |

4.6.4 a_as_elctimer_callback

a_as_elctimer_callback

| | |
|--------------|--|
| Synopsis | Callback function that conveys the result of transmission and reception when the data reception is complete in continuous operation of the ELC event trigger. |
| Header | - |
| Declaration | void a_as_elctimer_callback(r_a_as_result_t * p_result); |
| Description | This is a callback function to be registered by the function R_A_AS_Control (R_A_AS_CMD_SET_PARAM). This function conveys the result of transmission and reception in normal reception. This function is called every time when an interrupt request is generated in response to completion of the data reception (AFMTi_EOF). This function is the context of the interrupt handler. To ensure interrupt responsiveness, return quickly. The function name is an example and can be set freely. |
| Argument | p_result : Result of transmission and reception This is the pointer to the array where the result of transmission and reception declared by the structure r_a_as_result_t is stored. See "Table 4.3 Result of Transmission and Reception Stored in Each Array Element" for the contents of each element. The result of transmission and reception for the encoder address specified by the function R_A_AS_Control(R_A_AS_CMD_SET_PARAM) is updated. See "Table 4.4 Results of Transmission and Reception" for details. |
| Return value | None |
| Note | If the ELC event trigger is enabled, the result of transmission and reception should be acquired within the timer interval. Depending on the timing of response from the encoder, this callback may be called even if the function R_A_AS_Close or R_A_AS_Control(R_A_AS_CMD_ELC_DISABLE) has been executed. |

Table 4.3 Result of Transmission and Reception Stored in Each Array Element

| Array Number | Content |
|--------------|--|
| p_result[0] | Result of transmission and reception for the encoder section ENC1. |
| p_result[1] | Result of transmission and reception for the encoder section ENC2. |
| p_result[2] | Result of transmission and reception for the encoder section ENC3. |
| p_result[3] | Result of transmission and reception for the encoder section ENC4. |
| p_result[4] | Result of transmission and reception for the encoder section ENC5. |
| p_result[5] | Result of transmission and reception for the encoder section ENC6. |
| p_result[6] | Result of transmission and reception for the encoder section ENC7. |
| p_result[7] | Result of transmission and reception for the encoder section ENC8. |

Table 4.4 Results of Transmission and Reception

| Interrupt Source | Results of Transmission and Reception (Member variables of p_result) | | |
|---|--|----------|---|
| | Result | Data | Status |
| Timeout error (AFMTi_TMOU) *1 | Only valid when used in the callback functions | Invalid | Only valid when used in the callback functions. |
| Completion of the data reception (AFMTi_EOF) *1 | Only valid when used in the callback functions. | Valid *2 | Only valid when used in the callback functions. |

Note: 1. i = 00 to 15

2. If the ELC event trigger is disabled, the data reception results are valid until next request.

If the ELC event trigger is enabled, the data reception results are valid until next AFMTi_EOF interrupt is generated.

4.7 A-format Interrupt Handlers

4.7.1 a_as0_int_isr

a_as0_int_isr

| | |
|--------------|--|
| Synopsis | Interrupt handler for AFMT0_EOF |
| Header | - |
| Declaration | void a_as0_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 0 data reception. |
| Argument | None |
| Return value | None |

4.7.2 a_as1_int_isr

a_as1_int_isr

| | |
|--------------|--|
| Synopsis | Interrupt handler for AFMT1_EOF |
| Header | - |
| Declaration | void a_as1_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 1 data reception. * |
| Argument | None |
| Return value | None |

4.7.3 a_as2_int_isr

a_as2_int_isr

| | |
|--------------|--|
| Synopsis | Interrupt handler for AFMT2_EOF |
| Header | - |
| Declaration | void a_as2_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 2 data reception. * |
| Argument | None |
| Return value | None |

4.7.4 a_as3_int_isr

a_as3_int_isr

| | |
|--------------|--|
| Synopsis | Interrupt handler for AFMT3_EOF |
| Header | - |
| Declaration | void a_as3_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 3 data reception. * |
| Argument | None |
| Return value | None |

4.7.5 a_as4_int_isr

| | |
|----------------------|--|
| a_as4_int_isr | |
| Synopsis | Interrupt handler for AFMT4_EOF |
| Header | - |
| Declaration | void a_as4_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 4 data reception. * |
| Argument | None |
| Return value | None |

4.7.6 a_as5_int_isr

| | |
|----------------------|--|
| a_as5_int_isr | |
| Synopsis | Interrupt handler for AFMT5_EOF |
| Header | - |
| Declaration | void a_as5_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 5 data reception. * |
| Argument | None |
| Return value | None |

4.7.7 a_as6_int_isr

| | |
|----------------------|--|
| a_as6_int_isr | |
| Synopsis | Interrupt handler for AFMT6_EOF |
| Header | - |
| Declaration | void a_as6_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 6 data reception. * |
| Argument | None |
| Return value | None |

4.7.8 a_as7_int_isr

| | |
|----------------------|--|
| a_as7_int_isr | |
| Synopsis | Interrupt handler for AFMT7_EOF |
| Header | - |
| Declaration | void a_as7_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 7 data reception. * |
| Argument | None |
| Return value | None |

4.7.9 a_as8_int_isr

| | |
|----------------------|--|
| a_as8_int_isr | |
| Synopsis | Interrupt handler for AFMT8_EOF |
| Header | - |
| Declaration | void a_as8_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 8 data reception. * |
| Argument | None |
| Return value | None |

4.7.10 a_as9_int_isr**a_as9_int_isr**

| | |
|--------------|--|
| Synopsis | Interrupt handler for AFMT9_EOF |
| Header | - |
| Declaration | void a_as9_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 9 data reception. * |
| Argument | None |
| Return value | None |

4.7.11 a_as10_int_isr**a_as10_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT10_EOF |
| Header | - |
| Declaration | void a_as10_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 10 data reception. * |
| Argument | None |
| Return value | None |

4.7.12 a_as11_int_isr**a_as11_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT11_EOF |
| Header | - |
| Declaration | void a_as11_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 11 data reception. * |
| Argument | None |
| Return value | None |

4.7.13 a_as12_int_isr**a_as12_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT12_EOF |
| Header | - |
| Declaration | void a_as12_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 12 data reception. * |
| Argument | None |
| Return value | None |

4.7.14 a_as13_int_isr**a_as13_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT13_EOF |
| Header | - |
| Declaration | void a_as13_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 13 data reception. * |
| Argument | None |
| Return value | None |

4.7.15 a_as14_int_isr**a_as14_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT14_EOF |
| Header | - |
| Declaration | void a_as14_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 14 data reception. * |
| Argument | None |
| Return value | None |

4.7.16 a_as15_int_isr**a_as15_int_isr**

| | |
|--------------|---|
| Synopsis | Interrupt handler for AFMT15_EOF |
| Header | - |
| Declaration | void a_as15_int_isr(void); |
| Description | This is the interrupt handler for the completion of A_AS channel 15 data reception. * |
| Argument | None |
| Return value | None |

Note: This interrupt handler is not used in the initial channel configuration. When the channel is changed, the interrupt handler corresponding channel is used.

4.7.17 a_as_err_isr**a_as_err_isr**

| | |
|--------------|--|
| Synopsis | Interrupt handler for PERI_ERR0 |
| Header | - |
| Declaration | void a_as_err_isr(void); |
| Description | This is the interrupt handler for the timeout of A_AS channel 0 to 15. |
| Argument | None |
| Return value | None |

4.8 Specifications of EnDat API Functions

4.8.1 R_ENDAT_Open

| R_ENDAT_Open | |
|---------------------|---|
| Synopsis | Starting control of the encoder |
| Header | r_endat_rzt2_if.h |
| Declaration | r_endat_err_t R_ENDAT_Open(const int32_t id, r_endat_info_t* p_info); |
| Description | <p>EnDat Driver initializes following initial settings.</p> <ol style="list-style-type: none"> 1. Initialization of the encoder (Encoder with a battery unit is not supported) 2. Settings of propagation delay compensation <p>Execute this function 1.3 seconds after the encoder is turned on. The propagation delay of the cable is automatically measured, but if any of the R_ENDAT_CABLE_DELAY measurements fail, the number of measurements is reduced by that amount. If all measurements fail, the value ENDAT_ERR_DRV is returned.</p> |
| Arguments | <p>id : Specifies the ID to be used. (It is defined in r_endat_rzt2_dat.h.)</p> <p>R_ENDAT0_ID : Specifies channel 0.</p> <p>R_ENDAT1_ID : Specifies channel 1.</p> <p>: :</p> <p>R_ENDAT15_ID : Specifies channel 15.</p> <p>Others : Setting is not allowed.</p> <p>p_info : Specifies encoder information. Specify the address of the structure r_endat_info_t that contains the encoder information.</p> |
| Return value | <p>ENDAT_SUCCESS : Normal termination</p> <p>ENDAT_ERR_INVALID_ARG : Abnormal termination (The id or r_endat_info_t structure member of the p_info is not specified.)</p> <p>ENDAT_ERR_ACCESS : Abnormal termination (The channel is already open.)</p> <p>ENDAT_ERR_DRV : Abnormal termination (The initialization failed.)</p> |
| Note | The encoder initialization process includes sending the mode command "Encoder receive reset", reading Word 13: "Number of clocks", clearing Word 0 "Error messages", and clearing Word 1: "Warning messages". When initializing the encoder with a battery unit, add the required procedures to the encoder after executing this function by referring to the "Power-on procedure" in the HEIDENHAIN application note (v03). |

4.8.2 R_ENDAT_Close

| R_ENDAT_Close | |
|----------------------|--|
| Synopsis | Ending control of the EnDat encoder |
| Header | r_endat_rzt2_if.h |
| Declaration | r_endat_err_t R_ENDAT_Close(const int32_t id); |
| Description | This function handles ending of the encoder interface driver. |
| Arguments | <p>id : Specifies the ID to be used. (It is defined in r_endat_rzt2_dat.h.)</p> <p>R_ENDAT0_ID : Specifies channel 0.</p> <p>R_ENDAT1_ID : Specifies channel 1.</p> <p>: :</p> <p>R_ENDAT15_ID : Specifies channel 15.</p> <p>Others : Setting is not allowed.</p> |
| Return value | <p>ENDAT_SUCCESS : Normal termination</p> <p>ENDAT_ERR_INVALID_ARG : Abnormal termination (The id is not specified.)</p> <p>ENDAT_ERR_ACCESS : Abnormal termination (Transfer is in progress.)</p> |

4.8.3 R_ENDAT_GetVersion

R_ENDAT_GetVersion

| | | |
|--------------|--|--|
| Synopsis | Acquiring the version number of the encoder interface driver | |
| Header | r_endat_rzt2_if.h | |
| Declaration | uint32_t R_ENDAT_GetVersion(void); | |
| Description | This function acquires the version number of the EnDat driver. | |
| Arguments | None | |
| Return value | Version information | : The major and minor parts of the version number are stored in the sixteen MSBs and sixteen LSBs, respectively. Ex.) For ver.1.2, the value returned is 0x00010002 |

4.8.4 R_ENDAT_Control

R_ENDAT_Control

| | | |
|--------------|--|--|
| Synopsis | Controlling the EnDat encoder | |
| Header | r_endat_rzt2_if.h | |
| Declaration | r_endat_err_t R_ENDAT_Control(const int32_t id, const r_endat_cmd_t cmd, void *const p_buf); | |
| Description | Use the argument cmd to control the EnDat encoder. See "4.8.5 EnDat Control Commands" for the operation of the control commands. | |
| Arguments | id | : Specifies the ID to be used. (It is defined in r_endat_rzt2_dat.h.) R_ENDAT0_ID : Specifies channel 0. R_ENDAT1_ID : Specifies channel 1. : R_ENDAT15_ID : Specifies channel 15. Others : Setting is not allowed. |
| | cmd | : Command For details, see section "4.14.6(2) r_endat_cmd_t". |
| | p_buf | : Arguments for each cmd |
| Return value | ENDAT_SUCCESS | : Normal termination |
| | ENDAT_ERR_INVALID_ARG | : Abnormal termination (The id or cmd is not specified.) For other return values, see "4.8.5 EnDat Control Commands". |
| Note | Be sure to execute R_ENDAT_Open before executing this function. | |

(2) ENDAT_CMD_POS_STOP**ENDAT_CMD_POS_STOP**

| | |
|--------------|--|
| Synopsis | Stop continuous acquisition of position values |
| Header | r_endat_rzt2_if.h |
| Declaration | r_endat_err_t R_ENDAT_Control(const int32_t id, const r_endat_cmd_t cmd, void *const p_buf); |
| Description | Disables the Continuous mode setting during reception processing in Continuous mode, and disables the ELC mode setting during event-synchronized send/receive processing in ELC mode, thus continuous reception of position values from the EnDat encoder is stopped. An error is returned if there is no continuous reception processing of position values. |
| Arguments | id : Specifies the ID to be used. (It is defined in r_endat_rzt2_dat.h.) R_ENDAT0_ID : Specifies channel 0. R_ENDAT1_ID : Specifies channel 1. : : R_ENDAT15_ID : Specifies channel 15. Others : Setting is not allowed. cmd : Designate ENDAT_CMD_POS_STOP. p_buf : Not used. (Designate NULL.) |
| Return value | R_ENDAT_SUCCESS : Normal termination R_ENDAT_ERR_INVALID_ARG : Abnormal termination (The id or cmd is not specified.) R_ENDAT_ERR_ACCESS : Abnormal termination (Continuous mode or ELC mode request is not sent.) |

4.9 Specifications of EnDat User-defined Functions**4.9.1 enc_init_tclk_wait_callback****enc_init_tclk_wait_callback**

| | |
|--------------|---|
| Synopsis | Function to generate wait time after activating TCLK pin output |
| Header | - |
| Declaration | void enc_init_reset_wait_callback(void); |
| Description | Callback function to be registered with the R_ENDAT_Open function. Initialization process of the connected encoder generates the time to wait after activating TCLK pin output. Set 100 us waiting time or longer. The function name is an example and can be freely set. |
| Arguments | None |
| Return value | None |

4.9.2 enc_init_reset_wait_callback**enc_init_reset_wait_callback**

| | |
|--------------|---|
| Synopsis | Function to generate wait time after encoder reset |
| Header | - |
| Declaration | void enc_init_reset_wait_callback(void); |
| Description | Callback function to be registered with the R_ENDAT_Open function. Initialization process of the connected encoder generates the time to wait after the encoder reset process. Set 60 ms waiting time or longer. The function name is an example and can be freely set. |
| Arguments | None |
| Return value | None |

4.9.3 enc_init_mem_wait_callback

enc_init_mem_wait_callback

| | |
|--------------|--|
| Synopsis | Function to generate wait time for detecting memory area selection timeout |
| Header | - |
| Declaration | void enc_init_mem_wait_callback(void); |
| Description | <p>Callback function to be registered with the R_ENDAT_Open function. Generates a wait time used for detecting a timeout error in the process of selecting a memory area in the initialization process of the connected encoder. Set 743 us* waiting time or longer. The function name is an example and can be freely set.</p> <p>Note: This value is based on the assumption of (2 clock cycles + mode command(6 clock cycles) + MRS code(8 clock cycles) + 16 clock cycles + 2T(2 clock cycles) + maximum 7 clock cycles + Start(1 clock cycle) + MRS code(8 clock cycles) + 16 clock cycles + CRC(5 clock cycles))\times(1/100 kHz) + t_m(30 us) + t_R(0.5 us) + t_D(1.7 us) = 742.2 us.</p> <p>The transmission clock frequency is set to 100kHz in the driver during the encoder initialization process. The delay time t_D assumes a cable length of 150 m. Users are required to adjust the waiting time according to the encoder and the cable length.</p> |
| Arguments | None |
| Return value | None |

4.9.4 enc_init_pram_wait_callback

enc_init_pram_wait_callback

| | |
|--------------|--|
| Synopsis | Function to generate wait time for detecting parameter transmission timeout |
| Header | - |
| Declaration | void enc_init_pram_wait_callback(void); |
| Description | <p>Callback function to be registered with the R_ENDAT_Open function. Generates a wait time for the initialization process of the connected encoder to detect timeout errors in the process of sending and receiving parameters by the encoder. Set 13 ms* waiting time or longer. The function name is an example and can be freely set.</p> <p>Note: Assumes memory access time (12 ms) + (Start(1 clock cycle) + Address(8 clock cycles) + Parameters(16 clock cycles) + CRC(5 clock cycles))\times(1/100 kHz) + t_m(30 us) + t_R(0.5 us) + t_D(1.7 us) = 12.33 ms.</p> <p>During the encoder initialization process, the transmission clock frequency is set to 100 kHz in the driver. The delay time t_D assumes a cable length of 150 m. Users are required to adjust the waiting time according to the encoder and the cable length.</p> |
| Arguments | None |
| Return value | None |

4.9.5 enc_init_cable_wait_callback

enc_init_cable_wait_callback

Synopsis Function to generate wait time for detecting propagation delay measurement timeout

Header -

Declaration void enc_init_cable_wait_callback(void);

Description Callback function to be registered with the R_ENDAT_Open function. Generates a wait time used for detecting a timeout error in the process of measuring cable propagation delay in the initialization process of the connected encoder. Set 588 us* waiting time or longer. The function name is an example and can be freely set.

Note: Assumes $t_{cal}(5 \text{ us}) + (\text{Start}(1 \text{ clock cycle}) + \text{Error}(1 \text{ clock cycle}) + \text{maximum number of bits of main received data (48 bits) + number of CRC bits (5 bits)}) \times (1/100 \text{ kHz}) + t_m(30 \text{ us}) + t_R(0.5 \text{ us}) + t_D(1.7 \text{ us}) = 587.2 \text{ us}$.

During the encoder initialization process, the transmission clock frequency is set to 100 kHz in the driver. The delay time t_D assumes a cable length of 150 m. Users are required to adjust the waiting time according to the encoder and the cable length.

Arguments None

Return value None

4.9.6 endat_callback

endat_callback

Synopsis Data reception result notification function for sending requests

Header -

Declaration void endat_callback(r_endat_result_t * p_result, r_endat_protocol_err_t *p_err);

Description This callback function is registered with the R_ENDAT_Control(ENDAT_CMD_REQ) function

This function is the context of the interrupt handler. To ensure interrupt responsiveness, return immediately. The function name is an example and can be freely set.

Argument p_result : Result of sending/receiving

Pointer to structure r_endat_result_t that stores the result of sending/receiving data. The data reception result is valid until the next request is sent.

p_err : Error information

Pointer to the structure r_endat_protocol_err_t that contains the results of sending and receiving. The data reception result is valid until the next request is sent.

Return value None

4.9.7 endat_poscon_callback

| | |
|------------------------------|--|
| endat_poscon_callback | |
| Synopsis | Data reception result notification function for sending requests (Continuous mode, ELC mode) |
| Header | - |
| Declaration | void endat_poscon_callback(r_endat_result_t * p_result, endat_protocol_err_t *p_err); |
| Description | This callback function is registered with the R_ENDAT_Control (ENDAT_CMD_REQ) function when data transmission is performed in Continuous mode or ELC mode. This function notifies the result of data reception in response to a request. This function is the context of the interrupt handler. To ensure interrupt responsiveness, return immediately. The function name is an example and can be freely set. |
| Arguments | <p>p_result : Result of sending/receiving Pointer to the structure r_endat_result_t that stores the result of sending/receiving data. The data reception result is valid until the next request is sent/received.</p> <p>p_err : Error information Pointer to the structure r_endat_protocol_err_t that stores the results of sending and receiving. The data reception result is valid until the next request is sent/received.</p> |
| Return value | None |

4.9.8 endat_rdst_callback

| | |
|----------------------------|---|
| endat_rdst_callback | |
| Synopsis | Callback function to notify that the next data communication is ready to start |
| Header | - |
| Declaration | void endat_rdst_callback(void); |
| Description | This callback function is registered with the R_ENDAT_Control(ENDAT_CMD_REQ) function. It is called after the endat_callback function when an interrupt occurs with setting RDY bit of STATR register. While operating in Continuous mode or ELC mode, this function is called after the endat_poscon_callback function each time data reception is completed. This function is the context for the interrupt handler. To ensure interrupt responsiveness, return immediately. The function name is an example and can be freely set. |
| Arguments | None |
| Return value | None |

4.10 EnDat Interrupt Handlers

4.10.1 endat0_rx_int_isr

| | |
|--------------------------|---|
| endat0_rx_int_isr | |
| Synopsis | Channel 0 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat0_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 0. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.2 endat1_rx_int_isr**endat1_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 1 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat1_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 1. 1. ERR1, IERR2 interrupts 2. WTDG interrupts 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.3 endat2_rx_int_isr**endat2_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 2 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat2_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 2. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.4 endat3_rx_int_isr**endat3_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 3 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat3_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 3. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.5 endat4_rx_int_isr**endat4_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 4 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat4_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 4. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.6 endat5_rx_int_isr**endat5_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 5 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat5_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 5. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.7 endat6_rx_int_isr**endat6_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 6 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat6_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 6. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.8 endat7_rx_int_isr**endat7_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 7 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat7_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 7. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.9 endat8_rx_int_isr**endat8_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 8 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat8_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 8. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.10 endat9_rx_int_isr**endat9_rx_int_isr**

| | |
|--------------|---|
| Synopsis | Channel 9 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat9_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 9. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.11 endat10_rx_int_isr**endat10_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel e0 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat10_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 10. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.12 endat11_rx_int_isr**endat11_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 11 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat11_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 11. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.13 endat12_rx_int_isr**endat12_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 12 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat12_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 12. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.14 endat13_rx_int_isr**endat13_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 13 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat13_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 13. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.15 endat14_rx_int_isr**endat14_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 14 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat14_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 14. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

4.10.16 endat15_rx_int_isr**endat15_rx_int_isr**

| | |
|--------------|--|
| Synopsis | Channel 15 Data reception completion interrupt handler |
| Header | - |
| Declaration | void endat15_rx_int_isr(void); |
| Description | Interrupt handler for the following interrupt factors on EnDat channel 15. * 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |
| Arguments | None |
| Return value | None |

Note: This interrupt handler is not used in the initial channel configuration. When the channel is changed, the interrupt handler corresponding channel is used.

4.11 Interrupts

Table 4.5 lists the interrupt for the Dual Encoder driver. If the channels are changed, the ID will also change along with the interrupt channel change for the A-format and EnDat encoders.

Table 4.5 Interrupt for the Dual Encoder Driver

| Interrupt | ID * | | Outline |
|--------------|-----------|-----------|--|
| | CR52 ver. | CA55 ver. | |
| ENCIF_ERR0 | 388 | 417 | This is generated in response to the timeout of channel 0 to 15. |
| ENCIF00_INT0 | 389 | 716 | This is generated in response to the completion of channel 0 reception of the A-format encoder. |
| ENCIF01_INT0 | 390 | 720 | This is generated by the following interrupt factors of the Ch1 EnDat encoder. 1. ERR1, IERR2 interrupts 2. WTDG interrupt 3. EMPFR1-3 interrupts |

Note: This sample program has a CR52 version that runs on the CPU core Cortex-R52 and a CA55 version that runs on the CPU core Cortex-A55. CR52 ver. and CA55 ver. are descriptions of the respective version.

4.12 Constant and Error Code

Table 4.6 lists the constant/error code definition tables. For each definition, refer to the respective table. For EnDat error codes, see "4.14.6(1) r_endat_err_t".

Table 4.6 Constant/error code definition tables

| Table number | Contents |
|--------------|---|
| Table 4.7 | User-defined constants used by the A-format driver (r_a_as_rzt2_config.h) |
| Table 4.8 | A-format Driver Type |
| Table 4.9 | Methods of Connection between A_AS and Encoders |
| Table 4.10 | Control Commands of the R_A_AS_Control Function |
| Table 4.11 | A-format Bitrate |
| Table 4.12 | A-format Encoder Addresses |
| Table 4.13 | A-format Commands |
| Table 4.14 | A-format Error Codes |
| Table 4.15 | User-defined Constants to be Used in the EnDat Driver (r_endat_rzt2_config.h) |
| Table 4.16 | EnDat 2.2 Mode Commands |
| Table 4.17 | EnDat Transmission Clock Frequencies |
| Table 4.18 | EnDat Watchdog Timer Time Units |
| Table 4.19 | EnDat Low-level Period at the Start of Data Transmission |
| Table 4.20 | EnDat MRS Codes |

Table 4.7 User-defined constants used by the A-format driver (r_a_as_rzt2_config.h)

| Constant Name | Setting | Description |
|------------------------|---------|--|
| R_A_AS_T2_ONE_250KBPS | 0x0000 | The value set in the BRSEL register TM bit when the connection is one-to-one, and the bit rate is 2.5 Mbps. * |
| R_A_AS_T2_ONE_4MBPS | 0x0000 | The value set in the BRSEL register TM bit when the connection is one-to-one, and the bit rate is 4 Mbps. * |
| R_A_AS_T2_ONE_6670KBPS | 0x0000 | The value set in the BRSEL register TM bit when the connection is one-to-one, and the bit rate is 6.67 Mbps. * |
| R_A_AS_T2_ONE_8MBPS | 0x0000 | The value set in the BRSEL register TM bit when the connection is one-to-one, and the bit rate is 8 Mbps. * |
| R_A_AS_T2_BUS_250KBPS | 0x001A | The value set in the BRSEL register TM bit when the connection is a bus connection, and the bit rate is 2.5 Mbps. * |
| R_A_AS_T2_BUS_4MBPS | 0x0010 | The value set in the BRSEL register TM bit when the connection is a bus connection, and the bit rate is 4 Mbps. * |
| R_A_AS_T2_BUS_6670KBPS | 0x0009 | The value set in the BRSEL register TM bit when the connection is a bus connection, and the bit rate is 6.67 Mbps. * |
| R_A_AS_T2_BUS_8MBPS | 0x0008 | The value set in the BRSEL register TM bit when the connection is a bus connection, and the bit rate is 8 Mbps. * |

Note: In this sample program, the values set in each register are the recommended values.

Table 4.8 A-format Driver Type

| Constant Name | Setting | Description |
|-----------------|---------|---------------------------------|
| R_A_AS_A_FORMAT | 0 | Designates the A-format driver. |

Table 4.9 Methods of Connection between A_AS and Encoders

| Constant Name | Setting | Description |
|--------------------|---------|-----------------------|
| R_A_AS_ONE_FOR_ONE | 0 | One-to-one connection |
| R_A_AS_BUS | 1 | Bus connection |

Table 4.10 Control Commands of the R_A_AS_Control Function

| Constant Name | Setting | Description |
|------------------------|------------|--|
| R_A_AS_CMD_SET_PARAM | 0xAF000000 | Sets requests information |
| R_A_AS_CMD_ELC_DISABLE | 0xAF000002 | Disable input of the ELC event trigger |
| R_A_AS_CMD_TX_TRG | 0xAF000003 | Starts transmission of a command by timer operation. |
| R_A_AS_CMD_TX_ELC | 0xAF000005 | Starts transmission of a command by input of the ELC event trigger |

Table 4.11 A-format Bitrate

| Constant Name | Setting | Description |
|-----------------|---------|-------------|
| R_A_AS_250KBPS | 0 | 2.5 Mbps |
| R_A_AS_4MBPS | 1 | 4 Mbps |
| R_A_AS_6670KBPS | 2 | 6.67 Mbps |
| R_A_AS_8MBPS | 3 | 8 Mbps |

Table 4.12 A-format Encoder Addresses

| Constant Name | Setting | Description |
|---------------|---------|--|
| R_A_AS_EC�1 | 0 | The address of the encoder section ENC1. |
| R_A_AS_EC�2 | 1 | The address of the encoder section ENC2. |
| R_A_AS_EC�3 | 2 | The address of the encoder section ENC3. |
| R_A_AS_EC�4 | 3 | The address of the encoder section ENC4. |
| R_A_AS_EC�5 | 4 | The address of the encoder section ENC5. |
| R_A_AS_EC�6 | 5 | The address of the encoder section ENC6. |
| R_A_AS_EC�7 | 6 | The address of the encoder section ENC7. |
| R_A_AS_EC�8 | 7 | The address of the encoder section ENC8. |

Table 4.13 A-format Commands

| Constant Name | Setting | Description |
|---------------|---------|---|
| R_A_AS_CDF0 | 0 | The value defined for the command data frame CDF0. |
| R_A_AS_CDF1 | 1 | The value defined for the command data frame CDF1. |
| R_A_AS_CDF2 | 2 | The value defined for the command data frame CDF2. |
| R_A_AS_CDF3 | 3 | The value defined for the command data frame CDF3. |
| R_A_AS_CDF4 | 4 | The value defined for the command data frame CDF4. |
| R_A_AS_CDF5 | 5 | The value defined for the command data frame CDF5. |
| R_A_AS_CDF6 | 6 | The value defined for the command data frame CDF6. |
| R_A_AS_CDF7 | 7 | The value defined for the command data frame CDF7. |
| R_A_AS_CDF8 | 8 | The value defined for the command data frame CDF8. |
| R_A_AS_CDF9 | 9 | The value defined for the command data frame CDF9. |
| R_A_AS_CDF10 | 10 | The value defined for the command data frame CDF10. |
| R_A_AS_CDF11 | 11 | The value defined for the command data frame CDF11. |
| R_A_AS_CDF12 | 12 | The value defined for the command data frame CDF12. |
| R_A_AS_CDF13 | 13 | The value defined for the command data frame CDF13. |
| R_A_AS_CDF14 | 14 | The value defined for the command data frame CDF14. |
| R_A_AS_CDF15 | 15 | The value defined for the command data frame CDF15. |
| R_A_AS_CDF16 | 16 | The value defined for the command data frame CDF16. |
| R_A_AS_CDF17 | 17 | The value defined for the command data frame CDF17. |
| R_A_AS_CDF18 | 18 | The value defined for the command data frame CDF18. |
| R_A_AS_CDF19 | 19 | The value defined for the command data frame CDF19. |
| R_A_AS_CDF21 | 21 | The value defined for the command data frame CDF21. |
| R_A_AS_CDF22 | 22 | The value defined for the command data frame CDF22. |
| R_A_AS_CDF27 | 27 | The value defined for the command data frame CDF27. |
| R_A_AS_CDF28 | 28 | The value defined for the command data frame CDF28. |
| R_A_AS_CDF29 | 29 | The value defined for the command data frame CDF29. |
| R_A_AS_CDF30 | 30 | The value defined for the command data frame CDF30. |

Table 4.14 A-format Error Codes

| Constant Name | Setting | Description |
|------------------------|---------|-----------------------------|
| R_A_AS_SUCCESS | 0 | Normal termination |
| R_A_AS_ERR_INVALID_ARG | -1 | Argument error |
| R_A_AS_ERR_BUSY | -2 | The API cannot be executed. |
| R_A_AS_ERR_ACCESS | -3 | API execution order error. |

Table 4.15 User-defined Constants to be Used in the EnDat Driver (r_endat_rzt2_config.h)

| Constant | Set value | Content |
|---------------------|-----------|--|
| R_ENDAT_CABLE_DELAY | 5 | The number of times the propagation delay is automatically measured. Set it to 5 to 255 times. |
| R_ENDAT_ADD_NUM | 0u | Number of additional information to receive |

Table 4.16 EnDat 2.2 Mode Commands

| Constant | Value | Content |
|--------------------------|-------|---|
| R_ENDAT_POS | 0x07u | “Encoder send position values” command |
| R_ENDAT_MEM | 0x0Eu | “Selection of memory area” command |
| R_ENDAT_RX_PARAM | 0x1Cu | “Encoder receive parameter” command |
| R_ENDAT_PARAM | 0x23u | “Encoder send parameter” command |
| R_ENDAT_RESET | 0x2Au | “Encoder receive reset” command |
| R_ENDAT_POS_ADD_DATA | 0x38u | “Encoder send position values with additional data” command |
| R_ENDAT_POS_MEM | 0x09u | “Encoder send position values and selection of the memory area” command |
| R_ENDAT_POS_RX_PARAM | 0x1Bu | “Encoder send position values and receive parameter” command |
| R_ENDAT_POS_PARAM | 0x24u | “Encoder send position values and send parameter” command |
| R_ENDAT_POS_RX_ERR RESET | 0x2Du | “Encoder send position values and receiver error reset” command |

Note: For details, refer to the "EnDat Specification" which is available from HEIDENHAIN on request.

Table 4.17 EnDat Transmission Clock Frequencies

| Constant | value | content |
|---------------------|-------|-------------|
| R_ENDAT_FTCLK_16670 | 0x3u | 16.67 MHz * |
| R_ENDAT_FTCLK_8330 | 0x6u | 8.33 MHz * |
| R_ENDAT_FTCLK_4160 | 0xBu | 4.16 MHz * |
| R_ENDAT_FTCLK_4000 | 0x8u | 4 MHz * |
| R_ENDAT_FTCLK_2000 | 0xCu | 2 MHz |
| R_ENDAT_FTCLK_1000 | 0xDu | 1 MHz |
| R_ENDAT_FTCLK_200 | 0xEu | 0.2 MHz |
| R_ENDAT_FTCLK_100 | 0xFu | 0.1 MHz |

Note: Propagation delay compensation should be enabled (delay_comp=true).

Table 4.18 EnDat Watchdog Timer Time Units

| Constant | value | content |
|---------------------|-------|--|
| R_ENDAT_WD_RANGE_US | 0x00u | Watchdog Timer time unit is microseconds |
| R_ENDAT_WD_RANGE_MS | 0x80u | Watchdog Timer time unit is milliseconds |

Table 4.19 EnDat Low-level Period at the Start of Data Transmission

| Constant | value | content |
|-----------------------|-------|----------|
| R_ENDAT_TST_HALF_TCLK | 0x00u | 1/2 TCLK |
| R_ENDAT_TST_500NS | 0x01u | 0.5 us * |
| R_ENDAT_TST_1US | 0x02u | 1 us * |
| R_ENDAT_TST_1500NS | 0x03u | 1.5 us * |
| R_ENDAT_TST_2US | 0x04u | 2 us * |
| R_ENDAT_TST_4US | 0x05u | 4 us * |
| R_ENDAT_TST_8US | 0x06u | 8 us * |
| R_ENDAT_TST_10US | 0x07u | 10 us * |

Note The low-level period has a margin of error. See the hardware manual for details.

Table 4.20 EnDat MRS Codes

| Constant | value | content |
|----------------------------|-------|--|
| R_ENDAT_MRS_INFO1_NOP | 0x40u | Send additional info 1 without data contents (NOP) |
| R_ENDAT_MRS_DIA | 0x41u | Send diagnostic values |
| R_ENDAT_MRS_POS2_LSB | 0x42u | Send position value 2, word 1 LSB |
| R_ENDAT_MRS_POS2_CENTER | 0x43u | Send position value 2, word 2 |
| R_ENDAT_MRS_POS2_MSB | 0x44u | Send position value 2, word 3 MSB |
| R_ENDAT_MRS_MEM_LSB | 0x45u | Acknowledge memory content LSB |
| R_ENDAT_MRS_MEM_MSB | 0x46u | Acknowledge memory content MSB |
| R_ENDAT_MRS_MRS_CODE | 0x47u | Acknowledge MRS code |
| R_ENDAT_MRS_TEST_SMD | 0x48u | Acknowledge test command |
| R_ENDAT_MRS_TEST_LSB | 0x49u | Send test values, word 1 LSB |
| R_ENDAT_MRS_TEST_CENTER | 0x4Au | Send test values, word 2 |
| R_ENDAT_MRS_TEST_MSB | 0x4Bu | Send test values, word 3 MSB |
| R_ENDAT_MRS_TEMP1 | 0x4Cu | Send temperature 1 |
| R_ENDAT_MRS_TEMP2 | 0x4Du | Send temperature 2 |
| R_ENDAT_MRS_ADD_SEN | 0x4Eu | Additional sensors |
| R_ENDAT_MRS_NOT_INFO1 | 0x4Fu | Stop sending additional datum 1 |
| R_ENDAT_MRS_INFO2_NOP | 0x50u | Send additional datum 2 without data contents |
| R_ENDAT_MRS_COM | 0x51u | Send commutation |
| R_ENDAT_MRS_ACC | 0x52u | Send acceleration |
| R_ENDAT_MRS_COM_ACC | 0x53u | Send commutation & acceleration |
| R_ENDAT_MRS_LIM_POS | 0x54u | Send limit position signals |
| R_ENDAT_MRS_LIM_POS_ACC | 0x55u | Send limit position signals & acceleration |
| R_ENDAT_MRS_ASY_POS_LSB | 0x56u | Asynchronous position value, word 1 LSB |
| R_ENDAT_MRS_ASY_POS_CENTER | 0x57u | Asynchronous position value, word 2 |
| R_ENDAT_MRS_ASY_POS_MSB | 0x58u | Asynchronous position value, word 3 MSB |
| R_ENDAT_MRS_OPE_STA_ERR | 0x59u | Operating status error sources |
| R_ENDAT_MRS_TIM_STA | 0x5Bu | Timestamp |
| R_ENDAT_MRS_NOT_INFO2 | 0x5Fu | Stop sending additional datum 2 |
| R_ENDAT_MRS_OPE_STAT | 0xB9u | Operating status |
| R_ENDAT_MRS_ENC_MANU1 | 0xA1u | Parameters of the encoder manufacturer 1 |
| R_ENDAT_MRS_ENC_MANU2 | 0xA3u | Parameters of the encoder manufacturer 2 |
| R_ENDAT_MRS_ENC_MANU3 | 0xA5u | Parameters of the encoder manufacturer 3 |
| R_ENDAT_MRS_OPE_PARAM | 0xA7u | Operating parameters |
| R_ENDAT_MRS_OEM1 | 0xA9u | Parameters of the OEM 1 |
| R_ENDAT_MRS_OEM2 | 0xABu | Parameters of the OEM 2 |
| R_ENDAT_MRS_OEM3 | 0xADu | Parameters of the OEM 3 |
| R_ENDAT_MRS_OEM4 | 0xAFu | Parameters of the OEM 4 |
| R_ENDAT_MRS_COMP_VAL1 | 0xB1u | Compensation Values of the encoder manufacturer 1 |
| R_ENDAT_MRS_COMP_VAL2 | 0xB3u | Compensation Values of the encoder manufacturer 2 |
| R_ENDAT_MRS_COMP_VAL3 | 0xB5u | Compensation Values of the encoder manufacturer 3 |
| R_ENDAT_MRS_COMP_VAL4 | 0xB7u | Compensation Values of the encoder manufacturer 4 |
| R_ENDAT_MRS_PARAM_ENDAT22 | 0xBDu | Parameters of the encoder manufacturer for EnDat 2.2 |
| R_ENDAT_MRS_PARAM_SEC2 | 0xBFu | Parameters of the section 2 memory area |
| R_ENDAT_MRS_OPE_PARAM2 | 0xBBu | Operating parameters 2 |

Note: For details, refer to the "EnDat Specification" which is available from HEIDENHAIN on request.

4.13 Fixed-width Integer Types

Table 4.21 lists the fixed-width integers for the sample code. These fixed-width integers are defined in the standard libraries.

Table 4.21 Fixed-width Integers for the Sample Program

| Symbol | Description |
|----------|---|
| int8_t | 8-bit signed integer (defined in the standard libraries) |
| int16_t | 16-bit signed integer (defined in the standard libraries) |
| int32_t | 32-bit signed integer (defined in the standard libraries) |
| int64_t | 64-bit signed integer (defined in the standard libraries) |
| uint8_t | 8-bit unsigned integer (defined in the standard libraries) |
| uint16_t | 16-bit unsigned integer (defined in the standard libraries) |
| uint32_t | 32-bit unsigned integer (defined in the standard libraries) |
| uint64_t | 64-bit unsigned integer (defined in the standard libraries) |

4.14 Structures, Unions, and Enumerated Types

4.14.1 A-format Structures

(1) r_a_as_info_t

Initialization information of the A_AS control unit,

```
typedef struct
{
    uint8_t    connect;    Connection method
                    Designate the method of connection between A_AS and the
                    encoders. See "Table 4.9 Methods of Connection between A_AS
                    and Encoders" for the values to be designated.
                    Note: This setting is reflected in the BRSEL registers.

    uint8_t    bitrate;    Bit rate
                    Designate the bit rate for communications with the encoder. See
                    "Table 4.11 A-format Bitrate" for the values to be designated.
                    Note: This setting is reflected in the BRSEL registers.

    uint16_t   ifmg;       Margin value
                    Note: This is reserved for driver interface compatibility with RZ/T2M
                    group A-format driver. This setting value is not used for RZ/T2H.
} r_a_as_info_t
```

(2) r_a_as_req_t

Information of requests to be sent to the encoders.

```

typedef struct
{
    uint8_t      encadr;      Encoder address
                        Designate the encoder address. See "Table 4.12 A-format
                        Encoder Addresses" for the value to be designated.
                        This setting is reflected in the XEA bit of the COMMAND
                        register.
    uint8_t      cmd;        Command
                        Designate the command code to be sent to the encoder. See
                        "Table 4.13 A-format Commands" for the value to be
                        designated.
                        If the value is not listed in the said table and exceeds 0x20, an
                        error with the error code
                        R_A_AS_ERR_INVALID_ARG is generated.
                        Some commands are not available depending on the
                        connection method.
    uint8_t      memadr;     Memory address
                        Designate the address of the memory in the encoder. Set this
                        value only in the following cases:
                        cmd = R_A_AS_CDF13
                        cmd = R_A_AS_CDF14
                        Note: For the command R_A_AS_CDF13, the accessible
                        address range is between 0x00 and 0xFF.
                        For the command R_A_AS_CDF14, the accessible
                        address range is between 0x00 and 0xEF.
    uint16_t     memdat;     Data to be written to the memory
                        Designate the data to be written to the memory. Set this value
                        only in the following case:
                        cmd = R_A_AS_CDF14
    uint32_t     encid;      Recognition code
                        Designate the 24-bit recognition code. Set this value only in the
                        following cases:
                        cmd = R_A_AS_CDF18
                        cmd = R_A_AS_CDF19
    r_a_as_result_cb_t cbadr_txerr The pointer to the callback function *1 to be called in response
                        to PERI_ERR0 interrupt request. See "4.6.1
                        a_as_txerr_callback" for details.
    r_a_as_result_cb_t cbadr_rxset; The pointer to the callback function *1 to be called in response
                        to an AFMTi_EOF (i = 0 to 15) interrupt request. See "4.6.2
                        a_as_rxset_callback" for details.
    r_a_as_result_cb_t cbadr_rxend; The pointer to the callback function *1 to be called following the
                        cbadr_txerr() function or cbadr_rxset() function in response to
                        PERI_ERR0 interrupt or AFMTi_EOF (i = 0 to 15) interrupt
                        request. See "4.6.3 a_as_rxend_callback" for details.
    bool         pre;        Set true in this variable to set request information while
                        transmission and reception of data by the ELC event trigger is
                        in progress. Set false to set request information in other cases.
                        (true: Set request information while transmission and reception
                        of data by the ELC event trigger is in progress)
} r_a_as_req_t

```

Note 1. Callback function will not be run if the pointer is NULL.

(3) r_a_as_result_t

Result of transmission and reception in normal reception

```
typedef struct
{
    r_a_as_req_err_t  result;    Result of transmission and reception
                                See the enumerated type "4.14.3(1) r_a_as_req_err_t" for
                                details.
    r_a_as_data_t    data;      Reception data
                                See the structure "4.14.1(4) r_a_as_data_t" for details.
    r_a_as_status_t  status;    State of the A_AS
                                See the structure "4.14.1(5) r_a_as_status_t" for details.
} r_a_as_result_t
```

(4) r_a_as_data_t

Data received in normal reception

```
typedef struct
{
    uint32_t         rxi;        ENCnRXDATA0 register value
                                The value of the ENCnRXDATA0 register is stored here.
    uint32_t         rxd0;      ENCnRXDATA1 register value
                                The value of the ENCnRXDATA1 register is stored here.
    uint32_t         rxd1;      ENCnRXDATA2 register value
                                The value of the ENCnRXDATA2 register is stored here.
} r_a_as_data_t
```

(5) r_a_as_status_t

State of the A_AS on transmission or reception

```
typedef struct
{
    bool    iwdgerr;    Indicates IF watchdog error. Corresponds to timeout error.
    bool    dwdgerr;    Indicates DF watchdog error. Corresponds to timeout error.
    bool    starterr;   Indicates start bit errors. Corresponds to CA[1] FORM status flag.
    bool    stoperr;   Indicates stop bit errors. Corresponds to CA[1] FORM status flag.
    bool    syncerr;   Indicates sync code errors. Corresponds to CA[2] SYNC status flag.
    bool    rxeaerr;   Indicates received encoder address error. Corresponds to CA[0] CMD status
                    flag.
    bool    crcerr;    Indicates CRC error. Corresponds to CA[3] CRC status flag.
    bool    rxccerr;   Indicates received command code error. Corresponds to CA[0] CMD status
                    flag.

    bool    mdaterr;   Indicates EEPROM data error. *1
    bool    madrerr;   Indicates EEPROM address error. *1
    bool    rxdzerr;   Indicates ID code error. *1
    bool    fd1err;    Indicates fixed-data (1) error. *1
    bool    fd2err;    Indicates fixed-data (2) error. *1
    bool    fd3err;    Indicates fixed-data (3) error. *1
    bool    fd5err;    Indicates fixed-data (5) error. *1
    bool    elcin;     Information in response to ELCIN input is being stored. *1
    uint8_t txcc;     Transmission command code is stored.
                    (0: CDF0 to 19 and 23 to 30, 1: CDF21, 2: CDF22)
    bool    rxset;     This value indicates whether the setting of received data is complete.
                    (true: Ready to read; false: Not ready to read)
    bool    timer;     Indicates whether the timer is operating or not. *1
    bool    txerr;     Indicates transmission error. *1
    bool    rxend;     Indicates completion of reception. (true: Received; false: Not received)
} r_a_as_status_t
```

Note: 1. This is reserved for driver interface compatibility with RZ/T2M group A-format encoder driver. This is not used in the driver for RZ/T2H.

4.14.2 A-format Unions

Unions are not used in this sample program.

4.14.3 A-format Enumerated Types**(1) r_a_as_req_err_t**

Result of reception from the encoder

```
typedef enum
{
    R_A_AS_REQ_SUCCESS = 0,    Normal termination of data transmission and reception
    R_A_AS_REQ_ERR            An error occurred in data transmission or reception.
                            This error code is generated even if one of the error indicators
                            (excluding timer, rxend, rxset, elcin, and txcc) of the structure
                            "4.14.1(5) r_a_as_status_t" is "true".

    R_A_AS_REQ_BP_ERR        The reception FIFO buffer is full.
                            This error code is generated only in bypass reception.
} r_a_as_req_err_t
```

4.14.4 EnDat Structures

(1) r_endat_info_t

Initialization information of the EnDat control unit

```
typedef struct
{
    uint8_t      ftclk;          Transmission clock frequency setting
                                See "Table 4.17 EnDat Transmission Clock
                                Frequencies". This setting is reflected in the FTCLK bit of
                                the KONFR1 register.

    bool         filter;        Noise filter settings (true: enabled, false: disabled)
                                Note: This is reserved for driver interface compatibility
                                with RZ/T2M group EnDat driver. This setting value is not
                                used for RZ/T2H.

    bool         delay_comp;    Propagation delay correction (true: valid, false: invalid)
                                This setting is reflected in the DELAYCMP bit of the
                                KONFR1 register.

    uint8_t      tst;          Set the Low period at the start of data transmission
                                See "Table 4.19 EnDat Low-level Period at the Start of
                                Data Transmission". This setting is reflected in the
                                RCVTIME bit of the KONFR2 register.

    endat_wait_cb_t pecn_init_tclk_wait; A pointer to a callback function that generates the wait
                                time after activating TCLK pin output.
                                See "4.9.1 enc_init_tclk_wait_callback" for details.
                                Do not set NULL.

    endat_wait_cb_t p_enc_init_reset_wait; A pointer to a callback function that generates the wait
                                time after an encoder reset
                                See "4.9.2 enc_init_reset_wait_callback" for details.
                                Do not set NULL.

    endat_wait_cb_t p_enc_init_mem_wait; Pointer to callback function that generates wait time for
                                encoder memory area selection timeout error detection.
                                See "4.9.3 enc_init_mem_wait_callback" for details.
                                Do not set NULL.

    endat_wait_cb_t p_enc_init_pram_wait; Encoder parameter Send / receive timeout Error
                                detection function pointer to generate wait time
                                See "4.9.4 enc_init_pram_wait_callback" for details.
                                Do not set NULL.

    endat_wait_cb_t p_enc_init_cable_wait; A pointer to a function that produces a wait time for time-
                                out error detection for cable propagation delay
                                measurements. If propagation delay compensation is
                                disabled (delay_comp = false), the setting can be
                                omitted.
                                See "4.9.5 enc_init_cable_wait_callback" for details.
                                Do not set NULL when propagation delay compensation
                                is enabled.

} r_endat_info_t
```

(2) r_endat_watchdog_t

Watchdog Timer setting time

```

typedef struct
{
    uint8_t          range;    Set the unit of time for the Watchdog Timer
                        See "Table 4.18 EnDat Watchdog Timer Time Units"
    uint8_t          time;     Set the Watchdog Timer time
                        See "Table 4.22 EnDat Watchdog Timer Table"
} r_endat_watchdog_t

```

Table 4.22 EnDat Watchdog Timer Table

| Value of time | Time of the Watchdog Timer | |
|---------------|-----------------------------|-----------------------------|
| | range = R_ENDAT_WD_RANGE_US | range = R_ENDAT_WD_RANGE_MS |
| 0 | Stop | Stop |
| 1 | 2 us | 0.2 ms |
| 2 | 4 us | 0.4 ms |
| 3 | 6 us | 0.6 ms |
| : | : | : |
| 10 | 20 us | 2.0 ms |
| : | : | : |
| 127 | 254 us | 25.4 ms |

Note: Except for the stop time, there is a margin of error. Refer to the hardware manual for details.

(3) r_endat_req_t

Request information to be sent to the EnDat2.2 compliant encoder. The mode command, MRS code, address and port address are combined and sent to the encoder. The combinations are shown in "Table 4.23 Mode Command Combination Table".

```
typedef struct
{
    uint8_t      mode_cmd;    EnDat 2.2 Mode Command
                               See "Table 4.16 EnDat 2.2 Mode Commands".
    bool         dt;         Continuous mode setting (true: enabled, false:
                               disabled)
                               This setting is valid only if mode_cmd =
                               R_ENDAT_POS.
    uint8_t      mrs;        MRS code
                               See "Table 4.20 EnDat MRS Codes".
                               The setting is valid only if the mode command
                               combined with the MRS code in the "Table 4.23 Mode
                               Command Combination Table" is designated as the
                               mode_cmd.
    uint8_t      addr;       Address (0x00 to 0xFF)
                               The setting is valid only if the mode command
                               combined with the address in the "Table 4.23 Mode
                               Command Combination Table" is designated as the
                               mode_cmd.
    uint16_t     param_instruction; Parameters to be written to memory area of the
                               encoder
                               The setting is valid only if the mode command
                               combined with the parameters or block address in the
                               "Table 4.23 Mode Command Combination Table" is
                               designated as the mode_cmd.
    r_endat_watchdog_t watchdog; Setting time of watchdog timer
                               See "4.14.4(2) r_endat_watchdog_t".
                               When sending a request for the following settings, set
                               it to disabled (time =0).
                               mode_cmd=R_ENDAT_POS and dt=true
                               mode_cmd=R_ENDAT_RESET
                               mode_cmd=R_ENDAT_RX_PARAM
                               mode_cmd=R_ENDAT_PARAM
                               This setting is reflected in the KONFR2 register
                               WTD0G bit.
    bool         elc;        ELC mode setting (true: enabled, false: disabled)
                               This setting is valid only if
                               mode_cmd=R_ENDAT_POS and dt=false.
    r_endat_isr_result_cb_t pisr_result; Pointer to a callback function that conveys the result
                               of the request.
                               See "4.9.6 endat_callback" and "4.9.7
                               endat_poscon_callback" for details.
                               Do not set NULL.
    r_endat_isr_rdst_cb_t  pisr_rdst;  Pointer to a callback function that conveys that the
                               next data communication is ready.
                               See "4.9.8 endat_rdst_callback" for detail.
                               Do not set NULL.
} r_endat_req_t
```

Table 4.23 Mode Command Combination Table

| mode_cmd | Command value | mrs / addr | param_instruction |
|--------------------------|---------------|------------|-------------------|
| R_ENDAT_POS | 0x07u | -- | -- |
| R_ENDAT_MEM | 0x0Eu | MRS Code | -- |
| R_ENDAT_RX_PARAM | 0x1Cu | Address | Parameters *1 |
| R_ENDAT_PARAM | 0x23u | Address | -- |
| R_ENDAT_RESET | 0x2Au | Address | -- |
| R_ENDAT_POS_ADD_DATA | 0x38u | -- | -- |
| R_ENDAT_POS_MEM | 0x09u | MRS Code | Block address *2 |
| R_ENDAT_POS_RX_PARAM | 0x1Bu | Address | Parameters *1 |
| R_ENDAT_POS_PARAM | 0x24u | Address | -- |
| R_ENDAT_POS_RX_ERR_RESET | 0x2Du | Address | -- |

Note 1. Consider the setting value according to the address.
 2. Use only when the MRS code is R_ENDAT_MRS_PARAM_SEC2

(4) r_endat_result_t

Send/receive results

```
typedef struct
{
    r_endat_req_err_t    result;           Results of sending and receiving requests
                                     See "4.14.6(3) r_endat_req_err_t".
    r_endat_data_t      data;             Received data
                                     See "4.14.4(5) r_endat_data_t".
    r_endat_status_t    status;           Encoder Status
                                     See "4.14.4(6) r_endat_status_t".
} r_endat_result_t
```

(5) r_endat_data_t

Received data

```
typedef struct
{
    uint64_t            pos;              Received positional value or test value
                                     The RDATA_L bit in the EMPFR1_L register is
                                     stored in the lower 32 bits. The RDATA_H bit in the
                                     EMPFR1_H register is stored in the upper 32 bits.
    Uint32_t            add_datum1;       Additional data 1
                                     Stores the D bit value of the EMPFR3 register.
    Uint32_t            add_datum2;       Additional data 2
                                     Stores the D bit value of the EMPFR2 register.
} r_endat_data_t
```

(6) r_endat_status_t

Encoder Status

```
typedef struct
{
    bool        busy;        Encoder internal memory status
                        (true: accessing, false: accessible)
    bool        rm;         Increment encoder origin status
                        (true: origin detection, false: origin undetected)
    bool        wrn;        Warning status inside the encoder
                        (true: with warning, false: no warning)
} r_endat_status_t
```

(7) r_endat_protocol_err_t

EnDat I/F and encoder error information

```
typedef struct
{
    bool        err1;       Error1 bit status (true: occurred, false: not occurred)
    bool        crc1;       CRC check error for positional value (true: occurred, false: not
                        occurred)
    bool        ftype1;     EnDat TYPE1 error (true: occurred, false: not occurred)
    bool        ftype2;     EnDat TYPE2 error (true: occurred, false: not occurred)
    bool        msadr;      Address error in EnDat TYPE2 error (true: occurred, false: not
                        occurred)
    bool        err2;       Error2 bit status (true: occurred, false: not occurred)
    bool        crc3;       CRC check error for Additional data 1 (true: occurred, false: not
                        occurred)
    bool        crc2;       CRC check error for Additional data 2 (true: occurred, false: not
                        occurred)
    bool        wdg;        Watchdog error (true: occurred, false: not occurred)
    bool        ftype3;     EnDat TYPE3 error (true: occurred, false: not occurred)
    bool        modeerr;    Mode command transmission error (This bit is not used. It is always
                        false.)*
} r_endat_protocol_err_t
```

Note This is reserved for driver interface compatibility with RZ/T2M group EnDat encoder driver.
This is not used in the driver for RZ/T2H.

4.14.5 EnDat Unions

No unions are used.

4.14.6 EnDat Enumerated Types**(1) r_endat_err_t**

Error codes of the encoder interface

```

typedef enum
{
    ENDAT_SUCCESS          =0,    Normal termination
    ENDAT_ERR_INVALID_ARG ,      Argument error
    ENDAT_ERR_BUSY        ,      API is not executable
    ENDAT_ERR_ACCESS      ,      Error in the execution order of APIs
    ENDAT_ERR_DRV         ,      Internal error in driver
} r_endat_err_t

```

(2) r_endat_cmd_t

Command settings when the R_ENDAT_Control function is used

```

typedef enum
{
    ENDAT_CMD_REQ          ,      Send command to the encoder
    ENDAT_CMD_POS_STOP    ,      Stop continuous reception of positional values from the
                                encoder
} r_endat_cmd_t

```

(3) r_endat_req_err_t

Result of sending and receiving requests

```

typedef enum
{
    ENDAT_REQ_SUCCESS     =0,    Normal completion of data transmission and reception
    ENDAT_REQ_ERR        ,      Data transmission/reception control error occurs
} r_endat_rx_err_t

```

4.15 Description of the Sample Program

4.15.1 Operation Outline

This sample program supports bus connection of up to eight encoders compliant with the A-format specification (Nikon MAR-M50A) and the EnDat 2.2 compliant encoder "EQN1035". This sample program performs the following processes.

A-format

- 1) Request information input from the console is sent to the encoder (normal sending/receiving by writing to the TXTRG register).
- 2) Display data received from the encoder on the console
- 3) Send and receive commands using the ELC event input trigger function of AFMT. (GPT events are linked as input events. For an example of input event settings, see "Figure 4.6 Flowchart of a_as_elctimer function.")

EnDat

- 1) Send requests input from the debugger's terminal I/O to the EnDat encoder (EQN1035)
- 2) Display data received from the EnDat encoder (EQN1035) on the debugger's terminal I/O
- 3) Send and receive commands using the ELC event input trigger function of the EnDat I/F. (GPT events are linked as input events.)

(1) Dual Encoder System Block Diagram

Figure 4.1 shows a block diagram of the system.




Figure 4.1 System Block Diagram

(2) Software Structure

Figure 4.2 shows the structure of the software.

The A-format driver has the opening process part consisting of the R_A_AS_Open function, the closing process part consisting of the R_A_AS_Close function, the sending requests part consisting of the R_A_AS_Control function, and the data reception part (interrupt handler) consisting of callback functions.

The EnDat driver has the opening process part consisting of the R_ENDAT_Open function, the closing process part consisting of the R_ENDAT_Close function, the sending requests part consisting of the R_ENDAT_Control function, and the data reception part (interrupt handler) consisting of callback functions.

The sample program has the A-format driver control part that controls the A-format driver and sends requests, and the A-format result indication part (callback) that displays the results of data reception, the EnDat driver control part that controls the EnDat driver and sends requests, and the EnDat result indication part (callback) that displays the results of data reception.




Figure 4.2 Dual Encoder Software Structure

4.15.2 Sample Program Functions

Table 4.24 lists the major functions of the sample program.

Table 4.24 Major Functions of the Sample Program

| Function Type | Function Name | Page Number | |
|-------------------|------------------------------|---------------|-----------|
| | | Specification | Flowchart |
| Common Function | hal_entry | 55 | - |
| | enc_main | 55 | 66 |
| | dual_cmd_control | 55 | 67 |
| | get_cmd | 55 | - |
| | cmd_exit | 56 | - |
| | timer_start | 56 | - |
| | timer_stop | 56 | - |
| A-format Function | a_as_enc_init | 56 | - |
| | a_as_req | 57 | 68 |
| | a_as_elctimer | 57 | 69 |
| | a_as_elcstop | 57 | 70 |
| | a_as_txerr_callback | 57 | 70 |
| | a_as_rxset_callback | 58 | 71 |
| | a_as_rxend_callback | 58 | 71 |
| | a_as_elctimer_callback | 58 | 72 |
| EnDat Function | endat_power_on_wait | 58 | - |
| | enc_init_tclk_wait_callback | 59 | - |
| | enc_init_reset_wait_callback | 59 | - |
| | enc_init_mem_wait_callback | 59 | - |
| | enc_init_pram_wait_callback | 59 | - |
| | enc_init_cable_wait_callback | 60 | - |
| | endat_pos | 60 | 73 |
| | endat_poscon | 60 | 74 |
| | endat_elctimer | 60 | 75 |
| | endat_stop | 61 | 76 |
| | endat_temp | 61 | 77 |
| | endat_callback | 61 | 78 |
| | endat_poscon_callback | 61 | 79 |
| | endat_rdst_callback | 62 | 79 |
| | endat_result_display | 62 | - |

4.15.3 Specifications of Sample Program Functions

(1) Common Functions

(a) hal_entry

| hal_entry | |
|------------------|---|
| Synopsis | Entry function of the Dual Encoder sample program |
| Header | - |
| Declaration | void hal_entry(void); |
| Description | This is the entry function of the Dual Encoder sample program. From here, the function enc_main () is called. |
| Arguments | None |
| Return value | None |

(b) enc_main

| enc_main | |
|-----------------|---|
| Synopsis | Main function of the Dual Encoder sample program |
| Header | - |
| Declaration | int32_t enc_main(void); |
| Description | This is the main function of the Dual Encoder sample program. For details, see section "4.15.8(1) Flowchart of enc_main". |
| Arguments | None |
| Return value | 0 : Normal termination Others : Abnormal termination (error code of the encoder interface) |

(c) dual_cmd_control

| dual_cmd_control | |
|-------------------------|--|
| Synopsis | Dual Encoder driver control function |
| Header | - |
| Declaration | static void dual_cmd_control(void); |
| Description | This function performs console command input processing. |
| Arguments | None |
| Return value | None |

(d) get_cmd

| get_cmd | |
|----------------|--|
| Synopsis | Function to get command from console |
| Header | - |
| Declaration | static uint32_t get_cmd(char_t *p_arg[], const uint32_t arg_max); |
| Description | Get the command from the console |
| Arguments | p_arg : Pointer to an array console that stores commands acquired from the console arg_max : Maximum number of strings to acquire |
| Return value | Number of strings acquired from console |

(e) cmd_exit

| cmd_exit | |
|-----------------|---|
| Synopsis | End display function of the Dual Encoder sample program |
| Header | - |
| Declaration | static void cmd_exit(uint32_t arg_num, char_t *p_arg[]); |
| Description | Function executed when the console command exit is entered, indicating on the console that the sample program has terminated. |
| Arguments | arg_num : Number of strings entered from console (not used) *p_arg[] : First address of string entered from console (not used) |
| Return value | None |

(f) timer_start

| timer_start | |
|--------------------|--|
| Synopsis | GPT cycle setting/startup function |
| Header | - |
| Declaration | static void timer_start(uint32_t ch, uint32_t us); |
| Description | Set the timer cycle in GPT corresponding to the encoder of designated channel to start the timer. If an unused channel is designated, do nothing and return. |
| Arguments | ch : Encoder channel number us : Timer cycle [us] |
| Return value | None |

(g) timer_stop

| timer_stop | |
|-------------------|---|
| Synopsis | GPT timer stop |
| Header | - |
| Declaration | static void timer_stop(uint32_t ch); |
| Description | Stop the GPT timer corresponding to the encoder of designated channel. If an unused channel is designated, do nothing and return. |
| Arguments | ch : Encoder channel number |
| Return value | None |

(2) A-format Functions**(a) a_as_enc_init**

| a_as_enc_init | |
|----------------------|--|
| Synopsis | Initializing the encoder |
| Header | - |
| Declaration | static int32_t a_as_enc_init(int32_t id); |
| Description | This function is for initializing the encoder. The command data frame CDF8 is transmitted eight times consecutively to clear the status flag. |
| Argument | id : Encoder ID R_A_AS0_ID: Specify channel 0 encoder ID R_A_AS1_ID: Specify channel 1 encoder ID : R_A_AS15_ID: Specify channel 15 encoder ID |
| Return value | 0: Normal termination Others: Abnormal termination (error code of the encoder interface) |

(b) a_as_req

| | |
|-----------------|--|
| a_as_req | |
| Synopsis | Console command "req" function |
| Header | - |
| Declaration | static void a_as_req(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command "req" is input. See section "4.15.8(3) Flowchart of a_as_req" and section "4.15.10 Console Commands" for details. |
| Argument | arg_num : The number of character strings input through the console. *p_arg[] : The starting address where the character strings are stored. |
| Return value | None |

(c) a_as_elctimer

| | |
|----------------------|--|
| a_as_elctimer | |
| Synopsis | Console command "elctimer" function |
| Header | - |
| Declaration | static void a_as_elctimer (uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command "elctimer" is input. See section "4.15.8(4) Flowchart of a_as_elctimer" and section "4.15.10 Console Commands" for details. |
| Arguments | arg_num : The number of character strings input through the console. *p_arg[] : The starting address where the character strings are stored. |
| Return value | None |

(d) a_as_elcstop

| | |
|---------------------|--|
| a_as_elcstop | |
| Synopsis | Console command "elcstop" function |
| Header | - |
| Declaration | static void a_as_elcstop (uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command "elcstop" is input. See section "4.15.8(5) Flowchart of a_as_elcstop" and section "4.15.10 Console Commands" for details. |
| Argument | arg_num : The number of character strings input through the console. *p_arg[] : The starting address where the character strings are stored. |
| Return value | None |

(e) a_as_txerr_callback

| | |
|----------------------------|--|
| a_as_txerr_callback | |
| Synopsis | Callback for the console command "req" when a transmission error is generated |
| Header | - |
| Declaration | static void a_as_txerr_callback(r_a_as_result_t *p_result); |
| Description | This is a callback function that is executed when the console command "req" is input. It holds a pointer to the result of transmitted A-format request in normal reception in the variable a_as_result and indicates that a timeout error is generated. See section "4.15.8(6) Flowchart a_as_txerr_callback" for details. |
| Argument | *p_result : The address in the RAM where the result of transmission of the request and reception starts. |
| Return value | None |

(f) a_as_rxset_callback

| | |
|----------------------------|---|
| a_as_rxset_callback | |
| Synopsis | Callback for the console command "req" when the setting of received data is complete. |
| Header | - |
| Declaration | static void a_as_rxset_callback(r_a_as_result_t *p_result); |
| Description | This is a callback function that is executed when the console command "req" is input. It holds a pointer to the result of the transmitted an A-format request and received data in response in normal reception in the variable a_as_result and indicates completion of the setting of received data. See section "4.15.8(7) Flowchart of a_as_rxset_callback" for details. |
| Argument | *p_result : The address in the RAM where the result of transmission of the request and reception starts. |
| Return value | |

(g) a_as_rxend_callback

| | |
|----------------------------|---|
| a_as_rxend_callback | |
| Synopsis | Callback for the console command "req" when reception of the data has been completed. |
| Header | - |
| Declaration | static void a_as_rxend_callback(r_a_as_result_t *p_result); |
| Description | This is a callback function that is executed when the console command "req" is input. It indicates completion of the reception of data in response to the A-format request in normal reception. See section "4.15.8(8) Flowchart of a_as_rxend_callback" for details. |
| Argument | *p_result : The address in the RAM where the result of transmission of the request and reception starts. |
| Return value | None |

(h) a_as_elctimer_callback

| | |
|-------------------------------|--|
| a_as_elctimer_callback | |
| Synopsis | Callback for the console command "elctimer". |
| Header | - |
| Declaration | static void a_as_elctimer_callback(r_a_as_result_t * p_result); |
| Description | This is a callback function that is executed when the console command "elctimer" is input. It holds the result of the transmitted request and received data in the variables a_as_ti_result and a_as_ti_data. See section "4.15.8(9) Flowchart of a_as_elctimer_callback" for details. |
| Argument | *p_result : The address in the RAM where the result of transmission of the request and reception starts. |
| Return value | None |

(3) EnDat functions**(a) endat_power_on_wait**

| | |
|----------------------------|---|
| endat_power_on_wait | |
| Synopsis | Waiting time generation function after encoder power-on |
| Header | - |
| Declaration | static void endat_power_on_wait(void); |
| Description | This callback function generates the required 1.3s standby time after the encoder is turned on. |
| Arguments | None |
| Return value | None |

(b) enc_init_tclk_wait_callback**enc_init_tclk_wait_callback**

| | |
|--------------|---|
| Synopsis | Waiting time generation function after activating TCLK pin output |
| Header | - |
| Declaration | static void enc_init_tclk_wait_callback(void); |
| Description | This callback function generates a waiting time of 100 us after activating TCLK pin output. See "4.9.1 enc_init_tclk_wait_callback". |
| Arguments | None |
| Return value | None |

(c) enc_init_reset_wait_callback**enc_init_reset_wait_callback**

| | |
|--------------|---|
| Synopsis | Waiting time generation function after encoder reset |
| Header | - |
| Declaration | static void enc_init_reset_wait_callback(void); |
| Description | This callback function generates a waiting time of 60 ms after the encoder reset process in the initialization process of the connected encoder. See "4.9.2 enc_init_reset_wait_callback". |
| Arguments | None |
| Return value | None |

(d) enc_init_mem_wait_callback**enc_init_mem_wait_callback**

| | |
|--------------|--|
| Synopsis | Waiting time generation function for encoder memory area selection process |
| Header | - |
| Declaration | static void enc_init_mem_wait_callback(void); |
| Description | This callback function generates a waiting time of 743 us for detecting a timeout error in the process of selecting a memory area in the initialization process of the connected encoder. See "4.9.3 enc_init_mem_wait_callback". |
| Arguments | None |
| Return value | None |

(e) enc_init_pram_wait_callback**enc_init_pram_wait_callback**

| | |
|--------------|--|
| Synopsis | Waiting time generation function for encoder parameter sending/receiving process |
| Header | - |
| Declaration | static void enc_init_pram_wait_callback(void); |
| Description | This callback function generates a waiting time of 13 ms for detecting a timeout error in the initialization process of the connected encoder, during which the encoder sends and receives parameters. See "4.9.4 enc_init_pram_wait_callback". |
| Arguments | None |
| Return value | None |

(f) enc_init_cable_wait_callback**enc_init_cable_wait_callback**

| | |
|--------------|--|
| Synopsis | Wait time generation function for encoder cable propagation delay measurement process |
| Header | - |
| Declaration | static void enc_init_cable_wait_callback(void); |
| Description | Callback function to generate a waiting time of 588 us for detecting a timeout error in the process of measuring the cable propagation delay in the initialization process of the connected encoder. See "4.9.5 enc_init_cable_wait_callback" |
| Arguments | None |
| Return value | None |

(g) endat_pos**endat_pos**

| | |
|--------------|---|
| Synopsis | Function to get a positional value from the encoder |
| Header | - |
| Declaration | static void endat_pos(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command pos is entered. It acquires a positional value from the encoder. |
| Arguments | arg_num : Number of strings entered from the console (Not used) *p_arg[] : First address of string entered from console (Not used) |
| Return value | None |

(h) endat_poscon**endat_poscon**

| | |
|--------------|--|
| Synopsis | Function to get positional values continuously from the encoder |
| Header | - |
| Declaration | static void endat_poscon(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command poscon is entered to continuously acquire position values from the encoder using Continuous mode. |
| Arguments | arg_num : Number of strings entered from the console (Not used) *p_arg[] : First address of string entered from console (Not used) |
| Return value | None |

(i) endat_elctimer**endat_elctimer**

| | |
|--------------|--|
| Synopsis | Function to get positional values continuously from the encoder synchronously with the ELC events |
| Header | - |
| Declaration | static void endat_elctimer(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command elctimer is entered. It acquires positional values continuously from the encoder synchronously with the ELC events. |
| Arguments | arg_num : Number of strings entered from the console *p_arg[] : First address of string entered from console |
| Return value | None |

(j) endat_stop

| | |
|-------------------|--|
| endat_stop | |
| Synopsis | Function to stop continuous acquisition positional values from the encoder |
| Header | - |
| Declaration | static void endat_stop(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command stop is entered. It stops the continuous transmission of positional values from the encoder when it is operating in Continuous mode. While operating in ELC mode, this function cancels ELC mode operation and stops issuing continuous positional value acquisition commands. After the continuous positional value transmission from the encoder is stopped, the last 10 positional values are displayed. |
| Arguments | arg_num : Number of strings entered from the console (Not used) *p_arg[] : First address of string entered from console (Not used) |
| Return value | None |

(k) endat_temp

| | |
|-------------------|---|
| endat_temp | |
| Synopsis | Function to get temperature information from the encoder |
| Header | - |
| Declaration | static void endat_temp(uint32_t arg_num, char_t *p_arg[]); |
| Description | This function is executed when the console command temp is entered. It acquires temperature information from the encoder |
| Arguments | arg_num : Number of strings entered from the console (Not used) *p_arg[] : First address of string entered from console (Not used) |
| Return value | None |

(l) endat_callback

| | |
|-----------------------|--|
| endat_callback | |
| Synopsis | Callback function that conveys the result of the request transmission to the encoder |
| Header | - |
| Declaration | static void endat_callback(r_endat_result_t *p_result, r_endat_protocol_err_t *p_err); |
| Description | This function stores the result in memory. |
| Arguments | p_result : Result of the request transmission p_err : EnDat I/F and encoder error information |
| Return value | None |

(m) endat_poscon_callback

| | |
|------------------------------|--|
| endat_poscon_callback | |
| Synopsis | Callback function that conveys the result of the request transmission to the encoder |
| Header | - |
| Declaration | static void endat_poscon_callback (r_endat_result_t *p_result, r_endat_protocol_err_t *p_err); |
| Description | This function stores the continuously acquired results in memory |
| Arguments | p_result : Result of the request transmission p_err : EnDat I/F and encoder error information |
| Return value | None |

(n) endat_rdst_callback**endat_rdst_callback**

| | |
|--------------|--|
| Synopsis | Callback function to convey that the next data transmission is ready to start |
| Header | - |
| Declaration | static void endat_rdst_callback(void); |
| Description | This function conveys that the data reception completes and the next data communication is ready. It is called each time data reception is completed while operating in continuous mode or in ELC mode. This function sets the acquisition completion flag. |
| Arguments | None |
| Return value | None |

(o) endat_result_display**endat_result_display**

| | |
|--------------|--|
| Synopsis | Function to display the result of data reception |
| Header | - |
| Declaration | static void result_display(r_endat_result_t *p_result, r_endat_protocol_err_t *p_err); |
| Description | This function indicates the result of data reception in response to a request sent to the encoder. |
| Arguments | p_result : Result of the request transmission p_err : EnDat I/F and encoder error information |
| Return value | None |

4.15.4 Variables Used in the A-format Sample Program

The major static variables used in the sample program are listed below.

Table 4.25 Static Variables Used in the A-format Sample Program

| Type | Variable Name | Description |
|-----------------|---------------------------|--|
| bool | a_as_flg | Transmission and reception completion flag. (true: transmission and reception completed; false: transmission and reception in progress) |
| r_a_as_result_t | a_as_result[A_AS_ENC_NUM] | The results of acquisition are stored. |
| bool | a_as_elc_flg | ELC event input trigger flag (true: ELC event input trigger operation is in progress; false: ELC event input trigger operation is stopped) |
| bool | elc_trans_flg | The flag that indicates the state of transmission and reception of data from the ELC event input trigger. (true: Transmission and reception in progress, false: Transmission and reception completed) |
| r_a_as_req_t | a_as_req_elc | Holds the request information while ELC event input trigger operation is in progress. |

4.15.5 Constants Used in the A-format Sample Program

The major constants used in the sample program are listed below.

Table 4.26 Major Constants Used in the A-format Sample Program

| Constant | Setting | Description |
|--------------|---------|-----------------------------------|
| A_AS_ENC_NUM | 8 | The number of connected encoders. |

4.15.6 Variables of EnDat Sample Program

Table 4.27 lists the major static type variables. Const type variables are not used.

Table 4.27 Static Variables Used in the EnDat Sample Program

| Type | Variable Name | Description | Function to be used |
|------------------------|---------------------------|---|--|
| bool | endat_flag | Transmission completion flag (true: transmission completed, false: transmission is in progress) | endat_pos endat_poscon endat_elctimer endat_stop endat_temp endat_callback endat_rdst_callback |
| bool | endat_elc_flg | ELC mode operating flag (true: operating in ELC mode, false: not operating in ELC mode) | endat_pos endat_poscon endat_elctimer endat_stop |
| r_endat_result_t | *p_endat_result | Address containing data acquisition results | endat_pos endat_temp endat_callback |
| r_endat_protocol_err_t | *p_endat_err | Address containing error information | endat_pos endat_temp endat_callback |
| r_endat_req_err_t | poscon_err[ENDAT_POS_NUM] | Errors in continuously acquired positional values An array with 10 elements is used as a ring buffer to store the results of the latest 10 acquisitions. | endat_poscon endat_elctimer endat_stop endat_poscon_callback |
| uint64_t | poscon[ENDAT_POS_NUM] | Continuously acquired positional values An array with 10 elements is used as a ring buffer to store the results of the latest 10 acquisitions. | endat_poscon endat_elctimer endat_stop endat_poscon_callback |
| uint8_t | poscon_valid | Number of valid elements in poscon, poscon_err array Indicates the number of valid elements of positional values stored in the array. | endat_poscon endat_elctimer endat_stop endat_poscon_callback |
| uint8_t | poscon_num | Update position indices for poscon and poscon_err arrays The following are the indexes to be updated by the acquired position values. | endat_poscon endat_elctimer endat_stop endat_poscon_callback |
| bool | poscon_empty | Space information in poscon and poscon_err arrays (true: has space, false: has no space) | endat_poscon endat_elctimer endat_poscon_callback |
| int32_t | endat_cur_id | Used EnDat I/F driver ID | enc_main endat_cmd_control endat_pos endat_poscon endat_elctimer endat_stop endat_temp |

4.15.7 Constants of EnDat Sample Program

Table 4.28 lists the major constants used in the sample program.

Table 4.28 Major Constants Used in the EnDat Sample Program

| Constants | Value | Content |
|---------------------------|-------|--|
| ENDAT_ENC_TSAT_WAIT | 1300u | Standby time after power-on (1.3 s) |
| ENDAT_ENC_100US_WAIT | 100u | Waiting time after activating TCLK pin output (100 us) |
| ENDAT_ENC_INIT_RESET_WAIT | 60u | Time to wait after encoder reset process (60 ms) |
| ENDAT_ENC_INIT_MEM_WAIT | 743u | Waiting time for detection of timeout errors in the process of selecting memory area in encoder initialization (743 us) |
| ENDAT_ENC_INIT_PRAM_WAIT | 13u | Waiting time for detection of timeout errors in the process of sending and receiving parameters in encoder initialization. (13 ms) |
| ENDAT_ENC_INIT_CABLE_WAIT | 588u | Waiting time for detection of timeout errors in the process of measuring cable propagation delay in encoder initialization. (588 us) |
| ENDAT_WDG_MAX | 127u | Maximum watchdog timer setting value |
| ENDAT_POS_NUM | 10u | Number of elements of the array for storing continuously received position values |
| ENDAT_TEMP_SCA_FAC | 0.1 | Number of elements of the array for storing continuously received position values |
| ENDAT_TEMP_ABS_ZERO | 273.2 | Constant for temperature data unit conversion |

4.15.8 Flowchart of Main Processing

(1) Flowchart of enc_main




Figure 4.3 Flowchart of enc_main Function

(2) Flowchart of dual_cmd_control




Figure 4.4 Flowchart of dual_cmd_control Function

(3) Flowchart of a_as_req




Figure 4.5 Flowchart of a_as_req Function

(4) Flowchart of a_as_elctimer




Figure 4.6 Flowchart of a_as_elctimer Function

(5) Flowchart of a_as_elcstop




Figure 4.7 Flowchart of a_as_elcstop Function

(6) Flowchart of a_as_txerr_callback




Figure 4.8 Flowchart of a_as_txerr_callback Function

(7) Flowchart of a_as_rxset_callback




Figure 4.9 Flowchart of a_as_rxset_callback Function

(8) Flowchart of a_as_rxend_callback




Figure 4.10 Flowchart of a_as_rxend_callback Function

(9) Flowchart of a_as_elctimer_callback




Figure 4.11 Flowchart of a_as_elctimer_callback Function

(10) Flowchart of endat_pos




Figure 4.12 Flowchart endat_pos Function

(11) Flowchart of endat_poscon




Figure 4.13 Flowchart of endat_poscon Function

(12) Flowchart of endat_elctimer




Figure 4.14 Flowchart of endat_elctimer Function

(13) Flowchart of endat_stop




Figure 4.15 Flowchart of endat_stop Function

(14) Flowchart of endat_temp




Figure 4.16 Flowchart of endat_temp Function

(15) Flowchart of endat_callback




Figure 4.17 Flowchart endat_callback Function

(16) Flowchart of endat_poscon_callback




Figure 4.18 Flowchart endat_poscon_callback Function

(17) Flowchart of endat_rdst_callback




Figure 4.19 Flowchart of endat_rdst_callback Function

4.15.9 Dual Encoder Operation Sequence

(1) Dual Encoder Startup Sequence




Figure 4.20 Dual Encoder Startup Sequence Diagram

(2) A-format Request Transmission and Data Reception Sequence




Figure 4.21 A-format Request Transmission and Data Reception Sequence Diagram

(3) EnDat Request Transmission and Data Reception Sequence




Figure 4.22 EnDat Request Transmission and Data Reception Sequence Diagram

(4) A-format ELC Event Trigger Operation Sequence




Figure 4.23 A-format ELC Event Trigger Operation Sequence Diagram (1/2)




Figure 4.24 A-format ELC Event Trigger Operation Sequence Diagram (2/2)

(5) EnDat Request Transmission (Continuous Mode) and Data Reception Sequence




Figure 4.25 EnDat Request Transmission (Continuous Mode) and Data Reception Sequence Diagram

(6) EnDat Request Transmission (ELC Mode) and Data Reception Sequence




Figure 4.26 EnDat Request Transmission (ELC Mode) and Data Reception Sequence Diagram

(7) Dual Encoder Stop Sequence




Figure 4.27 Dual Encoder Stop Sequence Diagram

4.15.10 Console Commands

This sample program supports an encoder (MAR-M50A) compliant with the A-format specification and an encoder (EQN1035) compliant with the EnDat 2.2 specification. The commands that can be input from the console are as follows. Commands are prefixed with the identification code "A" or "E" to distinguish the target encoder of the command.

Table 4.29 A-format Console Commands

| Command | Content |
|-------------------------------|--|
| A req ea cmd param1 param2 | Sends the command frame input in the cmd to the encoder. ea: Encoder section number (decimal notation) cmd: Command frame param1 and param2: The values to be input depends on the cmd value. See "Table 4.32, A-format req Commands and Corresponding Parameters". |
| A elctimer ea val | Sends the command frame CDF0 to the designated encoder at 2.5 Mbps by the ELC event trigger. ea: Encoder section number (decimal notation) val: Timing of the trigger in microseconds. The maximum value allowed is 6990. Operation in response to input of the ELC event trigger is stopped by executing the console command "elcstop". |
| A elcstop | Stops the operation in response to input of the ELC event trigger. |

Table 4.30 EnDat Console Commands

| Command | Content |
|----------------|---|
| E pos | Get positional value only once. |
| E poscon | The positional values are acquired continuously. To stop continuous acquisition, enter the "stop" command. |
| E elctimer val | The positional value is continuously acquired in a timer cycle as an ELC event input trigger operation. The timer cycle is specified in units of us (maximum 6990us). To stop continuous acquisition, enter the "stop" command. |
| E stop | Stops continuous acquisition of positional values. |
| E temp | Obtains temperature measurements along with positional values from the encoder. |

Table 4.31 Common Console Commands

| command | content |
|---------|-------------------|
| exit | Exit the program. |

Table 4.32 A-format req Commands and Corresponding Parameters

| cmd | param1 | param2 |
|---------------------|---|--|
| CDF0 to CDF12 | None | None |
| CDF13 | An address in EEPROM (hexadecimal notation) Specify a value between 0x00 to 0xFF. | None |
| | Usage example (reading the data from address 0 of the encoder with section number 2) req 2 CDF13 00 | |
| CDF14 | An address in EEPROM (in hexadecimal) Specify a value between 0x00 to 0xEF. | The data to be written to EEPROM (in hexadecimal) Specify a value between 0x0000 to 0xFFFF. |
| | Usage example (writing 0x1234 to address 0 of the encoder with section number 2) req 2 CDF14 00 1234 | |
| CDF15 to 17 | None | None |
| CDF18, CDF19 | ID code (in hexadecimal) Specify a value between 0x00 0000 to 0xFF FFFF. | None |
| | Usage example (writing ID code 0x12 3456 to the encoder with section number 2) req 2 CDF18 123456 | |
| CDF21, CDF27, CDF29 | None | None |

Note: Though input of CDF11, CDF17, and CDF19 are possible, they cannot be used because the sample program is for operation with a bus connection.

Multiple transmission commands (CDF4 to 7, CDF22, CDF28, CDF30) and CDF20 command are not supported.

(1) Result of Running

After running, it will display the command prompt following the version. Enter the command after "Dual >".

```
Dual encoder sample program start
R_A_AS_GetVersion = 4.0

R_ENDAT_GetVersion = 4.0

Dual>
```

(2) Example of Command Execution

It is an example of executing console command that sends command frame CDF0 to a connecting encoder ENC1. Encoder address, status and angular information are displayed as the response from the encoder.

```
Dual>A req 1 CDF0
A req command
A -----
A ENC1
A R_A_AS_REQ_SUCCESS
A EA : 0
A ES : 2
A CC : 0
A ABS 40bit [39:32] : 0x00000001
A ABS 40bit [31:0] : 0x00B29A75
```

It is an example of executing E pos command. Results of sending and receiving requests, received positional value and additional data are displayed as the response from the encoder.

```
Dual>E pos
E pos command
E result      : ENDAT_SUCCESS
E pos_upper   : 0x00000000
E pos_lower   : 0x00778D1B
E add_datum1  : 0x00000000
E add_datum2  : 0x00000000
```

4.15.11 Procedure of Channel Changing

The RZ/T2H has 16 channels for encoder interfaces from channel 0 to 15. In the Dual Encoder sample program, A-format is initially assigned to channel 0 and EnDat to channel 1. If you change the channel assignments, change the macro definitions in the source code (dual_main.c) and each encoder driver (r_a_as_rzt2.c, r_endat_rzt2.c), as well as the interrupt handler and event link in the FSP Configurator.

(1) Settings of Initial Channel

The default macro settings are listed below.

```
dual_main.c ;
  #define A_AS_CH (0)      /* Set the channel for A-format */
  #define ENDAT_CH (1)    /* Set the channel for EnDat */
r_a_as_rzt2.c ;
  #define VECTOR_NUMBER_AFMTx_INT0 VECTOR_NUMBER_ENCIFO0_INT0
                                     /* Use the ENCIFO0_INT0 vector for A-format */
R_endat_rzt2.c :
  #define VECTOR_NUMBER_ENDATx_INT0 (VECTOR_NUMBER_ENCIFO1_INT0)
                                     /* Use the ENCIFO1_INT0 vector for EnDat */
```

The pins used and their functions are initially assigned as shown in Table 4.33.

Table 4.33 Used Pins and Their Functions

| Channel | Pin Name | I/O Port | Input/Output | Voltage Domain | Description |
|-----------|---------------------|----------|--------------|----------------|--------------------|
| AFMT0 | ENCIFOE00 (D/R) | P14_3 | Output | VDD33 | Data output enable |
| | ENCIFDO00 (REQ) | P14_4 | Output | VDD33 | Data output |
| | ENCIFDI00 (SDAT) | P14_5 | Input | VDD33 | Data input |
| ENDAT_CH1 | ENCIFCK1 (TCLK1) | P33_2 | Output | VDD1833_3 | Clock output |
| | ENCIFOE1 (DE1) | P33_3 | Output | VDD1833_3 | Data output enable |
| | ENCIFDO1 (DATA_DV1) | P33_4 | Output | VDD1833_3 | Data output |
| | ENCIFDI1 (DATA_RC1) | P33_5 | Input | VDD1833_3 | Data input |

(2) Settings of Example 1 of Changing Channel

If you change the assignments of A-format to channel 1 and EnDat to channel 0, change the macros definitions in each file as follows.

```
dual_main.c ;
  #define A_AS_CH (1)      /* Change the channel of A-format to 1 */
  #define ENDAT_CH (0)    /* Change the channel of EnDat to 0 */
r_a_as_rzt2.c :
  #define VECTOR_NUMBER_AFMTx_INT0 VECTOR_NUMBER_ENCIFO1_INT0
                                     /* Use the ENCIFO1_INT0 vector for A-format */
r_endat_rzt2.c :
  #define VECTOR_NUMBER_ENDATx_INT0 (VECTOR_NUMBER_ENCIFO0_INT0)
                                     /* Use the ENCIFO0_INT0 vector for EnDat */
```

Furthermore, change the interrupt handler (ISR) corresponding to the ENCIF00_INT0 event and ENCIF01_INT0 event from the FSP Configurator.

Table 4.34 Changes in Interrupt Handler

| Event | Initial ISR | ISR after changing channel |
|---|-------------------|----------------------------|
| ENCIF00_INT0 (ENCIF00 combined Interrupt 0) | a_as0_int_isr | endat0_rx_int_isr |
| ENCIF01_INT0 (ENCIF01 combined Interrupt 0) | endat1_rx_int_isr | a_as1_int_isr |

Interrupts Configuration Generate Project Content

User Events New User Event > Remove

| Event | ISR |
|---|-------------------|
| ENCIF_ERR0 (ENCIF error event 0) | a_as_err_isr |
| ENCIF00_INT0 (ENCIF00 combined interrupt 0) | endat0_rx_int_isr |
| ENCIF01_INT0 (ENCIF01 combined interrupt 0) | a_as1_int_isr |
| | |

A-format and EnDat have operating modes that receive periodic events output by GPT as ELC events. The assignment of ELC events is also done in the Event Links tab of the FSP Configurator. A-format corresponds to GPT00_0_INT4, and EnDat corresponds to GPT00_1_INT4.

Table 4.35 Changes in Event Links

| Event | Initial Peripheral Function | Peripheral Function after changing channel |
|---|-----------------------------|--|
| GPT00_0_INT4 (ENCIF00_0 combined Interrupt) | Encoder I/F SS trigger 0 | Encoder I/F SS trigger 1 |
| GPT01_1_INT4 (ENCIF00_1 combined Interrupt) | Encoder I/F SS trigger 1 | Encoder I/F SS trigger 0 |

Event Links Configuration Generate Project Content

User Events Produced New User Event > Remove

| Event |
|---|
| GPT00_0_INT4 (GPT00_0 combined interrupt) |
| GPT00_1_INT4 (GPT00_1 combined interrupt) |

User Events Consumed New User Event > Remove

| Peripheral Function | Event |
|--------------------------|---|
| Encoder I/F SS trigger 1 | GPT00_0_INT4 (GPT00_0 combined interrupt) |
| Encoder I/F SS trigger 0 | GPT00_1_INT4 (GPT00_1 combined interrupt) |

The pins used and their functions are assigned as shown in Table 4.36.

Table 4.36 Used Pins and Their Functions (Example 1 of Changing Channel)

| Channel | Pin Name | I/O Port | Input/Output | Voltage Domain | Description |
|-----------|---------------------|----------|--------------|----------------|--------------------|
| AFMT1 | ENCIFOE01 (D/R) | P33_3 | Output | VDD1833_3 | Data output enable |
| | ENCIFDO01 (REQ) | P33_4 | Output | VDD1833_3 | Data output |
| | ENCIFDI01 (SDAT) | P33_5 | Input | VDD1833_3 | Data input |
| ENDAT_CH0 | ENCIFCK0 (TCLK0) | P14_2 | Output | VDD33 | Clock output |
| | ENCIFOE0 (DE0) | P14_3 | Output | VDD33 | Data output enable |
| | ENCIFDO0 (DATA_DV0) | P14_4 | Output | VDD33 | Data output |
| | ENCIFDI0 (DATA_RC0) | P14_5 | Input | VDD33 | Data input |

(3) Settings of Example 2 of Changing Channel

If you change the assignments of A-format to Channel 2 and EnDat to Channel 5, please change the macros definitions in each file as follows.

```
dual_main.c ;
#define A_AS_CH (2) /* Change the channel of A-format to 2 */
#define ENDAT_CH (5) /* Change the channel of EnDat to 5 */
r_a_as_rzt2.c ;
#define VECTOR_NUMBER_AFMTx_INT0 VECTOR_NUMBER_ENCIFO2_INT0
/* Use the ENCIFO2_INT0 vector for A-format */
r_endat_rzt2.c :
#define VECTOR_NUMBER_ENDATx_INT0 (VECTOR_NUMBER_ENCIFO5_INT0)
/* Use the ENCIFO5_INT0 vector for EnDat */
```

Furthermore, delete the interrupt handler (ISR) corresponding to the ENCIFO0_INT0 event and ENCIFO1_INT0 event from the FSP Configurator, and register the interrupt handlers (ISR) corresponding to the ENCIFO2_INT0 event and the ENCIFO5_INT0 event from the FSP Configurator.

Table 4.37 Changes in Interrupt Handler

| Event | Initial ISR | ISR after changing channel |
|---|-------------------|----------------------------|
| ENCIFO0_INT0 (ENCIFO0 combined Interrupt 0) | a_as0_int_isr | (delete) |
| ENCIFO1_INT0 (ENCIFO1 combined Interrupt 0) | endat1_rx_int_isr | (delete) |
| ENCIFO2_INT0 (ENCIFO2 combined Interrupt 0) | - | a_as2_int_isr |
| ENCIFO5_INT0 (ENCIFO5 combined Interrupt 0) | - | endat5_rx_int_isr |

Interrupts Configuration

Generate Project Content

User Events


 New User Event >
 Remove

| Event | ISR |
|---|-------------------|
| ENCIF_ERR0 (ENCIF error event 0) | a_as_err_isr |
| ENCIFO2_INT0 (ENCIFO2 combined interrupt 0) | a_as2_int_isr |
| ENCIFO5_INT0 (ENCIFO5 combined interrupt 0) | endat5_rx_int_isr |
| | |

Change to the assignment of ELC events in the Event Links tab of the FSP Configurator.

Table 4.38 Changes in Event Links

| Event | Initial Peripheral Function | Peripheral Function after changing channel |
|---|-----------------------------|--|
| GPT00_0_INT4 (ENCIF00_0 combined Interrupt) | Encoder I/F SS trigger 0 | Encoder I/F SS trigger 2 |
| GPT00_1_INT4 (ENCIF00_1 combined Interrupt) | Encoder I/F SS trigger 1 | Encoder I/F SS trigger 5 |



The pins used and their functions are assigned as shown in Table 4.39. In this sample program, the I/O ports corresponding to the 16 channels of the encoder interface have already been selected. There is no need to change the I/O port settings in the Pins tab of the FSP Configurator.

Table 4.39 Used Pins and Their Functions (Example 2 of Changing Channel) *

| Channel | Pin Name | I/O Port | Input/Output | Voltage Domain | Description |
|-----------|---------------------|----------|--------------|----------------|--------------------|
| AFMT2 | ENCIFOE02 (D/R) | P03_4 | Output | VDD33 | Data output enable |
| | ENCIFDO02 (REQ) | P03_5 | Output | VDD33 | Data output |
| | ENCIFDI02 (SDAT) | P03_6 | Input | VDD33 | Data input |
| ENDAT_CH5 | ENCIFCK5 (TCLK5) | P12_4 | Output | VDD1833_6 | Clock output |
| | ENCIFOE5 (DE5) | P12_5 | Output | VDD1833_6 | Data output enable |
| | ENCIFDO5 (DATA_DV5) | P12_6 | Output | VDD1833_6 | Data output |
| | ENCIFDI5 (DATA_RC5) | P12_7 | Input | VDD1833_6 | Data input |

Note: For the pins used and their functions when assigning other channels, refer to the application note for the RZ/T2H Group Encoder I/F EnDat sample program for EnDat, and the RZ/T2H Group Encoder I/F A-format sample program for A-format.

5. Sample Code

The sample code is available from the Renesas Electronics website.

Revision History

| Rev. | Date | Description | |
|------|-----------|---|--|
| | | Page | Summary |
| 2.00 | Feb.28.25 | - | First Edition issued |
| 3.00 | Oct 31.25 | 11 to 19, 24 to 30 11 to 34 45 | Change description of headers for functions. Revise to unify description for functions. Revise description of structure r_a_as_status_t. |
| 4.00 | Apr 24.26 | 6 11 to 30, 46, 55 to 62 16 to 19, 27 to 30 | Change the frequency of the Cortex-A55 Core0 to 1200MHz. Change the prefix of pointer variables to "p_". Revised the header column of "Specifications of User-defined Function". |

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

- A-format is a trademark of Nikon Corporation.
- EnDat is a registered trademark of Dr. Johannes Heidenhain GmbH.
- IAR Embedded Workbench is a registered trademark of IAR Systems.
- Arm and Cortex are registered trademarks of Arm Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved.
- Additionally all product names and service names in this document are a trademark or a registered trademark which belongs to the respective owners.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.