

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

USER'S MANUAL

RENESAS

Phase-out/Discontinued

SE-17052

17K SERIES

Document No. EEU-1271
(O.D.No. EEU-686)
Date Published August 1991 P
Printed in Japan

USER'S MANUAL

NEC

Phase-out/Discontinued

SE-17052

17K SERIES

Phase-out/Discontinued

Phase-out/Discontinued

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Corporation. NEC Corporation assumes no responsibility for any errors which may appear in this document.

NEC Corporation does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from use of a device described herein or any other liability arising from use of such device. No license, either express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Corporation or of others.

The application circuits and their parameters are for references only and are not intended for use in actual design-in's.

Phase-out/Discontinued

Phase-out/Discontinued

CONTENTS

CHAPTER 1	INTRODUCTION	1
CHAPTER 2	SPECIFICATIONS	2
CHAPTER 3	BLOCK DIAGRAM	4
CHAPTER 4	OPERATING PROCEDURES	5
4.1	HOW TO USE SE-17052 WITH IE-17K	5
4.2	HOW TO USE SE-17052 ALONE	9
4.3	ADJUSTING OF OSCILLATING FREQUENCY	11
4.4	ADJUSTING OF OSCILLATING FREQUENCY FOR IDC	12
4.5	MONITOR PINS	13
4.6	SETTINGS AS SHIPPED	14
CHAPTER 5	CONNECTOR PIN TABLE	15
5.1	CONNECTOR (J1) FOR PROBE	15
5.2	CONNECTOR (J2) FOR PROBE	16
CHAPTER 6	EXTERNAL FORM OF PROBE	17

Phase-out/Discontinued


CHAPTER 1 INTRODUCTION

SE-17052 is a system evaluation board for 4-bit single chip microcontroller μ PD17052CW. SE-17052 can be used with the μ PD17000 series common in-circuit emulator IE-17K, and also SE-17052 can be used alone.

μ PD17052CW is used as an interface with the target system. Therefore, the function of SE-17052 is the same as μ PD17052CW.

In case of connecting SE-17052 to the target system, use the option EP-17052CW (80 pins SDIP probe for μ PD17052CW).


Fig. 1-1 External appearance



CHAPTER 2 SPECIFICATIONS


Model name	: SE-17052
Program memory	: • using SE-17052 with IE-17K μ PD43256C • using SE-17052 alone μ PD27C256D μ PD43256C is mounted as shipped.
Data memory	: built-in RAM of μ PD17052CW (4 bits x 448)
Oscillating frequency	: 8 MHz (using crystal oscillator) 8 MHz crystal oscillator is installed as shipped
Instruction cycle	: 2 μ s
Operating temperature	: +10 to +40 °C
Storage temperature	: -10 to +50 °C (but without condensation)
Power supply	: 5 V \pm 5 % • When using SE-17052 with IE-17K, the power is supplied from IE-17K. • When using SE-17052 alone, the power is supplied from the probe (EP-17052CW) or the connector CN11 on SE-17052.
Current consumption	: 180 mA (MAX.) (no load, using μ PD27C256D as a program memory)
Board dimensions	: 150 mm x 114 mm x 30 mm

Fig. 2-1 SE-17052 Component layout



CHAPTER 3 BLOCK DIAGRAM

Fig. 3-1 Block diagram of SE-17052



CHAPTER 4 OPERATING PROCEDURES


4.1 HOW TO USE SE-17052 WITH IE-17K

(1) DIP SWITCH (SW2) SETTING

The DIP switch (SW2) selects that the CE signal of μ PD17052CW is pulled up or not. When pulled up, it is set as shown in Fig. 4-1. When not pulled up, it is set as shown in Fig. 4-2.


Pull up the CE signal when using SE-17052 without the target system or when the CE signal is not supplied from the target system. The CE signal need not be pulled up when the CE signal is supplied from the target systems.

Fig. 4-1 SW2 setting (when pulled up)



NOTE:  is the setting side.

Fig. 4-2 SW2 setting (when not pulled up)



NOTE:  is the setting side.

When SE-17052 is shipped, the DIP switch (SW2) is set as shown in Fig. 4-2.

(2) RAM mounting

Mount the RAM (μ PD43256C) as a program memory.

Use the RAM mounted on SE-17052 as shipped.

When using the RAM other than μ PD43256C, mount the RAM that accepts the following condition.

$$T_{ACC} < 0.5 \mu s$$


(T_{ACC} : Address setting \rightarrow Data output delay time)

μ PD43256C-10, 12 and 15 are available.

(3) ROM/RAM change jumper switch settings

Set the ROM/RAM change Jumper switches to the RAM side as shown in Fig. 4-3.

Fig. 4-3 ROM/RAM change jumper switch setting



NOTE: is the connecting position.

(4) Installation and removal of SE-17052 into and from IE-17K

To install SE-17052 into IE-17K, firstly remove the external cover and the inside cover. Fig. 4-4 shows the external view of IE-17K after removing the external cover.

Removing the inside cover, the memory board can be seen. Three connectors are located on the memory board. SE-17052 can be installed into IE-17K by putting three connectors (CN7, 8 and 9) on SE-17052 into three connectors on IE-17K. (See Fig. 4-5)

When installing SE-17052, push it down vertically and check if three connectors are connected firmly.

SE-17052 can be removed from IE-17K by lifting it up vertically. (See Fig. 4-5)

Fig. 4-4 External view of IE-17K (after removing the external cover)





Fig. 4-5 Installation and removal of SE-17052



After installing SE-17052, turn on the power of IE-17K before installing the inside cover and the external cover. And check if the LED on SE-17052 lights.

The LED does not light in the following cases.

- No connection of the IE-17K power cord
- Over-current in SE-17052 (about 500 mA and more)
- Incorrect installing of SE-17052

If the LED does not light, turn off the power of IE-17K and take out SE-17052 and then reinstall it. If it does not light yet, the trouble may occur.

Next, connect the probe (EP-17052CW) to the connectors J1 and J2 on SE-17052 in order to connect to the target system.

Finally, install the inside cover and the external cover.

(5) Use of IE-17K

Connecting IE-17K to the host machine of PC-9800 series and so on, IE-17K can be used to debug the hardware and the software of the target system. With regard to the operation of IE-17K, refer to "IE-17K USER'S MANUAL".

The procedure to check if SE-17052 is correctly installed is described below.

By turning on the power or pressing the RESET switch of IE-17K when the power is already supplied, IE-17K is activated and displays a prompter (@@>) which indicates the command is acceptable. Next, by .LP command load the HEX file (.HEX) of the μ PD17052CW program made by the assembler (AS17K) or the HEX file output by .SP command. IE-17K does not operate till the HEX file is loaded. If SE-17052 is correctly installed to IE-17K, the following messages are displayed and a prompter is "BRK>".

And then IE-17K becomes the in-circuit emulator for μ PD17052CW.

```
OK
D17052

BRK>
```


When the above messages are not displayed, the causes seem as follows.

- If the device other than μ PD17052CW is mounted on SE-17052, the following error message is displayed.

? IDI INVALID DEVICE ID NUMBER [XX-0B]

“0B” indicates the device number of μ PD17052CW and “XX” indicates the actually mounted device number.

- If the SE board other than SE-17052 is installed, the following error message is displayed.

? ISE INVALID SE BOARD NUMBER [XX-0B]

“0B” indicates the SE board of SE-17052 and “XX” indicates the actually installed SE board number.

- If the HEX file other than the μ PD17052CW is loaded, the following error message is displayed.

? IDI INVALID SE BOARD NUMBER [0B-XX]

“0B” indicates the SE board of SE-17052 and “XX” indicates the SE board number of SE board that corresponds to the loaded HEX file.

- In case that SE-17052 is not installed to IE-17K correctly. When loading the HEX file by .LP command, after for a while, without the response from IE-17K, there is a possibility of the incorrect installing of SE-17052.

In case of the incorrect installing of SE-17052, reinstall it correctly. And also when loading the HEX file other than the μ PD17052CW, load the HEX file of the μ PD17052CW again.

(6) NOTE

- When turning on the power, turn on the power to IE-17K and then the target system.
- Never use the RESET switch on SE-17052. When resetting IE-17K, use the RESET switch on IE-17K.


4.2 HOW TO USE SE-17052 ALONE

(1) DIP SWITCH(SW2) SETTING

The DIP switch(SW2) selects that the CE signal of μ PD17052CW is pulled up or not. When pulled up, it is set as shown in Fig. 4-6. When not pulled up, it is set as shown in Fig. 4-7.


Pull up the CE signal when the CE signal is not supplied from the target system. The CE signal need not be pulled up when the CE signal is supplied from the target system.


Fig. 4-6 SW2 setting (when pulled up)



NOTE:  is the setting side.

Fig. 4-7 SW2 setting (when not pulled up)



NOTE:  is the setting side.

When SE-17052 is shipped, the DIP switch(SW2) is set as shown in Fig. 4-7.

(2) PROM mounting

When using SE-17052 alone, mount the PROM (μ PD27C256D) as a program memory. Mount the PROM that accepts the following condition.

$$T_{ACC} < 0.5 \mu s$$

(T_{ACC} : Address setting \rightarrow Data output delay time)

μ PD27C256D-15, 20 and 25 are available.

It is required to write whichever output file as below into the PROM as a program.

- PROM file (.PRO) for μ PD17052CW made by the assembler (AS17K) for μ PD17000 series.
Never write the HEX file (.HEX) made by AS17K into the PROM.
- File for the PROM made by .XS command of IE-17K.


[Note for PROM writing]


The last program memory address of the μ PD17052CW is 1FFFH.

(3) ROM/RAM change jumper switch settings

Set the ROM/RAM change jumper switches to the ROM side as shown in Fig. 4-8.

Fig. 4-8 ROM/RAM change jumper switch setting



NOTE:  is the connecting position.

(4) Power supply

SE-17052 is supplied with the power from the target system via the probe (EP-17052CW) or from the CN11 on SE-17052.

When using the CN11, two ways are provided. When the power that is supplied from the CN11 would be supplied to the target system, connect the power source (+side) to the pin No 2 of the CN11 and GND to the pin No 1 of the CN11. At this time the power is also supplied to the target system via the probe.

When the power that is supplied from the CN11 would not be supplied to the target system, connect the power source(+side) to the pin No 3 of the CN11 and GND to the pin No 1 of the CN11.

The power supply voltage must be $5\text{ V} \pm 5\%$.

When the power is supplied normally, the LED on SE-17052 lights.

The LED does not light in the following cases.

- No supplying power to SE-17052
- Over-current in SE-17052 (about 500 mA and more)


(5) Program executing

Connect the target system to SE-17052 as shown in Fig. 4-9.

Starting to supply the power to target system, the power is supplied to SE-17052 and the POWER-ON-RESET procedure is activated and the program written in the PROM is executed from the location 0.

By pressing the RESET switch on SE-17052, SE-17052 is reset forcibly. As same as the POWER-ON-RESET procedure, the program written in the PROM is executed from the location 0.


Fig. 4-9 Example of connection of SE-17052 to the target system



4.3 ADJUSTING OF OSCILLATING FREQUENCY

The oscillating frequency is set to 8 MHz \pm 20 ppm as shipped. When the adjusting of oscillating frequency would be performed, adjust it by using the trimmer capacitor (C10) on SE-17052. With regard to the measurement of oscillating frequency, use the CH11 pin on SE-17052.

Fig. 4-10 Adjusting of oscillating frequency




4.4 ADJUSTING OF OSCILLATING FREQUENCY FOR IDC

On SE-17052, the LC oscillating circuit (OSC) for IDC (Image Display Controller) is implemented. When using this circuit, disconnect the jumper switches JP7 and JP8 that connect the OSC_{IN} and OSC_{OUT} pins of μ PD17052CW to the target system. The jumper switches JP7 and JP8 are not connected as shipped.

When the adjusting of oscillating frequency for IDC would be performed, adjust it by using the trimmer capacitor on SE-17052 as shown in Fig. 4-11.

When the OSC_{IN} and OSC_{OUT} pins of μ PD17052CW would be connected to the target system, connect the jumper switched JP7 and JP8 and remove the coil.

Fig. 4-11 Adjusting of oscillating frequency for IDC




4.5 MONITOR PINS

On SE-17052 the monitor pins are provided in order to examine the status of the following pins of μ PD17052CW. The monitor pin layout shows in Fig. 4-12.

Monitor Pin Name	Pin Name of IC (Pin No.)
CH9	CE (13)
CH11	CKOUT (μ PD65200)


Fig. 4-12 Monitor Pin Layout



4.6 SETTINGS AS SHIPPED


When SE-17052 is shipped, the settings of IC2 (the program memory), the ROM/RAM change jumper switches, SW2 and the crystal oscillator are as below.

- IC2 (Program memory)
The RAM (μ PD43256C-12) is mounted.
- ROM/RAM change jumper switches
They are set so as to use the RAM as a program memory.



NOTE: is the connecting position.

- SW2
It is set so that the CE signal is not pulled up.



NOTE: is the setting side.

- Crystal oscillator
It is adjusted to 8 MHz \pm 20 ppm.

CHAPTER 5 CONNECTOR PIN TABLES

5.1 CONNECTOR (J1) FOR PROBE

J1 Pin No.	Pin Name (Pin No. of IC)	J1 Pin No.	Pin Name (Pin No. of IC)	J1 Pin No.	Pin Name (Pin No. of IC)
1	GND	21	GND	41	GND
2	V _{DD} (14)	22	P1B ₁ (11)	42	PWM ₃ (23)
3	GND	23	GND	43	GND
4	P1D ₃ (1)	24	P1B ₀ (12)	44	PWM ₂ (24)
5	P1D ₂ (2)	25	GND	45	GND
6	P1D ₁ (3)	26	CE (13)	46	PWM ₁ (25)
7	GND	27	GND	47	GND
8	P1D ₀ (4)	28	OSC _{OUT} (15)	48	PWM ₀ (26)
9	GND	29	GND	49	GND
10	P2A ₃ (5)	30	OSC _{IN} (16)	50	X _{OUT} (27)
11	GND	31	GND	51	GND
12	P2A ₂ (6)	32	P1A ₃ (18)	52	X _{IN} (28)
13	GND	33	GND	53	GND
14	P2A ₁ (7)	34	P1A ₂ (19)	54	RED (29)
15	GND	35	GND	55	GND
16	P2A ₀ (8)	36	P1A ₁ (20)	56	GREEN (30)
17	GND	37	GND	57	GND
18	P1B ₃ /TMIN (9)	38	P1A ₀ (21)	58	BLUE (31)
19	GND	39	GND	59	GND
20	P1B ₂ (10)	40	PWM _{RMP} (22)	60	BLANK (32)


5.2 CONNECTOR (J2) FOR PROBE

J2 Pin No.	Pin Name (Pin No. of IC)	J2 Pin No.	Pin Name (Pin No. of IC)	J2 Pin No.	Pin Name (Pin No. of IC)
1	GND	21	GND	41	GND
2	RMC (64)	22	P0C ₂ (52)	42	POA ₀ /SDA (42)
3	ADC ₀ (63)	23	GND	43	GND
4	P0D ₀ /ADC ₁ (62)	24	P0C ₃ (51)	44	POA ₁ /SCL (41)
5	GND	25	GND	45	GND
6	P0D ₁ /ADC ₂ (61)	26	P2C ₀ (50)	46	POA ₂ /SCK (40)
7	P0D ₂ /ADC ₃ (60)	27	GND	47	GND
8	P0D ₃ /ADC ₄ (59)	28	P2C ₁ (49)	48	POA ₃ /SO (39)
9	GND	29	GND	49	GND
10	P1C ₀ /ADC ₅ (58)	30	P2C ₂ (48)	50	POB ₀ /SI (38)
11	GND	31	GND	51	GND
12	P1C ₁ /ADC ₆ (57)	32	P2C ₃ (47)	52	POB ₁ (37)
13	GND	33	GND	53	GND
14	P1C ₂ /ADC ₇ (56)	34	P2B ₀ (46)	54	POB ₂ (36)
15	GND	35	NGD	55	GND
16	P1C ₃ (55)	36	P2B ₁ (45)	56	POB ₃ /HSCNT (35)
17	GND	37	GND	57	GND
18	P0C ₀ (54)	38	P2B ₂ (44)	58	$\overline{H}_{\text{SYNC}}$ (34)
19	GND	39	GND	59	GND
20	P0C ₁ (53)	40	P2B ₃ (43)	60	$\overline{V}_{\text{SYNC}}$ (33)

CHAPTER 6 EXTERNAL FORM OF PROBE

Model name: EP-17052CW

Fig. 6-1 External form of probe



Phase-out/Discontinued

Phase-out/Discontinued

NEC