

RL78/G1C

USB PCDC for Cubesuite+

APPLICATION NOTE

R01AN1749EG0100 Rev.1.00 Nov 11, 2013

Introduction

The purpose of this Application Note is to show the user how to add the associated RL78/G1C sample code to a new or existing CubeSuite+ workspace; as well as give an explanation of what the sample code does.

This sample demonstrates the use of the RL78/G1C as a USB peripheral using the CDC Abstract Model for serial port emulation. Refer to r01an0555ej0200.pdf for full details of the code.

Target Device

RL78/G1C

Development environment

IDE: Cubesuite+ Compiler: CA78K0R Hardware: Renesas Starter Kit for RL78/G1C

Contents

1.	Installation	. 2
	Creating the Project Workspace	
	Opening Sample Code and Source Files	
	Source Code Functionality	
5.	Code Execution	. 5




1. Installation

This section assumes CubeSuite+ IDE is already installed on the user's personal computer (PC). Create a new folder and name it as 'RSKRL78G1C_Workspace'. Copy the zipped file 'an_r01an1749eg0100_rl78g1c_usb.zip', available in the Application Note package downloaded from the website, to this folder. Extract 'an_r01an1749eg0100_rl78g1c_usb.zip' file to the RSKRL78G1C_Workspace folder.

2. Creating the Project Workspace

Open CubeSuite+ IDE by clicking the Windows Start button, select All Programs > Renesas Electronics CubeSuite+ > CubeSuite+.






From the menu bar select File > Project > Open Project...

🕼 CubeSuite+ - [Start]								
File Edit View	Project Build Debug Tool Window Help							
🕴 🚳 Start 🛃	💈 Create New Project							
🖥 🔂 🔛 1	Open Project							
Project Tree	Favorite Projects							

CubeSuite+ will open a dialog.

Navigate to the unzipped USB_PCDC folder located in RSKRL78G1C_Workspace. Select the USB_PCDC.mtpj file.

Click < Open>



A Progress Status dialog will appear briefly whilst CubeSuite+ loads the project.

Progress Stat	rus 📃
	Loading project
	Cancel



3. Opening Sample Code and Source Files

Once the project has been opened, the source code and all dependant files can be opened in the editor by expanding the folders in the Project Tree window and double clicking the files listed. All files have been grouped according to their file type.

<pre>E Edit Geve Dryot Euki Debug Tek Window Edp 2 ant 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2</pre>	JSB_PCDC - CubeSuite+ - (Descript	on.txt)										
article article												
Image: Structure 9 X INSERCT: Comparised Image: Structure INSERCT: Structure Image: Structure INSERCT: Structure Image: Structure INSERCT: Structure Image: Structure Instance Image: Structure Instancomparison Image: Structure<		B S C B	the we	× .	1	G G A	(1) (1) (1) (1) (1)	D (D 11) 631 (C	1 °2 15			
With Construction Columns* USE ECCC.Charles Columns* Image: Construction Columns* Image: Constructis Columns*	And the second s											_
UBB_PCCC (Project) UBB_PCCC (Arrows (Beward Tool) CANARM (Beward Tool) CANARM (Beward Tool) Controllery												3
PSFLNDC CMACCCONNOLOGY CATARMA (Build Tool) Control (Build	and the second se	30 20 -	0.00	olumns*								
Breadist,PCDC.bt 36 - 1. Compile the sample code and download to the RSK. Click the 'Restart' Description.bt 37 - button to start program execution. 38 -	CATSUNC (Microcontroller) CATSUNC (Microcontroller) CATSUNC (Neurocontroller) CATSUNC (Neurocontroller) Rel 19 E1(Senis) (Debug Tool) Program Ansiyter (Ansiyter File Senithing Songlithin Catsure (Senithing) Songlithin Truth_pedic_drive Senithing Truth_pedic_drive Senithing Truth_pedic_drive Senithing Truth_pedic_drive Senithing	1 - 2 - 2 - 3 - 3 - 3 - 5 - 7 - 9 - 10 - 112 - 12 - 13 - 14 - 15 - 12 - 13 - 14 - 15 - 12 - 22 - 23 - 24 - 26 - 26 - 26 - 26 - 27 - 28 - 29 - 20 - 21 - 22 - 23 - 24 - 2	INCLAIMER INCLAIMER INCLAIMER INCLAIMENT INCLAIMENT INTED TO WHITE INTED TO WHITE INTED TO WHITE INTED TO WHITE INTER TO WHITE INTER TO WHITE INTER INTER TO WHITE INTER TO	use with Re owned by Res 1 1 start, inc 1 start, inc 2 st	ness produce esss Electron Huding copyri NERCHANTABIL STANTED NOT P NOR ANY OF IT NOR ANY OF IT IS SOFTWARE, SOFTWAR	5. No other using the laws. Renersh MARE to OR STATUTO (NY, FITHESS ITTS ARE EXPERIMENT SONIBITED BY IS AFFILIATED OF CONTRACT SONIBITED BY IS AFFILIATED OF CONTRACT CONDITION OF A CONTRACT CONDITION OF A CONTRACT S COPPORTS OF A CONTRACT S CO	res are authors and is prot s No MARABATTE NY, INCLUDING ISSLY DISCLAIM CAM, NEITHER R COMPARIES SHALL AND NESCUENTIAL D SO ITS AFFI e changes to t c. By using t bund by access . All rights r the RL78/GIC del for seria 11 details of i to the R5K.	<pre>ited. This ected under S REGARDING BUT NOT AR PURPOSE ED. ENTENSS L BE LIABLE SANAGES FOR LIATES HAVE his software, ing the eserved. */ eserved. */ eserved. */ contemport eserved. */ contemport eserved</pre>	tart'	able,		
							m					
		and a state of the										
Duby		12081										
Cut_periodin	ш	+ All Messag	es /									_
Configuration in the second se	FP	9	£4	165	FB	FT	FB	F9	FIL	FD	682	

4. Source Code Functionality

The source code project is specifically written to run on the appropriate RSK. However this source code can be useful as an example even without the RSK.

The project was written using source files containing API functions generated using Code Generator. The project will contain a C source file 'r_cg_main.c'. This source file includes the C function main(). All source files and dependant files whose filenames are prefixed with 'r_' were generated using Application Leading Tool.



5. Code Execution

Demonstrates the use of the RL78/G1C as a USB peripheral using the CDC Abstract Model for serial port emulation. Refer to r01an0555ej0200.pdf for full details of the code.

Operation:

1. Compile the sample code and download to the RSK. Click the 'Go' button to start program execution.

2 Connect the RSK to a Windows PC USB port using a USB type-A to type-B mini cable.

3. Press SW2 to enter STOP mode - press any switch to exit. Windows Device Manager and locate the device 'CDC USB Demonstration', which should be marked with an exclamation mark. Right-click and select 'Update Driver Software' and 'Browse my computer for driver software'. Browse to the folder reference\cdc_inf under this project's root folder and click 'Next'. Select 'Install this driver anyway'. The driver should install successfully and be shown in Device Manager under Port (COM & LPT)->CDC USB Demonstration(COMX), where X should be a number in the range 1-99.

4. Use a terminal emulation program such as Hyperterminal, Teraterm or PuTTY and connect to COMX using 19200 baud, 8-bit data, no parity and 1 stop bit.

5. Type anything into the terminal emulation window, the characters will be received via the USB COM port and echoed back to the terminal Window.

Reference:

Refer to the application notes r01an0326ej0200.pdf "Renesas USB MCU USB Basic Firmware Mini" and r01an0555ej0200.pdf "USB Peripheral Communications Device Class Driver (PCDC) for Basic Firmware mini".



Website and Support

Renesas Electronics Website <u>http://www.renesas.com/</u>

Inquiries

http://www.renesas.com/contact/

All trademarks and registered trademarks are the property of their respective owners.



Revision History

		Description	on
Rev.	Date	Page	Summary
1.00	Nov 11, 2013		First edition issued

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accord with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.
- 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.
 In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.
 In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at
 - which resetting has been specified.
- 3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access
 these addresses; the correct operation of LSI is not guaranteed if they are accessed.
- 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal.
 Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.
- 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

— The characteristics of an MPU or MCU in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

- 1. Descriptions of circuits. software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herei
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or
- technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
- "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the se of Renesas Electronics products beyond such specified ranges

7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult please evaluate the safety of the final products or systems manufactured by you.

- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assume no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics

RENESAS

SALES OFFICES

Renesas Electronics Corporation

http://www.renesas.com

California Eastern Laboratories, Inc. 4590 Patrick Henry Drive, Santa Clara, California 95054, U.S.A Tel: +1-408-919-2500, Fax: +1-408-988-0279

Refer to "http://www.renesas.com/" for the latest and detailed information

Renesas Electronics Europe Limited Dukes Meadow, Milibard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K Tel: +44-1628-651-700, Fax: +44-1628-651-804

Renesas Electronics Europe GmbH Arcadiastrasse 10, 40472 D üsseldorf, Germa Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd. 7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd. Unit 301, Tower A, Central Towers, 555 LanGao Rd., Putuo District, Shanghai, China Tei: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong Tei + 852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd. 13F, No. 363, Fu Shing North Road, Taipei, Taiwan Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hylfux Innovation Centre Singapore 339949 Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd. Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tei: +60-37955-9309, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd. 12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea Tel: +82-2-558-3737. Fax: +82-2-558-5141