

Renesas RA Family

Standard Boot Firmware for the RA family MCUs Based on Arm® Cortex®-M33

Introduction

This document describes the Standard Boot Firmware Specifications for RA family MCUs flash memory based on Arm Cortex-M33 flash memory. Make sure you understand the target devices and FPSYS / FACI specifications before reading this document. We do not guarantee the operation of any usage not described in this document.

Target Device

Product Group-A (Hereafter referred to as GrpA)

- RA4M2 Group
- RA4M3 Group
- RA6M4 Group
- RA6M5 Group

Product Group-B (Hereafter referred to as GrpB)

- RA4E1 Group
- RA6E1 Group

Product Group-C (Hereafter referred to as GrpC)

- RA6T2 Group

Product Group-D (Hereafter referred to as GrpD)

- RA4E2 Group
- RA6E2 Group
- RA4T1 Group
- RA6T3 Group

Contents

| | |
|-----------------------------------------------------------------------------------------------------|-----|
| 1. Definition of term | 2 |
| 2. System Architecture | 5 |
| 3. Communication Method..... | 7 |
| 4. General Procedure | 10 |
| 5. Packet Format | 18 |
| 6. Command List | 22 |
| 7. Flow examples..... | 102 |
| 8. AC characteristics..... | 111 |
| 9. FACI command list | 112 |
| 10. Precaution list..... | 113 |
| 11. Cause for operation stop | 113 |
| 12. Cause for software reset | 113 |
| General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products | 1 |
| Notice..... | 1 |

1. Definition of term

A definition of the terminology used in this specification is indicated below.

1. [Boot firmware](#)
2. [Flash memory](#)
3. [Secure / Non-secure / Non-secure callable](#)
4. [Device Lifecycle management \(DLM\)](#)
5. [Block Protection](#)

1.1 Boot firmware

The program included in the microcontroller to rewrite the flash memory is called Boot firmware.


1.2 Flash memory

The following areas are collectively called flash memory.

- Code flash : The ROM area where program code is written (FLP/FLI)
- Data flash : The ROM area where data is written (EEP)

The Code flash area used by user is called "User area", the Data flash area used by user is called "Data area", and the area to store configuration data is called "Config area". The boot firmware rewrites and reads these User areas, Data area, and Config area according to commands given by the user.

Example of 1 MB flash memory structure (memory structure will differ from device to device)



1.3 Secure / Non-secure


The Renesas Advanced (RA) Family MCUs have the attributes of secure and non-secure. In particular, the memory area is divided into two exclusive areas, a secure area and a non-secure area. The CPU core has two secure states, a secure state and a non-secure state, and the secure state of the CPU changes depending on the secure attribute of the memory where the execution code exists. When the CPU core processes the execution code in the secure area, it is in the secure state, and when it processes the execution code in the non-secure area, it is in the non-secure state. Then, without going through special procedures, the CPU core transitions from the non-secure state to the secure state, or the CPU core is in the non-secure state and accesses the memory in the secure area. By preventing it by the mechanism of the CPU core, it bears a part of the security function of the Renesas Advanced (RA) Family MCUs.

The boot firmware specifies a secure area and a non-secure area for the User area, Data area, and SRAM by a user command.

1.4 Device Lifecycle Management (DLM) for GrpA, GrpB, and GrpC

RA family MCUs based on Arm Cortex-M33 microcontrollers adopt the concept of device life cycle and maintain the life cycle state inside the device.

The boot firmware controls the executable commands and the range of operations that can be performed with each command in each lifecycle state. In addition, it has a user-executable command as the only way to transition lifecycles.



| DLM state name | Description |
|----------------|---------------------------------------------|
| CM | Chip Manufacturing. |
| SSD | Secure Software Development. |
| NSECSD | Non-SECure Software Development. |
| DPL | DePLoyed. |
| LCK_DBG | LoCKed DeBuG. |
| LCK_BOOT | LoCKed BOOT interface. |
| RMA_REQ | Return Material Authorization REQuest. |
| RMA_ACK | Return Material Authorization ACKnowledged. |

1.5 Block Protection

Block protection refers to a function that prohibits erasing/writing the specified range of Flash memory. The specified range is done in blocks, and there are two types of protection listed below.

| Types of protection | Description |
|-----------------------------------|---------------------------------------------------------------------------------------------------|
| Block protection (BPS) | Protection that can temporarily enable erasing/writing by the register setting of flash sequencer |
| Permanent block protection (PBPS) | Protection that permanently disables erasing/writing |

2. System Architecture

Boot firmware has a serial programming interface that sends and receives flash control commands between the microcontroller and the host in serial programming mode. Boot firmware is embedded into the device.

2.1 GrpA(RA4M2, RA4M3, RA6M4, RA6M5), GrpB(RA4E1, RA6E1), GrpC(RA6T2), and GrpD(RA4E2, RA6E2, RA4T1, RA6T3) groups

This chapter describes the system architecture regarding the flash memory control.


2.1.1 Operating environment

| | |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CPU core | Arm Cortex-M33 |
| Max. CPU operating frequency | RA4M2, RA4M3, RA4E1: 100MHz (Boot firmware operating frequency: 100MHz) RA6M4, RA6M5, RA6E1: 200MHz (Boot firmware operating frequency: 100MHz) RA6T2: 240MHz (Boot firmware operating frequency: 100MHz) RA4E2, RA4T1 : 100MHz (Boot firmware operating frequency: 60MHz) RA6E2, RA6T3 : 200MHz (Boot firmware operating frequency: 60MHz) |
| Clock Source | RA4M2/3, RA6M4/5, RA4E1/2, RA6E1/2, RA4T1, RA6T3 8, 10, 16, 20, 24 MHz, * If neither is set, operates with HOCO * However, a Main-OSC whose frequency is around plus-minus 3% or less of the frequency above is set, there is a possibility that the frequency is misjudged and therefore USB communication fails. To avoid this, it is recommended to choose any of the followings when using USB communication. - Use a Main-OSC whose frequency is the very value listed above - Not use a Main-OSC and also use a Sub-OSC whose frequency is supported by the device's specifications • RA6T2 HOCO 20MHz (Doesn't use Main-OSC) |
| Operating voltage | VCC = 2.7 to 3.6 V |
| Operating mode | Boot mode |
| Flash memory | <ul style="list-style-type: none"> Code flash User area: 256KB(Max.) : RA4E2, RA6E2, RA4T1, RA6T3 512 KB(Max.) : RA4M2, RA4E1, RA6T2 1 MB(Max.) : RA4M3, RA6M4, RA6E1 2 MB(Max.) : RA6M5 Data flash 4KB : RA4E2, RA6E2, RA4T1, RA6T3 8KB(Max.) : RA4M2, RA4M3, RA6M4, RA6M5, RA4E1, RA6E2 16KB : RA6T2: |
| RAM | 40KB : RA4E2, RA6E2, RA4T1, RA6T3 64KB : RA6T2 128KB : RA4M2, RA4M3, RA4E1 256KB : RA6M4, RA6E1, RA6M5 |

| Communication method | Method | GrpA GrpB | GrpC | GrpD | |
|------------------------------|-------------------------------------|--------------|------|------|--|
| | 2-wire UART communication | | | | |
| | (Initial/Min) 9600 bps (Max) 6 Mbps | ✓ | ✓ | | |
| | (Initial/Min) 9600 bps (Max) 2 Mbps | | | ✓ | |
| | USB communication* 12 Mbps | ✓ | | ✓ | |
| SWD communication (Max) 6MHz | | | ✓ | | |

* When performing USB communication with HOCO, Sub-OSC must be oscillating stably.
* USB communication is confirmed under the condition that the host OS is Windows 10.

2.1.2 Block diagram



*1: GrpC doesn't support.

*2: GrpD supports


3. Communication Method

Boot firmware has interfaces for the following communication methods:

| | GrpA, GrpB | GrpC | GrpD |
|----------------------------------------------------------|------------|------|------|
| 2-wire UART communication | ✓ | ✓ | ✓ |
| Universal Serial Bus (USB) communication | ✓ | | ✓ |
| SWD communication | | | ✓ |

3.1 2-wire UART communication

Boot firmware supports the 2-wire UART communication.



General settings


| | | |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|
| Interface | SCI (ch9) | |
| RxD | <ul style="list-style-type: none"> • (GrpA, GrpB, GrpD) P110, Input mode • (GrpC) PA15, Input mode | |
| TxD | <ul style="list-style-type: none"> • (GrpA, GrpB, GrpD) P109, Output mode • (GrpC) PB03, Output mode | |
| Transfer rate | 9600bps | (Min, until the baud rate setting command) |
| Data length | 8 bits | (LSB first) |
| Parity bit | none | |
| Stop bit | 1 bit | |

Communication is performed at 9600bps until the transfer rate setting command. After the baud rate setting command is completed normally, communication is performed at the desired transfer rate. The maximum transfer rate that can be communicated with the device is returned by “RMB” of the signature request command.

* If the communication cable is disconnected during communication, subsequent operations are not guaranteed.

3.2 Universal Serial Bus (USB) communication

Boot firmware supports the USB communication.



General settings

Interface USBFS

VBUS P407, Input mode

D+ Input-Output mode

D- Input-Output mode

Transfer rate 12 Mbps (USB2.0 Full Speed)

Device class Communication Device Class (CDC)
SubClass : Abstract Control Model (ACM)
Protocol : Common AT commands

Vender ID 0x045B (Renesas)

Product ID 0x0261

Transfer mode Control (in/out)
Bulk (in, out)
Interrupt (in)


End point :

| | GrpA, GrpB | GrpC | GrpD |
|--------------------------------------------------|------------|------|------|
| Default control pipe, Control transfers (in/out) | EP0 | N/A | EP0 |
| TxD pipe, Bulk transfers (in) 64 bytes | EP1 | N/A | EP4 |
| RxD pipe, Bulk transfers (out) 64 bytes | EP2 | N/A | EP5 |
| Control pipe, Interrupt transfers (in) | EP6 | N/A | EP6 |

- * If the USB cable is disconnected during communication, subsequent operations are not guaranteed.
- * When performing USB communication, the host is notified as self power mode.
- * USB boot does not guarantee operation with bus power (when rewriting with bus power, please execute it after verifying sufficiently by users).
- * GrpC does not support USB communication.

3.3 SWD communication

Boot firmware supports the SWD communication. SWD communication is enabled by setting a magic code in the JBMDR register during terminal reset.



General settings

| | |
|---------------|-------------------------|
| [SWD] SWCLK | P300, Input mode |
| [SWD] SWDIO | P108, Input-Output mode |
| Transfer rate | 6MHz (Max) |
| Data length | 32bit |
| Magic code | 0xA5 |

[Endien of transmission and reception data]

Store the data transmitted from the Host in the JBRDR register by 4 bytes in order from the lower byte.

The data transmitted from the Microcontroller is stored in the JBTDR register by 4 bytes in order from the lower byte.

[example: 1byte data transmission from the Host to the Microcontroller]

sending data: 0x55

| JBRDR[31:24] | JBRDR[23:16] | JBRDR[15:8] | JBRDR[7:0] |
|--------------|--------------|-------------|------------|
| Don't care | Don't care | Don't care | 0x55 |

[example: 7byte data transmission from the Microcontroller to the Host]

sending data: 0x00, 0x01, 0x02, 0x03

| JBTDR[31:24] | JBTDR[23:16] | JBTDR[15:8] | JBTDR[7:0] |
|--------------|--------------|-------------|------------|
| 0x03 | 0x02 | 0x01 | 0x00 |

sending data: 0x04, 0x05, 0x06

| JBTDR[31:24] | JBTDR[23:16] | JBTDR[15:8] | JBTDR[7:0] |
|--------------|--------------|-------------|------------|
| Don't care | 0x06 | 0x05 | 0x04 |

[Communication handshake]

Host and microcontroller perform handshake by using JBSTR register in SWD communication.

Host must check JBSTR.RDF=0 before writing data to JBRDR, and JBSTR.TDE=0 before reading data from JBTDR.

However, this handshake is omittable when transmitting and receiving 5th-byte or after in a packet(*), namely host can write JBRDR and read JBTDR without checking JBSTR.

*) 5th-byte or after in a packet means the following specifically.

| | |
|-----------------------|---------------------------|
| Command packet | Command information - ETX |
| Data packet | Data - ETX |


Only GrpD supports SWD communication.

4. General Procedure

Boot firmware transits in the following order after the reset release. This sequence is non-invertible.

1. [Initialization phase](#)
2. [Communication setting phase](#)
3. [Command acceptable phase](#)

4.1 Sequence diagram (Generic sequence)




*1 From the Command acceptable phase, the host and microcontroller send data in turn unless otherwise noted. The host executes data transmission after data reception from the microcontroller.

*2: If the magic code "0xA5" is set in the JBMDR register during a pin reset, the microcontroller will boot into SWD mode.


GrpC supports only UART communication, and only GrpD supports SWD communication.

4.2 State transition diagram (generic state transition)

(GrpA, GrpB, and GrpC)



(GrpD)



4.3 Cause for operation to stop

The boot firmware enters an infinite loop in the following cases:

- When DLM state transitions to LCK_BOOT
- When DLM state transitions due to the Authentication command (after replying with completion status)
- When DLM state transits to SSD with the Initialize command (after replying with completion status)
- When DLM state has an abnormal value after DLM state transition
- When Trusted system goes into an abnormal state
- When the USB cable is disconnected with the USB status of “Configured” for GrpA and GrpB
- When the following CPU exceptions occur:
NMI / HardFault / MemManage / BusFault / UsageFault / SecureFault / SVCcall / DebugMonitor / PendSV / SysTick
- When Main-OSC and Sub-OSC are not oscillating at the specified frequency

4.4 Cause for software reset

Boot firmware performs software reset in the following cases.

- When the DLM state is LCK_BOOT after startup
- When DLM state is abnormal after startup
- When MD = 1 is detected during communication mode judgement

4.5 Initialization phase

Boot firmware initializes hardware modules in this phase. After that, boot firmware transits to the “Communication setting phase”.

4.5.1 Processing procedure

Boot firmware initializes after reset release.

- Boot firmware initializes hardware modules, and transits to the “Communication setting phase”.

The following features are only available in GrpD.

- If the operation mode is debug mode, debug mode processing is performed.
If the stored ID[127:126] in the device is not 11b, boot firmware sets to standby mode and become an infinite loop.
If the stored ID[127:126] in the device is 11b, boot firmware erases all the flash memory, and if the erasure succeeds, sets sleep mode and enters an infinite loop.
Also, if erasing fails, boot firmware sets to standby mode and enters an infinite loop.

If there is a block with permanent block protection, boot firmware sets to standby mode without executing all erasure, enters an infinite loop.

Also, if the FSPR in the config area is set 0, boot firmware sets to standby mode without executing all erasure, enters an infinite loop.

* Flash memory status does not change before command reception.

4.6 Communication setting phase

The boot firmware establishes communication with the host in this phase. Check the connection of each communication method under the conditions shown in the table below. After receiving the generic code using the established communication method, the boot firmware transitions to the "Command acceptable phase".

| Condition | Communication method | GrpA | GrpB | GrpC | GrpD |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|------|------|------|------|
| - Data "0x00" was continuously received 3 times by 2-wire UART communication | 2-wire UART communication | ✓ | ✓ | ✓ | ✓ |
| - Data "0x00" was continuously received 3 times by USB communication | USB communication | ✓ | ✓ | | ✓ |
| - DBGSTR.CDBGPWRUPREQ=1 is set during terminal reset - Magic code "0xA5" was set in the JBMDR register during terminal reset - MD pin level is High | SWD communication | | | | ✓ |


4.6.1 Processing procedure

Boot firmware performs communication settings.

- When all the following conditions are met, the boot firmware will perform a software reset.
 - MD=1
 - JBMDR ≠ 0xA5 (Only GrpD)
- When all the following conditions are met, JTAG/SWD communication is determined to be selected for GrpD.
 - * When JTAG/SWD communication is selected, wait for Generic code without waiting for 0x00.
 - MD=1
 - JBMDR=0xA5
- When JTAG/SWD communication is not selected or not supported, waiting for 0x00 to be received.
 - If 00h is received continuously for 3 bytes in either 2-wire UART communication(GrpA, GrpB, GrpC, GrpD) or USB communication(GrpA, GrpB, GrpD), "ACK" is transmitted. (* data is received until the communication mode is determined)
 - * The time from when reset is released until 0x00 can be received is shown [AC characteristics](#).
- After that, when Generic code is received, it sends a "Boot code".
 - If a code other than generic code is received, it will wait to receive Generic code again.
 - * The time from when reset is released until Generic code can be received is shown [AC characteristics](#).
- The boot firmware transitions to the "Command acceptable phase" when the transmission of "Boot code" is completed.

4.6.2 Settings of the 2-wire UART communication (For GrpA, GrpB, GrpC, and GrpD)

When the device operating mode is serial programming mode, the boot firmware initializes SCI and waits for reception. By receiving 0x00 three times consecutively, it is determined that asynchronous 2-wire communication is selected as the communication method. Before receiving 3 bytes, if data other than 0x00 is received or some data is received from USB, the count value will be reset. (without GrpC due to not support USB communication)



* Boot firmware of GrpA, GrpB, and GrpC outputs High from TxD after SCI initialization. Boot firmware of GrpD enables pull-up of TxD after SCI initialization, and outputs High from TxD after 3-byte 00h reception. After SCI initialization, the boot firmware outputs High from TxD.


By performing the following procedure, communication establishment is completed and the process moves to the "Command acceptable phase".

1. Receive 3 bytes of 0x00 data (9600 bps) from the host
(Perform 0x00 data transmission until ACK is received in step 2).
2. Send 0x00 data (ACK) from boot firmware.
3. Receive 0x55 data (generic code) from the host.
4. Send 0xC6 data (boot code) from boot firmware.

* If ACK is not returned even after sending 0x00 data, check the communication environment and try again from reset release.

4.6.3 Settings of the USB communication (For GrpA, GrpB, and GrpD)

When the device's operating mode is serial programming mode, the boot firmware configures the USB into an enumerable state. Set the data communication start by USB configured status detection. By receiving 0x00 three times consecutively, it is determined that USB communication is selected as the communication method. Before receiving 3 bytes, if data other than 0x00 is received or some data is received from UART, the count value will be reset.




By performing the following procedure, communication establishment is completed and the process moves to the 'Command acceptable phase'.

1. When the boot firmware detects the USB configured state, the USB communication start setting is performed.
 2. Receive 3 bytes of 0x00 data from the host
(Perform 00h data transmission until ACK is received in step 3.)
 3. Send 0x00 data (ACK) from boot firmware.
 4. Receive 0x55 data (generic code) from the host.
 5. Send 0xC6 data (boot code) from boot firmware.
- * If ACK is not returned even after sending 0x00 data, check the communication environment and try again from reset release.

4.6.4 Settings of the SWD communication (For GrpD)

When the boot firmware detects MD=1 and JBMDR=0xA5, establish communication with SWD communication.



By performing the following procedure, communication establishment is completed and the process moves to the "Command acceptable phase".

1. Assert the terminal reset
2. Set 1 to CSW.DBGSWENBLE
3. Set 1 to DBGSTR.CDBGPWRUPREQ
4. Wait until DBGSTR.CDBGPWRUPACK becomes 1
5. Set 0xA5 to JBMDR
6. Release the terminal reset
7. If MD detects 1 after following the above procedure, the boot firmware will set the SWD communication start setting
8. Receive 0x55 data (Generic code) from the host
9. Send 0xC6 data (Boot code) from the boot firmware

Moreover, follow the steps below to disconnect SWD communication with boot firmware.

1. Assert the terminal reset
2. Set 0x00 to JBMDR
3. Set 0 to DBGSTR.CDBGPWRUPREQ
4. Wait until DBGSTR.CDBGPWRUPACK becomes 0
5. Set 0 to CSW.DBGSWENBLE

4.7 Command acceptable phase

Boot firmware accepts the commands on this phase.

4.7.1 Processing procedure

When the boot firmware receives a command packet, it performs packet analysis.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the CMD in the received command packet is an undefined code, the boot firmware sends an "Unsupported command error"
- .
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.

When the processing above is successfully completed, boot firmware executes command processing. (Refer to explanation of [each command](#) for detail)

- When a command is normally finished boot firmware stays on the "Command acceptable phase".

5. Packet Format

Be sure to follow this format.

1. [Command packet](#)
2. [Data packet](#)

<Elements in the packet>

- CMD : [Command code](#)
- RES : [Response code](#)
- STS : [Status code](#)
- DLM : [Device Lifecycle Management state code](#)
- FST : [Flash status](#)
- ADR : [Failure address](#)

5.1 Command packet

The host sends data of a command packet to microcontroller by the following format.

| Symbol | Size | Value | Description |
|---------------------|----------------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SOH | 1 byte | 0x01 | Start of command packet |
| LNH | 1 byte | - | Packet length (length of "CMD + command information") [High] |
| LNL | 1 byte | - | Packet length (length of "CMD + command information") [Low] |
| CMD | 1 byte | - | Command code |
| Command information | 0 to 255 bytes | - | Command information e.g.) For write command: Start/End address e.g.) For erase command: Start/End address e.g.) For DLM state transit command: Source/Destination DLM state code (DLM) (DLM is supported on GrpA, GrpB, and GrpD) e.g.) for Baudrate setting command: UART baudrate |
| SUM | 1 byte | - | Sum data of "LNH + LNL + CMD + Command information" (expressed as two's complement) e.g.) LNH + LNL + CMD + Command information(1) + Command information(2) + ... + Command information(n) + SUM = 0x00 |
| ETX | 1 byte | 0x03 | End of packet |

*1: If the host sends data that exceeds 261 bytes, subsequent operations are not guaranteed.

5.2 Data packet

Host and boot firmware send data to each other by the following format.

| Symbol | Size | Value | Description |
|--------|--------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SOD | 1 byte | 0x81 | Start of data packet |
| LNH | 1 byte | - | Packet length (length of "RES + Data") [High] (*1) |
| LNL | 1 byte | - | Packet length (length of "RES + Data") [Low] (*1) |
| RES | 1 byte | - | Response code |
| Data | (*3) | - | Transmit data e.g.) For write data transmission: Write data e.g.) For status transmission: Status code (STS), Status detail (ST2), and Failure address (ADR) e.g.) For DLM state requesting: DLM state code (DLM) |
| SUM | 1 byte | - | Sum data of "LNH + LNL + RES + Data" (expressed as two's complement) e.g.) LNH + LNL + RES + Data(1) + Data(2) + ... + Data(n) + SUM = 0x00 |
| ETX | 1 byte | 0x03 | End of packet |

*1: If the host sends a packet whose length is 0 byte or over 1025 bytes, the microcontroller will return a packet with indefinite RES value.

*2: If the host sends data that exceeds 1030 bytes, subsequent operations are not guaranteed.

*3: The size is 1~1024byte.

5.3 CMD : Command code

| Value | Device | | | Name | Description |
|-------|--------------|------|------|----------------------------------|------------------------------------------------------|
| | GrpA GrpC | GrpB | GrpD | | |
| 0x71 | ✓ | ✓ | | DLM state transit command | Authentication-free DLM transition |
| 0x30 | ✓ | ✓ | ✓ | Authentication command | DLM transition for authentication |
| 0x28 | ✓ | ✓ | | Key setting command | Insert the key |
| 0x2A | ✓ | | | User key setting command | Insert the user custom key |
| 0x29 | ✓ | ✓ | | Key verify command | Verify the key |
| 0x2B | ✓ | | | User key verify command | Verify the user custom key |
| 0x50 | ✓ | ✓ | | Initialize command | Initialize all User area, Data area, and Config area |
| 0x2C | ✓ | ✓ | | DLM state request command | Request the current DLM state |
| 0x4E | ✓ | ✓ | | Boundary setting command | Set the boundary |
| 0x4F | ✓ | ✓ | | Boundary request command | Get the boundary setting |
| 0x51 | ✓ | ✓ | | Parameter setting command | Set the parameter |
| 0x52 | ✓ | ✓ | | Parameter request command | Get the parameter setting |
| 0x00 | ✓ | ✓ | ✓ | Inquiry command | Return ACK |
| 0x3A | ✓ | ✓ | ✓ | Signature request command | Get the signature information |
| 0x3B | ✓ | ✓ | ✓ | Area information request command | Get the area information |
| 0x34 | ✓ | ✓ | ✓ | Baud rate setting command | Set baud rate (only UART) |
| 0x12 | ✓ | ✓ | ✓ | Erase command | Erase data on target area |
| 0x13 | ✓ | ✓ | ✓ | Write command | Write data to target area |
| 0x15 | ✓ | ✓ | ✓ | Read command | Read data from target area |
| 0x18 | ✓ | ✓ | ✓ | CRC command | Cyclic Redundancy Check of target area |

5.4 RES : Response code

| Value | Name | Description |
|------------|------------------------------|-------------|
| 0x00 CMD | OK (ongoing normally) | - |
| 0x80 CMD | ERR (occurrence of an error) | - |

5.5 STS : Status code

| Value | GrpA GrpB GrpC | GrpD | Name | Description |
|-------|----------------------|------|----------------------------------|-----------------------------------------------------------------------------|
| 0x00 | ✓ | ✓ | Communication is normal [OK] | - |
| 0xC0 | ✓ | ✓ | Unsupported command error | (*1), Received an unsupported command |
| 0xC1 | ✓ | ✓ | Packet error | (*1), Abnormality of packet format |
| 0xC2 | ✓ | ✓ | Checksum error | (*1), Abnormality of packet's checksum value |
| 0xD0 | ✓ | ✓ | Parameter error | (*1), Abnormality of packet parameter |
| 0xD5 | ✓ | ✓ | Command acceptance error | (*1), A command cannot execute in current state (*4) |
| 0xD6 | ✓ | | DLM state unmatched error | (*1), Different from info2's value and DLMON register's value |
| 0xD7 | ✓ | | Hardware error | (*1), Abnormality of flash memory (DLM state) value |
| 0xDA | ✓ | ✓ | Protection error | (*1), Accessing protected areas or performing prohibited actions. |
| 0xE4 | ✓ | | Secure error | (*1), Included "Secure area" as targets for erase, write, and key injection |
| 0xDB | ✓ | ✓ | Trusted system error | (*1), Abnormality from the Trusted system(TSIP) |
| 0xDD | | ✓ | ID discord error | (*1), ID authentication failed. |
| 0xDE | | ✓ | Serial programming disable error | (*1), If serial programming is disabled. (stored ID[127] = 0) |
| 0xE5 | ✓ | ✓ | Flash access error | (*1), (*2), (*3), Abnormality from the Flash sequencer |

*1: When this error occurs, response code (RES) will be ERR.

*2: Boot firmware also returns the Status details (ST2) and the failure address (ADR) as additional error information.

*3: This error occurs when the flash sequencer becomes "command lock" state after execution flash sequencer command.

*4: GrpA, GrpB, GrpC : DLM state, GrpD : ID authentication state

5.6 DLM : Device Lifecycle Management state code (GrpD is not supported)

| Value | Name | Description |
|-------|----------|--------------------------------------------|
| 0x01 | CM | Chip Manufacturing |
| 0x02 | SSD | Secure Software Development |
| 0x03 | NSECSD | Non-Secure Software Development |
| 0x04 | DPL | DePLoyed |
| 0x05 | LCK_DBG | LoCKed DeBuG |
| 0x06 | LCK_BOOT | LoCKed BOOT interface |
| 0x07 | RMA_REQ | Return Material Authorization REQuEst |
| 0x08 | RMA_ACK | Return Material Authorization ACKnowledged |

5.7 ST2 : Status details

| Value | Name | Description |
|--------------|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FSTATR[31:0] | Flash Status | When a flash access error occurs, boot firmware returns the value of the FSTATR register. When not, boot firmware returns 0xFFFFFFFF. Boot firmware clears the FSTATR register after the status sending, so even when Error occurs, host can retry the next command without reset release. |

5.8 ADR : Failure address

| Value | Name | Description |
|---------------------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0x00000000h to 0xFFFFFFFF | Failure address | When a flash access error occurs, boot firmware returns the value of the start address of the flash sequencer command. When not, boot firmware returns 0xFFFFFFFF. |

6. Command List

| Name | Device (*1) | | | DLM state(*2) for GrpA, GrpB, and GrpC | | | | | | | ID Authentication for GrpD | |
|--------------------------------------------------|-------------|------|------|----------------------------------------|-----|---------|-----|---------|----------|---------|----------------------------|---------------|
| | GrpA GrpC | GrpB | GrpD | CM | SSD | NSEC SD | DPL | LCK_DBG | LCK_BOOT | RMA_REQ | Unauthenticated | Authenticated |
| DLM state transit command | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | | | |
| Authentication command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | (*3) | ✓ | (*4) | |
| Key setting command | ✓ | ✓ | | | ✓ | ✓ | | | (*3) | | | |
| User key setting command | ✓ | | | | ✓ | ✓ | | | (*3) | | | |
| Key verify command | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | |
| User key verify command | ✓ | | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | |
| Initialize command | ✓ | ✓ | | | ✓ | ✓ | ✓ | | (*3) | | | |
| DLM state request command | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | |
| Boundary setting command | ✓ | ✓ | | | ✓ | | | | (*3) | | | |
| Boundary request command | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | |
| Parameter setting command | ✓ | ✓ | | | ✓ | ✓ | ✓ | | (*3) | | | |
| Parameter request command | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | |
| Inquiry command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | | ✓ |
| Signature request command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | ✓ | ✓ |
| Area information request command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | ✓ | ✓ |
| Baud rate setting command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | ✓ | ✓ |
| Erase command | ✓ | ✓ | ✓ | | ✓ | ✓ | | | (*3) | | | ✓ |
| Write command | ✓ | ✓ | ✓ | | ✓ | ✓ | | | (*3) | | | ✓ |
| Read command | ✓ | ✓ | ✓ | | ✓ | ✓ | | | (*3) | | | ✓ |
| CRC command | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | (*3) | ✓ | ✓ | ✓ |

*1 : The command is available in the device. If an unavailable command is sent, boot firmware returns “Unsupported command error”.


*2 : The command is available in the state. If an unavailable command is sent, boot firmware returns “Command acceptance error”.

*3 : LCK_BOOT state never transits to the command acceptable phase because boot firmware executes software reset in the initialization phase.

*4 : Available when ID(Bit127 = 0b1) is set and ID is unauthenticated.

6.1 Device Lifecycle Management (GrpA, GrpB, and GrpC)

The following DLM state transitions can be triggered by each command:




6.2 DLM state transit command (GrpA, GrpB, and GrpC)

This command transitions the DLM state without authentication. The boot firmware is hung when the DLM state transitions to LCK_BOOT.

This command requires adherence to conditions described in [Command List](#).

6.2.1 Sequence diagram



6.2.2 Packets**6.2.2.1 Command packet**

| | | |
|-------|----------|--------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x03 |
| CMD | (1 byte) | 0x71 (DLM state transit command) |
| SDLM | (1 byte) | Source DLM state code |
| DDL M | (1 byte) | Destination DLM state code |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.2.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x71 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0x8D |
| ETX | (1 byte) | 0x03 |

6.2.2.3 Data packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xF1 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.2.2.4 Data packet [status ERR] (Flash access error in disclosed area)

| | | |
|-----|-----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xF1 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | FFFFFFFFh (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.2.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a “Command acceptance error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the command acceptance analysis is successfully completed, boot firmware analyzes the parameters.

- When SDLM is different from the current DLM state, boot firmware returns “Parameter error”.
- When DDLM is a DLM state that cannot transition from the current DLM state without authentication, boot firmware returns “Parameter error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the parameter analysis has successfully completed, boot firmware transitions to the DLM state.

- If an error occurs during transition to the DLM state, a “Flash access error” is returned but waits for the next command.
 - * Check the DLM state after the Flash access error occurred with the DLM state request command.
- If the DLM state after the transition is an invalid value, the boot firmware sends a “Hardware error” and becomes unresponsive.
Also, if the DLM state after transition is LCK_BOOT, the boot firmware sends “OK” and does not respond.
- When the DLM state transitions successfully, “OK” is returned and waits for the next command.


6.2.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in the current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| SDLM is different from the current DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| DDLm is not transitionable to DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after command execution in a nondisclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| DLM state is abnormal. | Hardware error | 0xFFFFFFFF | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.2.5 DLM state transition

The following shows the DLM state that can be transit by this command.



6.3 Authentication command

[Command outline for GrpA, GrpB, and GrpC](#), [Command outline for GrpD](#)


6.3.1 Command outline for GrpA, GrpB, and GrpC

This command authenticates using a key and transition the DLM state. Authentication is executed by the challenge and response method. Boot firmware erases the flash memory when the DLM state transits to RMA_REQ. Erase processing at this time is not affected by the block protection settings (BPS, BPS_SEC).

This command requires adherence to conditions described in [Command List](#).

GrpA, GrpB : Response = HMAC-SHA256(Key, 128-bit challenge || Fixed value(256bit));
GrpC : Response = AES-128 CMAC(Key, 128-bit challenge);

6.3.2 Sequence diagram for GrpA, GrpB, and GrpC



6.3.3 Packets for GrpA, GrpB, and GrpC**6.3.3.1 Command packet**

| | | | |
|-------|----------|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x04 | |
| CMD | (1 byte) | 0x30 (Authentication command) | |
| SDLM | (1 byte) | Source DLM state code | |
| DDLML | (1 byte) | Destination DLM state code | |
| CHCT | (1 byte) | Authentication type | 0x00 : Random number (can be used in all transit cases.) 0x01 : MCU unique ID (can be used only in transit to RMA_REQ.) |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.3.3.2 Data packet [Challenge value or Unique ID]

| | | | |
|------|------------|------------------------------|-------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x11 | |
| RES | (1 byte) | 0x30 (OK) | |
| CHCD | (16 bytes) | Challenge value or Unique ID | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 0x23, 0x45, ... , 0x55, 0x66, 0x77 |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.3.3.3 Data packet [Response value or Authentication code]

| | | | |
|-----|--------------------|---------------------------------------|-------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x21 | |
| RES | (1 byte) | 0x30 (OK) | |
| MAC | (32 bytes) (*1) | Response value or Authentication code | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 0x23, 0x45, ... , 0x55, 0x66, 0x77 |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

*1: Please fill "1" to lower 16 byte of MAC on Data Packet due to calculated Response by AES-128 CMAC in GrpC is 16 bytes .

6.3.3.4 Data packet [status OK]

| | | | |
|-----|-----------|--------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x30 (OK) | |
| STS | (1 byte) | 0x00 (OK) | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | 0xCE | |
| ETX | (1 byte) | 0x03 | |

6.3.3.5 Data packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xB0 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.3.3.6 Data packet [status ERR] (Flash access error in disclosed area)

| | | |
|-----|-----------|------------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xB0 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details e.g.) FSTATR[31:0] = 0x0120A000 -> 0x01, 0x20, 0xA0, 0x00 |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.3.3.7 Data packet [status ERR] (Flash access error in not disclosed area)

| | | |
|-----|-----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xB0 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.3.4 Processing procedure for GrpA, GrpB, and GrpC

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
* Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a “Command acceptance error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the command reception analysis ends normally, the boot firmware performs DLM state analysis.

- If the currently active DLM state does not match the stored DLM state, the boot firmware sends a “DLM state unmatched error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware analyzes the parameters.

- When SDLM is different from the current DLM state, boot firmware returns “Parameter error” after 5 seconds.
- When DDLM is a DLM state that cannot transit from the current DLM state with authentication, boot firmware returns “Parameter error” after 5 seconds.
- When CHCT is not of challenge type that can be used for transition of DLM state, boot firmware returns “Parameter error” after 5 seconds.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the parameter analysis has successfully completed, boot firmware sends data packet [Challenge value or Unique ID].

- If the Challenge value / Unique ID is successfully generated, the boot firmware sends the value.
- If the Trusted system becomes abnormal after the Challenge value / Unique ID generation, the boot firmware returns nothing and no response.
- * Flash memory status does not change before command reception.
- If the Challenge value / Unique ID generation fails, the boot firmware sends a “Trusted system error” and returns to the command wait state.
 - * Flash memory status does not change before command reception.

When sending the data packet [Challenge value or Unique ID] has successfully completed, boot firmware receives and analyzes a data packet [Response value or Authentication code].

- Boot firmware detects the beginning of a data packet by receiving SOD.
When boot firmware receives other data than SOD, it discards the data and waits for the next data until SOD is sent.
- When the received data packet does not have ETX, “Packet error” is returned after 5 seconds.
- When SUM in the received data packet is different from the value calculated by boot firmware, “Checksum error” is returned after 5 seconds.
- When LNH and LNL in the received data packet do not comply with the packet format, “Packet error” is returned after 5 seconds.
- When RES in the received data packet is different from defined values, “Packet error” is returned after 5 seconds.
- When LNH and LNL in the received data packet do not comply with the specifications of this command, “Packet error” is returned after 5 seconds.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware authenticates with received Response value or Authentication code.

- If the Trusted system becomes abnormal after authentication, the boot firmware returns nothing and no response.
- * Flash memory status does not change before command reception.
- When authentication fails, "Trusted system error" is returned and waits for the next command.
 - * Flash memory status does not change before command reception.

When authentication has successfully completed and DLM state transit to RMA_REQ, boot firmware erases the flash memory.

- * This command erases the flash memory even if initialization is disabled. Refer to the Parameter request command.
- If an error occurs during erasure in the Block protect the setting, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * The value of the Block protect setting is undefined.
- If an error occurs during erasure in the User area, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * The value of the area after ADR (failure address) of the User area is undefined.
- If an error occurs during erasure in the Data area, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * The value of the Data area is undefined.
- If an error occurs during erasure in the Config area, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * The value of the Config area is undefined.
- If an error occurs during boundary setting and key index (wrapped key) erasure in the User area, the boot firmware sends a "Flash access error" and returns to the command wait state.

When the Authentication has successfully completed (when transition to RMA_REQ, erase of flash memory is also successful), boot firmware transits the DLM state.

- If an error occurs during transition of the DLM state, "Flash access error" is returned but waits for the next command.
 - * Check the DLM state after the Flash access error occurred with the DLM state request command.
- If the DLM state after the transition is an invalid value, the boot firmware sends a "Hardware error" and becomes unresponsive.
- If the specified error does not occur, the boot firmware sends "OK" and becomes unresponsive.
 - * When the DLM state transitions to RMA_REQ, each area of the flash memory is in the following state:
 - User area is erased except for the following:
 - Blocks for which "0" is set for permanent block protection setting (PBPS, PBPS_SEC)
 - * Not affected by block protection settings (BPS, BPS_SEC)
 - All Data areas are erased
 - The Config area is written with "1" except for the following:
 - Permanent block protection setting (PBPS, PBPS_SEC)
 - Block protection setting (BPS, BPS_SEC) for block which "0" is set for permanent block protection setting (PBPS, PBPS_SEC)
 - Secure Attribute setting for block protection (BPS_SEL)
 - FSPR and BTFLG when FSPR = 0


6.3.5 Status information from microcontroller for GrpA, GrpB, and GrpC

(listed in descending order of priority)

| Condition | STS | FST | ADR |
|--------------------------------------------------------------------------------------------|-------------------------------------------|------------------------------|---------------------------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| The currently active DLM state does not match the stored DLM state. | DLM state unmatched error | 0xFFFFFFFF | 0xFFFFFFFF |
| SDLM is different from current DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| DDLML is not transitionable DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| CHCT is a nonexistent challenge type. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Challenge value/Unique ID generation failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| The RES of the received data packet is different from the value specified by this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Authentication failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after the command execution in disclosed area. | Flash access error | Flash status | Failure address |
| FACI detected an error after command execution in a nondisclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| DLM state is abnormal. | Hardware error | 0xFFFFFFFF | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.3.6 DLM state transition for GrpA, GrpB, and GrpC

The following diagram shows the DLM state that can be transit by this command.



6.3.7 Command outline for GrpD


This command compares the ID-code stored in the microcontroller with the ID-code received from the flash programmer, and sends the result to the flash programmer. If the received ID code is "ALeRASE(*1)", all areas of the flash memory are erased without ID authentication. Erase processing at this time is not affected by the block protection settings (BPS, BPS_SEC). This command cannot be executed if the ID-code stored in the microcontroller is all "1". Also, this command cannot be executed after successful authentication until reset if the ID-code stored in the microcontroller is NOT all "1".

This command require adherence to conditions described in Command List.

*1: "ALeRASE" = 0x41, 0x4C, 0x65, 0x52, 0x41, 0x53, 0x45, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF

| Condition | | Processing |
|-------------------------------|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| stored ID[127:0] = All "1" | | Non-secure device -> Return to command acceptance (Other commands become executable) |
| stored ID[127] = 0b | | Serial programming disable -> Serial programming disable error (Enter an infinite loop) |
| stored ID[127:126] = 10b | | ID authentication when ID mismatch -> ID discord error (Enter an infinite loop) when ID match -> Return to command acceptance (Other commands become executable) |
| stored ID[127:126] = 11b | received ID != "ALeRASE" | |
| stored ID[127:126] = 11b | received ID = "ALeRASE" | All area erasure when FSPR = 0 -> Protection error (Enter an infinite loop) when Error occurred -> Flash access error (Enter an infinite loop) when Successful erasure -> Return to command acceptance (Other commands become executable) |

6.3.8 Sequence diagram for GrpD



6.3.9 Packets for GrpD

6.3.9.1 Command packet

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|------------|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|------|------|------|-----------|--|--|--|------|------|------|------|------|------|------|------|-----------|--|--|--|----------|--|--|--|------|------|------|------|------|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|------|------|------|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|------|------|------|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| SOH | (1 byte) | 0x01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LNH | (1 byte) | 0x00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LNL | (1 byte) | 0x11 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CMD | (1 byte) | 0x30 (Authentication command) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IDC | (16 bytes) | ID code | e.g.) If stored ID is as follows, the Host should send IDC in order shown in the lower table. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <p>stored ID:</p> <table border="1"> <tr> <td colspan="4">ID[127:96]</td> <td colspan="4">ID[95:64]</td> </tr> <tr> <td>0xF0</td><td>0xF1</td><td>0xF2</td><td>0xF3</td> <td>0xE4</td><td>0xE5</td><td>0xE6</td><td>0xE7</td> </tr> <tr> <td colspan="4">ID[63:32]</td> <td colspan="4">ID[31:0]</td> </tr> <tr> <td>0xD8</td><td>0xD9</td><td>0xDA</td><td>0xDB</td> <td>0xCC</td><td>0xCD</td><td>0xCE</td><td>0xCF</td> </tr> </table> <p>Order of sending IDC for ID authentication:</p> <table border="1"> <tr> <td>1st</td><td>2nd</td><td>3rd</td><td>4th</td><td>5th</td><td>6th</td><td>7th</td><td>8th</td> </tr> <tr> <td>0xF0</td><td>0xF1</td><td>0xF2</td><td>0xF3</td><td>0xE4</td><td>0xE5</td><td>0xE6</td><td>0xE7</td> </tr> <tr> <td>9th</td><td>10th</td><td>11th</td><td>12th</td><td>13th</td><td>14th</td><td>15th</td><td>16th</td> </tr> <tr> <td>0xD8</td><td>0xD9</td><td>0xDA</td><td>0xDB</td><td>0xCC</td><td>0xCD</td><td>0xCE</td><td>0xCF</td> </tr> </table> <p>e.g.) for All area erasure, the Host should send "ALeRASE" as IDC.</p> <p>Order of sending IDC for All area erasure:</p> <table border="1"> <tr> <td>1st</td><td>2nd</td><td>3rd</td><td>4th</td><td>5th</td><td>6th</td><td>7th</td><td>8th</td> </tr> <tr> <td>0x41</td><td>0x4C</td><td>0x65</td><td>0x52</td><td>0x41</td><td>0x53</td><td>0x45</td><td>0xFF</td> </tr> <tr> <td>9th</td><td>10th</td><td>11th</td><td>12th</td><td>13th</td><td>14th</td><td>15th</td><td>16th</td> </tr> <tr> <td>0xFF</td><td>0xFF</td><td>0xFF</td><td>0xFF</td><td>0xFF</td><td>0xFF</td><td>0xFF</td><td>0xFF</td> </tr> </table> | ID[127:96] | | | | ID[95:64] | | | | 0xF0 | 0xF1 | 0xF2 | 0xF3 | 0xE4 | 0xE5 | 0xE6 | 0xE7 | ID[63:32] | | | | ID[31:0] | | | | 0xD8 | 0xD9 | 0xDA | 0xDB | 0xCC | 0xCD | 0xCE | 0xCF | 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | 0xF0 | 0xF1 | 0xF2 | 0xF3 | 0xE4 | 0xE5 | 0xE6 | 0xE7 | 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | 0xD8 | 0xD9 | 0xDA | 0xDB | 0xCC | 0xCD | 0xCE | 0xCF | 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | 0x41 | 0x4C | 0x65 | 0x52 | 0x41 | 0x53 | 0x45 | 0xFF | 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF |
| ID[127:96] | | | | ID[95:64] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0xF0 | 0xF1 | 0xF2 | 0xF3 | 0xE4 | 0xE5 | 0xE6 | 0xE7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ID[63:32] | | | | ID[31:0] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0xD8 | 0xD9 | 0xDA | 0xDB | 0xCC | 0xCD | 0xCE | 0xCF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0xF0 | 0xF1 | 0xF2 | 0xF3 | 0xE4 | 0xE5 | 0xE6 | 0xE7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0xD8 | 0xD9 | 0xDA | 0xDB | 0xCC | 0xCD | 0xCE | 0xCF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x41 | 0x4C | 0x65 | 0x52 | 0x41 | 0x53 | 0x45 | 0xFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | 0xFF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SUM | (1 byte) | Sum data | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ETX | (1 byte) | 0x03 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

6.3.9.2 Data packet [status OK]

| | | |
|-----|----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x30 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 byte) | 0xFFFFFFFF (unused code) |
| ADR | (4 byte) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.3.9.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xB0 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.3.10 Processing procedure for GrpD

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
* Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware executes the acceptance analysis.

- No setting OCD/Serial ID, or already authenticated, the boot firmware sends a "Command acceptance error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
* Flash memory status does not change before command reception.

Boot firmware checks for "Serial programming disable error" after the processing above.

- When bit 127 of the ID code stored in the device is 0, boot firmware sends a "Serial programming disable error" and finishes command processing.
Boot firmware does not accept any commands nor response for the commands after sending this error.
* Flash memory status does not change before command reception.

When no error occurs, boot firmware decides whether to execute ID code authentication.

- Boot firmware execute ID code authentication when at least one of the following conditions are met.
 - Bit 126 of the ID code stored in the device is 0b0
 - Bit 126 of the ID code stored in the device is 0b1 but received IDC is not "ALeRASE"
- When ID code authentication fails, boot firmware sends "ID discord error" and finishes command processing.
Boot firmware does not accept any commands nor response for the commands after sending this error.
* Flash memory status does not change before command reception
- When ID code authentication passes, boot firmware send "OK" and finishes command processing.
Then boot firmware transits to Command acceptable phase and wait for the next command.
* Flash memory status does not change before command reception

When no error occurs and also ID code authentication is not executed, boot firmware executes flash memory all erasure.

- If there is a permanent protected block, boot firmware send "Protection error" and does not execute all erasure but finishes command processing.
Boot firmware does not accept any commands nor response for the commands after sending this error.
* Flash memory status does not change before command reception
- When FSPR in Config area is set, e.g. the value is 0, boot firmware send "Protection error" and does not execute all erasure but finishes command processing.
Boot firmware does not accept any commands nor response for the commands after sending this error.
* Flash memory status does not change before command reception
- If the above error does not occur, boot firmware execute all erasure.
- When all erasure fails, boot firmware receives a data packet and returns "Erase error", "Write error" or "Sequencer error" and finishes command processing.
Boot firmware does not accept any commands nor response for the commands after sending this error.
* Refer to Status code for conditions of the errors
* Flash memory area are undefined.
- When all erasure passes, boot firmware send "OK" and finishes command processing.
Then boot firmware transits to Command acceptable phase and wait for the next command.
* All flash memory area are erased state

6.3.11 Status information from microcontroller for GrpD

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|------------------------------|---------------------------------|
| The received packet doesn't have ETX. | Packet error | FFFFFFFFh | FFFFFFFFh |
| Sum data in the received packet is different from the value calculated by the boot firmware. | Checksum error | FFFFFFFFh | FFFFFFFFh |
| Packet length in the received packet do not comply with the packet format. | Packet error | FFFFFFFFh | FFFFFFFFh |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | FFFFFFFFh | FFFFFFFFh |
| No setting OCD/Serial ID, or already authenticated. ("Status OK" has been sent as a response to the command packet.) | Command acceptance error | FFFFFFFFh | FFFFFFFFh |
| If the Highest-order bit of stored ID is "0". | Serial programming disable error | FFFFFFFFh | FFFFFFFFh |
| The ID authentication fails. | ID discord error | FFFFFFFFh | FFFFFFFFh |
| Permanent block protection is set even in 1bit. | Protection error | FFFFFFFFh | FFFFFFFFh |
| The FSPR bit is set. (FSPR = 0) | Protection error | FFFFFFFFh | FFFFFFFFh |
| FACI detected an error after the command execution in disclosed area. | Flash access error | Flash status | Failure address |
| FACI detected an error after the command execution in not disclosed area. | Flash access error | Flash status | FFFFFFFFh |
| Successful completion. | OK | FFFFFFFFh | FFFFFFFFh |

6.4 Key setting command (GrpA, GrpB, and GrpC)

This command sets the authentication key to the device. The authentication key must be specified in the DLM state.

This command requires adherence to conditions described in [Command List](#).

6.4.1 Sequence diagram



6.4.2 Packets

6.4.2.1 Command packet

| | | |
|------|----------|-------------------------------------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x02 |
| CMD | (1 byte) | 0x28 (Key setting command) |
| KYTY | (1 byte) | Key type 0x01 : SECDBG_KEY 0x02 : NONSECDBG_KEY 0x03 : RMA_KEY |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.4.2.2 Data packet [key data]

| SOD | (1 byte) | 0x81 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|------------|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|------|------|------|--|--|--|--|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|--|--|--|--|--|--|--|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|------|------|------|------|-----|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| LNH | (1 byte) | 0x00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LNL | (1 byte) | 0x51 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| RES | (1 byte) | 0x28 (OK) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ESKY | (32 bytes) | Session key (W-UFPK) | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 0x23, 0x45, ... , 0x55, 0x66, 0x77 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IVEC | (16 bytes) | Initialization vector | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 23, 0x45, ... , 0x55, 0x66, 0x77 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EOKY | (32 bytes) | Install data (encrypted key MAC) | <p>Encrypted key (0-15 bytes) + MAC (16-31 bytes) e.g.) If install data is as follows, the host must send EOKY in the order shown in the table that follows:</p> <p>Install data:</p> <table border="1"> <thead> <tr> <th colspan="8">Encrypted key</th> </tr> </thead> <tbody> <tr> <td>0x00</td><td>0x01</td><td>0x02</td><td>0x03</td><td>0x04</td><td>0x05</td><td>0x06</td><td>0x07</td> </tr> <tr> <td>0x08</td><td>0x09</td><td>0x0A</td><td>0x0B</td><td>0x0C</td><td>0x0D</td><td>0x0E</td><td>0x0F</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="8">MAC</th> </tr> </thead> <tbody> <tr> <td>0x10</td><td>0x11</td><td>0x12</td><td>0x13</td><td>0x14</td><td>0x15</td><td>0x16</td><td>0x17</td> </tr> <tr> <td>0x18</td><td>0x19</td><td>0x1A</td><td>0x1B</td><td>0x1C</td><td>0x1D</td><td>0x1E</td><td>0x1F</td> </tr> </tbody> </table> <p>Order of sending EOKY:</p> <table border="1"> <thead> <tr> <th>1st</th><th>2nd</th><th>3rd</th><th>4th</th><th>5th</th><th>6th</th><th>7th</th><th>8th</th> </tr> </thead> <tbody> <tr> <td>0x00</td><td>0x01</td><td>0x02</td><td>0x03</td><td>0x04</td><td>0x05</td><td>0x06</td><td>0x07</td> </tr> <tr> <th>9th</th><th>10th</th><th>11th</th><th>12th</th><th>13th</th><th>14th</th><th>15th</th><th>16th</th> </tr> <tr> <td>0x08</td><td>0x09</td><td>0x0A</td><td>0x0B</td><td>0x0C</td><td>0x0D</td><td>0x0E</td><td>0x0F</td> </tr> <tr> <th>17th</th><th>18th</th><th>19th</th><th>20th</th><th>21st</th><th>22nd</th><th>23rd</th><th>24th</th> </tr> <tr> <td>0x10</td><td>0x11</td><td>0x12</td><td>0x13</td><td>0x14</td><td>0x15</td><td>0x16</td><td>0x17</td> </tr> <tr> <th>25th</th><th>26th</th><th>27th</th><th>28th</th><th>29th</th><th>30th</th><th>31st</th><th>32nd</th> </tr> <tr> <td>0x18</td><td>0x19</td><td>0x1A</td><td>0x1B</td><td>0x1C</td><td>0x1D</td><td>0x1E</td><td>0x1F</td> </tr> </tbody> </table> | Encrypted key | | | | | | | | 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 | 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F | MAC | | | | | | | | 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 | 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F | 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 | 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F | 17th | 18th | 19th | 20th | 21st | 22nd | 23rd | 24th | 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 | 25th | 26th | 27th | 28th | 29th | 30th | 31st | 32nd | 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F |
| Encrypted key | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAC | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17th | 18th | 19th | 20th | 21st | 22nd | 23rd | 24th | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25th | 26th | 27th | 28th | 29th | 30th | 31st | 32nd | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SUM | (1 byte) | Sum data | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ETX | (1 byte) | 0x03 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

6.4.2.3 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x28 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0xD6 |
| ETX | (1 byte) | 0x03 |

6.4.2.4 Data packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xA8 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.4.2.5 Data packet [status ERR] (Flash access error)

| | | |
|-----|-----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xA8 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.4.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a “Command acceptance error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the acceptance analysis has successfully completed, boot firmware executes the parameter analysis.

- When KYTY is not of Key type that can be set in the current DLM state, boot firmware returns “Parameter error” and waits for the next command.
 - * Flash memory status does not change before command reception.
- If the specified error does not occur, the boot firmware sends “OK”.

When parameter analysis has successfully completed, boot firmware received and analyzes data packet.

- Boot firmware detects the beginning of a data packet by receiving SOD.
When boot firmware receives other data than SOD, it discards the data and waits for the next data until SOD is sent.
- When the received data packet does not have ETX, “Packet error” is returned after 5 seconds.
- When SUM in the received data packet is different from the value calculated by boot firmware, “Checksum error” is returned.
- When LNH and LNL in the received data packet do not comply with the packet format, “Packet error” is returned.
- When RES in the received data packet is different from defined values, “Packet error” is returned.
- When the number of received data exceeds the value specified in the command in the received data packet, “Parameter error” is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware generates and set authentication key after parameter analysis.

- If the Trusted system becomes abnormal after creating a key index (wrapped key), the boot firmware returns nothing and no response.
 - * Flash memory status does not change before command reception.

- If creation of key index (wrapped key) fails, the boot firmware sends a “Trusted system error” and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware writes authentication key after key generation.

- If an error occurs while writing key index (wrapped key), the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * Use Key verify command to check the status of the key index (wrapped key) after Flash access error occurred.
- When authentication key setting has successfully completed, boot firmware returns “OK” and waits for the next command.

6.4.4 Status information from microcontroller


(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|-----------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in the current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| KYTY cannot set the current DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The RES of the received data packet is different from the value specified by this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| The total length of received data of data packets exceeds the value specified in the command. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Authentication key generated failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after command execution in a nondisclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.4.5 DLM state that can be set

The following table shows the DLM state that can be set for Key type.

| Key type | DLM state |
|---------------|-------------|
| SECDBG_KEY | SSD |
| NONSECDBG_KEY | SSD, NSECSD |
| RMA_KEY | SSD |




6.5 User key setting command (GrpA and GrpC)

This command generates key index (wrapped key) using session key (W-UFPK) and install data (encrypted key | MAC) received from the host, and saves it in the specified area. Write processing at this time is not affected by the block protection settings (BPS, BPS_SEC). The storage area must be erased in advance.

This command requires adherence to conditions described in [Command List](#).

6.5.1 Sequence diagram



6.5.2 Packets

6.5.2.1 Command packet

| | | | |
|------|-----------|---------------------------------|--------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x06 | |
| CMD | (1 byte) | 0x2A (User key setting command) | |
| KADR | (4 bytes) | Key setting address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| ENTY | (1 byte) | User key type | Reference to User key list |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.5.2.2 Data packet [key data (1st)]

| | | | |
|------|------------|------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | N + 49 (Higher 1 byte) | |
| LNL | (1 byte) | N + 49 (Lower 1 byte) | |
| RES | (1 byte) | 0x2A (OK) | |
| ESKY | (32 bytes) | Session key (W-UFPK) | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 0x23, 0x45, ... , 0x55, 0x66, 0x77 |
| IVEC | (16 bytes) | Initialization vector | e.g.) 0x01234567_89AB ... 2233_44556677 -> 0x01, 0x23, 0x45, ... , 0x55, 0x66, 0x77 |
| ENKY | (N byte) | Install data (encrypted key MAC) | e.g) If the key type is ECC P-192 Private Key, the host must send ENKY in the order shown in the table that follows. |

Install data:

| Encrypted Key | | | | | | | |
|---------------|------|------|------|------|------|------|------|
| 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 |
| 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F |
| 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 |
| 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F |
| MAC | | | | | | | |
| 0x20 | 0x21 | 0x22 | 0x23 | 0x24 | 25 | 0x26 | 0x27 |
| 0x28 | 0x29 | 0x2A | 0x2B | 0x2C | 2D | 0x2E | 0x2F |

Order of sending ENKY:

| 1st | 2nd | 3rd | 4th | 5th | 6th | 7th | 8th |
|------|------|------|------|------|------|------|------|
| 0x00 | 0x01 | 0x02 | 0x03 | 0x04 | 0x05 | 0x06 | 0x07 |
| 9th | 10th | 11th | 12th | 13th | 14th | 15th | 16th |
| 0x08 | 0x09 | 0x0A | 0x0B | 0x0C | 0x0D | 0x0E | 0x0F |
| 17th | 18th | 19th | 20th | 21st | 22nd | 23rd | 24th |
| 0x10 | 0x11 | 0x12 | 0x13 | 0x14 | 0x15 | 0x16 | 0x17 |
| 25th | 26th | 27th | 28th | 29th | 30th | 31st | 32nd |
| 0x18 | 0x19 | 0x1A | 0x1B | 0x1C | 0x1D | 0x1E | 0x1F |
| 33rd | 34th | 35th | 36th | 37th | 38th | 39th | 40th |
| 0x20 | 0x21 | 0x22 | 0x23 | 0x24 | 0x25 | 0x26 | 0x27 |
| 41st | 42nd | 43rd | 44th | 45th | 46th | 47th | 48th |
| 0x28 | 0x29 | 0x2A | 0x2B | 0x2C | 0x2D | 0x2E | 0x2F |

| | | | |
|-----|----------|----------|--|
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

N = 1 to 976

6.5.2.3 Data packet [key data (2nd to last)]

| | | | |
|------|----------|------------------------------------|---------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | N + 1 (Higher 1 byte) | |
| LNL | (1 byte) | N + 1 (Lower 1 byte) | |
| RES | (1 byte) | 0x2A (OK) | |
| ENTY | (N byte) | Install data (encrypted key MAC) | *Order of sending: Low -> ... -> High |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

N = 1 to 1024

6.5.2.4 Data packet [status OK]

| | | | |
|-----|-----------|--------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x2A (OK) | |
| STS | (1 byte) | 0x00 (OK) | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | 0xD4 | |
| ETX | (1 byte) | 0x03 | |

6.5.2.5 Data packet [status ERR] (except Flash access error)

| | | | |
|-----|-----------|-----------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0xAA (ERR) | |
| STS | (1 byte) | Status code | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.5.2.6 Data packet [status ERR] (Flash access error)

| | | | |
|-----|-----------|---------------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0xAA (ERR) | |
| STS | (1 byte) | 0xE5 | |
| ST2 | (4 bytes) | Status details | |
| ADR | (4 bytes) | Failure address | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.5.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a “Command acceptance error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the command acceptance analysis has successfully completed, boot firmware analyzes the parameters.

- If ENTY is not specified as Key type, the boot firmware sends a “Parameter error”.
- If the area for key index size from KADR is not included in the User area or Data area specified in the area information, the boot firmware sends a “Parameter error”.
- If the area from KADR to key index size is across different KOAs, the boot firmware sends a “Parameter error”.
- If the WAU for the specified area is 0, the boot firmware sends a “Parameter error”.
- If KADR is not specified in the WAU of the area, the boot firmware sends a “Parameter error”.
- If the current DLM state is NSECSD and the specified range includes a secure area, the boot firmware sends a “Secure error”.
- If the area for the key index size from KADR contains a block with permanent block protection, the boot firmware sends a “Protection error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.
- If the above error does not occur, the boot firmware sends “OK”.

When the DLM state check has successfully completed, boot firmware changes the DLM state.

- Boot firmware detects the beginning of a data packet by receiving SOD.
When boot firmware receives data other than SOD, it discards the data and waits for the next data until SOD is sent.
- When the received data packet does not have ETX, “Packet error” is returned after 5 seconds.
- When SUM in the received data packet is different from the value calculated by boot firmware, “Checksum error” is returned after 5 seconds.
- When LNH and LNL in the received data packet do not comply with the packet format, “Packet error” is returned after 5 seconds.
- When RES in the received data packet is different from defined values, “Packet error” is returned after 5 seconds.
- When the number of accumulated ENKY data exceeds the install data size indicated by ENTY in the received data packet, the boot firmware sends a “Parameter error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.
- If the key data has not been received, the boot firmware receives the next data packet.

When all key data has been received, the boot firmware generates a key index (wrapped key).

- If the Trusted system becomes abnormal after creating a key index (wrapped key), the boot firmware returns nothing and no response.
 - * Flash memory status does not change before command reception.
- If creation of key index (wrapped key) fails, the boot firmware sends a “Trusted system error” and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

If the key index (wrapped key) is successfully generated, the boot firmware writes the key index to the specified area.

- If an error occurs while writing key index (wrapped key), the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * WAU size from failure address (ADR) of flash memory area is undefined.
- If the key index (wrapped key) is successfully saved to the device, the boot firmware sends “OK” and returns to the command wait state.

6.5.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|--------------------------------------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|---------------------------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| ENTY is not specified as Key type. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The area from KADR to key index size does not fit in the range of User area and Data area specified by area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The area from KADR to key index size spans different KOA. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The key storage area WAU is 0. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| KADR is not specified in the WAU for the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The current DLM state is NSECSD and KADR contains a secure area. | Secure error | 0xFFFFFFFF | 0xFFFFFFFF |
| There is a block with permanent block protection in the area from KADR to key index size. | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| The RES of the received data packet is different from the value specified by this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| KDAT in the received packet is different from KLEN. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Key index (wrapped key) generation failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after the command execution. | Flash access error | Flash status | Failure address |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.5.5 User key list

The following table shows a list of user keys specified by this command.


| Key type | Device | | Installation key | Install data size (byte) | Key index size (byte) |
|----------|--------------|------|---------------------------|--------------------------|-----------------------|
| | GrpA GrpB | GrpC | | | |
| 0x05 | ✓ | ✓ | AES-128 | 32 | 36 |
| 0x06 | ✓ | | AES-192 | 48 | 52 |
| 0x07 | ✓ | ✓ | AES-256 | 48 | 52 |
| 0x08 | ✓ | ✓ | AES-128 XTS | 48 | 52 |
| 0x09 | ✓ | ✓ | AES-256 XTS | 80 | 84 |
| 0x0A | ✓ | | RSA-1024 Public Key | 160 | 292 |
| 0x0B | ✓ | | RSA-1024 Private Key | 272 | 404 |
| 0x0C | ✓ | | RSA-2048 Public Key | 288 | 548 |
| 0x0D | ✓ | | RSA-2048 Private Key | 528 | 788 |
| 0x0E | ✓ | | RSA-3072 Public Key | 416 | 420 |
| 0x0F | ✓ | | RSA-3072 Private Key | 784 | 788 |
| 0x10 | ✓ | | RSA-4096 Public Key | 544 | 548 |
| 0x11 | ✓ | | RSA-4096 Private Key | 1040 | 1044 |
| 0x12 | ✓ | | ECC P192 Public Key | 80 | 84 |
| 0x13 | ✓ | | ECC P192 Private Key | 48 | 52 |
| 0x14 | ✓ | | ECC P224 Public Key | 80 | 84 |
| 0x15 | ✓ | | ECC P224 Private Key | 48 | 52 |
| 0x16 | ✓ | | ECC P256 Public Key | 80 | 84 |
| 0x17 | ✓ | | ECC P256 Private Key | 48 | 52 |
| 0x18 | ✓ | | ECC P384 Public Key | 112 | 116 |
| 0x19 | ✓ | | ECC P384 Private Key | 64 | 68 |
| 0x1A | ✓ | | HMAC-SHA224 | 48 | 52 |
| 0x1B | ✓ | | HMAC-SHA256 | 48 | 52 |
| 0x1C | ✓ | | ECC P256r1 Public Key | 80 | 84 |
| 0x1D | ✓ | | ECC P256r1 Private Key | 48 | 52 |
| 0x1E | ✓ | | ECC P384r1 Public Key | 112 | 116 |
| 0x1F | ✓ | | ECC P384r1 Private Key | 64 | 68 |
| 0x20 | ✓ | | ECC P512r1 Public Key | 144 | 148 |
| 0x21 | ✓ | | ECC P512r1 Private Key | 80 | 84 |
| 0x22 | ✓ | | ECC secp256k1 Public Key | 80 | 84 |
| 0x23 | ✓ | | ECC secp256k1 Private Key | 48 | 52 |
| 0xFF | ✓ | ✓ | Key update key | 48 | 52 |

6.6 Key verify command (GrpA, GrpB, and GrpC)

This command verifies the authentication key that is set for the device.

This command requires adherence to conditions described in [Command List](#).

6.6.1 Sequence diagram



6.6.2 Packets

6.6.2.1 Command packet

| | | |
|------|----------|----------------------------------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x02 |
| CMD | (1 byte) | 0x29 (Key verify command) |
| KYTY | (1 byte) | Key type 0x01: SECDBG_KEY 0x02: NONSECDBG_KEY 0x03: RMA_KEY |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.6.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x29 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0xD6 |
| ETX | (1 byte) | 0x03 |

6.6.2.3 Data packet [status ERR]

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xA9 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.6.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the parameter analysis.

- If KYTY is an unsupported key type, the boot firmware sends a “Parameter error” and returns to the command wait state.
 - * Flash memory status does not change before command reception.

Boot firmware verifies the authentication key after parameter analysis.

- If verification of key index (wrapped key) fails, the boot firmware sends a “Trusted system error” and returns to the command wait state.
 - * Flash memory status does not change before command reception.
- If the verification of the key index (wrapped key) has completed successfully, the boot firmware sends “OK” and returns to the command wait state.
 - * Flash memory status does not change before command reception.

6.6.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|--------------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| KYTY is not supported key type. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Verification of the authentication key failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.7 User key verify command (GrpA and GrpC)

This command verifies the authentication key that is set for the device. The authentication key must be specified in the DLM state to be read.

This command requires adherence to conditions described in [Command List](#).

6.7.1 Sequence diagram



6.7.2 Packets

6.7.2.1 Command packet

| | | | |
|------|-----------|--------------------------------|--------------------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x06 | |
| CMD | (1 byte) | 0x2B (User key verify command) | |
| KADR | (4 bytes) | Key address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| ENTY | (1 byte) | User key type | Supports the same key type as User key setting command |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.7.2.2 Data packet [status OK]

| | | | |
|-----|-----------|--------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x2B (OK) | |
| STS | (1 byte) | 0x00 (OK) | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | 0xD6 | |
| ETX | (1 byte) | 0x03 | |

6.7.2.3 Data packet [status ERR]

| | | | |
|-----|-----------|-----------------------------|--|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0xAB (ERR) | |
| STS | (1 byte) | Status code | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.7.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the parameter analysis.

- If ENTY is not specified as key type, the boot firmware sends a “Parameter error”.
- If the area for key index size from KADR is not included in the User area or Data area specified in the area information, the boot firmware sends a “Parameter error”.
- If the area from KADR to key index size is across different KOAs, the boot firmware sends a “Parameter error”.
- If the WAU for the specified area is 0, the boot firmware sends a “Parameter error”.
- If KADR is not specified in the WAU of the area, the boot firmware sends a “Parameter error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware verifies the authentication key after parameter analysis.

- When there is a mismatch in the authentication key stored in the device, boot firmware returns “Trusted system error”.
 - * Flash memory status does not change before command reception.
- If the above error does not occur, the boot firmware sends “OK”.
 - * Flash memory status does not change before command reception.

6.7.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| ENTY is not specified as key type. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The area from KADR to key index size does not fit in the range of User area and Data area specified by area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Verify the authentication key failed. | Trusted system error | 0xFFFFFFFF | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.8 Initialize command (GrpA, GrpB, and GrpC)

This command clears the User area, Data area, Config area, boundary setting, and key index (wrapped key). In addition, the DLM state transitions to SSD. Erase processing at this time is not affected by the block protection settings (BPS, BPS_SEC).

This command requires adherence to conditions described in [Command List](#).

6.8.1 Sequence diagram



6.8.2 Packets

6.8.2.1 Command packet

| | | |
|-------|----------|------------------------------------------------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x03 |
| CMD | (1 byte) | 0x50 (Initialize command) |
| SDLM | (1 byte) | Source DLM state code 0x02 : SSD 0x03 : NSECSD 0x04 : DPL |
| DDLML | (1 byte) | Destination DLM state code 0x02 : SSD |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.8.2.2 Data Packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x50 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0xAE |
| ETX | (1 byte) | 0x03 |

6.8.2.3 Data Packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xD0 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.8.2.4 Data packet [status ERR] (Flash access error in disclosed area)

| | | |
|-----|-----------|------------------------------------------------------------------------------------------|
| SOH | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xD0 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details e.g.) FSTATR[31:0] = 0x0120A000 -> 0x01, 0x20, 0xA0, 0x00 |
| ADR | (4 bytes) | Failure address e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.8.2.5 Data packet [status ERR] (Flash access error in not disclosed area)

| | | |
|-----|-----------|--------------------------------|
| SOH | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0Ah |
| RES | (1 byte) | 0xD0 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.8.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a “Command acceptance error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware analyzes the received parameters after packet analysis.

- When SDLM does not match with the current DLM state, “Parameter error” is returned.
- When DDLM is not SSD, “Parameter error” is returned.
- When initialization is disabled, “Protection error” is returned.
- When Permanent protected block exists (there is a bit that is “0” in PBPS[139:0] and PBPS_SEC[139:0]), “Protection error” is returned.
- When FSPR bit is 0, “Protection error” is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware executes the all erase processing after parameter analysis.


- If an error occurs during erasure in the block protect setting, the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * The value of the block protect setting is undefined.
- If an error occurs during erasure in the User area, the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * The value of the area after ADR (Failure address) of the User area is undefined.
- If an error occurs during erasure in the Data area, the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * The value of the Data area is undefined.
- If an error occurs during erasure in the Config area, the boot firmware sends a “Flash access error” and returns to the command wait state.
 - * The value of the Config area is undefined.
- If an error occurs during boundary setting and key index (wrapped key) erasure in the User area, the boot firmware sends a “Flash access error” and returns to the command wait state.
- If an error occurs during transition DLM state, “Flash access error” is returned but waits for the next command.
 - * Check the DLM state after the Flash access error has occurred with the DLM state request command.
- If the DLM state is an invalid value, the boot firmware sends a “Hardware error” and becomes unresponsive.
- If all erasure process has completed normally, the boot firmware sends “OK” and no response.
 - * The User area and Data area of flash memory are erased, the Config area is written (All-F), and the DLM state is SSD.

6.8.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|---------------------------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| SDLM is different from current DLM state. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| DDLML is not SSD. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Initialization is disabled. | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| There is a permanently protected block. | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| The FPSR bit is set. (FPSR = 0) | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after the command execution in disclosed area. | Flash access error | Flash status | Failure address |
| FACI detected an error after the command execution in not disclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| DLM state is abnormal. | Hardware error | 0xFFFFFFFF | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.8.5 DLM state transition




6.9 DLM state request command (GrpA, GrpB, and GrpC)

This command is used to get the current DLM state.

This command requires adherence to conditions described in [Command List](#).

6.9.1 Sequence diagram



6.9.2 Packets

6.9.2.1 Command packet

| | | |
|-----|----------|----------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x01 |
| CMD | (1 byte) | 0x2C (DLM state request command) |
| SUM | (1 byte) | 0xD3 |
| ETX | (1 byte) | 0x03 |

6.9.2.2 Data packet [DLM state]

| | | |
|-----|----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x02 |
| RES | (1 byte) | 0x2C (OK) |
| DLM | (1 byte) | DLM state code |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.9.2.3 Data packet [status ERR]

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xAC (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.9.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.

* Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the inquiry processing, sends DLM state and returns to the command wait state.

* Flash memory status does not change before command reception.

6.9.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|--------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |

6.10 Boundary setting command (GrpA, GrpB, and GrpC)

This command receives the boundary setting and stores it in the device. The stored boundary setting becomes effective after resetting the device.

This command requires adherence to conditions described in [Command List](#).

6.10.1 Sequence diagram



6.10.2 Packets

6.10.2.1 Command packet

| | | | |
|------|-----------|-----------------------------------------------------|------------------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0B | |
| CMD | (1 byte) | 0x4E | (Boundary setting command) |
| CFS1 | (2 bytes) | Size of code flash secure region (without NSC) [KB] | e.g.) 0x0100 -> 0x01, 0x00 (256 KB) |
| CFS2 | (2 bytes) | Size of code flash secure region [KB] | e.g.) 0x0100 -> 0x01, 0x00 (256 KB) * 32 KB align |
| DFS1 | (2 bytes) | Size of Data Flash Secure region [KB] | e.g.) 0x0004 -> 0x00, 0x04 (4 KB) |
| SRS1 | (2 bytes) | Size of SRAM Secure region (without NSC) [KB] | e.g.) 0x0040 -> 0x00, 0x40 (64 KB) |
| SRS2 | (2 bytes) | Size of SRAM secure region [KB] | e.g.) 0x0040 -> 0x00, 0x40 (64 KB) * 8 KB align |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

NSC: Non-secure callable regions

* If CFS2 or SRS2 does not comply with the alignment, the boot firmware rounds them down.

6.10.2.2 Data Packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x4E (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.10.2.3 Data Packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xCE (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.10.2.4 Data Packet [status ERR] (Flash access error in not disclosed area)

| | | |
|-----|-----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xCE (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.10.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- If this command cannot be executed in the current DLM state, the boot firmware sends a "Command acceptance error".
 - When the above error occurs, the boot firmware does not process and returns to the command waiting state.
- * Flash memory status does not change before command reception.

Boot firmware analyzes the received parameters after packet analysis.

- When CFS1 is bigger than CFS2, "Parameter error" is returned.
 - When SRS1 is bigger than SRS2, "Parameter error" is returned.
 - When the above error occurs, the boot firmware does not process and returns to the command waiting state.
- * Flash memory status does not change before command reception.

Boot firmware executes the write processing of boundary setting after parameter analysis.

- * When CFS2 or SRS2 in the received command packet does not comply with the alignment, the boot firmware rounds them down.
- If an error occurs while writing, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - When the write processing has finished normally, boot firmware returns "OK" and waits for the next command.

6.10.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| CFS1 is larger than CFS2. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| SRS1 is larger than SRS2. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after command execution in a non disclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.11 Boundary request command (GrpA, GrpB, and GrpC)

This command sends the boundary setting value to the host (returns the current value stored in the device).

This command requires adherence to conditions described in [Command List](#).

6.11.1 Sequence diagram



6.11.2 Packets

6.11.2.1 Command packet

| | | |
|-----|----------|---------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x01 |
| CMD | (1 byte) | 0x4F (Boundary request command) |
| SUM | (1 byte) | 0xB0 |
| ETX | (1 byte) | 0x03 |

6.11.2.2 Data packet [Boundary setting data]

| | | |
|------|-----------|-----------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0B |
| RES | (1 byte) | 0x4F (OK) |
| CFS1 | (2 bytes) | Size of code flash secure region (without NSC) [KB] e.g.) 0x0100 -> 0x01, 0x00 (256 KB) |
| CFS2 | (2 bytes) | Size of code flash secure region [KB] e.g.) 0x0100 -> 0x01, 0x00 (256 KB) |
| DFS1 | (2 bytes) | Size of data flash secure region [KB] e.g.) 0x0004 -> 0x00, 0x04 (4 KB) |
| SRS1 | (2 bytes) | Size of SRAM secure region (without NSC) [KB] e.g.) 0x0040 -> 0x00, 0x40 (64 KB) |
| SRS2 | (2 bytes) | Size of SRAM secure region [KB] e.g.) 0x0040 -> 0x00, 0x40 (64 KB) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

NSC: Non-secure callable regions

6.11.2.3 Data packet [status ERR]

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xCF (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.11.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware returns boundary setting after packet analysis.

- Boot firmware sends “Boundary information” and waits for next command.
 - * Flash memory status does not change before command reception.

6.11.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|--------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |

6.12 Parameter setting command (GrpA, GrpB, and GrpC)

This command stores the received parameter in the device.

This command requires adherence to conditions described in [Command List](#).

6.12.1 Sequence diagram



6.12.2 Packets

6.12.2.1 Command packet

| | | |
|------|----------|------------------------------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | N + 2 |
| CMD | (1 byte) | 0x51 (Parameter setting command) |
| PMID | (1 byte) | Parameter ID 0x01 : Setting of disable initialization |
| PRMT | (N byte) | Parameter data [PMID = 0x01] 0x00 : Disable initialization |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

N = 1 to 16

6.12.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x51 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.12.2.3 Data packet [status ERR] (except Flash access error)

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xD1 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.12.2.4 Data packet [status ERR] (Flash access error in not disclosed area)

| | | |
|-----|-----------|--------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xD1 (ERR) |
| STS | (1 byte) | 0xE5 (Flash access error) |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.12.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware analyzes the received parameters after packet analysis.

- When designated PMID is unsupported, “Parameter error” is returned.
- When this command is unavailable in the current DLM state, “Command acceptance error” is returned.
- If PRMT is not the specified value, the boot firmware sends a “Parameter error” and returns to the command wait state.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware executes write processing of parameter data after parameter analysis.

- If an error occurs while writing, the boot firmware sends a “Flash access error” and returns to the command wait state.
- When the write processing has finished normally, boot firmware returns “OK” and waits for the next command.

6.12.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Designated PMID is unsupported. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Executing this command is unavailable in current DLM state. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| PRMT is not the specified value. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after command execution in a non disclosed area. | Flash access error | Flash status | 0xFFFFFFFF |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.12.5 Parameter Details by PMID

Parameter details for each PMID are as follows:

[PMID = 0x01]

Setting of disable initialization.

Example: Disable initialization

N = 1

PRMT[2:0] : 000b

PRMT[7:3] : Any value can be specified (ignored when writing).

* PRMT[2:0] accepts only 0x000. If 0x000 is already written, the boot firmware does not write and returns OK.

* Once disabled, initialization cannot be enabled again.

[PMID other than the above]


Boot firmware is unsupported and returns “Parameter error”.

6.13 Parameter request command (GrpA, GrpB, and GrpC)

This command reads the specified parameter from the device and sends it to the host (returns the value currently stored in the device).

This command requires adherence to conditions described in [Command List](#).

6.13.1 Sequence diagram



6.13.2 Packets

6.13.2.1 Command packet

| | | |
|------|----------|---------------------------------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x02 |
| CMD | (1 byte) | 0x52 (Parameter request command) |
| PMID | (1 byte) | Parameter ID 0x01 : Enable / Disable of the initialization |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.13.2.2 Data packet [Parameter data]

| | | |
|------|----------|----------------------------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | N + 1 |
| RES | (1 byte) | 0x52 (OK) |
| PRMT | (N byte) | Parameter data [PMID = 0x01] 0x00 : Initialization is disabled 0x07 : Initialization is enabled |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

N = 1 to 16

6.13.2.3 Data packet [status ERR]

| | | |
|-----|-----------|-----------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xD2 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.13.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives data other than SOH, it waits until SOH is received.
- If ETX is not added to the received command packet, the boot firmware sends a “Packet error”.
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a “Checksum error”.
- If the received command packets of LNH and LNL are different from the values specified in the packet format, the boot firmware sends a “Packet error”.
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a “Packet error”.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware analyzes parameter after packet analysis.

- When designated PMID is unsupported, “Parameter error” is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

Boot firmware returns parameter after parameter analysis.

- Boot firmware sends parameter and waits for next command.
 - * Flash memory status does not change before command reception.

6.13.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|-------------------------------------------------------------------------------------------|---------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| LNH and LNL in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Designated PMID is unsupported. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |

6.13.5 Parameter Details by PMID

Parameter details for each PMID are as follows:

[PMID = 0x01]

Returns the enabled / disabled state of the Initialization.

Example) When Initialization is disabled

N = 1
 PRMT[2:0] : 000b
 PRMT[7:3] : Always returns 0

Example) When Initialization is enabled

N = 1
 PRMT[2:0] : 111b
 PRMT[7:3] : Always returns 0

[PMID other than the above]


Boot firmware is unsupported and returns "Parameter error".

6.14 Inquiry command (GrpA, GrpB, GrpC, and GrpD)

This command is used to check if boot firmware is “Command acceptable phase” or not.

This command require adherence to conditions described in [Command List](#).

6.14.1 Sequence diagram



6.14.2 Packets

6.14.2.1 Command packet

| | | |
|-----|-----------|------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (10xbyte) | 0x00 |
| LNL | (1 byte) | 0x01 |
| CMD | (1 byte) | 0x00 (Inquiry command) |
| SUM | (1 byte) | 0xFF |
| ETX | (1 byte) | 0x03 |

6.14.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x00 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0xFE |
| ETX | (1 byte) | 0x03 |

6.14.2.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x80 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.14.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packets of LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

For GrpD

When the processing above is successfully completed, boot firmware executes the acceptance analysis.

- If OCD/Serial ID is set and not authenticated, the boot firmware sends a "Command acceptance error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware executes the inquiry processing.

- The boot firmware sends "OK" .
 - * Flash memory status does not change before command reception.

6.14.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|---------------------------------------------------------------------------------------------------|------------------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| OCD/Serial ID is set, and ID authentication by Authentication command has not been performed.(*1) | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| The process has ended normally. | OK | 0xFFFFFFFF | 0xFFFFFFFF |


*1 : Supported on GrpD

6.15 Signature request command (GrpA, GrpB, GrpC, and GrpD)

This command sends the information of the device signature to the host.

This command requires adherence to conditions described in [Command List](#).

6.15.1 Sequence diagram



6.15.2 Packets

6.15.2.1 Command packet

| | | |
|-----|----------|----------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x01 |
| CMD | (1 byte) | 0x3A (Signature request command) |
| SUM | (1 byte) | 0xC5 |
| ETX | (1 byte) | 0x03 |

6.15.2.2 Data packet [Signature]

| | | | |
|-----|------------|-------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x2A | |
| RES | (1 byte) | 0x3A (OK) | |
| RMB | (4 bytes) | Recommended maximum UART baudrate of the device [bps] | *Order of sending: High -> ... -> Low e.g.) 6 Mbps (6000000 bps) -> 0x00, 0x5B, 0x8D, 0x80 |
| NOA | (1 byte) | Number of accessible areas | e.g.) If the device has 4 areas. -> 0x04 |
| TYP | (1 byte) | Type code (features and functions of the device) | 0x01:GrpA, GrpB 0x02:GrpC 0x05:GrpD |
| BFV | (3 bytes) | Boot firmware version | *Order of sending: Major version -> Minor version -> Build e.g.) v2.4.16 -> 0x02, 0x04, 0x10 |
| DID | (16 bytes) | Device ID | 16-byte ID code (unique ID) for identifying the individual MCU |
| PTN | (16 bytes) | Product type name | Character strings (0x20 for the space) *Order of sending: e.g.) R7FA6M3AH ->0x52, 0x37, 0x46, 0x41, 0x36, 0x4d, 0x33, 0x41, 0x48, 0x20, 0x20, 0x20, 0x20, 0x20, 0x20, 0x20, 0x20 |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.15.2.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xBA (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.15.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH .
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.

* Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware returns the signature.

- Send a signature and return to command waiting.
* Flash memory status does not change before command reception.

6.15.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|----------------------------------------------------------------------------------------------|--------------------------------|------------|------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |

6.16 Area information request command (GrpA, GrpB, GrpC, and GrpD)

This command sends the information of the designated area to the host. The alignment of the target address of command shall follow this area information.

This command requires adherence to conditions described in [Command List](#).

6.16.1 Sequence diagram



6.16.2 Packets

6.16.2.1 Command packet

| | | |
|-----|----------|-----------------------------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x02 |
| CMD | (1 byte) | 0x3B (Area information request command) |
| NUM | (1 byte) | Area number [0 to NOA-1] |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.16.2.2 Data packet [Area information]

| | | | |
|-----|-----------|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| SOD | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x1A | |
| RES | (1 byte) | 0x3B (OK) | |
| KOA | (1 byte) | Kind of the area | 0x0N : User area N(*2) 0x1N : Data area N(*2) 0x2N : Config area N(*2) |
| SAD | (4 bytes) | Start address | *Order of sending: High -> ... -> Low e.g.) 0x00010000 -> 0x00, 0x01, 0x00, 0x00 |
| EAD | (4 bytes) | End address | *Order of sending: High -> ... -> Low e.g.) 0x001FFFFFF -> 0x00, 0x1F, 0xFF, 0xFF |
| EAU | (4 bytes) | Erase access unit (alignment) [byte] (*1) | *Order of sending: High -> ... -> Low e.g.) 32 KB (32768byte) -> 0x00, 0x00, 0x80, 0x00 Target command : Erase command |
| WAU | (4 bytes) | Write access unit (alignment) [byte] (*1) | *Order of sending: High -> ... -> Low e.g.) 128byte -> 0x00, 0x00, 0x00, 0x80 Target command : Write command |
| RAU | (4 bytes) | Read access unit (alignment) [byte] (*1) | *Order of sending: High -> ... -> Low e.g.) 1byte -> 0x00, 0x00, 0x00, 0x01 Target command : Read command |
| CAU | (4 bytes) | CRC access unit (alignment) [byte] (*1) | *Order of sending: High -> ... -> Low e.g.) 4byte -> 0x00, 0x00, 0x00, 0x04 Target command : CRC command |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

*1 If each access unit is 0x00000000, target command is not available for the area.

*2 N = 0x0~0xF

6.16.2.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xBB (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.16.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware analyzes the command parameters.

- If the specified NUM is "NOA" returned by "signature requests command" or more, the boot firmware sends a "Parameter error" and return to command waiting status.
- * Flash memory status does not change before command reception.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the area information will be returned.

- Send area information of specified NUM and return to command waiting status.
 - * Flash memory status does not change before command reception.

6.16.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|----------------------------------------------------------------------------------------------|---------------------------------|------------|------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| If Area number in the received packet is non-existent area number. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |

6.16.5 Example of area information

e.g.) RA4M2 (Linear mode)

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|------------|------------|----------|-----------|--------|--------------|
| 0 | User area0(S) | 0x00 | 0x00000000 | 0x0000FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 1 | User area0(L) | 0x00 | 0x00010000 | 0x000FFFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 2 | Data area | 0x10 | 0x08000000 | 0x08001FFF | 64 Bytes | 4 Bytes | 1 Byte | 1 KB |
| 3 | Config area | 0x20 | 0x0100A100 | 0x0100A2FF | 0 (*1) | 16 Bytes | 1 Byte | 256Bytes(*2) |

e.g.) RA6M4 (Linear mode)

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|------------|------------|----------|-----------|--------|--------------|
| 0 | User area0(S) | 0x00 | 0x00000000 | 0x0000FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 1 | User area0(L) | 0x00 | 0x00010000 | 0x000FFFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 2 | Data area | 0x10 | 0x08000000 | 0x08001FFF | 64 Bytes | 4 Bytes | 1 Byte | 1 KB |
| 3 | Config area | 0x20 | 0x0100A100 | 0x0100A2FF | 0 (*1) | 16 Bytes | 1 Byte | 256Bytes(*2) |

e.g.) RA6M4 (Dual mode)

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|------------|------------|----------|-----------|--------|--------------|
| 0 | User area0(S) | 0x00 | 0x00000000 | 0x0000FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 1 | User area0(L) | 0x00 | 0x00010000 | 0x0007FFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 2 | User area1(S) | 0x01 | 0x00200000 | 0x0020FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 3 | User area1(L) | 0x01 | 0x00210000 | 0x0027FFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 4 | Data area | 0x10 | 0x08000000 | 0x08001FFF | 64 Bytes | 4 Bytes | 1 Byte | 1 KB |
| 5 | Config area | 0x20 | 0x0100A100 | 0x0100A2FF | 0 (*1) | 16 Bytes | 1 Byte | 256Bytes(*2) |

e.g.) RA4E1 (Linear mode)

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|------------|------------|----------|-----------|--------|--------------|
| 0 | User area0(S) | 0x00 | 0x00000000 | 0x0000FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 1 | User area0(L) | 0x00 | 0x00010000 | 0x000FFFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 2 | Data area | 0x10 | 0x08000000 | 0x08001FFF | 64 Bytes | 4 Bytes | 1 Byte | 1 KB |
| 3 | Config area | 0x20 | 0x0100A100 | 0x0100A2FF | 0 (*1) | 16 Bytes | 1 Byte | 256Bytes(*2) |

e.g.) RA6E1 (Linear mode)

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|------------|------------|----------|-----------|--------|--------------|
| 0 | User area0(S) | 0x00 | 0x00000000 | 0x0000FFFF | 8 KB | 128 Bytes | 1 Byte | 32 KB |
| 1 | User area0(L) | 0x00 | 0x00010000 | 0x000FFFFF | 32 KB | 128 Bytes | 1 Byte | 32 KB |
| 2 | Data area | 0x10 | 0x08000000 | 0x08001FFF | 64 Bytes | 4 Bytes | 1 Byte | 1 KB |
| 3 | Config area | 0x20 | 0x0100A100 | 0x0100A2FF | 0 (*1) | 16 Bytes | 1 Byte | 256Bytes(*2) |

e.g.) RA6T2

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|-----------|-----------|--------|----------|-------|--------------|
| 0 | User area0(S) | 0x00 | 00000000h | 0000FFFFh | 8KB | 128Bytes | 1Byte | 32KB |
| 1 | User area0(L) | 0x00 | 00010000h | 0007FFFFh | 32KB | 128Bytes | 1Byte | 32KB |
| 2 | Data area | 0x10 | 08000000h | 08003FFFh | 64B | 4Bytes | 1Byte | 1KB |
| 3 | Config area | 0x20 | 0100A100h | 0100A2FFh | 0 (*1) | 16Bytes | 1Byte | 256Bytes(*2) |

e.g.) RA6E2

| NUM | Area | KOA | SAD | EAD | EAU | WAU | RAU | CAU |
|-----|---------------|------|-----------|-----------|--------|----------|-------|--------------|
| 0 | User area0(S) | 0x00 | 00000000h | 0000FFFFh | 8KB | 128Bytes | 1Byte | 32KB |
| 1 | User area0(L) | 0x00 | 00010000h | 0003FFFFh | 32KB | 128Bytes | 1Byte | 32KB |
| 2 | Data area | 0x10 | 08000000h | 08000FFFh | 64B | 4Bytes | 1Byte | 1KB |
| 3 | Config area | 0x20 | 0100A100h | 0100A2FFh | 0 (*1) | 16Bytes | 1Byte | 256Bytes(*2) |

*1: When Access unit is 0, it indicates that the corresponding operation is not supported.


*2: CRC command to Config area is executable only for entire area, in other words only possible to specify the area's SAD/EAD as CRC command's SAD/EAD. See CRC command for details

6.17 Baud rate setting command (GrpA, GrpB, GrpC, and GrpD)

This command receives baudrate data and changes the UART baudrate of the device. If an error occurs, the baudrate is not changed. This command does not change the communication speed except for UART communication.

This command requires adherence to conditions described in [Command List](#).

6.17.1 Sequence diagram



*1: After this packet receiving, next command packet waits tBRT for keeping the baudrate setting time.

6.17.2 Packets

6.17.2.1 Command packet

| | | | |
|-----|-----------|---------------------------------|------------------------------------------|
|] | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x05 | |
| CMD | (1 byte) | 0x34 (Baudrate setting command) | |
| BRT | (4 bytes) | UART baudrate [bps] | You can set one of the following values. |

Order of sending BRT:

| Baud rate | GrpA GrpB GrpC | GrpD | 1st | 2nd | 3rd | 4th |
|-----------|----------------------|------|------|------|------|------|
| 9600bps | ✓ | ✓ | 0x00 | 0x00 | 0x25 | 0x80 |
| 115200bps | ✓ | ✓ | 0x00 | 0x01 | 0xC2 | 0x00 |
| 500Kbps | ✓ | ✓ | 0x00 | 0x07 | 0xA1 | 0x20 |
| 1.0Mbps | ✓ | ✓ | 0x00 | 0x0F | 0x42 | 0x40 |
| 1.5Mbps | ✓ | ✓ | 0x00 | 0x16 | 0xE3 | 0x60 |
| 2.0Mbps | ✓ | ✓ | 0x00 | 0x1E | 0x84 | 0x80 |
| 4.0Mbps | ✓ | | 0x00 | 0x3D | 0x09 | 0x00 |
| 6.0Mbps | ✓ | | 0x00 | 0x5B | 0x8D | 0x80 |

| | | | |
|-----|----------|----------|--|
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.17.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x34 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| FST | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | 0xCA |
| ETX | (1 byte) | 0x03 |

6.17.2.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOD | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0xB4 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.17.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the communication mode is not asynchronous 2-wire communication, a response will be returned when packet analysis ends normally.

- If the communication mode is not asynchronous 2-wire communication, the boot firmware sends "OK" and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

In asynchronous 2-wire communication, parameter analysis is performed when processing above is completed successfully.

- Sends "Parameter error" if the specified BRT (baudrate) is greater than the RMB in the Signature request command.
- Sends "Parameter error" if the specified BRT (baudrate) is not a supported baudrate value.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

In asynchronous 2-wire communication, when processing above is completed normally, the baud rate is set.

- After sending "OK", set the baudrate and return to the command waiting state.
 - * Flash memory status does not change before command reception.
 - * After the boot firmware returned OK (Started the baudrate setting), wait 1ms before sending next command.

6.17.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|----------------------------------------------------------------------------------------------|---------------------------------|------------|------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Received UART baudrate is greater than RMB. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Different from the baudrate value supported by the received UART baudrate. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Communication mode is different from UART. | OK | 0xFFFFFFFF | 0xFFFFFFFF |
| Started the baudrate setting. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.17.5 Baud rate setting values

(GrpA, GrpB, and GrpC)

| Intended baud rate | ABCS | CKS[1:0] | BRR[7:0] | MDDR[7:0] | Accuracy |
|--------------------|-------------|-------------|-------------|-------------|----------|
| 9600 bps | 0b0 | 0b00 | 0xFF | 0xC9 | -0.2% |
| 115200 bps | 0b0 | 0b00 | 0x1A | 0xFE | -0.3% |
| 500 Kbps | 0b0 | 0b00 | 0x05 | 0xF5 | -0.3% |
| 1.0 Mbps | 0b0 | 0b00 | 0x02 | 0xF5 | -0.3% |
| 1.5 Mbps | 0b0 | 0b00 | 0x01 | 0xF5 | -0.3% |
| 2.0 Mbps | 0b0 | 0b00 | 0x00 | 0xA3 | -0.5% |
| 4.0 Mbps | 0b1 | 0b00 | 0x00 | 0xA3 | -0.5% |
| 6.0 Mbps | 0b1 | 0b00 | 0x00 | 0xF5 | -0.3% |
| Other | unavailable | unavailable | unavailable | unavailable | - |

(GrpD)


| Intended baud rate | ABCS | CKS[1:0] | BRR[7:0] | MDDR[7:0] | Accuracy |
|--------------------|-------------|-------------|-------------|-------------|----------|
| 9600bps | 0b0 | 0b00 | 0xC2 | 0xFF | -0.2% |
| 115200bps | 0b0 | 0b00 | 0x0F | 0xFB | -0.3% |
| 500Kbps | 0b0 | 0b00 | 0x02 | 0xCC | -0.3% |
| 1.0Mbps | 0b0 | 0b00 | 0x00 | 0x88 | -0.3% |
| 1.5Mbps | 0b0 | 0b00 | 0x00 | 0xCC | -0.3% |
| 2.0Mbps | 0b1 | 0b00 | 0x00 | 0x88 | -0.5% |
| Other | unavailable | unavailable | unavailable | unavailable | - |

6.18 Erase command (GrpA, GrpB, GrpC, and GrpD)

This command erases data in the specified area of the flash memory. The alignment of the target addresses shall follow the area information returned by the Area information request command. Erasures are executed in order from the start address to the end address by the erase access unit. Erase processing at this time is not affected by the block protection settings (BPS, BPS_SEC) in case of GrpA,GrpB,GrpC, / (BPS_SEC) in case of GrpD.

This command requires adherence to conditions described in [Command List](#).

6.18.1 Sequence diagram



*1 : In case of GrpA, GrpB, and GrpC

6.18.2 Packets

6.18.2.1 Command packet

| | | | |
|-----|-----------|----------------------|---------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x09 | |
| CMD | (1 byte) | 0x12 (Erase command) | |
| SAD | (4 bytes) | Start address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| EAD | (4 bytes) | End address | e.g.) 0x003FFFFFF -> 0x00, 0x3F, 0xFF, 0xFF |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.18.2.2 Data packet [status OK]

| | | |
|-----|-----------|--------------------------|
| SOH | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x12 (OK) |
| STS | (1 byte) | 0x00 (OK) |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.18.2.3 Data packet [status ERR]

| | | |
|-----|-----------|---------------------------------|
| SOH | (1 byte) | 0x81 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x0A |
| RES | (1 byte) | 0x92 (ERR) |
| STS | (1 byte) | Status code |
| ST2 | (4 bytes) | Status details |
| ADR | (4 bytes) | Failure address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.18.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the packet analysis has successfully completed, boot firmware executes the acceptance analysis.

- (In case of GrpA, GrpB, and GrpC) : If this command cannot be executed in the current DLM state, (In case of GrpD) : If OCD/Serial ID is set and not authenticated, the boot firmware sends a "Command acceptance error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the boot firmware analyzes the command parameters.

-
- If the SAD is greater than EAD, the boot firmware sends a "Parameter error".
 - If the SAD or EAD is outside the range specified in the area information, the boot firmware sends a "Parameter error".
 - If SAD and EAD belong to different KOA, boot firmware will send a "Parameter error".
 - If the EAU for the specified area is 0, the boot firmware sends a "Parameter error".
 - If SAD and EAD are not specified in the EAU of the area, the boot firmware sends a "Parameter error".
 - (In case of GrpA, GrpB, and GrpC) : If the current DLM state is NSECSD and the specified range includes a secure area, the boot firmware sends a "Secure error".
 - When designated erasure range includes a permanent protected block, "Protection error" is returned.
 - When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When no error occurs, boot firmware executes the erase processing.

- If an error occurs during erasure, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * The value of the area after ADR (Failure address) of the Flash memory is undefined.
- When the erase processing is normally finished, boot firmware returns "OK" and waits for the next command.
 - * Specified areas in flash memory are erased state.

6.18.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|---------------------------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Executing this command is unavailable in current DLM state. (In case of GrpD) OCD/Serial ID is set, and ID authentication by Authentication command has not been performed. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address is bigger than End address. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address is outside the scope of User area specified in area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address and End address belong to different Kind of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The access unit "EAU" of the specified area is 0. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address does not comply with EAU of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Current DLM state is NSECSD and designated erasure range includes Secure region. (In case of GrpD) N/A | Secure error | 0xFFFFFFFF | 0xFFFFFFFF |
| Designated erasing range includes permanent protected blocks. | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after the command execution. | Flash access error | Flash status | Failure address |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.19 Write command (GrpA, GrpB, GrpC, and GrpD)

This command receives data from host and writes those data to the flash memory. The alignment of the target address shall follow the area information returned by the Area information request command. Writings are executed in order from the start address to the end address by the write access unit. Write processing at this time is not affected by the block protection settings (BPS, BPS_SEC) in case of GrpA, GrpB, GrpC, / (BPS_SEC) in case of GrpD.

This command requires adherence to conditions described in [Command List](#).

6.19.1 Sequence diagram



*1 : In case of GrpA, GrpB, and GrpC

6.19.2 Packets

6.19.2.1 Command packet

| | | | |
|-----|-----------|----------------------|---------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x09 | |
| CMD | (1 byte) | 0x13 (Write command) | |
| SAD | (4 bytes) | Start address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| EAD | (4 bytes) | End address | e.g.) 0x003FFFFFF -> 0x00, 0x3F, 0xFF, 0xFF |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.19.2.2 Data packet [write data]

| | | | |
|-----|----------|-----------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | N + 1 (Higher 1 byte) | |
| LNL | (1 byte) | N + 1 (Lower 1 byte) | |
| RES | (1 byte) | 0x13 (OK) | |
| DAT | (N byte) | Write data | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

N = 1 to 1024

6.19.2.3 Data packet [status OK]

| | | | |
|-----|-----------|--------------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x13 (OK) | |
| STS | (1 byte) | 0x00 (OK) | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.19.2.4 Data packet [status ERR]

| | | | |
|-----|-----------|---------------------------------|-----------------------------------------------------------|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x93 (ERR) | |
| STS | (1 byte) | Status code | |
| ST2 | (4 bytes) | Status details | e.g.) FSTATR[31:0] = 0x0120A000 -> 0x01, 0x20, 0xA0, 0x00 |
| ADR | (4 bytes) | Failure address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.19.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware executes the acceptance analysis.

- (In case of GrpA, GrpB, and GrpC) : If this command cannot be executed in the current DLM state, (In case of GrpD) : If OCD/Serial ID is set and not authenticated, the boot firmware sends a "Command acceptance error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the boot firmware analyzes the command parameters.

- If the SAD is greater than EAD, the boot firmware sends a "Parameter error".
- If the SAD or EAD is outside the range specified in the area information, the boot firmware sends a "Parameter error".
- If SAD and EAD belong to different KOA, boot firmware sends a "Parameter error".
- If the WAU for the specified area is 0, the boot firmware sends a "Parameter error".
- If SAD and EAD are not specified in the WAU of the area, the boot firmware sends a "Parameter error".
- (In case of GrpA, GrpB, and GrpC) : If the current DLM state is NSECSD and the specified range includes a secure area, the boot firmware sends a "Secure error".
- When designated writing range includes PBPS block, "Protection error" is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.
- If the above error does not occur, the boot firmware sends "OK".

When the processing above is successfully completed, boot firmware receives and analyzes a data packet.

- The boot firmware recognizes the start of the data packet by receiving SOD.
If the boot firmware receives something other than SOD, it will wait until it receives SOD.
- If ETX is not added to the received data packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received data packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- When RES in the received data packet is different from defined values by each command, "Packet error" is returned.
- When total length of the received data of data packets exceeds the size of specified area, "Parameter error" is returned.
- If size of the write data is not specified in the WAU of the area, the boot firmware sends a "Parameter error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the received data packet is not the last write data, boot firmware returns "OK" and executes the write processing.

- Boot firmware returns "OK" and executes the write processing.
- When the write processing is abnormally finished, boot firmware returns 'Flash access error' and waits for the next command.
 - * WAU size from failure address (ADR) of Flash memory area are undefined.
- When the write processing is normally finished, boot firmware receives the next data packet.

When the received data packet is the last write data, boot firmware executes the write processing and returns status.

- Boot firmware executes the write processing.
- If an error occurs while writing, the boot firmware sends a "Flash access error" and returns to the command wait state.
 - * WAU size from failure address (ADR) of Flash memory area are undefined.
- When the write processing is normally finished, boot firmware returns "OK" and waits for the next command.
 - * Sent data are written to the specified area on flash memory.

6.19.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|------------------------------|---------------------------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Executing this command is unavailable in current DLM state. (In case of GrpD) OCD/Serial ID is set, and ID authentication by Authentication command has not been performed. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address is bigger than End address. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address is outside the scope of accessible area specified in area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address and End address belong to different Kind of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The access unit "WAU" of the specified area is 0. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address does not comply with WAU of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Current DLM state is NSECSD and designated writing range includes secure region. (In case of GrpD) N/A | Secure error | 0xFFFFFFFF | 0xFFFFFFFF |
| Designated writing range includes permanent protected blocks. | Protection error | 0xFFFFFFFF | 0xFFFFFFFF |
| The response code of the received data packet is different from the value specified by this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| The total length of received data of data packets exceeds the specified end address. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The data size of the data packet doesn't comply with writing unit of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| FACI detected an error after the command execution. | Flash access error | Flash status | Failure address |
| Successful completion. | OK | 0xFFFFFFFF | 0xFFFFFFFF |

6.20 Read command (GrpA, GrpB, GrpC, and GrpD)

This command reads data from a specified area in the flash memory, and sends those data to host. The alignment of the target addresses shall follow the area information returned by the Area information request command. Readings are executed in order from the start address to the end address by the read access unit.

This command requires adherence to conditions described in [Command List](#).

6.20.1 Sequence diagram



*1 : In case of GrpA, GrpB, and GrpC

6.20.2 Packets

6.20.2.1 Command packet

| | | | |
|-----|-----------|---------------------|---------------------------------------------|
| SOH | (1 byte) | 0x01 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x09 | |
| CMD | (1 byte) | 0x15 (Read command) | |
| SAD | (4 bytes) | Start address | e.g.) 0x00004000 -> 0x00, 0x00, 0x40, 0x00 |
| EAD | (4 bytes) | End address | e.g.) 0x003FFFFFF -> 0x00, 0x3F, 0xFF, 0xFF |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.20.2.2 Data packet [status OK]

| | | | |
|-----|-----------|--------------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x15 (OK) | |
| STS | (1 byte) | 0x00 (OK) | |
| ST2 | (4 bytes) | 0xFFFFFFFF (unused code) | |
| ADR | (4 bytes) | 0xFFFFFFFF (unused code) | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.20.2.3 Data packet [status ERR]

| | | | |
|-----|-----------|---------------------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x95 (ERR) | |
| STS | (1 byte) | Status code | |
| ST2 | (4 bytes) | Status details | |
| ADR | (4 bytes) | Failure address | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.20.2.4 Data packet [read data]

| | | | |
|-----|----------|-----------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | N + 1 (Higher 1 byte) | |
| LNL | (1 byte) | N + 1 (Lower 1 byte) | |
| RES | (1 byte) | 0x15 (OK) | |
| DAT | (N byte) | Read data | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

N = 1 to 1024

6.20.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, boot firmware executes the acceptance analysis.

- (In case of GrpA, GrpB, and GrpC) : If this command cannot be executed in the current DLM state, (In case of GrpD) : If OCD/Serial ID is set and not authenticated, the boot firmware sends a "Command acceptance error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the boot firmware analyzes the command parameters.

- If the SAD is greater than EAD, the boot firmware sends a "Parameter error".
- If the SAD or EAD is outside the range specified in the area information, the boot firmware sends a "Parameter error".
- If SAD and EAD belong to different KOA, boot firmware sends a "Parameter error".
- If the RAU for the specified area is 0, the boot firmware sends a "Parameter error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the boot firmware performs a secure analysis.

- (In case of GrpA, GrpB, and GrpC) : If the current DLM state is NSECSD and the specified range includes a secure area, the boot firmware sends a "Secure error" and returns to the command waiting state without processing.
 - * Flash memory status does not change before command reception.

When no error occurs, boot firmware executes the read processing.

- Boot firmware returns the data stored in the internal buffer (packet-length: Max. 1024 bytes).
- When all the data have been sent, boot firmware waits for the next command.
 - * Flash memory status does not change before command reception.

If data transmission for the specified size is not completed, the boot firmware receives the data packet and performs packet analysis.

- Boot firmware detects the beginning of a data packet by receiving SOD.
When boot firmware receives other data than SOD, it discards the data and waits for the next data until SOD is sent.
- When the received data packet doesn't have ETX, "Packet error" is returned .
- When SUM in the received data packet is different from the value calculated by boot firmware, "Checksum error" is returned.
- When LNH and LNL in the received data packet do not comply with the packet format, "Packet error" is returned.
- When RES in the received data packet is different from defined values, "Packet error" is returned.
- When LNH and LNL in the received data packet do not comply format with this command, "Packet error" is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.
- If the above error does not occur, the boot firmware continues to read and send data.

6.20.4 Status information from microcontroller

(listed in descending order of priority)

| Condition | STS | ST2 | ADR |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|------------|------------|
| The received packet does not have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Executing this command is unavailable in current DLM state. (In case of GrpD) OCD/Serial ID is set, and ID authentication by Authentication command has not been performed. | Command acceptance error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address is bigger than End address. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address is outside the scope of accessible area specified in area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address and End address belong to different Kind of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The access unit "RAU" of the specified area is 0. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address doesn't comply with RAU of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| (In case of GrpA, GrpB, and GrpC) Current DLM state is NSECSD, designated reading range is User area or Data area and includes secure region. (In case of GrpD) N/A | Secure error | 0xFFFFFFFF | 0xFFFFFFFF |
| The response code of the received data packet is different from the value specified by this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |

6.21 CRC command (GrpA, GrpB, GrpC, and GrpD)

This command calculates CRC data from a specified area in the flash memory, and sends it to host. The alignment of the target addresses shall follow the area information returned by the Area information request command. Calculations are executed in order from the start address to the end address by the CRC access unit.


As an exception, when specifying Config area, it is able to specify only entire Config area regardless of CRC access unit returned by Area information command.

This command requires adherence to conditions described in [Command List](#).

Boot firmware uses following CRC method.

| | |
|-----------------------------------|------------------------|
| Name | CRC-32-IEEE-802.3 |
| Default value | 0xFFFFFFFF |
| Shift direction | Left shift |
| Polynomial representations | (MSB first) 0x04C11DB7 |

6.21.1 Sequence diagram



6.21.2 Packets

6.21.2.1 Command packet

| | | |
|-----|-----------|--------------------|
| SOH | (1 byte) | 0x01 |
| LNH | (1 byte) | 0x00 |
| LNL | (1 byte) | 0x09 |
| CMD | (1 byte) | 0x18 (CRC command) |
| SAD | (4 bytes) | Start address |
| SUM | (1 byte) | Sum data |
| ETX | (1 byte) | 0x03 |

6.21.2.2 Data packet [CRC data]

| | | | |
|-----|-----------|----------------------------------|--------------------------------------------|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x05 | |
| RES | (1 byte) | 0x18 (OK) | |
| CRC | (4 bytes) | CRC data (result of calculation) | e.g.) 0x01234567 -> 0x01, 0x23, 0x45, 0x67 |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.21.2.3 Data packet [status ERR]

| | | | |
|-----|-----------|---------------------------------|--|
| SOH | (1 byte) | 0x81 | |
| LNH | (1 byte) | 0x00 | |
| LNL | (1 byte) | 0x0A | |
| RES | (1 byte) | 0x98 (ERR) | |
| STS | (1 byte) | Status code | |
| ST2 | (4 bytes) | Status details | |
| ADR | (4 bytes) | Failure address | |
| SUM | (1 byte) | Sum data | |
| ETX | (1 byte) | 0x03 | |

6.21.3 Processing procedure

Boot firmware receives and analyzes a command packet.

- The boot firmware recognizes the start of the command packet by receiving SOH.
If the boot firmware receives something other than SOH, it will wait until it receives SOH.
- If ETX is not added to the received command packet, the boot firmware sends a "Packet error".
- If the SUM of the received command packet is different from the sum value, the boot firmware sends a "Checksum error".
- If the received command packet's LNH and LNL are different from the values specified in the packet format, the boot firmware sends a "Packet error".
- If the received command packet's LNH and LNL are different from the values specified in each command, the boot firmware sends a "Packet error".
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the processing above is successfully completed, the boot firmware analyzes the command parameters.

- If the SAD is greater than EAD, the boot firmware sends a "Parameter error".
- If the SAD or EAD is outside the range specified in the area information, the boot firmware sends a "Parameter error".
- If SAD and EAD belong to different KOA, boot firmware will send a "Parameter error".
- If the CAU for the specified area is 0, the boot firmware sends a "Parameter error".
- If SAD and EAD are not specified in the CAU of the area, the boot firmware sends a "Parameter error".
- When KOA is 0x20 (Config area) and SAD/EAD do not specify entire Config area, "Parameter error" is returned.
- When the above error occurs, the boot firmware does not process and returns to the command waiting state.
 - * Flash memory status does not change before command reception.

When the parameter analysis has successfully completed, boot firmware executes CRC calculation.

- After the CRC calculation, boot firmware returns "CRC data" and waits for the next command.
 - * Flash memory status does not change before command reception.



6.21.4 Status information from microcontroller

(listed in descending order of priority)


| Condition | STS | ST2 | ADR |
|---------------------------------------------------------------------------------------------------------|---------------------------------|------------|------------|
| The received packet doesn't have ETX. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| SUM data in the received packet is different from the value calculated by the boot firmware. | Checksum error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the packet format. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Packet length in the received packet do not comply with the specifications of this command. | Packet error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address is bigger than End address. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address is outside the scope of accessible area specified in area information. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address and End address belong to different Kind of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The access unit "CAU" of the specified area is 0. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| Start address or End address doesn't comply with CAU of the area. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |
| The specified area is Config area and Start address or End address does not match with specified value. | Parameter error | 0xFFFFFFFF | 0xFFFFFFFF |

7. Flow examples


7.1 Beginning communication




7.2 Acquisition of device information / baud rate settings




7.3 Transiting DLM state




7.4 ID authentication



7.5 User area / Data area updates




7.6 Config area updates




7.7 Initialize flash memory

(GrpA, GrpB, and GrpC)




(GrpD)




7.8 Boundary setting updates

(GrpA, GrpB, and GrpC)




7.9 Parameter setting updates

(GrpA, GrpB, and GrpC)



7.10 Command cancel

For commands that continuously send and receive packets, you can end the command by intentionally sending an error packet and return to the command acceptable phase.




e.g.) Error packets to end the command.

| Command | GrpA GrpB GrpC | GrpD | When to send error packets | Example of the error packet | | |
|------------------------|----------------------|------|-----------------------------------------------------|-----------------------------|----------|------------|
| | | | | | | |
| Authentication command | ✓ | | Data packet [Response value or Authentication code] | SOD | (1 byte) | 0x81 |
| | | | | LNH | (1 byte) | 0x00 |
| Key setting command | ✓ | | Data packet [key data] | LNL | (1 byte) | 0x01 |
| Write command | ✓ | ✓ | Data packet [write data] | RES | (1 byte) | 0xFF (ERR) |
| Read command | ✓ | ✓ | Data packet [status OK] | SUM | (1 byte) | 0x00 |
| | | | | ETX | (1 byte) | 0x03 |


8. AC characteristics

8.1 Communication setting phase



| Parameter | Product | Symbol | Min | Typ | Max | Unit |
|----------------------------------------------------------------|-----------|--------|-----|-----|------|------|
| Initial setting time (when using Main-OSC (External clock)) | GrpA,GrpB | tIS | - | - | 280 | ms |
| | GrpD | tIS | - | - | 40 | ms |
| Initial setting time (when using Main-OSC (Crystal resonator)) | GrpA,GrpB | tIS | - | - | 507 | ms |
| | GrpC | tIS | - | - | 419 | ms |
| | GrpD | tIS | - | - | 267 | ms |
| Initial setting time (when using HOCO) | GrpA,GrpB | tIS | - | - | 2613 | ms |
| | GrpD | tIS | - | - | 2336 | ms |
| Initial setting time 2 | GrpD | tIS2 | - | - | 36 | ms |

8.2 Baudrate setting command



| Parameter | Product | Symbol | Min | Typ | Max | Unit |
|-------------------------------------------------------------|------------------------|--------|-----|-----|-----|------|
| Initial setting time (when using Main-OSC (External clock)) | GrpA,GrpB GrpC,GrpD | tBRT | - | - | 1 | ms |

9. FACL command list

The FACL commands executed by each communication command are shown below

| Communication command | Product | FACL command | number of issue times |
|---------------------------|---------------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DLM state transit command | GrpA,GrpB, GrpC | Configuration set | 1 time |
| Authentication command | GrpA,GrpB, GrpC | Program | [Size of Data area / 4] times (transiting to RMA_REQ) |
| | | Block Erase | [Size of Code S area / 8 KByte] + [Size of Code L area / 32 KByte] + [Size of Data area / 64Byte *2] times (transiting to RMA_REQ) |
| | | Configuration set | 1 time (transiting to except RMA_REQ) 27 times (transiting to RMA_REQ and FSPR bit is 0) 28 times (transiting to RMA_REQ and FSPR bit is 1) |
| | GrpD | Program | 【Data Flash erasure】 1024 times |
| | | Block Erase | 【Code Flash erasure】 [Size of Code S area / 8KByte] times [Size of Code L area / 32KByte] times 【Data Flash erasure】 [Size of Data area / 64Byte] × 2 times |
| | | Configuration set | 【Config erasure】 6 times |
| | | Forced stop *) Use to clear error status | 4 times |
| | Key setting command | GrpA,GrpB, GrpC | Configuration set |
| User key setting command | GrpA,GrpC | Program | Depends on designated address |
| Initialize command | GrpA,GrpB, GrpC | Program | [Size of Data area / 4] times |
| | | Block Erase | [Size of User area (smaller block size) / 8 K] + [Size of User area (larger block size) / 32 K] + [Size of Data area / 64 * 2] times |
| | | Configuration set | 30 times |
| Boundary setting command | GrpA,GrpB, GrpC | Configuration set | 1 time |
| Parameter setting command | GrpA,GrpB, GrpC | Configuration set | 1 time |
| Erase command | GrpA,GrpB, GrpC | Block erase | Depends on designated address |
| | GrpD | Block Erase | Depends on designated address |
| | | Forced stop *) Use to clear error status | 1 time |
| Write command | GrpA,GrpB, GrpC | Program | Depends on designated address |
| | | Configuration set | Depends on designated address |
| | GrpD | Program | Depends on designated address |
| | | Configuration set | Depends on designated address |
| | | Forced stop *) Use to clear error status | 1 time |

10. Precaution list

10.1 Write command

- (1) If permanent block protection in the Config area is set, the protected area cannot be rewritten. Therefore, rewrite the protected area before setting the permanent block protection.

10.2 CRC command

- (1) Since erased Data area's value is undefined, calculated CRC data would be incorrect if range of calculating CRC data includes erased Data area.

11. Cause for operation stop

The boot firmware enters an infinite loop in the following cases

11.1 Initialization phase

- When following CPU exceptions occur
NMI / HardFault / MemManage / BusFault / UsageFault / SecureFault / SVCcall / DebugMonitor / PendSV / SysTick

11.2 Communication setting phase

- When the USB cable is disconnected when the USB status is "Configured"
- When following CPU exceptions occur
NMI / HardFault / MemManage / BusFault / UsageFault / SecureFault / SVCcall / DebugMonitor / PendSV / SysTick

11.3 Command acceptance phase

- When the USB cable is disconnected when the USB status is "Configured"
- When following CPU exceptions occur
NMI / HardFault / MemManage / BusFault / UsageFault / SecureFault / SVCcall / DebugMonitor / PendSV / SysTick

12. Cause for software reset

Boot firmware performs software reset in the following cases

12.1 Communication setting phase

- When MD=1 is detected and not requested SWD boot mode during communication mode judgement

Revision History

| Rev. | Date | Description | |
|------|---------------|------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| | | Page | Summary |
| 1.00 | Oct 30, 2020 | — | First release |
| 1.10 | Jun 30, 2021 | 1 | Added three product groups |
| 1.20 | Jun. 20, 2022 | 1, 5, 8-14, 18, 21, 27-28, 40, 47, 50, 74, 79, 89, 91, 106 | Added RA6T2, Merged RA4E1 and RA6E1 from another Application Note. Corrected some misdescriptions. |
| 1.30 | Mar. 15, 2023 | Many pages | Add RA4E2 and RA6E2 (SWD Boot, ID authentication) |
| 1.40 | May 30, 2023 | Many pages | Add RA4T1 and RA6T3 |
| 1.50 | Mar. 11, 2024 | 76 | Change the description of "6.15.2.2 Data packet [Signature]" |

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between V_{IL} (Max.) and V_{IH} (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between V_{IL} (Max.) and V_{IH} (Min.).

7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.