Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1st, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.



Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights
 of third parties by or arising from the use of Renesas Electronics products or technical information described in this document.
 No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights
 of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



Preliminary Application Note

V850E/IF3, V850E/IG3

32-bit Single-Chip Microcontrollers

Sample Programs for Clock Generator

V850E/IF3: μ PD70F3451 μ PD70F3452 V850E/IG3: μ PD70F3453 μ PD70F3454

Document No. U18734EJ1V0AN00 (1st edition) Date Published September 2007 N

© NEC Electronics Corporation 2007 Printed in Japan

[MEMO]

NOTES FOR CMOS DEVICES —

1 VOLTAGE APPLICATION WAVEFORM AT INPUT PIN

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between $V_{\rm IL}$ (MAX) and $V_{\rm IH}$ (MIN) due to noise, etc., the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between $V_{\rm IL}$ (MAX) and $V_{\rm IH}$ (MIN).

(2) HANDLING OF UNUSED INPUT PINS

Unconnected CMOS device inputs can be cause of malfunction. If an input pin is unconnected, it is possible that an internal input level may be generated due to noise, etc., causing malfunction. CMOS devices behave differently than Bipolar or NMOS devices. Input levels of CMOS devices must be fixed high or low by using pull-up or pull-down circuitry. Each unused pin should be connected to VDD or GND via a resistor if there is a possibility that it will be an output pin. All handling related to unused pins must be judged separately for each device and according to related specifications governing the device.

③ PRECAUTION AGAINST ESD

A strong electric field, when exposed to a MOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop generation of static electricity as much as possible, and quickly dissipate it when it has occurred. Environmental control must be adequate. When it is dry, a humidifier should be used. It is recommended to avoid using insulators that easily build up static electricity. Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors should be grounded. The operator should be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions need to be taken for PW boards with mounted semiconductor devices.

(4) STATUS BEFORE INITIALIZATION

Power-on does not necessarily define the initial status of a MOS device. Immediately after the power source is turned ON, devices with reset functions have not yet been initialized. Hence, power-on does not guarantee output pin levels, I/O settings or contents of registers. A device is not initialized until the reset signal is received. A reset operation must be executed immediately after power-on for devices with reset functions.

⑤ POWER ON/OFF SEQUENCE

In the case of a device that uses different power supplies for the internal operation and external interface, as a rule, switch on the external power supply after switching on the internal power supply. When switching the power supply off, as a rule, switch off the external power supply and then the internal power supply. Use of the reverse power on/off sequences may result in the application of an overvoltage to the internal elements of the device, causing malfunction and degradation of internal elements due to the passage of an abnormal current.

The correct power on/off sequence must be judged separately for each device and according to related specifications governing the device.

6 INPUT OF SIGNAL DURING POWER OFF STATE

Do not input signals or an I/O pull-up power supply while the device is not powered. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Input of signals during the power off state must be judged separately for each device and according to related specifications governing the device.

Caution: This product uses SuperFlash® technology licensed from Silicon Storage Technology, Inc.

SuperFlash is a registered trademark of Silicon Storage Technology, Inc. in several countries including the United States and Japan.

- The information contained in this document is being issued in advance of the production cycle for the product. The parameters for the product may change before final production or NEC Electronics Corporation, at its own discretion, may withdraw the product prior to its production.
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property
 rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other
 liability arising from the use of such products. No license, express, implied or otherwise, is granted under any
 patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes
 in semiconductor product operation and application examples. The incorporation of these circuits, software and
 information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC
 Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of
 these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special", and "Specific".
 The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics products before using it in a particular application.
 - "Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.
 - "Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).
 - "Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

- (1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.
- (2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

M5 02.11-1

INTRODUCTION

- Cautions 1. This Application Note explains a case where the V850E/IG3 is used as a representative microcontroller. Use this Application Note for your reference when using the V850E/IF3.
 - 2. Download the program used in this manual from the page of Programming Examples (http://www.necel.com/micro/en/designsupports/sampleprogram/index.html) in the NEC Electronics Website (http://www.necel.com/).
 - 3. The sample programs are provided for reference purposes only and operations are therefore not subject to guarantee by NEC Electronics Corporation. When using sample programs, customers are advised to sufficiently evaluate this product based on their systems, before use.
 - 4. When using sample programs, reference the following startup routine and link directive file and adjust them if necessary.

Startup routine: ig3_start.sLink directive file: ig3_link.dir

Target Readers This Application Note is intended for users who understand the functions of the

V850E/IF3 (μ PD70F3451, 70F3452), and V850E/IG3 (μ PD70F3453, 70F3454), and

who design application systems that use these microcontrollers.

Purpose This manual is intended to give users an understanding of the basic functions of the

V850E/IF3 and V850E/IG3, using the application programs.

How to Use This Manual It is assumed that the reader of this Application Note has general knowledge in the

fields of electrical engineering, logic circuits, and microcontrollers.

For details of hardware functions (especially register functions, setting methods, etc.)

and electrical specifications

 \rightarrow See the V850E/IF3, V850E/IG3 Hardware User's Manual.

For details of instruction functions

→ See the V850E1 Architecture User's Manual.

Conventions Data significance: Higher digits on the left and lower digits on the right

Active low representation: \overline{xxx} (overscore over pin or signal name)

Memory map address: Higher addresses on the top and lower addresses on

the bottom

Note: Footnote for item marked with **Note** in the text

Caution: Information requiring particular attention

Remark: Supplementary information Numeric representation: Binary ... xxxx or xxxxB

Decimal ... xxxx

Hexadecimal ... xxxxH

Prefix indicating the power

of 2 (address space,

memory capacity): K (kilo): $2^{10} = 1,024$

M (mega): $2^{20} = 1,024^2$ G (giga): $2^{30} = 1,024^3$ The function lists are structured as follows.

Theme

[Function] Function description [Function name] Name of sample function [Argument(s)] Type and overview of argument(s) [Processing content] Processing content of sample function [Starting method] Conditions for calling a function [SFR(s) used] Register name and setting content [call function(s)] Name and function of call function(s) Type, name, and overview of variable(s) used in sample function [Variable(s)] [Interrupt(s)] Name of function [Interrupt source(s)] Name [File name] Name of corresponding sample program file Caution(s) upon function usage [Caution(s)]

Product Differences The differences between the V850E/IG3 and the V850E/IF3 related to the clock generator are shown below.

ltem	V850E/IG3	V850E/IF3
CLKOUT pin	Provided (µPD70F3454GC-8EA-A only)	None

Related Documents

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

Documents related to V850E/IF3 and V850E/IG3

Document Name	Document No.
V850E1 Architecture User's Manual	U14559E
V850E/IF3, V850E/IG3 Hardware User's Manual	U18279E
V850E/IF3, V850E/IG3 Sample Programs for Serial Communication (UARTA) Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Serial Communication (UARTB) Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Serial Communication (CSIB) Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Serial Communication (I ² C) Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for DMA Function Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Timer M Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Watchdog Timer Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Timer AA Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Timer AB Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Timer T Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Port Function Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Clock Generator Application Note	This manual
V850E/IF3, V850E/IG3 Sample Programs for Standby Function Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Interrupt Function Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for A/D Converters 0 and 1 Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for A/D Converter 2 Application Note	To be prepared
V850E/IF3, V850E/IG3 Sample Programs for Low-Voltage Detector (LVI) Function Application Note	To be prepared
V850E/IF3, V850E/IG3 6-Phase PWM Output Control by Timer AB, Timer Q Option, Timer AA, A/D Converters 0 and 1 Application Note	U18717E

CONTENTS

CHAPTER 1	PLL MODE	9
CHAPTER 2	CLOCK MONITOR MODE	13

CHAPTER 1 PLL MODE

[Function] Sets the clock frequency by setting the CPU operation clock (PLL mode) and the PCC

register which is a special register.

[Function name] pll_main

[Argument] None

[Processing content] Calls the PLL setting function by terminating all DMAs in use.

When DMA is not used, the terminate processing of DMA is not needed.

[Starting method] None

[SFR used] None

[call functions] clock_pll_mode, clock_pcc_mode

[Variable] None

[Interrupt] None

[Interrupt source] None

[File name] clock_generator1.c

[Caution] Note that if the pll_main function is called the maskable interrupt request will not be

enabled (EI).

[Function name] clock_pll_mode

[Processing content] Sets to PLL mode by the PLLCTL register.

[SFR used] PLLCTL: 0x03 (Sets to PLL mode.)

[call functions] None
[Variable] None

[File name] clock_generator1.c

[Caution] None

[Function name] clock_pcc_mode

[Processing content] Sets the PCC register by forcibly terminating DMA transfer.

[SFRs used] DCHC0.TC0: DMA0 transfer status bit

DCHC0.E00: 1 (Enables DMA0 transfer.)

DCHC0.INIT0: 1 (Forcibly terminates DMA0 transfer.)

DCHC1.TC1 DMA1 transfer status bit DCHC1.E11: 1 (Enables DMA1 transfer.)

DCHC1.INIT1: 1 (Forcibly terminates DMA1 transfer.)

DCHC2.TC2 DMA2 transfer status bit DCHC2.E22: 1 (Enables DMA2 transfer.)

DCHC2.INIT2: 1 (Forcibly terminates DMA2 transfer.)

DCHC3.TC3 DMA3 transfer status bit DCHC3.E33: 1 (Enables DMA3 transfer.)

DCHC3.INIT3: 1 (Forcibly terminates DMA3 transfer.)
PRCMD: 0x00 (Writes to command register

(used when writing to a special register).)

PCC: 0x00 (Selects clock as fxx.)

[call functions] None
[Variable] None


[Cautions]

[File name] clock_generator1.c

DMA transfer is forcibly terminated in this sample program, because all DMA transfers
must be terminated before performing data setting to the special register.
 When DMA is not used, the terminate processing of DMA is not needed.

• Set the PCC register after switching to the PLL mode. The PCC register is a special register and can therefore only be written in a combination of specific sequences.

Figure 1-1. PLL mode (1/2)



PLL mode setting function PCC register setting function clock_pcc_mode clock_pll_mode Sets CPU operation PLLCTL = 0x03 clock to PLL mode. TC0 == 0 && E00 == 1 Checks DMA0 transfer. Yes INIT0 = 1 Forcibly terminates DMA0. Checks transition SELPLL == 1 to PLL mode. Yes TC1 == 0 && E11 == 1 ret Checks DMA1 transfer. Yes INIT1 = 1 Forcibly terminates DMA1. Not needed when DMA is not used. TC2 == 0 && E22 == 1 Checks DMA2 transfer. Yes Forcibly terminates DMA2. INIT2 = 1 TC3 == 0 && E33 == 1 Checks DMA3 transfer. Yes Forcibly terminates DMA3. INIT3 = 1

PRCMD = 0x00

PCC = 0x00

NOP instruction $\times\,5$

Writes to command register.

Inserts five NOP instructions.

Selects clock as fxx.

Figure 1-1. PLL mode (2/2)

CHAPTER 2 CLOCK MONITOR MODE

[Function] Performs clock monitor operation.

[Function name] clock_monitor_main

[Argument] None

[Processing content] Enables operation of the clock monitor mode by calling the clock monitor mode function.

[Starting method] None

[SFR used] None

[call functions] clock_monitor_mode

[Variable]None[Interrupt]None[Interrupt source]None

[File name] clock_generator2.c

[Caution] Note that if the clock_monitor_main function is called the maskable interrupt request will

not be enabled (EI).

[Function name]	clock_monitor_mode
-----------------	--------------------

[Processing content] Sets the operation mode of the clock monitor via the CLM register, by forcibly terminating

DMA transfer.

[SFRs used] DCHC0.TC0 DMA0 transfer status bit

DCHC0.E00: 1 (Enables DMA0 transfer.)

DCHC0.INIT0: 1 (Forcibly terminates DMA0 transfer.)

DCHC1.TC1 DMA1 transfer status bit DCHC1.E11: 1 (Enables DMA1 transfer.)

DCHC1.INIT1: 1 (Forcibly terminates DMA1 transfer.)

DCHC2.TC2 DMA2 transfer status bit DCHC2.E22: 1 (Enables DMA2 transfer.)

DCHC2.INIT2: 1 (Forcibly terminates DMA2 transfer.)

DCHC3.TC3 DMA3 transfer status bit DCHC3.E33: 1 (Enables DMA3 transfer.)

DCHC3.INIT3: 1 (Forcibly terminates DMA3 transfer.)
PRCMD: 0x01 (Writes to command register

(used when writing to a special register).)

CLM: 0x01 (Enables operation of clock monitor.)

[call functions] None
[Variable] None

[Cautions]

[File name] clock_generator2.c

• DMA transfer is forcibly terminated in this sample program, because all DMA transfers must be terminated before performing data setting to the special register.

When DMA is not used, the terminate processing of DMA is not needed.

• The CLM register is a special register and can therefore only be written in a combination of specific sequences.




Figure 2-1. Clock Monitor Mode (1/2)

Clock monitor mode setting clock_monitor_mode TC0 == 0 && E00 == 1 Checks DMA0 transfer. Yes INIT0 = 1 Forcibly terminates DMA0. TC1 == 0 && E11 == 1 Checks DMA1 transfer. Yes INIT1 = 1 Forcibly terminates DMA1. Not needed when DMA is not used. No TC2 == 0 && E22 == 1 Checks DMA2 transfer. Yes Forcibly terminates DMA2. INIT2 = 1 TC3 == 0 && E33 == 1 Checks DMA3 transfer. Yes INIT3 = 1 Forcibly terminates DMA3. PRCMD = 0x01Writes to command register. CLM = 0x01Enables clock monitor operation. NOP instruction $\times\,5$ Inserts five NOP instructions. ret

Figure 2-1. Clock Monitor Mode (2/2)

For further information, please contact:

NEC Electronics Corporation

1753, Shimonumabe, Nakahara-ku, Kawasaki, Kanagawa 211-8668, Japan Tel: 044-435-5111 http://www.necel.com/

[America]

NEC Electronics America, Inc.

2880 Scott Blvd. Santa Clara, CA 95050-2554, U.S.A. Tel: 408-588-6000 800-366-9782 http://www.am.necel.com/

[Europe]

NEC Electronics (Europe) GmbH

Arcadiastrasse 10 40472 Düsseldorf, Germany Tel: 0211-65030 http://www.eu.necel.com/

Hanover Office

Podbielskistrasse 166 B 30177 Hannover Tel: 0 511 33 40 2-0

Munich Office

Werner-Eckert-Strasse 9 81829 München Tel: 0 89 92 10 03-0

Stuttgart Office

Industriestrasse 3 70565 Stuttgart Tel: 0 711 99 01 0-0

United Kingdom Branch

Cygnus House, Sunrise Parkway Linford Wood, Milton Keynes MK14 6NP, U.K. Tel: 01908-691-133

Succursale Française

9, rue Paul Dautier, B.P. 52 78142 Velizy-Villacoublay Cédex France Tel: 01-3067-5800

Sucursal en España

Juan Esplandiu, 15 28007 Madrid, Spain Tel: 091-504-2787

Tyskland Filial

Täby Centrum Entrance S (7th floor) 18322 Täby, Sweden Tel: 08 638 72 00

Filiale Italiana

Via Fabio Filzi, 25/A 20124 Milano, Italy Tel: 02-667541

Branch The Netherlands

Steijgerweg 6 5616 HS Eindhoven The Netherlands Tel: 040 265 40 10

[Asia & Oceania]

NEC Electronics (China) Co., Ltd

7th Floor, Quantum Plaza, No. 27 ZhiChunLu Haidian District, Beijing 100083, P.R.China Tel: 010-8235-1155 http://www.cn.necel.com/

Shanghai Branch

Room 2509-2510, Bank of China Tower, 200 Yincheng Road Central, Pudong New Area, Shanghai, P.R.China P.C:200120 Tel:021-5888-5400 http://www.cn.necel.com/

Shenzhen Branch

Unit 01, 39/F, Excellence Times Square Building, No. 4068 Yi Tian Road, Futian District, Shenzhen, P.R.China P.C:518048 Tel:0755-8282-9800 http://www.cn.necel.com/

NEC Electronics Hong Kong Ltd.

Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong Tel: 2886-9318 http://www.hk.necel.com/

NEC Electronics Taiwan Ltd.

7F, No. 363 Fu Shing North Road Taipei, Taiwan, R. O. C. Tel: 02-8175-9600 http://www.tw.necel.com/

NEC Electronics Singapore Pte. Ltd.

238A Thomson Road, #12-08 Novena Square, Singapore 307684 Tel: 6253-8311 http://www.sg.necel.com/

NEC Electronics Korea Ltd.

11F., Samik Lavied'or Bldg., 720-2, Yeoksam-Dong, Kangnam-Ku, Seoul, 135-080, Korea Tel: 02-558-3737 http://www.kr.necel.com/