

---

## RL78/G14, R8C/36M Group

R01AN3957EJ0100

Rev.1.00

### Migration Guide from R8C to RL78: A/D Converter

---

Dec 21, 2017

#### Abstract

This application note describes how to implement, in the RL78/G14 A/D converter, the various operations equivalent to the operation modes provided by the R8C/36M group A/D converter. The operation modes include: one-shot mode, repeat mode 0, repeat mode 1, single sweep mode, and repeat sweep mode.

#### Target Devices

RL78/G14, R8C/36M Group

When applying this application note to other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU. For the specifications and electrical characteristics of the MCU, refer to the appropriate User's Manual: Hardware and technical updates.

## 目次

1. Migration from R8C Family to RL78 Family .....	5
2. Differences between RL78/G14 and R8C/36M Group .....	7
2.1 A/D Converter Specifications .....	7
2.2 Comparison of Registers.....	8
2.3 Absolute Accuracy .....	10
2.3.1 Characteristics of R8C/36M Group.....	10
2.3.2 Characteristics of RL78/G14.....	10
2.4 Selecting Analog Input Pins for Each Operation Mode.....	11
2.4.1 R8C/36M Group.....	11
2.4.2 RL78/G14.....	11
2.5 Interrupt Operation .....	11
3. Migration of A/D Converters by Using Sample Code Provided .....	12
4. Example of Migration from One-Shot Mode.....	13
4.1 Specifications .....	13
4.2 Conditions for Confirming Operations .....	14
4.3 Hardware Descriptions .....	14
4.3.1 Hardware Configuration Example .....	14
4.3.2 List of Pins Used .....	15
4.4 Software Descriptions .....	15
4.4.1 Operation Summary.....	15
4.4.2 List of Option Byte Settings.....	17
4.4.3 List of Constants .....	17
4.4.4 List of Variables.....	17
4.4.5 Functions.....	18
4.4.6 Function Specifications .....	18
4.4.7 Flowcharts.....	20
4.5 Sample Code.....	36
4.6 Reference Application Note .....	36
4.7 Reference Documents .....	36
5. Example of Migration from Repeat Mode 0.....	37
5.1 Specifications .....	37
5.2 Conditions for Confirming Operations .....	38
5.3 Hardware Descriptions .....	38
5.3.1 Hardware Configuration Example .....	38
5.3.2 List of Pins Used .....	39
5.4 Software Descriptions .....	39
5.4.1 Operation Summary.....	39
5.4.2 List of Option Byte Settings.....	41
5.4.3 List of Constants .....	41
5.4.4 List of Variables.....	41
5.4.5 Functions.....	42

5.4.6	Function Specifications .....	42
5.4.7	Flowcharts .....	44
5.5	Sample Code.....	59
5.6	Reference Application Note .....	59
5.7	Reference Documents .....	59
6.	Example of Migration from Repeat Mode 1 .....	60
6.1	Specifications .....	60
6.2	Conditions for Confirming Operations .....	62
6.3	Hardware Descriptions .....	62
6.3.1	Hardware Configuration Example .....	62
6.3.2	List of Pins Used .....	63
6.4	Software Descriptions .....	63
6.4.1	Operation Summary .....	63
6.4.2	List of Option Byte Settings.....	66
6.4.3	List of Constants .....	66
6.4.4	List of Variables.....	67
6.4.5	Functions.....	67
6.4.6	Function Specifications .....	68
6.4.7	Flowcharts .....	70
6.5	Sample Code.....	93
6.6	Reference Application Note .....	93
6.7	Reference Documents .....	93
7.	Example of Migration from Single Sweep Mode .....	94
7.1	Specifications .....	94
7.2	Conditions for Confirming Operations .....	96
7.3	Hardware Descriptions .....	96
7.3.1	Hardware Configuration Example .....	96
7.3.2	List of Pins Used .....	97
7.4	Software Descriptions .....	97
7.4.1	Operation Summary .....	97
7.4.2	List of Option Byte Settings.....	100
7.4.3	List of Constants .....	100
7.4.4	List of Variables.....	100
7.4.5	Functions.....	101
7.4.6	Function Specifications .....	101
7.4.7	Flowcharts .....	103
7.5	Sample Code.....	125
7.6	Reference Application Note .....	125
7.7	Reference Documents .....	125
8.	Example of Migration from Repeat Sweep Mode .....	126
8.1	Specifications .....	126
8.2	Conditions for Confirming Operations .....	128
8.3	Hardware Descriptions .....	128
8.3.1	Hardware Configuration Example .....	128

---

8.3.2	List of Pins Used .....	129
8.4	Software Descriptions .....	129
8.4.1	Operation Summary .....	129
8.4.2	List of Option Byte Settings .....	132
8.4.3	List of Constants .....	132
8.4.4	List of Variables .....	132
8.4.5	Functions .....	133
8.4.6	Function Specifications .....	133
8.4.7	Flowcharts .....	135
8.5	Sample Code .....	157
8.6	Reference Application Note .....	157
8.7	Reference Documents .....	157

## 1. Migration from R8C Family to RL78 Family

This chapter describes how to allow the RL78/G14 to support the various operation modes provided by the R8C/36M group A/D converter (one-shot mode, repeat mode 0, repeat mode 1, single sweep mode, and repeat sweep mode).

Table 1.1 shows the operation modes of the R8C/36M group A/D converter, and Table 1.2 shows the operation modes of the RL78/G14 A/D converter.

The R8C/36M group A/D converter performs A/D conversion according to one of the operation modes selected from the operation modes listed in Table 1.1. The RL78/G14 A/D converter performs A/D conversion according to the combination of the A/D conversion channel selection mode and A/D conversion operation mode listed in Table 1.2.

The R8C/36M group and RL78/G14 have different number of registers for storing A/D conversion results.

The R8C/36M group has several registers for storing A/D conversion results, which correspond to selected pins. Specifically, one register or eight registers can be used for one pin.

On the other hand, the RL78/G14 has only one register for storing the A/D conversion results.

Therefore, for sequential A/D conversion by the RL78/G14, the A/D conversion results need to be read by using the interrupts or DTC before the next A/D conversion ends.

In addition, the R8C/36M group and RL78/G14 store the A/D conversion results in different forms.

In 10-bit resolution A/D conversion, both MCUs store the A/D conversion results in 2-byte registers. With the R8C/36M group, the A/D conversion results are stored in the lower 10 bits in the A/D conversion result register (ADi). However, With the RL78/G14, the A/D conversion results are stored in the upper 10 bits in the A/D conversion result register (ADCR). Therefore, to allow the RL78/G14 to handle the A/D conversion results in the same form as the R8C/36M group, it is necessary to shift the A/D conversion results to the right by six bits through software.

In 8-bit resolution A/D conversion, both MCUs store the A/D conversion results in 1-byte registers. With the R8C/36M group, the A/D conversion results are stored in the lower 8 bits in the A/D conversion result register (ADi). With the RL78/G14, the A/D conversion results are stored in the upper 8 bits in the A/D conversion result register (ADCR).

Table 1.1 Operation Modes of R8C/36M Group A/D Converter (outline)

R8C/36M Group A/D Converter		
Operation Mode	Function	A/D Conversion Result Register
One-shot mode	A/D conversion is performed once on the input voltage of one pin.	A/D conversion result register corresponding to the selected pin
Repeat mode 0	A/D conversion is repeatedly performed on the input voltage of one pin.	
Repeat mode 1	A/D conversion is repeatedly performed on the input voltage of one pin.	Eight A/D conversion result registers (A/D conversion results are repeatedly stored in the consecutive registers according to the number of conversions.)
Single sweep mode	A/D conversion is performed once each on the input voltage of two, four, six, or eight pins.	A/D conversion result registers corresponding to the selected pins
Repeat sweep mode	A/D conversion is repeatedly performed on the input voltage of two, four, six, or eight pins.	

Table 1.2 Operation Modes of RL78/G14 A/D Converter (outline)

RL78/G14 A/D Converter		
Operation Mode	Operation Mode Specification	Function
A/D conversion channel selection mode	Select mode	A/D conversion is performed on the analog input of one selected channel.
	Scan mode	A/D conversion is performed on the analog input of four channels in order. Four consecutive channels can be selected from ANI0 to ANI14 as analog input channels.
A/D conversion operation mode	One-shot conversion mode	A/D conversion is performed once on the selected channel.
	Sequential conversion mode	A/D conversion is sequentially performed on the selected channels until it is stopped by software.

Table 1.3 shows the operation modes of the R8C/36M group and the corresponding combinations of the A/D conversion channel selection modes and A/D conversion operation modes of the RL78/G14.

Table 1.3 Correspondence among A/D Operation Modes

R8C/36M Group Operation Mode	RL78/G14	
	A/D Conversion Channel Selection Mode	A/D Conversion Operation Mode
One-shot mode	Select Mode	One-shot conversion mode
Repeat mode 0		Sequential conversion mode
Repeat mode 1		
Single sweep mode	Scan mode	One-shot conversion mode
Repeat sweep mode		Sequential conversion mode

## 2. Differences between RL78/G14 and R8C/36M Group

### 2.1 A/D Converter Specifications

Table 2.1 and Table 2.2 show the differences in the specifications of the A/D converters.

Table 2.1 Differences in Specifications of A/D Converters (1/2)

Item	R8C/36M Group	RL78/G14
A/D converter operating voltage range	$2.2\text{ V} \leq V_{\text{ref}} = AV_{\text{cc}} \leq 5.5\text{ V}$ (unavailable in wait mode, STOP mode, low-power read mode, and when flash memory is stopped)	<ul style="list-style-type: none"> <li>When standard 1/standard 2 mode is selected, <math>2.7\text{ V} \leq V_{\text{DD}} \leq 5.5\text{ V}</math></li> <li>When low voltage 1/low voltage 2 mode is selected, <math>1.6\text{ V} \leq V_{\text{DD}} \leq 5.5\text{ V}</math></li> </ul>
Reference voltage	$V_{\text{ref}}$ (2.2 V to $AV_{\text{cc}}$ )	Selected from $V_{\text{DD}}$ , $AV_{\text{REFP}}$ (1.6 V to $V_{\text{DD}}$ ), and internal reference voltage (1.45 V).
Analog input voltage	0 V to $V_{\text{ref}}$	<ul style="list-style-type: none"> <li>Reference voltage = <math>AV_{\text{REFP}}</math> ANI2 to ANI14: 0 V to <math>AV_{\text{REFP}}</math> ANI16 to ANI20: 0 V to <math>AV_{\text{REFP}}</math></li> <li>Reference voltage = <math>V_{\text{DD}}</math> ANI0 to ANI14: 0 V to <math>V_{\text{DD}}</math> ANI16 to ANI20: 0 V to <math>EV_{\text{DD}}</math></li> <li>Reference voltage = internal reference voltage 0 to <math>V_{\text{BGR}}</math></li> </ul>
Operating clock frequency (conversion clock frequency)	$f_{\text{AD}}$ , $f_{\text{AD}}/2$ , $f_{\text{AD}}/4$ , $f_{\text{AD}}/8$ , ( $f_{\text{AD}} = f_1$ or $f_{\text{OCO-F}}$ )	$f_{\text{CLK}}/64$ , $f_{\text{CLK}}/32$ , $f_{\text{CLK}}/16$ , $f_{\text{CLK}}/8$ , $f_{\text{CLK}}/6$ , $f_{\text{CLK}}/5$ , $f_{\text{CLK}}/4$ , $f_{\text{CLK}}/2$ $f_{\text{CLK}}$ (CPU/peripheral hardware clock frequency)
Resolution	8 or 10 bits	8 or 10 bits
Operation mode (A/D conversion mode)	<ul style="list-style-type: none"> <li>One-shot mode</li> <li>Repeat mode 0</li> <li>Repeat mode 1</li> <li>Single sweep mode</li> <li>Repeat sweep mode</li> </ul>	Defined by combination of A/D conversion channel selection mode (select mode, scan mode) and A/D conversion operation mode (sequential conversion mode, one-shot conversion mode).
Analog input pins	<ul style="list-style-type: none"> <li>12 pins AN0 to AN11</li> </ul>	<ul style="list-style-type: none"> <li>8 pins (30-pin, 32-pin product) ANI0 to ANI3, ANI16 to ANI19</li> <li>8 pins (36-pin product) ANI0 to ANI5, ANI18, ANI19</li> <li>9 pins (40-pin product) ANI0 to ANI6, ANI18, ANI19</li> <li>10 pins (44-pin, 48-pin product) ANI0 to ANI7, ANI18, ANI19</li> <li>12 pins (52-pin, 64-pin product) ANI0 to ANI7, ANI16 to ANI19</li> <li>17 pins (80-pin product) ANI0 to ANI11, ANI16 to ANI20</li> <li>20 pins (100-pin product) ANI0 to ANI14, ANI16 to ANI20</li> </ul>

Table 2.2 Differences in Specifications of A/D Converters (2/2)

Item	R8C/36M Group	RL78/G14
A/D conversion trigger	<ul style="list-style-type: none"> <li>• Software trigger</li> <li>• Timer RD</li> <li>• Timer RC</li> <li>• External trigger (ADTRG)</li> </ul>	<ul style="list-style-type: none"> <li>• Software trigger</li> <li>• Hardware trigger (Note 1)</li> </ul>
Hardware trigger operation mode selection	Impossible	Possible (hardware trigger no-wait mode, hardware trigger wait mode)
A/D conversion time	44 $\phi$ AD cycles min.	Selectable by using ADM0 register.
Number of pins that can be simultaneously used	1, 2, 4, 6 or 8 pins (Note 2)	1 or 4 pins (Note 2)
Number of registers for storing A/D conversion results	8 (AD0 to AD7)	1 (Note 3)
Operation in STOP mode	Impossible	Possible (SNOOZE mode function)
On-chip reference voltage/ internal reference voltage	1.34 V (TYP.)	1.45 V (TYP.)
A/D disconnection detection assistance function	Provided	Not provided
Temperature sensor	Not provided	Provided
Test mode	Not provided	Provided

Note 1. As a hardware trigger, one of the following signals can be selected: end of timer channel 1 count or capture interrupt signal (INTTM01), event signal selected by ELC, realtime clock interrupt signal (INTRTC), and 12-bit interval timer interrupt signal (INTIT).

The ELC can select events from among external interrupt edge detection (INTP0 to INTP5), key return signal detection (INTKR), RTC fixed-cycle signal/Alarm match detection (INTRTC), timer RD0 input capture/compare match (INTTRD0), timer RD1 input capture/compare match (INTTRD1), timer RD1 underflow (TRD1 underflow signal), timer RJ0 underflow/end of pulse width measurement period/end of pulse period measurement period (INTTRJ0), timer RG input capture/compare match (INTTRG), TAU count end/capture end (INTTM00-INTTM13), comparator detection (INTCMP0-INTCMP1).

Note 2. Depends on the operation mode.

Note 3. The RL78/G14 can only hold the A/D conversion results of one A/D conversion. When performing A/D conversion consecutively, read the A/D conversion results by using the DTC or the equivalent before the next A/D conversion ends.

For how to read the A/D conversion results by using the DTC, refer to the application note, RL78/G14 Transferring A/D Conversion Result Using the DTC CC-RL (R01AN2574).

## 2.2 Comparison of Registers

Table 2.3 shows the registers of the R8C/36M group and the RL78/G14 used for setting the various items.



Table 2.3 Register Comparison

Item to be Set	R8C/36M Group	RL78/G14
On-chip reference voltage	<ul style="list-style-type: none"> <li>OCVREFCR register</li> <li>ADCON1 register ADEX0 bit</li> </ul>	<ul style="list-style-type: none"> <li>ADM2 register ADREFP1, ADREFP0 bits ADREFM bit</li> <li>ADS register</li> </ul>
Registers for storing A/D conversion results	AD0 to AD7 registers	<ul style="list-style-type: none"> <li>ADCR register (10 bits) or ADCRH register (8 bits) selected</li> </ul>
Clock frequency division ratio	ADMOD register CKS1, CKS0 bits	ADM0 register FR2 to FR0 bits
Clock source	ADMOD register CKS2 bit	—
A/D operation mode	ADMOD register MD2 to MD0 bits	<ul style="list-style-type: none"> <li>ADM0 register ADMD bit</li> <li>ADM1 register ADSCM bit</li> </ul>
A/D conversion trigger	ADMOD register ADCAP1, ADCAP0 bits	ADM1 register ADTMD1, ADTMD0 bits ADTRS1, ADTRS0 bits
Analog input pins	ADINSEL register CH2 to CH0 bits SCAN1, SCAN0 bit ADGSEL1, ADGSEL0 bits	<ul style="list-style-type: none"> <li>ADS register</li> <li>PMC0, PMC10, PMC12, PMC14 registers</li> <li>PM0, PM2, PM10, PM12, PM14, PM15 registers</li> </ul>
A/D converter operation control	<ul style="list-style-type: none"> <li>ADCON0 register ADST bit</li> <li>ADCON1 register ADSTBY bit</li> </ul>	ADM0 register ADCS bit ADCE bit
Resolution	ADCON1 register BITS bit	ADM2 register ADTYP bit
A/D disconnection detection assistance control	ADCON1 register ADDDAEN bit ADDDAEL bit	—
A/D input clock control	—	PER0 register ADCEN bit
A/D conversion time mode	—	ADM0 register LV1, LV0 bits
A/D conversion result comparison upper and lower limit setting	—	<ul style="list-style-type: none"> <li>ADUL register</li> <li>ADLL register</li> </ul>
Upper and lower limit conversion result value checking	—	ADM2 register ADRCK bit
SNOOZE mode	—	ADM2 register AWC bit
Temperature sensor output	—	ADS register
A/D test mode	—	ADTES register ADTES1, ADTES0 bits

—: No applicable registers provided.

## 2.3 Absolute Accuracy

As the counterpart of the absolute accuracy of the R8C/36M group, the overall error is defined for the RL78/G14.

### 2.3.1 Characteristics of R8C/36M Group

Table 2.4 shows the absolute accuracy of the R8C/36M group.

Table 2.4 Absolute Accuracy of R8C/36M Group

Item		Test Conditions		Specified Values			Units
				Min.	Typ	Max.	
Absolute accuracy	10-bit mode	$V_{ref} = AV_{CC} = 5.0\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 3$	LSB
		$V_{ref} = AV_{CC} = 3.3\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 5$	LSB
		$V_{ref} = AV_{CC} = 3.0\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 5$	LSB
		$V_{ref} = AV_{CC} = 2.2\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 5$	LSB
	8-bit mode	$V_{ref} = AV_{CC} = 5.0\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 2$	LSB
		$V_{ref} = AV_{CC} = 3.3\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 2$	LSB
		$V_{ref} = AV_{CC} = 3.0\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 2$	LSB
		$V_{ref} = AV_{CC} = 2.2\text{ V}$	AN0 to AN7 input, AN8 to AN11 input	—	—	$\pm 2$	LSB

### 2.3.2 Characteristics of RL78/G14

Table 2.5 shows the overall error of the RL78/G14 under the following conditions.

$AV_{REF(+)} = AV_{REFP}/ANI0$  (ADREFP1 = 0, ADREFP0 = 1),  $AV_{REF(-)} = AV_{REFM}/ANI1$  (ADREFM = 1) selected,

Target ANI pins: ANI2 to ANI14 (ANI pins to which  $V_{DD}$  is supplied)

Table 2.5 Overall Error of RL78/G14

Item	Symbol	Conditions		MIN.	TYP.	MAX.	Units
Overall error (Note)	AINL	10-bit resolution $AV_{REFP} = V_{DD}$	$1.8\text{ V} \leq V_{DD} \leq 5.5\text{ V}$		1.2	$\pm 3.5$	LSB
			$1.6\text{ V} \leq V_{DD} \leq 5.5\text{ V}$		1.2	$\pm 7.0$	LSB

Note Quantization error ( $\pm 1/2$  LSB) is not included.

## 2.4 Selecting Analog Input Pins for Each Operation Mode

With the R8C/36M group, two, four, six, or eight analog input pins can be selected as the analog input pins in single sweep mode and repeat sweep mode. On the other hand, with the RL78/G14, only four analog input pins can be selected as the analog input pins in scan mode.

### 2.4.1 R8C/36M Group

Table 2.6 shows the analog input pins that can be used in each operation mode of the R8C/36M group.

Table 2.6 Usable Analog Input Pins for R8C/36M Group

Operation Mode	Usable Input Pins
One-shot mode, repeat mode 0, repeat mode 1	1 pin selected from AN0 to AN11 and OCVREF.
Single sweep mode, repeat sweep mode	AN0 and AN1 (2 pins), AN8 and AN9 (2 pins), AN0 to AN3 (4 pins), AN8 to AN11 (4 pins), AN0 to AN5 (6 pins) or AN0 to AN7 (8 pins)

### 2.4.2 RL78/G14

Table 2.7 shows the analog input pins that can be used in each channel selection mode of the RL78/G14.

Table 2.7 Usable Analog Input Pins for RL78/G14

Channel Selection Mode	Usable Input Pins
Select mode	1 pin selected from ANI0 to ANI14, ANI16 to ANI20, internal reference voltage, and temperature sensor output voltage.
Scan mode	4 pins ANI0 to ANI3, ANI1 to ANI4, ANI2 to ANI5, ANI3 to ANI6, ANI4 to ANI7, ANI5 to ANI8, ANI6 to ANI9, ANI7 to ANI10, ANI8 to ANI11, ANI9 to ANI12, ANI10 to ANI13, and ANI11 to ANI14.

When ports are used as analog input pins for the RL78/G14, it is necessary to set the appropriate port-related registers including the PMC registers. For information, refer to section, Register Settings When Using Alternate Function, of the RL78/G14 User's Manual: Hardware.

## 2.5 Interrupt Operation

In repeat mode 1, single sweep mode, and repeat sweep mode of the R8C/36M group, an interrupt is generated when the A/D conversion on all the selected pins ends; however, with the RL78/G14, an interrupt is generated each time the A/D conversion on one pin ends.

### 3. Migration of A/D Converters by Using Sample Code Provided

This sample program implements in the RL78/G14, the R8C/36M group A/D converter operations by the method shown in Table 3.1.

For details on the sample program, refer to the following chapters.

Table 3.1 Migration from R8C/36M Group to RL78/G14 by Using This Sample Program

R8C/36M Group	RL78/G14		
Operation Mode	A/D Conversion Channel Selection Mode	A/D Conversion Operation Mode	Method of Transferring A/D Conversion Results
One-shot mode	Select mode	One-shot conversion mode	Interrupt processing
Repeat mode 0		Sequential conversion mode	Interrupt processing
Repeat mode 1			DTC transfer
Single sweep mode	Scan mode	One-shot conversion mode	DTC transfer
Repeat sweep mode		Sequential conversion mode	DTC transfer

## 4. Example of Migration from One-Shot Mode

### 4.1 Specifications

To implement R8C/36M one-shot mode in the RL78/G14, the AD converter (software trigger, select, one-shot conversion mode) is used. The A/D conversion results are stored in the RAM by interrupt processing.

The analog input voltage of one pin selected from the ANI0 to ANI3, ANI16 to ANI22, internal reference voltage, temperature sensor output, and PGAOUT pins is A/D-converted in select mode and one-shot conversion mode, and the A/D conversion result values are stored in the RAM assigned by software processing. Specifically, A/D conversion on the selected one pin is performed; When A/D conversion ends, the conversion result is stored in the 10-bit A/D conversion result register (ADCR), and an A/D conversion end interrupt request is generated. Finally, the A/D conversion result is transferred from the ADCR register to the RAM by interrupt processing.

Table 4.1 shows the peripheral function used and the purpose of use, and Figure 4.1 shows the operation summary.

Table 4.1 Peripheral Function Used and Purpose of Use (example of migration from one-shot mode)

Peripheral Function	Purpose of Use
A/D converter	Performs A/D conversion on the analog input voltage.




Figure 4.1 Operation Summary (example of migration from one-shot mode)

## 4.2 Conditions for Confirming Operations

The sample code operations described in this application note are confirmed under the following conditions.

Table 4.2 Conditions for Confirming Operations (example of migration from one-shot mode)

Item	Description
Microcontroller used	RL78/G14 (R5F104LEA)
Operating frequency	<ul style="list-style-type: none"> <li>High-speed on-chip oscillator clock (<math>f_{IH}</math>): 32 MHz</li> <li>CPU/peripheral hardware clock (<math>f_{CLK}</math>): 32 MHz</li> </ul>
Operating voltage	5.0 V (can be operated from 3.6 V to 5.5 V) LVD operation ( $V_{LVD}$ ): Reset mode; rise 3.13 V/fall 3.06 V
Integrated development environment (CS+)	CS+ for CC V5.00.00 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.
Integrated development environment (e <sup>2</sup> studio)	e <sup>2</sup> studio V5.4.0.015 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.

## 4.3 Hardware Descriptions

### 4.3.1 Hardware Configuration Example

Figure 4.2 shows an example of the hardware configuration used for this application.




Figure 4.2 Hardware Configuration (example of migration from one-shot mode)

### 4.3.2 List of Pins Used

Table 4.3 lists the pin used and its function.

Table 4.3 Pin Used and Its Function (example of migration from one-shot mode)

Pin Name	I/O	Function
P20/ANI0	Input	A/D converter input (ANI0)

## 4.4 Software Descriptions

### 4.4.1 Operation Summary

With this sample program, the A/D conversion on one pin is performed in select mode, and the conversion result is stored in the RAM by A/D conversion end interrupt processing.

Upon completion of the A/D conversion on the ANI0 pin, an A/D conversion end interrupt is generated. In interrupt processing, the A/D conversion result is transferred from the transfer source addresses (ADCR register (FFF1EH, FFF1FH)) to the transfer destination addresses (variable `g_ad_value` (FF500H to FF501H)). In addition, the A/D conversion result transferred is relocated in the lower 10 bits before being stored in the buffer for storing the A/D conversion results of ANI0 (variable `g_ad_an0_value`).

Table 4.4 shows the A/D converter settings.

Table 4.4 A/D Converter Settings (example of migration from one-shot mode)

Item to be Set	Settings
Conversion clock frequency ( $f_{AD}$ )	$f_{CLK}/8$
A/D conversion mode	<ul style="list-style-type: none"> <li>A/D conversion trigger mode: Software trigger</li> <li>A/D conversion channel selection mode: Select mode</li> <li>A/D conversion operation mode: One-shot conversion mode</li> </ul>
Resolution	10 bits
Analog input channel	ANI0
A/D conversion result comparison upper limit (ADUL register)	FFH
A/D conversion result comparison lower limit (ADLL register)	00H
Upper and lower limit conversion result checking	INTAD generated when $ADLL \text{ register} \leq ADCR \text{ register} \leq ADUL \text{ register}$

- (1) The initial setting is made for the A/D converter.
- (2) The ADCS bit in the ADM0 register is set to 1 (conversion enabled) to start A/D conversion.
- (3) Upon completion of the A/D conversion on the ANI0 pin, an A/D conversion end interrupt is generated.
- (4) In interrupt processing, the A/D conversion result is read from the ADCR register and transferred to the RAM (variable g\_ad\_value).

Also, the A/D conversion result (variable g\_ad\_value) is shifted to the right by 6 bits (relocated in the lower 10 bits) and stored in the variable g\_ad\_an0\_value.

Figure 4.3 shows the A/D conversion timing and Figure 4.4 shows the relationship between the ADCR register and RAM.




Figure 4.3 A/D Conversion Timing (example of migration from one-shot mode)




Figure 4.4 Relationship between ADCR Register and RAM (example of migration from one-shot mode)



#### 4.4.2 List of Option Byte Settings

Table 4.5 lists option byte settings.

Table 4.5 Option Byte Settings (example of migration from one-shot mode)

Address	Setting	Contents
000C0H/010C0H	01101110B	Watchdog timer is stopped. (Counting stopped after a reset release)
000C1H/010C1H	00110011B	LVD reset mode Detection voltage: rise 3.13 V/fall 3.06 V
000C2H/010C2H	11101000B	HS mode High-speed on-chip oscillator clock frequency: 32 MHz
000C3H/010C3H	10000100B	On-chip debugging is enabled.

#### 4.4.3 List of Constants

Table 4.6 lists the constant used in the sample code.

Table 4.6 Constant Used in Sample Code (example of migration from one-shot mode)

Constant Name	Setting	Contents
AD_RESULT_ADDR	0FF500H	Transfer destination address of A/D conversion result

#### 4.4.4 List of Variables

Table 4.7 lists the global variables.

Table 4.7 Global Variables (example of migration from one-shot mode)

Type	Variable Name	Contents	Function Used
uint16_t __near	g_ad_value	Buffer for storing A/D conversion results	r_adc_interrupt
uint16_t	g_ad_an0_value	Buffer for storing A/D conversion result of ANI0	r_adc_interrupt

#### 4.4.5 Functions

Table 4.8 lists the Functions.

Table 4.8 Functions (example of migration from one-shot mode)

Function Name	Outline
hdwinit	Initial setting
R_Systeminit	Initial setting of peripheral functions
R_CGC_Create	CPU initial setting
R_ADC_Create	Initial setting of A/D converter
main	Main processing
R_ADC_Start	A/D conversion start
r_adc_interrupt	A/D conversion interrupt

#### 4.4.6 Function Specifications

The following tables list the sample code function specifications.

hdwinit	
Outline	Initial setting
Header	None
Declaration	void hdwinit(void)
Description	Perform the initial setting of peripheral functions.
Argument	None
Return Value	None

R_Systeminit	
Outline	Initial setting of peripheral functions
Header	None
Declaration	void R_Systeminit(void)
Description	Perform the initial setting of peripheral functions used in this document.
Argument	None
Return Value	None

R_CGC_Create	
Outline	CPU initial setting
Header	None
Declaration	void R_CGC_Create(void)
Description	Perform the initial setting of the CPU.
Argument	None
Return Value	None

---

R_ADC_Create	
Outline	Initial setting of A/D converter
Header	None
Declaration	void R_ADC_Create(void)
Description	Perform the initial setting to use the A/D converter in software trigger mode, select mode, and one-shot conversion mode.
Argument	None
Return Value	None

---

main	
Outline	Main processing
Header	None
Declaration	void main(void)
Description	Perform main processing.
Argument	None
Return Value	None

---

R_ADC_Start	
Outline	A/D conversion start
Header	None
Declaration	void R_ADC_Start(void)
Description	Perform A/D conversion.
Argument	None
Return Value	None

---

r_adc_interrupt	
Outline	A/D conversion interrupt
Header	None
Declaration	static void __near r_adc_interrupt(void)
Description	Perform an A/D conversion end interrupt service routine.
Argument	None
Return Value	None

---

4.4.7 Flowcharts

(1) Overall Flowchart

Figure 4.5 shows the Overall Flowchart.




Figure 4.5 Overall Flowchart (example of migration from one-shot mode)

(2) Initial Setting

Figure 4.6 shows the Initial Setting.




Figure 4.6 Initial Setting (example of migration from one-shot mode)

(3) Initial Setting of Peripheral Functions

Figure 4.7 shows the initial setting of peripheral functions.




Figure 4.7 Initial Setting of Peripheral Functions (example of migration from one-shot mode)

(4) Initial Setting of CPU

Figure 4.8 shows the initial setting of the CPU.




Figure 4.8 Initial Setting of CPU (example of migration from one-shot mode)

(5) Initial Setting of A/D Converter

Figure 4.9 shows the initial setting of the A/D converter.




Figure 4.9 Initial Setting of A/D Converter (example of migration from one-shot mode)

Starting clock supply to A/D converter

- Peripheral enable register 0 (PER0)  
Starts supplying clock to the A/D converter.

Symbol	7	6	5	4	3	2	1	0
PER0	<b>RTCEN</b>	<b>IICA1EN</b>	<b>ADCEN</b>	<b>IICA0EN</b>	<b>SAU1EN</b>	<b>SAU0EN</b>	<b>TAU1EN</b>	<b>TAU0EN</b>
Set value	x	x	1	x	x	x	x	x

Bit 5

<b>ADCEN</b>	<b>Control of A/D converter input clock supply</b>
0	Stops input clock supply. Stops input clock supply. • SFR used by the A/D converter cannot be written.
1	<b>Enables input clock supply.</b> • SFR used by the A/D converter can be read and written.

Stopping A/D converter operation

- A/D converter mode register 0 (ADM0)  
Stops the A/D converter.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	0	x	x	x	x	x	x	0

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	<b>Stops conversion operation.</b> [When read] <b>Conversion stopped/standby status</b>
1	Enables conversion operation. [When read] While in the software trigger mode: Conversion operation status While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	<b>Stops A/D voltage comparator operation.</b>
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Disabling A/D conversion end interrupt

- Interrupt mask flag register 1 (MK1H)  
Disables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
0	No interrupt request signal is generated.
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.



Specifying A/D conversion end interrupt priority level

- Priority specification flag register (PR11H, PR01H)  
Specifies level 3 (lowest priority level).

Symbol	7	6	5	4	3	2	1	0
PR11H	<b>TMPR11</b> <b>0</b>	<b>TRJPR10</b>	<b>SRPR13</b> <b>CSIPR131</b> <b>IICPR131</b>	<b>STPR13</b> <b>CSIPR130</b> <b>IICPR130</b>	<b>KRPR1</b>	<b>ITPR1</b>	<b>RTCPR1</b>	<b>ADPR1</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Symbol	7	6	5	4	3	2	1	0
PR01H	<b>TMPR01</b> <b>0</b>	<b>TRJPR00</b>	<b>SRPR03</b> <b>CSIPR031</b> <b>IICPR031</b>	<b>STPR03</b> <b>CSIPR030</b> <b>IICPR030</b>	<b>KRPR0</b>	<b>ITPR0</b>	<b>RTCPR0</b>	<b>ADPR0</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADPR1</b>	<b>ADPR0</b>	<b>Priority level selection</b>
0	0	Specifies level 0 (high priority level).
0	1	Specifies level 1.
1	0	Specifies level 2.
<b>1</b>	<b>1</b>	<b>Specifies level 3 (low priority level).</b>

Setting port mode register 2

- Port mode register 2 (PM2)  
Sets the port mode register 2 to input mode.

Symbol	7	6	5	4	3	2	1	0
PM2	<b>PM27</b>	<b>PM26</b>	<b>PM25</b>	<b>PM24</b>	<b>PM23</b>	<b>PM22</b>	<b>PM21</b>	<b>PM20</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>PM20</b>	<b>P20 pin I/O mode selection</b>
0	Output mode (output buffer on)
<b>1</b>	<b>Input mode (output buffer off)</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion mode and conversion time

- A/D converter mode register 0 (ADM0)  
Sets the A/D conversion mode and conversion time.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	×	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	×

Bit 6

ADMD	Specification of A/D conversion channel selection mode
<b>0</b>	Select mode
<b>1</b>	Scan mode

Bits 5-1

A/D converter mode register 0 (ADM0)					Mode	Conversion time selection					Conv. clock (f <sub>AD</sub> )
FR2	FR1	FR0	LV1	LV0		f <sub>CLK</sub> = 1 MHz	f <sub>CLK</sub> = 4 MHz	f <sub>CLK</sub> = 8 MHz	f <sub>CLK</sub> = 16 MHz	f <sub>CLK</sub> = 32 MHz	
0	0	0	<b>0</b>	<b>0</b>	Normal 1	Setting prohibited	Setting prohibited	Setting prohibited	76 μs	38 μs	f <sub>CLK</sub> /64
0	0	1				76 μs	38 μs	19 μs	f <sub>CLK</sub> /32		
0	1	0				76 μs	38 μs	19 μs	9.5 μs	f <sub>CLK</sub> /16	
<b>0</b>	<b>1</b>	<b>1</b>				38 μs	19 μs	9.5 μs	<b>4.75 μs</b>	<b>f<sub>CLK</sub>/8</b>	
1	0	0				28.5 μs	14.25 μs	7.125 μs	3.5625 μs	f <sub>CLK</sub> /6	
1	0	1				95 μs	23.75 μs	11.875 μs	5.938 μs	2.9688 μs	f <sub>CLK</sub> /5
1	1	0				76 μs	19 μs	9.5 μs	4.75 μs	2.375 μs	f <sub>CLK</sub> /4
1	1	1				38 μs	9.5 μs	4.75 μs	2.375 μs	Setting prohibited	f <sub>CLK</sub> /2
0	0	0	0	1	Normal 2	Setting prohibited	Setting prohibited	Setting prohibited	68 μs	34 μs	f <sub>CLK</sub> /64
0	0	1				68 μs	34 μs	17 μs	f <sub>CLK</sub> /32		
0	1	0				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /16	
0	1	1				34 μs	17 μs	8.5 μs	4.25 μs	f <sub>CLK</sub> /8	
1	0	0				25.5 μs	12.75 μs	6.375 μs	3.1875 μs	f <sub>CLK</sub> /6	
1	0	1				85 μs	21.25 μs	10.625 μs	5.3125 μs	2.6563 μs	f <sub>CLK</sub> /5
1	1	0				68 μs	17 μs	8.5 μs	4.25 μs	2.125 μs	f <sub>CLK</sub> /4
1	1	1				34 μs	8.5 μs	4.25 μs	2.125 μs	Setting prohibited	f <sub>CLK</sub> /2

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 1 (ADM1)  
Selects the A/D conversion trigger mode.

Symbol	7	6	5	4	3	2	1	0
ADM1	<b>ADTMD1</b>	<b>ADTMD0</b>	<b>ADSCM</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ADTRS1</b>	<b>ADTRS0</b>
Set value	<b>0</b>	x	<b>1</b>	0	0	0	x	x

## Bits 7-6

ADTMD1	ADTMD0	Selection of A/D conversion trigger mode
<b>0</b>	-	<b>Software trigger mode</b>
1	0	Hardware trigger no-wait mode
1	1	Hardware trigger wait mode

## Bit 5

ADSCM	Specification of A/D conversion mode
0	Sequential conversion mode
<b>1</b>	<b>One-shot conversion mode</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 2 (ADM2)  
Selects the A/D converter reference voltage source, checks the conversion result against the upper-limit/lower-limit value, and selects A/D conversion resolution.

Symbol	7	6	5	4	3	2	1	0
ADM2	<b>ADREFP1</b>	<b>ADREFP0</b>	<b>ADREFM</b>	<b>0</b>	<b>ADRCK</b>	<b>AWC</b>	<b>0</b>	<b>ADTYP</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	0	<b>0</b>	×	0	<b>0</b>

## Bits 7-6

ADREFP1	ADREFP0	Selection of + side reference voltage source of A/D converter
<b>0</b>	<b>0</b>	<b>Supplied from V<sub>DD</sub></b>
0	1	Supplied from P20/AV <sub>REFP</sub> /ANI0
1	0	Supplied from internal reference voltage (1.45 V)
1	1	Setting prohibited

Before rewriting ADREFP1 or ADREFP0 bit, set ADREFP1 and ADREFP0 to 0 and 0.  
When setting ADREFP1 and ADREFP0 bits to 1 and 0, respectively, this must be configured in accordance with the following procedure:  
(1) Set ADCE = 0  
(2) Set ADREFP1 and ADREFP0 to 1 and 0, respectively.  
(3) Set ADCE = 1  
A wait time (T.B.D) is necessary after (2) and (3).  
When ADREFP1 and ADREFP0 are set to 1 and 0, respectively, A/D conversion cannot be performed on the temperature sensor output. Be sure to perform A/D conversion while ADISS = 0.

## Bit 5

ADREFM	Selection of – side reference voltage source of A/D converter
<b>0</b>	<b>Supplied from V<sub>SS</sub></b>
1	Supplied from P21/AV <sub>REFM</sub> /ANI1

## Bit 3

ADRCK	Checking upper limit and lower limit conversion result values
<b>0</b>	<b>Interrupt signal (INTAD) is generated when the ADLL register ≤ the ADCR register ≤ the ADUL register.</b>
1	Interrupt signal (INTAD) is generated when ADCR register < ADLL register, ADUL register < ADCR register.

## Bit 0

ADTYP	Selection of A/D conversion resolution
<b>0</b>	<b>10-bit resolution</b>
1	8-bit resolution

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Setting upper limit value for conversion result comparison

- Conversion result comparison upper limit setting register (ADUL)  
Sets the upper limit conversion result compare value to FFH.

Symbol	7	6	5	4	3	2	1	0
ADUL	<b>ADUL7</b>	<b>ADUL6</b>	<b>ADUL5</b>	<b>ADUL4</b>	<b>ADUL3</b>	<b>ADUL2</b>	<b>ADUL1</b>	<b>ADUL0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

Setting lower limit values for conversion result comparison

- Conversion result comparison lower limit setting register (ADLL)  
Sets the lower limit conversion result compare value to 00H.

Symbol	7	6	5	4	3	2	1	0
ADLL	<b>ADLL7</b>	<b>ADLL6</b>	<b>ADLL5</b>	<b>ADLL4</b>	<b>ADLL3</b>	<b>ADLL2</b>	<b>ADLL1</b>	<b>ADLL0</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting analog input channel

- Analog input channel specification register (ADS)  
Sets the analog input channel to ANI0.

Symbol	7	6	5	4	3	2	1	0
ADS	<b>ADISS</b>	<b>0</b>	<b>0</b>	<b>ADS4</b>	<b>ADS3</b>	<b>ADS2</b>	<b>ADS1</b>	<b>ADS0</b>
Set value	<b>0</b>	0	0	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

## - Select mode (ADMD = 0)

Bits 7, 4 to 0

ADISS	ADS4	ADS3	ADS2	ADS1	ADS0	Analog input channel	Input source
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ANI0</b>	<b>P20/ANI0/AV<sub>REFP</sub> pin</b>
0	0	0	0	0	1	ANI1	P21/ANI1/AV <sub>REFM</sub> pin
0	0	0	0	1	0	ANI2	P22/ANI2 pin
0	0	0	0	1	1	ANI3	P23/ANI3 pin
0	0	0	1	0	0	ANI4	P24/ANI4 pin
0	0	0	1	0	1	ANI5	P25/ANI5 pin
0	0	0	1	1	0	ANI6	P26/ANI6 pin
0	0	0	1	1	1	ANI7	P27/ANI7 pin
0	0	1	0	0	0	ANI8	P150/ANI8 pin
0	0	1	0	0	1	ANI9	P151/ANI9 pin
0	0	1	0	1	0	ANI10	P152/ANI10 pin
0	0	1	0	1	1	ANI11	P153/ANI11 pin
0	0	1	1	0	0	ANI12	P154/ANI12 pin
0	0	1	1	0	1	ANI13	P155/ANI13 pin
0	0	1	1	1	0	ANI14	P156/ANI14 pin
0	1	0	0	0	0	ANI16	P03/ANI16 pin
0	1	0	0	0	1	ANI17	P02/ANI17 pin
0	1	0	0	1	0	ANI18	P147/ANI18 pin
0	1	0	0	1	1	ANI19	P120/ANI19 pin
0	1	0	1	0	0	ANI20	P100/ANI20 pin
1	0	0	0	0	0	—	Temperature sensor output voltage
1	0	0	0	0	1	—	Internal reference voltage (1.45 V)
Other than above						Setting prohibited	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D voltage comparator

- A/D converter mode register 0 (ADM0)  
Starts A/D voltage comparator operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	Stops A/D voltage comparator operation.
<b>1</b>	<b>Enables A/D voltage comparator operation.</b>

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

(6) Main Processing

Figure 4.10 shows the flowchart for the main processing.




Figure 4.10 Main Processing (example of migration from one-shot mode)

(7) Starting A/D Conversion

Figure 4.11 shows the flowchart for starting A/D conversion.




Figure 4.11 Starting A/D Conversion (example of migration from one-shot mode)



## Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

## Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
<b>0</b>	<b>No interrupt request signal is generated</b>
<b>1</b>	Interrupt request is generated, interrupt request status

## Enabling A/D conversion end interrupt

- Interrupt mask flag register (MK1H)  
Enables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

## Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
<b>0</b>	<b>Interrupt servicing enabled</b>
<b>1</b>	Interrupt servicing disabled

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Starting A/D converter

- A/D converter mode register 0 (ADM0)  
Starts A/D conversion operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	<b>1</b>	x	x	x	x	x	x	x

## Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	Stops conversion operation [When read] Conversion stopped/standby status
1	<b>Enables conversion operation</b> [When read] <b>While in the software trigger mode: Conversion operation status</b> <b>While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(8) A/D conversion end interrupt

Figure 4.12 shows the flowchart for A/D conversion end interrupt processing.




Figure 4.12 A/D Conversion End Interrupt (example of migration from one-shot mode)

#### 4.5 Sample Code

Sample code can be downloaded from the Renesas Electronics website.

#### 4.6 Reference Application Note

- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: A/D Converter CC-RL (R01AN3059)

#### 4.7 Reference Documents

##### User's Manual

- RL78/G14 User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- R8C/36M Group User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- Technical Update/Technical News  
(The latest information can be downloaded from the Renesas Electronics website.)

##### Migration Guide

- Migration to CubeSuite+ Integrated Development Environment for RL78 Family  
(On-chip Debug) - Migration from R8C, M16C to RL78 (R20UT2150)

## 5. Example of Migration from Repeat Mode 0

### 5.1 Specifications

To implement R8C/36M repeat mode 0 in the RL78/G14, the AD converter (software trigger, select, sequential conversion mode) is used. The A/D conversion results are stored in the RAM by interrupt processing.

The analog input voltage of one pin selected from the ANI0 to ANI3, ANI16 to ANI22, internal reference voltage, temperature sensor output, and PGAOUT pins is A/D-converted in select mode and sequential conversion mode, and the A/D conversion result values are stored in the RAM assigned by software processing. Specifically, A/D conversion on the selected one pin is sequentially performed; each time A/D conversion ends, the conversion result is stored in the 10-bit A/D conversion result register (ADCR), and an A/D conversion end interrupt request is generated. Finally, the A/D conversion result is transferred from the ADCR register to the RAM by interrupt processing.

Table 5.1 shows the peripheral function used and the purpose of use, and Figure 5.1 shows the operation summary.

Table 5.1 Peripheral Function Used and Purpose of Use (example of migration from repeat mode 0)

Peripheral Function	Purpose of Use
A/D converter	Performs A/D conversion on the analog input voltage.




Figure 5.1 Operation Summary (example of migration from repeat mode 0)

## 5.2 Conditions for Confirming Operations

The sample code operations described in this application note are confirmed under the following conditions.

Table 5.2 Conditions for Confirming Operations (example of migration from repeat mode 0)

Item	Description
Microcontroller used	RL78/G14 (R5F104LEA)
Operating frequency	<ul style="list-style-type: none"> <li>High-speed on-chip oscillator clock (<math>f_{IH}</math>): 32 MHz</li> <li>CPU/peripheral hardware clock (<math>f_{CLK}</math>): 32 MHz</li> </ul>
Operating voltage	5.0 V (can be operated from 3.6 V to 5.5 V) LVD operation ( $V_{LVD}$ ): Reset mode; rise 3.13 V/fall 3.06 V
Integrated development environment (CS+)	CS+ for CC V5.00.00 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.
Integrated development environment (e <sup>2</sup> studio)	e <sup>2</sup> studio V5.4.0.015 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.

## 5.3 Hardware Descriptions

### 5.3.1 Hardware Configuration Example

Figure 5.2 shows an example of the hardware configuration used for this application.




Figure 5.2 Hardware Configuration (example of migration from repeat mode 0)

### 5.3.2 List of Pins Used

Table 5.3 lists the pin used and its function.

Table 5.3 Pin Used and Its Function (example of migration from repeat mode 0)

Pin Name	I/O	Function
P20/ANI0	Input	A/D converter input (ANI0)

## 5.4 Software Descriptions

### 5.4.1 Operation Summary

With this sample program, the A/D conversion on one pin is performed in select mode, and the conversion result is stored in the RAM by A/D conversion end interrupt processing. By setting sequential conversion mode, A/D conversion is repeated.

Upon completion of the A/D conversion on the ANI0 pin, an A/D conversion end interrupt is generated. In interrupt processing, the A/D conversion result is transferred from the transfer source addresses (ADCR register (FFF1EH, FFF1FH)) to the transfer destination addresses (variable `g_ad_value` (FF500H to FF501H)). In addition, the A/D conversion result transferred is relocated in the lower 10 bits before being stored in the buffer for storing the A/D conversion results of ANI0 (variable `g_ad_an0_value`).

Table 5.4 shows the A/D converter settings.

Table 5.4 A/D Converter Settings (example of migration from repeat mode 0)

Item to be Set	Settings
Conversion clock frequency ( $f_{AD}$ )	$f_{CLK}/8$
A/D conversion mode	<ul style="list-style-type: none"> <li>A/D conversion trigger mode: Software trigger</li> <li>A/D conversion channel selection mode: Select mode</li> <li>A/D conversion operation mode: Sequential conversion mode</li> </ul>
Resolution	10 bits
Analog input channel	ANI0
A/D conversion result comparison upper limit (ADUL register)	FFH
A/D conversion result comparison lower limit (ADLL register)	00H
Upper and lower limit conversion result checking	INTAD generated when $ADLL \text{ register} \leq ADCR \text{ register} \leq ADUL \text{ register}$

- (1) The initial setting is made for the A/D converter.
- (2) The ADCS bit in the ADM0 register is set to 1 (conversion enabled) to start A/D conversion.
- (3) Upon completion of the A/D conversion on the ANI0 pin, an A/D conversion end interrupt is generated.
- (4) In interrupt processing, the A/D conversion result is read from the ADCR register and transferred to the RAM (variable g\_ad\_value).

Also, the A/D conversion result (variable g\_ad\_value) is shifted to the right by 6 bits (relocated in the lower 10 bits) and stored in the variable g\_ad\_an0\_value.

- (5) After this, A/D conversion is sequentially performed, where steps (3) and (4) are repeated.

Figure 5.3 shows the A/D conversion timing and Figure 5.4 shows the relationship between the ADCR register and RAM.




Figure 5.3 A/D Conversion Timing (example of migration from repeat mode 0)




Figure 5.4 Relationship between ADCR Register and RAM (example of migration from repeat mode 0)



#### 5.4.2 List of Option Byte Settings

Table 5.5 lists option byte settings.

Table 5.5 Option Byte Settings (example of migration from repeat mode 0)

Address	Setting	Contents
000C0H/010C0H	01101110B	Watchdog timer is stopped. (Counting stopped after a reset release)
000C1H/010C1H	00110011B	LVD reset mode Detection voltage: rise 3.13 V/fall 3.06 V
000C2H/010C2H	11101000B	HS mode High-speed on-chip oscillator clock frequency: 32 MHz
000C3H/010C3H	10000100B	On-chip debugging is enabled.

#### 5.4.3 List of Constants

Table 5.6 lists the constant used in the sample code.

Table 5.6 Constant Used in Sample Code (example of migration from repeat mode 0)

Constant Name	Setting	Contents
AD_RESULT_ADDR	0FF500H	Transfer destination address of A/D conversion result

#### 5.4.4 List of Variables

Table 5.7 lists the global variables.

Table 5.7 Global Variables (example of migration from repeat mode 0)

Type	Variable Name	Contents	Function Used
uint16_t __near	g_ad_value	Buffer for storing A/D conversion results	r_adc_interrupt
uint16_t	g_ad_an0_value	Buffer for storing A/D conversion result of ANI0	r_adc_interrupt

### 5.4.5 Functions

Table 5.8 lists the Functions.

Table 5.8 Functions (example of migration from repeat mode 0)

Function Name	Outline
hdwinit	Initial setting
R_Systeminit	Initial setting of peripheral functions
R_CGC_Create	CPU initial setting
R_ADC_Create	Initial setting of A/D converter
main	Main processing
R_ADC_Start	A/D conversion start
r_adc_interrupt	A/D conversion interrupt

### 5.4.6 Function Specifications

The following tables list the sample code function specifications.

hdwinit	
Outline	Initial setting
Header	None
Declaration	void hdwinit(void)
Description	Perform the initial setting of peripheral functions.
Argument	None
Return Value	None

R_Systeminit	
Outline	Initial setting of peripheral functions
Header	None
Declaration	void R_Systeminit(void)
Description	Perform the initial setting of peripheral functions used in this document.
Argument	None
Return Value	None

R_CGC_Create	
Outline	CPU initial setting
Header	None
Declaration	void R_CGC_Create(void)
Description	Perform the initial setting of the CPU.
Argument	None
Return Value	None

---

R_ADC_Create	
Outline	Initial setting of A/D converter
Header	None
Declaration	void R_ADC_Create(void)
Description	Perform the initial setting to use the A/D converter in software trigger mode, select mode, and sequential conversion mode.
Argument	None
Return Value	None

---

main	
Outline	Main processing
Header	None
Declaration	void main(void)
Description	Perform main processing.
Argument	None
Return Value	None

---

R_ADC_Start	
Outline	A/D conversion start
Header	None
Declaration	void R_ADC_Start(void)
Description	Perform A/D conversion.
Argument	None
Return Value	None

---

r_adc_interrupt	
Outline	A/D conversion interrupt
Header	None
Declaration	static void __near r_adc_interrupt(void)
Description	Perform an A/D conversion end interrupt service routine.
Argument	None
Return Value	None

---

5.4.7 Flowcharts

(1) Overall Flowchart

Figure 5.5 shows the Overall Flowchart.




Figure 5.5 Overall Flowchart (example of migration from repeat mode 0)

(2) Initial Setting

Figure 5.6 shows the Initial Setting.




Figure 5.6 Initial Setting (example of migration from repeat mode 0)

(3) Initial Setting of Peripheral Functions

Figure 5.7 shows the initial setting of peripheral functions.




Figure 5.7 Initial Setting of Peripheral Functions (example of migration from repeat mode 0)

(4) Initial Setting of CPU

Figure 5.8 shows the initial setting of the CPU.




Figure 5.8 Initial Setting of CPU (example of migration from repeat mode 0)

(5) Initial Setting of A/D Converter

Figure 5.9 shows the initial setting of the A/D converter.




Figure 5.9 Initial Setting of A/D Converter (example of migration from repeat mode 0)

Starting clock supply to A/D converter

- Peripheral enable register 0 (PER0)  
Starts supplying clock to the A/D converter.

Symbol	7	6	5	4	3	2	1	0
PER0	<b>RTCEN</b>	<b>IICA1EN</b>	<b>ADCEN</b>	<b>IICA0EN</b>	<b>SAU1EN</b>	<b>SAU0EN</b>	<b>TAU1EN</b>	<b>TAU0EN</b>
Set value	x	x	1	x	x	x	x	x

Bit 5

<b>ADCEN</b>	<b>Control of A/D converter input clock supply</b>
0	Stops input clock supply. Stops input clock supply. • SFR used by the A/D converter cannot be written.
1	<b>Enables input clock supply.</b> • SFR used by the A/D converter can be read and written.

Stopping A/D converter operation

- A/D converter mode register 0 (ADM0)  
Stops the A/D converter.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	0	x	x	x	x	x	x	0

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	<b>Stops conversion operation.</b> [When read] <b>Conversion stopped/standby status</b>
1	Enables conversion operation. [When read] While in the software trigger mode: Conversion operation status While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	<b>Stops A/D voltage comparator operation.</b>
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Disabling A/D conversion end interrupt

- Interrupt mask flag register 1 (MK1H)  
Disables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	×	×	×	×	×	×	×	<b>1</b>

## Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

## Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	×	×	×	×	×	×	×	<b>0</b>

## Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
0	No interrupt request signal is generated.
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.



Specifying A/D conversion end interrupt priority level

- Priority specification flag register (PR11H, PR01H)  
Specifies level 3 (lowest priority level).

Symbol	7	6	5	4	3	2	1	0
PR11H	<b>TMPR11</b> 0	<b>TRJPR10</b>	<b>SRPR13</b> <b>CSIPR131</b> <b>IICPR131</b>	<b>STPR13</b> <b>CSIPR130</b> <b>IICPR130</b>	<b>KRPR1</b>	<b>ITPR1</b>	<b>RTCPR1</b>	<b>ADPR1</b>
Set value	x	x	x	x	x	x	x	1

Symbol	7	6	5	4	3	2	1	0
PR01H	<b>TMPR01</b> 0	<b>TRJPR00</b>	<b>SRPR03</b> <b>CSIPR031</b> <b>IICPR031</b>	<b>STPR03</b> <b>CSIPR030</b> <b>IICPR030</b>	<b>KRPR0</b>	<b>ITPR0</b>	<b>RTCPR0</b>	<b>ADPR0</b>
Set value	x	x	x	x	x	x	x	1

Bit 0

ADPR1	ADPR0	Priority level selection
0	0	Specifies level 0 (high priority level).
0	1	Specifies level 1.
1	0	Specifies level 2.
1	1	<b>Specifies level 3 (low priority level).</b>

Setting port mode register 2

- Port mode register 2 (PM2)  
Sets the port mode register 2 to input mode.

Symbol	7	6	5	4	3	2	1	0
PM2	<b>PM27</b>	<b>PM26</b>	<b>PM25</b>	<b>PM24</b>	<b>PM23</b>	<b>PM22</b>	<b>PM21</b>	<b>PM20</b>
Set value	x	x	x	x	x	x	x	1

Bit 0

PM20	P20 pin I/O mode selection
0	Output mode (output buffer on)
1	<b>Input mode (output buffer off)</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion mode and conversion time

- A/D converter mode register 0 (ADM0)  
Sets the A/D conversion mode and conversion time.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	×	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	×

Bit 6

ADMD	Specification of A/D conversion channel selection mode
<b>0</b>	Select mode
<b>1</b>	Scan mode

Bits 5-1

A/D converter mode register 0 (ADM0)					Mode	Conversion time selection					Conv. clock (f <sub>AD</sub> )
FR2	FR1	FR0	LV1	LV0		f <sub>CLK</sub> = 1 MHz	f <sub>CLK</sub> = 4 MHz	f <sub>CLK</sub> = 8 MHz	f <sub>CLK</sub> = 16 MHz	f <sub>CLK</sub> = 32 MHz	
0	0	0	<b>0</b>	<b>0</b>	Normal 1	Setting prohibited	Setting prohibited	Setting prohibited	76 μs	38 μs	f <sub>CLK</sub> /64
0	0	1				76 μs	38 μs	19 μs	f <sub>CLK</sub> /32		
0	1	0				76 μs	38 μs	19 μs	9.5 μs	f <sub>CLK</sub> /16	
<b>0</b>	<b>1</b>	<b>1</b>				38 μs	19 μs	9.5 μs	<b>4.75 μs</b>	<b>f<sub>CLK</sub>/8</b>	
1	0	0				28.5 μs	14.25 μs	7.125 μs	3.5625 μs	f <sub>CLK</sub> /6	
1	0	1				95 μs	23.75 μs	11.875 μs	5.938 μs	2.9688 μs	f <sub>CLK</sub> /5
1	1	0				76 μs	19 μs	9.5 μs	4.75 μs	2.375 μs	f <sub>CLK</sub> /4
1	1	1				38 μs	9.5 μs	4.75 μs	2.375 μs	Setting prohibited	f <sub>CLK</sub> /2
0	0	0	0	1	Normal 2	Setting prohibited	Setting prohibited	Setting prohibited	68 μs	34 μs	f <sub>CLK</sub> /64
0	0	1				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /32	
0	1	0				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /16	
0	1	1				34 μs	17 μs	8.5 μs	4.25 μs	f <sub>CLK</sub> /8	
1	0	0				25.5 μs	12.75 μs	6.375 μs	3.1875 μs	f <sub>CLK</sub> /6	
1	0	1				85 μs	21.25 μs	10.625 μs	5.3125 μs	2.6563 μs	f <sub>CLK</sub> /5
1	1	0				68 μs	17 μs	8.5 μs	4.25 μs	2.125 μs	f <sub>CLK</sub> /4
1	1	1				34 μs	8.5 μs	4.25 μs	2.125 μs	Setting prohibited	f <sub>CLK</sub> /2

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 1 (ADM1)  
Selects the A/D conversion trigger mode.

Symbol	7	6	5	4	3	2	1	0
ADM1	<b>ADTMD1</b>	<b>ADTMD0</b>	<b>ADSCM</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ADTRS1</b>	<b>ADTRS0</b>
Set value	<b>0</b>	x	<b>0</b>	0	0	0	x	x

## Bits 7-6

ADTMD1	ADTMD0	Selection of A/D conversion trigger mode
<b>0</b>	-	<b>Software trigger mode</b>
1	0	Hardware trigger no-wait mode
1	1	Hardware trigger wait mode

## Bit 5

ADSCM	Specification of A/D conversion mode
<b>0</b>	<b>Sequential conversion mode</b>
1	One-shot conversion mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion trigger mode

- A/D converter mode register 2 (ADM2)  
Selects the A/D converter reference voltage source, checks the conversion result against the upper-limit/lower-limit value, and selects A/D conversion resolution.

Symbol	7	6	5	4	3	2	1	0
ADM2	<b>ADREFP1</b>	<b>ADREFP0</b>	<b>ADREFM</b>	<b>0</b>	<b>ADRCK</b>	<b>AWC</b>	<b>0</b>	<b>ADTYP</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	0	<b>0</b>	x	0	<b>0</b>

Bits 7-6

<b>ADREFP1</b>	<b>ADREFP0</b>	<b>Selection of + side reference voltage source of A/D converter</b>
<b>0</b>	<b>0</b>	<b>Supplied from V<sub>DD</sub></b>
0	1	Supplied from P20/AV <sub>REFP</sub> /ANI0
1	0	Supplied from internal reference voltage (1.45 V)
1	1	Setting prohibited

Before rewriting ADREFP1 or ADREFP0 bit, set ADREFP1 and ADREFP0 to 0 and 0.  
When setting ADREFP1 and ADREFP0 bits to 1 and 0, respectively, this must be configured in accordance with the following procedure:  
(1) Set ADCE = 0  
(2) Set ADREFP1 and ADREFP0 to 1 and 0, respectively.  
(3) Set ADCE = 1  
A wait time (T.B.D) is necessary after (2) and (3).  
When ADREFP1 and ADREFP0 are set to 1 and 0, respectively, A/D conversion cannot be performed on the temperature sensor output. Be sure to perform A/D conversion while ADISS = 0.

Bit 5

<b>ADREFM</b>	<b>Selection of – side reference voltage source of A/D converter</b>
<b>0</b>	<b>Supplied from V<sub>SS</sub></b>
1	Supplied from P21/AV <sub>REFM</sub> /ANI1

Bit 3

<b>ADRCK</b>	<b>Checking upper limit and lower limit conversion result values</b>
<b>0</b>	<b>Interrupt signal (INTAD) is generated when the ADLL register ≤ the ADCR register ≤ the ADUL register.</b>
1	Interrupt signal (INTAD) is generated when ADCR register < ADLL register, ADUL register < ADCR register.

Bit 0

<b>ADTYP</b>	<b>Selection of A/D conversion resolution</b>
<b>0</b>	<b>10-bit resolution</b>
1	8-bit resolution

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Setting upper limit value for conversion result comparison

- Conversion result comparison upper limit setting register (ADUL)  
Sets the upper limit conversion result compare value to FFH.

Symbol	7	6	5	4	3	2	1	0
ADUL	<b>ADUL7</b>	<b>ADUL6</b>	<b>ADUL5</b>	<b>ADUL4</b>	<b>ADUL3</b>	<b>ADUL2</b>	<b>ADUL1</b>	<b>ADUL0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

Setting lower limit values for conversion result comparison

- Conversion result comparison lower limit setting register (ADLL)  
Sets the lower limit conversion result compare value to 00H.

Symbol	7	6	5	4	3	2	1	0
ADLL	<b>ADLL7</b>	<b>ADLL6</b>	<b>ADLL5</b>	<b>ADLL4</b>	<b>ADLL3</b>	<b>ADLL2</b>	<b>ADLL1</b>	<b>ADLL0</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting analog input channel

- Analog input channel specification register (ADS)  
Sets the analog input channel to ANI0.

Symbol	7	6	5	4	3	2	1	0
ADS	<b>ADISS</b>	<b>0</b>	<b>0</b>	<b>ADS4</b>	<b>ADS3</b>	<b>ADS2</b>	<b>ADS1</b>	<b>ADS0</b>
Set value	<b>0</b>	0	0	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

## - Select mode (ADMD = 0)

Bits 7, 4 to 0

ADISS	ADS4	ADS3	ADS2	ADS1	ADS0	Analog input channel	Input source
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ANI0</b>	<b>P20/ANI0/AV<sub>REFP</sub> pin</b>
0	0	0	0	0	1	ANI1	P21/ANI1/AV <sub>REFM</sub> pin
0	0	0	0	1	0	ANI2	P22/ANI2 pin
0	0	0	0	1	1	ANI3	P23/ANI3 pin
0	0	0	1	0	0	ANI4	P24/ANI4 pin
0	0	0	1	0	1	ANI5	P25/ANI5 pin
0	0	0	1	1	0	ANI6	P26/ANI6 pin
0	0	0	1	1	1	ANI7	P27/ANI7 pin
0	0	1	0	0	0	ANI8	P150/ANI8 pin
0	0	1	0	0	1	ANI9	P151/ANI9 pin
0	0	1	0	1	0	ANI10	P152/ANI10 pin
0	0	1	0	1	1	ANI11	P153/ANI11 pin
0	0	1	1	0	0	ANI12	P154/ANI12 pin
0	0	1	1	0	1	ANI13	P155/ANI13 pin
0	0	1	1	1	0	ANI14	P156/ANI14 pin
0	1	0	0	0	0	ANI16	P03/ANI16 pin
0	1	0	0	0	1	ANI17	P02/ANI17 pin
0	1	0	0	1	0	ANI18	P147/ANI18 pin
0	1	0	0	1	1	ANI19	P120/ANI19 pin
0	1	0	1	0	0	ANI20	P100/ANI20 pin
1	0	0	0	0	0	—	Temperature sensor output voltage
1	0	0	0	0	1	—	Internal reference voltage (1.45 V)
Other than above						Setting prohibited	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D voltage comparator

- A/D converter mode register 0 (ADM0)  
Starts A/D voltage comparator operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	Stops A/D voltage comparator operation.
<b>1</b>	<b>Enables A/D voltage comparator operation.</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(6) Main Processing

Figure 5.10 shows the flowchart for the main processing.




Figure 5.10 Main Processing (example of migration from repeat mode 0)

(7) Starting A/D Conversion

Figure 5.11 shows the flowchart for starting A/D conversion.




Figure 5.11 Starting A/D Conversion (example of migration from repeat mode 0)



## Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

## Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
<b>0</b>	<b>No interrupt request signal is generated</b>
<b>1</b>	Interrupt request is generated, interrupt request status

## Enabling A/D conversion end interrupt

- Interrupt mask flag register (MK1H)  
Enables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

## Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
<b>0</b>	<b>Interrupt servicing enabled</b>
<b>1</b>	Interrupt servicing disabled

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Starting A/D converter

- A/D converter mode register 0 (ADM0)  
Starts A/D conversion operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	<b>1</b>	x	x	x	x	x	x	x

Bit 7	
<b>ADCS</b>	<b>A/D conversion operation control</b>
0	Stops conversion operation [When read] Conversion stopped/standby status
1	<b>Enables conversion operation</b> [When read] <b>While in the software trigger mode: Conversion operation status</b> <b>While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(8) A/D conversion end interrupt

Figure 5.12 shows the flowchart for A/D conversion end interrupt processing.




Figure 5.12 A/D Conversion End Interrupt (example of migration from repeat mode 0)

## 5.5 Sample Code

Sample code can be downloaded from the Renesas Electronics website.

## 5.6 Reference Application Note

- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: A/D Converter CC-RL (R01AN3059)
- RL78/G13 A/D Converter (Software Trigger and Sequential Conversion Modes) CC-RL (R01AN2581)

## 5.7 Reference Documents

### User's Manual

- RL78/G14 User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- R8C/36M Group User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- Technical Update/Technical News  
(The latest information can be downloaded from the Renesas Electronics website.)

### Migration Guide

- Migration to CubeSuite+ Integrated Development Environment for RL78 Family  
(On-chip Debug) - Migration from R8C, M16C to RL78 (R20UT2150)

## 6. Example of Migration from Repeat Mode 1

### 6.1 Specifications

To implement R8C/36M repeat mode 1 in the RL78/G14, the AD converter (software trigger, select, sequential conversion mode) and DTC transfer (repeat mode) are used.

The analog input voltage of one pin selected from ANI0 to ANI3, ANI16 to ANI22, internal reference voltage, temperature sensor output, and PGAOUT pins is A/D-converted in select mode and sequential conversion mode, and the A/D conversion result values are stored in the RAM corresponding to the number of A/D conversions (one to eight) by DTC transfer. Specifically, A/D conversion on the selected one pin is sequentially performed; each time A/D conversion ends, the conversion result is stored in the 10-bit A/D conversion result register (ADCR), and an A/D conversion end interrupt signal is generated. In response to the interrupt signal, the DTC is activated, and the A/D conversion result is transferred from the ADCR register to the RAM. When A/D conversion and DTC transfer are performed eight times, an A/D conversion end interrupt request is generated.

Table 6.1 shows the peripheral functions used and the purpose of use, and Figure 6.1 shows the operation summary.

Table 6.1 Peripheral Functions Used and Purpose of Use (example of migration from repeat mode 1)

Peripheral Function	Purpose of Use
A/D converter	Performs A/D conversion on the analog input voltage.
DTC	Transfers A/D conversion results to RAM.




Figure 6.1 Operation Summary (example of migration from repeat mode 1)

## 6.2 Conditions for Confirming Operations

The sample code operations described in this application note are confirmed under the following conditions.

Table 6.2 Conditions for Confirming Operations (example of migration from repeat mode 1)

Item	Description
Microcontroller used	RL78/G14 (R5F104LEA)
Operating frequency	<ul style="list-style-type: none"> <li>High-speed on-chip oscillator clock (<math>f_{IH}</math>): 32 MHz</li> <li>CPU/peripheral hardware clock (<math>f_{CLK}</math>): 32 MHz</li> </ul>
Operating voltage	5.0 V (can be operated from 3.6 V to 5.5 V) LVD operation ( $V_{LVD}$ ): Reset mode; rise 3.13 V/fall 3.06 V
Integrated development environment (CS+)	CS+ for CC V5.00.00 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.
Integrated development environment (e <sup>2</sup> studio)	e <sup>2</sup> studio V5.4.0.015 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.

## 6.3 Hardware Descriptions

### 6.3.1 Hardware Configuration Example

Figure 6.2 shows an example of the hardware configuration used for this application.




Figure 6.2 Hardware Configuration (example of migration from repeat mode 1)

### 6.3.2 List of Pins Used

Table 6.3 lists the pin used and its function.

Table 6.3 Pin Used and Its Function (example of migration from repeat mode 1)

Pin Name	I/O	Function
P20/ANI0	Input	A/D converter input (ANI0)

## 6.4 Software Descriptions

### 6.4.1 Operation Summary

With this sample program, the A/D conversion on one pin is performed in select mode, and the conversion results are stored in the RAM by DTC transfer. By setting sequential conversion mode, A/D conversion is repeated.

Upon completion of the first A/D conversion on the ANI0 pin, the first DTC transfer is performed from the transfer source addresses (ADCR register (FFF1EH, FFF1FH)) to the transfer destination addresses (g\_ad\_value[0] (FF500H to FF501H)). Upon completion of the second A/D conversion on the ANI0 pin, the second DTC transfer is performed to g\_ad\_value[1] (FF502H to FF503H) since the transfer destination is set as the repeat area. Similarly, the third to eighth A/D conversion results are DTC-transferred. Upon completion of the eighth transfer, an A/D conversion end interrupt is generated.

In interrupt processing, the A/D conversion results corresponding to the number of A/D conversion times (1 to 8) stored in the array g\_ad\_value[] (FF500H to FF515H) are relocated in the lower 10 bits before being stored in the buffer for storing the A/D conversion results (variable g\_ad\_an0\_value1 to g\_ad\_an0\_value8).

After this, the above sequence is repeated to update the acquired A/D conversion results.

Table 6.4 shows the A/D converter settings and Table 6.5 shows the DTC settings.

Table 6.4 A/D Converter Settings (example of migration from repeat mode 1)

Item to be Set	Settings
Conversion clock frequency (f <sub>AD</sub> )	f <sub>CLK</sub> /8
A/D conversion mode	<ul style="list-style-type: none"> <li>A/D conversion trigger mode: Software trigger</li> <li>A/D conversion channel selection mode: Select mode</li> <li>A/D conversion operation mode: Sequential conversion mode</li> </ul>
Resolution	10 bits
Analog input channel	ANI0
A/D conversion result comparison upper limit (ADUL register)	FFH
A/D conversion result comparison lower limit (ADLL register)	00H
Upper and lower limit conversion result checking	INTAD generated when ADLL register ≤ ADCR register ≤ ADUL register

Table 6.5 DTC Settings (example of migration from repeat mode 1)

Item to be Set	Settings
	Control Data 0
Transfer mode	Repeat mode
Repeat mode interrupt	Enabled
Source address control	Fixed
Destination address control	Repeat area
Chain transfer control	Disabled
Transfer block size	2 bytes (16-bit transfer)
DTC transfer count	8
Transfer source address	ADCR (FFF1EH to FFF1FH)
Transfer destination address	g_ad_value[0] (FF500H to FF501H), g_ad_value[1] (FF502H to FF503H), g_ad_value[2] (FF504H to FF505H), g_ad_value[3] (FF506H to FF507H), g_ad_value[4] (FF508H to FF509H), g_ad_value[5] (FF510H to FF511H), g_ad_value[6] (FF512H to FF513H), g_ad_value[7] (FF514H to FF515H)

- (1) The initial setting is made for the A/D converter and DTC.
- (2) The ADCS bit in the ADM0 register is set to 1 (conversion enabled) to start A/D conversion.
- (3) Upon completion of the A/D conversion on the ANI0 pin, the DTC is activated.
- (4) The DTC reads the A/D conversion result from the ADCR register and transfers it to the RAM (g\_ad\_value[0] to g\_ad\_value[7]) corresponding to the number of A/D conversion times (1 to 8).
- (5) Upon completion of the eighth DTC transfer, an A/D conversion end interrupt is generated.
- (6) In interrupt processing, DTC activation is again enabled. Also, the A/D conversion results g\_ad\_value[0] to g\_ad\_value[7] are shifted to the right by 6 bits (relocated in the lower 10 bits) and stored in the variables g\_ad\_an0\_value1 to g\_ad\_an0\_value8.
- (7) After this, steps (2) to (6) are repeated.

Figure 6.3 shows the A/D conversion and DTC transfer timing and Figure 6.4 shows the relationship between the ADCR register and RAM.






Figure 6.3 A/D Conversion and DTC Transfer Timing (example of migration from repeat mode 1)




Figure 6.4 Relationship between ADCR Register and RAM (example of migration from repeat mode 1)

### 6.4.2 List of Option Byte Settings

Table 6.6 lists option byte settings.

Table 6.6 Option Byte Settings (example of migration from repeat mode 1)

Address	Setting	Contents
000C0H/010C0H	01101110B	Watchdog timer is stopped. (Counting stopped after a reset release)
000C1H/010C1H	00110011B	LVD reset mode Detection voltage: rise 3.13 V/fall 3.06 V
000C2H/010C2H	11101000B	HS mode High-speed on-chip oscillator clock frequency: 32 MHz
000C3H/010C3H	10000100B	On-chip debugging is enabled.

### 6.4.3 List of Constants

Table 6.7 lists the constant used in the sample code.

Table 6.7 Constant Used in Sample Code (example of migration from repeat mode 1)

Constant Name	Setting	Contents
AD_RESULT_ADDR	0FF500H	Transfer destination address of A/D conversion result

#### 6.4.4 List of Variables

Table 6.8 lists the global variables.

Table 6.8 Global Variables (example of migration from repeat mode 1)

Type	Variable Name	Contents	Function Used
uint16_t __near	g_ad_value[8]	Buffer for storing A/D conversion results	r_adc_interrupt
uint16_t	g_ad_an0_value1	Buffer 1 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value2	Buffer 2 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value3	Buffer 3 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value4	Buffer 4 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value5	Buffer 5 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value6	Buffer 6 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value7	Buffer 7 for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an0_value8	Buffer 8 for storing A/D conversion result of ANI0	r_adc_interrupt

#### 6.4.5 Functions

Table 6.9 lists the Functions.

Table 6.9 Functions (example of migration from repeat mode 1)

Function Name	Outline
hdwinit	Initial setting
R_Systeminit	Initial setting of peripheral functions
R_CGC_Create	CPU initial setting
R_ADC_Create	Initial setting of A/D converter
R_DTC_Create	Initial setting of DTC
main	Main processing
R_DTCD0_Start	DTC activation
R_ADC_Start	A/D conversion start
r_adc_interrupt	A/D conversion interrupt

### 6.4.6 Function Specifications

The following tables list the sample code function specifications.

hdwinit	
Outline	Initial setting
Header	None
Declaration	void hdwinit(void)
Description	Perform the initial setting of peripheral functions.
Argument	None
Return Value	None

R_Systeminit	
Outline	Initial setting of peripheral functions
Header	None
Declaration	void R_Systeminit(void)
Description	Perform the initial setting of peripheral functions used in this document.
Argument	None
Return Value	None

R_CGC_Create	
Outline	CPU initial setting
Header	None
Declaration	void R_CGC_Create(void)
Description	Perform the initial setting of the CPU.
Argument	None
Return Value	None

R_ADC_Create	
Outline	Initial setting of A/D converter
Header	None
Declaration	void R_ADC_Create(void)
Description	Perform the initial setting to use the A/D converter in software trigger mode, select mode, and sequential conversion mode.
Argument	None
Return Value	None

R_DTC_Create	
Outline	Initial setting of DTC
Header	None
Declaration	void R_DTC_Create(void)
Description	Perform the initial setting to use the DTC in repeat mode.
Argument	None
Return Value	None

---

main	
Outline	Main processing
Header	None
Declaration	void main(void)
Description	Perform main processing.
Argument	None
Return Value	None

---

R_DTCD0_Start	
Outline	DTC activation
Header	None
Declaration	void R_DTCD0_Start(void)
Description	Enable DTC activation.
Argument	None
Return Value	None

---

R_ADC_Start	
Outline	A/D conversion start
Header	None
Declaration	void R_ADC_Start(void)
Description	Perform A/D conversion.
Argument	None
Return Value	None

---

r_adc_interrupt	
Outline	A/D conversion interrupt
Header	None
Declaration	static void __near r_adc_interrupt(void)
Description	Perform an A/D conversion end interrupt service routine.
Argument	None
Return Value	None

---

6.4.7 Flowcharts

(1) Overall Flowchart

Figure 6.5 shows the Overall Flowchart.




Figure 6.5 Overall Flowchart (example of migration from repeat mode 1)

(2) Initial Setting

Figure 6.6 shows the Initial Setting.




Figure 6.6 Initial Setting (example of migration from repeat mode 1)

(3) Initial Setting of Peripheral Functions

Figure 6.7 shows the initial setting of peripheral functions.




Figure 6.7 Initial Setting of Peripheral Functions (example of migration from repeat mode 1)

(4) Initial Setting of CPU

Figure 6.8 shows the initial setting of the CPU.




Figure 6.8 Initial Setting of CPU (example of migration from repeat mode 1)

(5) Initial Setting of A/D Converter

Figure 6.9 shows the initial setting of the A/D converter.




Figure 6.9 Initial Setting of A/D Converter (example of migration from repeat mode 1)



Starting clock supply to A/D converter

- Peripheral enable register 0 (PER0)  
Starts supplying clock to the A/D converter.

Symbol	7	6	5	4	3	2	1	0
PER0	<b>RTCEN</b>	<b>IICA1EN</b>	<b>ADCEN</b>	<b>IICA0EN</b>	<b>SAU1EN</b>	<b>SAU0EN</b>	<b>TAU1EN</b>	<b>TAU0EN</b>
Set value	×	×	1	×	×	×	×	×

Bit 5

<b>ADCEN</b>	<b>Control of A/D converter input clock supply</b>
0	Stops input clock supply. Stops input clock supply. <ul style="list-style-type: none"> <li>SFR used by the A/D converter cannot be written.</li> </ul>
1	<b>Enables input clock supply.</b> <ul style="list-style-type: none"> <li>SFR used by the A/D converter can be read and written.</li> </ul>

Stopping A/D converter operation

- A/D converter mode register 0 (ADM0)  
Stops A/D converter.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	0	×	×	×	×	×	×	0

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	<b>Stops conversion operation.</b> [When read] <b>Conversion stopped/standby status</b>
1	Enables conversion operation. [When read] While in the software trigger mode: Conversion operation status While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	<b>Stops A/D voltage comparator operation.</b>
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Disabling A/D conversion end interrupt

- Interrupt mask flag register 1 (MK1H)  
Disables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
0	No interrupt request signal is generated.
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Specifying A/D conversion end interrupt priority level

- Priority specification flag register (PR11H, PR01H)  
Specifies level 3 (lowest priority level).

Symbol	7	6	5	4	3	2	1	0
PR11H	<b>TMPR11</b> <b>0</b>	<b>TRJPR10</b>	<b>SRPR13</b> <b>CSIPR131</b> <b>IICPR131</b>	<b>STPR13</b> <b>CSIPR130</b> <b>IICPR130</b>	<b>KRPR1</b>	<b>ITPR1</b>	<b>RTCPR1</b>	<b>ADPR1</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Symbol	7	6	5	4	3	2	1	0
PR01H	<b>TMPR01</b> <b>0</b>	<b>TRJPR00</b>	<b>SRPR03</b> <b>CSIPR031</b> <b>IICPR031</b>	<b>STPR03</b> <b>CSIPR030</b> <b>IICPR030</b>	<b>KRPR0</b>	<b>ITPR0</b>	<b>RTCPR0</b>	<b>ADPR0</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADPR1</b>	<b>ADPR0</b>	<b>Priority level selection</b>
0	0	Specifies level 0 (high priority level).
0	1	Specifies level 1.
1	0	Specifies level 2.
<b>1</b>	<b>1</b>	<b>Specifies level 3 (low priority level).</b>

Setting port mode register 2

- Port mode register 2 (PM2)  
Sets the port mode register 2 to input mode.

Symbol	7	6	5	4	3	2	1	0
PM2	<b>PM27</b>	<b>PM26</b>	<b>PM25</b>	<b>PM24</b>	<b>PM23</b>	<b>PM22</b>	<b>PM21</b>	<b>PM20</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>PM20</b>	<b>P20 pin I/O mode selection</b>
0	Output mode (output buffer on)
<b>1</b>	<b>Input mode (output buffer off)</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion mode and conversion time

- A/D converter mode register 0 (ADM0)  
Sets the A/D conversion mode and conversion time.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	×	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	×

Bit 6

ADMD	Specification of A/D conversion channel selection mode
<b>0</b>	<b>Select mode</b>
<b>1</b>	Scan mode

Bits 5-1

A/D converter mode register 0 (ADM0)					Mode	Conversion time selection					Conv. clock (f <sub>AD</sub> )
FR2	FR1	FR0	LV1	LV0		f <sub>CLK</sub> = 1 MHz	f <sub>CLK</sub> = 4 MHz	f <sub>CLK</sub> = 8 MHz	f <sub>CLK</sub> = 16 MHz	f <sub>CLK</sub> = 32 MHz	
0	0	0	<b>0</b>	<b>0</b>	<b>Normal 1</b>	Setting prohibited	Setting prohibited	Setting prohibited	76 μs	38 μs	f <sub>CLK</sub> /64
0	0	1				76 μs	38 μs	19 μs	f <sub>CLK</sub> /32		
0	1	0				76 μs	38 μs	19 μs	9.5 μs	f <sub>CLK</sub> /16	
<b>0</b>	<b>1</b>	<b>1</b>				38 μs	19 μs	9.5 μs	<b>4.75 μs</b>	<b>f<sub>CLK</sub>/8</b>	
1	0	0				28.5 μs	14.25 μs	7.125 μs	3.5625 μs	f <sub>CLK</sub> /6	
1	0	1				95 μs	23.75 μs	11.875 μs	5.938 μs	2.9688 μs	f <sub>CLK</sub> /5
1	1	0				76 μs	19 μs	9.5 μs	4.75 μs	2.375 μs	f <sub>CLK</sub> /4
1	1	1				38 μs	9.5 μs	4.75 μs	2.375 μs	Setting prohibited	f <sub>CLK</sub> /2
0	0	0	0	1	<b>Normal 2</b>	Setting prohibited	Setting prohibited	Setting prohibited	68 μs	34 μs	f <sub>CLK</sub> /64
0	0	1				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /32	
0	1	0				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /16	
0	1	1				34 μs	17 μs	8.5 μs	4.25 μs	f <sub>CLK</sub> /8	
1	0	0				25.5 μs	12.75 μs	6.375 μs	3.1875 μs	f <sub>CLK</sub> /6	
1	0	1				85 μs	21.25 μs	10.625 μs	5.3125 μs	2.6563 μs	f <sub>CLK</sub> /5
1	1	0				68 μs	17 μs	8.5 μs	4.25 μs	2.125 μs	f <sub>CLK</sub> /4
1	1	1				34 μs	8.5 μs	4.25 μs	2.125 μs	Setting prohibited	f <sub>CLK</sub> /2

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 1 (ADM1)  
Selects the A/D conversion trigger mode.

Symbol	7	6	5	4	3	2	1	0
ADM1	<b>ADTMD1</b>	<b>ADTMD0</b>	<b>ADSCM</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ADTRS1</b>	<b>ADTRS0</b>
Set value	<b>0</b>	x	<b>0</b>	0	0	0	x	x

## Bits 7-6

<b>ADTMD1</b>	<b>ADTMD0</b>	<b>Selection of A/D conversion trigger mode</b>
<b>0</b>	-	<b>Software trigger mode</b>
1	0	Hardware trigger no-wait mode
1	1	Hardware trigger wait mode

## Bit 5

<b>ADSCM</b>	<b>Specification of A/D conversion mode</b>
<b>0</b>	<b>Sequential conversion mode</b>
1	One-shot conversion mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 2 (ADM2)  
Selects the A/D converter reference voltage source, checks the conversion result against upper-limit/lower-limit value, and selects A/D conversion resolution.

Symbol	7	6	5	4	3	2	1	0
ADM2	<b>ADREFP1</b>	<b>ADREFP0</b>	<b>ADREFM</b>	<b>0</b>	<b>ADRCK</b>	<b>AWC</b>	<b>0</b>	<b>ADTYP</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	0	<b>0</b>	x	0	<b>0</b>

## Bits 7-6

<b>ADREFP1</b>	<b>ADREFP0</b>	<b>Selection of + side reference voltage source of A/D converter</b>
<b>0</b>	<b>0</b>	<b>Supplied from V<sub>DD</sub></b>
0	1	Supplied from P20/AV <sub>REFP</sub> /ANI0
1	0	Supplied from internal reference voltage (1.45 V)
1	1	Setting prohibited

Before rewriting ADREFP1 or ADREFP0 bit, set ADREFP1 and ADREFP0 to 0 and 0.  
When setting ADREFP1 and ADREFP0 bits to 1 and 0, respectively, this must be configured in accordance with the following procedures.

- (1) Set ADCE = 0
- (2) Set ADREFP1 and ADREFP0 to 1 and 0, respectively.
- (3) Set ADCE = 1

A wait time (T.B.D) is necessary after (2) and (3).  
When ADREFP1 and ADREFP0 are set to 1 and 0, respectively, A/D conversion cannot be performed on the temperature sensor output. Be sure to perform A/D conversion while ADISS = 0.

## Bit 5

<b>ADREFM</b>	<b>Selection of – side reference voltage source of A/D converter</b>
<b>0</b>	<b>Supplied from V<sub>SS</sub></b>
1	Supplied from P21/AV <sub>REFM</sub> /ANI1

## Bit 3

<b>ADRCK</b>	<b>Checking upper limit and lower limit conversion result values</b>
<b>0</b>	<b>Interrupt signal (INTAD) is generated when the ADLL register ≤ the ADCR register ≤ the ADUL register.</b>
1	Interrupt signal (INTAD) is generated when ADCR register < ADLL register, ADUL register < ADCR register.

## Bit 0

<b>ADTYP</b>	<b>Selection of A/D conversion resolution</b>
<b>0</b>	<b>10-bit resolution</b>
1	8-bit resolution

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Setting upper limit value for conversion result comparison

- Conversion result comparison upper limit setting register (ADUL)  
Sets the upper limit conversion result compare value to FFH.

Symbol	7	6	5	4	3	2	1	0
ADUL	<b>ADUL7</b>	<b>ADUL6</b>	<b>ADUL5</b>	<b>ADUL4</b>	<b>ADUL3</b>	<b>ADUL2</b>	<b>ADUL1</b>	<b>ADUL0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

Setting lower limit values for conversion result comparison

- Conversion result comparison lower limit setting register (ADLL)  
Sets the lower limit conversion result compare value to 00H.

Symbol	7	6	5	4	3	2	1	0
ADLL	<b>ADLL7</b>	<b>ADLL6</b>	<b>ADLL5</b>	<b>ADLL4</b>	<b>ADLL3</b>	<b>ADLL2</b>	<b>ADLL1</b>	<b>ADLL0</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting analog input channel

- Analog input channel specification register (ADS)  
Sets the analog input channel to ANI0.

Symbol	7	6	5	4	3	2	1	0
ADS	<b>ADISS</b>	<b>0</b>	<b>0</b>	<b>ADS4</b>	<b>ADS3</b>	<b>ADS2</b>	<b>ADS1</b>	<b>ADS0</b>
Set value	<b>0</b>	0	0	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

## - Select mode (ADMD = 0)

Bits 7, 4 to 0

ADISS	ADS4	ADS3	ADS2	ADS1	ADS0	Analog input channel	Input source
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ANI0</b>	<b>P20/ANI0/AV<sub>REFP</sub> pin</b>
0	0	0	0	0	1	ANI1	P21/ANI1/AV <sub>REFM</sub> pin
0	0	0	0	1	0	ANI2	P22/ANI2 pin
0	0	0	0	1	1	ANI3	P23/ANI3 pin
0	0	0	1	0	0	ANI4	P24/ANI4 pin
0	0	0	1	0	1	ANI5	P25/ANI5 pin
0	0	0	1	1	0	ANI6	P26/ANI6 pin
0	0	0	1	1	1	ANI7	P27/ANI7 pin
0	0	1	0	0	0	ANI8	P150/ANI8 pin
0	0	1	0	0	1	ANI9	P151/ANI9 pin
0	0	1	0	1	0	ANI10	P152/ANI10 pin
0	0	1	0	1	1	ANI11	P153/ANI11 pin
0	0	1	1	0	0	ANI12	P154/ANI12 pin
0	0	1	1	0	1	ANI13	P155/ANI13 pin
0	0	1	1	1	0	ANI14	P156/ANI14 pin
0	1	0	0	0	0	ANI16	P03/ANI16 pin
0	1	0	0	0	1	ANI17	P02/ANI17 pin
0	1	0	0	1	0	ANI18	P147/ANI18 pin
0	1	0	0	1	1	ANI19	P120/ANI19 pin
0	1	0	1	0	0	ANI20	P100/ANI20 pin
1	0	0	0	0	0	—	Temperature sensor output voltage
1	0	0	0	0	1	—	Internal reference voltage (1.45 V)
Other than above						Setting prohibited	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.



Setting A/D voltage comparator

- A/D converter mode register 0 (ADM0)  
Starts A/D voltage comparator operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	Stops A/D voltage comparator operation.
<b>1</b>	<b>Enables A/D voltage comparator operation.</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(6) Initial Setting of DTC

Figure 6.10 shows the initial setting of the DTC.




Figure 6.10 Initial Setting of DTC (example of migration from repeat mode 1)

Starting clock supply to DTC

- Peripheral enable register 1 (PER1)  
Starts supplying clock to the DTC.

Symbol	7	6	5	4	3	2	1	0
PER1	<b>DACEN</b>	<b>TRGEN</b>	<b>CMPEN</b>	<b>TRD0EN</b>	<b>DTCEN</b>	<b>0</b>	<b>0</b>	<b>TRJ0EN</b>
Set value	x	x	x	x	1	0	0	x

Bit 3

<b>DTCEN</b>	<b>Control of DTC input clock supply</b>
0	Stops input clock supply.
1	<b>Enables input clock supply.</b>

Disabling DTC activation

- DTC activation enable register i (DTCENi) (i = 0 to 4)  
Disables DTC activation.

Symbol	7	6	5	4	3	2	1	0
DTCENi	<b>DTCENi7</b>	<b>DTCENi6</b>	<b>DTCENi5</b>	<b>DTCENi4</b>	<b>DTCENi3</b>	<b>DTCENi2</b>	<b>DTCENi1</b>	<b>DTCENi0</b>
Set value	0	0	0	0	0	0	0	0

Bit 7

<b>DTCENi7</b>	<b>DTC activation enable i7</b>
0	<b>Activation disabled</b>
1	Activation enabled
The DTCENi7 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 6

<b>DTCENi6</b>	<b>DTC activation enable i6</b>
0	<b>Activation disabled</b>
1	Activation enabled
The DTCENi6 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 5

<b>DTCENi5</b>	<b>DTC activation enable i5</b>
0	<b>Activation disabled</b>
1	Activation enabled
The DTCENi5 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Bit 4

DTCENi4	DTC activation enable i4
0	Activation disabled
1	Activation enabled
The DTCENi4 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 3

DTCENi3	DTC activation enable i3
0	Activation disabled
1	Activation enabled
The DTCENi3 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 2

DTCENi2	DTC activation enable i2
0	Activation disabled
1	Activation enabled
The DTCENi2 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 1

DTCENi1	DTC activation enable i1
0	Activation disabled
1	Activation enabled
The DTCENi1 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 0

DTCENi0	DTC activation enable i0
0	Activation disabled
1	Activation enabled
The DTCENi0 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Setting DTC base address

- DTC base address register (DTCBAR)  
Sets FDH for the DTC base address.

Symbol	7	6	5	4	3	2	1	0
DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR
	7	6	5	4	3	2	1	0
Set value	1	1	1	1	1	1	0	1

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting DTC control register

- DTC control register 0 (DTCCR0)  
Sets the DTC control register 0.

Symbol	7	6	5	4	3	2	1	0
DTCCR0	<b>0</b>	<b>SZ</b>	<b>RPTINT</b>	<b>CHNE</b>	<b>DAMOD</b>	<b>SAMOD</b>	<b>RPTSEL</b>	<b>MODE</b>
Set value	0	1	1	0	×	0	0	1

## Bit 6

<b>SZ</b>	<b>Transfer data size selection</b>
0	8 bits
1	16 bits

## Bit 5

<b>RPTINT</b>	<b>Enabling/disabling repeat mode interrupts</b>
0	Interrupt generation disabled
1	Interrupt generation enabled

The setting of the RPTINT bit is invalid when the MODE bit is 0 (normal mode).

## Bit 4

<b>CHNE</b>	<b>Enabling/disabling chain transfers</b>
0	Chain transfers disabled
1	Chain transfers enabled

Set the CHNE bit in the DTCCR23 register to 0 (chain transfers disabled).

## Bit 2

<b>SAMOD</b>	<b>Transfer source address control</b>
0	Fixed
1	Incremented

The setting of the SAMOD bit is invalid when the MODE bit is 1 (repeat mode) and the RPTSEL bit is 1 (transfer source is the repeat area).

## Bit 1

<b>RPTSEL</b>	<b>Repeat area selection</b>
0	Transfer destination is the repeat area
1	Transfer source is the repeat area

The setting of the RPTSEL bit is invalid when the MODE bit is 0 (normal mode).

## Bit 0

<b>MODE</b>	<b>Transfer mode selection</b>
0	Normal mode
1	Repeat mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting DTC block size register 0

- DTC block size register 0 (DTBLS0)  
Sets the DTC block size register 0 to 01H (2 bytes).

Symbol	7	6	5	4	3	2	1	0
DTBLS0	<b>DTBLS07</b>	<b>DTBLS06</b>	<b>DTBLS05</b>	<b>DTBLS04</b>	<b>DTBLS03</b>	<b>DTBLS02</b>	<b>DTBLS01</b>	<b>DTBLS00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>

DTBLS0	Transfer block size	
	8-bit transfer	16-bit transfer
00H	256 bytes	512 bytes
<b>01H</b>	1 byte	<b>2 bytes</b>
<b>02H</b>	<b>2 bytes</b>	<b>4 bytes</b>
03H	3 bytes	6 bytes
.	.	.
.	.	.
.	.	.
FDH	253 bytes	506 bytes
FEH	254 bytes	508 bytes
FFH	255 bytes	510 bytes

Setting DTC transfer count register 0

- DTC transfer count register 0 (DTCCT0)  
Sets the DTC transfer count register 0 to 08H (8 times).

Symbol	7	6	5	4	3	2	1	0
DTCCT0	<b>DTCCT07</b>	<b>DTCCT06</b>	<b>DTCCT05</b>	<b>DTCCT04</b>	<b>DTCCT03</b>	<b>DTCCT02</b>	<b>DTCCT01</b>	<b>DTCCT00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>

DTCCT0	Number of transfers
00H	256 times
01H	Once
02H	2 times
03H	3 times
.	.
<b>08H</b>	<b>8 times</b>
.	.
.	.
.	.
FDH	253 times
FEH	254 times
FFH	255 times

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

## Setting DTC transfer count reload register 0

- DTC transfer count reload register 0 (DTRLD0)  
Sets the DTC transfer count reload register 0 to 08H (8 times).

Symbol	7	6	5	4	3	2	1	0
DTRLD0	<b>DTRLD07</b>	<b>DTRLD06</b>	<b>DTRLD05</b>	<b>DTRLD04</b>	<b>DTRLD03</b>	<b>DTRLD02</b>	<b>DTRLD01</b>	<b>DTRLD00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>

## Setting DTC source address register 0

- DTC source address register 0 (DTSAR0)  
Set the DTC source address register 0 to the transfer source address FF1EH.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTSAR0	<b>DT SA R0 15</b>	<b>DT SA R0 14</b>	<b>DT SA R0 13</b>	<b>DT SA R0 12</b>	<b>DT SA R0 11</b>	<b>DT SA R0 10</b>	<b>DT SA R0 9</b>	<b>DT SA R0 8</b>	<b>DT SA R0 7</b>	<b>DT SA R0 6</b>	<b>DT SA R0 5</b>	<b>DT SA R0 4</b>	<b>DT SA R0 3</b>	<b>DT SA R0 2</b>	<b>DT SA R0 1</b>	<b>DT SA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>

## Setting DTC destination address register 0

- DTC destination address register 0 (DTDAR0)  
Set the DTC destination address register 0 to the transfer destination address F500H.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTDAR0	<b>DT DA R0 15</b>	<b>DT DA R0 14</b>	<b>DT DA R0 13</b>	<b>DT DA R0 12</b>	<b>DT DA R0 11</b>	<b>DT DA R0 10</b>	<b>DT DA R0 9</b>	<b>DT DA R0 8</b>	<b>DT DA R0 7</b>	<b>DT DA R0 6</b>	<b>DT DA R0 5</b>	<b>DT DA R0 4</b>	<b>DT DA R0 3</b>	<b>DT DA R0 2</b>	<b>DT DA R0 1</b>	<b>DT DA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(7) Main Processing

Figure 6.11 shows the flowchart for the main processing.




Figure 6.11 Main Processing (example of migration from repeat mode 1)



(8) Enabling DTC Activation

Figure 6.12 shows the flowchart for enabling DTC activation.




Figure 6.12 Enabling DTC Activation (example of migration from repeat mode 1)

Enabling DTC activation

- DTC activation enable register 1 (DTCEN1)  
Enables DTC activation by the A/D conversion end.

Symbol	7	6	5	4	3	2	1	0
DTCEN1	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>
	<b>7</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>	<b>0</b>
Set value	×	×	<b>1</b>	×	×	×	×	×

Bit 5	
<b>DTCEN15</b>	<b>DTC activation enable 15 (DTC activation source: A/D conversion end)</b>
0	Activation disabled
<b>1</b>	<b>Activation enabled</b>
The DTCEN15 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

(9) Starting A/D Conversion

Figure 6.13 shows the flowchart for starting A/D conversion.




Figure 6.13 Starting A/D Conversion (example of migration from repeat mode 1)

Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0	
<b>ADIF</b>	<b>Interrupt request flag</b>
<b>0</b>	<b>No interrupt request signal is generated</b>
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Enabling A/D conversion end interrupt

- Interrupt mask flag register (MK1H)  
Enables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
<b>0</b>	<b>Interrupt servicing enabled</b>
<b>1</b>	Interrupt servicing disabled

Starting A/D converter

- A/D converter mode register 0 (ADM0)  
Starts A/D conversion operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	<b>1</b>	x	x	x	x	x	x	x

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
<b>0</b>	Stops conversion operation [When read] Conversion stopped/standby status
<b>1</b>	<b>Enables conversion operation</b> [When read] <b>While in the software trigger mode: Conversion operation status</b> <b>While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(10) A/D conversion end interrupt

Figure 6.14 shows the flowchart for A/D conversion end interrupt processing.




Figure 6.14 A/D Conversion End Interrupt (example of migration from repeat mode 1)

## 6.5 Sample Code

Sample code can be downloaded from the Renesas Electronics website.

## 6.6 Reference Application Note

- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: A/D Converter CC-RL (R01AN3059)
- RL78/G13 A/D Converter (Software Trigger and Sequential Conversion Modes) CC-RL (R01AN2581)

## 6.7 Reference Documents

### User's Manual

- RL78/G14 User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- R8C/36M Group User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- Technical Update/Technical News  
(The latest information can be downloaded from the Renesas Electronics website.)

### Migration Guide

- Migration to CubeSuite+ Integrated Development Environment for RL78 Family  
(On-chip Debug) - Migration from R8C, M16C to RL78 (R20UT2150)

## 7. Example of Migration from Single Sweep Mode

### 7.1 Specifications

To implement R8C/36M single sweep mode in the RL78/G14, the AD converter (software trigger, scan, one-shot conversion mode) and DTC transfer (repeat mode) are used.

The analog input voltage of the ANI0 to ANI3 pins is A/D-converted in scan mode and one-shot conversion mode, and the A/D conversion result values are stored in the RAM assigned to each pin by DTC transfer. Specifically, A/D conversion on the pins is sequentially performed; each time A/D conversion on one pin ends, the conversion result is stored in the 10-bit A/D conversion result register (ADCR), and an A/D conversion end interrupt signal is generated. In response to the interrupt signal, the DTC is activated, and the A/D conversion result is transferred from the ADCR register to the RAM. When A/D conversion and DTC transfer on all the pins are completed, an A/D conversion end interrupt request is generated.

Table 7.1 shows the peripheral functions used and the purpose of use, and Figure 7.1 shows the operation summary.

Table 7.1 Peripheral Functions Used and Purpose of Use (example of migration from single sweep mode)

Peripheral Function	Purpose of Use
A/D converter	Performs A/D conversion on the analog input voltage.
DTC	Transfers A/D conversion result to RAM.




Figure 7.1 Operation Summary (example of migration from single sweep mode)

## 7.2 Conditions for Confirming Operations

The sample code operations described in this application note are confirmed under the following conditions.

Table 7.2 Conditions for Confirming Operations (example of migration from single sweep mode)

Item	Description
Microcontroller used	RL78/G14 (R5F104LEA)
Operating frequency	<ul style="list-style-type: none"> <li>High-speed on-chip oscillator clock (<math>f_{IH}</math>): 32 MHz</li> <li>CPU/peripheral hardware clock (<math>f_{CLK}</math>): 32 MHz</li> </ul>
Operating voltage	5.0 V (can be operated from 3.6 V to 5.5 V) LVD operation ( $V_{LVD}$ ): Reset mode; rise 3.13 V/fall 3.06 V
Integrated development environment (CS+)	CS+ for CC V5.00.00 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.
Integrated development environment (e <sup>2</sup> studio)	e <sup>2</sup> studio V5.4.0.015 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.

## 7.3 Hardware Descriptions

### 7.3.1 Hardware Configuration Example

Figure 7.2 shows an example of the hardware configuration used for this application.




Figure 7.2 Hardware Configuration (example of migration from single sweep mode)



### 7.3.2 List of Pins Used

Table 7.3 lists the pins used and their functions.

Table 7.3 Pins Used and Their Functions (example of migration from single sweep mode)

Pin Name	I/O	Function
P20/ANI0	Input	A/D converter input (ANI0)
P21/ANI1	Input	A/D converter input (ANI1)
P22/ANI2	Input	A/D converter input (ANI2)
P23/ANI3	Input	A/D converter input (ANI3)

## 7.4 Software Descriptions

### 7.4.1 Operation Summary

With this sample program, the A/D conversion on four pins is performed in scan mode, and the conversion results are stored in the RAM by DTC transfer. The DTC is used in repeat mode with the transfer destination set as repeat area, and the conversion results on the four pins are sequentially stored in the RAM.

Upon completion of the A/D conversion on the ANI0 pin, the first DTC transfer is performed from the transfer source addresses (ADCR register (FFF1EH, FFF1FH)) to the transfer destination addresses (`g_ad_value[0]` (FF500H to FF501H)). Upon completion of the A/D conversion on the ANI1 pin, the second DTC transfer is performed to `g_ad_value[1]` (FF502H to FF503H) since the transfer destination is set as the repeat area. Similarly, the A/D conversion results of the ANI3 and ANI4 pins are DTC-transferred. Upon completion of the fourth transfer, an A/D conversion end interrupt is generated.

In interrupt processing, the A/D conversion results stored in the array `g_ad_value[]` (FF500H to FF507H) are relocated in the lower 10 bits before being stored in the buffers for storing the A/D conversion results (variable `g_ad_an0_value` to `g_ad_an3_value`).

Table 7.4 shows the A/D converter settings and Table 7.5 shows the DTC settings.

Table 7.4 A/D Converter Settings (example of migration from single sweep mode)

Item to be Set	Settings
Conversion clock frequency ( $f_{AD}$ )	$f_{CLK}/8$
A/D conversion mode	<ul style="list-style-type: none"> <li>A/D conversion trigger mode: Software trigger</li> <li>A/D conversion channel selection mode: Scan mode</li> <li>A/D conversion operation mode: One-shot conversion mode</li> </ul>
Resolution	10 bits
Analog input channel	<ul style="list-style-type: none"> <li>Scan 0: ANI0</li> <li>Scan 1: ANI1</li> <li>Scan 2: ANI2</li> <li>Scan 3: ANI3</li> </ul>
A/D conversion result comparison upper limit (ADUL register)	FFH
A/D conversion result comparison lower limit (ADLL register)	00H
Upper and lower limit conversion result checking	INTAD generated when ADLL register $\leq$ ADCR register $\leq$ ADUL register

Table 7.5 DTC Settings (example of migration from repeat sweep ode)

Item to be Set	Settings
	Control Data 0
Transfer mode	Repeat mode
Repeat mode interrupt	Enabled
Source address control	Fixed
Destination address control	Repeat area
Chain transfer control	Disabled
Transfer block size	2 bytes (16-bit transfer)
DTC transfer count	4
Transfer source address	ADCR (FFF1EH to FFF1FH)
Transfer destination address	g_ad_value[0] (FF500H to FF501H), g_ad_value[1] (FF502H to FF503H), g_ad_value[2] (FF504H to FF505H), g_ad_value[3] (FF506H to FF507H)

- (1) The initial setting is made for the A/D converter and DTC.
- (2) The ADCS bit in the ADM0 register is set to 1 (conversion enabled) to start A/D conversion.
- (3) Upon completion of the A/D conversion on each of the pins (ANI0, ANI1, ANI2, and ANI3 pins), the DTC is activated.
- (4) The DTC reads the A/D conversion result from the ADCR register and transfers it to the RAM (g\_ad\_value[0] to g\_ad\_value[3]) corresponding to the pin.
- (5) Upon completion of the fourth DTC transfer, an A/D conversion end interrupt is generated. In interrupt processing, the A/D conversion results g\_ad\_value[0] to g\_ad\_value[3] are shifted to the right by 6 bits (relocated in the lower 10 bits) and stored in the variables g\_ad\_an0\_value to g\_ad\_an3\_value.
- (6) Determine if DTC activation is disabled by a program, enable DTC activation again, and start A/D conversion.
- (7) After this, steps (2) to (6) are repeated.

Figure 7.3 shows the A/D conversion and DTC transfer timing and Figure 7.4 shows the relationship between the ADCR register and RAM.




Figure 7.3 A/D Conversion and DTC Transfer Timing (example of migration from single sweep mode)




Figure 7.4 Relationship between ADCR Register and RAM (example of migration from single sweep mode)

### 7.4.2 List of Option Byte Settings

Table 7.6 lists option byte settings.

Table 7.6 Option Byte Settings (example of migration from single sweep mode)

Address	Setting	Contents
000C0H/010C0H	01101110B	Watchdog timer is stopped. (Counting stopped after a reset release)
000C1H/010C1H	00110011B	LVD reset mode Detection voltage: rise 3.13 V/fall 3.06 V
000C2H/010C2H	11101000B	HS mode High-speed on-chip oscillator clock frequency: 32 MHz
000C3H/010C3H	10000100B	On-chip debugging is enabled.

### 7.4.3 List of Constants

Table 7.7 lists the constant used in the sample code.

Table 7.7 Constant Used in Sample Code (example of migration from single sweep mode)

Constant Name	Setting	Contents
AD_RESULT_ADDR	0FF500H	Transfer destination address of A/D conversion result

### 7.4.4 List of Variables

Table 7.8 lists the global variables.

Table 7.8 Global Variables (example of migration from single sweep mode)

Type	Variable Name	Contents	Function Used
uint16_t __near	g_ad_value[4]	Buffer for storing A/D conversion results of ANI0 to ANI3	r_adc_interrupt
uint16_t	g_ad_an0_value	Buffer for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an1_value	Buffer for storing A/D conversion result of ANI1	r_adc_interrupt
uint16_t	g_ad_an2_value	Buffer for storing A/D conversion result of ANI2	r_adc_interrupt
uint16_t	g_ad_an3_value	Buffer for storing A/D conversion result of ANI3	r_adc_interrupt

### 7.4.5 Functions

Table 7.9 lists the Functions.

Table 7.9 Functions (example of migration from single sweep mode)

Function Name	Outline
hdwinit	Initial setting
R_Systeminit	Initial setting of peripheral functions
R_CGC_Create	CPU initial setting
R_ADC_Create	Initial setting of A/D converter
R_DTC_Create	Initial setting of DTC
main	Main processing
R_DTCD0_Start	DTC activation
R_ADC_Start	A/D conversion start
r_adc_interrupt	A/D conversion interrupt

### 7.4.6 Function Specifications

The following tables list the sample code function specifications.

hdwinit	
Outline	Initial setting
Header	None
Declaration	void hdwinit(void)
Description	Perform the initial setting of peripheral functions.
Argument	None
Return Value	None

R_Systeminit	
Outline	Initial setting of peripheral functions
Header	None
Declaration	void R_Systeminit(void)
Description	Perform the initial setting of peripheral functions used in this document.
Argument	None
Return Value	None

R_CGC_Create	
Outline	CPU initial setting
Header	None
Declaration	void R_CGC_Create(void)
Description	Perform the initial setting of the CPU.
Argument	None
Return Value	None

R_ADC_Create	
Outline	Initial setting of A/D converter
Header	None
Declaration	void R_ADC_Create(void)
Description	Perform the initial setting to use the A/D converter in software trigger mode, scan mode, and one-shot conversion mode.
Argument	None
Return Value	None
R_DTC_Create	
Outline	Initial setting of DTC
Header	None
Declaration	void R_DTC_Create(void)
Description	Perform the initial setting to use the DTC in repeat mode.
Argument	None
Return Value	None
main	
Outline	Main processing
Header	None
Declaration	void main(void)
Description	Perform main processing.
Argument	None
Return Value	None
R_DTCD0_Start	
Outline	DTC activation
Header	None
Declaration	void R_DTCD0_Start(void)
Description	Enable DTC activation.
Argument	None
Return Value	None
R_ADC_Start	
Outline	A/D conversion start
Header	None
Declaration	void R_ADC_Start(void)
Description	Perform A/D conversion.
Argument	None
Return Value	None
r_adc_interrupt	
Outline	A/D conversion interrupt
Header	None
Declaration	static void __near r_adc_interrupt(void)
Description	Perform an A/D conversion end interrupt service routine.
Argument	None
Return Value	None

7.4.7 Flowcharts

(1) Overall Flowchart

Figure 7.5 shows the Overall Flowchart.




Figure 7.5 Overall Flowchart (example of migration from single sweep mode)

(2) Initial Setting

Figure 7.6 shows the Initial Setting.




Figure 7.6 Initial Setting (example of migration from single sweep mode)

(3) Initial Setting of Peripheral Functions

Figure 7.7 shows the initial setting of peripheral functions.




Figure 7.7 Initial Setting of Peripheral Functions (example of migration from single sweep mode)

(4) Initial Setting of CPU

Figure 7.8 shows the initial setting of the CPU.




Figure 7.8 Initial Setting of CPU (example of migration from single sweep mode)



(5) Initial Setting of A/D Converter

Figure 7.9 shows the initial setting of the A/D converter.




Figure 7.9 Initial Setting of A/D Converter (example of migration from single sweep mode)

Starting clock supply to A/D converter

- Peripheral enable register 0 (PER0)  
Starts supplying clock to the A/D converter.

Symbol	7	6	5	4	3	2	1	0
PER0	<b>RTCEN</b>	<b>IICA1EN</b>	<b>ADCEN</b>	<b>IICA0EN</b>	<b>SAU1EN</b>	<b>SAU0EN</b>	<b>TAU1EN</b>	<b>TAU0EN</b>
Set value	x	x	1	x	x	x	x	x

Bit 5

<b>ADCEN</b>	<b>Control of A/D converter input clock supply</b>
0	Stops input clock supply. Stops input clock supply. • SFR used by the A/D converter cannot be written.
1	<b>Enables input clock supply.</b> • SFR used by the A/D converter can be read and written.

Stopping A/D converter operation

- A/D converter mode register 0 (ADM0)  
Stops A/D converter.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	0	x	x	x	x	x	x	0

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	<b>Stops conversion operation.</b> [When read] <b>Conversion stopped/standby status</b>
1	Enables conversion operation. [When read] While in the software trigger mode: Conversion operation status While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	<b>Stops A/D voltage comparator operation.</b>
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Disabling A/D conversion end interrupt

- Interrupt mask flag register 1 (MK1H)  
Disables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	×	×	×	×	×	×	×	<b>1</b>

## Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

## Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	×	×	×	×	×	×	×	<b>0</b>

## Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
0	No interrupt request signal is generated.
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Specifying A/D conversion end interrupt priority level

- Priority specification flag register (PR11H, PR01H)  
Specifies level 3 (lowest priority level).

Symbol	7	6	5	4	3	2	1	0
PR11H	<b>TMPR11</b> 0	<b>TRJPR10</b>	<b>SRPR13</b> <b>CSIPR131</b> <b>IICPR131</b>	<b>STPR13</b> <b>CSIPR130</b> <b>IICPR130</b>	<b>KRPR1</b>	<b>ITPR1</b>	<b>RTCPR1</b>	<b>ADPR1</b>
Set value	x	x	x	x	x	x	x	1

Symbol	7	6	5	4	3	2	1	0
PR01H	<b>TMPR01</b> 0	<b>TRJPR00</b>	<b>SRPR03</b> <b>CSIPR031</b> <b>IICPR031</b>	<b>STPR03</b> <b>CSIPR030</b> <b>IICPR030</b>	<b>KRPR0</b>	<b>ITPR0</b>	<b>RTCPR0</b>	<b>ADPR0</b>
Set value	x	x	x	x	x	x	x	1

Bit 0

<b>ADPR1</b>	<b>ADPR0</b>	<b>Priority level selection</b>
0	0	Specifies level 0 (high priority level).
0	1	Specifies level 1.
1	0	Specifies level 2.
1	1	<b>Specifies level 3 (low priority level).</b>

Setting port mode register 2

- Port mode register 2 (PM2)  
Sets the port mode register 2 to input mode.

Symbol	7	6	5	4	3	2	1	0
PM2	<b>PM27</b>	<b>PM26</b>	<b>PM25</b>	<b>PM24</b>	<b>PM23</b>	<b>PM22</b>	<b>PM21</b>	<b>PM20</b>
Set value	x	x	x	x	1	1	1	1

Bits 3-0

<b>PM2n</b>	<b>P2n pin I/O mode selection</b>
0	Output mode (output buffer on)
1	<b>Input mode (output buffer off)</b>

Remark n: Channel number (n = 0 to 3)

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion mode and conversion time

- A/D converter mode register 0 (ADM0)  
Sets the A/D conversion mode and conversion time.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	×	1	0	1	1	0	0	×

Bit 6

ADMD	Specification of A/D conversion channel selection mode
0	Select mode
1	Scan mode

Bits 5-1

A/D converter mode register 0 (ADM0)					Mode	Conversion time selection					Conv. clock (f <sub>AD</sub> )
FR2	FR1	FR0	LV1	LV0		f <sub>CLK</sub> = 1 MHz	f <sub>CLK</sub> = 4 MHz	f <sub>CLK</sub> = 8 MHz	f <sub>CLK</sub> = 16 MHz	f <sub>CLK</sub> = 32 MHz	
0	0	0	0	0	Normal 1	Setting prohibited	Setting prohibited	Setting prohibited	76 μs	38 μs	f <sub>CLK</sub> /64
0	0	1				76 μs	38 μs	19 μs	f <sub>CLK</sub> /32		
0	1	0				76 μs	38 μs	19 μs	9.5 μs	f <sub>CLK</sub> /16	
0	1	1				38 μs	19 μs	9.5 μs	<b>4.75 μs</b>	<b>f<sub>CLK</sub>/8</b>	
1	0	0				28.5 μs	14.25 μs	7.125 μs	3.5625 μs	f <sub>CLK</sub> /6	
1	0	1				95 μs	23.75 μs	11.875 μs	5.938 μs	2.9688 μs	f <sub>CLK</sub> /5
1	1	0				76 μs	19 μs	9.5 μs	4.75 μs	2.375 μs	f <sub>CLK</sub> /4
1	1	1				38 μs	9.5 μs	4.75 μs	2.375 μs	Setting prohibited	f <sub>CLK</sub> /2
0	0	0	0	1	Normal 2	Setting prohibited	Setting prohibited	Setting prohibited	68 μs	34 μs	f <sub>CLK</sub> /64
0	0	1				68 μs	34 μs	17 μs	f <sub>CLK</sub> /32		
0	1	0				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /16	
0	1	1				34 μs	17 μs	8.5 μs	4.25 μs	f <sub>CLK</sub> /8	
1	0	0				25.5 μs	12.75 μs	6.375 μs	3.1875 μs	f <sub>CLK</sub> /6	
1	0	1				85 μs	21.25 μs	10.625 μs	5.3125 μs	2.6563 μs	f <sub>CLK</sub> /5
1	1	0				68 μs	17 μs	8.5 μs	4.25 μs	2.125 μs	f <sub>CLK</sub> /4
1	1	1				34 μs	8.5 μs	4.25 μs	2.125 μs	Setting prohibited	f <sub>CLK</sub> /2

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 1 (ADM1)  
Selects the A/D conversion trigger mode.

Symbol	7	6	5	4	3	2	1	0
ADM1	<b>ADTMD1</b>	<b>ADTMD0</b>	<b>ADSCM</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ADTRS1</b>	<b>ADTRS0</b>
Set value	<b>0</b>	x	<b>1</b>	0	0	0	x	x

## Bits 7-6

<b>ADTMD1</b>	<b>ADTMD0</b>	<b>Selection of A/D conversion trigger mode</b>
<b>0</b>	-	<b>Software trigger mode</b>
1	0	Hardware trigger no-wait mode
1	1	Hardware trigger wait mode

## Bit 5

<b>ADSCM</b>	<b>Specification of A/D conversion mode</b>
0	Sequential conversion mode
<b>1</b>	<b>One-shot conversion mode</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 2 (ADM2)  
Selects the A/D converter reference voltage source, checks the conversion result against upper-limit/lower-limit value, and selects A/D conversion resolution.

Symbol	7	6	5	4	3	2	1	0
ADM2	<b>ADREFP1</b>	<b>ADREFP0</b>	<b>ADREFM</b>	<b>0</b>	<b>ADRCK</b>	<b>AWC</b>	<b>0</b>	<b>ADTYP</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	0	<b>0</b>	×	0	<b>0</b>

## Bits 7-6

<b>ADREFP1</b>	<b>ADREFP0</b>	<b>Selection of + side reference voltage source of A/D converter</b>
<b>0</b>	<b>0</b>	<b>Supplied from V<sub>DD</sub></b>
0	1	Supplied from P20/AV <sub>REFP</sub> /ANI0
1	0	Supplied from internal reference voltage (1.45 V)
1	1	Setting prohibited

Before rewriting ADREFP1 or ADREFP0 bit, set ADREFP1 and ADREFP0 bits to 0 and 0.  
When setting ADREFP1 and ADREFP0 bits to 1 and 0, respectively, this must be configured in accordance with the following procedures.

- (1) Set ADCE = 0
- (2) Set ADREFP1 and ADREFP0 to 1 and 0, respectively.
- (3) Set ADCE = 1

A wait time (T.B.D) is necessary after (2) and (3).  
When ADREFP1 and ADREFP0 are set to 1 and 0, respectively, A/D conversion cannot be performed on the temperature sensor output. Be sure to perform A/D conversion while ADISS = 0.

## Bit 5

<b>ADREFM</b>	<b>Selection of – side reference voltage source of A/D converter</b>
<b>0</b>	<b>Supplied from V<sub>SS</sub></b>
1	Supplied from P21/AV <sub>REFM</sub> /ANI1

## Bit 3

<b>ADRCK</b>	<b>Checking upper limit and lower limit conversion result values</b>
<b>0</b>	<b>Interrupt signal (INTAD) is generated when the ADLL register ≤ the ADCR register ≤ the ADUL register.</b>
1	Interrupt signal (INTAD) is generated when ADCR register < ADLL register, ADUL register < ADCR register.

## Bit 0

<b>ADTYP</b>	<b>Selection of A/D conversion resolution</b>
<b>0</b>	<b>10-bit resolution</b>
1	8-bit resolution

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Setting upper limit value for conversion result comparison

- Conversion result comparison upper limit setting register (ADUL)  
Sets the upper limit conversion result compare value to FFH.

Symbol	7	6	5	4	3	2	1	0
ADUL	<b>ADUL7</b>	<b>ADUL6</b>	<b>ADUL5</b>	<b>ADUL4</b>	<b>ADUL3</b>	<b>ADUL2</b>	<b>ADUL1</b>	<b>ADUL0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

Setting lower limit values for conversion result comparison

- Conversion result comparison lower limit setting register (ADLL)  
Sets the lower limit conversion result compare value to 00H.

Symbol	7	6	5	4	3	2	1	0
ADLL	<b>ADLL7</b>	<b>ADLL6</b>	<b>ADLL5</b>	<b>ADLL4</b>	<b>ADLL3</b>	<b>ADLL2</b>	<b>ADLL1</b>	<b>ADLL0</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.



## Setting analog input channels

- Analog input channel specification register (ADS)  
Set analog input channels to ANI0 to ANI3.

Symbol	7	6	5	4	3	2	1	0
ADS	<b>ADISS</b>	<b>0</b>	<b>0</b>	<b>ADS4</b>	<b>ADS3</b>	<b>ADS2</b>	<b>ADS1</b>	<b>ADS0</b>
Set value	<b>0</b>	0	0	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

## - Scan mode (ADMD = 1)

Bits 7, 4-0

ADISS	ADS4	ADS3	ADS2	ADS1	ADS0	Analog input channel			
						Scan 0	Scan 1	Scan 2	Scan 3
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ANI0</b>	<b>ANI1</b>	<b>ANI2</b>	<b>ANI3</b>
0	0	0	0	0	1	ANI1	ANI2	ANI3	ANI4
0	0	0	0	1	0	ANI2	ANI3	ANI4	ANI5
0	0	0	0	1	1	ANI3	ANI4	ANI5	ANI6
0	0	0	1	0	0	ANI4	ANI5	ANI6	ANI7
0	0	0	1	0	1	ANI5	ANI6	ANI7	ANI8
0	0	0	1	1	0	ANI6	ANI7	ANI8	ANI9
0	0	0	1	1	1	ANI7	ANI8	ANI9	ANI10
0	0	1	0	0	0	ANI8	ANI9	ANI10	ANI11
0	0	1	0	0	1	ANI9	ANI10	ANI11	ANI12
0	0	1	0	1	0	ANI10	ANI11	ANI12	ANI13
0	0	1	0	1	1	ANI11	ANI12	ANI13	ANI14
Other than the above						Setting prohibited			

## Setting A/D voltage comparator

- A/D converter mode register 0 (ADM0)  
Starts A/D voltage comparator operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

ADCE	A/D voltage comparator operation control
0	Stops A/D voltage comparator operation.
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(6) Initial Setting of DTC

Figure 7.10 shows the initial setting of the DTC.




Figure 7.10 Initial Setting of DTC (example of migration from single sweep mode)

Starting clock supply to DTC

- Peripheral enable register 1 (PER1)  
Starts supplying clock to the DTC.

Symbol	7	6	5	4	3	2	1	0
PER1	<b>DACEN</b>	<b>TRGEN</b>	<b>CMPEN</b>	<b>TRD0EN</b>	<b>DTCEN</b>	<b>0</b>	<b>0</b>	<b>TRJ0EN</b>
Set value	x	x	x	x	1	0	0	x

Bit 3

<b>DTCEN</b>	<b>Control of DTC input clock supply</b>
0	Stops input clock supply.
1	Enables input clock supply.

Disabling DTC activation

- DTC activation enable register i (DTCENi) (i = 0 to 4)  
Disables DTC activation.

Symbol	7	6	5	4	3	2	1	0
DTCENi	<b>DTCENi7</b>	<b>DTCENi6</b>	<b>DTCENi5</b>	<b>DTCENi4</b>	<b>DTCENi3</b>	<b>DTCENi2</b>	<b>DTCENi1</b>	<b>DTCENi0</b>
Set value	0	0	0	0	0	0	0	0

Bit 7

<b>DTCENi7</b>	<b>DTC activation enable i7</b>
0	Activation disabled
1	Activation enabled
The DTCENi7 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 6

<b>DTCENi6</b>	<b>DTC activation enable i6</b>
0	Activation disabled
1	Activation enabled
The DTCENi6 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 5

<b>DTCENi5</b>	<b>DTC activation enable i5</b>
0	Activation disabled
1	Activation enabled
The DTCENi5 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Bit 4

DTCENi4	DTC activation enable i4
0	Activation disabled
1	Activation enabled
The DTCENi4 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 3

DTCENi3	DTC activation enable i3
0	Activation disabled
1	Activation enabled
The DTCENi3 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 2

DTCENi2	DTC activation enable i2
0	Activation disabled
1	Activation enabled
The DTCENi2 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 1

DTCENi1	DTC activation enable i1
0	Activation disabled
1	Activation enabled
The DTCENi1 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 0

DTCENi0	DTC activation enable i0
0	Activation disabled
1	Activation enabled
The DTCENi0 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Setting DTC base address

- DTC base address register (DTCBAR)  
Sets FDH for the DTC base address.

Symbol	7	6	5	4	3	2	1	0
DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR
	7	6	5	4	3	2	1	0
Set value	1	1	1	1	1	1	0	1

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting DTC control register

- DTC control register 0 (DTCCR0)  
Sets the DTC control register 0.

Symbol	7	6	5	4	3	2	1	0
DTCCR0	<b>0</b>	<b>SZ</b>	<b>RPTINT</b>	<b>CHNE</b>	<b>DAMOD</b>	<b>SAMOD</b>	<b>RPTSEL</b>	<b>MODE</b>
Set value	0	1	1	0	×	0	0	1

## Bit 6

<b>SZ</b>	<b>Transfer data size selection</b>
0	8 bits
1	16 bits

## Bit 5

<b>RPTINT</b>	<b>Enabling/disabling repeat mode interrupts</b>
0	Interrupt generation disabled
1	Interrupt generation enabled

The setting of the RPTINT bit is invalid when the MODE bit is 0 (normal mode).

## Bit 4

<b>CHNE</b>	<b>Enabling/disabling chain transfers</b>
0	Chain transfers disabled
1	Chain transfers enabled

Set the CHNE bit in the DTCCR23 register to 0 (chain transfers disabled).

## Bit 2

<b>SAMOD</b>	<b>Transfer source address control</b>
0	Fixed
1	Incremented

The setting of the SAMOD bit is invalid when the MODE bit is 1 (repeat mode) and the RPTSEL bit is 1 (transfer source is the repeat area).

## Bit 1

<b>RPTSEL</b>	<b>Repeat area selection</b>
0	Transfer destination is the repeat area
1	Transfer source is the repeat area

The setting of the RPTSEL bit is invalid when the MODE bit is 0 (normal mode).

## Bit 0

<b>MODE</b>	<b>Transfer mode selection</b>
0	Normal mode
1	Repeat mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting DTC block size register 0

- DTC block size register 0 (DTBLS0)  
Sets the DTC block size register 0 to 01H (2 bytes).

Symbol	7	6	5	4	3	2	1	0
DTBLS0	<b>DTBLS07</b>	<b>DTBLS06</b>	<b>DTBLS05</b>	<b>DTBLS04</b>	<b>DTBLS03</b>	<b>DTBLS02</b>	<b>DTBLS01</b>	<b>DTBLS00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>

DTBLS0	Transfer block size	
	8-bit transfer	16-bit transfer
00H	256 bytes	512 bytes
<b>01H</b>	1 byte	<b>2 bytes</b>
<b>02H</b>	<b>2 bytes</b>	<b>4 bytes</b>
03H	3 bytes	6 bytes
.	.	.
.	.	.
.	.	.
FDH	253 bytes	506 bytes
FEH	254 bytes	508 bytes
FFH	255 bytes	510 bytes

Setting DTC transfer count register 0

- DTC transfer count register 0 (DTCCT0)  
Sets the DTC transfer count register 0 to 04H (4 times).

Symbol	7	6	5	4	3	2	1	0
DTCCT0	<b>DTCCT07</b>	<b>DTCCT06</b>	<b>DTCCT05</b>	<b>DTCCT04</b>	<b>DTCCT03</b>	<b>DTCCT02</b>	<b>DTCCT01</b>	<b>DTCCT00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>

DTCCT0	Number of transfers
00H	256 times
01H	Once
02H	2 times
03H	3 times
<b>04H</b>	<b>4 times</b>
.	.
.	.
.	.
FDH	253 times
FEH	254 times
FFH	255 times

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

## Setting DTC transfer count reload register 0

- DTC transfer count reload register 0 (DTRLD0)  
Sets the DTC transfer count reload register 0 to 04H (4 times).

Symbol	7	6	5	4	3	2	1	0
DTRLD0	<b>DTRLD07</b>	<b>DTRLD06</b>	<b>DTRLD05</b>	<b>DTRLD04</b>	<b>DTRLD03</b>	<b>DTRLD02</b>	<b>DTRLD01</b>	<b>DTRLD00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>

## Setting DTC source address register 0

- DTC source address register 0 (DTSAR0)  
Set the DTC source address register 0 to the transfer source address FF1EH.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTSAR0	<b>DT SA R0 15</b>	<b>DT SA R0 14</b>	<b>DT SA R0 13</b>	<b>DT SA R0 12</b>	<b>DT SA R0 11</b>	<b>DT SA R0 10</b>	<b>DT SA R0 9</b>	<b>DT SA R0 8</b>	<b>DT SA R0 7</b>	<b>DT SA R0 6</b>	<b>DT SA R0 5</b>	<b>DT SA R0 4</b>	<b>DT SA R0 3</b>	<b>DT SA R0 2</b>	<b>DT SA R0 1</b>	<b>DT SA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>

## Setting DTC destination address register 0

- DTC destination address register 0 (DTDAR0)  
Set the DTC destination address register 0 to the transfer destination address F500H.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTDAR0	<b>DT DA R0 15</b>	<b>DT DA R0 14</b>	<b>DT DA R0 13</b>	<b>DT DA R0 12</b>	<b>DT DA R0 11</b>	<b>DT DA R0 10</b>	<b>DT DA R0 9</b>	<b>DT DA R0 8</b>	<b>DT DA R0 7</b>	<b>DT DA R0 6</b>	<b>DT DA R0 5</b>	<b>DT DA R0 4</b>	<b>DT DA R0 3</b>	<b>DT DA R0 2</b>	<b>DT DA R0 1</b>	<b>DT DA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(7) Main Processing

Figure 7.11 shows the flowchart for the main processing.




Figure 7.11 Main Processing (example of migration from single sweep mode)



(8) Enabling DTC Activation

Figure 7.12 shows the flowchart for enabling DTC activation.




Figure 7.12 Enabling DTC Activation (example of migration from single sweep mode)

Enabling DTC activation

- DTC activation enable register 1 (DTCEN1)  
Enables DTC activation by the A/D conversion end.

Symbol	7	6	5	4	3	2	1	0
DTCEN1	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>
	<b>7</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>	<b>0</b>
Set value	×	×	<b>1</b>	×	×	×	×	×

Bit 5	
<b>DTCEN15</b>	<b>DTC activation enable 15 (DTC activation source: A/D conversion end)</b>
0	Activation disabled
<b>1</b>	<b>Activation enabled</b>
The DTCEN15 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

(9) Starting A/D Conversion

Figure 7.13 shows the flowchart for starting A/D conversion.




Figure 7.13 Starting A/D Conversion (example of migration from single sweep mode)

Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0	
<b>ADIF</b>	<b>Interrupt request flag</b>
<b>0</b>	<b>No interrupt request signal is generated</b>
1	Interrupt request is generated, interrupt request status

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Enabling A/D conversion end interrupt

- Interrupt mask flag register (MK1H)  
Enables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	TMMK10	TRJMK0	SRMK3 CSIMK31 IICMK31	STMK3 CSIMK30 IICMK30	KRMK	ITMK	RTCMK	ADMK
Set value	x	x	x	x	x	x	x	0

Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

Starting A/D converter

- A/D converter mode register 0 (ADM0)  
Starts A/D conversion operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	ADCS	ADMD	FR2	FR1	FR0	LV1	LV0	ADCE
Set value	1	x	x	x	x	x	x	x

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	Stops conversion operation [When read] Conversion stopped/standby status
1	<b>Enables conversion operation</b> [When read] <b>While in the software trigger mode: Conversion operation status</b> <b>While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(10) A/D conversion end interrupt

Figure 7.14 shows the flowchart for A/D conversion end interrupt processing.




Figure 7.14 A/D Conversion End Interrupt (example of migration from single sweep mode)

## 7.5 Sample Code

Sample code can be downloaded from the Renesas Electronics website.

## 7.6 Reference Application Note

- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: A/D Converter CC-RL (R01AN3059)
- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: Data Transfer Controller (R01AN1503)
- RL78/G14 How to Use the DTC for the RL78/G14 (R01AN0861)
- RL78/G14 Transferring A/D Conversion Result Using the DTC CC-RL (R01AN2574)

## 7.7 Reference Documents

### User's Manual

- RL78/G14 User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- R8C/36M Group User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- Technical Update/Technical News  
(The latest information can be downloaded from the Renesas Electronics website.)

### Migration Guide

- Migration to CubeSuite+ Integrated Development Environment for RL78 Family  
(On-chip Debug) - Migration from R8C, M16C to RL78 (R20UT2150)

## 8. Example of Migration from Repeat Sweep Mode

### 8.1 Specifications

To implement R8C/36M repeat sweep mode in the RL78/G14, the AD converter (software trigger, scan, sequential conversion mode) and DTC transfer (repeat mode) are used.

The analog input voltage of the ANI0 to ANI3 pins is A/D-converted in scan mode and sequential conversion mode, and the A/D conversion result values are stored in the RAM assigned to each pin by DTC transfer. Specifically, A/D conversion on the pins is sequentially performed; each time A/D conversion on one pin ends, the conversion result is stored in the 10-bit A/D conversion result register (ADCR), and an A/D conversion end interrupt signal is generated. In response to the interrupt signal, the DTC is activated, and the A/D conversion result is transferred from the ADCR register to the RAM. When A/D conversion and DTC transfer on all the pins are completed, an A/D conversion end interrupt request is generated.

Table 8.1 shows the peripheral functions used and the purpose of use, and Figure 8.1 shows the operation summary.

Table 8.1 Peripheral Functions Used and Purpose of Use (example of migration from repeat sweep mode)

Peripheral Function	Purpose of Use
A/D converter	Performs A/D conversion on the analog input voltage.
DTC	Transfers A/D conversion result to RAM.




Figure 8.1 Operation Summary (example of migration from repeat sweep mode)

## 8.2 Conditions for Confirming Operations

The sample code operations described in this application note are confirmed under the following conditions.

Table 8.2 Conditions for Confirming Operations (example of migration from repeat sweep mode)

Item	Description
Microcontroller used	RL78/G14 (R5F104LEA)
Operating frequency	<ul style="list-style-type: none"> <li>High-speed on-chip oscillator clock (<math>f_{IH}</math>): 32 MHz</li> <li>CPU/peripheral hardware clock (<math>f_{CLK}</math>): 32 MHz</li> </ul>
Operating voltage	5.0 V (can be operated from 3.6 V to 5.5 V) LVD operation ( $V_{LVD}$ ): Reset mode; rise 3.13 V/fall 3.06 V
Integrated development environment (CS+)	CS+ for CC V5.00.00 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.
Integrated development environment (e <sup>2</sup> studio)	e <sup>2</sup> studio V5.4.0.015 from Renesas Electronics Corp.
C compiler (CS+)	CC-RL V1.04.00 from Renesas Electronics Corp.

## 8.3 Hardware Descriptions

### 8.3.1 Hardware Configuration Example

Figure 8.2 shows an example of the hardware configuration used for this application.




Figure 8.2 Hardware Configuration (example of migration from repeat sweep mode)



### 8.3.2 List of Pins Used

Table 8.3 lists the pins used and their functions.

Table 8.3 Pins Used and Their Functions (example of migration from repeat sweep mode)

Pin Name	I/O	Function
P20/ANI0	Input	A/D converter input (ANI0)
P21/ANI1	Input	A/D converter input (ANI1)
P22/ANI2	Input	A/D converter input (ANI2)
P23/ANI3	Input	A/D converter input (ANI3)

## 8.4 Software Descriptions

### 8.4.1 Operation Summary

With this sample program, the A/D conversion on four pins is performed in scan mode, and the conversion results are stored in the RAM by DTC transfer. The DTC is used in repeat mode with the transfer destination set as repeat area, and the conversion results on the four pins are sequentially stored in the RAM. By setting sequential conversion mode, A/D conversion on the four pins is repeated.

Upon completion of the A/D conversion on the ANI0 pin, the first DTC transfer is performed from the transfer source addresses (ADCR register (FFF1EH, FFF1FH)) to the transfer destination addresses (`g_ad_value[0]` (FF500H to FF501H)). Upon completion of the A/D conversion on the ANI1 pin, the second DTC transfer is performed to `g_ad_value[1]` (FF502H to FF503H) since the transfer destination is set as the repeat area. Similarly, the A/D conversion results of the ANI3 and ANI4 pins are DTC-transferred. Upon completion of the fourth transfer, an A/D conversion end interrupt is generated.

In interrupt processing, the A/D conversion results stored in the array `g_ad_value[]` (FF500H to FF507H) are relocated in the lower 10 bits before being stored in the buffers for storing the A/D conversion results (variable `g_ad_an0_value` to `g_ad_an3_value`).

After this, the above sequence is repeated to update the acquired A/D conversion results.

Table 8.4 shows the A/D converter settings and Table 8.5 shows the DTC settings.

Table 8.4 A/D Converter Settings (example of migration from repeat sweep mode)

Item to be Set	Settings
Conversion clock frequency ( $f_{AD}$ )	$f_{CLK}/8$
A/D conversion mode	<ul style="list-style-type: none"> <li>A/D conversion trigger mode: Software trigger</li> <li>A/D conversion channel selection mode: Scan mode</li> <li>A/D conversion operation mode: Sequential conversion mode</li> </ul>
Resolution	10 bits
Analog input channel	<ul style="list-style-type: none"> <li>Scan 0: ANI0</li> <li>Scan 1: ANI1</li> <li>Scan 2: ANI2</li> <li>Scan 3: ANI3</li> </ul>
A/D conversion result comparison upper limit (ADUL register)	FFH
A/D conversion result comparison lower limit (ADLL register)	00H
Upper and lower limit conversion result checking	INTAD generated when ADLL register $\leq$ ADCR register $\leq$ ADUL register

Table 8.5 DTC Settings (example of migration from repeat sweep ode)

Item to be Set	Settings
	Control Data 0
Transfer mode	Repeat mode
Repeat mode interrupt	Enabled
Source address control	Fixed
Destination address control	Repeat area
Chain transfer control	Disabled
Transfer block size	2 bytes (16-bit transfer)
DTC transfer count	4
Transfer source address	ADCR (FFF1EH to FFF1FH)
Transfer destination address	g_ad_value[0] (FF500H to FF501H), g_ad_value[1] (FF502H to FF503H), g_ad_value[2] (FF504H to FF505H), g_ad_value[3] (FF506H to FF507H)

- (1) The initial setting is made for the A/D converter and DTC.
- (2) The ADCS bit in the ADM0 register is set to 1 (conversion enabled) to start A/D conversion.
- (3) Upon completion of the A/D conversion on each of the pins (ANI0, ANI1, ANI2, and ANI3 pins), the DTC is activated.
- (4) The DTC reads the A/D conversion result from the ADCR register and transfers it to the RAM (g\_ad\_value[0] to g\_ad\_value[3]) corresponding to the pin.
- (5) Upon completion of the fourth DTC transfer, an A/D conversion end interrupt is generated.
- (6) In interrupt processing, DTC activation is again enabled. Also, the A/D conversion results g\_ad\_value[0] to g\_ad\_value[3] are shifted to the right by 6 bits (relocated in the lower 10 bits) and stored in the variables g\_ad\_an0\_value to g\_ad\_an3\_value.
- (7) After this, steps (2) to (6) are repeated

Figure 8.3 shows the A/D conversion and DTC transfer timing and Figure 8.4 shows the relationship between the ADCR register and RAM.




Figure 8.3 A/D Conversion and DTC Transfer Timing (example of migration from repeat sweep mode)




Figure 8.4 Relationship between ADCR Register and RAM (example of migration from repeat sweep mode)

### 8.4.2 List of Option Byte Settings

Table 8.6 lists option byte settings.

Table 8.6 Option Byte Settings (example of migration from repeat sweep mode)

Address	Setting	Contents
000C0H/010C0H	01101110B	Watchdog timer is stopped. (Counting stopped after a reset release)
000C1H/010C1H	00110011B	LVD reset mode Detection voltage: rise 3.13 V/fall 3.06 V
000C2H/010C2H	11101000B	HS mode High-speed on-chip oscillator clock frequency: 32 MHz
000C3H/010C3H	10000100B	On-chip debugging is enabled.

### 8.4.3 List of Constants

Table 8.7 lists the constant used in the sample code.

Table 8.7 Constant Used in Sample Code (example of migration from repeat sweep mode)

Constant Name	Setting	Contents
AD_RESULT_ADDR	0FF500H	Transfer destination address of A/D conversion result

### 8.4.4 List of Variables

Table 8.8 lists the global variables.

Table 8.8 Global Variables (example of migration from repeat sweep mode)

Type	Variable Name	Contents	Function Used
uint16_t __near	g_ad_value[4]	Buffer for storing A/D conversion results of ANI0 to ANI3	r_adc_interrupt
uint16_t	g_ad_an0_value	Buffer for storing A/D conversion result of ANI0	r_adc_interrupt
uint16_t	g_ad_an1_value	Buffer for storing A/D conversion result of ANI1	r_adc_interrupt
uint16_t	g_ad_an2_value	Buffer for storing A/D conversion result of ANI2	r_adc_interrupt
uint16_t	g_ad_an3_value	Buffer for storing A/D conversion result of ANI3	r_adc_interrupt

### 8.4.5 Functions

Table 8.9 lists the Functions.

Table 8.9 Functions (example of migration from repeat sweep mode)

Function Name	Outline
hdwinit	Initial setting
R_Systeminit	Initial setting of peripheral functions
R_CGC_Create	CPU initial setting
R_ADC_Create	Initial setting of A/D converter
R_DTC_Create	Initial setting of DTC
main	Main processing
R_DTCD0_Start	DTC activation
R_ADC_Start	A/D conversion start
r_adc_interrupt	A/D conversion interrupt

### 8.4.6 Function Specifications

The following tables list the sample code function specifications.

hdwinit	
Outline	Initial setting
Header	None
Declaration	void hdwinit(void)
Description	Perform the initial setting of peripheral functions.
Argument	None
Return Value	None

R_Systeminit	
Outline	Initial setting of peripheral functions
Header	None
Declaration	void R_Systeminit(void)
Description	Perform the initial setting of peripheral functions used in this document.
Argument	None
Return Value	None

R_CGC_Create	
Outline	CPU initial setting
Header	None
Declaration	void R_CGC_Create(void)
Description	Perform the initial setting of the CPU.
Argument	None
Return Value	None

R_ADC_Create	
Outline	Initial setting of A/D converter
Header	None
Declaration	void R_ADC_Create(void)
Description	Perform the initial setting to use the A/D converter in software trigger mode, scan mode, and sequential conversion mode.
Argument	None
Return Value	None

R_DTC_Create	
Outline	Initial setting of DTC
Header	None
Declaration	void R_DTC_Create(void)
Description	Perform the initial setting to use the DTC in repeat mode.
Argument	None
Return Value	None

main	
Outline	Main processing
Header	None
Declaration	void main(void)
Description	Perform main processing.
Argument	None
Return Value	None

R_DTCD0_Start	
Outline	DTC activation
Header	None
Declaration	void R_DTCD0_Start(void)
Description	Enable DTC activation.
Argument	None
Return Value	None

R_ADC_Start	
Outline	A/D conversion start
Header	None
Declaration	void R_ADC_Start(void)
Description	Perform A/D conversion.
Argument	None
Return Value	None

r_adc_interrupt	
Outline	A/D conversion interrupt
Header	None
Declaration	static void __near r_adc_interrupt(void)
Description	Perform an A/D conversion end interrupt service routine.
Argument	None
Return Value	None

8.4.7 Flowcharts

(1) Overall Flowchart

Figure 8.5 shows the Overall Flowchart.




Figure 8.5 Overall Flowchart (example of migration from repeat sweep mode)

(2) Initial Setting

Figure 8.6 shows the Initial Setting.




Figure 8.6 Initial Setting (example of migration from repeat sweep mode)

(3) Initial Setting of Peripheral Functions

Figure 8.7 shows the initial setting of peripheral functions.




Figure 8.7 Initial Setting of Peripheral Functions (example of migration from repeat sweep mode)

(4) Initial Setting of CPU

Figure 8.8 shows the initial setting of the CPU.




Figure 8.8 Initial Setting of CPU (example of migration from repeat sweep mode)



## (5) Initial Setting of A/D Converter

Figure 8.9 shows the initial setting of the A/D converter.




Figure 8.9 Initial Setting of A/D Converter (example of migration from repeat sweep mode)

Starting clock supply to A/D converter

- Peripheral enable register 0 (PER0)  
Starts supplying clock to the A/D converter.

Symbol	7	6	5	4	3	2	1	0
PER0	<b>RTCEN</b>	<b>IICA1EN</b>	<b>ADCEN</b>	<b>IICA0EN</b>	<b>SAU1EN</b>	<b>SAU0EN</b>	<b>TAU1EN</b>	<b>TAU0EN</b>
Set value	x	x	1	x	x	x	x	x

Bit 5

<b>ADCEN</b>	<b>Control of A/D converter input clock supply</b>
0	Stops input clock supply. Stops input clock supply. <ul style="list-style-type: none"> <li>SFR used by the A/D converter cannot be written.</li> </ul>
1	<b>Enables input clock supply.</b> <ul style="list-style-type: none"> <li>SFR used by the A/D converter can be read and written.</li> </ul>

Stopping A/D converter operation

- A/D converter mode register 0 (ADM0)  
Stops A/D converter.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	0	x	x	x	x	x	x	0

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	<b>Stops conversion operation.</b> [When read] <b>Conversion stopped/standby status</b>
1	Enables conversion operation. [When read] While in the software trigger mode: Conversion operation status While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status

Bit 0

<b>ADCE</b>	<b>A/D voltage comparator operation control</b>
0	<b>Stops A/D voltage comparator operation.</b>
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Disabling A/D conversion end interrupt

- Interrupt mask flag register 1 (MK1H)  
Disables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	×	×	×	×	×	×	×	<b>1</b>

## Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
0	Interrupt servicing enabled
1	Interrupt servicing disabled

## Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	×	×	×	×	×	×	×	<b>0</b>

## Bit 0

<b>ADIF</b>	<b>Interrupt request flag</b>
0	No interrupt request signal is generated.
1	Interrupt request is generated, interrupt request status

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Specifying A/D conversion end interrupt priority level

- Priority specification flag register (PR11H, PR01H)  
Specifies level 3 (lowest priority level).

Symbol	7	6	5	4	3	2	1	0
PR11H	<b>TMPR11</b> 0	<b>TRJPR10</b>	<b>SRPR13</b> <b>CSIPR131</b> <b>IICPR131</b>	<b>STPR13</b> <b>CSIPR130</b> <b>IICPR130</b>	<b>KRPR1</b>	<b>ITPR1</b>	<b>RTCPR1</b>	<b>ADPR1</b>
Set value	x	x	x	x	x	x	x	1

Symbol	7	6	5	4	3	2	1	0
PR01H	<b>TMPR01</b> 0	<b>TRJPR00</b>	<b>SRPR03</b> <b>CSIPR031</b> <b>IICPR031</b>	<b>STPR03</b> <b>CSIPR030</b> <b>IICPR030</b>	<b>KRPR0</b>	<b>ITPR0</b>	<b>RTCPR0</b>	<b>ADPR0</b>
Set value	x	x	x	x	x	x	x	1

Bit 0

ADPR1	ADPR0	Priority level selection
0	0	Specifies level 0 (high priority level).
0	1	Specifies level 1.
1	0	Specifies level 2.
1	1	<b>Specifies level 3 (low priority level).</b>

Setting port mode register 2

- Port mode register 2 (PM2)  
Sets the port mode register 2 to input mode.

Symbol	7	6	5	4	3	2	1	0
PM2	<b>PM27</b>	<b>PM26</b>	<b>PM25</b>	<b>PM24</b>	<b>PM23</b>	<b>PM22</b>	<b>PM21</b>	<b>PM20</b>
Set value	x	x	x	x	1	1	1	1

Bits 3-0

PM2n	P2n pin I/O mode selection
0	Output mode (output buffer on)
1	<b>Input mode (output buffer off)</b>

Remark n: Channel number (n = 0 to 3)

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting A/D conversion mode and conversion time

- A/D converter mode register 0 (ADM0)  
Sets the A/D conversion mode and conversion time.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	×	1	0	1	1	0	0	×

Bit 6

ADMD	Specification of A/D conversion channel selection mode
0	Select mode
1	Scan mode

Bits 5-1

A/D converter mode register 0 (ADM0)					Mode	Conversion time selection					Conv. clock (f <sub>AD</sub> )
FR2	FR1	FR0	LV1	LV0		f <sub>CLK</sub> = 1 MHz	f <sub>CLK</sub> = 4 MHz	f <sub>CLK</sub> = 8 MHz	f <sub>CLK</sub> = 16 MHz	f <sub>CLK</sub> = 32 MHz	
0	0	0	0	0	Normal 1	Setting prohibited	Setting prohibited	Setting prohibited	76 μs	38 μs	f <sub>CLK</sub> /64
0	0	1				76 μs	38 μs	19 μs	f <sub>CLK</sub> /32		
0	1	0				76 μs	38 μs	19 μs	9.5 μs	f <sub>CLK</sub> /16	
0	1	1				38 μs	19 μs	9.5 μs	<b>4.75 μs</b>	<b>f<sub>CLK</sub>/8</b>	
1	0	0				28.5 μs	14.25 μs	7.125 μs	3.5625 μs	f <sub>CLK</sub> /6	
1	0	1				95 μs	23.75 μs	11.875 μs	5.938 μs	2.9688 μs	f <sub>CLK</sub> /5
1	1	0				76 μs	19 μs	9.5 μs	4.75 μs	2.375 μs	f <sub>CLK</sub> /4
1	1	1				38 μs	9.5 μs	4.75 μs	2.375 μs	Setting prohibited	f <sub>CLK</sub> /2
0	0	0	0	1	Normal 2	Setting prohibited	Setting prohibited	Setting prohibited	68 μs	34 μs	f <sub>CLK</sub> /64
0	0	1				68 μs	34 μs	17 μs	f <sub>CLK</sub> /32		
0	1	0				68 μs	34 μs	17 μs	8.5 μs	f <sub>CLK</sub> /16	
0	1	1				34 μs	17 μs	8.5 μs	4.25 μs	f <sub>CLK</sub> /8	
1	0	0				25.5 μs	12.75 μs	6.375 μs	3.1875 μs	f <sub>CLK</sub> /6	
1	0	1				85 μs	21.25 μs	10.625 μs	5.3125 μs	2.6563 μs	f <sub>CLK</sub> /5
1	1	0				68 μs	17 μs	8.5 μs	4.25 μs	2.125 μs	f <sub>CLK</sub> /4
1	1	1				34 μs	8.5 μs	4.25 μs	2.125 μs	Setting prohibited	f <sub>CLK</sub> /2

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 1 (ADM1)  
Selects the A/D conversion trigger mode.

Symbol	7	6	5	4	3	2	1	0
ADM1	<b>ADTMD1</b>	<b>ADTMD0</b>	<b>ADSCM</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ADTRS1</b>	<b>ADTRS0</b>
Set value	<b>0</b>	x	<b>0</b>	0	0	0	x	x

## Bits 7-6

ADTMD1	ADTMD0	Selection of A/D conversion trigger mode
<b>0</b>	-	<b>Software trigger mode</b>
1	0	Hardware trigger no-wait mode
1	1	Hardware trigger wait mode

## Bit 5

ADSCM	Specification of A/D conversion mode
<b>0</b>	<b>Sequential conversion mode</b>
1	One-shot conversion mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting A/D conversion trigger mode

- A/D converter mode register 2 (ADM2)  
Selects the A/D converter reference voltage source, checks the conversion result against upper-limit/lower-limit value, and selects A/D conversion resolution.

Symbol	7	6	5	4	3	2	1	0
ADM2	<b>ADREFP1</b>	<b>ADREFP0</b>	<b>ADREFM</b>	<b>0</b>	<b>ADRCK</b>	<b>AWC</b>	<b>0</b>	<b>ADTYP</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	0	<b>0</b>	x	0	<b>0</b>

## Bits 7-6

<b>ADREFP1</b>	<b>ADREFP0</b>	<b>Selection of + side reference voltage source of A/D converter</b>
<b>0</b>	<b>0</b>	<b>Supplied from V<sub>DD</sub></b>
0	1	Supplied from P20/AV <sub>REFP</sub> /ANI0
1	0	Supplied from internal reference voltage (1.45 V)
1	1	Setting prohibited

Before rewriting ADREFP1 or ADREFP0 bit, set ADREFP1 and ADREFP0 bits to 0 and 0.  
When setting ADREFP1 and ADREFP0 bits to 1 and 0, respectively, this must be configured in accordance with the following procedures.

- (1) Set ADCE = 0
- (2) Set ADREFP1 and ADREFP0 to 1 and 0, respectively.
- (3) Set ADCE = 1

A wait time (T.B.D) is necessary after (2) and (3).  
When ADREFP1 and ADREFP0 are set to 1 and 0, respectively, A/D conversion cannot be performed on the temperature sensor output. Be sure to perform A/D conversion while ADISS = 0.

## Bit 5

<b>ADREFM</b>	<b>Selection of – side reference voltage source of A/D converter</b>
<b>0</b>	<b>Supplied from V<sub>SS</sub></b>
1	Supplied from P21/AV <sub>REFM</sub> /ANI1

## Bit 3

<b>ADRCK</b>	<b>Checking upper limit and lower limit conversion result values</b>
<b>0</b>	<b>Interrupt signal (INTAD) is generated when the ADLL register ≤ the ADCR register ≤ the ADUL register.</b>
1	Interrupt signal (INTAD) is generated when ADCR register < ADLL register, ADUL register < ADCR register.

## Bit 0

<b>ADTYP</b>	<b>Selection of A/D conversion resolution</b>
<b>0</b>	<b>10-bit resolution</b>
1	8-bit resolution

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Setting upper limit value for conversion result comparison

- Conversion result comparison upper limit setting register (ADUL)  
Sets the upper limit conversion result compare value to FFH.

Symbol	7	6	5	4	3	2	1	0
ADUL	<b>ADUL7</b>	<b>ADUL6</b>	<b>ADUL5</b>	<b>ADUL4</b>	<b>ADUL3</b>	<b>ADUL2</b>	<b>ADUL1</b>	<b>ADUL0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

Setting lower limit values for conversion result comparison

- Conversion result comparison lower limit setting register (ADLL)  
Sets the lower limit conversion result compare value to 00H.

Symbol	7	6	5	4	3	2	1	0
ADLL	<b>ADLL7</b>	<b>ADLL6</b>	<b>ADLL5</b>	<b>ADLL4</b>	<b>ADLL3</b>	<b>ADLL2</b>	<b>ADLL1</b>	<b>ADLL0</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.



Setting analog input channels

- Analog input channel specification register (ADS)  
Set analog input channels to ANI0 to ANI3.

Symbol	7	6	5	4	3	2	1	0
ADS	<b>ADISS</b>	<b>0</b>	<b>0</b>	<b>ADS4</b>	<b>ADS3</b>	<b>ADS2</b>	<b>ADS1</b>	<b>ADS0</b>
Set value	<b>0</b>	0	0	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

- Scan mode (ADMD = 1)

Bits 7, 4-0

ADISS	ADS4	ADS3	ADS2	ADS1	ADS0	Analog input channel			
						Scan 0	Scan 1	Scan 2	Scan 3
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ANI0</b>	<b>ANI1</b>	<b>ANI2</b>	<b>ANI3</b>
0	0	0	0	0	1	ANI1	ANI2	ANI3	ANI4
0	0	0	0	1	0	ANI2	ANI3	ANI4	ANI5
0	0	0	0	1	1	ANI3	ANI4	ANI5	ANI6
0	0	0	1	0	0	ANI4	ANI5	ANI6	ANI7
0	0	0	1	0	1	ANI5	ANI6	ANI7	ANI8
0	0	0	1	1	0	ANI6	ANI7	ANI8	ANI9
0	0	0	1	1	1	ANI7	ANI8	ANI9	ANI10
0	0	1	0	0	0	ANI8	ANI9	ANI10	ANI11
0	0	1	0	0	1	ANI9	ANI10	ANI11	ANI12
0	0	1	0	1	0	ANI10	ANI11	ANI12	ANI13
0	0	1	0	1	1	ANI11	ANI12	ANI13	ANI14
Other than the above						Setting prohibited			

Setting A/D voltage comparator

- A/D converter mode register 0 (ADM0)  
Starts A/D voltage comparator operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	x	x	x	x	x	x	x	<b>1</b>

Bit 0

ADCE	A/D voltage comparator operation control
0	Stops A/D voltage comparator operation.
1	Enables A/D voltage comparator operation.

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(6) Initial Setting of DTC

Figure 8.10 shows the initial setting of the DTC.




Figure 8.10 Initial Setting of DTC (example of migration from repeat sweep mode)

Starting clock supply to DTC

- Peripheral enable register 1 (PER1)  
Starts supplying clock to the DTC.

Symbol	7	6	5	4	3	2	1	0
PER1	<b>DACEN</b>	<b>TRGEN</b>	<b>CMPEN</b>	<b>TRD0EN</b>	<b>DTCEN</b>	<b>0</b>	<b>0</b>	<b>TRJ0EN</b>
Set value	x	x	x	x	1	0	0	x

Bit 3

<b>DTCEN</b>	<b>Control of DTC input clock supply</b>
0	Stops input clock supply.
1	Enables input clock supply.

Disabling DTC activation

- DTC activation enable register i (DTCENi) (i = 0 to 4)  
Disables DTC activation.

Symbol	7	6	5	4	3	2	1	0
DTCENi	<b>DTCENi7</b>	<b>DTCENi6</b>	<b>DTCENi5</b>	<b>DTCENi4</b>	<b>DTCENi3</b>	<b>DTCENi2</b>	<b>DTCENi1</b>	<b>DTCENi0</b>
Set value	0	0	0	0	0	0	0	0

Bit 7

<b>DTCENi7</b>	<b>DTC activation enable i7</b>
0	Activation disabled
1	Activation enabled
The DTCENi7 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 6

<b>DTCENi6</b>	<b>DTC activation enable i6</b>
0	Activation disabled
1	Activation enabled
The DTCENi6 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 5

<b>DTCENi5</b>	<b>DTC activation enable i5</b>
0	Activation disabled
1	Activation enabled
The DTCENi5 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Bit 4

DTCENi4	DTC activation enable i4
0	Activation disabled
1	Activation enabled
The DTCENi4 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 3

DTCENi3	DTC activation enable i3
0	Activation disabled
1	Activation enabled
The DTCENi3 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 2

DTCENi2	DTC activation enable i2
0	Activation disabled
1	Activation enabled
The DTCENi2 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 1

DTCENi1	DTC activation enable i1
0	Activation disabled
1	Activation enabled
The DTCENi1 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Bit 0

DTCENi0	DTC activation enable i0
0	Activation disabled
1	Activation enabled
The DTCENi0 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

Setting DTC base address

- DTC base address register (DTCBAR)  
Sets FDH for the DTC base address.

Symbol	7	6	5	4	3	2	1	0
DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR	DTCBAR
	7	6	5	4	3	2	1	0
Set value	1	1	1	1	1	1	0	1

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

## Setting DTC control register

- DTC control register 0 (DTCCR0)  
Sets the DTC control register 0.

Symbol	7	6	5	4	3	2	1	0
DTCCR0	<b>0</b>	<b>SZ</b>	<b>RPTINT</b>	<b>CHNE</b>	<b>DAMOD</b>	<b>SAMOD</b>	<b>RPTSEL</b>	<b>MODE</b>
Set value	0	1	1	0	×	0	0	1

## Bit 6

<b>SZ</b>	<b>Transfer data size selection</b>
0	8 bits
1	16 bits

## Bit 5

<b>RPTINT</b>	<b>Enabling/disabling repeat mode interrupts</b>
0	Interrupt generation disabled
1	Interrupt generation enabled

The setting of the RPTINT bit is invalid when the MODE bit is 0 (normal mode).

## Bit 4

<b>CHNE</b>	<b>Enabling/disabling chain transfers</b>
0	Chain transfers disabled
1	Chain transfers enabled

Set the CHNE bit in the DTCCR23 register to 0 (chain transfers disabled).

## Bit 2

<b>SAMOD</b>	<b>Transfer source address control</b>
0	Fixed
1	Incremented

The setting of the SAMOD bit is invalid when the MODE bit is 1 (repeat mode) and the RPTSEL bit is 1 (transfer source is the repeat area).

## Bit 1

<b>RPTSEL</b>	<b>Repeat area selection</b>
0	Transfer destination is the repeat area
1	Transfer source is the repeat area

The setting of the RPTSEL bit is invalid when the MODE bit is 0 (normal mode).

## Bit 0

<b>MODE</b>	<b>Transfer mode selection</b>
0	Normal mode
1	Repeat mode

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

Setting DTC block size register 0

- DTC block size register 0 (DTBLS0)  
Sets the DTC block size register 0 to 01H (2 bytes).

Symbol	7	6	5	4	3	2	1	0
DTBLS0	<b>DTBLS07</b>	<b>DTBLS06</b>	<b>DTBLS05</b>	<b>DTBLS04</b>	<b>DTBLS03</b>	<b>DTBLS02</b>	<b>DTBLS01</b>	<b>DTBLS00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>

DTBLS0	Transfer block size	
	8-bit transfer	16-bit transfer
00H	256 bytes	512 bytes
<b>01H</b>	<b>1 byte</b>	<b>2 bytes</b>
<b>02H</b>	<b>2 bytes</b>	<b>4 bytes</b>
03H	3 bytes	6 bytes
.	.	.
.	.	.
.	.	.
FDH	253 bytes	506 bytes
FEH	254 bytes	508 bytes
FFH	255 bytes	510 bytes

Setting DTC transfer count register 0

- DTC transfer count register 0 (DTCCT0)  
Sets the DTC transfer count register 0 to 04H (4 times).

Symbol	7	6	5	4	3	2	1	0
DTCCT0	<b>DTCCT07</b>	<b>DTCCT06</b>	<b>DTCCT05</b>	<b>DTCCT04</b>	<b>DTCCT03</b>	<b>DTCCT02</b>	<b>DTCCT01</b>	<b>DTCCT00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>

DTCCT0	Number of transfers
00H	256 times
01H	Once
02H	2 times
03H	3 times
<b>04H</b>	<b>4 times</b>
.	.
.	.
.	.
FDH	253 times
FEH	254 times
FFH	255 times

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

## Setting DTC transfer count reload register 0

- DTC transfer count reload register 0 (DTRLD0)  
Sets the DTC transfer count reload register 0 to 04H (4 times).

Symbol	7	6	5	4	3	2	1	0
DTRLD0	<b>DTRLD07</b>	<b>DTRLD06</b>	<b>DTRLD05</b>	<b>DTRLD04</b>	<b>DTRLD03</b>	<b>DTRLD02</b>	<b>DTRLD01</b>	<b>DTRLD00</b>
Set value	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>

## Setting DTC source address register 0

- DTC source address register 0 (DTSAR0)  
Set the DTC source address register 0 to the transfer source address FF1EH.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTSAR0	<b>DT SA R0 15</b>	<b>DT SA R0 14</b>	<b>DT SA R0 13</b>	<b>DT SA R0 12</b>	<b>DT SA R0 11</b>	<b>DT SA R0 10</b>	<b>DT SA R0 9</b>	<b>DT SA R0 8</b>	<b>DT SA R0 7</b>	<b>DT SA R0 6</b>	<b>DT SA R0 5</b>	<b>DT SA R0 4</b>	<b>DT SA R0 3</b>	<b>DT SA R0 2</b>	<b>DT SA R0 1</b>	<b>DT SA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>

## Setting DTC destination address register 0

- DTC destination address register 0 (DTDAR0)  
Set the DTC destination address register 0 to the transfer destination address F500H.

Symbol	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DTDAR0	<b>DT DA R0 15</b>	<b>DT DA R0 14</b>	<b>DT DA R0 13</b>	<b>DT DA R0 12</b>	<b>DT DA R0 11</b>	<b>DT DA R0 10</b>	<b>DT DA R0 9</b>	<b>DT DA R0 8</b>	<b>DT DA R0 7</b>	<b>DT DA R0 6</b>	<b>DT DA R0 5</b>	<b>DT DA R0 4</b>	<b>DT DA R0 3</b>	<b>DT DA R0 2</b>	<b>DT DA R0 1</b>	<b>DT DA R0 0</b>
Set value	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(7) Main Processing

Figure 8.11 shows the flowchart for the main processing.




Figure 8.11 Main Processing (example of migration from repeat sweep mode)



(8) Enabling DTC Activation

Figure 8.12 shows the flowchart for enabling DTC activation.




Figure 8.12 Enabling DTC Activation (example of migration from repeat sweep mode)

Enabling DTC activation

- DTC activation enable register 1 (DTCEN1)  
Enables DTC activation by the A/D conversion end.

Symbol	7	6	5	4	3	2	1	0
DTCEN1	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>	<b>DTCEN1</b>
	<b>7</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>	<b>0</b>
Set value	×	×	<b>1</b>	×	×	×	×	×

Bit 5	
<b>DTCEN15</b>	<b>DTC activation enable 15 (DTC activation source: A/D conversion end)</b>
0	Activation disabled
<b>1</b>	<b>Activation enabled</b>
The DTCEN15 bit is set to 0 (activation disabled) by a condition for generating a transfer end interrupt.	

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

(9) Starting A/D Conversion

Figure 8.13 shows the flowchart for starting A/D conversion.




Figure 8.13 Starting A/D Conversion (example of migration from repeat sweep mode)

Setting A/D conversion end interrupt request flag

- Interrupt request flag register (IF1H)  
Clears the A/D conversion end interrupt request flag.

Symbol	7	6	5	4	3	2	1	0
IF1H	<b>TMIF10</b>	<b>TRJIF0</b>	<b>SRIF3</b> <b>CSIF31</b> <b>IICIF31</b>	<b>STIF3</b> <b>CSIF30</b> <b>IICIF30</b>	<b>KRIF</b>	<b>ITIF</b>	<b>RTCIF</b>	<b>ADIF</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0	
<b>ADIF</b>	<b>Interrupt request flag</b>
<b>0</b>	<b>No interrupt request signal is generated</b>
1	Interrupt request is generated, interrupt request status

x in “Set value” of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User’s Manual: Hardware.

Enabling A/D conversion end interrupt

- Interrupt mask flag register (MK1H)  
Enables the A/D conversion end interrupt.

Symbol	7	6	5	4	3	2	1	0
MK1H	<b>TMMK10</b>	<b>TRJMK0</b>	<b>SRMK3</b> <b>CSIMK31</b> <b>IICMK31</b>	<b>STMK3</b> <b>CSIMK30</b> <b>IICMK30</b>	<b>KRMK</b>	<b>ITMK</b>	<b>RTCMK</b>	<b>ADMK</b>
Set value	x	x	x	x	x	x	x	<b>0</b>

Bit 0

<b>ADMK</b>	<b>Interrupt servicing control</b>
<b>0</b>	<b>Interrupt servicing enabled</b>
1	Interrupt servicing disabled

Starting A/D converter

- A/D converter mode register 0 (ADM0)  
Starts A/D conversion operation.

Symbol	7	6	5	4	3	2	1	0
ADM0	<b>ADCS</b>	<b>ADMD</b>	<b>FR2</b>	<b>FR1</b>	<b>FR0</b>	<b>LV1</b>	<b>LV0</b>	<b>ADCE</b>
Set value	<b>1</b>	x	x	x	x	x	x	x

Bit 7

<b>ADCS</b>	<b>A/D conversion operation control</b>
0	Stops conversion operation [When read] Conversion stopped/standby status
1	<b>Enables conversion operation</b> [When read] <b>While in the software trigger mode: Conversion operation status</b> <b>While in the hardware trigger wait mode: A/D power supply stabilization wait status + conversion operation status</b>

x in "Set value" of the above table indicates that the pertinent bit is not used in this function.

Note: For details of register settings, refer to the RL78/G14 User's Manual: Hardware.

(10) A/D conversion end interrupt

Figure 8.14 shows the flowchart for A/D conversion end interrupt processing.




Figure 8.14 A/D Conversion End Interrupt (example of migration from repeat sweep mode)

## 8.5 Sample Code

Sample code can be downloaded from the Renesas Electronics website.

## 8.6 Reference Application Note

- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: A/D Converter CC-RL (R01AN3059)
- RL78/G14, R8C/36M Group  
Migration Guide from R8C to RL78: Data Transfer Controller (R01AN1503)
- RL78/G14 How to Use the DTC for the RL78/G14 (R01AN0861)

## 8.7 Reference Documents

### User's Manual

- RL78/G14 User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- R8C/36M Group User's Manual: Hardware  
(The latest versions can be downloaded from the Renesas Electronics website.)
- Technical Update/Technical News  
(The latest information can be downloaded from the Renesas Electronics website.)

### Migration Guide

- Migration to CubeSuite+ Integrated Development Environment for RL78 Family  
(On-chip Debug) - Migration from R8C, M16C to RL78 (R20UT2150)

## Website and Support

Renesas Electronics Website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/contact/>

All trademarks and registered trademarks are the property of their respective owners.

## Revision History

Rev.	Date	Description	
		Page	Summary
1.00	Dec 21, 2017	—	First edition issued

## General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

### 1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

- The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

### 2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.  
In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

### 3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

- The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

### 4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

- When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

### 5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

- The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.



## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other disputes involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawing, chart, program, algorithm, application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics products.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.  
\*Standard\*: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.  
\*High Quality\*: Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.  
Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (space and undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
6. When using the Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat radiation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions or failure or accident arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please ensure to implement safety measures to guard them against the possibility of bodily injury, injury or damage caused by fire, and social damage in the event of failure or malfunction of Renesas Electronics products, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures by your own responsibility as warranty for your products/system. Because the evaluation of microcomputer software alone is very difficult and not practical, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please investigate applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive carefully and sufficiently and use Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall not use Renesas Electronics products or technologies for (1) any purpose relating to the development, design, manufacture, use, stockpiling, etc., of weapons of mass destruction, such as nuclear weapons, chemical weapons, or biological weapons, or missiles (including unmanned aerial vehicles (UAVs)) for delivering such weapons, (2) any purpose relating to the development, design, manufacture, or use of conventional weapons, or (3) any other purpose of disturbing international peace and security, and you shall not sell, export, lease, transfer, or release Renesas Electronics products or technologies to any third party whether directly or indirectly with knowledge or reason to know that the third party or any other party will engage in the activities described above. When exporting, selling, transferring, etc., Renesas Electronics products or technologies, you shall comply with any applicable export control laws and regulations promulgated and administered by the governments of the countries asserting jurisdiction over the parties or transactions.
10. Please acknowledge and agree that you shall bear all the losses and damages which are incurred from the misuse or violation of the terms and conditions described in this document, including this notice, and hold Renesas Electronics harmless, if such misuse or violation results from your resale or making Renesas Electronics products available any third party.
11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.3.0-1 November 2016)



### SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

#### Renesas Electronics America Inc.

2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130

#### Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3  
Tel: +1-905-237-2004

#### Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.  
Tel: +44-1628-585-100, Fax: +44-1628-585-900

#### Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

#### Renesas Electronics (China) Co., Ltd.

Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

#### Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333  
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

#### Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2265-6688, Fax: +852 2886-9022

#### Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan  
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

#### Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949  
Tel: +65-6213-0200, Fax: +65-6213-0300

#### Renesas Electronics Malaysia Sdn.Bhd.

Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jin Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

#### Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL II Stage, Indiranagar, Bangalore, India  
Tel: +91-80-67208700, Fax: +91-80-67208777

#### Renesas Electronics Korea Co., Ltd.

12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141